

SOLIDWORKS API (.NET VBA C#) — Reference

(66/337): IDatumOrigin-IDatumTag

SOLIDWORKS API Documentation (converted from CHM)

IDatumOrigin (Type)

IDatumOrigin Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDatumOrigin Interface

Allows access to datum origin annotations.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IDatumOrigin
```

Visual Basic (Usage)



```
Dim instance As IDatumOrigin
```

C#

```
public interface IDatumOrigin
```

C++/CLI

```
public interface class IDatumOrigin
```

Visual Basic for Applications (VBA) Syntax

See [DatumOrigin](#).

Example

[Get Labels of Datum Origin \(C#\)](#)
[Get Labels of Datum Origin \(VB.NET\)](#)
[Get Labels of Datum Origin \(VBA\)](#)

Accessors

[IAnnotation::GetSpecificAnnotation](#) and [IAnnotation::!GetSpecificAnnotation](#)
[IDatumOrigin::GetNext](#)
[IHoleTable::DatumOrigin](#)
[IView::GetFirstDatumOrigin](#)
[IView::GetDatumOrigins](#) and [IView::!GetDatumOrigins](#)

Access Diagram

[DatumOrigin](#)

See Also

[IDatumOrigin Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IDatumOrigin Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDatumOrigin Interface

The following tables list the members exposed by [IDatumOrigin](#).

Public Properties

Name	Description
 Table	Gets the hole table associated with this datum origin.
 XLabel	Gets or sets the label for the X axis for this datum origin.
 YLabel	Gets or sets the label for the Y axis for this datum origin.

[Top](#)

Public Methods

Name	Description
 GetAnnotation	Gets the IAnnotation object for this datum origin.
 GetAxisPoints	Obsolete. Superseded by IDatumOrigin.GetAxisPoints2 .
 GetAxisPoints2	Gets the points that define the geometry of this datum origin.
 GetNext	Gets the next datum origin in the view.
 IGetAxisPoints	Obsolete. Superseded by IDatumOrigin.IGetAxisPoints2 .
 IGetAxisPoints2	Gets the points that define the geometry of this datum origin.
 ISetAxisPoints	Sets the points that define the geometry of this datum origin.
 Reattach	Attaches the datum origin to a different entity.
 SetAxisPoints	Sets the points that define the geometry of this datum origin.

[Top](#)

See Also

[IDatumOrigin Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDatumOrigin Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDatumOrigin Interface

For a list of all members of this type, see [IDatumOrigin members](#).

Public Methods

Name	Description
 GetAnnotation	Gets the IAnnotation object for this datum origin.
 GetAxisPoints	Obsolete. Superseded by IDatumOrigin.GetAxisPoints2 .
 GetAxisPoints2	Gets the points that define the geometry of this datum origin.
 GetNext	Gets the next datum origin in the view.
 IGetAxisPoints	Obsolete. Superseded by IDatumOrigin.IGetAxisPoints2 .
 IGetAxisPoints2	Gets the points that define the geometry of this datum origin.
 ISetAxisPoints	Sets the points that define the geometry of this datum origin.
 Reattach	Attaches the datum origin to a different entity.
 SetAxisPoints	Sets the points that define the geometry of this datum origin.

[Top](#)

See Also

[IDatumOrigin Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDatumOrigin Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDatumOrigin Interface

For a list of all members of this type, see [IDatumOrigin members](#).

Public Properties

Name	Description
 Table	Gets the hole table associated with this datum origin.
 XLabel	Gets or sets the label for the X axis for this datum origin.
 YLabel	Gets or sets the label for the Y axis for this datum origin.

[Top](#)

See Also

[IDatumOrigin Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAnnotation Method (IDatumOrigin)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumOrigin Interface](#) : GetAnnotation Method (IDatumOrigin)

Gets the [IAnnotation](#) object for this datum origin.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAnnotation() As Annotation
```

Visual Basic (Usage)



```
Dim instance As IDatumOrigin  
Dim value As Annotation  
  
value = instance.GetAnnotation()
```

C#

```
Annotation GetAnnotation()
```

C++/CLI

```
Annotation^ GetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [IAnnotation](#) object for this annotation

Visual Basic for Applications (VBA) Syntax

See [DatumOrigin::GetAnnotation](#).

Example

[Get Annotation Object \(VBA\)](#)
[Get Annotation Object \(VB.NET\)](#)
[Get Annotation Object \(C#\)](#)

Remarks

The IAnnotation object is a higher-level object that contains methods that apply to all types of annotations.

See Also

[IDatumOrigin Interface](#)
[IDatumOrigin Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetAxisPoints Method (IDatumOrigin)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumOrigin Interface](#) : GetAxisPoints Method (IDatumOrigin)

Obsolete. Superseded by [IDatumOrigin::GetAxisPoints2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetAxisPoints() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDatumOrigin  
Dim value As System.Object  
  
value = instance.GetAxisPoints()
```

C#

```
System.object GetAxisPoints()
```

C++/CLI

```
System.Object^ GetAxisPoints();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DatumOrigin::GetAxisPoints](#).

See Also

[IDatumOrigin Interface](#)
[IDatumOrigin Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetAxisPoints2 Method (IDatumOrigin)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumOrigin Interface](#) : GetAxisPoints2 Method (IDatumOrigin)

Gets the points that define the geometry of this datum origin.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAxisPoints2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDatumOrigin  
Dim value As System.Object
```

```
value = instance.GetAxisPoints2()
```

C#

```
System.object GetAxisPoints2()
```

C++/CLI

```
System.Object^ GetAxisPoints2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of 8 doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DatumOrigin::GetAxisPoints2](#).

Remarks

The array of 8 doubles is 4 (X,Y) coordinates in drawing space:

- The first coordinate (array items 0 and 1) is the start of the X leader portion of the symbol.
- The second coordinate (array items 2 and 3) is the tip of the arrowhead on the X leader portion of the symbol.
- The third coordinate (array items 4 and 5) is the start of the Y leader portion of the symbol.
- The fourth coordinate (array items 6 and 7) is the tip of the arrowhead on the Y leader portion of the symbol.

See Also

[IDatumOrigin Interface](#)
[IDatumOrigin Members](#)
[IDatumOrigin::GetAxisPoints2 Method](#)
[IDatumOrigin::SetAxisPoints Method](#)
[IDatumOrigin::SetAxisPoints Method](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetNext Method (IDatumOrigin)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumOrigin Interface](#) : GetNext Method (IDatumOrigin)

Gets the next datum origin in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext() As DatumOrigin
```

Visual Basic (Usage)



```
Dim instance As IDatumOrigin  
Dim value As DatumOrigin
```

```
value = instance.GetNext()
```

C#

```
DatumOrigin GetNext()
```

C++/CLI

```
DatumOrigin^ GetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [datum origin](#) in the view

Visual Basic for Applications (VBA) Syntax

See [DatumOrigin::GetNext](#).

See Also

[IDatumOrigin Interface](#)
[IDatumOrigin Members](#)
[View::GetFirstDatumOrigin Method](#)
[IAnnotation::GetSpecificAnnotation Method](#)
[IAnnotation::IGetSpecificAnnotation Method](#)
[IHoleTable::DatumOrigin Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetAxisPoints Method (IDatumOrigin)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumOrigin Interface](#) : IGetAxisPoints Method (IDatumOrigin)

Obsolete. Superseded by [IDatumOrigin::IGetAxisPoints2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetAxisPoints() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDatumOrigin  
Dim value As System.Double
```

```
value = instance.IGetAxisPoints()
```

C#

```
System.double IGetAxisPoints()
```

C++/CLI

```
System.double IGetAxisPoints();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DatumOrigin::IGetAxisPoints](#).

See Also

[IDatumOrigin Interface](#)
[IDatumOrigin Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetAxisPoints2 Method (IDatumOrigin)

[See Also](#)



Gets the points that define the geometry of this datum origin.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetAxisPoints2() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDatumOrigin
Dim value As System.Double

value = instance.IGetAxisPoints2()
```

C#

```
System.double IGetAxisPoints2()
```

C++/CLI

```
System.double IGetAxisPoints2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of 8 doubles is 4 (X,Y) coordinates in drawing space:
 - The first coordinate (array items 0 and 1) is the start of the X leader portion of the symbol.
 - The second coordinate (array items 2 and 3) is the tip of the arrowhead on the X leader portion of the symbol.
 - The third coordinate (array items 4 and 5) is the start of the Y leader portion of the symbol.
 - The fourth coordinate (array items 6 and 7) is the tip of the arrowhead on the Y leader portion of the symbol.
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See Also

[IDatumOrigin Interface](#)
[IDatumOrigin Members](#)
[IDatumOrigin::GetAxisPoints2 Method](#)
[IDatumOrigin::SetAxisPoints Method](#)
[IDatumOrigin::SetAxisPoints Method](#)

Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetAxisPoints Method (IDatumOrigin)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > IDatumOrigin Interface : ISetAxisPoints Method (IDatumOrigin)

Sets the points that define the geometry of this datum origin.

.NET Syntax

Visual Basic (Declaration)

```
Function ISetAxisPoints( _
    ByRef PointData As System.Double _
) As System.Boolean
```

```
Dim instance As IDatumOrigin
Dim PointData As System.Double
Dim value As System.Boolean

value = instance.ISetAxisPoints(PointData)
```

C#

```
System.bool ISetAxisPoints(
    ref System.double PointData
)
```

C++/CLI

```
System.bool ISetAxisPoints(
    & System.double% PointData
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PointData

- in-process, unmanaged C++: Pointer to an array of 4 doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

True if the points are set, false if not

Remarks

This method gives you control over the shape of the symbol.

The array of 4 doubles is 2 (X,Y) coordinates in drawing space:

- The first coordinate (array items 0 and 1) is the tip of the arrowhead on the X leader portion of the symbol.
- The second coordinate (array items 2 and 3) is the tip of the arrowhead on the Y leader portion of the symbol.

The interactive user has this control via the selection drag handles of the symbol.

This method returns a BOOLEAN indicating success or failure of the operation. The operation can fail if either of the coordinates is so close to the symbol origin that the symbol cannot be drawn properly. There must be:

- Room to draw the arrow at the end of the origin leaders
- A gap between the symbol origin and the beginning of the first leader.

You can get:

- Coordinates of the symbol origin using [IAnnotation::GetPosition](#).
- Arrowhead length using [IModelDocExtension::GetUserPreferenceDouble](#) - swDetailingArrowWidth
- Gap using [IModelDocExtension::GetUserPreferenceDouble](#) - swDetailingWitnessLineGap

See Also

[IDatumOrigin Interface](#)
[IDatumOrigin Members](#)
[IDatumOrigin::SetAxisPoints Method](#)
[IDatumOrigin::GetAxisPoints2 Method](#)
[IDatumOrigin::IGetAxisPoints2 Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0



Attaches the datum origin to a different entity.

.NET Syntax

Visual Basic (Declaration)

```
Function Reattach() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDatumOrigin  
Dim value As System.Boolean  
  
value = instance.Reattach()
```

C#

```
System.bool Reattach()
```

C++/CLI

```
System.bool Reattach();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the datum origin is attached to a different entity, false if not

Visual Basic for Applications (VBA) Syntax

See [DatumOrigin::Reattach](#).

Remarks

This method:

- Lets you manipulate the datum origin. It attaches the datum origin to the currently selected entity.
- Expects that only one entity (vertex, edge, or sketch point) is selected. That selected entity must be in the same view as the original entity to which the datum origin was attached.

See Also

[IDatumOrigin Interface](#)
[IDatumOrigin Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetAxisPoints Method (IDatumOrigin)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumOrigin Interface](#) : SetAxisPoints Method (IDatumOrigin)

Sets the points that define the geometry of this datum origin.

.NET Syntax

Visual Basic (Declaration)

```
Function SetAxisPoints( _  
    ByVal PointData As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDatumOrigin  
Dim PointData As System.Object
```

```
Dim value As System.Boolean

value = instance.SetAxisPoints(PointData)
```

C#

```
System.bool SetAxisPoints(
    System.object PointData
)
```

C++/CLI

```
System.bool SetAxisPoints(
    & System.Object^ PointData
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PointData
Array of 4 doubles (see [Remarks](#))

Visual Basic for Applications (VBA) Syntax

See [DatumOrigin::SetAxisPoints](#).

Remarks

This method gives you control over the shape of the symbol.

The array of 4 doubles is 2 (X,Y) coordinates in drawing space:

- The first coordinate (array items 0 and 1) is the tip of the arrowhead on the X leader portion of the symbol.
- The second coordinate (array items 2 and 3) is the tip of the arrowhead on the Y leader portion of the symbol.

The interactive user has this control via the selection drag handles of the symbol.

This method returns a BOOLEAN indicating success or failure of the operation. The operation can fail if either of the coordinates is so close to the symbol origin that the symbol cannot be drawn properly. There must be:

- Room to draw the arrow at the end of the origin leaders
- A gap between the symbol origin and the beginning of the first leader.

You can get:

- Coordinates of the symbol origin using [IAnnotation::GetPosition](#).
- Arrowhead length using [IModelDocExtension::GetUserPreferenceDouble](#) - swDetailingArrowWidth
- Gap using [IModelDocExtension::GetUserPreferenceDouble](#) - swDetailingWitnessLineGap

See Also

[IDatumOrigin Interface](#)
[IDatumOrigin Members](#)
[IDatumOrigin::ISetAxisPoints Method](#)
[IDatumOrigin::IGetAxisPoints2 Method](#)
[IDatumOrigin::GetAxisPoints2 Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Table Property (IDatumOrigin)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumOrigin Interface](#) : Table Property (IDatumOrigin)

Gets the hole table associated with this datum origin.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Table As HoleTable

Visual Basic (Usage)



```
Dim instance As IDatumOrigin  
Dim value As HoleTable  
  
value = instance.Table
```

C#

```
HoleTable Table {get;}
```

C++/CLI

```
property HoleTable^ Table {  
    HoleTable^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pointer to the [IHoleTable](#) object associated with datum origin

Visual Basic for Applications (VBA) Syntax

See [DatumOrigin::Table](#).

See Also

[IDatumOrigin Interface](#)
[IDatumOrigin Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

XLabel Property (IDatumOrigin)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumOrigin Interface](#) : XLabel Property (IDatumOrigin)

Gets or sets the label for the X axis for this datum origin.

.NET Syntax

Visual Basic (Declaration)

Property XLabel As System.String

Visual Basic (Usage)



```
Dim instance As IDatumOrigin  
Dim value As System.String  
  
instance.XLabel = value  
value = instance.XLabel
```

C#

```
System.string XLabel {get; set;}
```

C++/CLI

```
property System.String^ XLabel {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Label for the X axis for this datum origin

Visual Basic for Applications (VBA) Syntax

See [DatumOrigin::XLabel](#).

Example

[Get Labels of Datum Origin \(C#\)](#)
[Get Labels of Datum Origin \(VB.NET\)](#)
[Get Labels of Datum Origin \(VBA\)](#)

See Also

[IDatumOrigin Interface](#)
[IDatumOrigin Members](#)
[IDatumOrigin::YLabel Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

YLabel Property (IDatumOrigin)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumOrigin Interface](#) : YLabel Property (IDatumOrigin)

Gets or sets the label for the Y axis for this datum origin.

.NET Syntax

Visual Basic (Declaration)

```
Property YLabel As System.String
```

Visual Basic (Usage)



```
Dim instance As IDatumOrigin
Dim value As System.String
```

```
instance.YLabel = value
```

```
value = instance.YLabel
```

C#

```
System.string YLabel {get; set;}
```

C++/CLI

```
property System.String^ YLabel {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Label for the Y axis for this datum origin

Visual Basic for Applications (VBA) Syntax

See [DatumOrigin::YLabel](#).

Example

[Get Labels of Datum Origin \(C#\)](#)
[Get Labels of Datum Origin \(VB.NET\)](#)
[Get Labels of Datum Origin \(VBA\)](#)

See Also

[IDatumOrigin Interface](#)
[IDatumOrigin Members](#)
[IDatumOrigin::XLabel Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

IDatumTag (Type)

IDatumTag Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDatumTag Interface

Allows access to display information for datum tags.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IDatumTag
```

Visual Basic (Usage)



```
Dim instance As IDatumTag
```

C#

```
public interface IDatumTag
```

C++/CLI

```
public interface class IDatumTag
```

Visual Basic for Applications (VBA) Syntax

See [DatumTag](#).

Example

[Set Text in Datum Tags and GTols \(C#\)](#)
[Set Text in Datum Tags and GTols \(VB.NET\)](#)
[Set Text in Datum Tags and GTols \(VBA\)](#)

Accessors

[IAnnotation::GetSpecificAnnotation](#) and [IAnnotation::IGetSpecificAnnotation](#)
[IDatumTag::GetNext](#) and [IDatumTag::IGetNext](#)
[IModelDoc2::InsertDatumTag2](#) and [IModelDoc2::IInsertDatumTag2](#)
[IView::GetFirstDatumTag](#) and [IView::IGetFirstDatumTag](#)
[IView::GetDatumTags](#) and [IView::IGetDatumTags](#)

Access Diagram

[DatumTag](#)

See Also

[IDatumTag Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IDatumTag Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDatumTag Interface

The following tables list the members exposed by [IDatumTag](#).

Public Properties

Name	Description
 FilledTriangle	Gets or sets whether a filled triangle or empty triangle attaches to the model on the leader for this datum feature symbol.
 ForcedShoulder	Gets whether this datum tag has a forced shoulder on its leader.
 LeaderOrientation	Gets or sets the orientation of the leader for a round datum tag.
 Shoulder	Gets whether there is a shoulder (or bend) in the leader for this datum tag.

[Top](#)

Public Methods

Name	Description
 GetAnnotation	Gets the IAnnotation object for this datum tag.
 GetArcAtIndex	Gets information for the specified arc for this datum tag.
 GetArcCount	Gets the number of arc items in this datum tag.
 GetArrowHeadAtIndex	Gets information on the specified arrow head in this datum tag.
 GetArrowHeadCount	Gets the number of arrow heads in the datum tag.
 GetDisplayStyle	Gets the display style of this datum tag.
 GetLabel	Gets the label for this datum tag.
 GetLineAtIndex	Gets information for the specified line in this datum tag.
 GetLineCount	Gets the number of lines in this datum tag.
 GetNext	Gets the next datum tag in the view.
 GetTextAngleAtIndex	Gets the text angle for the specified text in this datum tag.
 GetTextAtIndex	Gets the specified text from this datum tag.
 GetTextCount	Gets the number of text items in the datum tag.
 GetTextHeightAtIndex	Gets the height of the specified text in this datum tag.
 GetTextInvertAtIndex	Gets the specified text item's invert flag.
 GetTextPositionAtIndex	Gets the text item's offset relative to note's text point.
 GetTextRefPositionAtIndex	Gets the reference position of the specified text item in this datum tag.
 GetTriangleAtIndex	Gets the triangle at the specified index of this datum tag.
 GetTriangleCount	Gets the number of triangles in this datum tag.
 GetUseDocDisplayStyle	Gets whether this datum tag uses the document setting for its display style.
 IGetAnnotation	Gets the IAnnotation object for this datum feature symbol annotation.
 IGetArcAtIndex	Gets information for the specified arc.
 IGetArrowHeadAtIndex	Gets information for the specified arrow head in this datum tag.
 IGetLineAtIndex	Gets information for the specified line in this datum tag.
 IGetNext	Gets the next datum tag in the view.
 IGetTextPositionAtIndex	Gets the text item's offset relative to note's text point.
 IGetTriangleAtIndex	Gets the triangle at the specified index of this datum tag.
 SetDisplayStyle	Sets the display style of this datum tag.
 SetLabel	Sets the label for this datum tag.
 SetText	Sets the text of this datum tag.

[Top](#)

See Also

[IDatumTag Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IDatumTag Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDatumTag Interface

For a list of all members of this type, see [IDatumTag members](#).

Public Methods

Name	Description
GetAnnotation	Gets the IAnnotation object for this datum tag.
GetArcAtIndex	Gets information for the specified arc for this datum tag.
GetArcCount	Gets the number of arc items in this datum tag.
GetArrowHeadAtIndex	Gets information on the specified arrow head in this datum tag.
GetArrowHeadCount	Gets the number of arrow heads in the datum tag.
GetDisplayStyle	Gets the display style of this datum tag.
GetLabel	Gets the label for this datum tag.
GetLineAtIndex	Gets information for the specified line in this datum tag.
GetLineCount	Gets the number of lines in this datum tag.
GetNext	Gets the next datum tag in the view.
GetTextAngleAtIndex	Gets the text angle for the specified text in this datum tag.
GetTextAtIndex	Gets the specified text from this datum tag.
GetTextCount	Gets the number of text items in the datum tag.
GetTextHeightAtIndex	Gets the height of the specified text in this datum tag.
GetTextInvertAtIndex	Gets the specified text item's invert flag.
GetTextPositionAtIndex	Gets the text item's offset relative to note's text point.
GetTextRefPositionAtIndex	Gets the reference position of the specified text item in this datum tag.
GetTriangleAtIndex	Gets the triangle at the specified index of this datum tag.
GetTriangleCount	Gets the number of triangles in this datum tag.
GetUseDocDisplayStyle	Gets whether this datum tag uses the document setting for its display style.
IGetAnnotation	Gets the IAnnotation object for this datum feature symbol annotation.
IGetArcAtIndex	Gets information for the specified arc.
IGetArrowHeadAtIndex	Gets information for the specified arrow head in this datum tag.
IGetLineAtIndex	Gets information for the specified line in this datum tag.
IGetNext	Gets the next datum tag in the view.
IGetTextPositionAtIndex	Gets the text item's offset relative to note's text point.
IGetTriangleAtIndex	Gets the triangle at the specified index of this datum tag.
SetDisplayStyle	Sets the display style of this datum tag.
SetLabel	Sets the label for this datum tag.
SetText	Sets the text of this datum tag.

[Top](#)

See Also

[IDatumTag Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IDatumTag Interface

For a list of all members of this type, see [IDatumTag members](#).

 Public Properties

Name	Description
 FilledTriangle	Gets or sets whether a filled triangle or empty triangle attaches to the model on the leader for this datum feature symbol.
 ForcedShoulder	Gets whether this datum tag has a forced shoulder on its leader.
 LeaderOrientation	Gets or sets the orientation of the leader for a round datum tag.
 Shoulder	Gets whether there is a shoulder (or bend) in the leader for this datum tag.

[Top](#)

 See Also

[IDatumTag Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

FilledTriangle Property (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : FilledTriangle Property (IDatumTag)

Gets or sets whether a filled triangle or empty triangle attaches to the model on the leader for this datum feature symbol.

 .NET Syntax

Visual Basic (Declaration)

Property FilledTriangle As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDatumTag
Dim value As System.Boolean

instance.FilledTriangle = value
value = instance.FilledTriangle
```

C#

```
System.bool FilledTriangle {get; set;}
```

C++/CLI

```
property System.bool FilledTriangle {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if this datum tag has a filled triangle, false if an empty triangle

 Visual Basic for Applications (VBA) Syntax

See [DatumTag::FilledTriangle](#).

 See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)

[IDatumTag::GetTriangleAtIndex Method](#)
[IDatumTag::GetTriangleCount Method](#)
[IDatumTag::IGetTriangleAtIndex Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ForcedShoulder Property (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : ForcedShoulder Property (IDatumTag)

Gets whether this datum tag has a forced shoulder on its leader.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property ForcedShoulder As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDatumTag
Dim value As System.Boolean

value = instance.ForcedShoulder
```

C#

```
System.bool ForcedShoulder {get;}
```

C++/CLI

```
property System.bool ForcedShoulder {
    System.bool get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the datum tag has a forced shoulder on its leader, false if not

Visual Basic for Applications (VBA) Syntax

See [DatumTag::ForcedShoulder](#).

Remarks

If a square tag is attached to an edge that is not at a 0 or 90 angle, then the leader will always have a shoulder (bent leader). The user cannot remove the shoulder.

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::Shoulder Property](#)

Availability

SOLIDWORKS 2006 SP4, Revision Number 14.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAnnotation Method (IDatumTag)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : GetAnnotation Method (IDatumTag)

Gets the [IAnnotation](#) object for this datum tag.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAnnotation() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim value As System.Object  
  
value = instance.GetAnnotation()
```

C#

```
System.object GetAnnotation()
```

C++/CLI

```
System.Object^ GetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Annotation

Visual Basic for Applications (VBA) Syntax

See [DatumTag::GetAnnotation](#).

Example

[Get Annotation Object \(VBA\)](#)
[Get Annotation Object \(VB.NET\)](#)
[Get Annotation Object \(C#\)](#)

Remarks

The [IAnnotation](#) object is a higher-level object that contains methods that apply to all types of annotations.

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::IGetAnnotation Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetArcAtIndex Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : GetArcAtIndex Method (IDatumTag)

Gets information for the specified arc for this datum tag.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArcAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

```
Dim instance As IDatumTag
Dim Index As System.Integer
Dim value As System.Object

value = instance.GetArcAtIndex(Index)
```

C#

```
System.object GetArcAtIndex(
    System.int Index
)
```

C++/CLI

```
System.Object^ GetArcAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the arc; index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DatumTag::GetArcAtIndex](#).

Remarks

The return value is the following array of doubles :

[*lineType*, *startPt*[3], *endPt*[3], *centerPt*[3], *rotationDir*]

where:

<i>lineType</i>	Line type as defined in swLineTypes_e
<i>startPt</i> [3]	XYZ arc start point
<i>endPt</i> [3]	XYZ arc end point
<i>centerPt</i> [3]	XYZ arc center point
<i>rotationDir</i>	Boolean returned as a double that represents the rotation direction, where CCW = True and CW = false

Before calling this method, call [IDatumTag::GetArcCount](#) to find out the number of arcs in this datum tag.

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::IGetArcAtIndex Method](#)
[IDatumTag::GetArcCount Method](#)

GetArcCount Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : GetArcCount Method (IDatumTag)

Gets the number of arc items in this datum tag.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArcCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim value As System.Integer  
  
value = instance.GetArcCount()
```

C#

```
System.int GetArcCount()
```

C++/CLI

```
System.int GetArcCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of arcs

Visual Basic for Applications (VBA) Syntax

See [DatumTag::GetArcCount](#).

Remarks

Call this method before calling [IDatumTag::GetArcAtIndex](#) or [IDatumTag::!GetArcAtIndex](#).

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::GetArcAtIndex Method](#)
[IDatumTag::!GetArcAtIndex Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetArrowHeadAtIndex Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : GetArrowHeadAtIndex Method (IDatumTag)

Gets information on the specified arrow head in this datum tag.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArrowHeadAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetArrowHeadAtIndex(Index)
```

C#

```
System.object GetArrowHeadAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetArrowHeadAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the arrow head; index begins at 0

Return Value

Array of doubles (see **Remarks**)

 Visual Basic for Applications (VBA) Syntax

See [DatumTag::GetArrowHeadAtIndex](#).

 Remarks

The return value is the following array of doubles :

[*arrowHeadPt[3]*, *arrowHeadDir[3]*, *arrowHeadWidth*, *arrowHeadHeight*, *arrowHeadStyle*]

where:

<i>arrowHeadPt[3]</i>	XYZ arrow head tip location
<i>arrowHeadDir[3]</i>	XYZ arrow head direction
<i>arrowHeadWidth</i>	Arrow head width where the width is measured along the arrow head direction
<i>arrowHeadHeight</i>	Arrow head height
<i>arrowHeadStyle</i>	Arrow head style as defined in swArrowStyle_e

 See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::IGetArrowHeadAtIndex Method](#)
[IDatumTag::GetArrowHeadCount Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetArrowHeadCount Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : GetArrowHeadCount Method (IDatumTag)

Gets the number of arrow heads in the datum tag.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetArrowHeadCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim value As System.Integer  
  
value = instance.GetArrowHeadCount()
```

C#

```
System.int GetArrowHeadCount()
```

C++/CLI

```
System.int GetArrowHeadCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of arrow heads

Visual Basic for Applications (VBA) Syntax

See [DatumTag::GetArrowHeadCount](#).

See Also

[IDatumTag Interface](#)

[IDatumTag Members](#)

[IDatumTag::GetArrowHeadAtIndex Method](#)

[IDatumTag::IGetArrowHeadAtIndex Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDisplayStyle Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : GetDisplayStyle Method (IDatumTag)

Gets the display style of this datum tag.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayStyle() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim value As System.Integer
```

```
value = instance.GetDisplayStyle()
```

C#

```
System.int GetDisplayStyle()
```

C++/CLI

```
System.int GetDisplayStyle();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Display style as defined in [swDatumDisplayType_e](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DatumTag::GetDisplayStyle](#).

Remarks

This method does not return `swDatumDisplayType_Default` if the datum tag is set to use the document default setting. Instead, either `swDatumDisplayType_Roundgb` or `swDatumDisplayType_Square` is returned.

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::GetUseDocDisplayStyle Method](#)
[IDatumTag::SetDisplayStyle Method](#)

Availability

SOLIDWORKS 2006 SP4, Revision Number 14.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLabel Method (IDatumTag)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : GetLabel Method (IDatumTag)

Gets the label for this datum tag.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLabel() As System.String
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim value As System.String  
  
value = instance.GetLabel()
```

C#

```
System.string GetLabel()
```

C++/CLI

```
System.String^ GetLabel();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Text string

Visual Basic for Applications (VBA) Syntax

See [DatumTag::GetLabel](#).

Example

[Set Text in Datum Tags and GTols \(C#\)](#)
[Set Text in Datum Tags and GTols \(VB.NET\)](#)
[Set Text in Datum Tags and GTols \(VBA\)](#)

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::SetLabel Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLineAtIndex Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : GetLineAtIndex Method (IDatumTag)

Gets information for the specified line in this datum tag.

■.NET Syntax

Visual Basic (Declaration)

```
Function GetLineAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetLineAtIndex(Index)
```

C#

```
System.object GetLineAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetLineAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the line; index begins at 0

Return Value

Array of doubles (see **Remarks**)

■Visual Basic for Applications (VBA) Syntax

See [DatumTag::GetLineAtIndex](#).

■Remarks

The return value is the following array of doubles :

[*lineType*, *startPt*[3], *endPt*[3]]

where:

<i>lineType</i>	Line type as defined in swLineTypes_e
<i>startPt</i> [3]	XYZ line start point
<i>endPt</i> [3]	XYZ line end point

■See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::GetLineAtIndex Method](#)
[IDatumTag::GetLineCount Method](#)



Gets the number of lines in this datum tag.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLineCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDatumTag
Dim value As System.Integer

value = instance.GetLineCount()
```

C#

```
System.int GetLineCount()
```

C++/CLI

```
System.int GetLineCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of lines

Visual Basic for Applications (VBA) Syntax

See [DatumTag::GetLineCount](#).

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::GetLineAtIndex Method](#)
[IDatumTag::GetLineAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNext Method (IDatumTag)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > IDatumTag Interface : GetNext Method (IDatumTag)

Gets the next datum tag in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDatumTag
Dim value As System.Object

value = instance.GetNext()
```

C#

```
System.object GetNext()
```

C++/CLI

```
System.Object^ GetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next datum tag

Visual Basic for Applications (VBA) Syntax

See [DatumTag::GetNext](#).

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::IGetNext Method](#)
[IView::GetFirstDatumTag Method](#)
[IAnnotation::GetSpecificAnnotation Method](#)
[IAnnotation::IGetSpecificAnnotation Method](#)
[IModelDoc2::InsertDatumTag2 Method](#)
[IModelDoc2::InsertDatumTag2 Method](#)
[IModelDoc2::IGetFirstDatumTag Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextAngleAtIndex Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : GetTextAngleAtIndex Method (IDatumTag)

Gets the text angle for the specified text in this datum tag.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextAngleAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.GetTextAngleAtIndex(Index)
```

C#

```
System.double GetTextAngleAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double GetTextAngleAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the text; index begins at 0

Return Value

Text angle for the specified piece of text in radians measured CCW from the X-axis

Visual Basic for Applications (VBA) Syntax

See [DatumTag::GetTextAngleAtIndex](#).

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::GetTextAtIndex Method](#)
[IDatumTag::GetTextCount Method](#)
[IDatumTag::GetTextHeightAtIndex Method](#)
[IDatumTag::GetTextInvertAtIndex Method](#)
[IDatumTag::GetTextPositionAtIndex Method](#)
[IDatumTag::GetTextRefPositionAtIndex Method](#)
[IDatumTag::IGetTextPositionAtIndex Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextAtIndex Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : GetTextAtIndex Method (IDatumTag)

Gets the specified text from this datum tag.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextAtIndex( _  
    ByVal Index As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim Index As System.Integer  
Dim value As System.String  
  
value = instance.GetTextAtIndex(Index)
```

C#

```
System.string GetTextAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.String^ GetTextAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the text; index begins at 0

Return Value

Text string for the specified piece of text

Visual Basic for Applications (VBA) Syntax

See [DatumTag::GetTextAtIndex](#).

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::GetTextAngleAtIndex Method](#)
[IDatumTag::GetTextCount Method](#)
[IDatumTag::GetTextHeightAtIndex Method](#)
[IDatumTag::GetTextInvertAtIndex Method](#)
[IDatumTag::GetTextPositionAtIndex Method](#)
[IDatumTag::GetTextRefPositionAtIndex Method](#)
[IDatumTag::IGetTextPositionAtIndex Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextCount Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : GetTextCount Method (IDatumTag)

Gets the number of text items in the datum tag.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim value As System.Integer  
  
value = instance.GetTextCount()
```

C#

```
System.int GetTextCount()
```

C++/CLI

```
System.int GetTextCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of text items

Visual Basic for Applications (VBA) Syntax

See [DatumTag::GetTextCount](#).

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::GetTextAngleAtIndex Method](#)
[IDatumTag::GetTextAtIndex Method](#)
[IDatumTag::GetTextHeightAtIndex Method](#)
[IDatumTag::GetTextInvertAtIndex Method](#)
[IDatumTag::GetTextPositionAtIndex Method](#)
[IDatumTag::GetTextRefPositionAtIndex Method](#)
[IDatumTag::GetTextPositionAtIndex Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextHeightAtIndex Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : GetTextHeightAtIndex Method (IDatumTag)

Gets the height of the specified text in this datum tag.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextHeightAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim Index As System.Integer  
Dim value As System.Double
```

```
value = instance.GetTextHeightAtIndex(Index)
```

C#

```
System.double GetTextHeightAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double GetTextHeightAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the text; index begins at 0

Return Value

Height of the specified text in meters

Visual Basic for Applications (VBA) Syntax

See [DatumTag::GetTextHeightAtIndex](#).

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::GetTextAngleAtIndex Method](#)
[IDatumTag::GetTextAtIndex Method](#)
[IDatumTag::GetTextCount Method](#)
[IDatumTag::GetTextInvertAtIndex Method](#)
[IDatumTag::GetTextPositionAtIndex Method](#)
[IDatumTag::GetTextRefPositionAtIndex Method](#)
[IDatumTag::IGetTextPositionAtIndex Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextInvertAtIndex Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : GetTextInvertAtIndex Method (IDatumTag)

Gets the specified text item's invert flag.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextInvertAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim Index As System.Integer  
Dim value As System.Integer
```

```
value = instance.GetTextInvertAtIndex(Index)
```

C#

```
System.int GetTextInvertAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.int GetTextInvertAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the text; index begins at 0

Return Value

Text item's invert flag

Visual Basic for Applications (VBA) Syntax

See [DatumTag::GetTextInvertAtIndex](#).

Remarks

The invert flag specifies whether the text was mirrored (reflected) about the X axis. Any reflection is applied after text rotation.

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::GetTextAngleAtIndex Method](#)
[IDatumTag::GetTextAtIndex Method](#)
[IDatumTag::GetTextCount Method](#)
[IDatumTag::GetTextHeightAtIndex Method](#)
[IDatumTag::GetTextPositionAtIndex Method](#)
[IDatumTag::GetTextRefPositionAtIndex Method](#)
[IDatumTag::GetTextPositionAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextPositionAtIndex Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : GetTextPositionAtIndex Method (IDatumTag)

Gets the text item's offset relative to note's text point.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextPositionAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetTextPositionAtIndex(Index)
```

C#

```
System.object GetTextPositionAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetTextPositionAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the text; index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DatumTag::GetTextPositionAtIndex](#).

Remarks

The return value is the following array of doubles :

[*textPtX*, *textPtY*, *textPtZ*]

where these text position values are offset values from the origin of this datum tag object.

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::GetTextPositionAtIndex Method](#)
[IDatumTag::GetTextAngleAtIndex Method](#)
[IDatumTag::GetTextAtIndex Method](#)
[IDatumTag::GetTextCount Method](#)
[IDatumTag::GetTextHeightAtIndex Method](#)
[IDatumTag::GetTextInvertAtIndex Method](#)
[IDatumTag::GetTextRefPositionAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextRefPositionAtIndex Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : GetTextRefPositionAtIndex Method (IDatumTag)

Gets the reference position of the specified text item in this datum tag.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextRefPositionAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim Index As System.Integer  
Dim value As System.Integer
```

```
value = instance.GetTextRefPositionAtIndex(Index)
```

C#

```
System.int GetTextRefPositionAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.int GetTextRefPositionAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the text; index begins at 0

Return Value

Reference position of the specified text item as defined in [swTextPosition_e](#)

Visual Basic for Applications (VBA) Syntax

See [DatumTag::GetTextRefPositionAtIndex](#).

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::GetTextAngleAtIndex Method](#)
[IDatumTag::GetTextAtIndex Method](#)
[IDatumTag::GetTextCount Method](#)
[IDatumTag::GetTextHeightAtIndex Method](#)
[IDatumTag::GetTextInvertAtIndex Method](#)
[IDatumTag::GetTextPositionAtIndex Method](#)
[IDatumTag::IGetTextPositionAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTriangleAtIndex Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : GetTriangleAtIndex Method (IDatumTag)

Gets the triangle at the specified index of this datum tag.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTriangleAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetTriangleAtIndex(Index)
```

C#

```
System.object GetTriangleAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetTriangleAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of triangle; index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DatumTag::GetTriangleAtIndex](#).

Remarks

The return value is the following array of doubles:

[*vertexPt1*[3], *vertexPt2*[3], *vertexPt3*[3], *isFilled*, *lineType*]

where:

<i>vertexPt1</i> [3]	First XYZ vertex point
<i>vertexPt2</i> [3]	Second XYZ vertex point
<i>vertexPt3</i> [3]	Third XYZ vertex point
<i>isFilled</i>	Boolean returned as a double that is True if the triangle is filled, false if it is not
<i>lineType</i>	Line type as defined in swLineTypes_e

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::GetTriangleAtIndex Method](#)
[IDatumTag::GetTriangleCount Method](#)
[IDatumTag::GetTriangleAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTriangleCount Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : GetTriangleCount Method (IDatumTag)

Gets the number of triangles in this datum tag.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTriangleCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim value As System.Integer  
  
value = instance.GetTriangleCount()
```

C#

```
System.int GetTriangleCount()
```

C++/CLI

```
System.int GetTriangleCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of triangles

Visual Basic for Applications (VBA) Syntax

See [DatumTag::GetTriangleCount](#).

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::GetTriangleAtIndex Method](#)

GetUseDocDisplayStyle Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : GetUseDocDisplayStyle Method (IDatumTag)

Gets whether this datum tag uses the document setting for its display style.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUseDocDisplayStyle() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim value As System.Boolean  
  
value = instance.GetUseDocDisplayStyle()
```

C#

```
System.bool GetUseDocDisplayStyle()
```

C++/CLI

```
System.bool GetUseDocDisplayStyle();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True to use the document setting for the datum feature symbol's display style, false to use local display style

Visual Basic for Applications (VBA) Syntax

See [DatumTag::GetUseDocDisplayStyle](#).

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::GetDisplayStyle Method](#)
[IDatumTag::SetDisplayStyle Method](#)

Availability

SOLIDWORKS 2006 SP4, Revision Number 14.4

IGetAnnotation Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : IGetAnnotation Method (IDatumTag)

Gets the [IAnnotation](#) object for this datum feature symbol annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetAnnotation() As Annotation
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim value As Annotation
```

```
value = instance.IGetAnnotation()
```

C#

```
Annotation IGetAnnotation()
```

C++/CLI

```
Annotation^ IGetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [IAnnotation](#) object

Visual Basic for Applications (VBA) Syntax

See [DatumTag::IGetAnnotation](#).

Remarks

The IAnnotation object is a higher-level object that contains methods that apply to all types of annotations.

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::GetAnnotation Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetArcAtIndex Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : IGetArcAtIndex Method (IDatumTag)

Gets information for the specified arc.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetArcAtIndex(  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetArcAtIndex(Index)
```

C#

```
System.double IGetArcAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetArcAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the arc; index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DatumTag::IGetArcAtIndex](#).

Remarks

The return value is the following array of doubles :

[*lineType*, *startPt*[3], *endPt*[3], *centerPt*[3], *rotationDir*]

where:

<i>lineType</i>	Line type as defined in swLineTypes_e
<i>startPt</i> [3]	XYZ arc start point
<i>endPt</i> [3]	XYZ arc end point
<i>centerPt</i> [3]	XYZ arc center point
<i>rotationDir</i>	Boolean returned as a double that represents the rotation direction, where CCW = True and CW = false

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::GetArcAtIndex Method](#)
[IDatumTag::GetArcCount Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetArrowHeadAtIndex Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : IGetArrowHeadAtIndex Method (IDatumTag)

Gets information for the specified arrow head in this datum tag.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetArrowHeadAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)

```
Dim instance As IDatumTag  
Dim Index As System.Integer  
Dim value As System.Double
```

```
value = instance.IGetArrowHeadAtIndex(Index)
```

C#



```
System.double IGetArrowHeadAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetArrowHeadAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the arrow head; index begins at 0

Return Value

Pointer to an array of doubles (see **Remarks**)

 Visual Basic for Applications (VBA) Syntax

See [DatumTag::IGetArrowHeadAtIndex](#).

 Remarks

The return value is the following array of doubles :

[*arrowHeadPt[3]*, *arrowHeadDir[3]*, *arrowHeadWidth*, *arrowHeadHeight*, *arrowHeadStyle*]

where:

<i>arrowHeadPt[3]</i>	XYZ arrow head tip location
<i>arrowHeadDir[3]</i>	XYZ arrow head direction
<i>arrowHeadWidth</i>	Arrow head width where the width is measured along the arrow head direction
<i>arrowHeadHeight</i>	Arrow head height
<i>arrowHeadStyle</i>	Arrow head style as defined in swArrowStyle_e

 See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::IGetArrowHeadAtIndex Method](#)
[IDatumTag::IGetArrowHeadCount Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetLineAtIndex Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : IGetLineAtIndex Method (IDatumTag)

Gets information for the specified line in this datum tag.

 .NET Syntax

Visual Basic (Declaration)

```
Function IGetLineAtIndex(  
    ByVal Index As System.Integer  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetLineAtIndex(Index)
```

C#

```
System.double IGetLineAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetLineAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the line; index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DatumTag::IGetLineAtIndex](#).

Remarks

The return value is the following array of doubles :

[*lineType*, *startPt*[3], *endPt*[3]]

where:

<i>lineType</i>	Line type as defined in swLineTypes_e
<i>startPt</i> [3]	XYZ line start point
<i>endPt</i> [3]	XYZ line end point

Call [IDatumTag::GetLineCount](#) before calling this method.

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::GetLineCount Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetNext Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : IGetNext Method (IDatumTag)

Gets the next datum tag in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNext() As DatumTag
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim value As DatumTag  
  
value = instance.IGetNext()
```

C#

```
DatumTag IGetNext()
```

C++/CLI

```
DatumTag^ IGetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the next [datum tag](#)

Visual Basic for Applications (VBA) Syntax

See [DatumTag::IGetNext](#).

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatum::GetNext Method](#)
[IView::GetFirstDatumTag Method](#)
[IView::IGetFirstDatumTag Method](#)
[IModelDoc2::InsertDatumTag2 Method](#)
[IModelDoc2::InsertDatumTag2 Method](#)
[IAnnotation::GetSpecificAnnotation Method](#)
[IAnnotation::IGetSpecificAnnotation Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTextPositionAtIndex Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : IGetTextPositionAtIndex Method (IDatumTag)

Gets the text item's offset relative to note's text point.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTextPositionAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetTextPositionAtIndex(Index)
```

C#

```
System.double IGetTextPositionAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetTextPositionAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the text; index begins at 0

Return Value

Pointer to an array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DatumTag::IGetTextPositionAtIndex](#).

Remarks

The return value is the following array of doubles :

[*textPtX*, *textPtY*, *textPtZ*]

where these text position values are offset values from the origin of this datum tag object.

Call [IDatumTag::GetTextCount](#) before calling this method.

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::GetTextPositionAtIndex Method](#)
[IDatumTag::GetTextAngleAtIndex Method](#)
[IDatumTag::GetTextAtIndex Method](#)
[IDatumTag::GetTextCount Method](#)
[IDatumTag::GetTextHeightAtIndex Method](#)
[IDatumTag::GetTextInvertAtIndex Method](#)
[IDatumTag::GetTextPositionAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetTriangleAtIndex Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : IGetTriangleAtIndex Method (IDatumTag)

Gets the triangle at the specified index of this datum tag.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTriangleAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetTriangleAtIndex(Index)
```

C#

```
System.double IGetTriangleAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetTriangleAtIndex(  
    & System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of triangle; index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DatumTag::IGetTriangleAtIndex](#).

Remarks

The return value is the following array of doubles:

[*vertexPt1*[3], *vertexPt2*[3], *vertexPt3*[3], *isFilled*, *lineType*]

where:

<i>vertexPt1</i> [3]	First XYZ vertex point
<i>vertexPt2</i> [3]	Second XYZ vertex point
<i>vertexPt3</i> [3]	Third XYZ vertex point
<i>isFilled</i>	Boolean returned as a double that is True if the triangle is filled, false if it is not
<i>lineType</i>	Line type as defined in swLineTypes_e

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::GetTriangleAtIndex Method](#)
[IDatumTag::GetTriangleCount Method](#)
[IDatumTag::FilledTriangle Property](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

LeaderOrientation Property (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : LeaderOrientation Property (IDatumTag)

Gets or sets the orientation of the leader for a round datum tag.

.NET Syntax

Visual Basic (Declaration)

Property LeaderOrientation As System.Integer

Visual Basic (Usage)



```
Dim instance As IDatumTag
Dim value As System.Integer

instance.LeaderOrientation = value

value = instance.LeaderOrientation
```

C#

```
System.int LeaderOrientation {get; set;}
```

C++/CLI

```
property System.int LeaderOrientation {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Orientation as defined in [swDatumGbLeaderStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [DatumTag::LeaderOrientation](#).

Remarks

Although you get or set this property at any time, this property only applies to round datum tags. If you use it when a square datum tag is shown, you will not see a value for the current display.

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)

Availability

SOLIDWORKS 2006 SP4, Revision Number 14.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDisplayStyle Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : SetDisplayStyle Method (IDatumTag)

Sets the display style of this datum tag.

.NET Syntax

Visual Basic (Declaration)

```
Function SetDisplayStyle( _  
    ByVal UseDoc As System.Boolean, _  
    ByVal Style As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim UseDoc As System.Boolean  
Dim Style As System.Integer  
Dim value As System.Boolean  
  
value = instance.SetDisplayStyle(UseDoc, Style)
```

C#

```
System.bool SetDisplayStyle(  
    System.bool UseDoc,  
    System.int Style  
)
```

C++/CLI

```
System.bool SetDisplayStyle(  
& System.bool UseDoc,  
& System.int Style  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDoc

True to use the document setting for the datum tag's display style, false to not

Style

Display style as defined in [swDatumDisplayType_e](#)

Return Value

True if the specified display style is set, false if not

Visual Basic for Applications (VBA) Syntax

See [DatumTag::SetDisplayStyle](#).

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::GetDisplayStyle Method](#)
[IDatumTag::GetUseDocDisplayStyle Method](#)

Availability

SOLIDWORKS 2006 SP4, Revision Number 14.4

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetLabel Method (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : SetLabel Method (IDatumTag)

Sets the label for this datum tag.

.NET Syntax

Visual Basic (Declaration)

```
Function SetLabel(_  
    ByVal Label As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim Label As System.String  
Dim value As System.Boolean  
  
value = instance.SetLabel(Label)
```

C#

```
System.bool SetLabel(  
    System.string Label  
)
```

C++/CLI

```
System.bool SetLabel(  
& System.String^ Label  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Label
Text string

Return Value

True if the label was successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [DatumTag::SetLabel](#).

Remarks

The label can consist of up to two characters. If the specified label is more than two characters long, SOLIDWORKS does not change the symbol and returns false.

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag::GetLabel Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetText Method (IDatumTag)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : SetText Method (IDatumTag)

Sets the text of this datum tag.

.NET Syntax

Visual Basic (Declaration)

```
Function SetText( _  
    ByVal WhichText As System.Integer, _  
    ByVal Text As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim WhichText As System.Integer  
Dim Text As System.String  
Dim value As System.Boolean  
  
value = instance.SetText(WhichText, Text)
```

C#

```
System.bool SetText(  
    System.int WhichText,  
    System.string Text  
)
```

C++/CLI

```
System.bool SetText(  
& System.int WhichText,  
& System.String^ Text  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichText

Text to set as defined in [swDatumTagTextParts](#) e

Text

New content for the specified WhichText

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DatumTag::SetText](#).

Example

[Set Text in Datum Tags and GTols \(VBA\)](#)
[Set Text in Datum Tags and GTols \(VB.NET\)](#)
[Set Text in Datum Tags and GTols \(C#\)](#)

Remarks

After calling this method, call [IModelView::GraphicsRedraw](#) to see the new text.

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)

Availability

SOLIDWORKS 2011 SP03, Revision Number 19.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

Shoulder Property (IDatumTag)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTag Interface](#) : Shoulder Property (IDatumTag)

Gets whether there is a shoulder (or bend) in the leader for this datum tag.

.NET Syntax

Visual Basic (Declaration)

Property Shoulder As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDatumTag  
Dim value As System.Boolean  
  
instance.Shoulder = value  
  
value = instance.Shoulder
```

C#

```
System.bool Shoulder {get; set;}
```

C++/CLI

```
property System.bool Shoulder {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if this datum tag has a shoulder, false if not

Visual Basic for Applications (VBA) Syntax

See [DatumTag::Shoulder](#).

Remarks

Although you get or set this property at any time, this property only applies to square datum tags. If you use it when a round datum tag is shown, you will not see a value for the current display.

See Also

[IDatumTag Interface](#)
[IDatumTag Members](#)
[IDatumTag.ForceShoulder Property](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0