

SOLIDWORKS API (.NET VBA C#) — Reference

(67/337): IDatumTargetSym-IDecal

SOLIDWORKS API Documentation (converted from CHM)

IDatumTargetSym (Type)

IDatumTargetSym Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDatumTargetSym Interface

Allows access to display information for datum target symbol annotations.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IDatumTargetSym
```

Visual Basic (Usage)

```
Dim instance As IDatumTargetSym
```

C#

```
public interface IDatumTargetSym
```

C++/CLI

```
public interface class IDatumTargetSym
```

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym](#).

Example

[Insert and Modify Datum Target Symbol \(C#\)](#)
[Insert and Modify Datum Target Symbol \(VB.NET\)](#)
[Insert and Modify Datum Target Symbol \(VBA\)](#)

Remarks

Datum target annotations are created interactively using **Insert**, **Annotations**, **Datum Target**.

Accessors

[IAnnotation::GetSpecificAnnotation](#) and [IAnnotation::!GetSpecificAnnotation](#)
[IDatumTargetSym::GetNext](#) and [IDatumTargetSym::!GetNext](#)
[IModelDocExtension::InsertDatumTargetSymbol2](#)
[IView::GetFirstDatumTargetSym](#) and [IView::!GetFirstDatumTargetSym](#)
[IView::GetDatumTargetSyms](#) and [IView::!GetDatumTargetSyms](#)

Access Diagram

[DatumTargetSym](#)

See Also

[IDatumTargetSym Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks](#) Namespace : IDatumTargetSym Interface

The following tables list the members exposed by [IDatumTargetSym](#).

Public Methods

Name	Description
 GetAnnotation	Gets the IAnnotation object for this specific datum target symbol.
 GetArcAtIndex	Gets information for the specified arc for this datum target symbol.
 GetArcCount	Gets the number of arc items in this datum target symbol.
 GetArrowHeadAtIndex	Gets information on the specified arrow head in this datum target symbol.
 GetArrowHeadCount	Gets the number of arrow heads in the datum target symbol.
 GetDatumReferenceLabel	Gets the specified datum target reference label.
 GetDisplaySizeOutside	Gets whether the datum target area size is displayed inside or outside of the symbol.
 GetDisplaySymbol	Gets whether the datum target symbol is displayed.
 GetDisplayTargetArea	Gets whether the datum target area is displayed.
 GetLineAtIndex	Gets information for the specified line.
 GetLineCount	Gets the number of line items in this datum target symbol.
 GetNext	Gets the next datum target symbol in the view.
 GetTargetAreaSize	Gets the size of the datum target symbol area.
 GetTargetShape	Gets the shape or style of the datum target area.
 GetTextAngleAtIndex	Gets the text angle for the specified text in this datum target symbol.
 GetTextAtIndex	Gets the specified text string from this datum target symbol.
 GetTextCount	Gets the number of text items in the datum target symbol.
 GetTextHeightAtIndex	Gets the height of the text for the specified text in this datum target symbol.
 GetTextInvertAtIndex	Gets the invert flag for the specified text item.
 GetTextPositionAtIndex	Gets the offset for the text item relative to the text point of the note.
 GetTextRefPositionAtIndex	Gets the reference position of the specified text item in this datum target symbol.
 GetTriangleAtIndex	Gets the triangle at the specified index.
 GetTriangleCount	Gets the number of triangles in this datum target symbol.
 IGetAnnotation	Gets the IAnnotation object for this specific datum target symbol.
 IGetArcAtIndex	Gets information for the specified arc for this datum target symbol.
 IGetArrowHeadAtIndex	Gets information on the specified arrow head in this datum target symbol.
 IGetLineAtIndex	Gets information for the specified line.
 IGetNext	Gets the next datum target symbol in the view.
 IGetTextPositionAtIndex	Gets the offset for the text item relative to the text point of the note.
 IGetTriangleAtIndex	Gets the triangle at the specified index.
 SetDatumReferenceLabel	Sets the specified datum target reference label.
 SetDatumTargetHorizontal	Sets this datum target to moveable horizontal.
 SetDatumTargetNotMoveable	Sets this datum target to not moveable.
 SetDatumTargetRotational	Sets this datum target to moveable rotational.
 SetDisplay	Sets the display characteristics of the datum target symbol.
 SetTargetArea	Sets the datum target area style and size.

[Top](#)

See Also

[IDatumTargetSym Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IDatumTargetSym Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDatumTargetSym Interface

For a list of all members of this type, see [IDatumTargetSym members](#).

Public Methods

Name	Description
 GetAnnotation	Gets the IAnnotation object for this specific datum target symbol.
 GetArcAtIndex	Gets information for the specified arc for this datum target symbol.
 GetArcCount	Gets the number of arc items in this datum target symbol.
 GetArrowHeadAtIndex	Gets information on the specified arrow head in this datum target symbol.
 GetArrowHeadCount	Gets the number of arrow heads in the datum target symbol.
 GetDatumReferenceLabel	Gets the specified datum target reference label.
 GetDisplaySizeOutside	Gets whether the datum target area size is displayed inside or outside of the symbol.
 GetDisplaySymbol	Gets whether the datum target symbol is displayed.
 GetDisplayTargetArea	Gets whether the datum target area is displayed.
 GetLineAtIndex	Gets information for the specified line.
 GetLineCount	Gets the number of line items in this datum target symbol.
 GetNext	Gets the next datum target symbol in the view.
 GetTargetAreaSize	Gets the size of the datum target symbol area.
 GetTargetShape	Gets the shape or style of the datum target area.
 GetTextAngleAtIndex	Gets the text angle for the specified text in this datum target symbol.
 GetTextAtIndex	Gets the specified text string from this datum target symbol.
 GetTextCount	Gets the number of text items in the datum target symbol.
 GetTextHeightAtIndex	Gets the height of the text for the specified text in this datum target symbol.
 GetTextInvertAtIndex	Gets the invert flag for the specified text item.
 GetTextPositionAtIndex	Gets the offset for the text item relative to the text point of the note.
 GetTextRefPositionAtIndex	Gets the reference position of the specified text item in this datum target symbol.
 GetTriangleAtIndex	Gets the triangle at the specified index.
 GetTriangleCount	Gets the number of triangles in this datum target symbol.
 IGetAnnotation	Gets the IAnnotation object for this specific datum target symbol.
 IGetArcAtIndex	Gets information for the specified arc for this datum target symbol.
 IGetArrowHeadAtIndex	Gets information on the specified arrow head in this datum target symbol.
 IGetLineAtIndex	Gets information for the specified line.
 IGetNext	Gets the next datum target symbol in the view.
 IGetTextPositionAtIndex	Gets the offset for the text item relative to the text point of the note.
 IGetTriangleAtIndex	Gets the triangle at the specified index.
 SetDatumReferenceLabel	Sets the specified datum target reference label.
 SetDatumTargetHorizontal	Sets this datum target to moveable horizontal.

	SetDatumTargetNotMoveable	Sets this datum target to not moveable.
	SetDatumTargetRotational	Sets this datum target to moveable rotational.
	SetDisplay	Sets the display characteristics of the datum target symbol.
	SetTargetArea	Sets the datum target area style and size.

[Top](#)

See Also

[IDatumTargetSym Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetAnnotation Method (IDatumTargetSym)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : GetAnnotation Method (IDatumTargetSym)

Gets the [IAnnotation](#) object for this specific datum target symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAnnotation() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym
Dim value As System.Object
```

```
value = instance.GetAnnotation()
```

C#

```
System.object GetAnnotation()
```

C++/CLI

```
System.Object^ GetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Annotation

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::GetAnnotation](#).

Example

[Get Annotation Object \(VBA\)](#)
[Get Annotation Object \(VB.NET\)](#)
[Get Annotation Object \(C#\)](#)

Remarks

The [IAnnotation](#) object is a higher-level object that contains methods general to all types of annotations.

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::IGetAnnotation Method](#)

Availability

SOLIDWORKS 99, datacode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetArcAtIndex Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : GetArcAtIndex Method (IDatumTargetSym)

Gets information for the specified arc for this datum target symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArcAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetArcAtIndex(Index)
```

C#

```
System.object GetArcAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetArcAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the arc; index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::GetArcAtIndex](#).

Remarks

The return value is the following array of doubles:

[*lineType*, *startPt*[3], *endPt*[3], *centerPt*[3], *rotationDir*]

where:

<i>lineType</i>	Line type as defined in swLineTypes_e
<i>startPt</i> [3]	XYZ arc start point
<i>endPt</i> [3]	XYZ arc end point
<i>centerPt</i> [3]	XYZ arc center point

rotationDir

Boolean returned as a double and represents the rotation direction, where CCW = True and CW = false

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetArcCount Method](#)
[IDatumTargetSym::IGetArcAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetArcCount Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : GetArcCount Method (IDatumTargetSym)

Gets the number of arc items in this datum target symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArcCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim value As System.Integer  
  
value = instance.GetArcCount()
```

C#

```
System.int GetArcCount()
```

C++/CLI

```
System.int GetArcCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of arcs

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::GetArcCount](#).

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetArcAtIndex Method](#)
[IDatumTargetSym::IGetArcAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetArrowHeadAtIndex Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : GetArrowHeadAtIndex Method (IDatumTargetSym)

Gets information on the specified arrow head in this datum target symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArrowHeadAtIndex( _  
    ByVal Index As System.Integer _
```

) As System.Object

Visual Basic (Usage)  Copy Code

```
Dim instance As IDatumTargetSym
Dim Index As System.Integer
Dim value As System.Object

value = instance.GetArrowHeadAtIndex(Index)
```

C#

```
System.object GetArrowHeadAtIndex(
    System.int Index
)
```

C++/CLI

```
System.Object^ GetArrowHeadAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the arrow head; index begins at 0

Return Value

Array of doubles (see **Remarks**)

 Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::GetArrowHeadAtIndex](#).

 Remarks

The return value is the following array of doubles:
[arrowHeadPt[3], arrowHeadDir[3], arrowHeadWidth, arrowHeadHeight, arrowHeadStyle]
where:

arrowHeadPt[3]	XYZ arrow head tip location
arrowHeadDir[3]	XYZ arrow head direction
arrowHeadWidth	Arrow head width where the width is measured along the arrow head direction
arrowHeadHeight	Arrow head height
arrowHeadStyle	Arrow head style as defined in swArrowStyle_e

 See Also

- [IDatumTargetSym Interface](#)
- [IDatumTargetSym Members](#)
- [IDatumTargetSym::GetArrowHeadCount Method](#)
- [IDatumTargetSym::!GetArrowHeadAtIndex Method](#)

GetArrowHeadCount Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : GetArrowHeadCount Method (IDatumTargetSym)

Gets the number of arrow heads in the datum target symbol.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetArrowHeadCount() As System.Integer
```

```
Dim instance As IDatumTargetSym
Dim value As System.Integer

value = instance.GetArrowHeadCount()
```

C#

```
System.int GetArrowHeadCount()
```

C++/CLI

```
System.int GetArrowHeadCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of arrow heads

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::GetArrowHeadCount](#).

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetArrowHeadAtIndex Method](#)
[IDatumTargetSym::IGetArrowHeadAtIndex Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDatumReferenceLabel Method (IDatumTargetSym)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : GetDatumReferenceLabel Method (IDatumTargetSym)

Gets the specified datum target reference label.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDatumReferenceLabel( _
    ByVal WhichOne As System.Integer _
) As System.String
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IDatumTargetSym
Dim WhichOne As System.Integer
Dim value As System.String

value = instance.GetDatumReferenceLabel(WhichOne)
```

C#

```
System.string GetDatumReferenceLabel(
    System.int WhichOne
)
```

C++/CLI

```
System.String^ GetDatumReferenceLabel(
    & System.int WhichOne
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichOne
0-based index indicating the datum reference label to get

Return Value

Datum reference label

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::GetDatumReferenceLabel](#).

Example

[Insert and Modify Datum Target Symbol \(C#\)](#)
[Insert and Modify Datum Target Symbol \(VB.NET\)](#)
[Insert and Modify Datum Target Symbol \(VBA\)](#)

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::SetDatumReferenceLabel Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDisplaySizeOutside Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : GetDisplaySizeOutside Method (IDatumTargetSym)

Gets whether the datum target area size is displayed inside or outside of the symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplaySizeOutside() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim value As System.Boolean
```

```
value = instance.GetDisplaySizeOutside()
```

C#

```
System.bool GetDisplaySizeOutside()
```

C++/CLI

```
System.bool GetDisplaySizeOutside();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the datum target area size is displayed outside of the symbol, false if the datum target area size is displayed inside of the symbol

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::GetDisplaySizeOutside](#).

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)

[IDatumTargetSym::SetDisplay Method](#)
[IDatumTargetSym::GetDisplaySymbol Method](#)
[IDatumTargetSym::GetDisplayTargetArea Method](#)
[IDatumTargetSym::SetDisplay Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDisplaySymbol Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : GetDisplaySymbol Method (IDatumTargetSym)

Gets whether the datum target symbol is displayed.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplaySymbol() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim value As System.Boolean  
  
value = instance.GetDisplaySymbol()
```

C#

```
System.bool GetDisplaySymbol()
```

C++/CLI

```
System.bool GetDisplaySymbol();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the datum target symbol is displayed, false if it is not

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::GetDisplaySymbol](#).

Remarks

Use:

- [IDatumTargetSym::GetDisplayTargetArea](#) to determine whether the datum target area part of this annotation is displayed.
- [IDatumTargetSym::SetDisplay](#) to enable or disable the display of the target area or symbol.

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetDisplaySizeOutside Method](#)
[IDatumTargetSym::GetDisplaySizeOutside Method](#)
[IDatumTargetSym::SetDisplay Method](#)
[IDatumTargetSym::SetDisplay Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDisplayTargetArea Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : GetDisplayTargetArea Method (IDatumTargetSym)

Gets whether the datum target area is displayed.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayTargetArea() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim value As System.Boolean  
  
value = instance.GetDisplayTargetArea()
```

C#

```
System.bool GetDisplayTargetArea()
```

C++/CLI

```
System.bool GetDisplayTargetArea();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the datum target area is displayed, false if it is not

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::GetDisplayTargetArea](#).

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetDisplaySizeOutside Method](#)
[IDatumTargetSym::GetDisplaySymbol Method](#)
[IDatumTargetSym::SetDisplay Method](#)
[IDatumTargetSym::SetTargetArea Method](#)
[IDatumTargetSym::GetTargetAreaSize Method](#)
[IDatumTargetSym::GetTargetShape Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLineAtIndex Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : GetLineAtIndex Method (IDatumTargetSym)

Gets information for the specified line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLineAtIndex(  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym
Dim Index As System.Integer
Dim value As System.Object

value = instance.GetLineAtIndex(Index)
```

C#

```
System.Object GetLineAtIndex(
    System.int Index
)
```

C++/CLI

```
System.Object^ GetLineAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the line; index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::GetLineAtIndex](#).

Remarks

The return value is the following array of doubles:

[*lineType*, *startPt[3]*, *endPt[3]*]

where:

<i>lineType</i>	Line type as defined in swLineTypes_e
<i>startPt[3]</i>	XYZ line start point
<i>endPt[3]</i>	XYZ line end point

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetLineCount Method](#)
[IDatumTargetSym::IGetLineAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLineCount Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : GetLineCount Method (IDatumTargetSym)

Gets the number of line items in this datum target symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLineCount() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IDatumTargetSym
Dim value As System.Integer
```



```
value = instance.GetLineCount()
```

C#

```
System.int GetLineCount()
```

C++/CLI

```
System.int GetLineCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of lines

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::GetLineCount](#).

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetLineAtIndex Method](#)
[IDatumTargetSym::!GetLineAtIndex Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetNext Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : GetNext Method (IDatumTargetSym)

Gets the next datum target symbol in the view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim value As System.Object  
  
value = instance.GetNext()
```

C#

```
System.object GetNext()
```

C++/CLI

```
System.Object^ GetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Datum target symbol

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::GetNext](#).

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IAnnotation::GetSpecificAnnotation Method](#)

[IAnnotation::IGetSpecificAnnotation Method](#)
[IDatumTargetSym::IGetNext Method](#)
[IModelDocExtension::InsertDatumTargetSymbol2 Method](#)
[IView::GetFirstDatumTargetSym Method](#)
[IView::IGetFirstDatumTargetSym Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTargetAreaSize Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : GetTargetAreaSize Method (IDatumTargetSym)

Gets the size of the datum target symbol area.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTargetAreaSize(  
    ByVal WhichOne As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim WhichOne As System.Integer  
Dim value As System.String  
  
value = instance.GetTargetAreaSize(WhichOne)
```

C#

```
System.string GetTargetAreaSize(  
    System.int WhichOne  
)
```

C++/CLI

```
System.String^ GetTargetAreaSize(  
& System.int WhichOne  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichOne
0-based index indicating which size value to get (see [Remarks](#))

Return Value

Target area size (see [Remarks](#))

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::GetTargetAreaSize](#).

Remarks

Use [IDatumTargetSym::GetTargetShape](#) to get the style for the target area.

If the target area style for this symbol is a ...	Then...
Point	There is one size value, which might be empty. Retrieve the text using an index value of 0. SOLIDWORKS displays the text in the upper half of the symbol, preceded by a diameter character.
Circle	There is one size value. Retrieve the text using an index value of 0. SOLIDWORKS displays the text in the upper half of the symbol, preceded by a diameter character.
Rectangle	There are two size values. Retrieve the text using an index value of 0 and 1. SOLIDWORKS displays the texts in the upper half of the symbol, separated by an x character.

Use [IDatumTargetSym::SetTargetArea](#) to set the target area size.

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetDisplayTargetArea Method](#)
[IDatumTargetSym::SetTargetArea Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTargetShape Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : GetTargetShape Method (IDatumTargetSym)

Gets the shape or style of the datum target area.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTargetShape() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim value As System.Integer
```

```
value = instance.GetTargetShape()
```

C#

```
System.int GetTargetShape()
```

C++/CLI

```
System.int GetTargetShape();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Target area shape or style as defined in [swDatumTargetAreaShape_e](#)

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::GetTargetShape](#).

Remarks

Use [IDatumTargetSym::SetTargetArea](#) to set the shape of the target area.

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetDisplayTargetArea Method](#)
[IDatumTargetSym::GetTargetAreaSize Method](#)
[IDatumTargetSym::SetTargetArea Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextAngleAtIndex Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : GetTextAngleAtIndex Method (IDatumTargetSym)

Gets the text angle for the specified text in this datum target symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextAngleAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.GetTextAngleAtIndex(Index)
```

C#

```
System.double GetTextAngleAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double GetTextAngleAtIndex(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the text; index begins at 0

Return Value

Text angle for the specified text in radians measured CCW from the X axis

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::GetTextAngleAtIndex](#).

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetTextCount Method](#)
[IDatumTargetSym::GetTextHeightAtIndex Method](#)
[IDatumTargetSym::GetTextInvertAtIndex Method](#)
[IDatumTargetSym::GetTextPositionAtIndex Method](#)
[IDatumTargetSym::GetTextRefPositionAtIndex Method](#)
[IDatumTargetSym::!GetTextPositionAtIndex Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextAtIndex Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : GetTextAtIndex Method (IDatumTargetSym)

Gets the specified text string from this datum target symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextAtIndex(  
    ByVal Index As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim Index As System.Integer  
Dim value As System.String  
  
value = instance.GetTextAtIndex(Index)
```

C#

```
System.string GetTextAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.String^ GetTextAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the text; index begins at 0

Return Value

Text string for the specified text

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::GetTextAtIndex](#).

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetTextAngleAtIndex Method](#)
[IDatumTargetSym::GetTextCount Method](#)
[IDatumTargetSym::GetTextHeightAtIndex Method](#)
[IDatumTargetSym::GetTextInvertAtIndex Method](#)
[IDatumTargetSym::GetTextPositionAtIndex Method](#)
[IDatumTargetSym::GetTextRefPositionAtIndex Method](#)
[IDatumTargetSym::IGetTextPositionAtIndex Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextCount Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : GetTextCount Method (IDatumTargetSym)

Gets the number of text items in the datum target symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim value As System.Integer  
  
value = instance.GetTextCount()
```

C#

```
System.int GetTextCount()
```

C++/CLI

```
System.int GetTextCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of text items

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::GetTextCount](#).

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetTextAngleAtIndex Method](#)
[IDatumTargetSym::GetTextAtIndex Method](#)
[IDatumTargetSym::GetTextHeightAtIndex Method](#)
[IDatumTargetSym::GetTextInvertAtIndex Method](#)
[IDatumTargetSym::GetTextPositionAtIndex Method](#)
[IDatumTargetSym::GetTextRefPositionAtIndex Method](#)
[IDatumTargetSym::IGetTextPositionAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextHeightAtIndex Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : GetTextHeightAtIndex Method (IDatumTargetSym)

Gets the height of the text for the specified text in this datum target symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextHeightAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.GetTextHeightAtIndex(Index)
```

C#

```
System.double GetTextHeightAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double GetTextHeightAtIndex(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the text; index begins at 0

Return Value

Height of the text for the specified text in meters

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::GetTextHeightAtIndex](#).

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetTextAngleAtIndex Method](#)
[IDatumTargetSym::GetTextAtIndex Method](#)
[IDatumTargetSym::GetTextCount Method](#)
[IDatumTargetSym::GetTextInvertAtIndex Method](#)
[IDatumTargetSym::GetTextPositionAtIndex Method](#)
[IDatumTargetSym::GetTextRefPositionAtIndex Method](#)
[IDatumTargetSym::IGetTextPositionAtIndex Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextInvertAtIndex Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : GetTextInvertAtIndex Method (IDatumTargetSym)

Gets the invert flag for the specified text item.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextInvertAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim Index As System.Integer  
Dim value As System.Integer
```

```
value = instance.GetTextInvertAtIndex(Index)
```

C#

```
System.int GetTextInvertAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.int GetTextInvertAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the text; index begins at 0

Return Value

Invert flag

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::GetTextInvertAtIndex](#).

Remarks

The invert flag specifies whether the text is mirrored (reflected) about the X axis. SOLIDWORKS Design applies reflection after text rotation.

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetTextAngleAtIndex Method](#)
[IDatumTargetSym::GetTextAtIndex Method](#)
[IDatumTargetSym::GetTextCount Method](#)
[IDatumTargetSym::GetTextHeightAtIndex Method](#)
[IDatumTargetSym::GetTextPositionAtIndex Method](#)
[IDatumTargetSym::GetTextRefPositionAtIndex Method](#)
[IDatumTargetSym::IGetTextPositionAtIndex Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextPositionAtIndex Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : GetTextPositionAtIndex Method (IDatumTargetSym)

Gets the offset for the text item relative to the text point of the note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextPositionAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetTextPositionAtIndex(Index)
```

C#

```
System.object GetTextPositionAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetTextPositionAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the text index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::GetTextPositionAtIndex](#).

Remarks

The return value is the following array of doubles:

[*textPtX*, *textPtY*, *textPtZ*]

where these text position values are actually offset values from the origin of this datum target symbol.

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetTextAngleAtIndex Method](#)
[IDatumTargetSym::GetTextAtIndex Method](#)
[IDatumTargetSym::GetTextCount Method](#)
[IDatumTargetSym::GetTextHeightAtIndex Method](#)
[IDatumTargetSym::GetTextInvertAtIndex Method](#)
[IDatumTargetSym::GetTextRefPositionAtIndex Method](#)
[IDatumTargetSym::IGetTextPositionAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextRefPositionAtIndex Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : GetTextRefPositionAtIndex Method (IDatumTargetSym)

Gets the reference position of the specified text item in this datum target symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextRefPositionAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim Index As System.Integer  
Dim value As System.Integer  
  
value = instance.GetTextRefPositionAtIndex(Index)
```

C#

```
System.int GetTextRefPositionAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.int GetTextRefPositionAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the text; index begins at 0

Return Value

Reference position as defined in [swTextPosition_e](#)

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::GetTextRefPositionAtIndex](#).

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetTextAngleAtIndex Method](#)
[IDatumTargetSym::GetTextAtIndex Method](#)
[IDatumTargetSym::GetTextCount Method](#)
[IDatumTargetSym::GetTextHeightAtIndex Method](#)
[IDatumTargetSym::GetTextInvertAtIndex Method](#)
[IDatumTargetSym::GetTextPositionAtIndex Method](#)
[IDatumTargetSym::IGetTextPositionAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTriangleAtIndex Method (IDatumTargetSym)

[See Also](#)



Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetTriangleAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As IDatumTargetSym  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetTriangleAtIndex(Index)
```

C#

```
System.object GetTriangleAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetTriangleAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the triangle; index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::GetTriangleAtIndex](#).

Remarks

The return value is the following array of doubles:

[*vertexPt1*[3], *vertexPt2*[3], *vertexPt3*[3], *isFilled*, *lineType*]

where:

<i>vertexPt1</i> [3]	First XYZ vertex point
<i>vertexPt2</i> [3]	Second XYZ vertex point
<i>vertexPt3</i> [3]	Third XYZ vertex point
<i>isFilled</i>	Boolean returned as a double and is True if the triangle is filled, false if it is not
<i>lineType</i>	Line type as defined in swLineTypes_e

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetTriangleCount Method](#)
[IDatumTargetSym::!GetTriangleAtIndex Method](#)

GetTriangleCount Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : GetTriangleCount Method (IDatumTargetSym)

Gets the number of triangles in this datum target symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTriangleCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim value As System.Integer  
  
value = instance.GetTriangleCount()
```

C#

```
System.int GetTriangleCount()
```

C++/CLI

```
System.int GetTriangleCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of triangles

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::GetTriangleCount](#).

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetTriangleAtIndex Method](#)
[IDatumTargetSym::!GetTriangleAtIndex Method](#)

IGetAnnotation Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : IGetAnnotation Method (IDatumTargetSym)

Gets the [IAnnotation](#) object for this specific datum target symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetAnnotation() As Annotation
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim value As Annotation  
  
value = instance.IGetAnnotation()
```

C#

```
Annotation IGetAnnotation()
```

C++/CLI

```
Annotation^ IGetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [IAnnotation](#) object

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::IGetAnnotation](#).

Remarks

The [IAnnotation](#) object is a higher-level object that contains methods general to all types of annotations.

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSymbol::GetAnnotation Method](#)

Availability

SOLIDWORKS 99 FCS, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetArcAtIndex Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : IGetArcAtIndex Method (IDatumTargetSym)

Gets information for the specified arc for this datum target symbol.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetArcAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetArcAtIndex(Index)
```

C#

```
System.double IGetArcAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetArcAtIndex(  
    & System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the arc; index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::IGetArcAtIndex](#).

Remarks

The return value is the following array of doubles:

[*lineType*, *startPt*[3], *endPt*[3], *centerPt*[3], *rotationDir*]

where:

<i>lineType</i>	Line type as defined in swLineTypes_e
<i>startPt</i> [3]	XYZ arc start point
<i>endPt</i> [3]	XYZ arc end point
<i>centerPt</i> [3]	XYZ arc center point
<i>rotationDir</i>	Boolean returned as a double and represents the rotation direction, where CCW = True and CW = false

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetArcAtIndex Method](#)
[IDatumTargetSym::GetArcCount Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetArrowHeadAtIndex Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : IGetArrowHeadAtIndex Method (IDatumTargetSym)

Gets information on the specified arrow head in this datum target symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetArrowHeadAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetArrowHeadAtIndex(Index)
```

C#

```
System.double IGetArrowHeadAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetArrowHeadAtIndex(  
    & System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the arrow head; index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::IGetArrowHeadAtIndex](#).

Remarks

The return value is the following array of doubles:
[*arrowHeadPt*[3], *arrowHeadDir*[3], *arrowHeadWidth*, *arrowHeadHeight*, *arrowHeadStyle*]

where:

<i>arrowHeadPt</i> [3]	XYZ arrow head tip location
<i>arrowHeadDir</i> [3]	XYZ arrow head direction
<i>arrowHeadWidth</i>	Arrow head width where the width is measured along the arrow head direction
<i>arrowHeadHeight</i>	Arrow head height
<i>arrowHeadStyle</i>	Arrow head style as defined in swArrowStyle_e

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetArrowHeadAtIndex Method](#)
[IDatumTargetSym::GetArrowHeadCount Method](#)

IGetLineAtIndex Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : IGetLineAtIndex Method (IDatumTargetSym)

Gets information for the specified line.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetLineAtIndex(  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetLineAtIndex(Index)
```

C#

```
System.double IGetLineAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetLineAtIndex(  
    & System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the line; index begins at 0

Return Value

Array of doubles (see **Remarks**)

 Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::IGetLineAtIndex](#).

 Remarks

The return value is the following array of doubles:

[*lineType*, *startPt*[3], *endPt*[3]]

where:

<i>lineType</i>	Line type as defined in swLineTypes_e
<i>startPt</i> [3]	XYZ line start point
<i>endPt</i> [3]	XYZ line end point

 See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetLineAtIndex Method](#)
[IDatumTargetSym::GetLineCount Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetNext Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : IGetNext Method (IDatumTargetSym)

Gets the next datum target symbol in the view.

 .NET Syntax

Visual Basic (Declaration)

Function IGetNext() As DatumTargetSym

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim value As DatumTargetSym
```

```
value = instance.IGetNext()
```

C#

```
DatumTargetSym IGetNext()
```

C++/CLI

```
DatumTargetSym^ IGetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the next [datum target symbol](#)

 Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::IGetNext](#).

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetNext Method](#)
[IAnnotation::GetSpecificAnnotation Method](#)
[IAnnotation::IGetSpecificAnnotation Method](#)
[IModelDocExtension::InsertDatumTargetSymbol2 Method](#)
[IView::GetFirstDatumTargetSym Method](#)
[IView::IGetFirstDatumTargetSym Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetTextPositionAtIndex Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : IGetTextPositionAtIndex Method (IDatumTargetSym)

Gets the offset for the text item relative to the text point of the note.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTextPositionAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetTextPositionAtIndex(Index)
```

C#

```
System.double IGetTextPositionAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetTextPositionAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the text; index begins at 0

Return Value

Pointer to an array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::IGetTextPositionAtIndex](#).

Remarks

The return value is the following array of doubles:

[*textPtX*, *textPtY*, *textPtZ*]

where these text position values are actually offset values from the origin of this datum target symbol.

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetTextAngleAtIndex Method](#)
[IDatumTargetSym::GetTextAtIndex Method](#)
[IDatumTargetSym::GetTextCount Method](#)
[IDatumTargetSym::GetTextHeightAtIndex Method](#)
[IDatumTargetSym::GetTextInvertAtIndex Method](#)
[IDatumTargetSym::GetTextPositionAtIndex Method](#)
[IDatumTargetSym::GetTextRefPositionAtIndex Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTriangleAtIndex Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : IGetTriangleAtIndex Method (IDatumTargetSym)

Gets the triangle at the specified index.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTriangleAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetTriangleAtIndex(Index)
```

C#

```
System.double IGetTriangleAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetTriangleAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the triangle; index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::IGetTriangleAtIndex](#).

Remarks

The return value is the following array of doubles:

[*vertexPt1*[3], *vertexPt2*[3], *vertexPt3*[3], *isFilled*, *lineType*]

where:

<i>vertexPt1</i> [3]	First XYZ vertex point
<i>vertexPt2</i> [3]	Second XYZ vertex point
<i>vertexPt3</i> [3]	Third XYZ vertex point

<i>isFilled</i>	Boolean returned as a double and is True if the triangle is filled, false if it is not
<i>lineType</i>	Line type as defined in swLineTypes_e

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::GetTriangleAtIndex Method](#)
[IDatumTargetSym::GetTriangleCount Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetDatumReferenceLabel Method (IDatumTargetSym)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : SetDatumReferenceLabel Method (IDatumTargetSym)

Sets the specified datum target reference label.

.NET Syntax

Visual Basic (Declaration)

```
Function SetDatumReferenceLabel( _
    ByVal WhichOne As System.Integer, _
    ByVal Text As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym
Dim WhichOne As System.Integer
Dim Text As System.String
Dim value As System.Boolean

value = instance.SetDatumReferenceLabel(WhichOne, Text)
```

C#

```
System.bool SetDatumReferenceLabel(
    System.int WhichOne,
    System.string Text
)
```

C++/CLI

```
System.bool SetDatumReferenceLabel(
    & System.int WhichOne,
    & System.String^ Text
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichOne

0-based index indicating the datum reference label to set

Text

Datum reference label

Return Value

True if the datum reference label is set successfully, false if it was not

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::SetDatumReferenceLabel](#).

Example

[Insert and Modify Datum Target Symbol \(C#\)](#)
[Insert and Modify Datum Target Symbol \(VB.NET\)](#)
[Insert and Modify Datum Target Symbol \(VBA\)](#)

Remarks

Use [IDatumTargetSym::GetDatumReferenceLabel](#) to get the datum target reference labels.

To see the change in a drawing, call [IModelDoc2::GraphicsRedraw2](#).

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDatumTargetHorizontal Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : SetDatumTargetHorizontal Method (IDatumTargetSym)

Sets this datum target to moveable horizontal.

.NET Syntax

Visual Basic (Declaration)

```
Function SetDatumTargetHorizontal(  
    ByVal MoveableDatumDirection As System.Integer, _  
    ByVal LockLeader As System.Boolean, _  
    ByVal LockLeaderAngle As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim MoveableDatumDirection As System.Integer  
Dim LockLeader As System.Boolean  
Dim LockLeaderAngle As System.Double  
Dim value As System.Boolean  
  
value = instance.SetDatumTargetHorizontal(MoveableDatumDirection, LockLeader, LockLeaderAngle)
```

C#

```
System.bool SetDatumTargetHorizontal(  
    System.int MoveableDatumDirection,  
    System.bool LockLeader,  
    System.double LockLeaderAngle  
)
```

C++/CLI

```
System.bool SetDatumTargetHorizontal(  
& System.int MoveableDatumDirection,  
& System.bool LockLeader,  
& System.double LockLeaderAngle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

MoveableDatumDirection

Moveable datum direction as defined in [swMoveableDatumDirection](#) e

LockLeader

True to lock the leader, false to not

LockLeaderAngle

Angle of locked leader; valid only if LockLeader is set to true

Return Value

True if this datum target is successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::SetDatumTargetHorizontal](#).

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::SetDatumTargetNotMoveable Method \(\)](#)
[IDatumTargetSym::SetDatumTargetRotational Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDatumTargetNotMoveable Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : SetDatumTargetNotMoveable Method (IDatumTargetSym)

Sets this datum target to not moveable.

.NET Syntax

Visual Basic (Declaration)

```
Function SetDatumTargetNotMoveable() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim value As System.Boolean
```

```
value = instance.SetDatumTargetNotMoveable()
```

C#

```
System.bool SetDatumTargetNotMoveable()
```

C++/CLI

```
System.bool SetDatumTargetNotMoveable();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if datum target successfully set to not move, false if not

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::SetDatumTargetNotMoveable](#).

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::SetDatumTargetHorizontal Method \(\)](#)
[IDatumTargetSym::SetDatumTargetRotational Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SetDatumTargetRotational Method (IDatumTargetSym)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : SetDatumTargetRotational Method (IDatumTargetSym)

Sets this datum target to moveable rotational.

.NET Syntax

Visual Basic (Declaration)

```
Function SetDatumTargetRotational( _
    ByVal MoveableDatumDirection As System.Integer, _
    ByVal LockLeader As System.Boolean, _
    ByVal LockLeaderAngle As System.Double, _
    ByVal GeometryRef As System.Boolean, _
    ByRef RefGeometryError As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym
Dim MoveableDatumDirection As System.Integer
Dim LockLeader As System.Boolean
Dim LockLeaderAngle As System.Double
Dim GeometryRef As System.Boolean
Dim RefGeometryError As System.Integer
Dim value As System.Boolean

value = instance.SetDatumTargetRotational(MoveableDatumDirection, LockLeader, LockLeaderAngle,
GeometryRef, RefGeometryError)
```

C#

```
System.bool SetDatumTargetRotational(
    System.int MoveableDatumDirection,
    System.bool LockLeader,
    System.double LockLeaderAngle,
    System.bool GeometryRef,
    out System.int RefGeometryError
)
```

C++/CLI

```
System.bool SetDatumTargetRotational(
    & System.int MoveableDatumDirection,
    & System.bool LockLeader,
    & System.double LockLeaderAngle,
    & System.bool GeometryRef,
    & [Out] System.int RefGeometryError
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

*MoveableDatumDirection*Moveable datum direction as defined in [swMoveableDatumDirection_e](#)*LockLeader*

True to lock the leader, false to not

LockLeaderAngle

Angle of locked leader; valid only if LockLeader is set to true

GeometryRef

True to use a geometry reference, false to not; true is valid only if MoveableDatumDirection is set to swMoveableDatumDirection_e.swMoveableDatumDirectionBySelection

*RefGeometryError*Reference geometry error as defined in [swRefGeometryError_e](#)

Return Value

True if datum target successfully set, false if errors

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::SetDatumTargetRotational](#).

Remarks

If GeometryRef is set to true, then select a geometry reference before calling this method.

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)
[IDatumTargetSym::SetDatumTargetNotMoveable Method \(\)](#)
[IDatumTargetSym::SetDatumTargetHorizontal Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetDisplay Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : SetDisplay Method (IDatumTargetSym)

Sets the display characteristics of the datum target symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function SetDisplay( _  
    ByVal Symbol As System.Boolean, _  
    ByVal TargetArea As System.Boolean, _  
    ByVal SizeOutside As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDatumTargetSym  
Dim Symbol As System.Boolean  
Dim TargetArea As System.Boolean  
Dim SizeOutside As System.Boolean  
Dim value As System.Boolean  
  
value = instance.SetDisplay(Symbol, TargetArea, SizeOutside)
```

C#

```
System.bool SetDisplay(  
    System.bool Symbol,  
    System.bool TargetArea,  
    System.bool SizeOutside  
)
```

C++/CLI

```
System.bool SetDisplay(  
& System.bool Symbol,  
& System.bool TargetArea,  
& System.bool SizeOutside  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Symbol

True displays the datum target symbol part of the annotation, false hides it

TargetArea

True displays the datum target area part of the annotation, false hides it

SizeOutside

True displays the datum target area size outside of the symbol, false displays it inside

Return Value

True if the display characteristics were set successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::SetDisplay](#).

Remarks

Use:

- [IDatumTargetSym::GetDisplaySymbol](#) to determine if the datum target symbol part of the annotation is displayed.
- [IDatumTargetSym::GetDisplayTargetArea](#) to determine if the datum target area part of the annotation is displayed.
- [IDatumTargetSym::GetDisplaySizeOutside](#) to determine whether the target area size is displayed inside or outside of the symbol.

To see the model or drawing changes caused by running this method, use [IModelDoc2::GraphicsRedraw2](#) to redraw your window.

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTargetArea Method (IDatumTargetSym)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDatumTargetSym Interface](#) : SetTargetArea Method (IDatumTargetSym)

Sets the datum target area style and size.

.NET Syntax

Visual Basic (Declaration)

```
Function SetTargetArea( _  
    ByVal Shape As System.Integer, _  
    ByVal Size1 As System.String, _  
    ByVal Size2 As System.String _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IDatumTargetSym  
Dim Shape As System.Integer  
Dim Size1 As System.String  
Dim Size2 As System.String  
Dim value As System.Boolean
```

```
value = instance.SetTargetArea(Shape, Size1, Size2)
```

C#

```
System.bool SetTargetArea(  
    System.int Shape,  
    System.string Size1,  
    System.string Size2  
)
```

C++/CLI

```
System.bool SetTargetArea(  
& System.int Shape,  
& System.String^ Size1,
```

```
& System.String^ Size2  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Shape

Target area shape or style as defined in [swDatumTargetAreaShape_e](#)

Size1

Target area diameter or width (see **Remarks**)

Size2

Target area height (see **Remarks**)

Return Value

True if the target area parameters were set successfully, false if they were not

Visual Basic for Applications (VBA) Syntax

See [DatumTargetSym::SetTargetArea](#).

Remarks

If the target area style for this symbol is...	Then...
Point	There is one size value, which might be empty. Retrieve the text using an index value of 0. SOLIDWORKS displays the text in the upper half of the symbol, preceded by a diameter character.
Circle	There is one size value. Retrieve the text using an index value of 0. SOLIDWORKS displays the text in the upper half of the symbol, preceded by a diameter character.
Rectangle	There are two size values. Retrieve the text using an index value of 0 and 1. SOLIDWORKS displays the texts in the upper half of the symbol, separated by an x character.

If the specified target area style is not one of the values in [swDatumTargetAreaShape_e](#), SOLIDWORKS does not modify the symbol, and the returns false.

Use [IDatumTargetSym::GetTargetShape](#) to get the target area style. Use [IDatumTargetSym::GetTargetAreaSize](#) to get the target area size.

To see the model or drawing changes, use [IModelDoc2::GraphicsRedraw2](#) to redraw your window.

See Also

[IDatumTargetSym Interface](#)
[IDatumTargetSym Members](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

IDecal (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IDecal Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDecal Interface

Allows access to the decals in models.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IDecal

Visual Basic (Usage)

Dim instance As [IDecal](#)

C#

public interface IDecal

C++/CLI

public interface class IDecal

Visual Basic for Applications (VBA) Syntax

See [Decal](#).

Example

[Add Decal \(VBA\)](#)
[Add Decal \(VB.NET\)](#)
[Add Decal \(C#\)](#)

Remarks

Decals cannot be added or edited in precise Hidden Lines Removed, Hidden Lines Visible, or Wireframe display modes.

Accessors

[IComponent2::GetDecals](#) and [IComponent2::IGetDecals](#)
[IModelDocExtension::CreateDecal](#)
[IModelDocExtension::GetDecal](#)
[IModelDocExtension::GetDecals](#) and [IModelDocExtension::IGetDecals](#)

Access Diagram

[Decal](#)

See Also

[IDecal Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFaceDecalProperties Interface](#)
[IModelDocExtension::DeleteAllDecals Method](#)
[IModelDocExtension::AddDecal Method](#)
[IModelDocExtension::DeleteDecal Method](#)
[IModelDocExtension::GetDecalsCount Method](#)
[IModelDocExtension::HideDecal Method](#)
[IModelDocExtension::ReverseDecalsOrder Method](#)
[IRenderMaterial Interface](#)

IDecal Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDecal Interface

The following tables list the members exposed by [IDecal](#).

Public Properties

Name	Description
DecalID	Gets the SOLIDWORKS decal ID.
Hidden	Gets or sets whether the decal hidden.
MaskFilename	Gets or sets the path and filename for the image to use as a mask for this decal.
MaskInvert	Gets or sets whether the mask is inverted.
MaskType	Gets or sets the type of mask used with this decal.

[Top](#)

Public Methods

Name	Description
GetMaskExcludedColorsCount	Gets the number of colors excluded from the mask image for this decal.
IGetMaskExcludedColors	Gets the colors excluded from the mask image for this decal.
ISetMaskExcludedColors	Sets the colors to exclude from the mask image for this decal.

[Top](#)

See Also

[IDecal Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFaceDecalProperties Interface](#)
[IModelDocExtension::DeleteAllDecals Method](#)
[IModelDocExtension::AddDecal Method](#)
[IModelDocExtension::DeleteDecal Method](#)
[IModelDocExtension::GetDecalsCount Method](#)
[IModelDocExtension::HideDecal Method](#)
[IModelDocExtension::ReverseDecalsOrder Method](#)
[IRenderMaterial Interface](#)
[IModelDocExtension::GetRenderCustomReferences Method](#)
[IModelDocExtension::GetRenderStockReferences Method](#)

IDecal Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDecal Interface

For a list of all members of this type, see [IDecal members](#).

Public Methods

Name	Description
GetMaskExcludedColorsCount	Gets the number of colors excluded from the mask image for this decal.
IGetMaskExcludedColors	Gets the colors excluded from the mask image for this decal.
ISetMaskExcludedColors	Sets the colors to exclude from the mask image for this decal.

[Top](#)

See Also

[IDecal Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFaceDecalProperties Interface](#)
[IModelDocExtension::DeleteAllDecals Method](#)
[IModelDocExtension::AddDecal Method](#)
[IModelDocExtension::DeleteDecal Method](#)

[IModelDocExtension::GetDecalsCount Method](#)
[IModelDocExtension::HideDecal Method](#)
[IModelDocExtension::ReverseDecalsOrder Method](#)
[IRenderMaterial Interface](#)
[IModelDocExtension::GetRenderCustomReferences Method](#)
[IModelDocExtension::GetRenderStockReferences Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDecal Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IDecal Interface

For a list of all members of this type, see [IDecal members](#).

Public Properties

Name	Description
 DecalID	Gets the SOLIDWORKS decal ID.
 Hidden	Gets or sets whether the decal hidden.
 MaskFilename	Gets or sets the path and filename for the image to use as a mask for this decal.
 MaskInvert	Gets or sets whether the mask is inverted.
 MaskType	Gets or sets the type of mask used with this decal.

[Top](#)

See Also

[IDecal Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFaceDecalProperties Interface](#)
[IModelDocExtension::DeleteAllDecals Method](#)
[IModelDocExtension::AddDecal Method](#)
[IModelDocExtension::DeleteDecal Method](#)
[IModelDocExtension::GetDecalsCount Method](#)
[IModelDocExtension::HideDecal Method](#)
[IModelDocExtension::ReverseDecalsOrder Method](#)
[IRenderMaterial Interface](#)
[IModelDocExtension::GetRenderCustomReferences Method](#)
[IModelDocExtension::GetRenderStockReferences Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

DecalID Property (IDecal)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDecal Interface](#) : DecalID Property (IDecal)

Gets the SOLIDWORKS decal ID.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property DecalID As System.Integer

Visual Basic (Usage)

```
Dim instance As IDecal  
Dim value As System.Integer  
  
value = instance.DecalID
```

C#

```
System.int DecalID {get;}
```

C++/CLI

```
property System.int DecalID {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

SOLIDWORKS decal ID (index number)

Visual Basic for Applications (VBA) Syntax

See [Decal::DecalID](#).

Remarks

By default, decal IDs are persistent, which means if three decals (IDs 1, 2, and 3) were applied to the model, and you [removed decal](#) ID 2, then the remaining decal IDs are 1 and 3.

See Also

[IDecal Interface](#)
[IDecal Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetMaskExcludedColorsCount Method (IDecal)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDecal Interface](#) : GetMaskExcludedColorsCount Method (IDecal)

Gets the number of colors excluded from the mask image for this decal.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMaskExcludedColorsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDecal  
Dim value As System.Integer  
  
value = instance.GetMaskExcludedColorsCount()
```

C#

```
System.int GetMaskExcludedColorsCount()
```

C++/CLI

```
System.int GetMaskExcludedColorsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of colors excluded from the mask image

Visual Basic for Applications (VBA) Syntax

See [Decal::GetMaskExcludedColorsCount](#).

Remarks

Call this method before calling [IDecal::IGetMaskExcludedColors](#) to get the size of the array for that method.

See Also

[IDecal Interface](#)
[IDecal Members](#)
[IDecal::ISetMaskExcludedColors Method](#)

[IDecal::MaskFilename Property](#)
[IDecal::MaskInvert Property](#)
[IDecal::MaskType Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Hidden Property (IDecal)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDecal Interface](#) : Hidden Property (IDecal)

Gets or sets whether the decal hidden.

.NET Syntax

Visual Basic (Declaration)

Property Hidden As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDecal
Dim value As System.Boolean
```

```
instance.Hidden = value
```

```
value = instance.Hidden
```

C#

```
System.bool Hidden {get; set;}
```

C++/CLI

```
property System.bool Hidden {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the decal is hidden, false if not

Visual Basic for Applications (VBA) Syntax

See [Decal::Hidden](#).

See Also

[IDecal Interface](#)
[IDecal Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetMaskExcludedColors Method (IDecal)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDecal Interface](#) : IGetMaskExcludedColors Method (IDecal)

Gets the colors excluded from the mask image for this decal.

.NET Syntax

```
Function IGetMaskExcludedColors( _
    ByVal Count As System.Integer _
) As System.Integer
```



```
Dim instance As IDecal
Dim Count As System.Integer
Dim value As System.Integer

value = instance.IGetMaskExcludedColors(Count)
```

```
System.int IGetMaskExcludedColors(
    System.int Count
)
```

```
System.int IGetMaskExcludedColors(
    & System.int Count
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of colors excluded from the mask image

Return Value

- in-process, unmanaged C++: Pointer to an array of the RGB colors excluded from the mask image
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Visual Basic for Applications (VBA) Syntax

See [IDecal::IGetMaskExcludedColors](#).

Remarks

Before calling this method, call [IDecal::GetMaskExcludedColorsCount](#) to get the value of Count.

See Also

[IDecal Interface](#)
[IDecal Members](#)
[IDecal::SetMaskExcludedColors Method](#)
[IDecal::MaskFilename Property](#)
[IDecal::MaskInvert Property](#)
[IDecal::MaskType Property](#)

Availability

SOLIDWORKS 2008FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetMaskExcludedColors Method (IDecal)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDecal Interface](#) : ISetMaskExcludedColors Method (IDecal)

Sets the colors to exclude from the mask image for this decal.

.NET Syntax

```
Sub ISetMaskExcludedColors( _
    ByVal Count As System.Integer, _
    ByRef MaskColors As System.Integer _
)
```

Visual Basic (Usage)



```
Dim instance As IDecal
Dim Count As System.Integer
Dim MaskColors As System.Integer

instance.ISetMaskExcludedColors(Count, MaskColors)
```

C#

```
void ISetMaskExcludedColors(
    System.int Count,
    ref System.int MaskColors
)
```

C++/CLI

```
void ISetMaskExcludedColors(
    & System.int Count,
    & System.int% MaskColors
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of colors to exclude from the mask image

MaskColors

- In-process, unmanaged C++: Pointer to an array of the RGB colors excluded from the mask image

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Visual Basic for Applications (VBA) Syntax

See [IDecal::ISetMaskExcludedColors](#).

See Also

[IDecal Interface](#)

[IDecal Members](#)

[IDecal::GetMaskExcludedColorsCount Method](#)

[IDecal::GetMaskExcludedColors Method](#)

[IDecal::MaskFilename Property](#)

[IDecal::MaskInvert Property](#)

[IDecal::MaskType Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MaskFilename Property (IDecal)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDecal Interface](#) : MaskFilename Property (IDecal)

Gets or sets the path and filename for the image to use as a mask for this decal.

.NET Syntax

Visual Basic (Declaration)

```
Property MaskFilename As System.String
```

Visual Basic (Usage)



```
Dim instance As IDecal
Dim value As System.String

instance.MaskFilename = value

value = instance.MaskFilename
```

C#

```
System.string MaskFilename {get; set;}
```

C++/CLI

```
property System.String^ MaskFilename {
    System.String^ get();
    void set ( &    System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Fully qualified path and filename of the image to use as a mask

Visual Basic for Applications (VBA) Syntax

See [Decal::MaskFilename](#).

See Also

[IDecal Interface](#)
[IDecal Members](#)
[IDecal::GetMaskExcludedColorsCount Method](#)
[IDecal::IGetMaskExcludedColors Method](#)
[IDecal::ISetMaskExcludedColors Method](#)
[IDecal::MaskInvert Property](#)
[IDecal::MaskType Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MaskInvert Property (IDecal)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDecal Interface](#) : MaskInvert Property (IDecal)

Gets or sets whether the mask is inverted.

.NET Syntax

Visual Basic (Declaration)

```
Property MaskInvert As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDecal
Dim value As System.Boolean

instance.MaskInvert = value

value = instance.MaskInvert
```

C#

```
System.bool MaskInvert {get; set;}
```

C++/CLI

```
property System.bool MaskInvert {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the mask is inverted, false if not

Visual Basic for Applications (VBA) Syntax

See [Decal::MaskInvert](#).

See Also

[IDecal Interface](#)
[IDecal Members](#)
[IDecal::GetMaskExcludedColorsCount Method](#)
[IDecal::IGetMaskExcludedColors Method](#)
[IDecal::ISetMaskExcludedColors Method](#)
[IDecal::MaskFilename Property](#)
[IDecal::MaskType Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MaskType Property (IDecal)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDecal Interface](#) : MaskType Property (IDecal)

Gets or sets the type of mask used with this decal.

.NET Syntax

Visual Basic (Declaration)

```
Property MaskType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDecal
Dim value As System.Integer

instance.MaskType = value

value = instance.MaskType
```

C#

```
System.int MaskType {get; set;}
```

C++/CLI

```
property System.int MaskType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of mask:

- 0 = No mask
- 1 = Image mask file
- 2 = Selective color mask

- 3 = Use decal image alpha channel

Visual Basic for Applications (VBA) Syntax

See [Decal::MaskType](#).

Example

[Get Mask Types of Each Decal \(VBA\)](#).

See Also

[IDecal Interface](#)
[IDecal Members](#)
[IDecal::GetMaskExcludedColorsCount Method](#)
[IDecal::IGetMaskExcludedColors Method](#)
[IDecal::ISetMaskExcludedColors Method](#)
[IDecal::MaskFilename Property](#)
[IDecal::MaskInvert Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0