

SOLIDWORKS API (.NET VBA C#) — Reference

(68/337): IDeleteBodyFeatureData- IDerivedPartFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IDeleteBodyFeatureData (Type)

IDeleteBodyFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDeleteBodyFeatureData Interface

Allows access to a Body-Delete/Keep feature.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IDeleteBodyFeatureData
```

Visual Basic (Usage)

```
Dim instance As IDeleteBodyFeatureData
```

C#

```
public interface IDeleteBodyFeatureData
```

C++/CLI

```
public interface class IDeleteBodyFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [DeleteBodyFeatureData](#).

Example

[Insert Body-Delete/Keep Feature \(VBA\)](#)
[Insert Body-Delete/Keep Feature \(VB.NET\)](#)
[Insert Body-Delete/Keep Feature \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[DeleteBodyFeatureData](#)

See Also

[IDeleteBodyFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertDeleteBody_Method](#)

IDeleteBodyFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDeleteBodyFeatureData Interface

The following tables list the members exposed by [IDeleteBodyFeatureData](#).

Public Properties

Name	Description
 Bodies	Gets or sets the bodies to delete or keep.
 KeepBodies	Gets or sets whether to keep bodies.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that describe this Body-Delete/Keep feature.
 GetBodiesCount	Gets the number of bodies to delete or keep.
 IGetBodies	Gets the bodies to delete.
 ISetBodies	Sets the bodies to delete.
 ReleaseSelectionAccess	Releases access to selections that describe this Body-Delete/Keep feature.

[Top](#)

See Also

[IDeleteBodyFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertDeleteBody Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDeleteBodyFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDeleteBodyFeatureData Interface

For a list of all members of this type, see [IDeleteBodyFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that describe this Body-Delete/Keep feature.
 GetBodiesCount	Gets the number of bodies to delete or keep.
 IGetBodies	Gets the bodies to delete.
 ISetBodies	Sets the bodies to delete.
 ReleaseSelectionAccess	Releases access to selections that describe this Body-Delete/Keep feature.

[Top](#)

See Also

[IDeleteBodyFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertDeleteBody Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDeleteBodyFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDeleteBodyFeatureData Interface

For a list of all members of this type, see [IDeleteBodyFeatureData members](#).

Public Properties

Name	Description
 Bodies	Gets or sets the bodies to delete or keep.
 KeepBodies	Gets or sets whether to keep bodies.

[Top](#)

See Also

[IDeleteBodyFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertDeleteBody Method](#)

 

[SolidWorks.Interop.sldworks Namespace](#) > [IDeleteBodyFeatureData Interface](#) : AccessSelections Method (IDeleteBodyFeatureData)

Gains access to the selections that describe this Body-Delete/Keep feature.

 .NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IDeleteBodyFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component in which the feature is to be modified

Return Value

True if the selections are successfully accessed, false if not

 Visual Basic for Applications (VBA) Syntax

See [DeleteBodyFeatureData::AccessSelections](#).

 Remarks

To modify a feature in a...		Then...	Remark
Part		- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL	
Assembly		- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified	

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IDeleteBodyFeatureData::ReleaseSelectionAccess](#) if you did not

 See Also

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Bodies Property (IDeleteBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDeleteBodyFeatureData Interface](#) : Bodies Property (IDeleteBodyFeatureData)

Gets or sets the bodies to delete or keep.

.NET Syntax

Visual Basic (Declaration)

Property Bodies As System.Object

Visual Basic (Usage)



```
Dim instance As IDeleteBodyFeatureData  
Dim value As System.Object
```

```
instance.Bodies = value
```

```
value = instance.Bodies
```

C#

```
System.object Bodies {get; set;}
```

C++/CLI

```
property System.Object^ Bodies {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [bodies](#) to delete or keep

Visual Basic for Applications (VBA) Syntax

See [DeleteBodyFeatureData::Bodies](#).

Remarks

Call [IDeleteBodyFeatureData::KeepBodies](#) to specify whether to keep or delete the bodies.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IDeleteBodyFeatureData Interface](#)
[IDeleteBodyFeatureData Members](#)
[IDeleteBodyFeatureData::GetBodiesCount Method](#)
[IDeleteBodyFeatureData::IGetBodies Method](#)
[IDeleteBodyFeatureData::ISetBodies Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetBodiesCount Method (IDeleteBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDeleteBodyFeatureData Interface](#) : GetBodiesCount Method (IDeleteBodyFeatureData)

Gets the number of bodies to delete or keep.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBodiesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDeleteBodyFeatureData  
Dim value As System.Integer
```

```
value = instance.GetBodiesCount()
```

C#

```
System.int GetBodiesCount()
```

C++/CLI

```
System.int GetBodiesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of bodies

Visual Basic for Applications (VBA) Syntax

See [DeleteBodyFeatureData::GetBodiesCount](#).

Example

See the [IDeleteBodyFeatureData](#) examples.

Remarks

Call this method before calling [IDeleteBodyFeautre::IGetBodies](#) to determine the size of the array.

See Also

[IDeleteBodyFeatureData Interface](#)
[IDeleteBodyFeatureData Members](#)
[IDeleteBodyFeatureData::iSetBodies Method](#)
[IDeleteBodyFeatureData::Bodies Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetBodies Method (IDeleteBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDeleteBodyFeatureData Interface](#) : IGetBodies Method (IDeleteBodyFeatureData)

Gets the bodies to delete.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBodies( _  
    ByVal Count As System.Integer _  
) As Body2
```

Visual Basic (Usage)



```
Dim instance As IDeleteBodyFeatureData  
Dim Count As System.Integer  
Dim value As Body2  
  
value = instance.IGetBodies(Count)
```

C#

```
Body2 IGetBodies(  
    System.int Count  
)
```

C++/CLI

```
Body2^ IGetBodies(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of bodies

Return Value

- in-process, unmanaged C++: Pointer to an array of [IBody2](#) objects of size count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IDeleteBodiesFeatureData::GetBodiesCount](#) before calling this method to get the number of bodies to delete.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IDeleteBodyFeatureData Interface](#)
[IDeleteBodyFeatureData Members](#)
[IDeleteBodyFeatureData::IGetBodies Method](#)
[IDeleteBodyFeatureData::Bodies Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetBodies Method (IDeleteBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDeleteBodyFeatureData Interface](#) : ISetBodies Method (IDeleteBodyFeatureData)

Sets the bodies to delete.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetBodies( _  
    ByVal Count As System.Integer, _  
    ByRef Bodies As Body2 _  
)
```

```
Dim instance As IDeleteBodyFeatureData
Dim Count As System.Integer
Dim Bodies As Body2

instance.ISetBodies(Count, Bodies)
```

C#

```
void ISetBodies(
    System.int Count,
    ref Body2 Bodies
)
```

C++/CLI

```
void ISetBodies(
    & System.int Count,
    & Body2^% Bodies
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of bodies

Bodies

- in-process, unmanaged C++: Pointer to an array of [IBody2](#) objects of size count

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IDeleteBodyFeatureData Interface](#)

[IDeleteBodyFeatureData Members](#)

[IDeleteBodyBodyFeatureData::GetBodiesCount Method](#)

[IDeleteBodyBodyFeatureData::IGetBodies Method](#)

[IDeleteBodyBodyFeatureData::Bodies Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

KeepBodies Property (IDeleteBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDeleteBodyFeatureData Interface](#) : KeepBodies Property (IDeleteBodyFeatureData)

Gets or sets whether to keep bodies.

.NET Syntax

Visual Basic (Declaration)

```
Property KeepBodies As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IDeleteBodyFeatureData
Dim value As System.Boolean

instance.KeepBodies = value

value = instance.KeepBodies
```

C#

```
System.bool KeepBodies {get; set;}
```

C++/CLI

```
property System.bool KeepBodies {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to keep bodies, false to delete bodies

Visual Basic for Applications (VBA) Syntax

See [DeleteBodyFeatureData::KeepBodies](#).

Example

See the [IDeleteBodyFeatureData](#) examples.

Remarks

Call [IDeleteBodyFeatureData::Bodies](#) to specify the bodies to keep or delete.

See Also

[IDeleteBodyFeatureData Interface](#)
[IDeleteBodyFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IDeleteBodyFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDeleteBodyFeatureData Interface](#) : ReleaseSelectionAccess Method (IDeleteBodyFeatureData)

Releases access to selections that describe this Body-Delete/Keep feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IDeleteBodyFeatureData

instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DeleteBodyFeatureData::ReleaseSelectionAccess](#).

Remarks

[IDeleteBodyFeatureData::AccessSelections](#) put the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did.

See Also

[IDeleteBodyFeatureData Interface](#)
[IDeleteBodyFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

IDeleteFaceFeatureData (Type)

IDeleteFaceFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDeleteFaceFeatureData Interface

Allows access to a DeleteFace feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IDeleteFaceFeatureData

Visual Basic (Usage)

Dim instance As [IDeleteFaceFeatureData](#)

C#

public interface IDeleteFaceFeatureData

C++/CLI

public interface class IDeleteFaceFeatureData

Visual Basic for Applications (VBA) Syntax

See [DeleteFaceFeatureData](#).

Example

[Insert and Change DeleteFace Feature \(C#\)](#)
[Insert and Change DeleteFace Feature \(VB.NET\)](#)
[Insert and Change DeleteFace Feature \(VBA\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[DeleteFaceFeatureData](#)

See Also

[IDeleteFaceFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::EditDeleteFace Method](#)
[IModelDocExtension::InsertDeleteFace](#)

IDeleteFaceFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDeleteFaceFeatureData Interface

The following tables list the members exposed by [IDeleteFaceFeatureData](#).

Public Properties

Name	Description
Options	Gets or sets the option for the DeleteFace feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Allows access to the selections that describe the DeleteFace feature.
 GetDeletedFaces	Get the faces of the DeleteFace feature.
 GetDeletedFacesCount	Gets the number of faces in the DeleteFace feature.
 IAccessSelections	Allows access to the selections that describe the DeleteFace feature.
 IGetDeletedFaces	Get the faces of the DeleteFace feature.
 ISetDeletedFaces	Sets the faces for the DeleteFace feature.
 ReleaseSelectionAccess	Releases access to selections that describe the DeleteFace feature.
 SetDeletedFaces	Sets the faces for the DeleteFace feature.

[Top](#)

See Also

[IDeleteFaceFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::EditDeleteFace Method](#)
[IModelDocExtension::InsertDeleteFace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IDeleteFaceFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDeleteFaceFeatureData Interface

For a list of all members of this type, see [IDeleteFaceFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Allows access to the selections that describe the DeleteFace feature.
 GetDeletedFaces	Get the faces of the DeleteFace feature.
 GetDeletedFacesCount	Gets the number of faces in the DeleteFace feature.
 IAccessSelections	Allows access to the selections that describe the DeleteFace feature.
 IGetDeletedFaces	Get the faces of the DeleteFace feature.
 ISetDeletedFaces	Sets the faces for the DeleteFace feature.
 ReleaseSelectionAccess	Releases access to selections that describe the DeleteFace feature.
 SetDeletedFaces	Sets the faces for the DeleteFace feature.

[Top](#)

See Also

[IDeleteFaceFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::EditDeleteFace Method](#)
[IModelDocExtension::InsertDeleteFace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IDeleteFaceFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDeleteFaceFeatureData Interface

For a list of all members of this type, see [IDeleteFaceFeatureData members](#).

Public Properties

Name	Description
 Options	Gets or sets the option for the DeleteFace feature.

[Top](#)

See Also

[IDeleteFaceFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::EditDeleteFace Method](#)
[IModelDocExtension::InsertDeleteFace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IDeleteFaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDeleteFaceFeatureData Interface](#) : AccessSelections Method (IDeleteFaceFeatureData)

Allows access to the selections that describe the DeleteFace feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDeleteFaceFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component in which the feature is to be modified

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [DeleteFaceFeatureData::AccessSelections](#).

Example

[Insert and Change DeleteFace Feature \(C#\)](#)
[Insert and Change DeleteFace Feature \(VB.NET\)](#)
[Insert and Change DeleteFace Feature \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc argument is the ModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IDeleteFaceFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IDeleteFaceFeatureData Interface](#)
[IDeleteFaceFeatureData Members](#)
[IDeleteFaceFeatureData::IAccessSelections Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDeletedFaces Method (IDeleteFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDeleteFaceFeatureData Interface](#) : GetDeletedFaces Method (IDeleteFaceFeatureData)

Get the faces of the DeleteFace feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDeletedFaces() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDeleteFaceFeatureData
Dim value As System.Object

value = instance.GetDeletedFaces()
```

C#

```
System.object GetDeletedFaces()
```

C++/CLI

```
System.Object^ GetDeletedFaces();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [faces](#)

Visual Basic for Applications (VBA) Syntax

See [DeleteFaceFeatureData::GetDeletedFaces](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IDeleteFaceFeatureData Interface](#)
[IDeleteFaceFeatureData Members](#)
[IDeleteFaceFeatureData::GetDeletedFacesCount Method](#)
[IDeleteFaceFeatureData::IGetDeletedFaces Method](#)
[IDeleteFaceFeatureData::!SetDeletedFaces Method](#)
[IDeleteFaceFeatureData::SetDeletedFaces Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDeletedFacesCount Method (IDeleteFaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDeleteFaceFeatureData Interface](#) : GetDeletedFacesCount Method (IDeleteFaceFeatureData)

Gets the number of faces in the DeleteFace feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDeletedFacesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDeleteFaceFeatureData  
Dim value As System.Integer  
  
value = instance.GetDeletedFacesCount()
```

C#

```
System.int GetDeletedFacesCount()
```

C++/CLI

```
System.int GetDeletedFacesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of faces

Visual Basic for Applications (VBA) Syntax

See [DeleteFaceFeatureData::GetDeletedFacesCount](#).

Example

[Insert and Change DeleteFace Features \(C#\)](#)
[Insert and Change DeleteFace Features \(VB.NET\)](#)
[Insert and Change DeleteFace Feature \(VBA\)](#)

Remarks

Call this method before calling [IDeleteFaceFeatureData::!GetDeletedFaces](#) to determine the size of its array.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IDeleteFaceFeatureData Interface](#)
[IDeleteFaceFeatureData Members](#)
[IDeleteFaceFeatureData::GetDeletedFaces Method](#)
[IDeleteFaceFeatureData::!GetDeletedFaces Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections Method (IDeleteFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDeleteFaceFeatureData Interface](#) : IAccessSelections Method (IDeleteFaceFeatureData)

Allows access to the selections that describe the DeleteFace feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDeleteFaceFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
    & ModelDoc2^ TopDoc,  
    & Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component in which the feature is to be modified

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [DeleteFaceFeatureData::!AccessSelections](#).

Remarks

To modify a feature in a...

Then...

- | | |
|----------|---|
| Part | <ul style="list-style-type: none">TopDoc argument is the IModelDoc2 for the partComponent argument is NULL |
| Assembly | <ul style="list-style-type: none">TopDoc argument is the ModelDoc2 object for the assembly |

- Component argument is the [IComponent2](#) object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IDeleteFaceFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IDeleteFaceFeatureData Interface](#)
[IDeleteFaceFeatureData Members](#)
[IDeleteFaceFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDeletedFaces Method (IDeleteFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDeleteFaceFeatureData Interface](#) : IGetDeletedFaces Method (IDeleteFaceFeatureData)

Get the faces of the DeleteFace feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDeletedFaces( _  
    ByVal Count As System.Integer _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As IDeleteFaceFeatureData  
Dim Count As System.Integer  
Dim value As Face2
```

```
value = instance.IGetDeletedFaces(Count)
```

C#

```
Face2 IGetDeletedFaces(  
    System.int Count  
)
```

C++/CLI

```
Face2^ IGetDeletedFaces(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of faces

Return Value

- in-process, unmanaged C++: Pointer to an array of [faces](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [IDeleteFaceFeatureData::GetDeletedFacesCount](#) before calling this method to get the value for Count.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IDeleteFaceFeatureData Interface](#)
[IDeleteFaceFeatureData Members](#)
[IDeleteFaceFeatureData::GetDeletedFaces Method](#)
[IDeleteFaceFeatureData::ISetDeletedFaces Method](#)
[IDeleteFaceFeatureData::SetDeletedFaces Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetDeletedFaces Method (IDeleteFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDeleteFaceFeatureData Interface](#) : ISetDeletedFaces Method (IDeleteFaceFeatureData)

Sets the faces for the DeleteFace feature.

.NET Syntax

Visual Basic (Declaration)

```
Function ISetDeletedFaces( _  
    ByVal Count As System.Integer, _  
    ByRef Facedisp As Face2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDeleteFaceFeatureData  
Dim Count As System.Integer  
Dim Facedisp As Face2  
Dim value As System.Boolean  
  
value = instance.ISetDeletedFaces(Count, Facedisp)
```

C#

```
System.bool ISetDeletedFaces(  
    System.int Count,  
    ref Face2 Facedisp  
)
```

C++/CLI

```
System.bool ISetDeletedFaces(  
& System.int Count,  
& Face2^% Facedisp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of faces

Facedisp

- in-process, unmanaged C++: Pointer to an array of [faces](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

True if the faces are set, false if not

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IDeleteFaceFeatureData Interface](#)
[IDeleteFaceFeatureData Members](#)
[IDeleteFaceFeatureData::SetDeletedFaces Method](#)
[IDeleteFaceFeatureData::GetDeletedFaces Method](#)
[IDeleteFaceFeatureData::GetDeletedFacesCount Method](#)
[IDeleteFaceFeatureData::IGetDeletedFaces Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Options Property (IDeleteFaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDeleteFaceFeatureData Interface](#) : Options Property (IDeleteFaceFeatureData)

Gets or sets the option for the DeleteFace feature.

.NET Syntax

Visual Basic (Declaration)

Property Options As System.Integer

Visual Basic (Usage)



```
Dim instance As IDeleteFaceFeatureData  
Dim value As System.Integer
```

```
instance.Options = value
```

```
value = instance.Options
```

C#

```
System.int Options {get; set;}
```

C++/CLI

```
property System.int Options {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Option as defined in [swFaceDeleteOption_e](#)

Visual Basic for Applications (VBA) Syntax

See [DeleteFaceFeatureData::Options](#).

Example

[Insert and Change DeleteFace Feature \(C#\)](#)
[Insert and Change DeleteFace Feature \(VB.NET\)](#)
[Insert and Change DeleteFace Feature \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IDeleteFaceFeatureData Interface](#)
[IDeleteFaceFeatureData Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IDeleteFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDeleteFaceFeatureData Interface](#) : ReleaseSelectionAccess Method (IDeleteFaceFeatureData)

Releases access to selections that describe the DeleteFace feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IDeleteFaceFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DeleteFaceFeatureData::ReleaseSelectionAccess](#).

Remarks

[IDeleteFaceFeatureData::AccessSelections](#) and [IDeleteFaceFeatureData::!AccessSelections](#) put the model into a rollback state to allow access to the selections that define the DeleteFace feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did.

See Also

[IDeleteFaceFeatureData Interface](#)
[IDeleteFaceFeatureData Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDeletedFaces Method (IDeleteFaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDeleteFaceFeatureData Interface](#) : SetDeletedFaces Method (IDeleteFaceFeatureData)

Sets the faces for the DeleteFace feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetDeletedFaces( _  
    ByVal Faces As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDeleteFaceFeatureData  
Dim Faces As System.Object  
Dim value As System.Boolean  
  
value = instance.SetDeletedFaces(Faces)
```

C#

```
System.bool SetDeletedFaces(  
    System.object Faces  
)
```

C++/CLI

```
System.bool SetDeletedFaces(  
& System.Object^ Faces  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Faces
Array of [faces](#)

Return Value

True if the faces are set, false if not

Visual Basic for Applications (VBA) Syntax

See [DeleteFaceFeatureData::SetDeletedFaces](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IDeleteFaceFeatureData Interface](#)
[IDeleteFaceFeatureData Members](#)
[IDeleteFaceFeatureData::GetDeletedFaces Method](#)
[IDeleteFaceFeatureData::GetDeletedFacesCount Method](#)
[IDeleteFaceFeatureData::IGetDeletedFaces Method](#)
[IDeleteFaceFeatureData::ISetDeletedFaces Method](#)

Availability

SolidWorks 2010 FCS, Revision Number 18.0

IDerivedPartFeatureData (Type)

IDerivedPartFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDerivedPartFeatureData Interface

Allows access to a derived part feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IDerivedPartFeatureData
```

Visual Basic (Usage)



```
Dim instance As IDerivedPartFeatureData
```

C#

```
public interface IDerivedPartFeatureData
```

C++/CLI

```
public interface class IDerivedPartFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [DerivedPartFeatureData](#).

Example

[Modify Derived Part \(C#\)](#)
[Modify Derived Part \(VB.NET\)](#)
[Modify Derived Part \(VBA\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[DerivedPartFeatureData](#)

See Also

[IDerivedPartFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPartDoc::InsertPart2 Method](#)
[IFeature::ModifyDefinition Method](#)
[IFeature::IModifyDefinition2 Method](#)

IDerivedPartFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDerivedPartFeatureData Interface

The following tables list the members exposed by [IDerivedPartFeatureData](#).

Public Properties

Name	Description
ImportAbsorbedSketches	Gets or sets whether to import absorbed sketches with the derived part feature.

	ImportAxis	Gets or sets whether to import the axis with the derived part feature.
	ImportCoordinateSystems	Gets or sets whether to import coordinate systems with the derived part feature.
	ImportCThread	Gets or sets whether to import cosmetic threads with the derived part feature.
	ImportCustomProperties	Gets or sets which custom properties to import with the derived part feature.
	ImportCutListProperties	Gets or sets whether to import cut list properties with the derived part feature.
	ImportHoleWizardData	Gets or sets whether to import Hole Wizard data with the derived part feature.
	ImportMaterial	Gets or sets whether to import material with the derived part feature.
	ImportModelDimensions	Gets or sets whether to import model dimensions with the derived part feature.
	ImportPlane	Gets or sets whether to import planes with the derived part feature.
	ImportSheetMetalInformation	Gets or sets how to import sheet metal information with the derived part feature.
	ImportSolidBodies	Gets or sets whether to import solid bodies with the derived part feature.
	ImportSurf	Gets or sets whether to import surface bodies with the derived part feature.
	ImportUnAbsorbedSketches	Gets or sets whether to import unabsorbed sketches with the derived part feature.
	PartConfiguration	Gets or sets the part configuration to use to create the derived part feature.
	PathName	Gets the path for the derived part feature. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

Public Methods

Name	Description
	AccessSelections Gains access to the selections used to define this derived part feature.
	GetModelDoc Gets the model document from which this part was derived (i.e., the base model document).
	GetMoveFeature Gets the move/copy feature belonging to this derived part feature.
	IAccessSelections Gains access to the selections used to define this derived part feature.
	ReleaseSelectionAccess Releases access to selections that describe this derived part feature.

[Top](#)

See Also

[IDerivedPartFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPartDoc::InsertPart2 Method](#)
[IFeature::ModifyDefinition Method](#)
[IFeature::IModifyDefinition2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDerivedPartFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDerivedPartFeatureData Interface

For a list of all members of this type, see [IDerivedPartFeatureData members](#).

Public Methods

Name	Description
	AccessSelections Gains access to the selections used to define this derived part feature.
	GetModelDoc Gets the model document from which this part was derived (i.e., the base model document).
	GetMoveFeature Gets the move/copy feature belonging to this derived part feature.
	IAccessSelections Gains access to the selections used to define this derived part feature.
	ReleaseSelectionAccess Releases access to selections that describe this derived part feature.

[Top](#)

See Also

[IDerivedPartFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPartDoc::InsertPart2 Method](#)
[IFeature::ModifyDefinition Method](#)
[IFeature::IModifyDefinition2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDerivedPartFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IDerivedPartFeatureData Interface

For a list of all members of this type, see [IDerivedPartFeatureData members](#).

Public Properties

Name	Description
 ImportAbsorbedSketches	Gets or sets whether to import absorbed sketches with the derived part feature.
 ImportAxis	Gets or sets whether to import the axis with the derived part feature.
 ImportCoordinateSystems	Gets or sets whether to import coordinate systems with the derived part feature.
 ImportCThread	Gets or sets whether to import cosmetic threads with the derived part feature.
 ImportCustomProperties	Gets or sets which custom properties to import with the derived part feature.
 ImportCutListProperties	Gets or sets whether to import cut list properties with the derived part feature.
 ImportHoleWizardData	Gets or sets whether to import Hole Wizard data with the derived part feature.
 ImportMaterial	Gets or sets whether to import material with the derived part feature.
 ImportModelDimensions	Gets or sets whether to import model dimensions with the derived part feature.
 ImportPlane	Gets or sets whether to import planes with the derived part feature.
 ImportSheetMetalInformation	Gets or sets how to import sheet metal information with the derived part feature.
 ImportSolidBodies	Gets or sets whether to import solid bodies with the derived part feature.
 ImportSurf	Gets or sets whether to import surface bodies with the derived part feature.
 ImportUnAbsorbedSketches	Gets or sets whether to import unabsorbed sketches with the derived part feature.
 PartConfiguration	Gets or sets the part configuration to use to create the derived part feature.
 PathName	Gets the path for the derived part feature. NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

See Also

[IDerivedPartFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IPartDoc::InsertPart2 Method](#)
[IFeature::ModifyDefinition Method](#)
[IFeature::IModifyDefinition2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IDerivedPartFeatureData)

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPartFeatureData Interface](#) : AccessSelections Method (IDerivedPartFeatureData)

Gains access to the selections used to define this derived part feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections(  
    ByVal TopDoc As System.Object, _
```

```
ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDerivedPartFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component in which the feature is to be modified

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [DerivedPartFeatureData::AccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IDerivedPartFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IDerivedPartFeatureData Interface](#)
[IDerivedPartFeatureData Members](#)
[IDerivedPartFeatureData::IAccessSelections Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetModelDoc Method (IDerivedPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPartFeatureData Interface](#) : GetModelDoc Method (IDerivedPartFeatureData)

Gets the model document from which this part was derived (i.e., the base model document).

.NET Syntax

Visual Basic (Declaration)

```
Function GetModelDoc() As ModelDoc2
```

Visual Basic (Usage)



```
Dim instance As IDerivedPartFeatureData  
Dim value As ModelDoc2  
  
value = instance.GetModelDoc()
```

C#

```
ModelDoc2 GetModelDoc()
```

C++/CLI

```
ModelDoc2^ GetModelDoc();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Base [model document](#)

Visual Basic for Applications (VBA) Syntax

See [DerivedPartFeatureData::GetModelDoc](#).

See Also

[IDerivedPartFeatureData Interface](#)
[IDerivedPartFeatureData Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetMoveFeature Method (IDerivedPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPartFeatureData Interface](#) : GetMoveFeature Method (IDerivedPartFeatureData)

Gets the move/copy feature belonging to this derived part feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMoveFeature() As Feature
```

Visual Basic (Usage)



```
Dim instance As IDerivedPartFeatureData  
Dim value As Feature  
  
value = instance.GetMoveFeature()
```

C#

```
Feature GetMoveFeature()
```

C++/CLI

```
Feature^ GetMoveFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Move/copy [feature](#)

Visual Basic for Applications (VBA) Syntax

See [DerivedPartFeatureData::GetMoveFeature](#).

See Also

[IDerivedPartFeatureData Interface](#)
[IDerivedPartFeatureData Members](#)
[IFeature Interface](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections Method (IDerivedPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPartFeatureData Interface](#) : IAccessSelections Method (IDerivedPartFeatureData)

Gains access to the selections used to define this derived part feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDerivedPartFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component in which the feature is to be modified

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [DerivedPartFeatureData::!AccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is <code>NULL</code>
Assembly	- TopDoc is the <code>IModelDoc2</code> object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::!ModifyDefinition2](#) if you modified the feature
- [IDerivedPartFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IDerivedPartFeatureData Interface](#)
[IDerivedPartFeatureData Members](#)
[IDerivedPartFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ImportAbsorbedSketches Property (IDerivedPartFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPartFeatureData Interface](#) : ImportAbsorbedSketches Property (IDerivedPartFeatureData)

Gets or sets whether to import absorbed sketches with the derived part feature.

.NET Syntax

Visual Basic (Declaration)

Property ImportAbsorbedSketches As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDerivedPartFeatureData  
Dim value As System.Boolean
```

```
instance.ImportAbsorbedSketches = value
```

```
value = instance.ImportAbsorbedSketches
```

C#

```
System.bool ImportAbsorbedSketches {get; set;}
```

C++/CLI

```
property System.bool ImportAbsorbedSketches {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to its import absorbed sketches, false to not

Visual Basic for Applications (VBA) Syntax

See [DerivedPartFeatureData::ImportAbsorbedSketches](#).

Example

[Modify Derived Part \(C#\)](#)
[Modify Derived Part \(VB.NET\)](#)
[Modify Derived Part \(VBA\)](#)

See Also

[IDerivedPartFeatureData Interface](#)
[IDerivedPartFeatureData Members](#)
[IDerivedPartFeatureData.ImportUnAbsorbedSketches Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ImportAxis Property (IDerivedPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPartFeatureData Interface](#) : ImportAxis Property (IDerivedPartFeatureData)

Gets or sets whether to import the axis with the derived part feature.

.NET Syntax

Visual Basic (Declaration)

Property ImportAxis As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDerivedPartFeatureData  
Dim value As System.Boolean
```

```
instance.ImportAxis = value
```

```
value = instance.ImportAxis
```

C#

```
System.bool ImportAxis {get; set;}
```

C++/CLI

```
property System.bool ImportAxis {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import its axis, false to not

Visual Basic for Applications (VBA) Syntax

See [DerivedPartFeatureData.ImportAxis](#).

See Also

[IDerivedPartFeatureData Interface](#)
[IDerivedPartFeatureData Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ImportCoordinateSystems Property (IDerivedPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPartFeatureData Interface](#) : ImportCoordinateSystems Property (IDerivedPartFeatureData)

Gets or sets whether to import coordinate systems with the derived part feature.

.NET Syntax

Visual Basic (Declaration)

Property ImportCoordinateSystems As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDerivedPartFeatureData  
Dim value As System.Boolean
```

```
instance.ImportCoordinateSystems = value
```

```
value = instance.ImportCoordinateSystems
```

C#

```
System.bool ImportCoordinateSystems {get; set;}
```

C++/CLI

```
property System.bool ImportCoordinateSystems {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import its coordinate systems, false to not

Visual Basic for Applications (VBA) Syntax

See [DerivedPartFeatureData.ImportCoordinateSystems](#).

See Also

[IDerivedPartFeatureData Interface](#)
[IDerivedPartFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ImportCThread Property (IDerivedPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPartFeatureData Interface](#) : ImportCThread Property (IDerivedPartFeatureData)

Gets or sets whether to import [cosmetic threads](#) with the derived part feature.

.NET Syntax

Visual Basic (Declaration)

Property ImportCThread As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDerivedPartFeatureData  
Dim value As System.Boolean
```

```
instance.ImportCThread = value  
value = instance.ImportCThread
```

C#

```
System.bool ImportCThread {get; set;}
```

C++/CLI

```
property System.bool ImportCThread {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import its cosmetics threads, false not not

Visual Basic for Applications (VBA) Syntax

See [DerivedPartFeatureData.ImportCThread](#).

See Also

[IDerivedPartFeatureData Interface](#)
[IDerivedPartFeatureData Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ImportCustomProperties Property (IDerivedPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPartFeatureData Interface](#) : ImportCustomProperties Property (IDerivedPartFeatureData)

Gets or sets which custom properties to import with the derived part feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ImportCustomProperties As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDerivedPartFeatureData  
Dim value As System.Integer
```

```
instance.ImportCustomProperties = value  
value = instance.ImportCustomProperties
```

C#

```
System.int ImportCustomProperties {get; set;}
```

C++/CLI

```
property System.int ImportCustomProperties {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Custom properties to import as defined in [swImportPartCustomPropertiesToOptions_e](#)

Visual Basic for Applications (VBA) Syntax

See [DerivedPartFeatureData::ImportCustomProperties](#).

Remarks

This property is valid when:

- the derived part has custom properties,
- and -
- [IDerivedPartFeatureData::ImportSolidBodies](#) is set to true.

See Also

[IDerivedPartFeatureData Interface](#)
[IDerivedPartFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ImportCutListProperties Property (IDerivedPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPartFeatureData Interface](#) : ImportCutListProperties Property (IDerivedPartFeatureData)

Gets or sets whether to import cut list properties with the derived part feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ImportCutListProperties As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDerivedPartFeatureData  
Dim value As System.Boolean  
  
instance.ImportCutListProperties = value  
value = instance.ImportCutListProperties
```

C#

```
System.bool ImportCutListProperties {get; set;}
```

C++/CLI

```
property System.bool ImportCutListProperties {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import its cut list properties, false to not

Visual Basic for Applications (VBA) Syntax

See [DerivedPartFeatureData::ImportCutListProperties](#).

Remarks

This property is valid only if:

- the derived part has cut list properties,
- and -
- [IDerivedPartFeatureData::ImportSheetMetalInformation](#) is not specified.

See Also

[IDerivedPartFeatureData Interface](#)
[IDerivedPartFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ImportHoleWizardData Property (IDerivedPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPartFeatureData Interface](#) : ImportHoleWizardData Property (IDerivedPartFeatureData)

Gets or sets whether to import Hole Wizard data with the derived part feature.

.NET Syntax

Visual Basic (Declaration)

Property ImportHoleWizardData As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDerivedPartFeatureData  
Dim value As System.Boolean
```

```
instance.ImportHoleWizardData = value
```

```
value = instance.ImportHoleWizardData
```

C#

```
System.bool ImportHoleWizardData {get; set;}
```

C++/CLI

```
property System.bool ImportHoleWizardData {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import its Hole Wizard data, false to not

Visual Basic for Applications (VBA) Syntax

See [DerivedPartFeatureData::ImportHoleWizardData](#).

Remarks

This property is valid only if [IDerivedPartFeatureData::ImportSolidBodies](#) is true.

See Also

[IDerivedPartFeatureData Interface](#)
[IDerivedPartFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ImportMaterial Property (IDerivedPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPartFeatureData Interface](#) : ImportMaterial Property (IDerivedPartFeatureData)

Gets or sets whether to import material with the derived part feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ImportMaterial As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDerivedPartFeatureData  
Dim value As System.Boolean
```

```
instance.ImportMaterial = value
```

```
value = instance.ImportMaterial
```

C#

```
System.bool ImportMaterial {get; set;}
```

C++/CLI

```
property System.bool ImportMaterial {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import its material, false to not

Visual Basic for Applications (VBA) Syntax

See [DerivedPartFeatureData::ImportMaterial](#).

Remarks

This property is valid only while the derived part is being inserted. It is not valid while it is being edited.

See Also

[IDerivedPartFeatureData Interface](#)
[IDerivedPartFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ImportModelDimensions Property (IDerivedPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPartFeatureData Interface](#) : ImportModelDimensions Property (IDerivedPartFeatureData)

Gets or sets whether to import model dimensions with the derived part feature.

Visual Basic Syntax

Visual Basic (Declaration)

Property ImportModelDimensions As System.Boolean

Visual Basic (Usage)

```
Dim instance As IDerivedPartFeatureData
Dim value As System.Boolean

instance.ImportModelDimensions = value
value = instance.ImportModelDimensions
```

C#

```
System.bool ImportModelDimensions {get; set;}
```

C++/CLI

```
property System.bool ImportModelDimensions {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import its model dimensions, false to not

Visual Basic for Applications (VBA) Syntax

See [DerivedPartFeatureData.ImportModelDimensions](#).

Remarks

This property is valid only if [IDerivedPartFeatureData.ImportSolidBodies](#) is true.

See Also

[IDerivedPartFeatureData Interface](#)
[IDerivedPartFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ImportPlane Property (IDerivedPartFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPartFeatureData Interface](#) : ImportPlane Property (IDerivedPartFeatureData)

Gets or sets whether to import planes with the derived part feature.

Visual Basic Syntax

Visual Basic (Declaration)

Property ImportPlane As System.Boolean

Visual Basic (Usage)

```
Dim instance As IDerivedPartFeatureData
Dim value As System.Boolean
```

```
instance.ImportPlane = value  
value = instance.ImportPlane
```

C#

```
System.bool ImportPlane {get; set;}
```

C++/CLI

```
property System.bool ImportPlane {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import its planes, false to not

Visual Basic for Applications (VBA) Syntax

See [DerivedPartFeatureData::ImportPlane](#).

Example

[Modify Derived Part \(C#\)](#)
[Modify Derived Part \(VB.NET\)](#)
[Modify Derived Part \(VBA\)](#)

See Also

[IDerivedPartFeatureData Interface](#)
[IDerivedPartFeatureData Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ImportSheetMetalInformation Property (IDerivedPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPartFeatureData Interface](#) : ImportSheetMetalInformation Property (IDerivedPartFeatureData)

Gets or sets how to import sheet metal information with the derived part feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ImportSheetMetalInformation As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDerivedPartFeatureData  
Dim value As System.Integer  
  
instance.ImportSheetMetalInformation = value  
value = instance.ImportSheetMetalInformation
```

C#

```
System.int ImportSheetMetalInformation {get; set;}
```

C++/CLI

```
property System.int ImportSheetMetalInformation {  
    System.int get();
```

```
void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

How to import sheet metal information as defined in [swImportSheetMetalInformation_e](#)

Visual Basic for Applications (VBA) Syntax

See [DerivedPartFeatureData::ImportSheetMetalInformation](#).

Remarks

This property:

- is valid only if the part being inserted is a sheet metal part.
- is not valid if [IDerivedPartFeatureData::ImportCutListProperties](#) is set to true.

See Also

[IDerivedPartFeatureData Interface](#)
[IDerivedPartFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ImportSolidBodies Property (IDerivedPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPartFeatureData Interface](#) : ImportSolidBodies Property (IDerivedPartFeatureData)

Gets or sets whether to import solid bodies with the derived part feature.

.NET Syntax

Visual Basic (Declaration)

Property ImportSolidBodies As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDerivedPartFeatureData  
Dim value As System.Boolean
```

```
instance.ImportSolidBodies = value
```

```
value = instance.ImportSolidBodies
```

C#

```
System.bool ImportSolidBodies {get; set;}
```

C++/CLI

```
property System.bool ImportSolidBodies {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import its solid bodies, false to not

Visual Basic for Applications (VBA) Syntax

See [DerivedPartFeatureData::ImportSolidBodies](#).

See Also

[IDerivedPartFeatureData Interface](#)
[IDerivedPartFeatureData Members](#)
[IDerivedPartFeatureData.ImportModelDimensions Property\(\)](#)
[IDerivedPartFeatureData.ImportHoleWizardData Property\(\)](#)
[IDerivedPartFeatureData.ImportCustomProperties Property\(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ImportSurf Property (IDerivedPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPartFeatureData Interface](#) : ImportSurf Property (IDerivedPartFeatureData)

Gets or sets whether to import surface bodies with the derived part feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ImportSurf As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDerivedPartFeatureData  
Dim value As System.Boolean
```

```
instance.ImportSurf = value
```

```
value = instance.ImportSurf
```

C#

```
System.bool ImportSurf {get; set;}
```

C++/CLI

```
property System.bool ImportSurf {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import its surface bodies, false to not

Visual Basic for Applications (VBA) Syntax

See [DerivedPartFeatureData.ImportSurf](#).

See Also

[IDerivedPartFeatureData Interface](#)
[IDerivedPartFeatureData Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ImportUnAbsorbedSketches Property (IDerivedPartFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPartFeatureData Interface](#) : ImportUnAbsorbedSketches Property (IDerivedPartFeatureData)

Gets or sets whether to import unabsorbed sketches with the derived part feature.

.NET Syntax

Visual Basic (Declaration)

Property ImportUnAbsorbedSketches As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDerivedPartFeatureData
Dim value As System.Boolean

instance.ImportUnAbsorbedSketches = value

value = instance.ImportUnAbsorbedSketches
```

C#

```
System.bool ImportUnAbsorbedSketches {get; set;}
```

C++/CLI

```
property System.bool ImportUnAbsorbedSketches {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import unabsorbed sketches, false to not

Visual Basic for Applications (VBA) Syntax

See [DerivedPartFeatureData::ImportUnAbsorbedSketches](#).

Example

[Modify Derived Part \(C#\)](#)
[Modify Derived Part \(VB.NET\)](#)
[Modify Derived Part \(VBA\)](#)

See Also

[IDerivedPartFeatureData Interface](#)
[IDerivedPartFeatureData Members](#)
[IDerivedPartFeatureData::ImportAbsorbedSketches Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

PartConfiguration Property (IDerivedPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPartFeatureData Interface](#) : PartConfiguration Property (IDerivedPartFeatureData)

Gets or sets the part configuration to use to create the derived part feature.

.NET Syntax

Visual Basic (Declaration)

Property PartConfiguration As System.String

Visual Basic (Usage)



```
Dim instance As IDerivedPartFeatureData
Dim value As System.String

instance.PartConfiguration = value

value = instance.PartConfiguration
```

C#

```
System.string PartConfiguration {get; set;}
```

C++/CLI

```
property System.String^ PartConfiguration {
    System.String^ get();
    void set ( &    System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the part configuration to use; Nothing or null to use the Default configuration

Visual Basic for Applications (VBA) Syntax

See [DerivedPartFeatureData::PartConfiguration](#).

See Also

[IDerivedPartFeatureData Interface](#)
[IDerivedPartFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PathName Property (IDerivedPartFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPartFeatureData Interface](#) : PathName Property (IDerivedPartFeatureData)

Gets the path for the derived part feature.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property PathName As System.String
```

Visual Basic (Usage)



```
Dim instance As IDerivedPartFeatureData
Dim value As System.String

instance.PathName = value

value = instance.PathName
```

C#

```
System.string PathName {get; set;}
```

C++/CLI

```
property System.String^ PathName {
    System.String^ get();
```

```
void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Fully qualified path and file name of the derived part feature

Visual Basic for Applications (VBA) Syntax

See [DerivedPartFeatureData::PathName](#).

Example

[Modify Derived Part \(C#\)](#)
[Modify Derived Part \(VB.NET\)](#)
[Modify Derived Part \(VBA\)](#)

See Also

[IDerivedPartFeatureData Interface](#)
[IDerivedPartFeatureData Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReleaseSelectionAccess Method (IDerivedPartFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDerivedPartFeatureData Interface](#) : ReleaseSelectionAccess Method (IDerivedPartFeatureData)

Releases access to selections that describe this derived part feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IDerivedPartFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DerivedPartFeatureData::ReleaseSelectionAccess](#).

Remarks

[IDerivedPartFeatureData::AccessSelections](#) or [IDerivedPartFeatureData::!AccessSelections](#) puts the model into a rollback state to allow access to the selections that define the feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did.

See Also

[IDerivedPartFeatureData Interface](#)
[IDerivedPartFeatureData Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0