

# SOLIDWORKS APL(.NET VBA C#) — Reference

## (70/337): IDesignTable

SOLIDWORKS API Documentation (converted from CHM)

# IDesignTable (Type)

## IDesignTable Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDesignTable Interface

Allows access to design table information and values.

**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

### .NET Syntax

Visual Basic (Declaration)

```
Public Interface IDesignTable
```

Visual Basic (Usage)



```
Dim instance As IDesignTable
```

C#

```
public interface IDesignTable
```

C++/CLI

```
public interface class IDesignTable
```

### Visual Basic for Applications (VBA) Syntax

See [DesignTable](#).

### Example

[Add Row to Design Table \(VBA\)](#)  
[Get Design Table \(C#\)](#)  
[Get Design Table \(VB.NET\)](#)  
[Get Design Table \(VBA\)](#)

### Accessors

[IModelDoc2::GetDesignTable](#) and [IModelDoc2::!GetDesignTable](#)

### Access Diagram

[DesignTable](#)

### See Also

[IDesignTable Members](#)  
[SolidWorks.Interop.sldworks Namespace](#)

## IDesignTable Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDesignTable Interface

For a list of all members of this type, see [IDesignTable members](#).

### Public Methods

| Name                                                                                                       | Description                                                      |
|------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------|
|  <a href="#">AddRow</a> | Adds a row to the design table.                                  |
|  <a href="#">Attach</a> | Activates the design table within the part or assembly document. |

|                                                                                                                              |                                                                                              |
|------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------|
|  <a href="#">Detach</a>                      | Detaches the design table from the Microsoft Excel sheet.                                    |
|  <a href="#">EditFeature</a>                | Lets you change the characteristics of the design table.                                     |
|  <a href="#">EditTable</a>                  | <b>Obsolete. Superseded by <a href="#">IDesignTable.EditTable2</a>.</b>                      |
|  <a href="#">EditTable2</a>                 | Lets you edit the design table.                                                              |
|  <a href="#">GetColumnCount</a>             | Gets the number of columns in the design table that are currently visible in the model view. |
|  <a href="#">GetEntryText</a>               | Gets the contents of the specified cell as a string regardless of the cell's data type.      |
|  <a href="#">GetEntryValue</a>              | Gets the contents of the specified cell.                                                     |
|  <a href="#">GetHeaderText</a>              | Gets the header text for the specified column.                                               |
|  <a href="#">GetRowCount</a>                | Gets the number of rows in the design table that are currently visible in the model view.    |
|  <a href="#">GetStartColumnNumber</a>       | Gets the number of the first column in which a dimension is displayed.                       |
|  <a href="#">GetStartRowNumber</a>          | Gets the number of the first row in which dimensions are displayed.                          |
|  <a href="#">GetTitle</a>                   | Gets the design table title.                                                                 |
|  <a href="#">GetTotalColumnCount</a>        | Gets the number of columns in the design table.                                              |
|  <a href="#">GetTotalRowCount</a>           | Gets the number of rows in the design table.                                                 |
|  <a href="#">GetVisibleColumnCount</a>      | Gets the number of columns visible in this design table.                                     |
|  <a href="#">GetVisibleLeftColumnNumber</a> | Gets the number of the leftmost visible column.                                              |
|  <a href="#">GetVisibleRowCount</a>         | Gets the number of rows visible in the design table.                                         |
|  <a href="#">GetVisibleTopRowNumber</a>     | Gets the number of the topmost visible row.                                                  |
|  <a href="#">IsActive</a>                   | Gets whether the design table is currently being edited.                                     |
|  <a href="#">SaveAsExcelFile</a>            | Saves the design table to a Microsoft Excel file.                                            |
|  <a href="#">SetEntryText</a>               | Sets the text value of the specified entry.                                                  |
|  <a href="#">SetEntryValue</a>             | Sets the data type and value in the specified cell.                                          |
|  <a href="#">SetRowChanged</a>            | Sets the number of the row that was changed.                                                 |
|  <a href="#">UpdateFeature</a>            | Updates the characteristics of the design table.                                             |
|  <a href="#">UpdateModel</a>              | Applies the edits to the design table to the model.                                          |
|  <a href="#">UpdateTable</a>              | Applies the changes made to the design table to the model.                                   |

[Top](#)

## See Also

[IDesignTable Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IDesignTable Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDesignTable Interface

The following tables list the members exposed by [IDesignTable](#).

## Public Properties

| Name                                                                                                                        | Description                                                                                                                      |
|-----------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
|  <a href="#">AutoAddNewConfigs</a>       | Gets or sets whether to automatically add rows or columns to the design table when new configurations are added to the model.    |
|  <a href="#">AutoAddNewParams</a>        | Gets or sets whether or not to automatically add rows or columns to the design table when new parameters are added to the model. |
|  <a href="#">ColumnHidden</a>            | Gets the visibility state of the specified column.                                                                               |
|  <a href="#">EnableCellDropdownLists</a> | Gets or sets whether to enable cell drop-down lists in the design table.                                                         |
|  <a href="#">FileName</a>                | Gets or sets the Microsoft Excel file for this design table.                                                                     |
| <a href="#">LastError</a>                                                                                                   | Gets or sets the last error that occurred in this design table.                                                                  |

[LinkToFile](#)

Gets or sets whether to link the design table to the model.

[RowHidden](#)

Gets the visibility state of the specified row.

[SourceType](#)

Gets or sets the type of source file for this design table.

[Updatable](#)

Gets or sets whether edits to the model update the design table.

[Warn](#)

Gets or sets whether to display a warning when invalid information is encountered in the design table when updating the design table.

[Worksheet](#)

Gets the Microsoft Excel worksheet for this design table.

[Top](#)

## Public Methods

| Name                                                                                                                           | Description                                                                                  |
|--------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------|
|  <a href="#">AddRow</a>                       | Adds a row to the design table.                                                              |
|  <a href="#">Attach</a>                       | Activates the design table within the part or assembly document.                             |
|  <a href="#">Detach</a>                       | Detaches the design table from the Microsoft Excel sheet.                                    |
|  <a href="#">EditFeature</a>                  | Lets you change the characteristics of the design table.                                     |
|  <a href="#">EditTable</a>                    | Obsolete. Superseded by <a href="#">IDesignTable.EditTable2</a>                              |
|  <a href="#">EditTable2</a>                   | Lets you edit the design table.                                                              |
|  <a href="#">GetColumnCount</a>               | Gets the number of columns in the design table that are currently visible in the model view. |
|  <a href="#">GetEntryText</a>                 | Gets the contents of the specified cell as a string regardless of the cell's data type.      |
|  <a href="#">GetEntryValue</a>                | Gets the contents of the specified cell.                                                     |
|  <a href="#">GetHeaderText</a>               | Gets the header text for the specified column.                                               |
|  <a href="#">GetRowCount</a>                | Gets the number of rows in the design table that are currently visible in the model view.    |
|  <a href="#">GetStartColumnNumber</a>       | Gets the number of the first column in which a dimension is displayed.                       |
|  <a href="#">GetStartRowNumber</a>          | Gets the number of the first row in which dimensions are displayed.                          |
|  <a href="#">GetTitle</a>                   | Gets the design table title.                                                                 |
|  <a href="#">GetTotalColumnCount</a>        | Gets the number of columns in the design table.                                              |
|  <a href="#">GetTotalRowCount</a>           | Gets the number of rows in the design table.                                                 |
|  <a href="#">GetVisibleColumnCount</a>      | Gets the number of columns visible in this design table.                                     |
|  <a href="#">GetVisibleLeftColumnNumber</a> | Gets the number of the leftmost visible column.                                              |
|  <a href="#">GetVisibleRowCount</a>         | Gets the number of rows visible in the design table.                                         |
|  <a href="#">GetVisibleTopRowNumber</a>     | Gets the number of the topmost visible row.                                                  |
|  <a href="#">IsActive</a>                   | Gets whether the design table is currently being edited.                                     |
|  <a href="#">SaveAsExcelFile</a>            | Saves the design table to a Microsoft Excel file.                                            |
|  <a href="#">SetEntryText</a>               | Sets the text value of the specified entry.                                                  |
|  <a href="#">SetEntryValue</a>              | Sets the data type and value in the specified cell.                                          |
|  <a href="#">SetRowChanged</a>              | Sets the number of the row that was changed.                                                 |
|  <a href="#">UpdateFeature</a>              | Updates the characteristics of the design table.                                             |
|  <a href="#">UpdateModel</a>                | Applies the edits to the design table to the model.                                          |
|  <a href="#">UpdateTable</a>                | Applies the changes made to the design table to the model.                                   |

[Top](#)

## See Also

[IDesignTable Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)

# IDesignTable Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDesignTable Interface

For a list of all members of this type, see [IDesignTable members](#).

## Public Properties

| Name                                                                                                                      | Description                                                                                                                           |
|---------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|
|  <a href="#">AutoAddNewConfigs</a>       | Gets or sets whether to automatically add rows or columns to the design table when new configurations are added to the model.         |
|  <a href="#">AutoAddNewParams</a>        | Gets or sets whether or not to automatically add rows or columns to the design table when new parameters are added to the model.      |
|  <a href="#">ColumnHidden</a>            | Gets the visibility state of the specified column.                                                                                    |
|  <a href="#">EnableCellDropdownLists</a> | Gets or sets whether to enable cell drop-down lists in the design table.                                                              |
|  <a href="#">FileName</a>                | Gets or sets the Microsoft Excel file for this design table.                                                                          |
|  <a href="#">LastError</a>               | Gets or sets the last error that occurred in this design table.                                                                       |
|  <a href="#">LinkToFile</a>              | Gets or sets whether to link the design table to the model.                                                                           |
|  <a href="#">RowHidden</a>               | Gets the visibility state of the specified row.                                                                                       |
|  <a href="#">SourceType</a>              | Gets or sets the type of source file for this design table.                                                                           |
|  <a href="#">Updatetable</a>             | Gets or sets whether edits to the model update the design table.                                                                      |
|  <a href="#">Warn</a>                    | Gets or sets whether to display a warning when invalid information is encountered in the design table when updating the design table. |
|  <a href="#">Worksheet</a>               | Gets the Microsoft Excel worksheet for this design table.                                                                             |

[Top](#)

## See Also

[IDesignTable Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)

# AddRow Method (IDesignTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : AddRow Method (IDesignTable)

Adds a row to the design table.

## .NET Syntax

Visual Basic (Declaration)

```
Function AddRow( _  
    ByVal CellValues As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IDesignTable  
Dim CellValues As System.Object  
Dim value As System.Boolean
```

```
value = instance.AddRow(CellValues)
```

C#

```
System.bool AddRow(  
    System.object CellValues  
)
```

C++/CLI



```
System.bool AddRow(  
& System.Object^ CellValues  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*CellValues*  
Array of the cell values

#### Return Value

True if the row was successfully added, false if not

### Visual Basic for Applications (VBA) Syntax

See [DesignTable::AddRow](#).

### Example

[Add Row to Design Table \(VBA\)](#)

### Remarks

Do not use [IDesignTable::Attach](#) or [IDesignTable::Detach](#) with this method. Instead, use [IDesignTable::EditTable2](#) and [IDesignTable::UpdateTable](#).

### See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::GetRowCount Method](#)  
[IDesignTable::GetTotalRowCount Method](#)  
[IDesignTable::GetVisibleRowCount Method](#)  
[IDesignTable::GetVisibleTopRowNumber Method](#)  
[IDesignTable::SetRowChanged Method](#)  
[IDesignTable::RowHidden Property](#)  
[IDesignTable::AutoAddNewConfigs Property](#)  
[IDesignTable::AutoAddNewParams Property](#)

### Availability

SOLIDWORKS 2001 SP01, Revision Number 8.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Attach Method (IDesignTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : Attach Method (IDesignTable)

Activates the design table within the part or assembly document.

### .NET Syntax

Visual Basic (Declaration)

```
Function Attach() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim value As System.Boolean  
  
value = instance.Attach()
```

C#

```
System.bool Attach()
```

C++/CLI

```
System.bool Attach();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

True if the design table is successfully activated, false if not

### Visual Basic for Applications (VBA) Syntax

See [DesignTable::Attach](#).

### Example

[Get Microsoft Excel Design Table Worksheet \(VBA\)](#)  
[Save Design Table as Microsoft Excel File \(VBA\)](#)  
[Get Design Table \(C#\)](#)  
[Get Design Table \(VB.NET\)](#)  
[Get Design Table \(VBA\)](#)

### Remarks

If you want SOLIDWORKS to run in the background, then do not use this method. Using this method will cause SOLIDWORKS to become visible.

Do not use this method and [IDesignTable::EditTable2](#) in the same macro. Using IDesignTable::EditTable2 is preferable because it returns a pointer to the Microsoft Excel worksheet being operated on.

If you use IDesignTable::Attach, then you must call this method before calling any of the other IDesignTable methods. When your application is finished extracting data from the design table, use [IDesignTable::Detach](#) to detach the IDesignTable object from the Microsoft Excel object.

### See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## AutoAddNewConfigs Property (IDesignTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : AutoAddNewConfigs Property (IDesignTable)

Gets or sets whether to automatically add rows or columns to the design table when new configurations are added to the model.

### .NET Syntax

#### Visual Basic (Declaration)

```
Property AutoAddNewConfigs As System.Boolean
```

#### Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim value As System.Boolean  
  
instance.AutoAddNewConfigs = value  
  
value = instance.AutoAddNewConfigs
```

#### C#

```
System.bool AutoAddNewConfigs {get; set;}
```

#### C++/CLI

```
property System.bool AutoAddNewConfigs {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True to automatically add rows or columns, false to not

### Visual Basic for Applications (VBA) Syntax

See [DesignTable::AutoAddNewConfigs](#).

### Remarks

You must call:

- [IDesignTable::EditFeature](#) before setting this property.
- [IDesignTable::UpdateFeature](#) after setting this property.

### See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::AddRow Method](#)  
[IDesignTable::AutoAddNewParams Property](#)  
[IDesignTable::GetColumnCount Method](#)  
[IDesignTable::GetRowCount Method](#)  
[IDesignTable::GetStartColumnNumber Method](#)  
[IDesignTable::GetStartRowNumber Method](#)  
[IDesignTable::GetTotalColumnCount Method](#)  
[IDesignTable::GetTotalRowCount Method](#)  
[IDesignTable::GetVisibleColumnCount Method](#)  
[IDesignTable::GetVisibleLeftColumnNumber Method](#)  
[IDesignTable::GetVisibleRowCount Method](#)  
[IDesignTable::GetVisibleTopRowNumber Method](#)  
[IDesignTable::ColumnHidden Property](#)  
[IDesignTable::RowHidden Property](#)

### Availability

SOLIDWORKS 2004 SP3, Revision Number 12.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

## AutoAddNewParams Property (IDesignTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : AutoAddNewParams Property (IDesignTable)

Gets or sets whether or not to automatically add rows or columns to the design table when new parameters are added to the model.

### .NET Syntax

Visual Basic (Declaration)

```
Property AutoAddNewParams As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim value As System.Boolean  
  
instance.AutoAddNewParams = value  
  
value = instance.AutoAddNewParams
```

C#

```
System.bool AutoAddNewParams {get; set;}
```

C++/CLI

```
property System.bool AutoAddNewParams {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Property Value

True to automatically add rows or columns, false to not

## Visual Basic for Applications (VBA) Syntax

See [DesignTable::AutoAddNewParams](#).

## Remarks

You must call:

- [IDesignTable::EditFeature](#) before setting this property.
- [IDesignTable::UpdateFeature](#) after setting this property.

## See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::AddRow Method](#)  
[IDesignTable::GetColumnCount Method](#)  
[IDesignTable::GetRowCount Method](#)  
[IDesignTable::GetStartColumnNumber Method](#)  
[IDesignTable::GetStartRowNumber Method](#)  
[IDesignTable::GetTotalColumnCount Method](#)  
[IDesignTable::GetVisibleRowCount Method](#)  
[IDesignTable::GetVisibleTopRowNumber Method](#)  
[IDesignTable::AutoAddNewConfigs Property](#)  
[IDesignTable::ColumnHidden Property](#)  
[IDesignTable::RowHidden Property](#)

## Availability

SOLIDWORKS 2004 SP3, Revision Number 12.3

SOLIDWORKS API Help

[Send comments](#) on this topic.

## ColumnHidden Property (IDesignTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : ColumnHidden Property (IDesignTable)

Gets the visibility state of the specified column.

## .NET Syntax

### Visual Basic (Declaration)

```
ReadOnly Property ColumnHidden( _  
    ByVal Col As System.Integer _  
) As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim Col As System.Integer  
Dim value As System.Boolean  
  
value = instance.ColumnHidden(Col)
```

### C#

```
System.bool ColumnHidden(  
    System.int Col  
) {get;}
```

### C++/CLI

```
property System.bool ColumnHidden {  
    System.bool get(System.int Col);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Parameters

Col  
Column for which to get its visibility state; 1 is the first column

**Property Value**

True if hidden, false if visible

 **Visual Basic for Applications (VBA) Syntax**

See [DesignTable::ColumnHidden](#).

 **See Also**

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::GetColumnCount Method](#)  
[IDesignTable::GetStartColumnNumber Method](#)  
[IDesignTable::GetTotalColumnCount Method](#)  
[IDesignTable::GetVisibleColumnCount Method](#)  
[IDesignTable::GetVisibleLeftColumnNumber Method](#)  
[IDesignTable::RowHidden Property](#)

 **Availability**

SOLIDWORKS 2003 SP4, Revision Number 11.4

SOLIDWORKS API Help

[Send comments](#) on this topic.

**Detach Method (IDesignTable)**

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : Detach Method (IDesignTable)

Detaches the design table from the Microsoft Excel sheet.

 **.NET Syntax**

Visual Basic (Declaration)

Sub Detach()

Visual Basic (Usage)



Dim instance As [IDesignTable](#)

instance.Detach()

C#

void Detach()

C++/CLI

void Detach();

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

 **Visual Basic for Applications (VBA) Syntax**

See [DesignTable::Detach](#).

 **Example**

[Get Microsoft Excel Design Table Worksheet \(VBA\)](#)  
[Save Design Table as Microsoft Excel File \(VBA\)](#)  
[Get Design Table \(VBA\)](#)  
[Get Design Table \(VB.NET\)](#)  
[Get Design Table \(C#\)](#)

 **Remarks**

Call this method after you have finished using the other [IDesignTable](#) methods.

This function does not specifically deactivate the design table.

## See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::Attach Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## EditFeature Method (IDesignTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : EditFeature Method (IDesignTable)

Lets you change the characteristics of the design table.

## .NET Syntax

Visual Basic (Declaration)

```
Sub EditFeature()
```

Visual Basic (Usage)



```
Dim instance As IDesignTable  
  
instance.EditFeature()
```

C#

```
void EditFeature()
```

C++/CLI

```
void EditFeature();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Visual Basic for Applications (VBA) Syntax

See [DesignTable::EditFeature](#).

## Example

[Get or Set Whether Edits Update the Design Table \(VBA\)](#)  
[Disable Cell Drop-down Lists in Design Table \(C#\)](#)  
[Disable Cell Drop-down Lists in Design Table \(VB.NET\)](#)  
[Disable Cell Drop-down Lists in Design Table \(VBA\)](#)

## See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::EditTable2 Method](#)  
[IDesignTable::UpdateTable Property](#)  
[IDesignTable::UpdateFeature Method](#)  
[IDesignTable::UpdateModel Method](#)  
[IDesignTable::UpdateTable Method](#)  
[IDesignTable::IsActive Method](#)

## Availability

SOLIDWORKS 2004 SP3, Revision Number 12.3

SOLIDWORKS API Help

[Send comments](#) on this topic.

## EditTable Method (IDesignTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : EditTable Method (IDesignTable)

Obsolete. Superseded by [IDesignTable::EditTable2](#).

## .NET Syntax

### Visual Basic (Declaration)

```
Sub EditTable()
```

### Visual Basic (Usage)



```
Dim instance As IDesignTable  
  
instance.EditTable()
```

### C#

```
void EditTable()
```

### C++/CLI

```
void EditTable();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Visual Basic for Applications (VBA) Syntax

See [DesignTable::EditTable](#).

## See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## EditTable2 Method (IDesignTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : EditTable2 Method (IDesignTable)

Lets you edit the design table.

## .NET Syntax

### Visual Basic (Declaration)

```
Function EditTable2( _  
    ByVal NewWindow As System.Boolean _  
) As System.Object
```

### Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim NewWindow As System.Boolean  
Dim value As System.Object  
  
value = instance.EditTable2(NewWindow)
```

### C#

```
System.object EditTable2(  
    System.bool NewWindow  
)
```

### C++/CLI

```
System.Object^ EditTable2(  
&    System.bool NewWindow  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Parameters

### *NewWindow*

True to edit the design table in a separate window, false to not

## Return Value

Microsoft Excel worksheet for this design table

## Visual Basic for Applications (VBA) Syntax

See [DesignTable::EditTable2](#).

## Example

[Disable Cell Drop-down Lists in Design Table \(C#\)](#)  
[Disable Cell Drop-down Lists in Design Table \(VB.NET\)](#)  
[Disable Cell Drop-down Lists in Design Table \(VBA\)](#)

## Remarks

Do not use this method and [IDesignTable::Attach](#) in the same macro. Using IDesignTable::EditTable2 is preferable because it returns a pointer to the Microsoft Excel worksheet being operated on.

To avoid problems with zooming, set bNewWindow to True.

You can change the parameter values in the cells, add rows for additional configurations, or add columns to control additional parameters.

If the return value of this method is assigned to a variable, then it must be released before closing the design table with [IDesignTable::UpdateTable](#)(type, True).

## See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::IsActive Method](#)  
[IDesignTable::Updatable Property](#)  
[IDesignTable::UpdateModel Method](#)  
[IDesignTable::UpdateFeature Method](#)

## Availability

SOLIDWORKS 2006 SP4, Revision Number 14.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

## EnableCellDropdownLists Property (IDesignTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : EnableCellDropdownLists Property (IDesignTable)

Gets or sets whether to enable cell drop-down lists in the design table.

## .NET Syntax

### Visual Basic (Declaration)

Property EnableCellDropdownLists As System.Boolean

### Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim value As System.Boolean  
  
instance.EnableCellDropdownLists = value  
  
value = instance.EnableCellDropdownLists
```

### C#

```
System.bool EnableCellDropdownLists {get; set;}
```

### C++/CLI

```
property System.bool EnableCellDropdownLists {
    System.bool get();
    void set ( & System.bool value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True to enable cell drop-down lists in the design table, false to disable them

### Visual Basic for Applications (VBA) Syntax

See [DesignTable::EnableCellDropdownLists](#).

### Example

[Disable Cell Drop-down Lists in Design Table \(C#\)](#)  
[Disable Cell Drop-down Lists in Design Table \(VB.NET\)](#)  
[Disable Cell Drop-down Lists in Design Table \(VBA\)](#)

### Remarks

You must call:

- [IDesignTable::EditFeature](#) before setting this property.
- [IDesignTable::UpdateFeature](#) after setting this property.

### See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)

### Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## FileName Property (IDesignTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : FileName Property (IDesignTable)

Gets or sets the Microsoft Excel file for this design table.

### .NET Syntax

Visual Basic (Declaration)

Property FileName As System.String

Visual Basic (Usage)



```
Dim instance As IDesignTable
Dim value As System.String
```

```
instance.FileName = value
```

```
value = instance.FileName
```

C#

```
System.string FileName {get; set;}
```

C++/CLI

```
property System.String^ FileName {
    System.String^ get();
    void set ( & System.String^ value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Full path and filename for the Microsoft Excel file

### Visual Basic for Applications (VBA) Syntax

See [DesignTable::FileName](#).

### See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::SaveAsExcelFile Method](#)  
[IDesignTable::LinkToFile Property](#)  
[IDesignTable::SourceType Property](#)

### Availability

SOLIDWORKS 2004 SP3, Revision Number 12.3

SOLIDWORKS API Help

[Send comments](#) on this topic.

## GetColumnCount Method (IDesignTable)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : GetColumnCount Method (IDesignTable)

Gets the number of columns in the design table that are currently visible in the model view.

### .NET Syntax

Visual Basic (Declaration)

```
Function GetColumnCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim value As System.Integer
```

```
value = instance.GetColumnCount()
```

C#

```
System.int GetColumnCount()
```

C++/CLI

```
System.int GetColumnCount();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Number of columns in the design table

### Visual Basic for Applications (VBA) Syntax

See [DesignTable::GetColumnCount](#).

### Example

[Get Design Table \(VBA\)](#)  
[Get Design Table \(VB.NET\)](#)  
[Get Design Table \(C#\)](#)

## Remarks

Before using any of the [IDesignTable](#) methods, you must use [IDesignTable::Attach](#) to activate the design table. After you finish getting design table data, use [IDesignTable::Detach](#) to deactivate the table.

Use [IDesignTable::GetTotalColumnCount](#) to get the total number of columns in the design table.

To obtain information outside the visible region of the design table, get the Microsoft Excel worksheet that [IDesignTable::Attach](#) activated. You can then use the Microsoft Excel API to make additional queries.

## See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::GetStartColumnNumber Method](#)  
[IDesignTable::GetVisibleLeftColumnNumber Method](#)  
[IDesignTable::ColumnHidden Property](#)  
[IDesignTable::GetVisibleColumnCount Method](#)  
[IDesignTable::GetHeaderText Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetEntryText Method (IDesignTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : GetEntryText Method (IDesignTable)

Gets the contents of the specified cell as a string regardless of the cell's data type.

## .NET Syntax

Visual Basic (Declaration)

```
Function GetEntryText( _  
    ByVal Row As System.Integer, _  
    ByVal Col As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim Row As System.Integer  
Dim Col As System.Integer  
Dim value As System.String  
  
value = instance.GetEntryText(Row, Col)
```

C#

```
System.string GetEntryText(  
    System.int Row,  
    System.int Col  
)
```

C++/CLI

```
System.String^ GetEntryText(  
& System.int Row,  
& System.int Col  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

*Row*  
0-based row number of the cell

*Col*  
0-based column number of the cell

### Return Value

Text string in the specified cell

## Visual Basic for Applications (VBA) Syntax

See [DesignTable::GetEntryText](#).

## Example

[Get Design Table \(VBA\)](#)  
[Get Design Table \(VB.NET\)](#)  
[Get Design Table \(C#\)](#)

## Remarks

For example, if the cell is of type double, it is returned as a string.

Use [IDesignTable::GetEntryValue](#) to get typed return values.

Before using any of the [IDesignTable](#) methods, use [IDesignTable::Attach](#) to activate the design table. After you are finish getting design table data, use [IDesignTable::Detach](#) to deactivate the table.

## See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::GetEntryValue Method](#)  
[IDesignTable::SetEntryText Method](#)  
[IDesignTable::SetEntryValue Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetEntryValue Method (IDesignTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : GetEntryValue Method (IDesignTable)

Gets the contents of the specified cell.

## .NET Syntax

### Visual Basic (Declaration)

```
Function GetEntryValue( _  
    ByVal Row As System.Integer, _  
    ByVal Col As System.Integer _  
) As System.Object
```

### Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim Row As System.Integer  
Dim Col As System.Integer  
Dim value As System.Object  
  
value = instance.GetEntryValue(Row, Col)
```

### C#

```
System.object GetEntryValue(  
    System.int Row,  
    System.int Col  
)
```

### C++/CLI

```
System.Object^ GetEntryValue(  
& System.int Row,  
& System.int Col  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Parameters

*Row*  
0-based row number of the cell  
*Col*  
0-based column number of the cell

#### Return Value

Object containing the information from the specified cell

### Visual Basic for Applications (VBA) Syntax

See [DesignTable::GetEntryValue](#).

### Remarks

After you receive a valid return value from this method, you can evaluate the the data type of the object (for example, double, long, or string).

Use [IDesignTable::GetEntryText](#) to return the cell contents as a string.

Before you use any of the design table methods, you must first activate the design table using [IDesignTable::Attach](#). After you are finished getting design table data, you can deactivate the table using [IDesignTable::Detach](#).

### See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::GetEntryText Method](#)  
[IDesignTable::SetEntryText Method](#)  
[IDesignTable::SetEntryValue Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetHeaderText Method (IDesignTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : GetHeaderText Method (IDesignTable)

Gets the header text for the specified column.

### .NET Syntax

#### Visual Basic (Declaration)

```
Function GetHeaderText( _  
    ByVal Col As System.Integer _  
) As System.String
```

#### Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim Col As System.Integer  
Dim value As System.String  
  
value = instance.GetHeaderText(Col)
```

#### C#

```
System.string GetHeaderText(  
    System.int Col  
)
```

#### C++/CLI

```
System.String^ GetHeaderText(  
& System.int Col  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*Col*  
0-based column number with the header text

#### Return Value

Text string from the column header

#### Visual Basic for Applications (VBA) Syntax

See [DesignTable::GetHeaderText](#).

#### Remarks

Before you use any of the design table methods, you must first activate the design table using [IDesignTable::Attach](#). After you are finished getting design table data, you can deactivate the table using [IDesignTable::Detach](#).

#### See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::GetColumnCount Method](#)  
[IDesignTable::GetStartColumnNumber Method](#)  
[IDesignTable::GetTotalColumnCount Method](#)  
[IDesignTable::GetVisibleColumnCount Method](#)  
[IDesignTable::GetVisibleLeftColumnNumber Method](#)  
[IDesignTable::ColumnHidden Property](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetRowCount Method (IDesignTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : GetRowCount Method (IDesignTable)

Gets the number of rows in the design table that are currently visible in the model view.

#### .NET Syntax

Visual Basic (Declaration)

```
Function GetRowCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim value As System.Integer  
  
value = instance.GetRowCount()
```

C#

```
System.int GetRowCount()
```

C++/CLI

```
System.int GetRowCount();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Number of rows currently visible in the model view

#### Visual Basic for Applications (VBA) Syntax

See [DesignTable::GetRowCount](#).

#### Example

[Get Design Table \(VBA\)](#)  
[Get Design Table \(VB.NET\)](#)  
[Get Design Table \(C#\)](#)

#### Remarks

Before you use any of the [IDesignTable](#) methods, you must first activate the IDesignTable using [IDesignTable::Attach](#). Once you are finished getting IDesignTable data, you can deactivate the table using [IDesignTable::Detach](#).

Use [IDesignTable::GetTotalRowCount](#) to get the total number of rows in the design table.

To get information outside the visible region of the IDesignTable, get the Microsoft Excel worksheet activated by IDesignTable::Attach. Then, you can use the Microsoft Excel API to make additional queries.

## See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::GetStartRowIndex Method](#)  
[IDesignTable::GetVisibleRowCount Method](#)  
[IDesignTable::GetVisibleTopRowIndex Method](#)  
[IDesignTable::SetRowChanged Method](#)  
[IDesignTable::RowHidden Property](#)  
[IDesignTable::AddRow Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetStartColumnNumber Method (IDesignTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : GetStartColumnNumber Method (IDesignTable)

Gets the number of the first column in which a dimension is displayed.

## .NET Syntax

Visual Basic (Declaration)

```
Function GetStartColumnNumber() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim value As System.Integer
```

```
value = instance.GetStartColumnNumber()
```

C#

```
System.int GetStartColumnNumber()
```

C++/CLI

```
System.int GetStartColumnNumber();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Return Value

Number of the first column in which a dimensions is displayed

## Visual Basic for Applications (VBA) Syntax

See [DesignTable::GetStartColumnNumber](#).

## Example

[Get Microsoft Excel Design Table Worksheet \(VBA\)](#)

## See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::GetColumnCount Method](#)  
[IDesignTable::GetTotalColumnCount Method](#)  
[IDesignTable::GetVisibleLeftColumnNumber Method](#)  
[IDesignTable::ColumnHidden Property](#)  
[IDesignTable::GetStartRowIndex Method](#)

## Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

## GetStartRowNumber Method (IDesignTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : GetStartRowNumber Method (IDesignTable)

Gets the number of the first row in which dimensions are displayed.

### .NET Syntax

Visual Basic (Declaration)

```
Function GetStartRowNumber() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim value As System.Integer  
  
value = instance.GetStartRowNumber()
```

C#

```
System.int GetStartRowNumber()
```

C++/CLI

```
System.int GetStartRowNumber();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Number of the first row in which dimensions are displayed

### Visual Basic for Applications (VBA) Syntax

See [DesignTable::GetStartRowNumber](#).

### Example

[Get Microsoft Excel Design Table Worksheet \(VBA\)](#)

### See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::GetRowCount Method](#)  
[IDesignTable::GetStartColumnNumber Method](#)  
[IDesignTable::GetTotalRowCount Method](#)  
[IDesignTable::GetVisibleRowCount Method](#)  
[IDesignTable::GetVisibleTopRowNumber Method](#)  
[IDesignTable::RowHidden Property](#)  
[IDesignTable::AddRow Method](#)

### Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

## GetTitle Method (IDesignTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : GetTitle Method (IDesignTable)

Gets the design table title.

### .NET Syntax

Visual Basic (Declaration)

## Function GetTitle() As System.String

Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim value As System.String  
  
value = instance.GetTitle()
```

C#

```
System.string GetTitle()
```

C++/CLI

```
System.String^ GetTitle();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Return Value

Design table title

## Visual Basic for Applications (VBA) Syntax

See [DesignTable::GetTitle](#).

## Example

[Get Design Table \(VBA\)](#)  
[Get Design Table \(VB.NET\)](#)  
[Get Design Table \(C#\)](#)

## Remarks

This method returns the title of the design table. If the title row is absent, then this method returns an empty string. If the title row exists but there is no title, then this method returns a single space.

## See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)

## Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetTotalColumnCount Method (IDesignTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : GetTotalColumnCount Method (IDesignTable)

Gets the number of columns in the design table.

## .NET Syntax

Visual Basic (Declaration)

```
Function GetTotalColumnCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim value As System.Integer  
  
value = instance.GetTotalColumnCount()
```

C#

```
System.int GetTotalColumnCount()
```

C++/CLI

```
System.int GetTotalColumnCount();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Number of columns in the design table

### Visual Basic for Applications (VBA) Syntax

See [DesignTable::GetTotalColumnCount](#).

### Example

[Get Microsoft Excel Design Table Worksheet \(VBA\)](#)  
[Get Design Table \(C#\)](#)  
[Get Design Table \(VB.NET\)](#)  
[Get Design Table \(VBA\)](#)

### Remarks

The column index ranges from 1 to the return value.

Before you use any of the [IDesignTable](#) methods, use [IDesignTable::Attach](#) to activate the IDesignTable. After you finish getting IDesignTable data, use [IDesignTable::Detach](#) to deactivate the table.

This method differs from [IDesignTable::GetColumnCount](#) in that it counts all the columns in the design table. IDesignTable::GetColumnCount counts only the columns that are currently visible in the [IModelView](#).

To get information outside of the visible region of the design table, get the Microsoft Excel worksheet activated by IDesignTable::Attach. Then, you can use the Microsoft Excel API to make additional queries.

### See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::GetColumnCount Method](#)  
[IDesignTable::GetStartColumnNumber Method](#)  
[IDesignTable::GetVisibleColumnCount Method](#)  
[IDesignTable::GetVisibleLeftColumnNumber Method](#)  
[IDesignTable::ColumnHidden Property](#)

### Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetTotalRowCount Method (IDesignTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : GetTotalRowCount Method (IDesignTable)

Gets the number of rows in the design table.

### .NET Syntax

Visual Basic (Declaration)

```
Function GetTotalRowCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim value As System.Integer
```

```
value = instance.GetTotalRowCount()
```

C#

```
System.int GetTotalRowCount()
```

C++/CLI

```
System.int GetTotalRowCount();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Total number of rows in this design table

### Visual Basic for Applications (VBA) Syntax

See [DesignTable::GetTotalRowCount](#).

### Example

[Get Design Table \(C#\)](#)  
[Get Design Table \(VB.NET\)](#)  
[Get Design Table \(VBA\)](#)

### Remarks

The row index ranges from 1 to the return value.

Before you use any of the [IDesignTable](#) methods, use [IDesignTable::Attach](#) to activate the IDesignTable. After you finish getting IDesignTable data, use [IDesignTable::Detach](#) to deactivate the table.

This method differs from [IDesignTable::GetRowCount](#) in that it counts all the rows in the design table. IDesignTable::GetRowCount counts only the rows that are currently visible in the [IModelView](#).

To get information outside of the visible region of the design table, get the Microsoft Excel worksheet activated by IDesignTable::Attach. Then, you can use the Microsoft Excel API to make additional queries.

### See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::AddRow Method](#)  
[IDesignTable::GetRowCount Method](#)  
[IDesignTable::GetStartRowIndex Method](#)  
[IDesignTable::GetVisibleRowCount Method](#)  
[IDesignTable::GetVisibleTopRowIndex Method](#)  
[IDesignTable::RowHidden Property](#)

### Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetVisibleColumnCount Method (IDesignTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : GetVisibleColumnCount Method (IDesignTable)

Gets the number of columns visible in this design table.

### .NET Syntax

Visual Basic (Declaration)

```
Function GetVisibleColumnCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim value As System.Integer
```

```
value = instance.GetVisibleColumnCount()
```

C#

```
System.int GetVisibleColumnCount()
```

C++/CLI

```
System.int GetVisibleColumnCount();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Number of columns visible in this design table

### Visual Basic for Applications (VBA) Syntax

See [DesignTable::GetVisibleColumnCount](#).

### Example

[Get Microsoft Design Table Worksheet \(VBA\)](#)  
[Get Design Table \(VBA\)](#)  
[Get Design Table \(VB.NET\)](#)  
[Get Design Table \(C#\)](#)

### See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::GetColumnCount Method](#)  
[IDesignTable::GetStartColumnNumber Method](#)  
[IDesignTable::GetVisibleLeftColumnNumber Method](#)  
[IDesignTable::ColumnHidden Property](#)  
[IDesignTable::GetTotalColumnCount Method](#)

### Availability

SOLIDWORKS 2000 SP01, Revision Number 8.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetVisibleLeftColumnNumber Method (IDesignTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : GetVisibleLeftColumnNumber Method (IDesignTable)

Gets the number of the leftmost visible column.

### .NET Syntax

Visual Basic (Declaration)

```
Function GetVisibleLeftColumnNumber() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim value As System.Integer  
  
value = instance.GetVisibleLeftColumnNumber()
```

C#

```
System.int GetVisibleLeftColumnNumber()
```

C++/CLI

```
System.int GetVisibleLeftColumnNumber();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Number of the leftmost visible column

## Visual Basic for Applications (VBA) Syntax

See [DesignTable::GetVisibleLeftColumnNumber](#).

## Example

[Get Microsoft Excel Design Table Worksheet \(VBA\)](#)

## See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::GetColumnCount Method](#)  
[IDesignTable::GetStartColumnNumber Method](#)  
[IDesignTable::GetTotalColumnCount Method](#)  
[IDesignTable::GetVisibleColumnCount Method](#)  
[IDesignTable::ColumnHidden Property](#)

## Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## GetVisibleRowCount Method (IDesignTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : GetVisibleRowCount Method (IDesignTable)

Gets the number of rows visible in the design table.

## .NET Syntax

### Visual Basic (Declaration)

```
Function GetVisibleRowCount() As System.Integer
```

### Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim value As System.Integer  
  
value = instance.GetVisibleRowCount()
```

### C#

```
System.int GetVisibleRowCount()
```

### C++/CLI

```
System.int GetVisibleRowCount();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Return Value

Number of rows visible in the design table

## Visual Basic for Applications (VBA) Syntax

See [DesignTable::GetVisibleRowCount](#).

## Example

[Get Microsoft Excel Design Table Worksheet \(VBA\)](#)  
[Get Design Table \(C#\)](#)  
[Get Design Table \(VB.NET\)](#)  
[Get Design Table \(VBA\)](#)

## See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::AddRow Method](#)  
[IDesignTable::GetRowCount Method](#)  
[IDesignTable::GetStartRowIndex Method](#)  
[IDesignTable::GetTotalRowCount Method](#)  
[IDesignTable::GetVisibleTopRowIndex Method](#)  
[IDesignTable::RowHidden Property](#)

## Availability

SOLIDWORKS 2000 SP01, Revision Number 8.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetVisibleTopRowIndex Method (IDesignTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : GetVisibleTopRowIndex Method (IDesignTable)

Gets the number of the topmost visible row.

## .NET Syntax

Visual Basic (Declaration)

```
Function GetVisibleTopRowIndex() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim value As System.Integer  
  
value = instance.GetVisibleTopRowIndex()
```

C#

```
System.int GetVisibleTopRowIndex()
```

C++/CLI

```
System.int GetVisibleTopRowIndex();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Return Value

Number of the topmost visible row

## Visual Basic for Applications (VBA) Syntax

See [DesignTable::GetVisibleTopRowIndex](#).

## Example

[Get Microsoft Excel Design Table Worksheet \(VBA\)](#)

## See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::AddRow Method](#)  
[IDesignTable::GetRowCount Method](#)  
[IDesignTable::GetStartRowIndex Method](#)  
[IDesignTable::GetTotalRowCount Method](#)  
[IDesignTable::GetVisibleTopRowIndex Method](#)  
[IDesignTable::RowHidden Property](#)

## Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IsActive Method (IDesignTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : IsActive Method (IDesignTable)

Gets whether the design table is currently being edited.

### .NET Syntax

Visual Basic (Declaration)

```
Function IsActive() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim value As System.Boolean  
  
value = instance.IsActive()
```

C#

```
System.bool IsActive()
```

C++/CLI

```
System.bool IsActive();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

True If design table is currently being edited, false if not

### Visual Basic for Applications (VBA) Syntax

See [DesignTable::IsActive](#).

### Example

[Save Design Table as Microsoft Excel File \(VBA\)](#)

### See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::EditFeature Method](#)  
[IDesignTable::EditTable2 Method](#)  
[IDesignTable::UpdateFeature Method](#)  
[IDesignTable::UpdateModel Method](#)  
[IDesignTable::UpdateTable Method](#)  
[IDesignTable::Updatable Property](#)

### Availability

SOLIDWORKS 2005 SP1, Revision Number 13.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

## LastError Property (IDesignTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : LastError Property (IDesignTable)

Gets or sets the last error that occurred in this design table.

### .NET Syntax

Visual Basic (Declaration)

```
Property LastError As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim value As System.Integer
```

```
instance.LastError = value
```

```
value = instance.LastError
```

C#

```
System.int LastError {get; set;}
```

C++/CLI

```
property System.int LastError {  
    System.int get();  
    void set ( &    System.int value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Last error that occurred in this design table as defined in [swDesignTableErrors\\_e](#)

#### Visual Basic for Applications (VBA) Syntax

See [DesignTable::LastError](#).

#### Remarks

Getting this property returns the last error generated by a request to modify the design table. Setting this property allows you to clear the last design table error that occurred.

#### See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)

#### Availability

SOLIDWORKS 2008 SP4, Revision Number 16.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

### LinkToFile Property (IDesignTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : LinkToFile Property (IDesignTable)

Gets or sets whether to link the design table to the model.

#### .NET Syntax

Visual Basic (Declaration)

```
Property LinkToFile As System.Boolean
```

Visual Basic (Usage)

 Copy Code

```
Dim instance As IDesignTable  
Dim value As System.Boolean
```

```
instance.LinkToFile = value
```

```
value = instance.LinkToFile
```

C#

```
System.bool LinkToFile {get; set;}
```

C++/CLI

```
property System.bool LinkToFile {
    System.bool get();
    void set ( & System.bool value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True to link the design table to the model, false to not

### Visual Basic for Applications (VBA) Syntax

See [DesignTable::LinkToFile](#).

### Remarks

When a design table is linked to the model, any changes you make to the design table outside of the SOLIDWORKS Design software are reflected in the design table within the SOLIDWORKS Design model, and vice versa.

### See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::FileName Property](#)  
[IDesignTable::SourceType Property](#)  
[IDesignTable::UpdateModel Method](#)

### Availability

SOLIDWORKS 2004 SP3, Revision Number 12.3

SOLIDWORKS API Help

[Send comments](#) on this topic.

## RowHidden Property (IDesignTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : RowHidden Property (IDesignTable)

Gets the visibility state of the specified row.

### .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property RowHidden( _
    ByVal Row As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDesignTable
Dim Row As System.Integer
Dim value As System.Boolean
```

```
value = instance.RowHidden(Row)
```

C#

```
System.bool RowHidden(
    System.int Row
) {get;}
```

C++/CLI

```
property System.bool RowHidden {
    System.bool get(System.int Row);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

Row  
Row for which to get its visibility state; 1 is the first row

#### Property Value

True if hidden, false if visible

## Visual Basic for Applications (VBA) Syntax

See [DesignTable::RowHidden](#).

## See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::AddRow Method](#)  
[IDesignTable::GetRowCount Method](#)  
[IDesignTable::GetStartColumnNumber Method](#)  
[IDesignTable::GetStartRowNumber Method](#)  
[IDesignTable::GetVisibleRowCount Method](#)  
[IDesignTable::GetVisibleTopRowNumber Method](#)  
[IDesignTable::ColumnHidden Property](#)

## Availability

SOLIDWORKS 2003 SP4, Revision Number 11.4

SOLIDWORKS API Help

[Send comments](#) on this topic.

## SaveAsExcelFile Method (IDesignTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : SaveAsExcelFile Method (IDesignTable)

Saves the design table to a Microsoft Excel file.

## .NET Syntax

### Visual Basic (Declaration)

```
Function SaveAsExcelFile( _  
    ByVal Value As System.String _  
) As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim Value As System.String  
Dim value As System.Boolean  
  
value = instance.SaveAsExcelFile(Value)
```

### C#

```
System.bool SaveAsExcelFile(  
    System.string Value  
)
```

### C++/CLI

```
System.bool SaveAsExcelFile(  
&    System.String^ Value  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*Value*  
Path and filename for the Microsoft Excel file

#### Return Value

True if the design table is saved to a Microsoft Excel file, false if not

## Visual Basic for Applications (VBA) Syntax

See [DesignTable::SaveAsExcelFile](#).

## Example

[Save Design Table as Microsoft Excel File \(VBA\)](#)

## See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::FileName Property](#)  
[IDesignTable::SourceType Property](#)

## Availability

SOLIDWORKS 2004 SP4, Revision Number 12.4

SOLIDWORKS API Help

[Send comments](#) on this topic.

## SetEntryText Method (IDesignTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : SetEntryText Method (IDesignTable)

Sets the text value of the specified entry.

## .NET Syntax

### Visual Basic (Declaration)

```
Sub SetEntryText( _  
    ByVal Row As System.Integer, _  
    ByVal Col As System.Integer, _  
    ByVal TextIn As System.String _  
)
```

### Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim Row As System.Integer  
Dim Col As System.Integer  
Dim TextIn As System.String  
  
instance.SetEntryText(Row, Col, TextIn)
```

### C#

```
void SetEntryText(  
    System.int Row,  
    System.int Col,  
    System.string TextIn  
)
```

### C++/CLI

```
void SetEntryText(  
& System.int Row,  
& System.int Col,  
& System.String^ TextIn  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

*Row*

Row number

*Col*

Column number

*TextIn*  
Text value for entry

## Visual Basic for Applications (VBA) Syntax

See [DesignTable::SetEntryText](#).

## See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::SetEntryValue Method](#)  
[IDesignTable::GetEntryText Method](#)  
[IDesignTable::GetEntryValue Method](#)

## Availability

SOLIDWORKS 2000 SP01, Revision Number 8.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

## SetEntryValue Method (IDesignTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : SetEntryValue Method (IDesignTable)

Sets the data type and value in the specified cell.

## .NET Syntax

### Visual Basic (Declaration)

```
Sub SetEntryValue( _  
    ByVal Row As System.Integer, _  
    ByVal Col As System.Integer, _  
    ByVal IsText As System.Boolean, _  
    ByVal Retval As System.String _  
)
```

### Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim Row As System.Integer  
Dim Col As System.Integer  
Dim IsText As System.Boolean  
Dim Retval As System.String  
  
instance.SetEntryValue(Row, Col, IsText, Retval)
```

### C#

```
void SetEntryValue(  
    System.int Row,  
    System.int Col,  
    System.bool IsText,  
    System.string Retval  
)
```

### C++/CLI

```
void SetEntryValue(  
& System.int Row,  
& System.int Col,  
& System.bool IsText,  
& System.String^ Retval  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Parameters

*Row*

Row number  
*Col*  
Column number  
*IsText*  
True for text, false for general  
*RetVal*  
Value of the specific cell

## Visual Basic for Applications (VBA) Syntax

See [DesignTable::SetEntryValue](#).

## Remarks

This method lets you change the data type from text to general and from general to text and specify a value.

## See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::GetEntryText Method](#)  
[IDesignTable::GetEntryValue Method](#)  
[IDesignTable::SetEntryText Method](#)

## Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## SetRowChanged Method (IDesignTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : SetRowChanged Method (IDesignTable)

Sets the number of the row that was changed.

## .NET Syntax

### Visual Basic (Declaration)

```
Sub SetRowChanged( _  
    ByVal RowIndex As System.Integer _  
)
```

### Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim RowIndex As System.Integer  
  
instance.SetRowChanged(RowIndex)
```

### C#

```
void SetRowChanged(  
    System.int RowIndex  
)
```

### C++/CLI

```
void SetRowChanged(  
&    System.int RowIndex  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

*RowIndex*  
Number of row that changed

## Visual Basic for Applications (VBA) Syntax

See [DesignTable::SetRowChanged](#).

## Remarks

Setting the number of the row that changed provides significant performance gains for products like CD Catalog Viewer, a component of 3D PartStream.NET.

## See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::AddRow Method](#)  
[IDesignTable::GetRowCount Method](#)  
[IDesignTable::GetStartRowIndex Method](#)  
[IDesignTable::GetTotalRowCount Method](#)  
[IDesignTable::GetVisibleRowCount Method](#)  
[IDesignTable::GetVisibleTopRowIndex Method](#)  
[IDesignTable::RowHidden Property](#)

## Availability

SOLIDWORKS 2003 SP4, Revision Number 11.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

## SourceType Property (IDesignTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : SourceType Property (IDesignTable)

Gets or sets the type of source file for this design table.

## Visual Basic Syntax

Visual Basic (Declaration)

```
Property SourceType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim value As System.Integer
```

```
instance.SourceType = value
```

```
value = instance.SourceType
```

C#

```
System.int SourceType {get; set;}
```

C++/CLI

```
property System.int SourceType {  
    System.int get();  
    void set ( & System.int value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Type of source file as defined in [swDesignTableSourceTypes\\_e](#)

## Visual Basic for Applications (VBA) Syntax

See [DesignTable::SourceType](#).

## Remarks

You must call:

- [IDesignTable::EditFeature](#) before setting this property.
- [IDesignTable::UpdateFeature](#) after setting this property.

## See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::FileName Property](#)  
[IDesignTable::LinkToFile Property](#)  
[IDesignTable::SaveAsExcelFile Method](#)

## Availability

SOLIDWORKS 2004 SP3, Revision Number 12.3

SOLIDWORKS API Help

[Send comments](#) on this topic.

## Updatable Property (IDesignTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : Updatable Property (IDesignTable)

Gets or sets whether edits to the model update the design table.

## .NET Syntax

Visual Basic (Declaration)

Property Updatable As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDesignTable
Dim value As System.Boolean
```

```
instance.Updatable = value
```

```
value = instance.Updatable
```

C#

```
System.bool Updatable {get; set;}
```

C++/CLI

```
property System.bool Updatable {
    System.bool get();
    void set ( & System.bool value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

True if edits to the model update the design table, false if not

## Visual Basic for Applications (VBA) Syntax

See [DesignTable::Updatable](#).

## Example

[Get or Set Whether Edits Update Design Table \(VBA\)](#)

## Remarks

You must call:

- [IDesignTable::EditFeature](#) before setting this property.
- [IDesignTable::UpdateFeature](#) after setting this property.

## See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::EditFeature Method](#)  
[IDesignTable::EditTable2 Method](#)  
[IDesignTable::IsActive Method](#)  
[IDesignTable::UpdateFeature Method](#)  
[IDesignTable::UpdateModel Method](#)  
[IDesignTable::UpdateTable Method](#)

## Availability

SOLIDWORKS 2004 SP3, Revision Number 12.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

## UpdateFeature Method (IDesignTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : UpdateFeature Method (IDesignTable)

Updates the characteristics of the design table.

## .NET Syntax

Visual Basic (Declaration)

Function UpdateFeature() As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim value As System.Boolean  
  
value = instance.UpdateFeature()
```

C#

```
System.bool UpdateFeature()
```

C++/CLI

```
System.bool UpdateFeature();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Return Value

True if the characteristics of the design table are updated, false if not

## Visual Basic for Applications (VBA) Syntax

See [DesignTable::UpdateFeature](#).

## Example

[Get or Set Whether Edits Update Design Table \(VBA\)](#)  
[Disable Cell Drop-down Lists in Design Table \(C#\)](#)  
[Disable Cell Drop-down Lists in Design Table \(VB.NET\)](#)  
[Disable Cell Drop-down Lists in Design Table \(VBA\)](#)

## See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::EditFeature Method](#)  
[IDesignTable::EditTable2 Method](#)  
[IDesignTable::IsActive Method](#)  
[IDesignTable::UpdateModel Method](#)  
[IDesignTable::UpdateTable Method](#)

## Availability

SOLIDWORKS 2004 SP3, Revision Number 12.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

## UpdateModel Method (IDesignTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : UpdateModel Method (IDesignTable)

Applies the edits to the design table to the model.

### .NET Syntax

Visual Basic (Declaration)

```
Function UpdateModel() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim value As System.Boolean
```

```
value = instance.UpdateModel()
```

C#

```
System.bool UpdateModel()
```

C++/CLI

```
System.bool UpdateModel();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

True if the model is updated successfully, false if it was not

### Visual Basic for Applications (VBA) Syntax

See [DesignTable::UpdateModel](#).

### Remarks

This method is a simplified version of [IDesignTable::UpdateTable](#).

### See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::EditFeature Method](#)  
[IDesignTable::EditTable2 Method](#)  
[IDesignTable::IsActive Method](#)  
[IDesignTable::UpdateFeature Method](#)  
[IDesignTable::UpdateTable Property](#)  
[IDesignTable::LinkToFile Property](#)

### Availability

SOLIDWORKS 2000 SP01, Revision Number 8.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

## UpdateTable Method (IDesignTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : UpdateTable Method (IDesignTable)

Applies the changes made to the design table to the model.

### .NET Syntax

Visual Basic (Declaration)

```
Function UpdateTable( _  
    ByVal Type As System.Integer, _
```

```
ByVal Close As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim Type As System.Integer  
Dim Close As System.Boolean  
Dim value As System.Boolean  
  
value = instance.UpdateTable(Type, Close)
```

C#

```
System.bool UpdateTable(  
    System.int Type,  
    System.bool Close  
)
```

C++/CLI

```
System.bool UpdateTable(  
& System.int Type,  
& System.bool Close  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*Type*

Type of update as defined in [swDesignTableUpdateOptions\\_e](#)

*Close*

True to close the design table, false to not

#### Return Value

True if the changes made to the design table update the model, false if not

### Visual Basic for Applications (VBA) Syntax

See [DesignTable::UpdateTable](#).

### Example

[Add Row to Design Table \(VBA\)](#)

[Disable Cell Drop-down Lists in Design Table \(C#\)](#)

[Disable Cell Drop-down Lists in Design Table \(VB.NET\)](#)

[Disable Cell Drop-down Lists in Design Table \(VBA\)](#)

### Remarks

[IDesignTable::UpdateModel](#) is a simplified version of this method.

### See Also

[IDesignTable Interface](#)

[IDesignTable Members](#)

[IDesignTable::EditFeature Method](#)

[IDesignTable::EditTable2 Method](#)

[IDesignTable::IsActive Method](#)

[IDesignTable::UpdateFeature Method](#)

[IDesignTable::UpdateModel Method](#)

[IDesignTable::Warn Property](#)

### Availability

SOLIDWORKS 2004 SP3, Revision Number 12.3



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : Warn Property (IDesignTable)

Gets or sets whether to display a warning when invalid information is encountered in the design table when updating the design table.

## .NET Syntax

### Visual Basic (Declaration)

```
Property Warn As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As IDesignTable  
Dim value As System.Boolean
```

```
instance.Warn = value
```

```
value = instance.Warn
```

### C#

```
System.bool Warn {get; set;}
```

### C++/CLI

```
property System.bool Warn {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

True to display a warning when invalid information is encountered in the design table when updating the design table, false to not

## Visual Basic for Applications (VBA) Syntax

See [DesignTable::Warn](#).

## Remarks

If information is entered to the left of the parameters row or below the configuration name column, then the SOLIDWORKS Design software warns of an invalid value and stops processing the design table without completing the remaining rows and columns. If this happens, some configurations do not update properly.

You must call:

- [IDesignTable::EditFeature](#) before setting this property.
- [IDesignTable::UpdateFeature](#) after setting this property.

## See Also

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::UpdateTable Method](#)

## Availability

SOLIDWORKS 2004 SP3, Revision Number 12.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Worksheet Property (IDesignTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDesignTable Interface](#) : Worksheet Property (IDesignTable)

Gets the Microsoft Excel worksheet for this design table.

## .NET Syntax

## ReadOnly Property Worksheet As System.Object



```
Dim instance As IDesignTable  
Dim value As System.Object  
  
value = instance.Worksheet
```

```
System.object Worksheet {get;}
```

```
property System.Object^ Worksheet {  
    System.Object^ get();  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

**Property Value**

Microsoft Excel worksheet for this design table

**Visual Basic for Applications (VBA) Syntax**

See [DesignTable::Worksheet](#).

**Example**

[Get Microsoft Excel Design Table Worksheet \(VBA\)](#)

**Remarks**

Before you can call this method, you must call [IDesignTable::Attach](#).

**See Also**

[IDesignTable Interface](#)  
[IDesignTable Members](#)  
[IDesignTable::FileName Property](#)  
[IDesignTable::SaveAsExcelFile Method](#)  
[IDesignTable::Detach Method](#)  
[IDesignTable::SourceType Property](#)

**Availability**

SOLIDWORKS 2007 FCS, Revision Number 15.0