

SOLIDWORKS API (NET VBA C#) — Reference

(71/337): IDetailCircle-IDiagnoseResult

SOLIDWORKS API Documentation (converted from CHM)

IDetailCircle (Type)

IDetailCircle Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDetailCircle Interface

Allows access to a detail circle.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IDetailCircle
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle
```

C#

```
public interface IDetailCircle
```

C++/CLI

```
public interface class IDetailCircle
```

Visual Basic for Applications (VBA) Syntax

See [DetailCircle](#).

Example

[Create Detail Circle and Detail View \(C#\)](#)
[Create Detail Circle and Detail View \(VB.NET\)](#)
[Create Detail Circle and Detail View \(VBA\)](#)

Accessors

[IFeature::GetSpecificFeature2](#)
[IView::GetDetail](#) and [IView::!GetDetail](#)
[IView::GetDetailCircles](#) and [IView::!GetDetailCircles](#)

Access Diagram

[DetailCircle](#)

See Also

[IDetailCircle Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IDetailCircle Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDetailCircle Interface

The following tables list the members exposed by [IDetailCircle](#).

Public Properties

Name	Description
JaggedOutline	Gets or sets whether to show a jagged outline in the detail view.

[Layer](#)

Gets or sets the layer on which the detail circle is on.

[NoOutline](#)

Gets or sets whether to show an outline in the detail view.

[PinPosition](#)

Sets the pin position for this detail circle.

[ScaleHatchPattern](#)

Gets or sets whether to scale the hatch pattern for this detail circle.

[ShapeIntensity](#)

Gets or sets the shape intensity of the jagged outline in the detail view.

[Top](#)

Public Methods

Name	Description
 GetArrowInfo	Gets the position of the arrows for this detail circle.
 GetConnectingLine	Gets the end point coordinates of the connecting line for this detail circle.
 GetDetailView	Gets the drawing view of this detail circle.
 GetDisplay	Gets the type of circle or profile used to create the detail.
 GetLabel	Gets the label for this detail circle.
 GetLabelPosition	Gets the position of the label of this detail circle.
 GetLeaderInfo	Gets the leader information for this detail circle.
 GetName	Gets the name of this detail circle.
 GetProfileItems	Gets the sketch segments that make up this detail circle profile.
 GetProfileItemsCount	Gets the number of sketch segments that make up this detail circle profile.
 GetStyle	Gets the style of this detail circle.
 GetTextFormat	Gets the text format for this detail circle.
 GetUseDocTextFormat	Gets whether or not SOLIDWORKS is currently using the document default setting for text format.
 GetView	Gets the the drawing view that displays this detail circle.
 HasFullOutline	Gets whether this detail circle has a full outline in the detail view.
 IGetArrowInfo	Gets the position of the arrows for this detail circle.
 IGetConnectingLine	Gets the end point coordinates of the connecting line
 IGetLeaderInfo	Gets the leader information for this detail circle.
 IGetProfileItems	Gets the sketch segments that make up this detail circle profile.
 Select	Selects the detail circle.
 SetDisplay	Sets the display of the detail circle to a circle or to the profile.
 SetFullOutline	Sets whether the complete detail circle or detail profile is shown in the detail view, or if just the part of the circle or profile that intersects the view geometry is shown.
 SetLabel	Sets the label for this detail circle.
 SetLabelPosition	Sets the position of the label for this detail circle.
 SetName	Sets the name of this detail circle, as displayed in the FeatureManager design tree.
 SetParameters	Sets the location and size of this detail circle.
 SetStyle	Sets the style of the detail circle (for example, standard, broken, leader, no leader, or connected).
 SetTextFormat	Sets the text format for this detail circle.

[Top](#)

See Also

[IDetailCircle Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IDetailCircle Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDetailCircle Interface

For a list of all members of this type, see [IDetailCircle members](#).

Public Methods

Name	Description
GetArrowInfo	Gets the position of the arrows for this detail circle.
GetConnectingLine	Gets the end point coordinates of the connecting line for this detail circle.
GetDetailView	Gets the drawing view of this detail circle.
GetDisplay	Gets the type of circle or profile used to create the detail.
GetLabel	Gets the label for this detail circle.
GetLabelPosition	Gets the position of the label of this detail circle.
GetLeaderInfo	Gets the leader information for this detail circle.
GetName	Gets the name of this detail circle.
GetProfileItems	Gets the sketch segments that make up this detail circle profile.
GetProfileItemsCount	Gets the number of sketch segments that make up this detail circle profile.
GetStyle	Gets the style of this detail circle.
GetTextFormat	Gets the text format for this detail circle.
GetUseDocTextFormat	Gets whether or not SOLIDWORKS is currently using the document default setting for text format.
GetView	Gets the the drawing view that displays this detail circle.
HasFullOutline	Gets whether this detail circle has a full outline in the detail view.
IGetArrowInfo	Gets the position of the arrows for this detail circle.
IGetConnectingLine	Gets the end point coordinates of the connecting line
IGetLeaderInfo	Gets the leader information for this detail circle.
IGetProfileItems	Gets the sketch segments that make up this detail circle profile.
Select	Selects the detail circle.
SetDisplay	Sets the display of the detail circle to a circle or to the profile.
SetFullOutline	Sets whether the complete detail circle or detail profile is shown in the detail view, or if just the part of the circle or profile that intersects the view geometry is shown.
SetLabel	Sets the label for this detail circle.
SetLabelPosition	Sets the position of the label for this detail circle.
SetName	Sets the name of this detail circle, as displayed in the FeatureManager design tree.
SetParameters	Sets the location and size of this detail circle.
SetStyle	Sets the style of the detail circle (for example, standard, broken, leader, no leader, or connected).
SetTextFormat	Sets the text format for this detail circle.

[Top](#)

See Also

[IDetailCircle Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

[Send comments on this topic.](#)

IDetailCircle Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDetailCircle Interface

For a list of all members of this type, see [IDetailCircle members](#).

Public Properties

Name	Description
 JaggedOutline	Gets or sets whether to show a jagged outline in the detail view.
 Layer	Gets or sets the layer on which the detail circle is on.
 NoOutline	Gets or sets whether to show an outline in the detail view.
 PinPosition	Sets the pin position for this detail circle.
 ScaleHatchPattern	Gets or sets whether to scale the hatch pattern for this detail circle.
 ShapeIntensity	Gets or sets the shape intensity of the jagged outline in the detail view.

[Top](#)

See Also

[IDetailCircle Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetArrowInfo Method (IDetailCircle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : GetArrowInfo Method (IDetailCircle)

Gets the position of the arrows for this detail circle.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArrowInfo() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim value As System.Object  
  
value = instance.GetArrowInfo()
```

C#

```
System.object GetArrowInfo()
```

C++/CLI

```
System.Object^ GetArrowInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array containing the arrow position information

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::GetArrowInfo](#).

Remarks

The section line in a drawing view has arrows at each end of the line. This method returns an array that contains 12 doubles, the (X, Y, Z) of the start and end point of one arrow, followed by the (X, Y, Z) of the start and end point of the other arrow.

These values match some of the information in the array returned by [IView::GetSectionLineInfo2](#) and [IViewIGetSectionLineInfo2](#); the arrow information near the middle of the array. The arrow information in that array also contains the arrow width, height, and style, which is not in the array returned by this method. To get this information using document preference settings, use [IModelDocExtension::GetUserPreferenceDouble](#) with swDetailingSectionArrowHeight, swDetailingSectionArrowWidth, or swDetailingSectionArrowLength, and [IModelDocExtension::GetUserPreferenceInteger](#) with swDetailingArrowStyleForDimensions.

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::IGetArrowInfo Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetConnectingLine Method (IDetailCircle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : GetConnectingLine Method (IDetailCircle)

Gets the end point coordinates of the connecting line for this detail circle.

.NET Syntax

Visual Basic (Declaration)

```
Function GetConnectingLine() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim value As System.Object  
  
value = instance.GetConnectingLine()
```

C#

```
System.object GetConnectingLine()
```

C++/CLI

```
System.Object^ GetConnectingLine();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::GetConnectingLine](#).

Remarks

This is only valid if there is a connecting line. Use [IDetailCircle::GetStyle](#) to determine if this detail circle is valid for this command.

retval[0]	X-coordinate of first connecting line point
retval[1]	Y-coordinate of first connecting line point
retval[2]	Z-coordinate of first connecting line point
retval[3]	X-coordinate of second connecting line point
retval[4]	Y-coordinate of second connecting line point
retval[5]	Z-coordinate of second connecting line point

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::IGetConnectingLine Method](#)

Availability

GetDetailView Method (IDetailCircle)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : GetDetailView Method (IDetailCircle)

Gets the drawing view of this detail circle.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDetailView() As View
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim value As View  
  
value = instance.GetDetailView()
```

C#

```
View GetDetailView()
```

C++/CLI

```
View^ GetDetailView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [drawing view](#) that owns this detail circle

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::GetDetailView](#).

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

GetDisplay Method (IDetailCircle)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : GetDisplay Method (IDetailCircle)

Gets the type of circle or profile used to create the detail.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplay() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim value As System.Integer
```

```
value = instance.GetDisplay()
```

C#

```
System.int GetDisplay()
```

C++/CLI

```
System.int GetDisplay();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Profile type as defined in [swDetCircleShowType_e](#)

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::GetDisplay](#).

Example

[Create Detail Circle and Detail View \(C#\)](#)
[Create Detail Circle and Detail View \(VB.NET\)](#)
[Create Detail Circle and Detail View \(VBA\)](#)

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::SetDisplay Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLabel Method (IDetailCircle)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : GetLabel Method (IDetailCircle)

Gets the label for this detail circle.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLabel() As System.String
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim value As System.String
```

```
value = instance.GetLabel()
```

C#

```
System.string GetLabel()
```

C++/CLI

```
System.String^ GetLabel();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Label for this detail circle

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::GetLabel](#).

Example

[Create Detail Circle and Detail View \(C#\)](#)
[Create Detail Circle and Detail View \(VB.NET\)](#)
[Create Detail Circle and Detail View \(VBA\)](#)

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::SetLabel Method](#)
[IDetailCircle::GetLabelPosition Method \(\)](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetLabelPosition Method (IDetailCircle)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : GetLabelPosition Method (IDetailCircle)

Gets the position of the label of this detail circle.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetLabelPosition( _  
    ByRef XPosition As System.Double, _  
    ByRef YPosition As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim XPosition As System.Double  
Dim YPosition As System.Double  
  
instance.GetLabelPosition(XPosition, YPosition)
```

C#

```
void GetLabelPosition(  
    out System.double XPosition,  
    out System.double YPosition  
)
```

C++/CLI

```
void GetLabelPosition(  
& [Out] System.double XPosition,  
& [Out] System.double YPosition  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

XPosition
x coordinate of the label
YPosition
y coordinate of the label

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::GetLabelPosition](#).

Example

[Create Detail Circle and Detail View \(VBA\)](#)
[Create Detail Circle and Detail View \(VB.NET\)](#)
[Create Detail Circle and Detail View \(C#\)](#)

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::SetLabelPosition Method \(\)](#)
[IDetailCircle::GetLabel Method \(\)](#)

Availability

SOLIDWORKS 2014 SP3, Revision Number 22.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLeaderInfo Method (IDetailCircle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : GetLeaderInfo Method (IDetailCircle)

Gets the leader information for this detail circle.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLeaderInfo() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle
Dim value As System.Object

value = instance.GetLeaderInfo()
```

C#

```
System.Object GetLeaderInfo()
```

C++/CLI

```
System.Object^ GetLeaderInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::GetLeaderInfo](#).

Remarks

There can be 0, 1 or 2 lines in the leader line. If the GTol is not attached, there are 0 lines. Otherwise, leaders can use a straight leaderline (1 line) or a bent leaderline (2 lines). Your applications must infer the number of leader lines based on [IGtol::IsAttached](#) and [IGtol::HasExtraLeader](#).

- IsAttached() == false implies no leaderline, therefore, no leaderline points (PointCount=0).
- HasExtraLeader() == false means that this is a straight leaderline, therefore, 1 line (PointCount=2)
- HasExtraLeader() == True means that this is a bent leaderline, therefore, 2 lines (PointCount=3)

Format of return information is the following array of doubles:

- retval[0] = X-coordinate of first leader point
- retval[1] = Y-coordinate of first leader point
- retval[2] = Z-coordinate of first leader point
- retval[3] = X-coordinate of second leader point
- retval[4] = Y-coordinate of second leader point
- retval[5] = Z-coordinate of second leader point
- retval[6] = X-coordinate of third leader point

- retVal[7] = Y-coordinate of third leader point
- retVal[8] = Z-coordinate of third leader point

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::GetLeaderInfo Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetName Method (IDetailCircle)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : GetName Method (IDetailCircle)

Gets the name of this detail circle.

.NET Syntax

Visual Basic (Declaration)

```
Function GetName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim value As System.String
```

```
value = instance.GetName()
```

C#

```
System.string GetName()
```

C++/CLI

```
System.String^ GetName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Name of this detail circle

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::GetName](#).

Example

[Create Detail Circle and Detail View \(C#\)](#)
[Create Detail Circle and Detail View \(VB.NET\)](#)
[Create Detail Circle and Detail View \(VBA\)](#)

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::SetName Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetProfileItems Method (IDetailCircle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : GetProfileItems Method (IDetailCircle)

Gets the sketch segments that make up this detail circle profile.

.NET Syntax

Visual Basic (Declaration)

```
Function GetProfileItems() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim value As System.Object  
  
value = instance.GetProfileItems()
```

C#

```
System.object GetProfileItems()
```

C++/CLI

```
System.Object^ GetProfileItems();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of the [sketch segments](#) that make up this detail circle profile

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::GetProfileItems](#).

Remarks

Do not modify the sketch segments returned by this method. This method only provides information about the profile geometry of the detail circle. To modify a detail circle, use [IDetailCircle::SetParameters](#).

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::IGetProfileItems Method](#)
[IDetailCircle::GetProfileItemsCount Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetProfileItemsCount Method (IDetailCircle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : GetProfileItemsCount Method (IDetailCircle)

Gets the number of sketch segments that make up this detail circle profile.

.NET Syntax

Visual Basic (Declaration)

```
Function GetProfileItemsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle
Dim value As System.Integer

value = instance.GetProfileItemsCount()
```

C#

```
System.int GetProfileItemsCount()
```

C++/CLI

```
System.int GetProfileItemsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of sketch segments that make up this detail circle profile

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::GetProfileItemsCount](#).

Remarks

Call this method before calling [IDetailCircle::IGetProfileItems](#) to determine the size of the array.

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::GetProfileItems Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetStyle Method (IDetailCircle)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : GetStyle Method (IDetailCircle)

Gets the style of this detail circle.

.NET Syntax

Visual Basic (Declaration)

```
Function GetStyle() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle
Dim value As System.Integer

value = instance.GetStyle()
```

C#

```
System.int GetStyle()
```

C++/CLI

```
System.int GetStyle();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Detail circle style as defined in [swDetViewStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::GetStyle](#).

Example

[Create Detail Circle and Detail View \(C#\)](#)
[Create Detail Circle and Detail View \(VB.NET\)](#)
[Create Detail Circle and Detail View \(VBA\)](#)

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::SetStyle Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextFormat Method (IDetailCircle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : GetTextFormat Method (IDetailCircle)

Gets the text format for this detail circle.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextFormat() As TextFormat
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim value As TextFormat  
  
value = instance.GetTextFormat()
```

C#

```
TextFormat GetTextFormat()
```

C++/CLI

```
TextFormat^ GetTextFormat();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [ITextFormat](#) object

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::GetTextFormat](#).

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::SetTextFormat Method](#)
[IDetailCircle::GetUseDocTextFormat Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUseDocTextFormat Method (IDetailCircle)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : GetUseDocTextFormat Method (IDetailCircle)

Gets whether or not SOLIDWORKS is currently using the document default setting for text format.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUseDocTextFormat() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim value As System.Boolean  
  
value = instance.GetUseDocTextFormat()
```

C#

```
System.bool GetUseDocTextFormat()
```

C++/CLI

```
System.bool GetUseDocTextFormat();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if SOLIDWORKS is using the default settings for the text format, false if not

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::GetUseDocTextFormat](#).

Example

[Create Detail Circle and Detail View \(C#\)](#)
[Create Detail Circle and Detail View \(VB.NET\)](#)
[Create Detail Circle and Detail View \(VBA\)](#)

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::GetTextFormat Method](#)
[IDetailCircle::SetTextFormat Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetView Method (IDetailCircle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : GetView Method (IDetailCircle)

Gets the the drawing view that displays this detail circle.

.NET Syntax

Visual Basic (Declaration)

```
Function GetView() As View
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim value As View  
  
value = instance.GetView()
```

C#

```
View GetView()
```

C++/CLI

```
View^ GetView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [IView](#) object

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::GetView](#).

Remarks

This is the owning drawing view from which the detail view was derived.

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

HasFullOutline Method (IDetailCircle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : HasFullOutline Method (IDetailCircle)

Gets whether this detail circle has a full outline in the detail view.

.NET Syntax

Visual Basic (Declaration)

```
Function HasFullOutline() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim value As System.Boolean  
  
value = instance.HasFullOutline()
```

C#

```
System.bool HasFullOutline()
```

C++/CLI

```
System.bool HasFullOutline();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the detail circle has a full outline in the detail view, false if not

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::HasFullOutline](#).

Remarks

This method is only available when [IDetailCircle::NoOutline](#) is false.

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::SetFullOutline Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetArrowInfo Method (IDetailCircle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : IGetArrowInfo Method (IDetailCircle)

Gets the position of the arrows for this detail circle.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetArrowInfo() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle
Dim value As System.Double

value = instance.IGetArrowInfo()
```

C#

```
System.double IGetArrowInfo()
```

C++/CLI

```
System.double IGetArrowInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array containing the arrow position inform
- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

Remarks

The section line in a drawing view has arrows at each end of the line. This method returns an array that contains 12 doubles, the (X, Y, Z) of the start and end point of one arrow, followed by the (X, Y, Z) of the start and end point of the other arrow.

These values match some of the information in the array returned by [IView::GetSectionLineInfo2](#) and [IViewIGetSectionLineInfo2](#); the arrow information near the middle of the array. The arrow information in that array also contains the arrow width, height, and style, which is not in the

array returned by this method. To get this information using document preference settings, use [IModelDocExtension::GetUserPreferenceDouble](#) with swDetailingSectionArrowHeight, swDetailingSectionArrowWidth, or swDetailingSectionArrowLength, and [IModelDocExtension::GetUserPreferenceInteger](#) with swDetailingArrowStyleForDimensions.

 See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::GetArrowInfo Method](#)

 Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help [Send comments on this topic.](#)

IGetConnectingLine Method (IDetailCircle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : IGetConnectingLine Method (IDetailCircle)

Gets the end point coordinates of the connecting line

 .NET Syntax

Visual Basic (Declaration)

```
Function IGetConnectingLine() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim value As System.Double  
  
value = instance.IGetConnectingLine()
```

C#

```
System.double IGetConnectingLine()
```

C++/CLI

```
System.double IGetConnectingLine();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of 6 doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

 Remarks

This is only valid if there is a connecting line. Use [IDetailCircle::GetStyle](#) to determine if this detail circle is valid for this command.

retval[0]	X-coordinate of first connecting line point
retval[1]	Y-coordinate of first connecting line point
retval[2]	Z-coordinate of first connecting line point
retval[3]	X-coordinate of second connecting line point
retval[4]	Y-coordinate of second connecting line point
retval[5]	Z-coordinate of second connecting line point

 See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::GetConnectingLine Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetLeaderInfo Method (IDetailCircle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : IGetLeaderInfo Method (IDetailCircle)

Gets the leader information for this detail circle.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetLeaderInfo() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim value As System.Double  
  
value = instance.IGetLeaderInfo()
```

C#

```
System.double IGetLeaderInfo()
```

C++/CLI

```
System.double IGetLeaderInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::IGetLeaderInfo](#).

Remarks

There can be 0, 1 or 2 lines in the leader line. If the GTol is not attached, there are 0 lines. Otherwise, leaders can use a straight leaderline (1 line) or a bent leaderline (2 lines). Your applications must infer the number of leader lines based on [IGtol::IsAttached](#) and [IGtol::HasExtraLeader](#).

- IsAttached() == false implies no leaderline; therefore, no leaderline points (PointCount=0).
- HasExtraLeader() == false means that this is a straight leaderline; therefore, 1 line (PointCount=2)
- HasExtraLeader() == True means that this is a bent leaderline; therefore, 2 lines (PointCount=3)

Format of return information is the following array of doubles:

- retval[0] = X-coordinate of first leader point
- retval[1] = Y-coordinate of first leader point
- retval[2] = Z-coordinate of first leader point
- retval[3] = X-coordinate of second leader point
- retval[4] = Y-coordinate of second leader point
- retval[5] = Z-coordinate of second leader point
- retval[6] = X-coordinate of third leader point
- retval[7] = Y-coordinate of third leader point
- retval[8] = Z-coordinate of third leader point

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::GetLeaderInfo Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

IGetProfileItems Method (IDetailCircle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : IGetProfileItems Method (IDetailCircle)

Gets the sketch segments that make up this detail circle profile.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetProfileItems( _
    ByVal Count As System.Integer _
) As SketchSegment
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle
Dim Count As System.Integer
Dim value As SketchSegment

value = instance.IGetProfileItems(Count)
```

C#

```
SketchSegment IGetProfileItems(
    System.int Count
)
```

C++/CLI

```
SketchSegment^ IGetProfileItems(
    & System.int Count
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of sketch segments that make up this detail circle profile

Return Value

- in-process, unmanaged C++: Pointer to an array of [sketch segments](#) that make up this detail circle profile
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IDetailCircle::GetProfileItemsCount](#) before calling this method to determine the size of the array.

Do not modify the sketch segments returned by this method. This method only provides information about the profile geometry of the detail circle. To modify a detail circle, use [IDetailCircle::SetParameters](#).

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::GetProfileItems Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number

JaggedOutline Property (IDetailCircle)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : JaggedOutline Property (IDetailCircle)

Gets or sets whether to show a jagged outline in the detail view.

 **.NET Syntax**

Visual Basic (Declaration)

Property JaggedOutline As System.Boolean

Visual Basic (Usage)

Dim instance As [IDetailCircle](#)
Dim value As System.Boolean

instance.JaggedOutline = value

value = instance.JaggedOutline

C#

System.bool JaggedOutline {get; set;}

C++/CLI

property System.bool JaggedOutline {
 System.bool get();
 void set (& System.bool value);
}

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value
True to show a jagged outline in the detail view, false to not (see **Remarks**)

 **Visual Basic for Applications (VBA) Syntax**

See [DetailCircle::JaggedOutline](#).

 **Example**

[Create Detail Circle and Detail View \(C#\)](#)
[Create Detail Circle and Detail View \(VB.NET\)](#)
[Create Detail Circle and Detail View \(VBA\)](#)

 **Remarks**

This property is only available when [IDetailCircle::NoOutline](#) is false.
To set the intensity of the jagged outline, call [IDetailCircle::ShapeIntensity](#).

 **See Also**

[IDetailCircle Interface](#)
[IDetailCircle Members](#)

 **Availability**

SOLIDWORKS 2017 FCS, Revision Number 25.0

Layer Property (IDetailCircle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : Layer Property (IDetailCircle)

Gets or sets the layer on which the detail circle is on.

 **.NET Syntax**

Visual Basic (Declaration)

Property Layer As System.String

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim value As System.String
```

```
instance.Layer = value
```

```
value = instance.Layer
```

C#

```
System.string Layer {get; set;}
```

C++/CLI

```
property System.String^ Layer {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Layer name

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::Layer](#).

Remarks

An empty string indicates no layer. If you set the layer to a layer name that does not exist, nothing happens.

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

NoOutline Property (IDetailCircle)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : NoOutline Property (IDetailCircle)

Gets or sets whether to show an outline in the detail view.

.NET Syntax

Visual Basic (Declaration)

```
Property NoOutline As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim value As System.Boolean
```

```
instance.NoOutline = value
```

```
value = instance.NoOutline
```

C#

```
System.bool NoOutline {get; set;}
```

C++/CLI

```
property System.bool NoOutline {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to not show an outline in the detail view, false to show an outline in the detail view

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::NoOutline](#).

Example

[Create Detail Circle and Detail View \(C#\)](#)
[Create Detail Circle and Detail View \(VB.NET\)](#)
[Create Detail Circle and Detail View \(VBA\)](#)

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::HasFullOutline Method \(\)](#)
[IDetailCircle::SetFullOutline Method \(\)](#)
[IDetailCircle::JaggedOutline Property \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

PinPosition Property (IDetailCircle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : PinPosition Property (IDetailCircle)

Sets the pin position for this detail circle.

.NET Syntax

Visual Basic (Declaration)

```
Property PinPosition As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim value As System.Boolean  
  
instance.PinPosition = value  
value = instance.PinPosition
```

C#

```
System.bool PinPosition {get; set;}
```

C++/CLI

```
property System.bool PinPosition {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to prevent the detail view from moving if the parent view changes size, false to not

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::PinPosition](#).

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ScaleHatchPattern Property (IDetailCircle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : ScaleHatchPattern Property (IDetailCircle)

Gets or sets whether to scale the hatch pattern for this detail circle.

.NET Syntax

Visual Basic (Declaration)

Property ScaleHatchPattern As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDetailCircle
Dim value As System.Boolean
```

```
instance.ScaleHatchPattern = value
```

```
value = instance.ScaleHatchPattern
```

C#

```
System.bool ScaleHatchPattern {get; set;}
```

C++/CLI

```
property System.bool ScaleHatchPattern {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to scale the hatch pattern based on the scale of the detail view, false to not

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::ScaleHatchPattern](#).

See Also

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Select Method (IDetailCircle)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : Select Method (IDetailCircle)

Selects the detail circle.

.NET Syntax

Visual Basic (Declaration)

```
Function Select( _  
    ByVal Append As System.Boolean, _  
    ByVal Data As SelectData _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim Append As System.Boolean  
Dim Data As SelectData  
Dim value As System.Boolean  
  
value = instance.Select(Append, Data)
```

C#

```
System.bool Select(  
    System.bool Append,  
    SelectData Data  
)
```

C++/CLI

```
System.bool Select(  
    & System.bool Append,  
    & SelectData^ Data  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Append

True appends the detail circle to the selection list, false replaces the selection list with this detail circle

Data

Pointer to the [ISelectData](#) object

Return Value

True if the detail circle is selected, false if not

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::Select](#).

Example

[Create Detail Circle and Detail View \(C#\)](#)
[Create Detail Circle and Detail View \(VB.NET\)](#)
[Create Detail Circle and Detail View \(VBA\)](#)

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetDisplay Method (IDetailCircle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : SetDisplay Method (IDetailCircle)

Sets the display of the detail circle to a circle or to the profile.

.NET Syntax

Visual Basic (Declaration)

```
Function SetDisplay( _  
    ByVal Display As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim Display As System.Integer  
Dim value As System.Boolean  
  
value = instance.SetDisplay(Display)
```

C#

```
System.bool SetDisplay(  
    System.int Display  
)
```

C++/CLI

```
System.bool SetDisplay(  
& System.int Display  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Display
Display as defined by [swDetCircleShowType_e](#)

Return Value

True if setting the detail circle display is successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::SetDisplay](#).

Remarks

Use this method to display the detail circle or detail profile as a circle or as a profile.

If...

Then...

Detail circle was originally set up as a circle

- there is no profile.
- using this method to set display to swDetCirclePROFILE has no effect.
- this method returns false.

Style of the detail circle (see [IDetailCircle::GetStyle](#)) is swDetViewBROKEN or swDetViewSTANDARD and the current detailing standard is ANSI

this method cannot set the display to swDetCirclePROFILE because the display must be a circle.

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::GetStyle Method](#)

Availability

SOLIDWORKS 2004 SP1, Revision Number 12.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetFullOutline Method (IDetailCircle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : SetFullOutline Method (IDetailCircle)

Sets whether the complete detail circle or detail profile is shown in the detail view, or if just the part of the circle or profile that intersects the view geometry is shown.

.NET Syntax

Visual Basic (Declaration)

```
Function SetFullOutline( _  
    ByVal FullOutline As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim FullOutline As System.Boolean  
Dim value As System.Boolean  
  
value = instance.SetFullOutline(FullOutline)
```

C#

```
System.bool SetFullOutline(  
    System.bool FullOutline  
)
```

C++/CLI

```
System.bool SetFullOutline(  
    & System.bool FullOutline  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FullOutline

True if the full circle or profile outline is shown in the detail view, false if only the portion of the circle or profile that intersects the view geometry is shown

Return Value

True if setting the full outline flag is successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::SetFullOutline](#).

Remarks

This method:

- is only available when [IDetailCircle::NoOutline](#) is false.
- automatically loads the model for the detail view if necessary, without prompting the user.

If the style of the detail circle (see [IDetailCircle::GetStyle](#)) is swDetViewCONNECTED, then this method cannot disable the full outline because the full outline of the circle or profile must be shown.

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::HasFullOutline Method](#)

Availability

SOLIDWORKS 2004 SP1, Revision Number 12.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetLabel Method (IDetailCircle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : SetLabel Method (IDetailCircle)

Sets the label for this detail circle.

.NET Syntax

Visual Basic (Declaration)

```
Function SetLabel( _  
    ByVal Label As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim Label As System.String  
Dim value As System.Boolean  
  
value = instance.SetLabel(Label)
```

C#

```
System.bool SetLabel(  
    System.string Label  
)
```

C++/CLI

```
System.bool SetLabel(  
& System.String^ Label  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Label
Label for this detail view

Return Value

True if label is set, false if not

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::SetLabel](#).

Remarks

Setting the detail circle label also updates the detail view label.

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::GetLabel Method](#)
[IDrawingDoc::CreateDetailViewAt3 Method](#)

Availability

SOLIDWORKS 2004 SP1, Revision Number 12.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetLabelPosition Method (IDetailCircle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : SetLabelPosition Method (IDetailCircle)

Sets the position of the label for this detail circle.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetLabelPosition( _  
    ByVal XPosition As System.Double, _  
    ByVal YPosition As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim XPosition As System.Double  
Dim YPosition As System.Double  
  
instance.SetLabelPosition(XPosition, YPosition)
```

C#

```
void SetLabelPosition(  
    System.double XPosition,  
    System.double YPosition  
)
```

C++/CLI

```
void SetLabelPosition(  
& System.double XPosition,  
& System.double YPosition  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

XPosition
x coordinate of the label
YPosition
y coordinate of the label

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::SetLabelPostion](#).

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::GetLabelPosition Method \(\)](#)
[IDetailCircle::SetLabel Method \(\)](#)

Availability

SOLIDWORKS 2014 SP3, Revision Number 22.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetName Method (IDetailCircle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : SetName Method (IDetailCircle)

Sets the name of this detail circle, as displayed in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

```
Function SetName(  
    ByVal Name As System.String  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim Name As System.String  
Dim value As System.Boolean  
  
value = instance.SetName(Name)
```

C#

```
System.bool SetName(  
    System.string Name  
)
```

C++/CLI

```
System.bool SetName(  
& System.String^ Name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name
Name of this detail circle

Return Value

True if setting the detail circle name is successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::SetName](#).

Remarks

If setting the name of a feature, then the new name must be unique in the FeatureManager design tree. If the name is not unique, then the name is not changed. Also, the name cannot contain any of the SOLIDWORKS reserved special characters.

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::GetName Method](#)

Availability

SOLIDWORKS 2004 SP1, Revision Number 12.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetParameters Method (IDetailCircle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : SetParameters Method (IDetailCircle)

Sets the location and size of this detail circle.

.NET Syntax

Visual Basic (Declaration)

```
Function SetParameters( _  
    ByVal XPosition As System.Double, _  
    ByVal YPosition As System.Double, _  
    ByVal Radius As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim XPosition As System.Double  
Dim YPosition As System.Double  
Dim Radius As System.Double  
Dim value As System.Boolean  
  
value = instance.SetParameters(XPosition, YPosition, Radius)
```

C#

```
System.bool SetParameters(  
    System.double XPosition,  
    System.double YPosition,  
    System.double Radius  
)
```

C++/CLI

```
System.bool SetParameters(  
& System.double XPosition,  
& System.double YPosition,  
& System.double Radius  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

XPosition

x location of the detail circle

YPosition

y location of the detail circle

Radius

Size of the radius of the detail circle

Return Value

True if the detail circle is created at the specified location and at the specified size, false if not

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::SetParameters](#).

Remarks

Use [IModelDoc2::EditRebuild3](#) to update the drawing, including the detail circle.

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SetStyle Method (IDetailCircle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : SetStyle Method (IDetailCircle)

Sets the style of the detail circle (for example, standard, broken, leader, no leader, or connected).

.NET Syntax

Visual Basic (Declaration)

```
Function SetStyle( _  
    ByVal Style As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim Style As System.Integer  
Dim value As System.Boolean  
  
value = instance.SetStyle(Style)
```

C#

```
System.bool SetStyle(  
    System.int Style  
)
```

C++/CLI

```
System.bool SetStyle(  
& System.int Style  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Style
Style as defined by [swDetViewStyle_e](#)

Return Value

True if setting the detail view style is successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::SetStyle](#).

Remarks

This method sets different styles for the detail view display, following the detailing standard, as a broken circle, as a circle or profile with or without a leader to the detail label, or with a line connecting the detail circle or profile with the detail view.

This method automatically load the model for the detail view, if necessary, without prompting the user.

If the style of the detail circle is swDetViewBROKEN or swDetViewSTANDARD and the current detailing standard is ANSI, then this method automatically switches the detail circle or profile display to circle because a broken circle style requires a circle, not a profile.

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)
[IDetailCircle::GetStyle Method](#)

Availability

SOLIDWORKS 2004 SP1, Revision Number 12.1

SetTextFormat Method (IDetailCircle)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDetailCircle Interface](#) : SetTextFormat Method (IDetailCircle)

Sets the text format for this detail circle.

.NET Syntax

Visual Basic (Declaration)

```
Function SetTextFormat( _  
    ByVal UseDoc As System.Boolean, _  
    ByVal TextFormat As TextFormat _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim UseDoc As System.Boolean  
Dim TextFormat As TextFormat  
Dim value As System.Boolean  
  
value = instance.SetTextFormat(UseDoc, TextFormat)
```

C#

```
System.bool SetTextFormat(  
    System.bool UseDoc,  
    TextFormat TextFormat  
)
```

C++/CLI

```
System.bool SetTextFormat(  
& System.bool UseDoc,  
& TextFormat^ TextFormat  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDoc

True to use the local document text format, false to use the text format specified by

TextFormat

TextFormat

[Text format](#) to use if UseDoc is false

Return Value

True if the format was set successfully, false if it was not

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::SetTextFormat](#).

See Also

[IDetailCircle Interface](#)

[IDetailCircle Members](#)

[IDetailCircle::GetTextFormat Method](#)

[IDetailCircle::GetUseDocTextFormat Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0



Gets or sets the shape intensity of the jagged outline in the detail view.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property ShapeIntensity As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDetailCircle  
Dim value As System.Integer
```

```
instance.ShapeIntensity = value  
value = instance.ShapeIntensity
```

C#

```
System.int ShapeIntensity {get; set;}
```

C++/CLI

```
property System.int ShapeIntensity {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Shape intensity of the jagged outline; valid range is 1 (most) to 5 (least) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DetailCircle::ShapeIntensity](#).

Example

[Create Detail Circle and Detail View \(C#\)](#)
[Create Detail Circle and Detail View \(VB.NET\)](#)
[Create Detail Circle and Detail View \(VBA\)](#)

Remarks

This property is only available when [IDetailCircle::JaggedOutline](#) is true and [IDetailCircle::NoOutline](#) is false.

See Also

[IDetailCircle Interface](#)
[IDetailCircle Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

IDiagnoseResult (Type)

IDiagnoseResult Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDiagnoseResult Interface

Get the gaps and coedges in each gap on this body.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IDiagnoseResult
```

Visual Basic (Usage)



```
Dim instance As IDiagnoseResult
```

C#

```
public interface IDiagnoseResult
```

C++/CLI

```
public interface class IDiagnoseResult
```

Visual Basic for Applications (VBA) Syntax

See [DiagnoseResult](#).

Example

[Get and Fill Gaps in Body \(C#\)](#)
[Get and Fill Gaps in Body \(VB.NET\)](#)
[Get and Fill Gaps in Body \(VBA\)](#)

Remarks

A gap is the laminar loop where the coedges on the loop do not have an associated face.

Accessors

[IBody2::Diagnose](#)

Access Diagram

[DiagnoseResult](#)

See Also

[IDiagnoseResult Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertFillSurface2 Method](#)

IDiagnoseResult Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDiagnoseResult Interface

The following tables list the members exposed by [IDiagnoseResult](#).

Public Methods

Name	Description
 GetCoEdgesAtGap	Gets the coedges at the specified gap.
 GetCoEdgesCountAtGap	Gets the number of coedges at the specified gap.
 GetGapsCount	Gets the number of gaps on the body.
 IGetCoEdgesAtGap	Gets the coedges at the specified gap.

[Top](#)

 See Also

[IDiagnoseResult Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertFillSurface2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDiagnoseResult Interface Methods

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IDiagnoseResult Interface

For a list of all members of this type, see [IDiagnoseResult members](#).

 Public Methods

Name	Description
 GetCoEdgesAtGap	Gets the coedges at the specified gap.
 GetCoEdgesCountAtGap	Gets the number of coedges at the specified gap.
 GetGapsCount	Gets the number of gaps on the body.
 IGetCoEdgesAtGap	Gets the coedges at the specified gap.

[Top](#)

 See Also

[IDiagnoseResult Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertFillSurface2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCoEdgesAtGap Method (IDiagnoseResult)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDiagnoseResult Interface](#) : GetCoEdgesAtGap Method (IDiagnoseResult)

Gets the coedges at the specified gap.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetCoEdgesAtGap( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As IDiagnoseResult  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetCoEdgesAtGap(Index)
```

C#

```
System.object GetCoEdgesAtGap(  
    System.int Index  
)
```



```
System.Object^ GetCoEdgesAtGap(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index number of the gap to get

Return Value

Array of [coedges](#)

Visual Basic for Applications (VBA) Syntax

See [DiagnoseResult::GetCoEdgesAtGap](#).

Example

[Get and Fill Gaps in Body \(C#\)](#)
[Get and Fill Gaps in Body \(VB.NET\)](#)
[Get and Fill Gaps in Body \(VBA\)](#)

Remarks

Call [IDiagnoseResult::GetGapsCount](#) before calling this method to determine the index number of the gap to get on this body.

See Also

[IDiagnoseResult Interface](#)
[IDiagnoseResult Members](#)
[IDiagnoseResult::GetCoEdgesCountAtGap Method](#)
[IDiagnoseResult::IGetCoEdgesAtGap Method](#)

Availability

SOLIDWORKS 2004 SP4, Revision Number 12.4

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetCoEdgesCountAtGap Method (IDiagnoseResult)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDiagnoseResult Interface](#) : GetCoEdgesCountAtGap Method (IDiagnoseResult)

Gets the number of coedges at the specified gap.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCoEdgesCountAtGap( _
    ByVal Index As System.Integer _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDiagnoseResult
Dim Index As System.Integer
Dim value As System.Integer
```

```
value = instance.GetCoEdgesCountAtGap(Index)
```

C#

```
System.int GetCoEdgesCountAtGap(
    System.int Index
```

)

C++/CLI

```
System.int GetCoEdgesCountAtGap(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index number of the gap to get

Return Value

Number of coedges at that gap

Visual Basic for Applications (VBA) Syntax

See [IDiagnoseResult::GetCoEdgesCountAtGap](#).

Example

Call this method before calling [IDiagnoseResult::IGetCoEdgesAtGap](#).

See Also

[IDiagnoseResult Interface](#)
[IDiagnoseResult Members](#)

Availability

SOLIDWORKS 2004 SP4, Revision Number 12.4

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetGapsCount Method (IDiagnoseResult)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDiagnoseResult Interface](#) : GetGapsCount Method (IDiagnoseResult)

Gets the number of gaps on the body.

.NET Syntax

Visual Basic (Declaration)

```
Function GetGapsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDiagnoseResult  
Dim value As System.Integer  
  
value = instance.GetGapsCount()
```

C#

```
System.int GetGapsCount()
```

C++/CLI

```
System.int GetGapsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of gaps

Visual Basic for Applications (VBA) Syntax

See [DiagnoseResult::GetGapsCount](#).

Example

[Get and Fill Gaps in Body \(C#\)](#)
[Get and Fill Gaps in Body \(VB.NET\)](#)
[Get and Fill Gaps in Body \(VBA\)](#)

Remarks

Call this method before calling [IDiagnoseResult::GetCoEdgesAtGap](#) and [IDiagnoseResult::IGetCoEdgesAtGap](#).

See Also

[IDiagnoseResult Interface](#)
[IDiagnoseResult Members](#)

Availability

SOLIDWORKS 2004 SP4, Revision Number 12.4

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetCoEdgesAtGap Method (IDiagnoseResult)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDiagnoseResult Interface](#) : IGetCoEdgesAtGap Method (IDiagnoseResult)

Gets the coedges at the specified gap.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetCoEdgesAtGap( _  
    ByVal Index As System.Integer, _  
    ByVal CoEdgeCount As System.Integer _  
) As CoEdge
```

Visual Basic (Usage)



```
Dim instance As IDiagnoseResult  
Dim Index As System.Integer  
Dim CoEdgeCount As System.Integer  
Dim value As CoEdge  
  
value = instance.IGetCoEdgesAtGap(Index, CoEdgeCount)
```

C#

```
CoEdge IGetCoEdgesAtGap(  
    System.int Index,  
    System.int CoEdgeCount  
)
```

C++/CLI

```
CoEdge^ IGetCoEdgesAtGap(  
    & System.int Index,  
    & System.int CoEdgeCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index number of the gap to get

CoEdgeCount
Number of coedges at that gap

Return Value

- in-process, unmanaged C++: Pointer to an array of [ICoEdge](#) objects
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call:

- [IDiagnoseResult::GetGapsCount](#) before calling this method to determine the index number of the gap to get on this body.
- [IDiagnoseResult::GetCoEdgesCountAtGap](#) before calling this method to get the number of coedges at the gap on this body.

See Also

[IDiagnoseResult Interface](#)
[IDiagnoseResult Members](#)

Availability

SOLIDWORKS 2004 SP4, Revision Number 12.4