

# SOLIDWORKS API (.NET VBA C#) — Reference

## (73/337): IDimensionSensorData- IDimensionTolerance

SOLIDWORKS API Documentation (converted from CHM)

# IDimensionSensorData (Type)

## IDimensionSensorData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDimensionSensorData Interface

Allows access to a Measurement (dimension) sensor feature.

**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

### .NET Syntax

Visual Basic (Declaration)

```
Public Interface IDimensionSensorData
```

Visual Basic (Usage)



```
Dim instance As IDimensionSensorData
```

C#

```
public interface IDimensionSensorData
```

C++/CLI

```
public interface class IDimensionSensorData
```

### Visual Basic for Applications (VBA) Syntax

See [DimensionSensorData](#).

### Example

[Get and Set Sensor \(C#\)](#)  
[Get and Set Sensor \(VB.NET\)](#)  
[Get and Set Sensor \(VBA\)](#)

### Accessors

[ISensor::GetSensorFeatureData](#)

### Access Diagram

[DimensionSensorData](#)

### See Also

[IDimensionSensorData Members](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[ISensor Interface](#)

## IDimensionSensorData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDimensionSensorData Interface

The following tables list the members exposed by [IDimensionSensorData](#).

### Public Properties

| Name                                                                                                            | Description                                                                      |
|-----------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------|
|  <a href="#">SensorValue</a> | Gets the value of the display dimension for this Measurement (dimension) sensor. |

[Top](#)

## Public Methods

| Name                                                                                                                  | Description                                                         |
|-----------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------|
|  <a href="#">GetDisplayDimension</a> | Gets the display dimension for this Measurement (dimension) sensor. |

[Top](#)

## See Also

[IDimensionSensorData Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[ISensor Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IDimensionSensorData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDimensionSensorData Interface

For a list of all members of this type, see [IDimensionSensorData members](#).

## Public Methods

| Name                                                                                                                  | Description                                                         |
|-----------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------|
|  <a href="#">GetDisplayDimension</a> | Gets the display dimension for this Measurement (dimension) sensor. |

[Top](#)

## See Also

[IDimensionSensorData Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[ISensor Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IDimensionSensorData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDimensionSensorData Interface

For a list of all members of this type, see [IDimensionSensorData members](#).

## Public Properties

| Name                                                                                                            | Description                                                                      |
|-----------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------|
|  <a href="#">SensorValue</a> | Gets the value of the display dimension for this Measurement (dimension) sensor. |

[Top](#)

## See Also

[IDimensionSensorData Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[ISensor Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetDisplayDimension Method (IDimensionSensorData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionSensorData Interface](#) : GetDisplayDimension Method (IDimensionSensorData)

Gets the display dimension for this Measurement (dimension) sensor.

## .NET Syntax

Visual Basic (Declaration)

Function GetDisplayDimension() As DisplayDimension

Visual Basic (Usage)



```
Dim instance As IDimensionSensorData
Dim value As DisplayDimension

value = instance.GetDisplayDimension()
```

C#

```
DisplayDimension GetDisplayDimension()
```

C++/CLI

```
DisplayDimension^ GetDisplayDimension();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

[Display dimension](#)

### Visual Basic for Applications (VBA) Syntax

See [DimensionSensorData::GetDisplayDimension](#).

### Example

[Get and Set Sensor \(C#\)](#)  
[Get and Set Sensor \(VB.NET\)](#)  
[Get and Set Sensor \(VBA\)](#)

### See Also

[IDimensionSensorData Interface](#)  
[IDimensionSensorData Members](#)

### Availability

SOLIDWORKS 2009 SP2, Revision Number 17.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

## SensorValue Property (IDimensionSensorData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionSensorData Interface](#) : SensorValue Property (IDimensionSensorData)

Gets the value of the display dimension for this Measurement (dimension) sensor.

### .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property SensorValue As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDimensionSensorData
Dim value As System.Double

value = instance.SensorValue
```

C#

```
System.double SensorValue {get;}
```

C++/CLI

```
property System.double SensorValue {
    System.double get();
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Value of the display dimension for this Measurement (dimension) sensor

#### Visual Basic for Applications (VBA) Syntax

See [DimensionSensorData::SensorValue](#).

#### Example

[Get and Set Sensor \(C#\)](#)  
[Get and Set Sensor \(VB.NET\)](#)  
[Get and Set Sensor \(VBA\)](#)

#### See Also

[IDimensionSensorData Interface](#)  
[IDimensionSensorData Members](#)

#### Availability

SOLIDWORKS 2009 SP2, Revision Number 17.2

# IDimensionTolerance (Type)

## IDimensionTolerance Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDimensionTolerance Interface

Allows you to get and set dimension tolerances.  
**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

### .NET Syntax

Visual Basic (Declaration)

```
Public Interface IDimensionTolerance
```

Visual Basic (Usage)



```
Dim instance As IDimensionTolerance
```

C#

```
public interface IDimensionTolerance
```

C++/CLI

```
public interface class IDimensionTolerance
```

### Visual Basic for Applications (VBA) Syntax

See [DimensionTolerance](#).

### Example

[Get Dimension Tolerance \(VBA\)](#)  
[Get Dimension Tolerance \(VB.NET\)](#)  
[Get Dimension Tolerance \(C#\)](#)

### Accessors

[IDimension::Tolerance](#)

### Access Diagram

[DimensionTolerance](#)

### See Also

[IDimensionTolerance Members](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IDisplayDimension Interface](#)

## IDimensionTolerance Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDimensionTolerance Interface

For a list of all members of this type, see [IDimensionTolerance members](#).

### Public Methods

| Name                              | Description                                                                                 |
|-----------------------------------|---------------------------------------------------------------------------------------------|
| <a href="#">GetFitFonthHeight</a> | Gets the height of the fit tolerance font.                                                  |
| <a href="#">GetFitFontScale</a>   | Gets the ratio of the height of the fit tolerance font to the height of the dimension font. |

|                                                                                   |                                        |                                                                                                                            |
|-----------------------------------------------------------------------------------|----------------------------------------|----------------------------------------------------------------------------------------------------------------------------|
|  | <a href="#">GetFitFontUseDimension</a> | Gets whether the fit tolerance font is the same size as the dimension font.                                                |
|  | <a href="#">GetFitFontUseScale</a>     | Gets whether the fit tolerance font size is scaled based on the dimension font size, or if it is an absolute height value. |
|  | <a href="#">GetFontHeight</a>          | Gets the height of the tolerance font.                                                                                     |
|  | <a href="#">GetFontScale</a>           | Gets the ratio of the height of the tolerance font to the height of the dimension font.                                    |
|  | <a href="#">GetFontUseDimension</a>    | Gets whether the tolerance font is the same size as the dimension font.                                                    |
|  | <a href="#">GetFontUseScale</a>        | Gets whether the tolerance font size is scaled based on the dimension font size, or if it is an absolute height value.     |
|  | <a href="#">GetHoleFitValue</a>        | Gets the tolerance hole fit value.                                                                                         |
|  | <a href="#">GetMaxValue</a>            | <b>Obsolete. Superseded by <a href="#">IDimensionTolerance.GetMaxValue2</a>.</b>                                           |
|  | <a href="#">GetMaxValue2</a>           | Gets the tolerance maximum value.                                                                                          |
|  | <a href="#">GetMinValue</a>            | <b>Obsolete. Superseded by <a href="#">IDimensionTolerance.GetMinValue2</a>.</b>                                           |
|  | <a href="#">GetMinValue2</a>           | Gets the tolerance minimum value.                                                                                          |
|  | <a href="#">GetShaftFitValue</a>       | Gets the tolerance shaft fit value.                                                                                        |
|  | <a href="#">SetFitFont</a>             | Sets the fit tolerance font values.                                                                                        |
|  | <a href="#">SetFitValues</a>           | Sets the tolerance hole fit and shaft fit values.                                                                          |
|  | <a href="#">SetFont</a>                | Sets the tolerance font values.                                                                                            |
|  | <a href="#">SetValues</a>              | <b>Obsolete. Superseded by <a href="#">IDimensionTolerance.SetValues2</a>.</b>                                             |
|  | <a href="#">SetValues2</a>             | Sets the tolerance minimum and maximum values of a <a href="#">dimension</a> .                                             |

[Top](#)

## See Also

[IDimensionTolerance Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IDisplayDimension Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IDimensionTolerance Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDimensionTolerance Interface

The following tables list the members exposed by [IDimensionTolerance](#).

## Public Properties

| Name                                                                                                                | Description                                                               |
|---------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------|
|  <a href="#">FitDisplayStyle</a> | Gets or sets how this dimension fit tolerance is displayed.               |
|  <a href="#">FitType</a>         | Gets or sets the fit type for this dimension fit tolerance.               |
|  <a href="#">ShowParenthesis</a> | Indicates whether to show parentheses around linear tolerance dimensions. |
|  <a href="#">Type</a>            | Gets or sets the type of tolerance.                                       |

[Top](#)

## Public Methods

| Name                                                                                                                       | Description                                                                                                                |
|----------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------|
|  <a href="#">GetFitFontHeight</a>       | Gets the height of the fit tolerance font.                                                                                 |
|  <a href="#">GetFitFontScale</a>        | Gets the ratio of the height of the fit tolerance font to the height of the dimension font.                                |
|  <a href="#">GetFitFontUseDimension</a> | Gets whether the fit tolerance font is the same size as the dimension font.                                                |
|  <a href="#">GetFitFontUseScale</a>     | Gets whether the fit tolerance font size is scaled based on the dimension font size, or if it is an absolute height value. |
|  <a href="#">GetFontHeight</a>          | Gets the height of the tolerance font.                                                                                     |
|  <a href="#">GetFontScale</a>           | Gets the ratio of the height of the tolerance font to the height of the dimension font.                                    |
|  <a href="#">GetFontUseDimension</a>    | Gets whether the tolerance font is the same size as the dimension font.                                                    |

|                                                                                   |                                  |                                                                                                                        |
|-----------------------------------------------------------------------------------|----------------------------------|------------------------------------------------------------------------------------------------------------------------|
|   |                                  |                                                                                                                        |
|  | <a href="#">GetFontUseScale</a>  | Gets whether the tolerance font size is scaled based on the dimension font size, or if it is an absolute height value. |
|  | <a href="#">GetHoleFitValue</a>  | Gets the tolerance hole fit value.                                                                                     |
|  | <a href="#">GetMaxValue</a>      | Obsolete. Superseded by <a href="#">IDimensionTolerance.GetMaxValue2</a> .                                             |
|  | <a href="#">GetMaxValue2</a>     | Gets the tolerance maximum value.                                                                                      |
|  | <a href="#">GetMinValue</a>      | Obsolete. Superseded by <a href="#">IDimensionTolerance.GetMinValue2</a> .                                             |
|  | <a href="#">GetMinValue2</a>     | Gets the tolerance minimum value.                                                                                      |
|  | <a href="#">GetShaftFitValue</a> | Gets the tolerance shaft fit value.                                                                                    |
|  | <a href="#">SetFitFont</a>       | Sets the fit tolerance font values.                                                                                    |
|  | <a href="#">SetFitValues</a>     | Sets the tolerance hole fit and shaft fit values.                                                                      |
|  | <a href="#">SetFont</a>          | Sets the tolerance font values.                                                                                        |
|  | <a href="#">SetValues</a>        | Obsolete. Superseded by <a href="#">IDimensionTolerance.SetValues2</a> .                                               |
|  | <a href="#">SetValues2</a>       | Sets the tolerance minimum and maximum values of a <a href="#">dimension</a> .                                         |

[Top](#)

## See Also

[IDimensionTolerance Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IDisplayDimension Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## IDimensionTolerance Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDimensionTolerance Interface

For a list of all members of this type, see [IDimensionTolerance members](#).

## Public Properties

| Name                                                                                                                | Description                                                               |
|---------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------|
|  <a href="#">FitDisplayStyle</a> | Gets or sets how this dimension fit tolerance is displayed.               |
|  <a href="#">FitType</a>         | Gets or sets the fit type for this dimension fit tolerance.               |
|  <a href="#">ShowParenthesis</a> | Indicates whether to show parentheses around linear tolerance dimensions. |
|  <a href="#">Type</a>            | Gets or sets the type of tolerance.                                       |

[Top](#)

## See Also

[IDimensionTolerance Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IDisplayDimension Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## FitDisplayStyle Property (IDimensionTolerance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionTolerance Interface](#) : FitDisplayStyle Property (IDimensionTolerance)

Gets or sets how this dimension fit tolerance is displayed.

## .NET Syntax

Visual Basic (Declaration)

Property FitDisplayStyle As System.Integer

Visual Basic (Usage)



```
Dim instance As IDimensionTolerance
Dim value As System.Integer

instance.FitDisplayStyle = value

value = instance.FitDisplayStyle
```

C#

```
System.int FitDisplayStyle {get; set;}
```

C++/CLI

```
property System.int FitDisplayStyle {
    System.int get();
    void set ( & System.int value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Fit tolerance display style as defined in [swFitTolDisplay\\_e](#)

### Visual Basic for Applications (VBA) Syntax

See [DimensionTolerance::FitDisplayStyle](#).

### Remarks

Use [ICalloutVariable::FitDisplayStyle](#) for multiple callouts in a display dimension for a hole.

To see the effects of changing the fit tolerance display style, use [IModelDoc2::GraphicsRedraw2](#).

### See Also

[IDimensionTolerance Interface](#)  
[IDimensionTolerance Members](#)  
[IDimensionTolerance::FitType Property \(\)](#)  
[IDimensionTolerance::GetFitFontHeight Method \(\)](#)  
[IDimensionTolerance::GetFitFontScale Method \(\)](#)  
[IDimensionTolerance::GetFitFontUseDimension Method \(\)](#)  
[IDimensionTolerance::GetFitFontUseScale Method \(\)](#)  
[IDimensionTolerance::GetHoleFitValue Method \(\)](#)  
[IDimensionTolerance::GetShaftFitValue Method \(\)](#)  
[IDimensionTolerance::SetFitFont Method \(\)](#)  
[IDimensionTolerance::SetFitValues Method \(\)](#)

### Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## FitType Property (IDimensionTolerance)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionTolerance Interface](#) : FitType Property (IDimensionTolerance)

Gets or sets the fit type for this dimension fit tolerance.

### .NET Syntax

Visual Basic (Declaration)

```
Property FitType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDimensionTolerance
Dim value As System.Integer

instance.FitType = value
```

```
value = instance.FitType
```

C#

```
System.int FitType {get; set;}
```

C++/CLI

```
property System.int FitType {  
    System.int get();  
    void set ( & System.int value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Fit type as defined in [swFitType\\_e](#)

### Visual Basic for Applications (VBA) Syntax

See [DimensionTolerance::FitType](#).

### Example

[Get Dimension Tolerance \(C#\)](#)  
[Get Dimension Tolerance \(VB.NET\)](#)  
[Get Dimension Tolerance \(VBA\)](#)

### Remarks

This property is only available when the [type of tolerance](#) is [swTolType\\_e](#):

- swTolFIT,
- swTolFITTOONLY, or
- swTolFITWITHTOL.

### See Also

[IDimensionTolerance Interface](#)  
[IDimensionTolerance Members](#)  
[IDimensionTolerance::GetFitFontHeight Method \(\)](#)  
[IDimensionTolerance::GetFitFontScale Method \(\)](#)  
[IDimensionTolerance::GetFitFontUseDimension Method \(\)](#)  
[IDimensionTolerance::GetFitFontUseScale Method \(\)](#)  
[IDimensionTolerance::GetHoleFitValue Method \(\)](#)  
[IDimensionTolerance::GetShaftFitValue Method \(\)](#)  
[IDimensionTolerance::SetFitFont Method \(\)](#)  
[IDimensionTolerance::SetFitValues Method \(\)](#)  
[IDimensionTolerance::FitDisplayStyle Property \(\)](#)

### Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## GetFitFontHeight Method (IDimensionTolerance)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionTolerance Interface](#) : GetFitFontHeight Method (IDimensionTolerance)

Gets the height of the fit tolerance font.

### .NET Syntax

Visual Basic (Declaration)

```
Function GetFitFontHeight() As System.Double
```

Visual Basic (Usage)

```
Dim instance As IDimensionTolerance  
Dim value As System.Double
```



```
value = instance.GetFitFontHeight()
```

C#

```
System.double GetFitFontHeight()
```

C++/CLI

```
System.double GetFitFontHeight();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Height of the fit tolerance font in system units

### Visual Basic for Applications (VBA) Syntax

See [IDimensionTolerance::GetFitFontHeight](#).

### Example

[Get Dimension Tolerance \(C#\)](#)  
[Get Dimension Tolerance \(VB.NET\)](#)  
[Get Dimension Tolerance \(VBA\)](#)

### Remarks

This value is used only if the [IDimensionTolerance::GetFitFontUseDimension](#) and [IDimensionTolerance::GetFitFontUseScale](#) are false.

To get other tolerance fit font information, use [IDimensionTolerance::GetFitFontScale](#).

To set the tolerance font information, use [IDimensionTolerance::SetFitFont](#).

This method deals with the fit tolerance font information, not the tolerance font information. To get or set tolerance information, use [IDimensionTolerance::GetFontUseDimension](#), [IDimensionTolerance::GetFontUseScale](#), [IDimensionTolerance::GetFontScale](#), [IDimensionTolerance::GetFontHeight](#), and [IDimensionTolerance::SetFont](#).

### See Also

[IDimensionTolerance Interface](#)  
[IDimensionTolerance Members](#)  
[IDimensionTolerance::FitDisplayStyle Property \(\)](#)  
[IDimensionTolerance::FitType Property \(\)](#)  
[IDimensionTolerance::GetHoleFitValue Method \(\)](#)  
[IDimensionTolerance::GetShaftFitValue Method \(\)](#)  
[IDimensionTolerance::SetFitValues Method \(\)](#)

### Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetFitFontScale Method (IDimensionTolerance)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionTolerance Interface](#) : GetFitFontScale Method (IDimensionTolerance)

Gets the ratio of the height of the fit tolerance font to the height of the dimension font.

### .NET Syntax

Visual Basic (Declaration)

```
Function GetFitFontScale() As System.Double
```

Visual Basic (Usage)

```
Dim instance As IDimensionTolerance  
Dim value As System.Double
```



```
value = instance.GetFitFontScale()
```

C#

```
System.double GetFitFontScale()
```

C++/CLI

```
System.double GetFitFontScale();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Ratio of the height of the fit tolerance font to the height of the dimension font

### Visual Basic for Applications (VBA) Syntax

See [DimensionTolerance::GetFitFontScale](#).

### Example

[Get Dimension Tolerance \(C#\)](#)  
[Get Dimension Tolerance \(VB.NET\)](#)  
[Get Dimension Tolerance \(VBA\)](#)

### Remarks

If [IDimensionTolerance::GetFitFontUseDimension](#) is true, then the value returned by the [IDimensionTolerance::GetFitFontUseScale](#) is true and the value returned by [IDimensionTolerance::GetFitFontScale](#) method is 1.0.

To get other fit tolerance font information, use [IDimensionTolerance::GetFitFontHeight](#).

To set the fit tolerance font information, use [IDimensionTolerance::SetFitFont](#).

This method deals with the fit tolerance font information, not the tolerance font information. To get or set tolerance information, use [IDimensionTolerance::GetFontUseDimension](#), [IDimensionTolerance::GetFontUseScale](#), [IDimensionTolerance::GetFontScale](#), [IDimensionTolerance::GetFontHeight](#), and [IDimensionTolerance::SetFont](#).

### See Also

[IDimensionTolerance Interface](#)  
[IDimensionTolerance Members](#)  
[IDimensionTolerance::FitDisplayStyle Property \(\)](#)  
[IDimensionTolerance::FitType Property \(\)](#)  
[IDimensionTolerance::GetShaftFitValue Method \(\)](#)  
[IDimensionTolerance::GetHoleFitValue Method \(\)](#)  
[IDimensionTolerance::SetFitValues Method \(\)](#)

### Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## GetFitFontUseDimension Method (IDimensionTolerance)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionTolerance Interface](#) : GetFitFontUseDimension Method (IDimensionTolerance)

Gets whether the fit tolerance font is the same size as the dimension font.

### .NET Syntax

Visual Basic (Declaration)

```
Function GetFitFontUseDimension() As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IDimensionTolerance  
Dim value As System.Boolean
```



```
value = instance.GetFitFontUseDimension()
```

C#

```
System.bool GetFitFontUseDimension()
```

C++/CLI

```
System.bool GetFitFontUseDimension();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

True if the fit tolerance font is the same size as the dimension font, false if not

### Visual Basic for Applications (VBA) Syntax

See [IDimensionTolerance::GetFitFontUseDimension](#).

### Example

[Get Dimension Tolerance \(C#\)](#)  
[Get Dimension Tolerance \(VB.NET\)](#)  
[Get Dimension Tolerance \(VBA\)](#)

### Remarks

To get other fit tolerance font information, use [IDimensionTolerance::GetFitFontUseScale](#), [IDimensionTolerance::GetFitFontScale](#), and [IDimensionTolerance::GetFitFontHeight](#).

To set the fit tolerance font information, use [IDimensionTolerance::SetFitFont](#).

This method deals with the fit tolerance font information, not the tolerance font information. To get or set tolerance information, use [IDimensionTolerance::GetFontUseDimension](#), [IDimensionTolerance::GetFontUseScale](#), [IDimensionTolerance::GetFontScale](#), [IDimensionTolerance::GetFontHeight](#), and [IDimensionTolerance::SetFont](#).

### See Also

[IDimensionTolerance Interface](#)  
[IDimensionTolerance Members](#)  
[IDimensionTolerance::FitDisplayStyle Property \(\)](#)  
[IDimensionTolerance::FitType Property \(\)](#)  
[IDimensionTolerance::GetHoleFitValue Method \(\)](#)  
[IDimensionTolerance::GetShaftFitValue Method \(\)](#)  
[IDimensionTolerance::SetFitValues Method \(\)](#)

### Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetFitFontUseScale Method (IDimensionTolerance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionTolerance Interface](#) : GetFitFontUseScale Method (IDimensionTolerance)

Gets whether the fit tolerance font size is scaled based on the dimension font size, or if it is an absolute height value.

### .NET Syntax

Visual Basic (Declaration)

```
Function GetFitFontUseScale() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimensionTolerance  
Dim value As System.Boolean  
  
value = instance.GetFitFontUseScale()
```

C#

```
System.bool GetFitFontUseScale()
```

C++/CLI

```
System.bool GetFitFontUseScale();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

True if the fit tolerance font size is scaled based on the dimension font size, false if the fit tolerance font size is an absolute height value

### Visual Basic for Applications (VBA) Syntax

See [IDimensionTolerance::GetFitFontUseScale](#).

### Remarks

If [IDimensionTolerance::GetFitFontUseDimension](#) is true, then the value returned by IDimensionTolerance::GetFitFontUseScale method is true and the value returned by [IDimensionTolerance::GetFitFontScale](#) is 1.0.

To get other fit tolerance font information, use [IDimensionTolerance::GetFitFontHeight](#).

To set the fit tolerance font information, use [IDimensionTolerance::SetFitFont](#).

This method deals with the fit tolerance font information, not the tolerance font information. To get or set tolerance information, use [IDimensionTolerance::GetFontUseDimension](#), [IDimensionTolerance::GetFontUseScale](#), [IDimensionTolerance::GetFontScale](#), [IDimensionTolerance::GetFontHeight](#), and [IDimensionTolerance::SetFont](#).

### See Also

[IDimensionTolerance Interface](#)  
[IDimensionTolerance Members](#)  
[IDimensionTolerance::FitDisplayStyle Property \(\)](#)  
[IDimensionTolerance::FitType Property \(\)](#)  
[IDimensionTolerance::GetHoleFitValue Method \(\)](#)  
[IDimensionTolerance::GetShaftFitValue Method \(\)](#)  
[IDimensionTolerance::SetFitValues Method \(\)](#)

### Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetFontHeight Method (IDimensionTolerance)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionTolerance Interface](#) : GetFontHeight Method (IDimensionTolerance)

Gets the height of the tolerance font.

### .NET Syntax

Visual Basic (Declaration)

```
Function GetFontHeight() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDimensionTolerance  
Dim value As System.Double
```

```
value = instance.GetFontHeight()
```

C#

```
System.double GetFontHeight()
```

C++/CLI

```
System.double GetFontHeight();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Height of the tolerance font in system units

### Visual Basic for Applications (VBA) Syntax

See [IDimensionTolerance::GetFontHeight](#).

### Example

[Get Dimension Tolerance \(VBA\)](#)  
[Get Dimension Tolerance \(VB.NET\)](#)  
[Get Dimension Tolerance \(C#\)](#)

### Remarks

This value is used only if [IDimensionTolerance::GetFontUseDimension](#) and [IDimensionTolerance::GetFontUseScale](#) are false.

To get other tolerance font information, use [IDimensionTolerance::GetFontScale](#).

To set the tolerance font information, use [IDimensionTolerance::SetFont](#).

This method deals with the tolerance font information, not the fit tolerance font information. To get or set fit tolerance information, use [IDimensionTolerance::GetFitFontUseDimension](#), [IDimensionTolerance::GetFitFontUseScale](#), [IDimensionTolerance::GetFitFontScale](#), [IDimensionTolerance::GetFitFontHeight](#), and [IDimensionTolerance::SetFitFont](#).

### See Also

[IDimensionTolerance Interface](#)  
[IDimensionTolerance Members](#)

### Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetFontScale Method (IDimensionTolerance)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionTolerance Interface](#) : GetFontScale Method (IDimensionTolerance)

Gets the ratio of the height of the tolerance font to the height of the dimension font.

### .NET Syntax

#### Visual Basic (Declaration)

```
Function GetFontScale() As System.Double
```

#### Visual Basic (Usage)



```
Dim instance As IDimensionTolerance  
Dim value As System.Double  
  
value = instance.GetFontScale()
```

#### C#

```
System.double GetFontScale()
```

#### C++/CLI

```
System.double GetFontScale();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Return Value

Ratio of the height of the tolerance font to the height of the dimension font

## Visual Basic for Applications (VBA) Syntax

See [IDimensionTolerance::GetFontScale](#).

## Example

[Get Dimension Tolerance \(VBA\)](#)  
[Get Dimension Tolerance \(VB.NET\)](#)  
[Get Dimension Tolerance \(C#\)](#)

## Remarks

If [IDimensionTolerance::GetFontUseDimension](#) is true, then the value returned by the [IDimensionTolerance::GetFontUseScale](#) is True and the value returned by [IDimensionTolerance::GetFontScale](#) is 1.0.

To get other tolerance font information, use [IDimensionTolerance::GetFontHeight](#).

To set the tolerance font information, use [IDimensionTolerance::SetFont](#).

This method deals with the tolerance font information, not the fit tolerance font information. To get or set fit tolerance information, use [IDimensionTolerance::GetFitFontUseDimension](#), [IDimensionTolerance::GetFitFontUseScale](#), [IDimensionTolerance::GetFitFontScale](#), [IDimensionTolerance::GetFitFontHeight](#), and [IDimensionTolerance::SetFitFont](#).

## See Also

[IDimensionTolerance Interface](#)  
[IDimensionTolerance Members](#)

## Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetFontUseDimension Method (IDimensionTolerance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionTolerance Interface](#) : GetFontUseDimension Method (IDimensionTolerance)

Gets whether the tolerance font is the same size as the dimension font.

## .NET Syntax

Visual Basic (Declaration)

```
Function GetFontUseDimension() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimensionTolerance  
Dim value As System.Boolean  
  
value = instance.GetFontUseDimension()
```

C#

```
System.bool GetFontUseDimension()
```

C++/CLI

```
System.bool GetFontUseDimension();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Return Value

True if the tolerance font is the same size as the dimension font, false if not

## Visual Basic for Applications (VBA) Syntax

See [IDimensionTolerance::GetFontUseDimension](#).

## Remarks

To get other tolerance font information, use [IDimensionTolerance::GetFontUseScale](#), [IDimensionTolerance::GetFontScale](#), and [IDimensionTolerance::GetFontHeight](#).

To set the tolerance font information, use [IDimensionTolerance::SetFont](#).

This method deals with the tolerance font information, not the fit tolerance font information. To get or set fit tolerance information, use [IDimensionTolerance::GetFitFontUseDimension](#), [IDimensionTolerance::GetFitFontUseScale](#), [IDimensionTolerance::GetFitFontScale](#), [IDimensionTolerance::GetFitFontHeight](#), and [IDimensionTolerance::SetFitFont](#).

## See Also

[IDimensionTolerance Interface](#)  
[IDimensionTolerance Members](#)

## Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetFontUseScale Method (IDimensionTolerance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionTolerance Interface](#) : GetFontUseScale Method (IDimensionTolerance)

Gets whether the tolerance font size is scaled based on the dimension font size, or if it is an absolute height value.

## .NET Syntax

Visual Basic (Declaration)

```
Function GetFontUseScale() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimensionTolerance
Dim value As System.Boolean

value = instance.GetFontUseScale()
```

C#

```
System.bool GetFontUseScale()
```

C++/CLI

```
System.bool GetFontUseScale();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Return Value

True if the tolerance font size is scaled based on the dimension font size, false if the tolerance font size is an absolute height value

## Visual Basic for Applications (VBA) Syntax

See [IDimensionTolerance::GetFontUseScale](#).

## Remarks

If [IDimensionTolerance::GetFontUseDimension](#) is true, then the value returned by this [IDimensionTolerance::GetFontUseScale](#) is True and the value returned by [IDimensionTolerance::GetFontScale](#) is 1.0.

To get other tolerance font information, use the [IDimensionTolerance::GetFontHeight](#).

To set the tolerance font information, use the [IDimensionTolerance::SetFont](#) method.

This method deals with the tolerance font information, not the fit tolerance font information. To get or set fit tolerance information, use [IDimensionTolerance::GetFitFontUseDimension](#), [IDimensionTolerance::GetFitFontUseScale](#), [IDimensionTolerance::GetFitFontScale](#), [IDimensionTolerance::GetFitFontHeight](#), and [IDimensionTolerance::SetFitFont](#).

#### See Also

[IDimensionTolerance Interface](#)  
[IDimensionTolerance Members](#)

#### Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## GetHoleFitValue Method (IDimensionTolerance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionTolerance Interface](#) : GetHoleFitValue Method (IDimensionTolerance)

Gets the tolerance hole fit value.

#### .NET Syntax

Visual Basic (Declaration)

```
Function GetHoleFitValue() As System.String
```

Visual Basic (Usage)



```
Dim instance As IDimensionTolerance  
Dim value As System.String  
  
value = instance.GetHoleFitValue()
```

C#

```
System.string GetHoleFitValue()
```

C++/CLI

```
System.String^ GetHoleFitValue();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Tolerance hole fit value

#### Visual Basic for Applications (VBA) Syntax

See [DimensionTolerance::GetHoleFitValue](#).

#### Remarks

Depending on the [type of fit tolerance](#), to:

- get the tolerance shaft fit value, use [IDimensionTolerance::GetShaftFitValue](#).
- set the tolerance fit values, use [IDimensionTolerance::SetFitValues](#).

#### See Also

[IDimensionTolerance Interface](#)  
[IDimensionTolerance Members](#)  
[IDimensionTolerance::FitType Property \(\)](#)  
[ICalloutVariable::HoleFit Property \(\)](#)

#### Availability

## GetMaxValue Method (IDimensionTolerance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionTolerance Interface](#) : GetMaxValue Method (IDimensionTolerance)

Obsolete. Superseded by [IDimensionTolerance::GetMaxValue2](#).

### .NET Syntax

#### Visual Basic (Declaration)

```
Function GetMaxValue() As System.Double
```

#### Visual Basic (Usage)



```
Dim instance As IDimensionTolerance  
Dim value As System.Double  
  
value = instance.GetMaxValue()
```

#### C#

```
System.double GetMaxValue()
```

#### C++/CLI

```
System.double GetMaxValue();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Tolerance maximum value

### Visual Basic for Applications (VBA) Syntax

See [DimensionTolerance::GetMaxValue](#).

### Remarks

Depending on the [tolerance type](#), the tolerance minimum and maximum values might not be visible.

To:

- get the tolerance minimum value, use [IDimensionTolerance::GetMinValue](#).
- set the tolerance values, use [IDimensionTolerance::SetValues](#).

### See Also

[IDimensionTolerance Interface](#)  
[IDimensionTolerance Members](#)

### Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

## GetMaxValue2 Method (IDimensionTolerance)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionTolerance Interface](#) : GetMaxValue2 Method (IDimensionTolerance)

Gets the tolerance maximum value.

### .NET Syntax

#### Visual Basic (Declaration)

```
Function GetMaxValue2( _
    ByRef ToleranceValue As System.Double _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDimensionTolerance
Dim ToleranceValue As System.Double
Dim value As System.Integer

value = instance.GetMaxValue2(ToleranceValue)
```

C#

```
System.int GetMaxValue2(
    out System.double ToleranceValue
)
```

C++/CLI

```
System.int GetMaxValue2(
    & [Out] System.double ToleranceValue
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*ToleranceValue*  
Tolerance maximum value

#### Return Value

Status of tolerance maximum value as defined in [swDimensionToleranceWarning\\_e](#)

### Visual Basic for Applications (VBA) Syntax

See [DimensionTolerance::GetMaxValue2](#).

### Example

[Get Dimension Tolerance \(C#\)](#)  
[Get Dimension Tolerance \(VB.NET\)](#)  
[Get Dimension Tolerance \(VBA\)](#)

### Remarks

Depending on the [tolerance type](#), the tolerance minimum and maximum values might not be visible.

To:

- get the tolerance minimum value, use [IDimensionTolerance::GetMinValue2](#).
- set the tolerance values, use [IDimensionTolerance::SetValues2](#).

### See Also

[IDimensionTolerance Interface](#)  
[IDimensionTolerance Members](#)

### Availability

SOLIDWORKS 2015 SP3, Revision Number 23.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetMinValue Method (IDimensionTolerance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionTolerance Interface](#) : GetMinValue Method (IDimensionTolerance)

Obsolete. Superseded by [IDimensionTolerance::GetMinValue2](#).

## Visual Basic Syntax

### Visual Basic (Declaration)

```
Function GetMinValue() As System.Double
```

### Visual Basic (Usage)

```
Dim instance As IDimensionTolerance
Dim value As System.Double

value = instance.GetMinValue()
```

### C#

```
System.double GetMinValue()
```

### C++/CLI

```
System.double GetMinValue();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Return Value

Tolerance minimum value

## Visual Basic for Applications (VBA) Syntax

See [DimensionTolerance::GetMinValue](#).

## Remarks

Depending on the [tolerance type](#), the tolerance minimum and maximum values might not be visible.

To:

- get the tolerance maximum value, use [IDimensionTolerance::GetMaxValue](#).
- set the tolerance values, use [IDimensionTolerance::SetValues](#).

## See Also

[IDimensionTolerance Interface](#)  
[IDimensionTolerance Members](#)

## Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## GetMinValue2 Method (IDimensionTolerance)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionTolerance Interface](#) : GetMinValue2 Method (IDimensionTolerance)

Gets the tolerance minimum value.

## Visual Basic Syntax

### Visual Basic (Declaration)

```
Function GetMinValue2( _  
    ByRef ToleranceValue As System.Double _  
) As System.Integer
```

### Visual Basic (Usage)

```
Dim instance As IDimensionTolerance  
Dim ToleranceValue As System.Double
```

```
Dim value As System.Integer

value = instance.GetMinValue2(ToleranceValue)
```

C#

```
System.int GetMinValue2(
    out System.double ToleranceValue
)
```

C++/CLI

```
System.int GetMinValue2(
    & [Out] System.double ToleranceValue
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*ToleranceValue*  
Tolerance minimum value

#### Return Value

Status of tolerance minimum value as defined in [swDimensionToleranceWarning\\_e](#)

### Visual Basic for Applications (VBA) Syntax

See [DimensionTolerance::GetMinValue2](#).

### Example

[Get Dimension Tolerance \(C#\)](#)  
[Get Dimension Tolerance \(VB.NET\)](#)  
[Get Dimension Tolerance \(VBA\)](#)

### Remarks

Depending on the [tolerance type](#), the tolerance minimum and maximum values might not be visible.

To:

- get the tolerance maximum value, use [IDimensionTolerance::GetMaxValue2](#).
- set the tolerance values, use [IDimensionTolerance::SetValues2](#).

### See Also

[IDimensionTolerance Interface](#)  
[IDimensionTolerance Members](#)

### Availability

SOLIDWORKS 2015 SP3, Revision Number 23.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetShaftFitValue Method (IDimensionTolerance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionTolerance Interface](#) : GetShaftFitValue Method (IDimensionTolerance)

Gets the tolerance shaft fit value.

### .NET Syntax

Visual Basic (Declaration)

```
Function GetShaftFitValue() As System.String
```

Visual Basic (Usage)



Copy Code

```
Dim instance As IDimensionTolerance
Dim value As System.String

value = instance.GetShaftFitValue()
```

C#

```
System.string GetShaftFitValue()
```

C++/CLI

```
System.String^ GetShaftFitValue();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Tolerance shaft fit value

### Visual Basic for Applications (VBA) Syntax

See [DimensionTolerance::GetShaftFitValue](#).

### Remarks

Depending on the [type of fit tolerance](#), to:

- get the tolerance hole fit value, use [IDimensionTolerance::GetHoleFitValue](#).
- set the tolerance fit values, use [IDimensionTolerance::SetFitValues](#).

### See Also

[IDimensionTolerance Interface](#)  
[IDimensionTolerance Members](#)  
[ICalloutVariable::ShaftFit Property \(\)](#)  
[IDimensionTolerance::FitType Property \(\)](#)

### Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## SetFitFont Method (IDimensionTolerance)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionTolerance Interface](#) : SetFitFont Method (IDimensionTolerance)

Sets the fit tolerance font values.

### .NET Syntax

Visual Basic (Declaration)

```
Function SetFitFont( _
    ByVal UseDimension As System.Boolean, _
    ByVal UseScale As System.Boolean, _
    ByVal Value As System.Double _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimensionTolerance
Dim UseDimension As System.Boolean
Dim UseScale As System.Boolean
Dim Value As System.Double
Dim value As System.Boolean

value = instance.SetFitFont(UseDimension, UseScale, Value)
```

C#

```
System.bool SetFitFont(
    System.bool UseDimension,
    System.bool UseScale,
    System.double Value
)
```

C++/CLI

```
System.bool SetFitFont(
    & System.bool UseDimension,
    & System.bool UseScale,
    & System.double Value
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*UseDimension*

True if the fit tolerance font should be the same size as the dimension font, false if not

*UseScale*

True if the fit tolerance font should be scaled based on the dimension font, false if the fit tolerance font size is an absolute height value

*Value*

Scale ratio if UseScale is true or height value if UseScale is false

#### Return Value

True if the fit tolerance font is set, false if not

### Visual Basic for Applications (VBA) Syntax

See [DimensionTolerance::SetFitFont](#).

### Example

[Get Dimension Tolerance \(C#\)](#)

[Get Dimension Tolerance \(VB.NET\)](#)

[Get Dimension Tolerance \(VBA\)](#)

### Remarks

| If UseDimension is...                                                                                                                                                                                                                                                           | Then...                                                                                                                              |                   |                                |      |                                                          |       |                                                          |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------|-------------------|--------------------------------|------|----------------------------------------------------------|-------|----------------------------------------------------------|
| True                                                                                                                                                                                                                                                                            | <ul style="list-style-type: none"> <li>The other arguments are ignored.</li> <li>UseScale is true.</li> <li>Value is 1.0.</li> </ul> |                   |                                |      |                                                          |       |                                                          |
| False                                                                                                                                                                                                                                                                           | UseScale determines how Value is interpreted.                                                                                        |                   |                                |      |                                                          |       |                                                          |
| <table> <tr> <th>If UseScale is...</th><th>Then Value is assumed to be...</th></tr> <tr> <td>True</td><td>Scale value to use, and the height value is not changed.</td></tr> <tr> <td>False</td><td>Height value to use, and the scale value is not changed.</td></tr> </table> |                                                                                                                                      | If UseScale is... | Then Value is assumed to be... | True | Scale value to use, and the height value is not changed. | False | Height value to use, and the scale value is not changed. |
| If UseScale is...                                                                                                                                                                                                                                                               | Then Value is assumed to be...                                                                                                       |                   |                                |      |                                                          |       |                                                          |
| True                                                                                                                                                                                                                                                                            | Scale value to use, and the height value is not changed.                                                                             |                   |                                |      |                                                          |       |                                                          |
| False                                                                                                                                                                                                                                                                           | Height value to use, and the scale value is not changed.                                                                             |                   |                                |      |                                                          |       |                                                          |

To get the fit tolerance font information, use [IDimensionTolerance::GetFitFontUseDimension](#), [IDimensionTolerance::GetFitFontUseScale](#), [IDimensionTolerance::GetFitFontScale](#), and [IDimensionTolerance::GetFitFontHeight](#).

This method deals with the fit tolerance font information, not the tolerance font information. To get or set tolerance information, use [IDimensionTolerance::GetFontUseDimension](#), [IDimensionTolerance::GetFontUseScale](#), [IDimensionTolerance::GetFontScale](#), [IDimensionTolerance::GetFontHeight](#), and [IDimensionTolerance::SetFont](#).

To see the effects of changing the fit tolerance font information, use [IModelDoc2::GraphicsRedraw2](#).

### See Also

[IDimensionTolerance Interface](#)

[IDimensionTolerance Members](#)

[IDimensionTolerance::FitDisplayStyle Property\(\)](#)

[IDimensionTolerance::FitType Property\(\)](#)

## Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## SetFitValues Method (IDimensionTolerance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionTolerance Interface](#) : SetFitValues Method (IDimensionTolerance)

Sets the tolerance hole fit and shaft fit values.

## .NET Syntax

### Visual Basic (Declaration)

```
Function SetFitValues( _  
    ByVal HoleFit As System.String, _  
    ByVal ShaftFit As System.String _  
) As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As IDimensionTolerance  
Dim HoleFit As System.String  
Dim ShaftFit As System.String  
Dim value As System.Boolean  
  
value = instance.SetFitValues(HoleFit, ShaftFit)
```

### C#

```
System.bool SetFitValues(  
    System.string HoleFit,  
    System.string ShaftFit  
)
```

### C++/CLI

```
System.bool SetFitValues(  
& System.String^ HoleFit,  
& System.String^ ShaftFit  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

*HoleFit*  
Tolerance hole fit value  
*ShaftFit*  
Tolerance shaft fit value

### Return Value

True if the setting of the fit values is successful, false if not

## Visual Basic for Applications (VBA) Syntax

See [DimensionTolerance::SetFitValues](#).

## Remarks

### To get tolerance...

### Use...

Hole fit value

[IDimensionTolerance::GetHoleFitValue](#)

Shaft fit value

[IDimensionTolerance::GetShaftFitValue](#)

To see the effects of changing the tolerance fit values, use [IModelDoc2::GraphicsRedraw2](#).

## See Also

[IDimensionTolerance Interface](#)  
[IDimensionTolerance Members](#)  
[IDimensionTolerance::FitType Property \(\)](#)  
[ICalloutVariable::HoleFit Property \(\)](#)  
[ICalloutVariable::ShaftFit Property \(\)](#)

## Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## SetFont Method (IDimensionTolerance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionTolerance Interface](#) : SetFont Method (IDimensionTolerance)

Sets the tolerance font values.

## .NET Syntax

### Visual Basic (Declaration)

```
Function SetFont( _  
    ByVal UseDimension As System.Boolean, _  
    ByVal UseScale As System.Boolean, _  
    ByVal Value As System.Double _  
) As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As IDimensionTolerance  
Dim UseDimension As System.Boolean  
Dim UseScale As System.Boolean  
Dim Value As System.Double  
Dim value As System.Boolean
```

```
value = instance.SetFont(UseDimension, UseScale, Value)
```

### C#

```
System.bool SetFont(  
    System.bool UseDimension,  
    System.bool UseScale,  
    System.double Value  
)
```

### C++/CLI

```
System.bool SetFont(  
& System.bool UseDimension,  
& System.bool UseScale,  
& System.double Value  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

#### *UseDimension*

True if the tolerance font should be the same size as the dimension font, false if not

#### *UseScale*

True if the tolerance font size should be scaled based on the dimension font size, false if the tolerance font size is an absolute height value

#### *Value*

Scale ratio if UseScale is true or height value if UseScale is false

### Return Value

True if the tolerance font is set, false if not

## Visual Basic for Applications (VBA) Syntax

See [DimensionTolerance::SetFont](#).

## Remarks

| If UseDimension is... | Then...                                                                                                                                                                                                                                                                                                                    |                   |                                    |      |                                                          |       |                                                          |
|-----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|------------------------------------|------|----------------------------------------------------------|-------|----------------------------------------------------------|
| True                  | <ul style="list-style-type: none"><li>• The other arguments are ignored.</li><li>• UseScale is True.</li><li>• Value is 1.0.</li></ul>                                                                                                                                                                                     |                   |                                    |      |                                                          |       |                                                          |
| false                 | UseScale determines how Value is interpreted. <table><tr><th>If UseScale is...</th><th>Then Value is assumed to be the...</th></tr><tr><td>True</td><td>scale value to use, and the height value is not changed.</td></tr><tr><td>false</td><td>height value to use, and the scale value is not changed.</td></tr></table> | If UseScale is... | Then Value is assumed to be the... | True | scale value to use, and the height value is not changed. | false | height value to use, and the scale value is not changed. |
| If UseScale is...     | Then Value is assumed to be the...                                                                                                                                                                                                                                                                                         |                   |                                    |      |                                                          |       |                                                          |
| True                  | scale value to use, and the height value is not changed.                                                                                                                                                                                                                                                                   |                   |                                    |      |                                                          |       |                                                          |
| false                 | height value to use, and the scale value is not changed.                                                                                                                                                                                                                                                                   |                   |                                    |      |                                                          |       |                                                          |

To get the tolerance font information, use [IDimensionTolerance::GetFontUseDimension](#), [IDimensionTolerance::GetFontUseScale](#), [IDimensionTolerance::GetFontScale](#), and [IDimensionTolerance::GetFontHeight](#).

This method deals with the tolerance font information, not the fit tolerance font information. To get or set fit tolerance information, use [IDimensionTolerance::GetFitFontUseDimension](#), [IDimensionTolerance::GetFitFontUseScale](#), [IDimensionTolerance::GetFitFontScale](#), [IDimensionTolerance::GetFitFontHeight](#), and [IDimensionTolerance::SetFitFont](#).

To see the effects of changing the tolerance font information, use [IModelDoc2::GraphicsRedraw2](#).

## See Also

[IDimensionTolerance Interface](#)  
[IDimensionTolerance Members](#)

## Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## SetValues Method (IDimensionTolerance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionTolerance Interface](#) : SetValues Method (IDimensionTolerance)

Obsolete. Superseded by [IDimensionTolerance::SetValues2](#).

## .NET Syntax

Visual Basic (Declaration)

```
Function SetValues( _  
    ByVal MinValue As System.Double, _  
    ByVal MaxValue As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimensionTolerance  
Dim MinValue As System.Double  
Dim MaxValue As System.Double  
Dim value As System.Boolean
```

```
value = instance.SetValues(MinValue, MaxValue)
```

C#

```
System.bool SetValues(  
    System.double MinValue,  
    System.double MaxValue  
)
```

```
System.bool SetValues(
& System.double MinValue,
& System.double MaxValue
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*MinValue*  
Tolerance minimum value  
*MaxValue*  
Tolerance maximum value

#### Return Value

True if the minimum and maximum tolerance values are set, false if not

### Visual Basic for Applications (VBA) Syntax

See [DimensionTolerance::SetValues](#).

### Remarks

You cannot set the dimension tolerance values if the [tolerance type](#) is [swTolType\\_e.swTolNONE](#). Depending on the tolerance type, the dimension tolerance minimum and maximum values might not be visible.

| To get tolerance... | Use...                                           |
|---------------------|--------------------------------------------------|
| Minimum value       | <a href="#">IDimensionTolerance::GetMinValue</a> |
| Maximum value       | <a href="#">IDimensionTolerance::GetMaxValue</a> |

To see the effects of changing the tolerance values, call [IModelDoc2::GraphicsRedraw2](#).

### See Also

[IDimensionTolerance Interface](#)  
[IDimensionTolerance Members](#)

### Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## SetValues2 Method (IDimensionTolerance)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionTolerance Interface](#) : SetValues2 Method (IDimensionTolerance)

Sets the tolerance minimum and maximum values of a [dimension](#).

### .NET Syntax

Visual Basic (Declaration)

```
Function SetValues2( _
    ByVal MinValue As System.Double, _
    ByVal MaxValue As System.Double, _
    ByVal WhichConfigurations As System.Integer, _
    ByVal Config\_names As System.Object _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IDimensionTolerance
Dim MinValue As System.Double
Dim MaxValue As System.Double
Dim WhichConfigurations As System.Integer
```



```
Dim Config_names As System.Object
Dim value As System.Boolean

value = instance.SetValues2(MinValue, MaxValue, WhichConfigurations, Config_names)
```

C#

```
System.bool SetValues2(
    System.double MinValue,
    System.double MaxValue,
    System.int WhichConfigurations,
    System.object Config\_names
)
```

C++/CLI

```
System.bool SetValues2(
    & System.double MinValue,
    & System.double MaxValue,
    & System.int WhichConfigurations,
    & System.Object^ Config\_names
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*MinValue*

Dimension tolerance minimum value

*MaxValue*

Dimension tolerance maximum value

*WhichConfigurations*

Configurations to which to set the dimension tolerance minimum and maximum values as defined in [swSetValueInConfiguration\\_e](#)

*Config\_names*

Names of the configurations for which to set dimension tolerance values

#### Return Value

True if the dimension tolerance values are set, false if not

### Visual Basic for Applications (VBA) Syntax

See [DimensionTolerance::SetValues2](#).

### Example

[Change Dimension Tolerance in a Configuration \(C#\)](#)  
[Change Dimension Tolerance in a Configuration \(VB.NET\)](#)  
[Change Dimension Tolerance in a Configuration \(VBA\)](#)

### Remarks

You cannot set the dimension tolerance values if the [tolerance type](#) is [swTolType\\_e.swTolNONE](#). Depending on the tolerance type, the dimension tolerance minimum and maximum values might not be visible.

| To get the dimension tolerance... | Use...                                           |
|-----------------------------------|--------------------------------------------------|
| Minimum value                     | <a href="#">IDimensionTolerance::GetMinValue</a> |
| Maximum value                     | <a href="#">IDimensionTolerance::GetMaxValue</a> |

To see the effects of changing the dimension tolerance values, call [IModelView::GraphicsRedraw](#).

### See Also

[IDimensionTolerance Interface](#)  
[IDimensionTolerance Members](#)

### Availability

SOLIDWORKS 2013 SP04, Revision Number 21.4

## ShowParenthesis Property (IDimensionTolerance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionTolerance Interface](#) : ShowParenthesis Property (IDimensionTolerance)

Indicates whether to show parentheses around linear tolerance dimensions.

### .NET Syntax

Visual Basic (Declaration)

Property ShowParenthesis As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDimensionTolerance  
Dim value As System.Boolean
```

```
instance.ShowParenthesis = value
```

```
value = instance.ShowParenthesis
```

C#

```
System.bool ShowParenthesis {get; set;}
```

C++/CLI

```
property System.bool ShowParenthesis {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True to show parentheses around linear tolerance dimensions, false to not

### Visual Basic for Applications (VBA) Syntax

See [DimensionTolerance::ShowParenthesis](#).

### Remarks

This property supports bilateral, symmetric, or fit-with-tolerance types only.

In SOLIDWORKS 2016 and later, use [ICalloutVariable::ShowParenthesis](#) to set whether to show parentheses in a hole's display dimension with multiple values in a callout. Calling IDimensionTolerance::ShowParenthesis to set whether to show parentheses in a hole's display dimension with multiple values in a callout does not override ICalloutVariable::ShowParenthesis' setting.

To see the effects of changing this property, use [IModelDoc2::GraphicsRedraw2](#).

### See Also

[IDimensionTolerance Interface](#)

[IDimensionTolerance Members](#)

[IDimensionTolerance::ShowParenthesis Property\(\)](#)

### Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Type Property (IDimensionTolerance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimensionTolerance Interface](#) : Type Property (IDimensionTolerance)

Gets or sets the type of tolerance.

## .NET Syntax

### Visual Basic (Declaration)

Property Type As System.Integer

### Visual Basic (Usage)



```
Dim instance As IDimensionTolerance  
Dim value As System.Integer  
  
instance.Type = value  
value = instance.Type
```

### C#

```
System.int Type {get; set;}
```

### C++/CLI

```
property System.int Type {  
    System.int get();  
    void set ( & System.int value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Type of tolerance as defined in [swTolType\\_e](#) (see **Remarks**)

## Visual Basic for Applications (VBA) Syntax

See [DimensionTolerance::Type](#).

## Example

See [IDimensionTolerance](#) examples.

## Remarks

In SOLIDWORKS 2016 and later, use [ICalloutVariable::ToleranceType](#) to set the type of tolerance for a hole's display dimension with multiple values in a callout. Calling IDimensionTolerance::Type to set the type of tolerance for a hole's display dimension with multiple values in a callout does not override ICalloutVariable::ToleranceType's setting.

To see the effects of changing the tolerance type, use [IModelDoc2::GraphicsRedraw2](#).

## See Also

[IDimensionTolerance Interface](#)  
[IDimensionTolerance Members](#)

## Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0