

SOLIDWORKS API (.NET VBA C#) — Reference

(74/337) IDimPatternFeatureData- IDimXpertManager

SOLIDWORKS API Documentation (converted from CHM)

IDimPatternFeatureData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IDimPatternFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDimPatternFeatureData Interface

Allows access to a variable pattern feature, which uses a table to store the dimensions and values of the pattern instances.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IDimPatternFeatureData
```

Visual Basic (Usage)



```
Dim instance As IDimPatternFeatureData
```

C#

```
public interface IDimPatternFeatureData
```

C++/CLI

```
public interface class IDimPatternFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [DimPatternFeatureData](#).

Example

[Insert Variable Pattern Feature \(C#\)](#)
[Insert Variable Pattern Feature \(VB.NET\)](#)
[Insert Variable Pattern Feature \(VBA\)](#)
[Delete Instances and Dimensions in Variable Pattern Feature \(C#\)](#)
[Delete Instances and Dimensions in Variable Pattern Feature \(VB.NET\)](#)
[Delete Instances and Dimensions in Variable Pattern Feature \(VBA\)](#)
[Delete and Insert Instances in Variable Pattern Feature \(C#\)](#)
[Delete and Insert Instances in Variable Pattern Feature \(VB.NET\)](#)
[Delete and Insert Instances in Variable Pattern Feature \(VBA\)](#)

Remarks

Read [Pattern Features and their Feature Data Objects](#).

The variable pattern feature uses a table to store the dimensions and values of pattern instances.

You can [import tables](#) and [export tables](#) using this interface.

Before calling `IFeatureManager::CreateDefinition`, you must pre-select the entities needed to create the derived pattern feature. Use [IModelDocExtension::SelectByID2](#) to select the reference geometry to drive the seed feature and the feature to pattern in any order using Marks:

- reference geometry to drive seed feature = 1048576
- feature to pattern = 4

You must call [IFeatureManager::CreateFeature](#) after initializing this feature data object in order to successfully create the derived pattern feature

Accessors

[IFeature::GetDefinition](#)

[IFeatureManager::CreateDefinition](#)

Access Diagram

[DimPatternFeatureData](#)

See Also

[IDimPatternFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::FeatureAdvancedTableDrivenPattern Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDimPatternFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : IDimPatternFeatureData Interface

The following tables list the members exposed by [IDimPatternFeatureData](#).

Public Properties

Name	Description
 PropagateVisualProperties	Gets or sets whether to propagate visual properties (e.g., colors, textures, etc.) to all variable pattern instances.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Allows access to the selections that describe this variable pattern feature.
 AddDimension	Adds the selected dimension as a column to the pattern table for this variable pattern feature.
 AddInstanceAt	Adds a pattern instance to this variable pattern feature.
 DeleteDimension	Deletes the specified column of dimensions in the pattern table in this variable pattern feature.
 DeleteInstanceAt	Deletes the specified pattern instance in this variable pattern feature.
 ExportToExcel	Exports the pattern table to the specified Microsoft Excel file for this variable pattern feature.
 GetControllingDimensionCount	Gets the number of controlling dimensions in this variable pattern feature.
 GetControllingDimensionName	Gets the name of the controlling dimension for the pattern instance at the specified index in this variable pattern feature.
 GetInstanceCount	Gets the number of pattern instances in this variable pattern feature.
 GetInstanceDimensionName	Gets the name of the pattern dimension for the pattern instance in this variable pattern feature.
 GetInstanceIndex	Gets the index of the pattern instance in the FeatureManager design tree in the variable pattern feature.
 GetInstanceNameByIndex	Gets the name of the pattern instance at the specified index in the pattern table in this variable pattern feature.
 GetInstanceSuppressStateByIndex	Gets whether the pattern instance at the specified index in the pattern table is suppressed in this variable pattern feature.
 GetInstanceSuppressStateByName	Gets whether the pattern instance with the specified name is suppressed in this variable pattern feature.
 GetTableRowIndex	Gets the index of the specified pattern instance in the pattern table in this variable pattern feature.
 ImportFromExcel	Imports a table from the specified Microsoft Excel file for this variable pattern feature.
 ReleaseSelectionAccess	Releases access to the selections used to define this variable pattern feature.
 SetInstanceDimensionValue	Sets a new value for the pattern dimension of the specified pattern instance in this variable pattern feature.
 SetInstanceSuppressStateByIndex	Sets whether the pattern instance with the specified index in the pattern table is suppressed in this variable pattern feature.
 SetInstanceSuppressStateByName	Sets whether a pattern instance with the specified name is suppressed in this variable pattern feature.

[Top](#)

See Also

[IDimPatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::FeatureAdvancedTableDrivenPattern Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDimPatternFeatureData Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IDimPatternFeatureData Interface

For a list of all members of this type, see [IDimPatternFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Allows access to the selections that describe this variable pattern feature.
 AddDimension	Adds the selected dimension as a column to the pattern table for this variable pattern feature.
 AddInstanceAt	Adds a pattern instance to this variable pattern feature.
 DeleteDimension	Deletes the specified column of dimensions in the pattern table in this variable pattern feature.
 DeleteInstanceAt	Deletes the specified pattern instance in this variable pattern feature.
 ExportToExcel	Exports the pattern table to the specified Microsoft Excel file for this variable pattern feature.
 GetControllingDimensionCount	Gets the number of controlling dimensions in this variable pattern feature.
 GetControllingDimensionName	Gets the name of the controlling dimension for the pattern instance at the specified index in this variable pattern feature.
 GetInstanceCount	Gets the number of pattern instances in this variable pattern feature.
 GetInstanceDimensionName	Gets the name of the pattern dimension for the pattern instance in this variable pattern feature.
 GetInstanceIndex	Gets the index of the pattern instance in the FeatureManager design tree in the variable pattern feature.
 GetInstanceNameByIndex	Gets the name of the pattern instance at the specified index in the pattern table in this variable pattern feature.
 GetInstanceSuppressStateByIndex	Gets whether the pattern instance at the specified index in the pattern table is suppressed in this variable pattern feature.
 GetInstanceSuppressStateByName	Gets whether the pattern instance with the specified name is suppressed in this variable pattern feature.
 GetTableRowIndex	Gets the index of the specified pattern instance in the pattern table in this variable pattern feature.
 ImportFromExcel	Imports a table from the specified Microsoft Excel file for this variable pattern feature.
 ReleaseSelectionAccess	Releases access to the selections used to define this variable pattern feature.
 SetInstanceDimensionValue	Sets a new value for the pattern dimension of the specified pattern instance in this variable pattern feature.
 SetInstanceSuppressStateByIndex	Sets whether the pattern instance with the specified index in the pattern table is suppressed in this variable pattern feature.
 SetInstanceSuppressStateByName	Sets whether a pattern instance with the specified name is suppressed in this variable pattern feature.

[Top](#)

See Also

[IDimPatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::FeatureAdvancedTableDrivenPattern Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDimPatternFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDimPatternFeatureData Interface

For a list of all members of this type, see [IDimPatternFeatureData members](#).

Public Properties

Name	Description
 PropagateVisualProperties	Gets or sets whether to propagate visual properties (e.g., colors, textures, etc.) to all variable pattern instances.

[Top](#)

See Also

[IDimPatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::FeatureAdvancedTableDrivenPattern Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IDimPatternFeatureData)

[See Also](#) [Example](#)



Allows access to the selections that describe this variable pattern feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function AccessSelections(  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimPatternFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component in which to modify the feature

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [DimPatternFeatureData::AccessSelections](#).

Example

[Insert Variable Pattern Feature \(C#\)](#)
[Insert Variable Pattern Feature \(VB.NET\)](#)
[Insert Variable Pattern Feature \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is Nothing or null
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which to modify the feature

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IDimPatternFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IDimPatternFeatureData Interface](#)
[IDimPatternFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddDimension Method (IDimPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimPatternFeatureData Interface](#) : AddDimension Method (IDimPatternFeatureData)

Adds the selected dimension as a column to the pattern table for this variable pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AddDimension() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimPatternFeatureData  
Dim value As System.Boolean
```

```
value = instance.AddDimension()
```

C#

```
System.bool AddDimension()
```

C++/CLI

```
System.bool AddDimension();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True adds the selected dimension as a column to the pattern table, false does not

Visual Basic for Applications (VBA) Syntax

See [DimPatternFeatureData::AddDimension](#).

Example

[Delete Instances and Dimensions in Variable Pattern Feature \(C#\)](#)
[Delete Instances and Dimensions in Variable Pattern Feature \(VB.NET\)](#)
[Delete Instances and Dimensions in Variable Pattern Feature \(VBA\)](#)

See Also

[IDimPatternFeatureData Interface](#)
[IDimPatternFeatureData Members](#)
[IDimPatternFeatureData.DeleteDimension Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddInstanceAt Method (IDimPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimPatternFeatureData Interface](#) : AddInstanceAt Method (IDimPatternFeatureData)

Adds a pattern instance to this variable pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AddInstanceAt( _  
    ByVal IsSuppressed As System.Boolean, _  
    ByVal Index As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimPatternFeatureData  
Dim IsSuppressed As System.Boolean  
Dim Index As System.Integer  
Dim value As System.Boolean  
  
value = instance.AddInstanceAt(IsSuppressed, Index)
```

C#

```
System.bool AddInstanceAt(  
    System.bool IsSuppressed,  
    System.int Index  
)
```

C++/CLI

```
System.bool AddInstanceAt(  
& System.bool IsSuppressed,  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

IsSuppressed

True to suppress this pattern instance, false to not

Index

0-based index indicating where to add this pattern instance in the pattern table and pattern; -1 indicates to add this pattern instance to the end of the pattern table and pattern (see **Remarks**)

Return Value

True if the pattern instance is added, false if not

Visual Basic for Applications (VBA) Syntax

See [DimPatternFeatureData::AddInstanceAt](#).

Example

[Delete and Insert Instances in Variable Pattern Feature \(C#\)](#)

[Delete and Insert Instances in Variable Pattern Feature \(VB.NET\)](#)

[Delete and Insert Instances in Variable Pattern Feature \(VBA\)](#)

Remarks

Use [IDimPatternFeatureData::GetInstanceCount](#) to get the number of pattern instances.

By default, this pattern instance inherits the default values of the parent sketch or feature of the variable pattern feature.

Use [IDimPatternFeatureData::SetInstanceDimensionValue](#) to modify this pattern instance's values.

See Also

[IDimPatternFeatureData Interface](#)

[IDimPatternFeatureData Members](#)

[IDimPatternFeatureData::DeleteInstanceAt Method\(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeleteDimension Method (IDimPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimPatternFeatureData Interface](#) : DeleteDimension Method (IDimPatternFeatureData)

Deletes the specified column of dimensions in the pattern table in this variable pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteDimension( _  
    ByVal DimensionColumnName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimPatternFeatureData  
Dim DimensionColumnName As System.String  
Dim value As System.Boolean  
  
value = instance.DeleteDimension(DimensionColumnName)
```

C#

```
System.bool DeleteDimension(  
    System.string DimensionColumnName  
)
```

C++/CLI

```
System.bool DeleteDimension(  
& System.String^ DimensionColumnName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DimensionColumnName

Name of the column of dimensions to delete (see **Remarks**)

Return Value

True if the column of dimensions is deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [DimPatternFeatureData::DeleteDimension](#).

Example

[Delete Instances and Dimensions in Variable Pattern Feature \(C#\)](#)
[Delete Instances and Dimensions in Variable Pattern Feature \(VB.NET\)](#)
[Delete Instances and Dimensions in Variable Pattern Feature \(VBA\)](#)

Remarks

The name of a column corresponds to the dimension name and feature name, separated by an @ symbol; e.g., **D3@Fillet1**.

There are various ways of getting the name of the column of dimensions to delete from a pattern table. For example, you can traverse the features, get the dimensions, and get the names of the dimensions. You can also select a dimension and get its name. See the examples for details.

NOTE: You cannot delete a column containing the dimensions of a parent sketch or feature.

See Also

[IDimPatternFeatureData Interface](#)
[IDimPatternFeatureData Members](#)
[IDimPatternFeatureData::AddDimension Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DeleteInstanceAt Method (IDimPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimPatternFeatureData Interface](#) : DeleteInstanceAt Method (IDimPatternFeatureData)

Deletes the specified pattern instance in this variable pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteInstanceAt( _  
    ByVal Index As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimPatternFeatureData  
Dim Index As System.Integer  
Dim value As System.Boolean  
  
value = instance.DeleteInstanceAt(Index)
```

C#

```
System.bool DeleteInstanceAt(  
    System.int Index  
)
```

C++/CLI

```
System.bool DeleteInstanceAt(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

0-based index indicating where to delete this pattern instance in the pattern table and pattern; -1 indicates to delete this pattern instance at the end of the pattern table and pattern (see **Remark**

Return Value

True if the pattern instance is deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [DimPatternFeatureData.DeleteInstanceAt](#).

Example

[Delete Instances and Dimensions in Variable Pattern Feature \(C#\)](#)
[Delete Instances and Dimensions in Variable Pattern Feature \(VB.NET\)](#)
[Delete Instances and Dimensions in Variable Pattern Feature \(VBA\)](#)

Remarks

Use [IDimPatternFeatureData::GetInstanceCount](#) to get the number of pattern instances.

See Also

[IDimPatternFeatureData Interface](#)
[IDimPatternFeatureData Members](#)
[IDimPatternFeatureData::AddInstanceAt Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ExportToExcel Method (IDimPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimPatternFeatureData Interface](#) : ExportToExcel Method (IDimPatternFeatureData)

Exports the pattern table to the specified Microsoft Excel file for this variable pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function ExportToExcel( _  
    ByVal ExcelFile As System.String, _  
    ByVal Overwrite As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDimPatternFeatureData  
Dim ExcelFile As System.String  
Dim Overwrite As System.Boolean  
Dim value As System.Integer
```

```
value = instance.ExportToExcel(ExcelFile, Overwrite)
```

C#

```
System.int ExportToExcel(  
    System.string ExcelFile,  
    System.bool Overwrite  
)
```

C++/CLI

```
System.int ExportToExcel(  
& System.String^ ExcelFile,  
& System.bool Overwrite  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ExcelFile

Path and Microsoft Excel file name to which to export the pattern table; valid filename extensions are .xls, .xlsx, and .xlsm

Overwrite

True to overwrite a file in the specified path with the same file name, false to not

Return Value

Status of exporting the pattern table to a Microsoft Excel file as defined in [swPatternFeatureImportExportError_e](#)

Visual Basic for Applications (VBA) Syntax

See [DimPatternFeatureData::ExportToExcel](#).

Example

[Insert Variable Pattern Feature \(C#\)](#)
[Insert Variable Pattern Feature \(VB.NET\)](#)
[Insert Variable Pattern Feature \(VBA\)](#)

See Also

[IDimPatternFeatureData Interface](#)
[IDimPatternFeatureData Members](#)
[IDimPatternFeatureData::ImportFromExcel Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetControllingDimensionCount Method (IDimPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimPatternFeatureData Interface](#) : GetControllingDimensionCount Method (IDimPatternFeatureData)

Gets the number of controlling dimensions in this variable pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetControllingDimensionCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDimPatternFeatureData  
Dim value As System.Integer
```

```
value = instance.GetControllingDimensionCount()
```

C#

```
System.int GetControllingDimensionCount()
```

C++/CLI

```
System.int GetControllingDimensionCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of controlling dimensions

Visual Basic for Applications (VBA) Syntax

See [DimPatternFeatureData::GetControllingDimensionCount](#).

Example

[Insert Variable Pattern Feature \(C#\)](#)
[Insert Variable Pattern Feature \(VB.NET\)](#)
[Insert Variable Pattern Feature \(VBA\)](#)

See Also

[IDimPatternFeatureData Interface](#)
[IDimPatternFeatureData Members](#)
[IDimPatternFeatureData::GetControllingDimensionName Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetControllingDimensionName Method (IDimPatternFeatureData)

[See Also](#) [Example](#)



Gets the name of the controlling dimension for the pattern instance at the specified index in this variable pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetControllingDimensionName( _  
    ByVal Index As System.Integer _  
) As System.String
```

Visual Basic (Usage)

```
Dim instance As IDimPatternFeatureData  
Dim Index As System.Integer  
Dim value As System.String  
  
value = instance.GetControllingDimensionName(Index)
```

C#

```
System.string GetControllingDimensionName(  
    System.int Index  
)
```

C++/CLI

```
System.String^ GetControllingDimensionName(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the controlling dimension pattern (see **Remarks**)

Return Value

Name of the controlling dimension of the pattern instance

Visual Basic for Applications (VBA) Syntax

See [DimPatternFeatureData::GetControllingDimensionName](#).

Example

[Insert Variable Pattern Feature \(C#\)](#)
[Insert Variable Pattern Feature \(VB.NET\)](#)
[Insert Variable Pattern Feature \(VBA\)](#)

Remarks

Use [IDimPatternFeatureData::GetControllingDimensionCount](#) to get the number of controlling dimensions.

See Also

[IDimPatternFeatureData Interface](#)
[IDimPatternFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

Gets the number of pattern instances in this variable pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetInstanceCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDimPatternFeatureData  
Dim value As System.Integer  
  
value = instance.GetInstanceCount()
```

C#

```
System.int GetInstanceCount()
```

C++/CLI

```
System.int GetInstanceCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of pattern instances

Visual Basic for Applications (VBA) Syntax

See [DimPatternFeatureData.GetInstanceCount](#).

Example

[Insert Variable Pattern Feature \(C#\)](#)
[Insert Variable Pattern Feature \(VB.NET\)](#)
[Insert Variable Pattern Feature \(VBA\)](#)

See Also

[IDimPatternFeatureData Interface](#)
[IDimPatternFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetInstanceDimensionName Method (IDimPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimPatternFeatureData Interface](#) : GetInstanceDimensionName Method (IDimPatternFeatureData)

Gets the name of the pattern dimension for the pattern instance in this variable pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetInstanceDimensionName( _  
    ByVal InstanceName As System.String, _  
    ByVal ControllingDimName As System.String _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IDimPatternFeatureData
Dim InstanceName As System.String
Dim ControllingDimName As System.String
Dim value As System.String

value = instance.GetInstanceDimensionName(InstanceName, ControllingDimName)
```

C#

```
System.string GetInstanceDimensionName(
    System.string InstanceName,
    System.string ControllingDimName
)
```

C++/CLI

```
System.String^ GetInstanceDimensionName(
    & System.String^ InstanceName,
    & System.String^ ControllingDimName
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

InstanceName
Name of the pattern instance (see **Remarks**)

ControllingDimName
Controlling dimension of the pattern instance (see **Remarks**)

Return Value

Name of the pattern dimension

Visual Basic for Applications (VBA) Syntax

See [DimPatternFeatureData.GetInstanceDimensionName](#).

Example

[Insert Variable Pattern Feature \(C#\)](#)
[Insert Variable Pattern Feature \(VB.NET\)](#)
[Insert Variable Pattern Feature \(VBA\)](#)

Remarks

Use..	To get...
IDimPatternFeatureData.GetInstanceNameByIndex	InstanceName
IDimPatternFeatureData.GetControllingDimensionName	ControllingDimName

See Also

[IDimPatternFeatureData Interface](#)
[IDimPatternFeatureData Members](#)
[IDimPatternFeatureData.SetInstanceDimensionValue Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetInstanceIndex Method (IDimPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimPatternFeatureData Interface](#) : GetInstanceIndex Method (IDimPatternFeatureData)

Gets the index of the pattern instance in the FeatureManager design tree in the variable pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetInstanceIndex( _  
    ByVal InstanceName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDimPatternFeatureData  
Dim InstanceName As System.String  
Dim value As System.Integer  
  
value = instance.GetInstanceIndex(InstanceName)
```

C#

```
System.int GetInstanceIndex(  
    System.string InstanceName  
)
```

C++/CLI

```
System.int GetInstanceIndex(  
& System.String^ InstanceName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

InstanceName

Name of the pattern instance (see **Remarks**)

Return Value

Index of InstanceName in the FeatureManager design tree

Visual Basic for Applications (VBA) Syntax

See [DimPatternFeatureData::GetInstanceIndex](#).

Remarks

Use [IDimPatternFeatureData::GetInstanceNameByIndex](#) to get InstanceName.

See Also

[IDimPatternFeatureData Interface](#)

[IDimPatternFeatureData Members](#)

[IDimPatternFeatureData::GetInstanceCount Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetInstanceNameByIndex Method (IDimPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimPatternFeatureData Interface](#) : GetInstanceNameByIndex Method (IDimPatternFeatureData)

Gets the name of the pattern instance at the specified index in the pattern table in this variable pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetInstanceNameByIndex(  
    ByVal TableRowIndex As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IDimPatternFeatureData  
Dim TableRowIndex As System.Integer  
Dim value As System.String  
  
value = instance.GetInstanceNameByIndex(TableRowIndex)
```

C#

```
System.string GetInstanceNameByIndex(  
    System.int TableRowIndex  
)
```

C++/CLI

```
System.String^ GetInstanceNameByIndex(  
& System.int TableRowIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TableRowIndex
1-based index of the pattern instance in the pattern table (see **Remarks**)

Return Value

Name of the pattern instance

Visual Basic for Applications (VBA) Syntax

See [DimPatternFeatureData::GetInstanceNameByIndex](#).

Example

[Insert Variable Pattern Feature \(C#\)](#)
[Insert Variable Pattern Feature \(VB.NET\)](#)
[Insert Variable Pattern Feature \(VBA\)](#)

Remarks

Use [IDimPatternFeatureData::GetInstanceCount](#) to get TableRowIndex.

See Also

[IDimPatternFeatureData Interface](#)
[IDimPatternFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetInstanceSuppressStateByIndex Method (IDimPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimPatternFeatureData Interface](#) : GetInstanceSuppressStateByIndex Method (IDimPatternFeatureData)

Gets whether the pattern instance at the specified index in the pattern table is suppressed in this variable pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetInstanceSuppressStateByIndex( _  
    ByVal TableRowIndex As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimPatternFeatureData  
Dim TableRowIndex As System.Integer  
Dim value As System.Boolean  
  
value = instance.GetInstanceSuppressStateByIndex(TableRowIndex)
```

C#

```
System.bool GetInstanceSuppressStateByIndex(  
    System.int TableRowIndex  
)
```

C++/CLI

```
System.bool GetInstanceSuppressStateByIndex(  
&    System.int TableRowIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TableRowIndex
Index of the pattern instance in the pattern table (see **Remarks**)

Return Value

True if the pattern instance is suppressed, false if not

Visual Basic for Applications (VBA) Syntax

See [DimPatternFeatureData::GetInstanceSuppressStateByIndex](#).

Example

[Insert Variable Pattern Feature \(C#\)](#)
[Insert Variable Pattern Feature \(VB.NET\)](#)
[Insert Variable Pattern Feature \(VBA\)](#)

Remarks

Use [IDimPatternFeatureData::GetTableRowIndex](#) to get TableRowIndex.

See Also

[IDimPatternFeatureData Interface](#)
[IDimPatternFeatureData Members](#)
[IDimPatternFeatureData::SetInstanceSuppressStateByIndex Method \(\)](#)
[IDimPatternFeatureData::GetInstanceSuppressStateByName Method \(\)](#)
[IDimPatternFeatureData::SetInstanceSuppressStateByName Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetInstanceSuppressStateByName Method (IDimPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimPatternFeatureData Interface](#) : GetInstanceSuppressStateByName Method (IDimPatternFeatureData)

Gets whether the pattern instance with the specified name is suppressed in this variable pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetInstanceSuppressStateByName( _  
    ByVal InstanceName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimPatternFeatureData  
Dim InstanceName As System.String  
Dim value As System.Boolean  
  
value = instance.GetInstanceSuppressStateByName(InstanceName)
```

C#

```
System.bool GetInstanceSuppressStateByName(  
    System.string InstanceName  
)
```

C++/CLI

```
System.bool GetInstanceSuppressStateByName(  
    & System.String^ InstanceName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

InstanceName

Name of the pattern instance (see **Remarks**)

Return Value

True if the pattern instance is suppressed, false if not

Visual Basic for Applications (VBA) Syntax

See [DimPatternFeatureData::GetInstanceSuppressStateByName](#).

Remarks

Use [IDimPatternFeatureData::GetInstanceNameByIndex](#) to get InstanceName.

See Also

[IDimPatternFeatureData Interface](#)
[IDimPatternFeatureData Members](#)
[IDimPatternFeatureData::SetInstanceSuppressStateByName Method \(\)](#)
[IDimPatternFeatureData::GetInstanceSuppressStateByIndex Method \(\)](#)
[IDimPatternFeatureData::SetInstanceSuppressStateByIndex Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTableRowIndex Method (IDimPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimPatternFeatureData Interface](#) : GetTableRowIndex Method (IDimPatternFeatureData)

Gets the index of the specified pattern instance in the pattern table in this variable pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTableRowIndex( _  
    ByVal InstanceName As System.String _
```

) As System.Integer

Visual Basic (Usage)



```
Dim instance As IDimPatternFeatureData  
Dim InstanceName As System.String  
Dim value As System.Integer  
  
value = instance.GetTableRowIndex(InstanceName)
```

C#

```
System.int GetTableRowIndex(  
    System.string InstanceName  
)
```

C++/CLI

```
System.int GetTableRowIndex(  
& System.String^ InstanceName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

InstanceName

Name of the pattern instance (see **Remarks**)

Return Value

Index in the pattern table for InstanceName (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DimPatternFeatureData::GetTableRowIndex](#).

Example

[Insert Variable Pattern Feature \(C#\)](#)

[Insert Variable Pattern Feature \(VB.NET\)](#)

[Insert Variable Pattern Feature \(VBA\)](#)

Remarks

Use [IDimPatternFeatureData::GetInstanceNameByIndex](#) to get InstanceName.

NOTE: The index returned by this method is a value in a row in the **Instance** column in the pattern table.

See Also

[IDimPatternFeatureData Interface](#)

[IDimPatternFeatureData Members](#)

[IDimPatternFeatureData::GetInstanceIndex Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ImportFromExcel Method (IDimPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimPatternFeatureData Interface](#) : ImportFromExcel Method (IDimPatternFeatureData)

Imports a table from the specified Microsoft Excel file for this variable pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function ImportFromExcel( _  
    ByVal ExcelFile As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDimPatternFeatureData  
Dim ExcelFile As System.String  
Dim value As System.Integer  
  
value = instance.ImportFromExcel(ExcelFile)
```

C#

```
System.int ImportFromExcel(  
    System.string ExcelFile  
)
```

C++/CLI

```
System.int ImportFromExcel(  
& System.String^ ExcelFile  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ExcelFile

Path and Microsoft Excel file name from which to import a table; valid filename extensions are .xls, .xlsx, and .xlsm

Return Value

Status of importing a table from a Microsoft Excel file as defined in [swPatternFeatureImportExportError_e](#)

Visual Basic for Applications (VBA) Syntax

See [DimPatternFeatureData::ImportFromExcel](#).

See Also

[IDimPatternFeatureData Interface](#)
[IDimPatternFeatureData Members](#)
[IDimPatternFeatureData::ExportToExcel Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PropagateVisualProperties Property (IDimPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimPatternFeatureData Interface](#) : PropagateVisualProperties Property (IDimPatternFeatureData)

Gets or sets whether to propagate visual properties (e.g., colors, textures, etc.) to all variable pattern instances.

.NET Syntax

Visual Basic (Declaration)

```
Property PropagateVisualProperties As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDimPatternFeatureData  
Dim value As System.Boolean  
  
instance.PropagateVisualProperties = value
```

```
value = instance.PropagateVisualProperties
```

C#

```
System.bool PropagateVisualProperties {get; set;}
```

C++/CLI

```
property System.bool PropagateVisualProperties {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to propagate visual properties, false to not

Visual Basic for Applications (VBA) Syntax

See [DimPatternFeatureData::PropagateVisualProperties](#).

Example

[Delete Instances and Dimensions in Variable Pattern Feature \(C#\)](#)
[Delete Instances and Dimensions in Variable Pattern Feature \(VB.NET\)](#)
[Delete Instances and Dimensions in Variable Pattern Feature \(VBA\)](#)

See Also

[IDimPatternFeatureData Interface](#)
[IDimPatternFeatureData Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IDimPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimPatternFeatureData Interface](#) : ReleaseSelectionAccess Method (IDimPatternFeatureData)

Releases access to the selections used to define this variable pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IDimPatternFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [IDimPatternFeatureData::ReleaseSelectionAccess](#).

Example

[Insert Variable Pattern Feature \(C#\)](#)
[Insert Variable Pattern Feature \(VB.NET\)](#)
[Insert Variable Pattern Feature \(VBA\)](#)

Remarks

[IDimPatternFeatureData::AccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature. Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) if you did.

See Also

[IDimPatternFeatureData Interface](#)
[IDimPatternFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetInstanceDimensionValue Method (IDimPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimPatternFeatureData Interface](#) : SetInstanceDimensionValue Method (IDimPatternFeatureData)

Sets a new value for the pattern dimension of the specified pattern instance in this variable pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetInstanceDimensionValue( _  
    ByVal TableRowIndex As System.Integer, _  
    ByVal ControlDimName As System.String, _  
    ByVal NewValue As System.Double _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IDimPatternFeatureData  
Dim TableRowIndex As System.Integer  
Dim ControlDimName As System.String  
Dim NewValue As System.Double  
Dim value As System.String  
  
value = instance.SetInstanceDimensionValue(TableRowIndex, ControlDimName, NewValue)
```

C#

```
System.string SetInstanceDimensionValue(  
    System.int TableRowIndex,  
    System.string ControlDimName,  
    System.double NewValue  
)
```

C++/CLI

```
System.String^ SetInstanceDimensionValue(  
& System.int TableRowIndex,  
& System.String^ ControlDimName,  
& System.double NewValue  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TableRowIndex
Index of the pattern instance in the pattern table (see **Remarks**)
ControlDimName
Name of the controlling dimension of the pattern instance (see **Remarks**)
NewValue
New value for the pattern dimension

Return Value

If a new value for the pattern dimension is...	Then Return Value is an...
Set	Empty string indicating success
Not set	Error string

 Visual Basic for Applications (VBA) Syntax

See [DimPatternFeatureData::SetInstanceDimensionValue](#).

 Example

[Delete and Insert Instances in Variable Pattern Feature \(C#\)](#)
[Delete and Insert Instances in Variable Pattern Feature \(VB.NET\)](#)
[Delete and Insert Instances in Variable Pattern Feature \(VBA\)](#)

 Remarks

Use:

- [IDimPatternFeatureData::GetTableRowIndex](#) to get TableRowIndex.
- [IDimPatternFeatureData::GetControllingDimensionName](#) to get ControlDimName.

 See Also

[IDimPatternFeatureData Interface](#)
[IDimPatternFeatureData Members](#)
[IDimPatternFeatureData::GetInstanceDimensionName Method \(\)](#)

 Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SetInstanceSuppressStateByIndex Method (IDimPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimPatternFeatureData Interface](#) : SetInstanceSuppressStateByIndex Method (IDimPatternFeatureData)

Sets whether the pattern instance with the specified index in the pattern table is suppressed in this variable pattern feature.

 .NET Syntax

Visual Basic (Declaration)

```
Function SetInstanceSuppressStateByIndex( _  
    ByVal TableRowIndex As System.Integer, _  
    ByVal SuppressState As System.Boolean _  
) As System.String
```

Visual Basic (Usage)

```
Dim instance As IDimPatternFeatureData  
Dim TableRowIndex As System.Integer  
Dim SuppressState As System.Boolean  
Dim value As System.String  
  
value = instance.SetInstanceSuppressStateByIndex(TableRowIndex, SuppressState)
```

C#

```
System.string SetInstanceSuppressStateByIndex(  
    System.int TableRowIndex,
```



```
        System.bool SuppressState  
    )
```

C++/CLI

```
System.String^ SetInstanceSuppressStateByIndex(  
& System.int TableRowIndex,  
& System.bool SuppressState  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TableRowIndex

Index of the pattern instance in the pattern table to suppress (see **Remarks**)

SuppressState

True to suppress the pattern instance, false to not

Return Value

If the pattern instance is...	Then Return Value is an...
Suppressed	Empty string indicating success
Not suppressed	Error string

Visual Basic for Applications (VBA) Syntax

See [DimPatternFeatureData::SetInstanceSuppressStateByIndex](#).

Remarks

Use [IDimPatternFeatureData::GetTableRowIndex](#) to get TableRowIndex.

See Also

[IDimPatternFeatureData Interface](#)

[IDimPatternFeatureData Members](#)

[IDimPatternFeatureData::GetInstanceSuppressStateByIndex Method \(\)](#)

[IDimPatternFeatureData::GetInstanceSuppressStateByName Method \(\)](#)

[IDimPatternFeatureData::SetInstanceSuppressStateByName Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetInstanceSuppressStateByName Method (IDimPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimPatternFeatureData Interface](#) : SetInstanceSuppressStateByName Method (IDimPatternFeatureData)

Sets whether a pattern instance with the specified name is suppressed in this variable pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetInstanceSuppressStateByName( _  
    ByVal InstanceName As System.String, _  
    ByVal SuppressState As System.Boolean _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IDimPatternFeatureData  
Dim InstanceName As System.String  
Dim SuppressState As System.Boolean  
Dim value As System.String
```

```
value = instance.SetInstanceSuppressStateByName(InstanceName, SuppressState)
```

C#

```
System.string SetInstanceSuppressStateByName(  
    System.string InstanceName,  
    System.bool SuppressState  
)
```

C++/CLI

```
System.String^ SetInstanceSuppressStateByName(  
& System.String^ InstanceName,  
& System.bool SuppressState  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

InstanceName
Name of pattern instance to suppress (see **Remarks**)
SuppressState
True if the pattern instance is suppressed, false if not

Return Value

If the pattern instance is...	Then Return Value is an...
Suppressed	Empty string indicating success
Not suppressed	Error string

 Visual Basic for Applications (VBA) Syntax

See [DimPatternFeatureData::SetInstanceSuppressStateByName](#).

 Remarks

Use [IDimPatternFeatureData::GetInstanceNameByIndex](#) to get InstanceName.

 See Also

[IDimPatternFeatureData Interface](#)
[IDimPatternFeatureData Members](#)
[IDimPatternFeatureData::GetInstanceSuppressStateByName Method \(\)](#)
[IDimPatternFeatureData::GetInstanceSuppressStateByIndex Method \(\)](#)
[IDimPatternFeatureData::SetInstanceSuppressStateByIndex Method \(\)](#)

 Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

IDimXpertManager (Type)

IDimXpertManager Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDimXpertManager Interface

Allows you to get the DimXpert schema for a configuration.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IDimXpertManager
```

Visual Basic (Usage)



```
Dim instance As IDimXpertManager
```

C#

```
public interface IDimXpertManager
```

C++/CLI

```
public interface class IDimXpertManager
```

Visual Basic for Applications (VBA) Syntax

See [DimXpertManager](#).

Example

[Get DimXpertManager Info \(VBA\)](#)
[Get DimXpertManager Info \(VB.NET\)](#)

Accessors

[IConfiguration::DimXpertManager](#)
[IModelDocExtension::DimXpertManager](#)
[ISelectionMgr::GetSelectedObject6](#)

Access Diagram

[DimXpertManager](#)

See Also

[IDimXpertManager Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IDimXpertManager Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDimXpertManager Interface

The following tables list the members exposed by [IDimXpertManager](#).

Public Properties

Name	Description
DimXpertPart	Provides access to the detailed geometric dimensioning and tolerancing information for a part.

 SchemaComment	Gets a comment for the DimXpert schema.
 SchemaDescription	Gets the description of the DimXpert schema.
 SchemaName	Gets the name of the DimXpertSchema.
 TreeDisplay	Gets the organization of the DimXpertManager tab information: by annotation, by features, or flat.

[Top](#)

 See Also

[IDimXpertManager Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IDimXpertManager Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDimXpertManager Interface

For a list of all members of this type, see [IDimXpertManager members](#).

 Public Properties

Name	Description
 DimXpertPart	Provides access to the detailed geometric dimensioning and tolerancing information for a part.
 SchemaComment	Gets a comment for the DimXpert schema.
 SchemaDescription	Gets the description of the DimXpert schema.
 SchemaName	Gets the name of the DimXpertSchema.
 TreeDisplay	Gets the organization of the DimXpertManager tab information: by annotation, by features, or flat.

[Top](#)

 See Also

[IDimXpertManager Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

DimXpertPart Property (IDimXpertManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimXpertManager Interface](#) : DimXpertPart Property (IDimXpertManager)

Provides access to the detailed geometric dimensioning and tolerancing information for a part.

 .NET Syntax

Visual Basic (Declaration)

ReadOnly Property DimXpertPart As System.Object

Visual Basic (Usage)



```
Dim instance As IDimXpertManager
Dim value As System.Object

value = instance.DimXpertPart
```

C#

```
System.object DimXpertPart {get;}
```

C++/CLI

```
property System.Object^ DimXpertPart {
    System.Object^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IDimXpertPart](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertManager::DimXpertPart](#).

See Also

[IDimXpertManager Interface](#)
[IDimXpertManager Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SchemaComment Property (IDimXpertManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimXpertManager Interface](#) : SchemaComment Property (IDimXpertManager)

Gets a comment for the DimXpert schema.

.NET Syntax

Visual Basic (Declaration)

```
Property SchemaComment As System.String
```

Visual Basic (Usage)



```
Dim instance As IDimXpertManager
Dim value As System.String

instance.SchemaComment = value
value = instance.SchemaComment
```

C#

```
System.string SchemaComment {get;set;}
```

C++/CLI

```
property System.String^ SchemaComment {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Comment for the DimXpert schema

Visual Basic for Applications (VBA) Syntax

See [DimXpertManager::SchemaComment](#).

Remarks

This property corresponds to a Properties menu item when the right-mouse-button is clicked on a schema in the DimXpertManager tab.

See Also

[IDimXpertManager Interface](#)
[IDimXpertManager Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SchemaDescription Property (IDimXpertManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimXpertManager Interface](#) : SchemaDescription Property (IDimXpertManager)

Gets the description of the DimXpert schema.

.NET Syntax

Visual Basic (Declaration)

Property SchemaDescription As System.String

Visual Basic (Usage)



```
Dim instance As IDimXpertManager  
Dim value As System.String
```

```
instance.SchemaDescription = value
```

```
value = instance.SchemaDescription
```

C#

```
System.string SchemaDescription {get; set;}
```

C++/CLI

```
property System.String^ SchemaDescription {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

The description of the DimXpert schema

Visual Basic for Applications (VBA) Syntax

See [DimXpertManager::SchemaDescription](#).

Remarks

This property corresponds to a Properties menu item when the right-mouse-button is clicked on a schema in the DimXpertManager tab.

See Also

[IDimXpertManager Interface](#)
[IDimXpertManager Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SchemaName Property (IDimXpertManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimXpertManager Interface](#) : SchemaName Property (IDimXpertManager)

Gets the name of the DimXpertSchema.

.NET Syntax

Visual Basic (Declaration)

```
Property SchemaName As System.String
```

Visual Basic (Usage)



```
Dim instance As IDimXpertManager  
Dim value As System.String
```

```
instance.SchemaName = value
```

```
value = instance.SchemaName
```

C#

```
System.string SchemaName {get; set;}
```

C++/CLI

```
property System.String^ SchemaName {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

The name of the DimXpert schema

Visual Basic for Applications (VBA) Syntax

See [DimXpertManager::SchemaName](#).

Remarks

This property corresponds to a Properties menu item when the right-mouse-button is clicked on a schema in the DimXpertManager tab.

See Also

[IDimXpertManager Interface](#)
[IDimXpertManager Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TreeDisplay Property (IDimXpertManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDimXpertManager Interface](#) : TreeDisplay Property (IDimXpertManager)

Gets the organization of the DimXpertManager tab information: by annotation, by features, or flat.

.NET Syntax

Visual Basic (Declaration)

```
Property TreeDisplay As System.Integer
```

```
Dim instance As IDimXpertManager
Dim value As System.Integer

instance.TreeDisplay = value

value = instance.TreeDisplay
```

C#

```
System.int TreeDisplay {get; set;}
```

C++/CLI

```
property System.int TreeDisplay {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of tree display as defined in [swDimXpertTreeDisplay_e](#)

Visual Basic for Applications (VBA) Syntax

See [DimXpertManager::TreeDisplay](#).

Example

[Get DimXpertManager Info \(VBA\)](#)
[Get DimXpertManager Info \(VB.NET\)](#)

Remarks

This property corresponds to a Tree Display menu item when the right-mouse-button is clicked on a schema in the DimXpertManager tab.

See Also

[IDimXpertManager Interface](#)
[IDimXpertManager Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0