

SOLIDWORKS API (.NET VBA C#) — Reference

(76/337): IDisplayDimension (part 1 of 3)

SOLIDWORKS API Documentation (converted from CHM)

IDisplayDimension (part 1 of 3) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IDisplayDimension Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDisplayDimension Interface

Represents instances of dimensions displayed in [parts](#), [assemblies](#), [drawings](#) and [sensors](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IDisplayDimension
```

Visual Basic (Usage)

```
Dim instance As IDisplayDimension
```

C#

```
public interface IDisplayDimension
```

C++/CLI

```
public interface class IDisplayDimension
```

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension](#).

Example

[Get Chamfer Display Dimension \(C#\)](#)
[Get Chamfer Display Dimension \(VB.NET\)](#)
[Get Chamfer Display Dimension \(VBA\)](#)
[Get and Set Sensor \(C#\)](#)
[Get and Set Sensor \(VB.NET\)](#)
[Get and Set Sensor \(VBA\)](#)
[Get DimXpert Display Dimensions and Feature \(C#\)](#)
[Get DimXpert Display Dimensions and Feature \(VB.NET\)](#)
[Get DimXpert Display Dimensions and Feature \(VBA\)](#)
[Set Properties of Angular Running Dimension \(VBA\)](#)
[Set Properties of Angular Running Dimension \(VB.NET\)](#)
[Set Properties of Angular Running Dimension \(C#\)](#)

Remarks

You can display a SOLIDWORKS dimension more than once. For example, you can bring the base-extrude dimension into three different views on a drawing. These three dimensions are referred to as display dimensions and are represented by the DisplayDimension object in the SOLIDWORKS API. The original base-extrude dimension is represented by the [Dimension](#) object in the SOLIDWORKS API.

SOLIDWORKS stores many of the properties associated with a dimension with the underlying Dimension object. For example, you must get the Dimension object using [IDisplayDimension::GetDimension](#) to access or modify the underlying dimension value.

Accessors

[IAnnotation::GetSpecificAnnotation](#) and [IAnnotation::IGetSpecificAnnotation](#)

[IDisplayDimension::GetNext5](#)

[IDrawingDoc::AddChamferDim](#) and [IDrawingDoc::IAddChamferDim](#)

[IDrawingDoc::AddHoleCallout2](#) and [IDrawingDoc::IAddHoleCallout2](#)

[IDrawingDoc::CreateAngDim4](#) and [IDrawingDoc::ICreateAngDim4](#)

[IDrawingDoc::CreateDiamDim4](#) and [IDrawingDoc::ICreateDiamDim4](#)

[IDrawingDoc::CreateLinearDim4](#)

[IDrawingDoc::CreateOrdinateDim4](#) and [IDrawingDoc::ICreateOrdinateDim4](#)

[IEnumDisplayDimensions::Next](#)
[IFeature::EnumDisplayDimensions](#)
[IFeature::GetDisplayDimension](#)
[IFeature::GetFirstDisplayDimension](#)
[IFeature::GetNextDisplayDimension](#)
[ILinearPatternFeatureData::D1Axis](#)
[ILinearPatternFeatureData::D2Axis](#)
[ILocalLinearPatternFeatureData::D1Axis](#)
[ILocalLinearPatternFeatureData::D2Axis](#)
[IMacroFeatureData::GetDisplayDimensions](#) and [IMacroFeatureData::IGetDisplayDimensions](#)
[IMate2::DisplayDimension2](#)
[IModelDoc2::AddDiameterDimension2](#) and [IModelDoc2::IAddDiameterDimension2](#)
[IModelDoc2::AddHorizontalDimension2](#) and [IModelDoc2::IAddHorizontalDimension2](#)
[IModelDoc2::AddRadialDimension2](#) and [IModelDoc2::IAddRadialDimension2](#)
[IModelDoc2::AddVerticalDimension2](#) and [IModelDoc2::IAddVerticalDimension2](#)
[IModelDocExtension::AddDimension](#)
[IModelDocExtension::AddPathLengthDim](#)
[IModelDocExtension::AddSpecificDimension](#)
[IModelDocExtension::AddSymmetricDimension](#)
[IModelDocExtension::InsertChainDimensions](#)
[ISketchBlockDefinition::GetDisplayDimensions](#) and [ISketchBlockDefinition::IGetDisplayDimensions](#)
[ISketchManager::AddAlongXDimension](#), [ISketchManager::AddAlongYDimension](#), and [ISketchManager::AddAlongZDimension](#)
[ISketchRelation::GetDisplayDimension](#)
[IView::GetFirstDisplayDimension5](#)
[IView::GetDisplayDimensions](#) and [IView::IGetDisplayDimensions](#)

 Access Diagram

[DisplayDimension](#)

 See Also

[IDisplayDimension Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICalloutVariable Interface](#)
[IDimensionTolerance Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDisplayDimension Interface Members

[See Also](#) [Properties](#) [Methods](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IDisplayDimension Interface

The following tables list the members exposed by [IDisplayDimension](#).

 Public Properties

Name	Description
 ArcExtensionLineOrOppositeSide	Gets or sets whether to attach or extend the radial dimension leader on this radial display dimension.
 ArrowSide	Gets or sets the position of the dimension arrows.
 CenterText	Gets or sets whether the text of this display dimension should be automatically centered.
 ChamferPrecision	Gets or sets the precision of the length and angle values in a chamfer display dimension.
 ChamferTextStyle	Gets or sets the text style for chamfer dimensions.
 Diametric	Gets or sets whether this display dimension is radial/single distance or diameter/doubled distance.
 DimensionToInside	Gets or sets whether dimensions to arcs are always to the inside of the arc.

 DisplayAsChain	Gets or sets whether the extension lines of every dimension in this set of angular running or ordinate dimensions are chained together.
 DisplayAsLinear	Gets or sets whether this diameter dimension is displayed as a linear dimension.
 Elevation	Gets or sets whether to display an elevation symbol, which is controlled by IDisplayDimension::EndSymbol , at the end of ordinate dimension extension lines.
 EndSymbol	Gets or sets the ordinate dimension end symbol.
 ExtensionLineExtendsFromCenterOfSet	Gets or sets whether extension lines extend from the center of this set of angular running dimensions.
 ExtensionLineSameAsLeaderStyle	Gets or sets whether to use leader line styles for extension line styles.
 ExtensionLineUseDocumentDisplay	Gets or sets whether to use the document settings for extension lines.
 Foreshortened	Gets or sets whether a linear dimension is foreshortened in a drawing.
 GridBubble	Gets or sets whether to display a grid bubble at the end of ordinate dimension extension lines.
 HorizontalJustification	Gets or sets the dimension text's horizontal justification.
 Inspection	Gets or sets whether a display dimension above the dimension line is displayed as an inspection dimension.
 IsLinked	Gets whether the dimension has text linked to it.
 Jogged	Gets or sets whether this ordinate or angular running dimension is jogged.
 LeaderVisibility	Gets or sets which leader lines (dimension lines) are visible on a display dimension.
 LowerInspection	Gets or sets whether a display dimension below the dimension line is displayed as an inspection dimension.
 MarkedForDrawing	Gets or sets whether this display dimension is marked to include in a drawing document.
 MaxWitnessLineLength	Gets or sets the maximum length of dimension extension lines.
 OffsetText	Gets or sets whether or not to offset the text of a dimension.
 RunBidirectionally	Gets or sets whether each dimension runs in a direction closest to the baseline in this angular running dimension.
 Scale2	Gets or sets the scale value that is applied to the dimension value of this non-associative distance dimension.
 ShortenedRadius	Gets or sets whether to display this radius display dimension with a foreshortened radius.
 ShowDimensionValue	Gets or sets whether the dimension value is displayed as part of the dimension text.
 ShowLowerParenthesis	Gets or sets whether to enclose the text below the dimension line of the display dimension in parentheses.
 ShowParenthesis	Gets or sets whether to enclose the text above the dimension line of the display dimension in parentheses.
 ShowToIParenthesis	Obsolete. Superseded by IDisplayDimension::ShowParenthesis .
 SmartWitness	Gets or sets the smart display of extension lines.
 SolidLeader	Gets or sets whether this display dimension is displayed with a solid leader for arc and radial dimensions.
 Split	Gets or sets whether to split a dual dimension above and below an unbroken dimension line (also called a leader).
 Type2	Gets the type of dimension.
 VerticalJustification	Gets the dimension text's vertical justification.
 WitnessVisibility	Gets or sets which extension lines are visible.

[Top](#)

Public Methods

Name	Description
 AddDisplayEnt	Overrides the display graphics of objects.
 AddDisplayText	Overrides the display text.
 AlignToEdge	Aligns this linear dimension with the specified edge.
 AutoJogOrdinate	Sets the auto-jog for this ordinate dimension.
 ExplementaryAngle	Flips an angular dimension to its explementary angle.
 GetAlternatePrecision	Obsolete. Superseded by IDisplayDimension::GetAlternatePrecision2 .
 GetAlternatePrecision2	Gets the displayed precision for the dual portion of this dimension.
 GetAlternateToIPrecision	Obsolete. Superseded by IDisplayDimension::GetAlternateToIPrecision .

	GetAlternateTolPrecision2	Gets the displayed precision for the dual tolerance portion of this dimension.
	GetAnnotation	Gets the IAnnotation object for this specific annotation.
	GetArcLengthLeader	Gets the leader style of this arc length dimension.
	GetArrowHeadStyle	Obsolete. Superseded by IDisplayDimension::GetArrowHeadStyle2
	GetArrowHeadStyle2	Gets the arrowhead style used by this display dimension.
	GetAutoArcLengthLeader	Gets whether the leader style of this arc-length dimension is being automatically selected or selected by the user.
	GetBentLeaderLength	Gets the length of the bent leader to use when displaying this dimension.
	GetBrokenLeader2	Gets whether this display dimension has a broken or split leader.
	GetChamferUnits	Gets the local units of measurement for a chamfer display dimension.
	GetDefinitionTransform	Gets the transform for this dimension.
	GetDimension	Obsolete. Superseded by IDisplayDimension::GetDimension2
	GetDimension2	Gets the model dimension used to create this display dimension.
	GetDisplayData	Gets the display data for this display dimension.
	GetExtensionLineAsCenterline	Gets whether the specified extension line is a centerline.
	GetFractionBase	Gets whether this display dimension is displayed as a decimal value or a fraction.
	GetFractionValue	Gets the largest fraction denominator to be used when this display dimension is displayed in fraction format.
	GetHoleCalloutVariables	Gets access to hole callout variables in a hole callout.
	GetJogParameters	Gets the jog in a linear dimension extension line.
	GetLinkedText	Gets the text linked to this display dimension.
	GetLowerText	Gets the text below the dimension line in a display dimension.
	GetNameForSelection	Gets the name of the selected display dimension needed by IModelDocExtension::SelectByID2
	GetNext	Obsolete. Superseded by IDisplayDimension::GetNext5
	GetNext2	Obsolete. Superseded by IDisplayDimension::GetNext5
	GetNext3	Obsolete. Superseded by IDisplayDimension::GetNext5
	GetNext4	Obsolete. Superseded by IDisplayDimension::GetNext5
	GetNext5	Gets the next display dimension.
	GetOrdinateDimensionArrowSize	Gets the diameter of the circle for the arrow of the base ordinate dimension.
	GetOverride	Gets whether to display the actual dimension value or to override it with another value.
	GetOverrideValue	Gets the value to display instead of the actual dimension value.
	GetPrimaryPrecision	Obsolete. Superseded by IDisplayDimension::GetPrimaryPrecision2
	GetPrimaryPrecision2	Gets the primary dimension precision setting for this display dimension.
	GetPrimaryTolPrecision	Obsolete. Superseded by IDisplayDimension::GetPrimaryTolPrecision2
	GetPrimaryTolPrecision2	Gets the primary tolerance precision setting for this display dimension.
	GetRoundToFraction	Gets whether the displayed dimension value is rounded off so that SOLIDWORKS can display it as a fraction.
	GetSecondArrow	Gets whether this diameter display dimension has the second arrow enabled.
	GetSupportsGenericText	Gets whether the display dimension was created in SOLIDWORKS 2011 or later, which, if so, indicates that the display dimension is generic text.
	GetText	Gets the text above the dimension line in a display dimension.
	GetTextFormat	Obsolete. Superseded by IAnnotation::GetTextFormat
	GetTextFormatItems	Gets the format tokens of the specified text portion of a multi-value display dimension.
	GetType	Obsolete. Superseded by IDisplayDimension::Type2
	GetUnits	Gets the units used by this display dimension.
	GetUseDocArrowHeadStyle	Gets whether this display dimension uses the document default setting for dimension arrowhead style.
	GetUseDocBentLeaderLength	Gets whether this dimension is using the document default for bent leader length or not.

		
	GetUseDocBrokenLeader	Gets whether this display dimension uses the document default setting for displaying leaders as broken.
	GetUseDocDual	Gets whether this display dimension uses the document setting for positioning dual dimensions.
	GetUseDocPrecision	Obsolete. Not superseded.
	GetUseDocSecondArrow	Gets whether this diameter display dimension uses the document default setting for the display of the second outside arrow.
	GetUseDocTextFormat	Obsolete. Superseded by IAnnotation::GetUseDocTextFormat .
	GetUseDocUnits	Gets whether this display dimension uses the document default setting for units.
	GetWitnessLineGap	Gets the gap of the specified dimension extension line.
	IAddDisplayEnt	Overrides the display graphics of objects for this display dimension.
	IAddDisplayText	Overrides the display text for this display dimension.
	IGetAnnotation	Gets the IAnnotation object for this specific annotation.
	IGetDimension	Obsolete. Superseded by IDisplayDimension::GetDimension2 .
	IGetDisplayData	Gets the display data for this display dimension.
	IGetNext	Obsolete. Superseded by IDisplayDimension::GetNext5 .
	IGetNext2	Obsolete. Superseded by IDisplayDimension::GetNext5 .
	IGetNext3	Obsolete. Superseded by IDisplayDimension::GetNext5 .
	IGetTextFormat	Obsolete. Superseded by IAnnotation::IGetTextFormat .
	IsDimXpert	Obsolete. Superseded by IAnnotation::IsDimXpert .
	ISetTextFormat	Obsolete. Superseded by IAnnotation::ISetTextFormat .
	IsHoleCallout	Gets whether this display dimension is a hole callout.
	IsReferenceDim	Gets whether this display dimension is a reference dimension.
	ResetExtensionLineStyle	Resets the style of the specified extension line.
	SetArcLengthLeader	Sets the leader style of this arc-length dimension.
	SetArrowHeadStyle	Obsolete. Superseded by IDisplayDimension::SetArrowHeadStyle2 .
	SetArrowHeadStyle2	Sets the arrowhead style of this display dimension.
	SetBentLeaderLength	Sets the bent leader length to use for this dimension.
	SetBrokenLeader2	Sets the broken leader display characteristic of this display dimension.
	SetDual	Obsolete. Superseded by IDisplayDimension::SetDual2 .
	SetDual2	Controls the display of dual dimensions of this display dimension.
	SetExtensionLineAsCenterline	Sets whether the specified extension line is a centerline.
	SetHorizontal	Displays this linear dimension on the horizontal.
	SetJogParameters	Set the linear dimension extension line to be jogged.
	SetLineFontDimensionStyle	Sets the style of leader for this display dimension.
	SetLineFontDimensionThickness	Sets the thickness of leaders of this display dimension.
	SetLineFontExtensionStyle	Sets the line font style for the extension lines of this display dimension.
	SetLineFontExtensionThickness	Sets the thickness of the extension lines of this display dimension.
	SetLinkedText	Sets the text to link to this display dimension.
	SetLowerText	Sets the text below the dimension line in a display dimension.
	SetOrdinateDimensionArrowSize	Sets the diameter of the circle for the arrow of the base ordinate dimension if the base ordinate dimension standard is set to DIN.
	SetOverride	Sets whether to display the actual dimension value or to display another value, and, if so, that value.
	SetPrecision	Obsolete. Superseded by IDisplayDimension::SetPrecision2 .
	SetPrecision2	Obsolete. Superseded by IDisplayDimension::SetPrecision3 .
	SetPrecision3	Sets the number of digits to display after the decimal point for precision and tolerance values in this display dimension.

		
	SetSecondArrow	Sets the second arrow characteristics of this diameter display dimension.
	SetText	Sets the text above the dimension line in a display dimension.
	SetTextFormat	Obsolete. Superseded by IAnnotation::SetTextFormat
	SetUnits	Obsolete. Superseded by IDisplayDimension::SetUnits2
	SetUnits2	Sets the unit display characteristics of this display dimension.
	SetVertical	Displays this linear dimension on the vertical.
	SetWitnessLineGap	Sets the gap for the specified dimension extension line.
	SupplementaryAngle	Changes the angle in the selected angular dimension to its supplementary angle.
	Unlink	Unlinks a previously linked display dimension.
	VerticallyOppositeAngle	Flips an angular dimension to its vertically opposite angle.

[Top](#)

See Also

[IDisplayDimension Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICalloutVariable Interface](#)
[IDimensionTolerance Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDisplayDimension Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDisplayDimension Interface

For a list of all members of this type, see [IDisplayDimension members](#).

Public Methods

Name	Description
 AddDisplayEnt	Overrides the display graphics of objects.
 AddDisplayText	Overrides the display text.
 AlignToEdge	Aligns this linear dimension with the specified edge.
 AutoJogOrdinate	Sets the auto-jog for this ordinate dimension.
 ExplementaryAngle	Flips an angular dimension to its explementary angle.
 GetAlternatePrecision	Obsolete. Superseded by IDisplayDimension::GetAlternatePrecision2
 GetAlternatePrecision2	Gets the displayed precision for the dual portion of this dimension.
 GetAlternateTolPrecision	Obsolete. Superseded by IDisplayDimension::GetAlternateTolPrecision
 GetAlternateTolPrecision2	Gets the displayed precision for the dual tolerance portion of this dimension.
 GetAnnotation	Gets the IAnnotation object for this specific annotation.
 GetArcLengthLeader	Gets the leader style of this arc length dimension.
 GetArrowHeadStyle	Obsolete. Superseded by IDisplayDimension::GetArrowHeadStyle2
 GetArrowHeadStyle2	Gets the arrowhead style used by this display dimension.
 GetAutoArcLengthLeader	Gets whether the leader style of this arc-length dimension is being automatically selected or selected by the user.
 GetBentLeaderLength	Gets the length of the bent leader to use when displaying this dimension.
 GetBrokenLeader2	Gets whether this display dimension has a broken or split leader.
 GetChamferUnits	Gets the local units of measurement for a chamfer display dimension.
 GetDefinitionTransform	Gets the transform for this dimension.
 GetDimension	Obsolete. Superseded by IDisplayDimension::GetDimension2
 GetDimension2	Gets the model dimension used to create this display dimension.

	GetDisplayData	Gets the display data for this display dimension.
	GetExtensionLineAsCenterline	Gets whether the specified extension line is a centerline.
	GetFractionBase	Gets whether this display dimension is displayed as a decimal value or a fraction.
	GetFractionValue	Gets the largest fraction denominator to be used when this display dimension is displayed in fraction format.
	GetHoleCalloutVariables	Gets access to hole callout variables in a hole callout.
	GetJogParameters	Gets the jog in a linear dimension extension line.
	GetLinkedText	Gets the text linked to this display dimension.
	GetLowerText	Gets the text below the dimension line in a display dimension.
	GetNameForSelection	Gets the name of the selected display dimension needed by IModelDocExtension.SelectByID2 .
	GetNext	Obsolete. Superseded by IDisplayDimension.GetNext5 .
	GetNext2	Obsolete. Superseded by IDisplayDimension.GetNext5 .
	GetNext3	Obsolete. Superseded by IDisplayDimension.GetNext5 .
	GetNext4	Obsolete. Superseded by IDisplayDimension.GetNext5 .
	GetNext5	Gets the next display dimension.
	GetOrdinateDimensionArrowSize	Gets the diameter of the circle for the arrow of the base ordinate dimension.
	GetOverride	Gets whether to display the actual dimension value or to override it with another value.
	GetOverrideValue	Gets the value to display instead of the actual dimension value.
	GetPrimaryPrecision	Obsolete. Superseded by IDisplayDimension.GetPrimaryPrecision2 .
	GetPrimaryPrecision2	Gets the primary dimension precision setting for this display dimension.
	GetPrimaryTolPrecision	Obsolete. Superseded by IDisplayDimension.GetPrimaryTolPrecision2 .
	GetPrimaryTolPrecision2	Gets the primary tolerance precision setting for this display dimension.
	GetRoundToFraction	Gets whether the displayed dimension value is rounded off so that SOLIDWORKS can display it as a fraction.
	GetSecondArrow	Gets whether this diameter display dimension has the second arrow enabled.
	GetSupportsGenericText	Gets whether the display dimension was created in SOLIDWORKS 2011 or later, which, if so, indicates that the display dimension is generic text.
	GetText	Gets the text above the dimension line in a display dimension.
	GetTextFormat	Obsolete. Superseded by IAnnotation.GetTextFormat .
	GetTextFormatItems	Gets the format tokens of the specified text portion of a multi-value display dimension.
	GetType	Obsolete. Superseded by IDisplayDimension.Type2 .
	GetUnits	Gets the units used by this display dimension.
	GetUseDocArrowHeadStyle	Gets whether this display dimension uses the document default setting for dimension arrowhead style.
	GetUseDocBentLeaderLength	Gets whether this dimension is using the document default for bent leader length or not.
	GetUseDocBrokenLeader	Gets whether this display dimension uses the document default setting for displaying leaders as broken.
	GetUseDocDual	Gets whether this display dimension uses the document setting for positioning dual dimensions.
	GetUseDocPrecision	Obsolete. Not superseded.
	GetUseDocSecondArrow	Gets whether this diameter display dimension uses the document default setting for the display of the second outside arrow.
	GetUseDocTextFormat	Obsolete. Superseded by IAnnotation.GetUseDocTextFormat .
	GetUseDocUnits	Gets whether this display dimension uses the document default setting for units.
	GetWitnessLineGap	Gets the gap of the specified dimension extension line.
	IAddDisplayEnt	Overrides the display graphics of objects for this display dimension.
	IAddDisplayText	Overrides the display text for this display dimension.
	IGetAnnotation	Gets the IAnnotation object for this specific annotation.
	IGetDimension	Obsolete. Superseded by IDisplayDimension.GetDimension2 .
	IGetDisplayData	Gets the display data for this display dimension.

	IGetNext	Obsolete. Superseded by IDisplayDimension::GetNext5 .
	IGetNext2	Obsolete. Superseded by IDisplayDimension::GetNext5 .
	IGetNext3	Obsolete. Superseded by IDisplayDimension::GetNext5 .
	IGetTextFormat	Obsolete. Superseded by IAnnotation::IGetTextFormat .
	IsDimXpert	Obsolete. Superseded by IAnnotation::IsDimXpert .
	ISetTextFormat	Obsolete. Superseded by IAnnotation::ISetTextFormat .
	IsHoleCallout	Gets whether this display dimension is a hole callout.
	IsReferenceDim	Gets whether this display dimension is a reference dimension.
	ResetExtensionLineStyle	Resets the style of the specified extension line.
	SetArcLengthLeader	Sets the leader style of this arc-length dimension.
	SetArrowHeadStyle	Obsolete. Superseded by IDisplayDimension::SetArrowHeadStyle2 .
	SetArrowHeadStyle2	Sets the arrowhead style of this display dimension.
	SetBentLeaderLength	Sets the bent leader length to use for this dimension.
	SetBrokenLeader2	Sets the broken leader display characteristic of this display dimension.
	SetDual	Obsolete. Superseded by IDisplayDimension::SetDual2 .
	SetDual2	Controls the display of dual dimensions of this display dimension.
	SetExtensionLineAsCenterline	Sets whether the specified extension line is a centerline.
	SetHorizontal	Displays this linear dimension on the horizontal.
	SetJogParameters	Set the linear dimension extension line to be jogged.
	SetLineFontDimensionStyle	Sets the style of leader for this display dimension.
	SetLineFontDimensionThickness	Sets the thickness of leaders of this display dimension.
	SetLineFontExtensionStyle	Sets the line font style for the extension lines of this display dimension.
	SetLineFontExtensionThickness	Sets the thickness of the extension lines of this display dimension.
	SetLinkedText	Sets the text to link to this display dimension.
	SetLowerText	Sets the text below the dimension line in a display dimension.
	SetOrdinateDimensionArrowSize	Sets the diameter of the circle for the arrow of the base ordinate dimension if the base ordinate dimension standard is set to DIN.
	SetOverride	Sets whether to display the actual dimension value or to display another value, and, if so, that value.
	SetPrecision	Obsolete. Superseded by IDisplayDimension::SetPrecision2 .
	SetPrecision2	Obsolete. Superseded by IDisplayDimension::SetPrecision3 .
	SetPrecision3	Sets the number of digits to display after the decimal point for precision and tolerance values in this display dimension.
	SetSecondArrow	Sets the second arrow characteristics of this diameter display dimension.
	SetText	Sets the text above the dimension line in a display dimension.
	SetTextFormat	Obsolete. Superseded by IAnnotation::ISetTextFormat .
	SetUnits	Obsolete. Superseded by IDisplayDimension::SetUnits2 .
	SetUnits2	Sets the unit display characteristics of this display dimension.
	SetVertical	Displays this linear dimension on the vertical.
	SetWitnessLineGap	Sets the gap for the specified dimension extension line.
	SupplementaryAngle	Changes the angle in the selected angular dimension to its supplementary angle.
	Unlink	Unlinks a previously linked display dimension.
	VerticallyOppositeAngle	Flips an angular dimension to its vertically opposite angle.

See Also

[IDisplayDimension Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICalloutVariable Interface](#)
[IDimensionTolerance Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDisplayDimension Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IDisplayDimension Interface

For a list of all members of this type, see [IDisplayDimension members](#).

Public Properties

Name	Description
 ArcExtensionLineOrOppositeSide	Gets or sets whether to attach or extend the radial dimension leader on this radial display dimension.
 ArrowSide	Gets or sets the position of the dimension arrows.
 CenterText	Gets or sets whether the text of this display dimension should be automatically centered.
 ChamferPrecision	Gets or sets the precision of the length and angle values in a chamfer display dimension.
 ChamferTextStyle	Gets or sets the text style for chamfer dimensions.
 Diametric	Gets or sets whether this display dimension is radial/single distance or diameter/doubled distance.
 DimensionToInside	Gets or sets whether dimensions to arcs are always to the inside of the arc.
 DisplayAsChain	Gets or sets whether the extension lines of every dimension in this set of angular running or ordinate dimensions are chained together.
 DisplayAsLinear	Gets or sets whether this diameter dimension is displayed as a linear dimension.
 Elevation	Gets or sets whether to display an elevation symbol, which is controlled by IDisplayDimension.EndSymbol , at the end of ordinate dimension extension lines.
 EndSymbol	Gets or sets the ordinate dimension end symbol.
 ExtensionLineExtendsFromCenterOfSet	Gets or sets whether extension lines extend from the center of this set of angular running dimensions.
 ExtensionLineSameAsLeaderStyle	Gets or sets whether to use leader line styles for extension line styles.
 ExtensionLineUseDocumentDisplay	Gets or sets whether to use the document settings for extension lines.
 Foreshortened	Gets or sets whether a linear dimension is foreshortened in a drawing.
 GridBubble	Gets or sets whether to display a grid bubble at the end of ordinate dimension extension lines.
 HorizontalJustification	Gets or sets the dimension text's horizontal justification.
 Inspection	Gets or sets whether a display dimension above the dimension line is displayed as an inspection dimension.
 IsLinked	Gets whether the dimension has text linked to it.
 Jogged	Gets or sets whether this ordinate or angular running dimension is jogged.
 LeaderVisibility	Gets or sets which leader lines (dimension lines) are visible on a display dimension.
 LowerInspection	Gets or sets whether a display dimension below the dimension line is displayed as an inspection dimension.
 MarkedForDrawing	Gets or sets whether this display dimension is marked to include in a drawing document.
 MaxWitnessLineLength	Gets or sets the maximum length of dimension extension lines.
 OffsetText	Gets or sets whether or not to offset the text of a dimension.
 RunBidirectionally	Gets or sets whether each dimension runs in a direction closest to the baseline in this angular running dimension.
 Scale2	Gets or sets the scale value that is applied to the dimension value of this non-associative distance dimension.
 ShortenedRadius	Gets or sets whether to display this radius display dimension with a foreshortened radius.
 ShowDimensionValue	Gets or sets whether the dimension value is displayed as part of the dimension text.
 ShowLowerParenthesis	Gets or sets whether to enclose the text below the dimension line of the display dimension in parentheses.
 ShowParenthesis	Gets or sets whether to enclose the text above the dimension line of the display dimension in parentheses.
 ShowToIParenthesis	Obsolete. Superseded by IDisplayDimension.ShowParenthesis .

 SmartWitness	Gets or sets the smart display of extension lines.
 SolidLeader	Gets or sets whether this display dimension is displayed with a solid leader for arc and radial dimensions.
 Split	Gets or sets whether to split a dual dimension above and below an unbroken dimension line (also called a leader).
 Type2	Gets the type of dimension.
 VerticalJustification	Gets the dimension text's vertical justification.
 WitnessVisibility	Gets or sets which extension lines are visible.

[Top](#)

See Also

[IDisplayDimension Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICalloutVariable Interface](#)
[IDimensionTolerance Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddDisplayEnt Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : AddDisplayEnt Method (IDisplayDimension)

Overrides the display graphics of objects.

.NET Syntax

Visual Basic (Declaration)

```
Function AddDisplayEnt( _
    ByVal Type As System.Integer, _
    ByVal Data As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim Type As System.Integer
Dim Data As System.Object
Dim value As System.Boolean

value = instance.AddDisplayEnt(Type, Data)
```

C#

```
System.bool AddDisplayEnt(
    System.int Type,
    System.object Data
)
```

C++/CLI

```
System.bool AddDisplayEnt(
    & System.int Type,
    & System.Object^ Data
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Type

Type of graphical entity (see **Remarks**)

Data

Geometric data describing the entity (see **Remarks**)

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::AddDisplayEnt](#).

 Example

[Replace Dimension with Text \(VBA\)](#)

 Remarks

The new graphics displayed by this method are temporary. When the user changes the dimension, this display dimension reverts back to the SOLIDWORKS standard.

The type controls which geometry is added and what information is placed in the data array. All colors and line styles are taken from DisplayDimension.

type	Description	data
1	Line	6 doubles; (x, y, z) start point and (x, y, z) end point
2	Filled triangle	9 doubles; 3 (x, y, z) points of the triangle to fill
3	Filled 4 sided polygon	12 doubles; 4 (x, y, z) points of the polygon to fill
4	Arc	12 doubles; (x, y, z) center point, (x, y, z) normal vector, (x, y, z) start point and (x, y, z) end point
5	Circle	7 doubles; (x, y, z) center point, (x, y, z) normal vector and radius
6	Filled dot	4 doubles; (x, y, z) center point and radius

 See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::IAddDisplayText Method](#)

 Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help [Send comments on this topic.](#)

AddDisplayText Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : AddDisplayText Method (IDisplayDimension)
Overrides the display text.

 .NET Syntax

Visual Basic (Declaration)

```
Function AddDisplayText( _  
    ByVal Text As System.String, _  
    ByVal Position As System.Object, _  
    ByVal Format As System.Object, _  
    ByVal Attachment As System.Integer, _  
    ByVal WidthFactor As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)  Copy Code

```

Dim instance As IDisplayDimension
Dim Text As System.String
Dim Position As System.Object
Dim Format As System.Object
Dim Attachment As System.Integer
Dim WidthFactor As System.Double
Dim value As System.Boolean

```

```
value = instance.AddDisplayText(Text, Position, Format, Attachment, WidthFactor)
```

C#

```

System.bool AddDisplayText(
    System.string Text,
    System.object Position,
    System.object Format,
    System.int Attachment,
    System.double WidthFactor
)

```

C++/CLI

```

System.bool AddDisplayText(
    & System.String^ Text,
    & System.Object^ Position,
    & System.Object^ Format,
    & System.int Attachment,
    & System.double WidthFactor
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Text

Text to display

Position

Location of the text; array of 3 doubles

Format

Object for the text format

Attachment

Justification of the text as defined in [swTextJustification_e](#)

WidthFactor

Horizontal scale factor of the text

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::AddDisplayText](#).

Example

[Replace Dimension with Text \(VBA\)](#)

Remarks

The new graphics displayed by this method are temporary. When the user changes the dimension, this display dimension reverts back to the SOLIDWORKS standard.

See Also

[IDisplayDimension Interface](#)

[IDisplayDimension Members](#)

[IDisplayDimension::AddDisplayText Method](#)

[IDisplayDimension::HorizontalJustification Property](#)

[IDisplayDimension::VerticalJustification Property](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

AlignToEdge Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : AlignToEdge Method (IDisplayDimension)

Aligns this linear dimension with the specified edge.

.NET Syntax

Visual Basic (Declaration)

```
Function AlignToEdge( _  
    ByVal AlignmentEdge As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim AlignmentEdge As System.Object  
Dim value As System.Boolean  
  
value = instance.AlignToEdge(AlignmentEdge)
```

C#

```
System.bool AlignToEdge(  
    System.object AlignmentEdge  
)
```

C++/CLI

```
System.bool AlignToEdge(  
& System.Object^ AlignmentEdge  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AlignmentEdge
[IEdge](#)

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::AlignToEdge](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::SetHorizontal Method \(\)](#)
[IDisplayDimension::SetVertical Method \(\)](#)

Availability

SOLIDWORKS 2024 SP03, Revision Number 32.3

ArcExtensionLineOrOppositeSide Property (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : ArcExtensionLineOrOppositeSide Property (IDisplayDimension)

Gets or sets whether to attach or extend the radial dimension leader on this radial display dimension.

.NET Syntax

```
Property ArcExtensionLineOrOppositeSide As System.Boolean
```



```
Dim instance As IDisplayDimension
Dim value As System.Boolean

instance.ArcExtensionLineOrOppositeSide = value

value = instance.ArcExtensionLineOrOppositeSide
```

```
System.bool ArcExtensionLineOrOppositeSide {get; set;}
```

```
property System.bool ArcExtensionLineOrOppositeSide {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

If...	Then...
True	- Attach the radial dimension leader to the arc extension line. - or - If the radial dimension leader encounters arc geometry, then extend the radial dimension leader to the opposite side of the arc.
False	Neither attach nor extend the radial dimension leader.

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::ArcExtensionLineOrOppositeSide](#).

Example

[Set Radial Dimension Leader \(C#\)](#)
[Set Radial Dimension Leader \(VB.NET\)](#)
[Set Radial Dimension Leader \(VBA\)](#)

Remarks

This property is only valid for radial display dimensions.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IModelDoc2::AddRadialDimension2 Method\(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

ArrowSide Property (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : ArrowSide Property (IDisplayDimension)

Gets or sets the position of the dimension arrows.

.NET Syntax

```
Property ArrowSide As System.Integer
```

```
Dim instance As IDisplayDimension
Dim value As System.Integer

instance.ArrowSide = value

value = instance.ArrowSide
```

C#

```
System.int ArrowSide {get; set;}
```

C++/CLI

```
property System.int ArrowSide {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Dimension arrow side state as defined in [swDimensionArrowsSide_e](#)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::ArrowSide](#).

Example

[Get Dimension Values in Drawing \(VBA\)](#)
[Get Display Dimension Properties \(VBA\)](#)

Remarks

By specifying one of the following values in the Dimension Arrow Side state, the location of the dimension arrow with respect to the extension lines can be controlled. Valid values are listed in the [swDimensionArrowsSide_e](#) enumeration.

The graphics of the drawing change when you change this property. After you finish changing the drawing, use [IModelDoc2::WindowRedraw](#) to regenerate the drawing and display your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetSecondArrow Method](#)
[IDisplayDimension::GetUseDocSecondArrow Method](#)
[IDisplayDimension::SetSecondArrow Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AutoJogOrdinate Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : AutoJogOrdinate Method (IDisplayDimension)

Sets the auto-jog for this ordinate dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function AutoJogOrdinate() As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IDisplayDimension
Dim value As System.Boolean

value = instance.AutoJogOrdinate()
```

C#

```
System.bool AutoJogOrdinate()
```

C++/CLI

```
System.bool AutoJogOrdinate();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the auto-jog was successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::AutoJogOrdinate](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDrawingDoc::CreateOrdinateDim4 Method](#)
[IDrawingDoc::InsertHorizontalOrdinate Method](#)
[IDrawingDoc::InsertOrdinate Method](#)
[IDrawingDoc::InsertVerticalOrdinate Method](#)
[IModelDocExtension::AddOrdinateDimension Method](#)
[IDisplayDimension::Jogged Property](#)
[IDisplayDimension::GetOrdinateDimensionArrowSize Method](#)
[IDisplayDimension::SetOrdinateDimensionArrowSize Method](#)
[IDisplayDimension::DisplayAsChain Property](#)
[IDisplayDimension::Elevation Property](#)
[IDisplayDimension::EndSymbol Property](#)
[IDisplayDimension::GridBubble Property](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CenterText Property (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : CenterText Property (IDisplayDimension)

Gets or sets whether the text of this display dimension should be automatically centered.

.NET Syntax

Visual Basic (Declaration)

```
Property CenterText As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.Boolean
```

```
instance.CenterText = value
```

```
value = instance.CenterText
```

C#

```
System.bool CenterText {get; set;}
```

C++/CLI

```
property System.bool CenterText {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True centers the text, false does not center the text

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::CenterText](#).

Remarks

Dimension text must be positioned somewhere between the two dimensioned points in order to be centered.

In a...	The two points are the...
linear dimension	the end points of the dimension
diameter dimension	the end points of the dimension line lying on the arc.
radius dimension	the center point and the dimension line end point lying on the arc

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::SetText Method](#)
[IDisplayDimension::GetText Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

ChamferPrecision Property (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : ChamferPrecision Property (IDisplayDimension)

Gets or sets the precision of the length and angle values in a chamfer display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Property ChamferPrecision( _
    ByVal Index As System.Integer _
) As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IDisplayDimension
Dim Index As System.Integer
Dim value As System.Integer

instance.ChamferPrecision(Index) = value

value = instance.ChamferPrecision(Index)
```

C#

```
System.int ChamferPrecision(
    System.int Index
) {get; set;}
```

C++/CLI



```
property System.int ChamferPrecision {
    System.int get(System.int Index);
    void set (System.int Index, System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
0 for length, 1 for angle

Property Value

Number of decimal places to display for the value at the specified index

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::ChamferPrecision](#).

Example

[Get Chamfer Display Dimension \(C#\)](#)
[Get Chamfer Display Dimension \(VB.NET\)](#)
[Get Chamfer Display Dimension \(VBA\)](#)

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetChamferUnits Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ChamferTextStyle Property (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : ChamferTextStyle Property (IDisplayDimension)

Gets or sets the text style for chamfer dimensions.

.NET Syntax

Visual Basic (Declaration)

```
Property ChamferTextStyle As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.Integer

instance.ChamferTextStyle = value
value = instance.ChamferTextStyle
```

C#

```
System.int ChamferTextStyle {get; set;}
```

C++/CLI

```
property System.int ChamferTextStyle {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Text style for chamfer dimensions only as defined by [swDetailingChamferDimLeaderTextStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::ChamferTextStyle](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Diametric Property (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : Diametric Property (IDisplayDimension)

Gets or sets whether this display dimension is radial/single distance or diameter/doubled distance.

.NET Syntax

Visual Basic (Declaration)

```
Property Diametric As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean
```

```
instance.Diametric = value
```

```
value = instance.Diametric
```

C#

```
System.bool Diametric {get; set;}
```

C++/CLI

```
property System.bool Diametric {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to display the diameter/doubled distance dimension, false to display the radial/single distance dimension

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::Diametric](#).

Example

[Change Radial to Diametric Style \(VBA\)](#)
[Create Non-associative Diameter Dimension \(VBA\)](#)

Remarks

Depending on the [type](#) of this display dimension, this property toggles between:

- radial and diameter display dimensions
- radial linear and diametric linear display dimensions

This property does not affect other types of dimensions.

Use [IModelDocExtension::AddSpecificDimension](#) to create single or doubled distance display dimensions.

After using this property, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetType Method](#)
[IDisplayDimension::Type2 Property](#)
[IDisplayDimension::DisplayAsLinear Property](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

DimensionToInside Property (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : DimensionToInside Property (IDisplayDimension)

Gets or sets whether dimensions to arcs are always to the inside of the arc.

.NET Syntax

Visual Basic (Declaration)

Property DimensionToInside As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.Boolean

instance.DimensionToInside = value
value = instance.DimensionToInside
```

C#

```
System.bool DimensionToInside {get; set;}
```

C++/CLI

```
property System.bool DimensionToInside {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True dimension to the inside of arc, false does not dimension to the inside of the arc

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::DimensionToInside](#).

Remarks

This property applies only to radius dimensions. This property does not affect other types of dimensions.

After using this property, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

DisplayAsChain Property (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : DisplayAsChain Property (IDisplayDimension)

Gets or sets whether the extension lines of every dimension in this set of angular running or ordinate dimensions are chained together.

.NET Syntax

Visual Basic (Declaration)

```
Property DisplayAsChain As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean
```

```
instance.DisplayAsChain = value
```

```
value = instance.DisplayAsChain
```

C#

```
System.bool DisplayAsChain {get; set;}
```

C++/CLI

```
property System.bool DisplayAsChain {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if extension lines are chained together, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::DisplayAsChain](#).

Example

[Insert Angular Running Dimension \(VBA\)](#)
[Insert Angular Running Dimension \(VB.NET\)](#)
[Insert Angular Running Dimension \(C#\)](#)

Remarks

This property applies only to ordinate and angular running dimensions. This method does not affect other types of dimensions.

This property corresponds to:

- **Display as chain dimension** check box in the **Witness/Leader Display** panel of the **Leaders** tab of the **Dimension** PropertyManager page that appears when you right-click in a drawing and select **More Dimensions > Angular Running Dimension**.
- **Ordinate chain** check box in the **Witness/Leader Display** panel of the **Leaders** tab of the **Dimension** PropertyManager page that appears when you right-click in a drawing and select **More Dimensions > Ordinate**.

After using this property, use [IModelView::GraphicsRedraw](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::AutoJogOrdinate Method](#)
[IDisplayDimension::Elevation Property](#)
[IDisplayDimension::EndSymbol Property](#)
[IDisplayDimension::GridBubble Property](#)
[IDisplayDimension::Jogged Property](#)
[IDisplayDimension::ExtensionLineExtendsFromCenterOfSet Property](#)
[IDisplayDimension::RunBidirectionally Property](#)
[IDisplayDimension::ExtensionLineSameAsLeaderStyle Property](#)
[IDisplayDimension::ExtensionLineUseDocumentDisplay Property](#)
[IDisplayDimension::ResetExtensionLineStyle Property](#)
[IModelDocExtension::AddOrdinateDimension Method](#)
[IDisplayDimension::SetOrdinateDimensionArrowSize Method](#)
[IDisplayDimension::GetOrdinateDimensionArrowSize Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DisplayAsLinear Property (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : DisplayAsLinear Property (IDisplayDimension)

Gets or sets whether this diameter dimension is displayed as a linear dimension.

.NET Syntax

Visual Basic (Declaration)

Property DisplayAsLinear As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean
```

```
instance.DisplayAsLinear = value
```

```
value = instance.DisplayAsLinear
```

C#

```
System.bool DisplayAsLinear {get; set;}
```

C++/CLI

```
property System.bool DisplayAsLinear {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True displays a linear dimension, false displays a diameter dimension

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::DisplayAsLinear](#).

Remarks

This property applies only to diameter dimensions. It does not affect other types of dimensions.

After using this property, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::Type2 Property](#)
[IDisplayDimension::Foreshortened Property \(\)](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

Elevation Property (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : Elevation Property (IDisplayDimension)

Gets or sets whether to display an elevation symbol, which is controlled by [IDisplayDimension::EndSymbol](#), at the end of ordinate dimension extension lines.

Visual Basic Syntax

Visual Basic (Declaration)

Property Elevation As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean
```

```
instance.Elevation = value
```

```
value = instance.Elevation
```

C#

```
System.bool Elevation {get; set;}
```

C++/CLI

```
property System.bool Elevation {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to display elevation symbol, false to not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::Elevation](#).

Example

[Display Elevation Symbol \(VBA\)](#)

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::Jogged Property](#)
[IDisplayDimension::GridBubble Property](#)
[IDisplayDimension::AutoJogOrdinate Method](#)
[IDisplayDimension::DisplayAsChain Property](#)
[IModelDocExtension::AddOrdinateDimension Method](#)
[IDisplayDimension::GetOrdinateDimensionArrowSize Method](#)
[IDisplayDimension::SetOrdinateDimensionArrowSize Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EndSymbol Property (IDisplayDimension)

[See Also](#) [Example](#)



Gets or sets the ordinate dimension end symbol.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property EndSymbol As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Integer
```

```
instance.EndSymbol = value
```

```
value = instance.EndSymbol
```

C#

```
System.int EndSymbol {get; set;}
```

C++/CLI

```
property System.int EndSymbol {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Ordinate dimension end symbol as defined in [swOrdDimEndSymbol_e](#)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::EndSymbol](#).

Example

[Display Elevation Symbol \(VBA\)](#)

Remarks

[IDisplayDimension::Elevation](#) controls whether to display an elevation symbol controlled by this property.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::Jogged Property](#)
[IDisplayDimension::GridBubble Property](#)
[IDisplayDimension::AutoJogOrdinate Method](#)
[IDisplayDimension::DisplayAsChain Property](#)
[IModelDocExtension::AddOrdinateDimension Method](#)
[IDisplayDimension::GetOrdinateDimensionArrowSize Method](#)
[IDisplayDimension::SetOrdinateDimensionArrowSize Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

ExplementaryAngle Method (IDisplayDimension)

[See Also](#) [Example](#)



Flips an angular dimension to its explementary angle.

.NET Syntax

Visual Basic (Declaration)

```
Function ExplementaryAngle() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean  
  
value = instance.ExplementaryAngle()
```

C#

```
System.bool ExplementaryAngle()
```

C++/CLI

```
System.bool ExplementaryAngle();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::ExplementaryAngle](#).

Example

[Create Angular Dimension \(VBA\)](#)
[Create Angular Dimension \(VB.NET\)](#)
[Create Angular Dimension \(C#\)](#)

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::VerticallyOppositeAngle Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ExtensionLineExtendsFromCenterOfSet Property (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : ExtensionLineExtendsFromCenterOfSet Property (IDisplayDimension)

Gets or sets whether extension lines extend from the center of this set of angular running dimensions.

.NET Syntax

Visual Basic (Declaration)

```
Property ExtensionLineExtendsFromCenterOfSet As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.Boolean

instance.ExtensionLineExtendsFromCenterOfSet = value

value = instance.ExtensionLineExtendsFromCenterOfSet
```

C#

```
System.bool ExtensionLineExtendsFromCenterOfSet {get; set;}
```

C++/CLI

```
property System.bool ExtensionLineExtendsFromCenterOfSet {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if extension lines extend from the center of the set of angular running dimensions, false if they extend from the selection point

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::ExtensionLineExtendsFromCenterOfSet](#).

Example

[Insert Angular Running Dimension \(VBA\)](#)
[Insert Angular Running Dimension \(VB.NET\)](#)
[Insert Angular Running Dimension \(C#\)](#)

Remarks

This property corresponds to the **Extension line extends from center of set** check box in the **Witness/Leader Display** panel of the **Leaders** tab of the **Dimension** PropertyManager page that appears when you right-click in a drawing and select **More Dimensions > Angular Running Dimension**.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::DisplayAsChain Property \(\)](#)
[IDisplayDimension::RunBidirectionally Property \(\)](#)
[IDisplayDimension::Jogged Property \(\)](#)
[IDisplayDimension::ExtensionLineSameAsLeaderStyle Property \(\)](#)
[IDisplayDimension::ExtensionLineUseDocumentDisplay Property \(\)](#)
[IDisplayDimension::ResetExtensionLineStyle Property \(\)](#)
[IDisplayDimension::SetLineFontExtensionStyle Method \(\)](#)
[IDisplayDimension::SetLineFontExtensionThickness Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ExtensionLineSameAsLeaderStyle Property (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : ExtensionLineSameAsLeaderStyle Property (IDisplayDimension)

Gets or sets whether to use leader line styles for extension line styles.

.NET Syntax

Visual Basic (Declaration)

```
Property ExtensionLineSameAsLeaderStyle As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.Boolean

instance.ExtensionLineSameAsLeaderStyle = value

value = instance.ExtensionLineSameAsLeaderStyle
```

C#

```
System.bool ExtensionLineSameAsLeaderStyle {get; set;}
```

C++/CLI

```
property System.bool ExtensionLineSameAsLeaderStyle {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use leader line styles for extension line styles, false to not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::ExtensionLineSameAsLeaderStyle](#).

Example

[Insert Angular Running Dimension \(VBA\)](#)
[Insert Angular Running Dimension \(VB.NET\)](#)
[Insert Angular Running Dimension \(C#\)](#)

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::ExtensionLineExtendsFromCenterOfSet Property\(\)](#)
[IDisplayDimension::ExtensionLineUseDocumentDisplay Property\(\)](#)
[IDisplayDimension::ResetExtensionLineStyle Property\(\)](#)
[IDisplayDimension::DisplayAsChain Property\(\)](#)
[IDisplayDimension::RunBidirectionally Property\(\)](#)
[IDisplayDimension::Jogged Property\(\)](#)
[IDisplayDimension::SetLineFontExtensionStyle Method\(\)](#)
[IDisplayDimension::SetLineFontExtensionThickness Method\(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ExtensionLineUseDocumentDisplay Property (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : ExtensionLineUseDocumentDisplay Property (IDisplayDimension)

Gets or sets whether to use the document settings for extension lines.

.NET Syntax

Visual Basic (Declaration)

```
Property ExtensionLineUseDocumentDisplay As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.Boolean

instance.ExtensionLineUseDocumentDisplay = value
```

```
value = instance.ExtensionLineUseDocumentDisplay
```

C#

```
System.bool ExtensionLineUseDocumentDisplay {get; set;}
```

C++/CLI

```
property System.bool ExtensionLineUseDocumentDisplay {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the document settings for extension lines, false to not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::ExtensionLineUseDocumentDisplay](#).

Example

[Insert Angular Running Dimension \(VBA\)](#)
[Insert Angular Running Dimension \(VB.NET\)](#)
[Insert Angular Running Dimension \(C#\)](#)

Remarks

This property is valid only if [IDisplayDimension::ExtensionLineSameAsLeaderStyle](#) is set to false.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::ExtensionLineExtendsFromCenterOfSet Property \(\)](#)
[IDisplayDimension::ResetExtensionLineStyle Property \(\)](#)
[IDisplayDimension::DisplayAsChain Property \(\)](#)
[IDisplayDimension::RunBidirectionally Property \(\)](#)
[IDisplayDimension::Jogged Property \(\)](#)
[IDisplayDimension::SetLineFontExtensionStyle Method \(\)](#)
[IDisplayDimension::SetLineFontExtensionThickness Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Foreshortened Property (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : Foreshortened Property (IDisplayDimension)

Gets or sets whether a linear dimension is foreshortened in a drawing.

.NET Syntax

Visual Basic (Declaration)

```
Property Foreshortened As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean
```

```
instance.Foreshortened = value
```

```
value = instance.Foreshortened
```

C#

```
System.bool Foreshortened {get; set;}
```

C++/CLI

```
property System.bool Foreshortened {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the linear dimension is foreshortened, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::Foreshortened](#).

Example

[Get Whether Linear Dimension Is Foreshortened \(C#\)](#)
[Get Whether Linear Dimension Is Foreshortened \(VB.NET\)](#)
[Get Whether Linear Dimension Is Foreshortened \(VBA\)](#)

Remarks

This property is only valid for linear dimensions and only when the detailing standard is ANSI.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::DisplayAsLinear Property \(\)](#)
[IModelDoc2::AddDimension2 Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAlternatePrecision Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetAlternatePrecision Method (IDisplayDimension)

Obsolete. Superseded by [IDisplayDimension::GetAlternatePrecision2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetAlternatePrecision() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Integer  
  
value = instance.GetAlternatePrecision()
```

C#

```
System.int GetAlternatePrecision()
```

C++/CLI

```
System.int GetAlternatePrecision();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetAlternatePrecision](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAlternatePrecision2 Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetAlternatePrecision2 Method (IDisplayDimension)

Gets the displayed precision for the dual portion of this dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAlternatePrecision2() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Integer
```

```
value = instance.GetAlternatePrecision2()
```

C#

```
System.int GetAlternatePrecision2()
```

C++/CLI

```
System.int GetAlternatePrecision2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Precision setting as defined in [swDimensionPrecisionSettings_e](#)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetAlternatePrecision2](#).

Example

[Get Precisions for a Dimension \(VBA\)](#)

Remarks

If the return value equals swPrecisionFollowsDocumentSetting, then the precision used is the document default for dual dimension values. You can retrieve the value using [IModelDocExtension::GetUserPreferenceInteger](#) with swDetailingAltLinearDimPrecision. Otherwise, the return value is the precision in the dimensions dual units.

Use [IDisplayDimension::SetPrecision2](#) to set precision values on this display dimension.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetPrimaryTolPrecision2 Method](#)
[IDisplayDimension::GetPrimaryPrecision2 Method](#)
[IDisplayDimension::GetPrimaryTolPrecision2 Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAlternateTolPrecision Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetAlternateTolPrecision Method (IDisplayDimension)

Obsolete. Superseded by [IDisplayDimension::GetAlternateTolPrecision](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetAlternateTolPrecision() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Integer  
  
value = instance.GetAlternateTolPrecision()
```

C#

```
System.int GetAlternateTolPrecision()
```

C++/CLI

```
System.int GetAlternateTolPrecision();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetAlternateTolPrecision](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAlternateTolPrecision2 Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetAlternateTolPrecision2 Method (IDisplayDimension)

Gets the displayed precision for the dual tolerance portion of this dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAlternateTolPrecision2() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Integer  
  
value = instance.GetAlternateTolPrecision2()
```

C#

```
System.int GetAlternateTolPrecision2()
```

```
System.int GetAlternateTolPrecision2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Precision setting as defined in [swDimensionPrecisionSettings_e](#)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetAlternateTolPrecision2](#).

Example

[Get Precisions for a Dimension \(VBA\)](#)

Remarks

If the return value equals swPrecisionFollowsDocumentSetting, then the precision being used is the document default for dual dimension values. You can retrieve the value using [IModelDocExtension::GetUserPreferenceInteger](#) with swDetailingAltLinearTolPrecision.

If the return value equals swTolerancePrecisionFollowsNominal, then the precision being used is the same as the precision being used for the dual dimension value. You can retrieve the value using [DisplayDimension::GetAlternatePrecision2](#).

Otherwise, the return value is the precision in the dimensions dual units.

Use [IDisplayDimension::SetPrecision2](#) to set precision values on this display dimension.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetPrimaryPrecision2 Method](#)
[IDisplayDimension::GetPrimaryTolPrecision2 Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetAnnotation Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetAnnotation Method (IDisplayDimension)

Gets the IAnnotation object for this specific annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAnnotation() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.Object

value = instance.GetAnnotation()
```

C#

```
System.object GetAnnotation()
```

C++/CLI

```
System.Object^ GetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Annotation](#)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetAnnotation](#).

Example

[Get Dimension Values in Drawing \(VBA\)](#)
[Iterate Through Dimensions in Model \(VBA\)](#)
[Unlink Dimensions \(VBA\)](#)
[Get Annotation Object \(VBA\)](#)
[Get Annotation Object \(VB.NET\)](#)
[Get Annotation Object \(C#\)](#)
[Traverse Annotations \(C#\)](#)
[Traverse Annotations \(VB.NET\)](#)
[Traverse Annotations \(VBA\)](#)

Remarks

The IAnnotation object is a higher-level object that contains methods that are available to all types of annotations.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::IGetAnnotation Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetArcLengthLeader Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetArcLengthLeader Method (IDisplayDimension)

Gets the leader style of this arc length dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArcLengthLeader() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Integer  
  
value = instance.GetArcLengthLeader()
```

C#

```
System.int GetArcLengthLeader()
```

C++/CLI

```
System.int GetArcLengthLeader();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Annotation

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetArcLengthLeader](#).

Remarks

The [IAnnotation](#) object is a higher-level object that contains methods that are general to all types of annotations.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::SetArcLengthLeader Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetArrowHeadStyle Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetArrowHeadStyle Method (IDisplayDimension)

Obsolete. Superseded by [IDisplayDimension::GetArrowHeadStyle2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetArrowHeadStyle() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Integer  
  
value = instance.GetArrowHeadStyle()
```

C#

```
System.int GetArrowHeadStyle()
```

C++/CLI

```
System.int GetArrowHeadStyle();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetArrowHeadStyle](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetArrowHeadStyle2 Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetArrowHeadStyle2 Method (IDisplayDimension)

Gets the arrowhead style used by this display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArrowHeadStyle2( _  
    ByRef Style1 As System.Integer, _
```

```
ByRef Style2 As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim Style1 As System.Integer  
Dim Style2 As System.Integer  
Dim value As System.Boolean  
  
value = instance.GetArrowHeadStyle2(Style1, Style2)
```

C#

```
System.bool GetArrowHeadStyle2(  
    out System.int Style1,  
    out System.int Style2  
)
```

C++/CLI

```
System.bool GetArrowHeadStyle2(  
& [Out] System.int Style1,  
& [Out] System.int Style2  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Style1

Arrowhead style of first arrowhead as defined in [swArrowStyle_e](#)

Style2

Arrowhead style of second arrowhead as defined in [swArrowStyle_e](#)

Return Value

True if the styles are set, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetArrowHeadStyle2](#).

Remarks

The arrowhead style for a display dimension is controlled by a value stored in one of two places: on the owning document or on the individual display dimension. Use this method and [IDisplayDimension::GetUseDocArrowHeadStyle](#) to get the current values for these settings. Use [IDisplayDimension::SetArrowHeadStyle2](#) to set the arrowhead style.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAutoArcLengthLeader Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetAutoArcLengthLeader Method (IDisplayDimension)

Gets whether the leader style of this arc-length dimension is being automatically selected or selected by the user.

.NET Syntax

Visual Basic (Declaration)

Function GetAutoArcLengthLeader() As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean  
  
value = instance.GetAutoArcLengthLeader()
```

C#

```
System.bool GetAutoArcLengthLeader()
```

C++/CLI

```
System.bool GetAutoArcLengthLeader();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the leader style is selected automatically , false if the leader style is selected by the user

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetAutoArcLengthLeader](#).

Remarks

The leader style of an arc-length dimension is specific to each display dimension. It can be parallel (the leaders are parallel to each other) or radial (the leaders are perpendicular to the extension line and would extend through the center of the arc). SOLIDWORKS can automatically select the style, or it can be specified by the user. Use `IDisplayDimension::GetAutoArcLengthLeader` to determine whether the leader type is selected automatically.

This method gets the leader style stored on this display dimension. If this display dimension is set to select the leader type automatically, then this method might return a value that is different from what is displayed.

This method applies to only arc length dimensions. It returns -1 if you run it on any other types of dimensions.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetArcLengthLeader Method](#)
[IDisplayDimension::SetArcLengthLeader Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBentLeaderLength Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetBentLeaderLength Method (IDisplayDimension)

Gets the length of the bent leader to use when displaying this dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBentLeaderLength() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Double  
  
value = instance.GetBentLeaderLength()
```

C#

```
System.double GetBentLeaderLength()
```

C++/CLI

```
System.double GetBentLeaderLength();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Length of the bent leader in system units

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetBentLeaderLength](#).

Remarks

This method returns the length of the bent leader regardless of how the dimension is currently being displayed. Even if the dimension is not currently being displayed with a bent leader, this method still returns the length.

If the dimension is using the document default setting for dimension bent leader length, this method returns that value. You can use [IDisplayDimension::GetUseDocBentLeaderLength](#) to determine if this dimension is using the document default setting for dimension bent leader length or not.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::SetBentLeaderLength Method](#)
[IDisplayDimension::GetUseDocBentLeaderLength Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBrokenLeader2 Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetBrokenLeader2 Method (IDisplayDimension)

Gets whether this display dimension has a broken or split leader.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBrokenLeader2() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Integer
```

```
value = instance.GetBrokenLeader2()
```

C#

```
System.int GetBrokenLeader2()
```

C++/CLI

```
System.int GetBrokenLeader2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Broken leader value as defined in [swDisplayDimensionLeaderText_e](#)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetBrokenLeader2](#).

Remarks

Dimension text can be displayed above a solid leader line or the dimension leader line can be broken with the text displayed either horizontal or aligned with the leader line. You can use this method to determine which setting is used by this display dimension.

The setting can be local to the display dimension, or the display dimension might use the default document setting. This method returns a valid value only if it is using a local setting; if this display dimension uses the default document setting, it returns -1.

Use [IDisplayDimension::SetBrokenLeader2](#) to set this value.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetUseDocBrokenLeader Method](#)
[IDisplayDimension::SetBrokenLeader2 Method](#)
[IDisplayDimension::SolidLeader Property](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetChamferUnits Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetChamferUnits Method (IDisplayDimension)

Gets the local units of measurement for a chamfer display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function GetChamferUnits( _  
    ByRef LengthUnit As System.Integer, _  
    ByRef AngularUnit As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim LengthUnit As System.Integer  
Dim AngularUnit As System.Integer  
Dim value As System.Boolean
```

```
value = instance.GetChamferUnits(LengthUnit, AngularUnit)
```

C#

```
System.bool GetChamferUnits(  
    out System.int LengthUnit,  
    out System.int AngularUnit  
)
```

C++/CLI

```
System.bool GetChamferUnits(  
& [Out] System.int LengthUnit,  
& [Out] System.int AngularUnit  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

LengthUnit
Unit of length as defined in [swLengthUnit_e](#)
AngularUnit
Unit of angle as defined in [swAngleUnit_e](#)

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetChamferUnits](#).

Example

[Get Chamfer Display Dimension \(C#\)](#)
[Get Chamfer Display Dimension \(VB.NET\)](#)
[Get Chamfer Display Dimension \(VBA\)](#)

Remarks

The unit display setting of a chamfer display dimension is controlled by a value stored in one of two places: on the owning document or on the individual display dimension. Use [IDisplayDimension::GetUseDocUnits](#) to determine whether the units settings are local or from the owning document. If [IDisplayDimension::GetUseDocUnits](#) returns true, then the units settings are from the owning document, and this API returns -1 for both length and angle units of measurement.

Local unit information for a chamfer display dimension is in force when Override Units is selected on the Other tab of the dimension's PropertyManager page. If Override Units is selected, then this API returns units as defined in [swLengthUnit_e](#) (length measurement) and [swAngleUnit_e](#) (angle measurement).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetUnits Method](#)
[IDisplayDimension::ChamferPrecision Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDefinitionTransform Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetDefinitionTransform Method (IDisplayDimension)

Gets the transform for this dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDefinitionTransform() As MathTransform
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As MathTransform
```

```
value = instance.GetDefinitionTransform()
```

C#

```
MathTransform GetDefinitionTransform()
```

C++/CLI

```
MathTransform^ GetDefinitionTransform();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [IMathTransform](#) object

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetDefinitionTransform](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

Availability

SOLIDWORKS 2004 SP2, Revision Number 12.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDimension Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetDimension Method (IDisplayDimension)

Obsolete. Superseded by [IDisplayDimension::GetDimension2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimension() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Object  
  
value = instance.GetDimension()
```

C#

```
System.object GetDimension()
```

C++/CLI

```
System.Object^ GetDimension();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Dimension

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetDimension](#).

Example

[Get Block Information \(VBA\)](#)
[Get Component Via Display Dimension \(VBA\)](#)
[Get Display Dimension Properties \(VBA\)](#)
[Iterate Through Dimensions in Model \(VBA\)](#)
[Set Dimensions to Mid-tolerance \(VBA\)](#)
[Traverse Feature Dimensions \(VBA\)](#)
[Unlink Dimensions \(VBA\)](#)

Remarks

SOLIDWORKS can display a dimension more than once. For example, a base-extrude dimension can be brought into three different views on a drawing. These three dimensions are referred to as display dimensions and are represented by the [IDisplayDimension](#) object in the SOLIDWORKS API. The original base-extrude dimension is represented by the [IDimension](#) object in the SOLIDWORKS API.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IFeature::Parameter Method](#)
[IFeature::IParameter Method](#)
[IModelDoc2::Parameter Method](#)
[IModelDoc2::IParameter Method](#)
[IDisplayDimension::IGetDimension Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDimension2 Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetDimension2 Method (IDisplayDimension)

Gets the model dimension used to create this display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimension2( _  
    ByVal Index As System.Integer _  
) As Dimension
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim Index As System.Integer  
Dim value As Dimension  
  
value = instance.GetDimension2(Index)
```

C#

```
Dimension GetDimension2(  
    System.int Index  
)
```

C++/CLI

```
Dimension^ GetDimension2(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

- 0 to get the first chamfer display dimension
- 1 to get the second chamfer display dimension

Return Value

[Dimension](#)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetDimension2](#).

Example

[Get and Set Sensor \(C#\)](#)
[Get and Set Sensor \(VB.NET\)](#)
[Get and Set Sensor \(VBA\)](#)

Remarks

The Index argument is valid for chamfer display dimensions only. If the display dimension is not a chamfer display dimension, then Index is ignored. To get both chamfer display dimensions, you must call this property twice; specify 0 for Index in the first call and 1 for Index in the second call.

SOLIDWORKS can display a dimension more than once. For example, a base-extrude dimension can be brought into three different views on a drawing. These three dimensions are referred to as display dimensions and are represented by the DisplayDimension object in the SOLIDWORKS API. The original base-extrude dimension is represented by the Dimension object in the SOLIDWORKS API.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDisplayData Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetDisplayData Method (IDisplayDimension)

Gets the display data for this display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayData() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Object
```

```
value = instance.GetDisplayData()
```

C#

```
System.object GetDisplayData()
```

C++/CLI

```
System.Object^ GetDisplayData();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Object for display data

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetDisplayData](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::IGetDisplayData Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetExtensionLineAsCenterline Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetExtensionLineAsCenterline Method (IDisplayDimension)

Gets whether the specified extension line is a centerline.

.NET Syntax

Visual Basic (Declaration)

```
Function GetExtensionLineAsCenterline( _  
    ByVal ExtIndex As System.Short, _  
    ByRef Centerline As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim ExtIndex As System.Short  
Dim Centerline As System.Boolean  
Dim value As System.Boolean  
  
value = instance.GetExtensionLineAsCenterline(ExtIndex, Centerline)
```

C#

```
System.bool GetExtensionLineAsCenterline(  
    System.short ExtIndex,  
    out System.bool Centerline  
)
```

C++/CLI

```
System.bool GetExtensionLineAsCenterline(  
& System.short ExtIndex,  
& [Out] System.bool Centerline  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ExtIndex
Index of extension line
Centerline
True if the extension line is a centerline, false if not

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetExtensionLineAsCenterline](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFractionBase Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetFractionBase Method (IDisplayDimension)

Gets whether this display dimension is displayed as a decimal value or a fraction.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFractionBase() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.Integer

value = instance.GetFractionBase()
```

C#

```
System.int GetFractionBase()
```

C++/CLI

```
System.int GetFractionBase();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Value indicating decimal or fractional display as defined in [swFractionDisplay_e](#)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetFractionBase](#).

Remarks

The unit display settings of a display dimension are controlled by a value that SOLIDWORKS stores in one of two places: on the owning document or on the individual display dimension. Use [IDisplayDimension::GetUseDocUnits](#) to determine whether this IDisplayDimension uses the document default or a specific value set for this IDisplayDimension.

If this display dimension is using the unit information stored locally on the DisplayDimension, this method returns a value defined in [swFractionDisplay_e](#). If this display dimension uses settings from the document, then this method returns -1.

Use [IDisplayDimension::SetUnits](#) to set the units settings of a display dimension.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetFractionValue Method](#)
[IDisplayDimension::GetRoundToFraction Method](#)
[IDisplayDimension::GetUnits Method](#)
[IDisplayDimension::SetUnits Method](#)
[IDisplayDimension::GetUseDocUnits Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFractionValue Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetFractionValue Method (IDisplayDimension)

Gets the largest fraction denominator to be used when this display dimension is displayed in fraction format.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFractionValue() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.Integer
```

```
value = instance.GetFractionValue()
```

C#

```
System.int GetFractionValue()
```

C++/CLI

```
System.int GetFractionValue();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Denominator for fraction display (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetFractionValue](#).

Remarks

The unit display settings of a display dimension are controlled by a value that SOLIDWORKS stores in one of two places: on the owning document or on the individual display dimension. Use [IDisplayDimension::GetUseDocUnits](#) to determine whether this IDisplayDimension uses the document default or a specific value set for this IDisplayDimension.

If this display dimension uses the unit information stored locally, this method returns the largest fraction denominator to be used (for example, 4 for 1/4, or 32 for 1/32). This method returns -1 if this display dimension uses settings from the document.

Fraction display is valid only for unit types swINCHES or swFEETINCHES. In all other cases, this method returns -1. Use [IDisplayDimension::SetUnits](#) to set the units settings of a display dimension.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetFractionBase Method](#)
[IDisplayDimension::GetRoundToFraction Method](#)
[IDisplayDimension::SetUnits Method](#)
[IDisplayDimension::GetUseDocUnits Method](#)
[IDisplayDimension::GetUnits Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetHoleCalloutVariables Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetHoleCalloutVariables Method (IDisplayDimension)

Gets access to hole callout variables in a hole callout.

.NET Syntax

Visual Basic (Declaration)

```
Function GetHoleCalloutVariables() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Object
```

```
value = instance.GetHoleCalloutVariables()
```

C#

```
System.object GetHoleCalloutVariables()
```

C++/CLI

```
System.Object^ GetHoleCalloutVariables();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [CalloutVariable](#) objects

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetHoleCalloutVariables](#).

Example

[Get and Set Hole Callout Variables \(C#\)](#)
[Get and Set Hole Callout Variables \(VB.NET\)](#)
[Get and Set Hole Callout Variables \(VBA\)](#)

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[ICalloutAngleVariable Interface](#)
[ICalloutLengthVariable Interface](#)
[ICalloutStringVariable Interface](#)
[IDisplayDimension::IsHoleCallout Method \(\)](#)
[IDrawingDoc::AddHoleCallout2 Method \(\)](#)
[IDrawingDoc::IAddHoleCallout2 Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetJogParameters Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetJogParameters Method (IDisplayDimension)

Gets the jog in a linear dimension extension line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetJogParameters( _  
    ByVal WitnessIndex As System.Short, _  
    ByRef Jogged As System.Boolean, _  
    ByRef Offset1 As System.Double, _  
    ByRef Offset2 As System.Double, _  
    ByRef Offset1to2 As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim WitnessIndex As System.Short  
Dim Jogged As System.Boolean  
Dim Offset1 As System.Double  
Dim Offset2 As System.Double  
Dim Offset1to2 As System.Double  
Dim value As System.Boolean
```

```
value = instance.GetJogParameters(WitnessIndex, Jogged, Offset1, Offset2, Offset1to2)
```

C#

```
System.bool GetJogParameters(  
    System.short WitnessIndex,  
    out System.bool Jogged,  
    out System.double Offset1,  
    out System.double Offset2,
```

```
        out System.double Offset1to2  
    )
```

C++/CLI

```
System.bool GetJogParameters(  
    & System.short WitnessIndex,  
    & [Out] System.bool Jogged,  
    & [Out] System.double Offset1,  
    & [Out] System.double Offset2,  
    & [Out] System.double Offset1to2  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WitnessIndex

Index of linear dimension extension line whose jog to get

Jogged

True if the linear dimension extension line is jogged, false if not

Offset1

First line segment of the linear dimension extension line

Offset2

Second line segment of the linear dimension extension line; this is the line segment that is jogged

Offset1to2

Third line segment of the linear dimension extension line

Return Value

True if the operation succeeds, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetJogParameters](#).

Example

[Add and Offset Dimension Extension Lines Jogs \(VBA\)](#)

See Also

[IDisplayDimension Interface](#)

[IDisplayDimension Members](#)

[IDisplayDimension::SetJogParameters Method](#)

[IModelDocExtension::JogDimension Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0