

SOLIDWORKS API (.NET VBA C#) — Reference

(77/337): IDisplayDimension (part 2 of 3)

SOLIDWORKS API Documentation (converted from CHM)

IDisplayDimension (part 2 of 3) (Type)

GetLinkedText Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetLinkedText Method (IDisplayDimension)

Gets the text linked to this display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLinkedText() As System.String
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.String

value = instance.GetLinkedText()
```

C#

```
System.string GetLinkedText()
```

C++/CLI

```
System.String^ GetLinkedText();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Text linked to this display dimension

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetLinkedText](#).

Example

[Get Linked Dimensions \(VBA\)](#)

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::SetLinkedText Method](#)
[IDisplayDimension::Unlink Method](#)
[IDisplayDimension::IsLinked Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

GetLowerText Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetLowerText Method (IDisplayDimension)

Gets the text below the dimension line in a display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLowerText() As System.String
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.String  
  
value = instance.GetLowerText()
```

C#

```
System.string GetLowerText()
```

C++/CLI

```
System.String^ GetLowerText();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Text below the dimension line

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetLowerText](#).

Example

[Get Chamfer Display Dimension \(C#\)](#)
[Get Chamfer Display Dimension \(VB.NET\)](#)
[Get Chamfer Display Dimension \(VBA\)](#)

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::SetLowerText Method \(\)](#)
[IModelDocExtension::EditDimensionProperties Method \(\)](#)
[IModelDocExtension::IEditDimensionProperties Method\(\)](#)
[IDisplayDimension::GetText Method \(\)](#)
[IDisplayDimension::SetText Method\(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetNameForSelection Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetNameForSelection Method (IDisplayDimension)

Gets the name of the selected display dimension needed by [IModelDocExtension::SelectByID2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNameForSelection() As System.String
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.String  
  
value = instance.GetNameForSelection()
```

C#

```
System.string GetNameForSelection()
```

C++/CLI

```
System.String^ GetNameForSelection();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Name of selected display dimension

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetNameForSelection](#).

Example

[Get Chamfer Display Dimension \(C#\)](#)
[Get Chamfer Display Dimension \(VB.NET\)](#)
[Get Chamfer Display Dimension \(VBA\)](#)

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDimension::GetNameForSelection Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNext Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetNext Method (IDisplayDimension)

Obsolete. Superseded by [IDisplayDimension::GetNext5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Object  
  
value = instance.GetNext()
```

C#

```
System.object GetNext()
```

C++/CLI

```
System.Object^ GetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetNext](#).

See Also

GetNext2 Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetNext2 Method (IDisplayDimension)

Obsolete. Superseded by [IDisplayDimension::GetNext5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Object  
  
value = instance.GetNext2()
```

C#

```
System.object GetNext2()
```

C++/CLI

```
System.Object^ GetNext2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetNext2](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

GetNext3 Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetNext3 Method (IDisplayDimension)

Obsolete. Superseded by [IDisplayDimension::GetNext5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext3() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Object  
  
value = instance.GetNext3()
```

C#

```
System.object GetNext3()
```

C++/CLI

```
System.Object^ GetNext3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetNext3](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNext4 Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetNext4 Method (IDisplayDimension)

Obsolete. Superseded by [IDisplayDimension::GetNext5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext4() As DisplayDimension
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As DisplayDimension  
  
value = instance.GetNext4()
```

C#

```
DisplayDimension GetNext4()
```

C++/CLI

```
DisplayDimension^ GetNext4();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetNext4](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNext5 Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetNext5 Method (IDisplayDimension)

Gets the next display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext5() As DisplayDimension
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As DisplayDimension

value = instance.GetNext5()
```

C#

```
DisplayDimension GetNext5()
```

C++/CLI

```
DisplayDimension^ GetNext5();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the next [IDisplayDimension](#) object

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetNext5](#).

Example

[Get Dimension Values in Drawing \(VBA\)](#)

Remarks

A dimension can be displayed multiple times. For example, a base-extrude dimension can be brought into three different views on a drawing. These three dimensions are referred to as display dimensions and are represented by the DisplayDimension object in the SOLIDWORKS API. The original base-extrude dimension is represented by the [IDimension](#) object in the SOLIDWORKS API.

Call this method after calling [IView::GetFirstDisplayDimension5](#).

This method displays:

- dimensions on both the sheet and sheet format.
- suppressed dimensions.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IView::GetFirstDisplayDimension5 Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetOrdinateDimensionArrowSize Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetOrdinateDimensionArrowSize Method (IDisplayDimension)

Gets the diameter of the circle for the arrow of the base ordinate dimension.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetOrdinateDimensionArrowSize( _
    ByRef UseDoc As System.Boolean, _
    ByRef ArrowSize As System.Double _
)
```

Visual Basic (Usage)

```
Dim instance As IDisplayDimension
Dim UseDoc As System.Boolean
Dim ArrowSize As System.Double

instance.GetOrdinateDimensionArrowSize(UseDoc, ArrowSize)
```



C#

```
void GetOrdinateDimensionArrowSize(  
    out System.bool UseDoc,  
    out System.double ArrowSize  
)
```

C++/CLI

```
void GetOrdinateDimensionArrowSize(  
& [Out] System.bool UseDoc,  
& [Out] System.double ArrowSize  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDoc

True to use the document setting for the diameter of the circle for the arrow of the base ordinate dimension, false to use the diameter of the circle for the arrow of the base ordinate dimension set by [IDisplayDimension::SetOrdinateDimensionArrowSize](#) if the base ordinate dimension standard is set to DIN

ArrowSize

Diameter of the circle for the arrow of the base ordinate dimension

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetOrdinateDimensionArrowSize](#).

Example

[Create Ordinate Dimensions \(C#\)](#)
[Create Ordinate Dimensions \(VB.NET\)](#)
[Create Ordinate Dimensions \(VBA\)](#)

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::AutoJogOrdinate Method \(\)](#)
[IDisplayDimension::DisplayAsChain Property \(\)](#)
[IDisplayDimension::Elevation Property \(\)](#)
[IDisplayDimension::Jogged Property \(\)](#)
[IDisplayDimension::EndSymbol Property \(\)](#)
[IDisplayDimension::GridBubble Property \(\)](#)
[IDisplayDimension::AddOrdinateDimension Method \(\)](#)
[IDrawingDoc::InsertOrdinate Method \(\)](#)
[IDrawingDoc::InsertHorizontalOrdinate Method \(\)](#)
[IDrawingDoc::InsertVerticalOrdinate Method \(\)](#)
[IDrawingDoc::CreateOrdinateDim4 Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetOverride Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetOverride Method (IDisplayDimension)

Gets whether to display the actual dimension value or to override it with another value.

.NET Syntax

Visual Basic (Declaration)

```
Function GetOverride() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean
```

```
value = instance.GetOverride()
```

C#

```
System.bool GetOverride()
```

C++/CLI

```
System.bool GetOverride();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True to display the override value, false to display the actual dimension value

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetOverride](#).

Remarks

Use [IDisplayDimension::GetOverrideValue](#) to get the override value.

Use [IDisplayDimension::SetOverride](#) to set whether to override the actual dimension value with another value and, if so, that value.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetOverrideValue Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetOverrideValue Method (IDisplayDimension)

Gets the value to display instead of the actual dimension value.

.NET Syntax

Visual Basic (Declaration)

```
Function GetOverrideValue() As System.Double
```

Visual Basic (Usage)

```
Dim instance As IDisplayDimension  
Dim value As System.Double  
  
value = instance.GetOverrideValue()
```

C#

```
System.double GetOverrideValue()
```

C++/CLI

```
System.double GetOverrideValue();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Value to display instead of the actual dimension value

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetOverrideValue](#).

Remarks

Use [IDisplayDimension::GetOverride](#) to get whether to display the actual dimension value or to override it with another value.

Use [IDisplayDimension::SetOverride](#) to set whether to override the actual dimension value with another value, and, if so, that value.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPrimaryPrecision Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetPrimaryPrecision Method (IDisplayDimension)

Obsolete. Superseded by [IDisplayDimension::GetPrimaryPrecision2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetPrimaryPrecision() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Integer  
  
value = instance.GetPrimaryPrecision()
```

C#

```
System.int GetPrimaryPrecision()
```

C++/CLI

```
System.int GetPrimaryPrecision();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetPrimaryPrecision](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPrimaryPrecision2 Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetPrimaryPrecision2 Method (IDisplayDimension)

Gets the primary dimension precision setting for this display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPrimaryPrecision2() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Integer  
  
value = instance.GetPrimaryPrecision2()
```

C#

```
System.int GetPrimaryPrecision2()
```

C++/CLI

```
System.int GetPrimaryPrecision2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Precision setting as defined by [swDimensionPrecisionSettings_e](#)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetPrimaryPrecision2](#).

Example

[Get Precisions for a Dimension \(VBA\)](#)

Remarks

If the return value equals swPrecisionFollowsDocumentSetting, then the precision being used is the document default for dual dimension values. You can retrieve the value using [IModelDocExtension::GetUserPreferenceInteger](#) with swDetailingLinearDimPrecision or swDetailingAngularDimPrecision. Otherwise, the return value is the precision in the dimensions primary units.

Use [IDisplayDimension::SetPrecision2](#) to set precision values on this display dimension.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetAlternatePrecision2 Method](#)
[IDisplayDimension::GetAlternateTolPrecision2 Method](#)
[IDisplayDimension::GetPrimaryTolPrecision2 Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPrimaryTolPrecision Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetPrimaryTolPrecision Method (IDisplayDimension)

Obsolete. Superseded by [IDisplayDimension::GetPrimaryTolPrecision2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetPrimaryTolPrecision() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Integer
```

```
value = instance.GetPrimaryTolPrecision()
```

C#

```
System.int GetPrimaryTolPrecision()
```

C++/CLI

```
System.int GetPrimaryTolPrecision();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetPrimaryTolPrecision](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPrimaryTolPrecision2 Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetPrimaryTolPrecision2 Method (IDisplayDimension)

Gets the primary tolerance precision setting for this display dimension.

NET Syntax

Visual Basic (Declaration)

```
Function GetPrimaryTolPrecision2() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Integer
```

```
value = instance.GetPrimaryTolPrecision2()
```

C#

```
System.int GetPrimaryTolPrecision2()
```

C++/CLI

```
System.int GetPrimaryTolPrecision2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Precision setting as defined by [swDimensionPrecisionSettings_e](#)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetPrimaryTolPrecision2](#).

Example

[Get Precisions for a Dimension \(VBA\)](#)

Remarks

If the return value equals `swPrecisionFollowsDocumentSetting`, then the precision being used is the document default for dual dimension values. You can retrieve the value using [IModelDocExtension::GetUserPreferenceInteger](#) with `swDetailingLinearTolPrecision` or `swDetailingAngularTolPrecision`.

If the return value is `swTolerancePrecisionFollowsNominal`, then the precision being used is the same as the precision being used for the dimension value. You can retrieve the value using [IDisplayDimension::GetPrimaryPrecision2](#)

Otherwise, the return value is the precision in the dimensions primary units.

Use [IDisplayDimension::SetPrecision2](#) to set the precision values on this display dimension.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension.GetAlternateTolPrecision2 Method](#)
[IDisplayDimension.GetAlternatePrecision2 Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRoundToFraction Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetRoundToFraction Method (IDisplayDimension)

Gets whether the displayed dimension value is rounded off so that SOLIDWORKS can display it as a fraction.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRoundToFraction() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.Boolean

value = instance.GetRoundToFraction()
```

C#

```
System.bool GetRoundToFraction()
```

C++/CLI

```
System.bool GetRoundToFraction();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True rounds off the displayed dimension value to a fraction, false does not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetRoundToFraction](#).

Remarks

The unit display settings of a display dimension are controlled by a value that SOLIDWORKS stores in one of two places: on the owning document or on the individual display dimension. Use [IDisplayDimension::GetUseDocUnits](#) to determine whether this `IDisplayDimension` uses the document default or a specific value set for this `IDisplayDimension`.

If this display dimension uses local unit information, then the return value indicates whether the displayed value of this dimension is rounded off to a value that SOLIDWORKS can represent as a fraction.

Fraction display is valid only for unit types `swINCHES` or `swFEETINCHES`. In all other cases, this method returns -1. Use [IDisplayDimension::SetUnits](#) to set the units settings of a display dimension.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[GetFractionBase Method](#)
[GetFractionValue Method](#)
[IDisplayDimension::GetUnits Method](#)
[IDisplayDimension::GetUseDocUnits Method](#)
[IDisplayDimension::SetUnits Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSecondArrow Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetSecondArrow Method (IDisplayDimension)

Gets whether this diameter display dimension has the second arrow enabled.

NET Syntax

Visual Basic (Declaration)

```
Function GetSecondArrow() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean  
  
value = instance.GetSecondArrow()
```

C#

```
System.bool GetSecondArrow()
```

C++/CLI

```
System.bool GetSecondArrow();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the second arrow is displayed, false if the second arrow is not displayed (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetSecondArrow](#).

Remarks

For diameter dimensions, the second outside arrow is the arrow that appears on the opposite side of the arc from the dimension text. This occurs only when the text is outside of the arc.

Display of this arrow is optional, and is controlled by a value stored in one of two places: on the owning document or on the individual display dimension. Use [IDisplayDimension::GetUseDocSecondArrow](#) to determine whether the document or the individual display dimension is controlling the second arrow display.

The return value from this method is not valid when the document is controlling the display of second arrows.

This method applies only to diameter dimensions. If this method is executed on any other type of dimension, SOLIDWORKS returns false.

Use [IDisplayDimension::SetSecondArrow](#) to set the second arrow values.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetUseDocSecondArrow Method](#)
[IDisplayDimension::SetSecondArrow Method](#)
[IDisplayDimension::ArrowSide Property](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSupportsGenericText Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetSupportsGenericText Method (IDisplayDimension)

Gets whether the display dimension was created in SOLIDWORKS 2011 or later, which, if so, indicates that the display dimension is generic text.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSupportsGenericText() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.Boolean

value = instance.GetSupportsGenericText()
```

C#

```
System.bool GetSupportsGenericText()
```

C++/CLI

```
System.bool GetSupportsGenericText();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the display dimension was created in SOLIDWORKS 2011 or later and is generic text, false if the display dimension was created in an earlier release of SOLIDWORKS and is dimension text.

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetSupportsGenericText](#).

Example

[Get SOLIDWORKS Version of Display Dimension \(C#\)](#)
[Get SOLIDWORKS Version of Display Dimension \(VB.NET\)](#)
[Get SOLIDWORKS Version of Display Dimension \(VBA\)](#)

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

Availability

SOLIDWORKS 2011 SP4, Revision 19.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetText Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetText Method (IDisplayDimension)

Gets the text above the dimension line in a display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function GetText( _  
    ByVal WhichText As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim WhichText As System.Integer  
Dim value As System.String  
  
value = instance.GetText(WhichText)
```

C#

```
System.string GetText(  
    System.int WhichText  
)
```

C++/CLI

```
System.String^ GetText(  
& System.int WhichText  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichText

Aspect of the text to get as defined in [swDimensionTextParts_e](#) (see **Remarks**)

Return Value

Text above the dimension line

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetText](#).

Example

[Get Block Information \(VBA\)](#)
[Get Dimension Values in Drawing \(VBA\)](#)
[Get Whether Display Dimension is a Hole Callout \(VBA\)](#)

Remarks

swDimensionTextParts_e.swDimensionTextAll is not a valid value for the WhichText parameter for this method.

NOTE: This method does not support [hole callouts](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::SetText Method \(\)](#)
[IDisplayDimension::GetLowerText Method \(\)](#)
[IDisplayDimension::SetLowerText Method \(\)](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextFormat Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetTextFormat Method (IDisplayDimension)

Obsolete. Superseded by [IAnnotation::GetTextFormat](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextFormat() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Object  
  
value = instance.GetTextFormat()
```

C#

```
System.object GetTextFormat()
```

C++/CLI

```
System.Object^ GetTextFormat();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetTextFormat](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextFormatItems Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetTextFormatItems Method (IDisplayDimension)

Gets the format tokens of the specified text portion of a multi-value display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextFormatItems(  
    ByVal WhichText As System.Integer, _  
    ByRef TokensDefinition As System.Object, _  
    ByRef TokensEvaluated As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim WhichText As System.Integer  
Dim TokensDefinition As System.Object  
Dim TokensEvaluated As System.Object  
Dim value As System.Integer  
  
value = instance.GetTextFormatItems(WhichText, TokensDefinition, TokensEvaluated)
```

C#

```
System.int GetTextFormatItems(  
    System.int WhichText,  
    out System.object TokensDefinition,  
    out System.object TokensEvaluated  
)
```

C++/CLI

```
System.int GetTextFormatItems(  
& System.int WhichText,  
& [Out] System.Object^ TokensDefinition,
```

```
& [Out] System.Object^ TokensEvaluated
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichText

Portion of the display dimension text as defined in [swDimensionTextParts](#) e

TokensDefinition

Array of strings containing format symbols for the text portion specified in WhichText

TokensEvaluated

Array of strings containing evaluations of symbols in TokensDefinition

Return Value

Size of returned arrays

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetTextFormatItems](#).

Example

[Get Chamfer Display Dimension \(C#\)](#)

[Get Chamfer Display Dimension \(VB.NET\)](#)

[Get Chamfer Display Dimension \(VBA\)](#)

Remarks

Each display dimension's PropertyManager page contains a section called Dimension Text that specifies the format of the displayed dimension. The format consists of function symbols or tokens enclosed within angle brackets (e.g., <DIM>), each of which connotes the function or definition of the value symbols that follow it.

This method retrieves all of the symbols, both function and value, for the portion of the display dimension text specified by WhichText. It also retrieves values for any symbols that can be evaluated in TokensDefinition.

NOTE: This method does not support [hole callouts](#).

See Also

[IDisplayDimension Interface](#)

[IDisplayDimension Members](#)

[IDisplayDimension::GetText Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetType Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetType Method (IDisplayDimension)

Obsolete. Superseded by [IDisplayDimension::Type2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
```

```
Dim value As System.Integer
```

```
value = instance.GetType()
```

C#

```
System.int GetType()
```

C++/CLI

```
System.int GetType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Dimension type as defined in [swDimensionType_e](#)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetType](#).

Remarks

Radial and diametric dimensions both return `swRadialDimension`. To determine how this radial dimension is currently displayed, use [IDisplayDimension::Diametric](#) and [IDisplayDimension::DisplayAsLinear](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::Type2 Property](#)
[IDisplayDimension::Diametric Property](#)

Availability

SOLIDWORKS 99 SP06, datecode 1999355

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUnits Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetUnits Method (IDisplayDimension)

Gets the units used by this display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUnits() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Integer  
  
value = instance.GetUnits()
```

C#

```
System.int GetUnits()
```

C++/CLI

```
System.int GetUnits();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Units for this display dimension as defined in [swLengthUnit_e](#) or [swAngleUnit_e](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetUnits](#).

Remarks

A display dimension's units are controlled by a value stored in one of two places:

- document setting.
- or -
- local display dimension setting.

Use [IDisplayDimension::GetUseDocUnits](#) to determine whether the display dimension's settings are from the document setting or local display dimension setting.

If the display dimension uses...	Then IDisplayDimension::GetUnits returns...
Document setting	-1
Local display dimension setting	swLengthUnit_e or swAngleUnit_e value

Use [IDisplayDimension::SetUnits](#) to set the display dimension's unit setting.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetChamferUnits Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUseDocArrowHeadStyle Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetUseDocArrowHeadStyle Method (IDisplayDimension)

Gets whether this display dimension uses the document default setting for dimension arrowhead style.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUseDocArrowHeadStyle() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.Boolean

value = instance.GetUseDocArrowHeadStyle()
```

C#

```
System.bool GetUseDocArrowHeadStyle()
```

C++/CLI

```
System.bool GetUseDocArrowHeadStyle();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this display dimension uses the document setting, false if it uses the local display dimension setting

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetUseDocArrowHeadStyle](#).

Remarks

The arrowhead style for a display dimension is controlled by a value stored in one of two places: on the owning document or on the individual display dimension. This method gets the setting that indicates which setting is currently in use.

Use [IDisplayDimension::SetArrowHeadStyle2](#) to set this value.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetArrowHeadStyle2 Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUseDocBentLeaderLength Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetUseDocBentLeaderLength Method (IDisplayDimension)

Gets whether this dimension is using the document default for bent leader length or not.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUseDocBentLeaderLength() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean  
  
value = instance.GetUseDocBentLeaderLength()
```

C#

```
System.bool GetUseDocBentLeaderLength()
```

C++/CLI

```
System.bool GetUseDocBentLeaderLength();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if using the document default setting for dimension bent leader length, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetUseDocBentLeaderLength](#).

Remarks

This method returns whether the document default setting is being used or not, regardless of how the dimension is currently being displayed. Even if the dimension is not currently being displayed with a bent leader, this method returns the value.

Use [IDisplayDimension::GetBentLeaderLength](#) to determine the bent leader length for this dimension.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::SetBentLeaderLength Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUseDocBrokenLeader Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetUseDocBrokenLeader Method (IDisplayDimension)

Gets whether this display dimension uses the document default setting for displaying leaders as broken.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUseDocBrokenLeader() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.Boolean

value = instance.GetUseDocBrokenLeader()
```

C#

```
System.bool GetUseDocBrokenLeader()
```

C++/CLI

```
System.bool GetUseDocBrokenLeader();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this display dimension uses the document setting, false if it uses a specific setting

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetUseDocBrokenLeader](#).

Remarks

SOLIDWORKS can display dimension text above a solid, unbroken leader line, or the dimension leader line can be broken with the text displayed either horizontal or aligned with the leader line. This method allows you to determine if this [IDisplayDimension](#) is using the document default setting for this value or if the user has applied a specific setting to this specific IDisplayDimension.

Use [IDisplayDimension::SetBrokenLeader2](#) to set this value.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetBrokenLeader2 Method](#)
[IDisplayDimension::SolidLeader Property](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUseDocDual Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetUseDocDual Method (IDisplayDimension)

Gets whether this display dimension uses the document setting for positioning dual dimensions.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUseDocDual() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.Boolean

value = instance.GetUseDocDual()
```

C#

```
System.bool GetUseDocDual()
```

C++/CLI

```
System.bool GetUseDocDual();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this display dimension uses its dual dimension's top, bottom, right, or left document setting, false if the display dimension uses a setting opposite of the dual dimension's top, bottom, right, or left document setting

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetUseDocDual](#).

Remarks

Use [IDisplayDimension::SetDual](#) to set the dual dimension's top, bottom, right, or left setting for this display dimension.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::Split Property\(\)](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUseDocPrecision Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetUseDocPrecision Method (IDisplayDimension)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUseDocPrecision() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.Boolean

value = instance.GetUseDocPrecision()
```

C#

```
System.bool GetUseDocPrecision()
```

C++/CLI

```
System.bool GetUseDocPrecision();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetUseDocPrecision](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUseDocSecondArrow Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetUseDocSecondArrow Method (IDisplayDimension)

Gets whether this diameter display dimension uses the document default setting for the display of the second outside arrow.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUseDocSecondArrow() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.Boolean

value = instance.GetUseDocSecondArrow()
```

C#

```
System.bool GetUseDocSecondArrow()
```

C++/CLI

```
System.bool GetUseDocSecondArrow();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this display dimension uses the document setting, false if it uses the local setting

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetUseDocSecondArrow](#).

Remarks

For diameter dimensions, the second outside arrow is the arrow that appears on the opposite side of the arc from the dimension text. This occurs only when the text is outside of the arc.

This method determines whether this display dimension uses the default document setting for second arrow display.

This method applies only to diameter dimensions. If you execute this method for any other types of dimensions, SOLIDWORKS returns false.

Use [IDisplayDimension::SetSecondArrow](#) to set this value.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::ArrowSide Property](#)
[IDisplayDimension::GetSecondArrow Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

GetUseDocTextFormat Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetUseDocTextFormat Method (IDisplayDimension)

Obsolete. Superseded by [IAnnotation::GetUseDocTextFormat](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetUseDocTextFormat() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean  
  
value = instance.GetUseDocTextFormat()
```

C#

```
System.bool GetUseDocTextFormat()
```

C++/CLI

```
System.bool GetUseDocTextFormat();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetUseDocTextFormat](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

GetUseDocUnits Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetUseDocUnits Method (IDisplayDimension)

Gets whether this display dimension uses the document default setting for units.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUseDocUnits() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean  
  
value = instance.GetUseDocUnits()
```

C#

```
System.bool GetUseDocUnits()
```

C++/CLI

```
System.bool GetUseDocUnits();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this display dimension uses the document setting, false if it uses the local display dimension setting

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetUseDocUnits](#).

Example

[Get Chamfer Display Dimension \(C#\)](#)
[Get Chamfer Display Dimension \(VB.NET\)](#)
[Get Chamfer Display Dimension \(VBA\)](#)

Remarks

The unit display settings of a display dimension are controlled by a value stored in one of two places: on the owning document or on the individual display dimension. This method determines whether this display dimension uses the default document setting for units.

Use [IDisplayDimension::SetUnits](#) to set this value.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetUnits Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetWitnessLineGap Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GetWitnessLineGap Method (IDisplayDimension)

Gets the gap of the specified dimension extension line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetWitnessLineGap( _  
    ByVal WitnessIndex As System.Short, _  
    ByRef UseDoc As System.Boolean, _  
    ByRef Gap As System.Double _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim WitnessIndex As System.Short  
Dim UseDoc As System.Boolean  
Dim Gap As System.Double  
Dim value As System.Boolean  
  
value = instance.GetWitnessLineGap(WitnessIndex, UseDoc, Gap)
```

C#

```
System.bool GetWitnessLineGap(  
    System.short WitnessIndex,  
    out System.bool UseDoc,  
    out System.double Gap  
)
```

C++/CLI

```
System.bool GetWitnessLineGap(
& System.short WitnessIndex,
& [Out] System.bool UseDoc,
& [Out] System.double Gap
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WitnessIndex

Index of the extension line whose gap to get

UseDoc

True if using the document default value of the gap, false if not (see **Remarks**)

Gap

Gap value in system units (see **Remarks**)

Return Value

True if the operation succeeds, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GetWitnessLineGap](#).

Example

[Get and Set Dimension Extension Lines Gap \(VBA\)](#)

Remarks

The UseDoc argument is dependent on the detailing standard. You can retrieve the document default value using the [document-level user-preference swDetailingWitnessLineGap](#).

The Gap argument is the document default value if UseDoc is true; otherwise, the value returned is the locally set value.

See Also

[IDisplayDimension Interface](#)

[IDisplayDimension Members](#)

[IDisplayDimension::SetWitnessLineGap Method](#)

[IView::GetDimensionInfo6 Method](#)

[IView::IGetDimensionInfo6 Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GridBubble Property (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : GridBubble Property (IDisplayDimension)

Gets or sets whether to display a grid bubble at the end of ordinate dimension extension lines.

.NET Syntax

Visual Basic (Declaration)

```
Property GridBubble As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
```

```
Dim value As System.Boolean
```

```
instance.GridBubble = value
```

```
value = instance.GridBubble
```

C#

```
System.bool GridBubble {get; set;}
```

C++/CLI

```
property System.bool GridBubble {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to display a grid bubble at the end of ordinate dimension extension lines, false to not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::GridBubble](#).

Example

[Display Grid Bubble \(VBA\)](#)

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::AutoJogOrdinate Method](#)
[IDisplayDimension::DisplayAsChain Property](#)
[IDisplayDimension::Elevation Property](#)
[IDisplayDimension::EndSymbol Property](#)
[IDisplayDimension::Jogged Property](#)
[IDisplayDimension::GetOrdinateDimensionArrowSize Method](#)
[IDisplayDimension::SetOrdinateDimensionArrowSize Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

HorizontalJustification Property (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : HorizontalJustification Property (IDisplayDimension)

Gets or sets the dimension text's horizontal justification.

.NET Syntax

Visual Basic (Declaration)

```
Property HorizontalJustification As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Integer  
  
instance.HorizontalJustification = value  
value = instance.HorizontalJustification
```

C#

```
System.int HorizontalJustification {get; set;}
```

C++/CLI

```
property System.int HorizontalJustification {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Horizontal justification as defined in [swTextJustification_e](#)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::HorizontalJustification](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::VerticalJustification Property](#)
[IDisplayDimension::AddDisplayText Method](#)
[IDisplayDimension::IAddDisplayText Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAddDisplayEnt Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : IAddDisplayEnt Method (IDisplayDimension)

Overrides the display graphics of objects for this display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function IAddDisplayEnt( _
    ByVal Type As System.Integer, _
    ByRef Data As System.Double _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim Type As System.Integer
Dim Data As System.Double
Dim value As System.Boolean

value = instance.IAddDisplayEnt(Type, Data)
```

C#

```
System.bool IAddDisplayEnt(
    System.int Type,
    ref System.double Data
)
```

C++/CLI

```
System.bool IAddDisplayEnt(
    & System.int Type,
    & System.double% Data
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Type

Type of graphical entity (see [Remarks](#))

Data

- in-process, unmanaged C++: Pointer to an array of geometric data describing the entity (see **Remarks**)

VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

True if successful, false if not

Remarks

The new graphics displayed by this method are temporary. When the user changes the dimension, this display dimension reverts back to the SOLIDWORKS standard.

The type controls which geometry is added and what information is placed in the data array. All colors and line styles are taken from IDisplayDimension.

type	Description	data
1	Line	6 doubles; (x, y, z) start point and (x, y, z) end point
2	Filled triangle	9 doubles; 3 (x, y, z) points of the triangle to fill
3	Filled 4 sided polygon	12 doubles; 4 (x, y, z) points of the polygon to fill
4	Arc	12 doubles; (x, y, z) center point, (x, y, z) normal vector, (x, y, z) start point and (x, y, z) end point
5	Circle	7 doubles; (x, y, z) center point, (x, y, z) normal vector and radius
6	Filled dot	4 doubles; (x, y, z) center point and radius

The size of the array is the size of the expected returned array.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::AddDisplayEnt Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAddDisplayText Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : IAddDisplayText Method (IDisplayDimension)

Overrides the display text for this display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function IAddDisplayText( _  
    ByVal Text As System.String, _  
    ByRef Position As System.Double, _  
    ByVal Format As TextFormat, _  
    ByVal Attachment As System.Integer, _  
    ByVal WidthFactor As System.Double _  
    ) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IDisplayDimension  
Dim Text As System.String  
Dim Position As System.Double  
Dim Format As TextFormat  
Dim Attachment As System.Integer  
Dim WidthFactor As System.Double  
Dim value As System.Boolean  
  
value = instance.IAddDisplayText(Text, Position, Format, Attachment, WidthFactor)
```



C#

```
System.bool IAddDisplayText(  
    System.string Text,  
    ref System.double Position,  
    TextFormat Format,  
    System.int Attachment,  
    System.double WidthFactor  
)
```

C++/CLI

```
System.bool IAddDisplayText(  
& System.String^ Text,  
& System.double% Position,  
& TextFormat^ Format,  
& System.int Attachment,  
& System.double WidthFactor  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Text

Text to display

Position

Location of the text; pointer to an array of 3 doubles

Format

Pointer to [ITextFormat](#) object

Attachment

Justification of the text as defined in [swTextJustification e](#)

WidthFactor

Horizontal scale factor of the text

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::IAddDisplayText](#).

Remarks

The new graphics displayed by this method are temporary. When the user changes the dimension, this display dimension reverts back to the SOLIDWORKS standard.

See Also

[IDisplayDimension Interface](#)

[IDisplayDimension Members](#)

[IDisplayDimension::AddDisplayText Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetAnnotation Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : IGetAnnotation Method (IDisplayDimension)

Gets the [IAnnotation](#) object for this specific annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetAnnotation() As Annotation
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As Annotation

value = instance.IGetAnnotation()
```

C#

```
Annotation IGetAnnotation()
```

C++/CLI

```
Annotation^ IGetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [IAnnotation](#) object

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::IGetAnnotation](#).

Remarks

The [IAnnotation](#) object is a higher-level object that contains methods that are general to all types of annotations.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetAnnotation Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDimension Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : IGetDimension Method (IDisplayDimension)

Obsolete. Superseded by [IDisplayDimension::GetDimension2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDimension() As Dimension
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As Dimension

value = instance.IGetDimension()
```

C#

```
Dimension IGetDimension()
```

C++/CLI

```
Dimension^ IGetDimension();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to an [IDimension](#) object

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::IGetDimension](#).

Remarks

SOLIDWORKS can display a dimension more than once. For example, a base-extrude dimension can be brought into three different views on a drawing. These three dimensions are referred to as display dimensions and are represented by the [IDisplayDimension](#) object in the SOLIDWORKS API. The original base-extrude dimension is represented by the [IDimension](#) object in the SOLIDWORKS API.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetDimension Method](#)
[IFeature::IParameter Method](#)
[IFeature::Parameter Method](#)
[IModelDoc2::IParameter Method](#)
[IModelDoc2::Parameter Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDisplayData Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : IGetDisplayData Method (IDisplayDimension)

Gets the display data for this display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDisplayData() As DisplayData
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As DisplayData  
  
value = instance.IGetDisplayData()
```

C#

```
DisplayData IGetDisplayData()
```

C++/CLI

```
DisplayData^ IGetDisplayData();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [IDisplayData](#) object

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::IGetDisplayData](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetDisplayData Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNext Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : IGetNext Method (IDisplayDimension)

Obsolete. Superseded by [IDisplayDimension::GetNext5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNext() As DisplayDimension
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As DisplayDimension  
  
value = instance.IGetNext()
```

C#

```
DisplayDimension IGetNext()
```

C++/CLI

```
DisplayDimension^ IGetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::IGetNext](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetNext2 Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : IGetNext2 Method (IDisplayDimension)

Obsolete. Superseded by [IDisplayDimension::GetNext5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNext2() As DisplayDimension
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As DisplayDimension  
  
value = instance.IGetNext2()
```

C#

```
DisplayDimension IGetNext2()
```

C++/CLI

```
DisplayDimension^ IGetNext2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::IGetNext2](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetNext3 Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : IGetNext3 Method (IDisplayDimension)

Obsolete. Superseded by [IDisplayDimension::GetNext5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNext3() As DisplayDimension
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As DisplayDimension  
  
value = instance.IGetNext3()
```

C#

```
DisplayDimension IGetNext3()
```

C++/CLI

```
DisplayDimension^ IGetNext3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::IGetNext3](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTextFormat Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : IGetTextFormat Method (IDisplayDimension)

Obsolete. Superseded by [IAnnotation::IGetTextFormat](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTextFormat() As TextFormat
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As TextFormat  
  
value = instance.IGetTextFormat()
```

C#

```
TextFormat IGetTextFormat()
```

C++/CLI

```
TextFormat^ IGetTextFormat();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::IGetTextFormat](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Inspection Property (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : Inspection Property (IDisplayDimension)

Gets or sets whether a display dimension above the dimension line is displayed as an inspection dimension.

.NET Syntax

Visual Basic (Declaration)

```
Property Inspection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean  
  
instance.Inspection = value  
value = instance.Inspection
```

C#

```
System.bool Inspection {get; set;}
```

C++/CLI

```
property System.bool Inspection {  
    System.bool get();  
    void set ( &    System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the display dimension above the dimension line is displayed as an inspection dimension, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::Inspection](#).

Remarks

An inspection dimension is contained within an oval.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetText Method \(\)](#)
[IDisplayDimension::SetText Method \(\)](#)
[IDisplayDimension::LowerInspection Property \(\)](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsDimXpert Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : IsDimXpert Method (IDisplayDimension)

Obsolete. Superseded by [IAnnotation::IsDimXpert](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IsDimXpert() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean  
  
value = instance.IsDimXpert()
```

C#

```
System.bool IsDimXpert()
```

C++/CLI

```
System.bool IsDimXpert();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the display dimension is a DimXpert dimension, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::IsDimXpert](#).

Example

[Get DimXpert Display Dimensions and Feature \(C#\)](#)
[Get DimXpert Display Dimensions and Feature \(VB.NET\)](#)
[Get DimXpert Display Dimensions and Feature \(VBA\)](#)

Remarks

Use this method to determine if the display dimension is a DimXpert display dimension. If it is, then use [IAnnotation::GetDimXpertFeature](#) to access the DimXpert feature, which provides access to the display dimension information.

DimXpert dimensions can be hidden shown or hidden as a group, which can be important when exporting to a DXF/DWG file.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IAnnotation::IsDimXpert Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetTextFormat Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : ISetTextFormat Method (IDisplayDimension)

Obsolete. Superseded by [IAnnotation::ISetTextFormat](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ISetTextFormat( _  
    ByVal TextFormatType As System.Integer, _  
    ByVal TextFormat As TextFormat _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim TextFormatType As System.Integer  
Dim TextFormat As TextFormat  
Dim value As System.Boolean  
  
value = instance.ISetTextFormat(TextFormatType, TextFormat)
```

C#

```
System.bool ISetTextFormat(  
    System.int TextFormatType,  
    TextFormat TextFormat  
)
```

C++/CLI

```
System.bool ISetTextFormat(  
& System.int TextFormatType,  
& TextFormat^ TextFormat  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TextFormatType

TextFormat

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::ISetTextFormat](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsHoleCallout Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : IsHoleCallout Method (IDisplayDimension)

Gets whether this display dimension is a hole callout.

.NET Syntax

Visual Basic (Declaration)

```
Function IsHoleCallout() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.Boolean

value = instance.IsHoleCallout()
```

C#

```
System.bool IsHoleCallout()
```

C++/CLI

```
System.bool IsHoleCallout();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the display dimension is a hole callout, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::IsHoleCallout](#).

Example

[Get Whether Display Dimension is a Hole Callout \(VBA\)](#)

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDrawingDoc::AddHoleCallout2 Method \(\)](#)
[IDrawingDoc::AddHoleCallout2 Method \(\)](#)
[IDisplayDimension::GetHoleCalloutVariables Method \(\)](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsLinked Property (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : IsLinked Property (IDisplayDimension)

Gets whether the dimension has text linked to it.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property IsLinked As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.Boolean

value = instance.IsLinked
```

C#

```
System.bool IsLinked {get;}
```

C++/CLI

```
property System.bool IsLinked {
    System.bool get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the text is linked to the dimension, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::IsLinked](#).

Example

[Unlink Dimensions \(VBA\)](#)

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetLinkedText Method](#)
[IDisplayDimension::SetLinkedText Method](#)
[IDisplayDimension::Unlink Method](#)

Availability

SOLIDWORKS 2003 SP2, Revision Number 11.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsReferenceDim Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : IsReferenceDim Method (IDisplayDimension)

Gets whether this display dimension is a reference dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function IsReferenceDim() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean  
  
value = instance.IsReferenceDim()
```

C#

```
System.bool IsReferenceDim()
```

C++/CLI

```
System.bool IsReferenceDim();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this display dimension is a reference dimension, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::IsReferenceDim](#).

Example

[Add Reference Dimension \(C#\)](#)
[Add Reference Dimension \(VB.NET\)](#)
[Add Reference Dimension \(VBA\)](#)

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDimension::IsReference Method \(\)](#)
[IDrawingDoc::InsertRefDim Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Jogged Property (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : Jogged Property (IDisplayDimension)

Gets or sets whether this ordinate or angular running dimension is jogged.

.NET Syntax

Visual Basic (Declaration)

Property Jogged As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean
```

```
instance.Jogged = value
```

```
value = instance.Jogged
```

C#

```
System.bool Jogged {get; set;}
```

C++/CLI

```
property System.bool Jogged {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if dimension is jogged, false if it is not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::Jogged](#).

Example

[Insert Angular Running Dimension \(VBA\)](#)
[Insert Angular Running Dimension \(VB.NET\)](#)
[Insert Angular Running Dimension \(C#\)](#)

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::AutoJogOrdinate Method](#)
[IDisplayDimension::DisplayAsChain Property](#)
[IDisplayDimension::Elevation Property](#)
[IDisplayDimension::EndSymbol Property](#)
[IDisplayDimension::GridBubble Property](#)
[IDisplayDimension::ExtensionLineExtendsFromCenterOfSet Property](#)
[IDisplayDimension::RunBidirectionally Property](#)
[IDisplayDimension::ExtensionLineSameAsLeaderStyle Property](#)
[IDisplayDimension::ExtensionLineUseDocumentDisplay Property](#)
[IDisplayDimension::ResetExtensionLineStyle Property](#)

[IModelDocExtension::AddOrdinateDimension Method](#)
[IDisplayDimension::SetOrdinateDimensionArrowSize Method](#)
[IDisplayDimension::GetOrdinateDimensionArrowSize Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LeaderVisibility Property (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : LeaderVisibility Property (IDisplayDimension)

Gets or sets which leader lines (dimension lines) are visible on a display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Property LeaderVisibility As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Integer  
  
instance.LeaderVisibility = value  
value = instance.LeaderVisibility
```

C#

```
System.int LeaderVisibility {get; set;}
```

C++/CLI

```
property System.int LeaderVisibility {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Leader visibility state as defined in [swLeaderLineVisibility_e](#)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::LeaderVisibility](#).

Example

[Get Display Dimension Properties \(VBA\)](#)

Remarks

After using this property, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

LowerInspection Property (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : LowerInspection Property (IDisplayDimension)

Gets or sets whether a display dimension below the dimension line is displayed as an inspection dimension.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property LowerInspection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.Boolean

instance.LowerInspection = value
value = instance.LowerInspection
```

C#

```
System.bool LowerInspection {get; set;}
```

C++/CLI

```
property System.bool LowerInspection {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the display dimension below the dimension is displayed as an inspection dimension, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::LowerInspection](#).

Example

[Get Chamfer Display Dimension \(C#\)](#)
[Get Chamfer Display Dimension \(VB.NET\)](#)
[Get Chamfer Display Dimension \(VBA\)](#)

Remarks

An inspection dimension is contained within an oval.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetLowerText Method \(\)](#)
[IDisplayDimension::SetLowerText Method \(\)](#)
[IDisplayDimension::Inspection Property \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MarkedForDrawing Property (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : MarkedForDrawing Property (IDisplayDimension)

Gets or sets whether this display dimension is marked to include in a drawing document.

Visual Basic Syntax

Visual Basic (Declaration)

Property MarkedForDrawing As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean  
  
instance.MarkedForDrawing = value  
value = instance.MarkedForDrawing
```

C#

```
System.bool MarkedForDrawing {get; set;}
```

C++/CLI

```
property System.bool MarkedForDrawing {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the display dimension is marked to include in the drawing document, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::MarkedForDrawing](#).

Example

[Determine if Display Dimension Marked for Drawing \(VBA\)](#)

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

MaxWitnessLineLength Property (IDisplayDimension)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : MaxWitnessLineLength Property (IDisplayDimension)

Gets or sets the maximum length of dimension extension lines.

.NET Syntax

Visual Basic (Declaration)

```
Property MaxWitnessLineLength As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Double  
  
instance.MaxWitnessLineLength = value  
value = instance.MaxWitnessLineLength
```

C#

```
System.double MaxWitnessLineLength {get; set;}
```

C++/CLI

```
property System.double MaxWitnessLineLength {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Length

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::MaxWitnessLineLength](#).

Example

[Set and Get Maximum Extension Line Length \(VBA\)](#)

Remarks

After using this property, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::SmartWitness Property](#)
[IDisplayDimension::WitnessVisibility Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

OffsetText Property (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : OffsetText Property (IDisplayDimension)

Gets or sets whether or not to offset the text of a dimension.

.NET Syntax

Visual Basic (Declaration)

```
Property OffsetText As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean  
  
instance.OffsetText = value  
  
value = instance.OffsetText
```

C#

```
System.bool OffsetText {get; set;}
```

C++/CLI

```
property System.bool OffsetText {  
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to offset the dimension text, false to not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::OffsetText](#).

Remarks

If this property is set to...	Then...
True	- Dimension text is attached to the end of a leader that can be moved about freely. - Dimension line and extension lines to which the dimension text is associated do not move.
false	- Dimension text is displayed on the dimension line. - Dimension line and extension lines can move when the dimension text is moved.

Because radial and diametric dimensions are already attached to the end of a leader, this property is not available for these types of dimensions.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetText Method](#)
[IDisplayDimension::SetText Method](#)

Availability

SOLIDWORKS 2004 SP4, Revision Number 12.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

ResetExtensionLineStyle Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : ResetExtensionLineStyle Method (IDisplayDimension)

Resets the style of the specified extension line.

.NET Syntax

Visual Basic (Declaration)

```
Function ResetExtensionLineStyle( _  
    ByVal ExtIndex As System.Short _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim ExtIndex As System.Short  
Dim value As System.Boolean  
  
value = instance.ResetExtensionLineStyle(ExtIndex)
```

C#

```
System.bool ResetExtensionLineStyle(  
    System.short ExtIndex  
)
```

C++/CLI

```
System.bool ResetExtensionLineStyle(  
& System.short ExtIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ExtIndex
Index of extension line

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::ResetExtensionLineStyle](#).

Remarks

Call this method to reset the extension line style if you previously called [DisplayDimension::SetExtensionLineAsCenterline](#) to set the extension line as a centerline. This method corresponds to the extension line's shortcut menu item **Reset extension line style**, which appears after you select the extension line's shortcut menu item **Set extension line as centerline**.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[DisplayDimension::ExtensionLineExtendsFromCenterOfSet Property \(\)](#)
[DisplayDimension::ExtensionLineSameAsLeaderStyle Property \(\)](#)
[IDisplayDimension::ExtensionLineUseDocumentDisplay Property \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RunBidirectionally Property (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : RunBidirectionally Property (IDisplayDimension)

Gets or sets whether each dimension runs in a direction closest to the baseline in this angular running dimension.

.NET Syntax

Visual Basic (Declaration)

```
Property RunBidirectionally As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean  
  
instance.RunBidirectionally = value  
  
value = instance.RunBidirectionally
```

C#

```
System.bool RunBidirectionally {get; set;}
```

C++/CLI

```
property System.bool RunBidirectionally {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if each dimension runs in a direction closest to the baseline, false if all dimensions run in the same direction (see **Remarks**)

 Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::RunBidirectionally](#).

 Example

[Insert Angular Running Dimension \(VBA\)](#)
[Insert Angular Running Dimension \(VB.NET\)](#)
[Insert Angular Running Dimension \(C#\)](#)

 Remarks

If this property is...	Then...
True	No angle dimension in the angular running dimension is greater than 180° from the baseline, and each angle is measured from a direction that is closest to the baseline.
False	The running direction of all angle dimensions is determined by the first angle dimension added. For example, if the user places the baseline dimension at the top of the part, clicking on a feature to the right of the baseline dimension forces all subsequent angular dimensions to be measured clockwise from the baseline.

This property corresponds to the **Run bidirectionally** check box in the **Witness/Leader Display** panel of the **Leaders** tab of the **Dimension** PropertyManager page that appears when you right-click in a drawing and select **More Dimensions > Angular Running Dimension**.

 See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::DisplayAsChain Property \(\)](#)
[IDisplayDimension::ExtensionLineExtendsFromCenterOfSet Property \(\)](#)
[IDisplayDimension::Jogged Property \(\)](#)

 Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0