

SOLIDWORKS API (.NET VBA C#) — Reference

(78/337): IDisplayDimension (part 3 of 3)

SOLIDWORKS API Documentation (converted from CHM)

IDisplayDimension (part 3 of 3) (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Scale2 Property (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : Scale2 Property (IDisplayDimension)

Gets or sets the scale value that is applied to the dimension value of this non-associative distance dimension.

.NET Syntax

Visual Basic (Declaration)

Property Scale2 As System.Double

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Double
```

```
instance.Scale2 = value
```

```
value = instance.Scale2
```

C#

```
System.double Scale2 {get; set;}
```

C++/CLI

```
property System.double Scale2 {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Scale applied to the dimension value

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::Scale2](#).

Remarks

This scale value applies only to non-associative distance dimensions, such as those created using [IDrawingDoc::CreateLinearDim4](#) or [IDrawingDoc::CreateDiamDim4](#). For these dimensions, SOLIDWORKS multiplies the actual dimension measurement by this scale value to get the dimension value that is displayed on the screen. For any other types of dimensions (such as associative dimensions or angular measuremer dimensions), setting the scale factor has no effect and getting the scale factor will always return 1.

The scale value must be greater than 0. This has no effect in the OLE interface, and returns S_false in the COM interface.

After using this property, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetArcLengthLeader Method (IDisplayDimension)

[See Also](#)



Sets the leader style of this arc-length dimension.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function SetArcLengthLeader( _  
    ByVal AutoLeader As System.Boolean, _  
    ByVal LeaderType As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim AutoLeader As System.Boolean  
Dim LeaderType As System.Integer  
Dim value As System.Integer
```

```
value = instance.SetArcLengthLeader(AutoLeader, LeaderType)
```

C#

```
System.int SetArcLengthLeader(  
    System.bool AutoLeader,  
    System.int LeaderType  
)
```

C++/CLI

```
System.int SetArcLengthLeader(  
& System.bool AutoLeader,  
& System.int LeaderType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AutoLeader

True if the leader style is automatically selected, false if the leader style is selected by the user

LeaderType

Leader style as defined in [swArcLengthLeaderType_e](#) if autoLeader is false

Return Value

Return status:

0	Command was successful, leader style values were set
-1	Command failed for an unknown reason, no leader style values were set
-2	Specified leader style value is not valid

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetArcLengthLeader](#).

Remarks

The leader style of an arc length dimension is specific to each display dimension. The leader style can be parallel (the leaders are parallel to each other) or radial (the leaders are perpendicular to the extension line and would extend through the center of the arc). The style can be selected automatically by SOLIDWORKS, or specified by the user.

If the autoLeader value is passed in as True to automatically select the leader style, then SOLIDWORKS ignores the leaderStyle value.

This method applies only to arc length dimensions. It does not affect any other types of dimensions.

After using this method, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetArcLengthLeader Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetArrowHeadStyle Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetArrowHeadStyle Method (IDisplayDimension)

Obsolete. Superseded by [IDisplayDimension::SetArrowHeadStyle2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetArrowHeadStyle( _  
    ByVal UseDoc As System.Boolean, _  
    ByVal ArrowHeadStyle As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim UseDoc As System.Boolean  
Dim ArrowHeadStyle As System.Integer  
  
instance.SetArrowHeadStyle(UseDoc, ArrowHeadStyle)
```

C#

```
void SetArrowHeadStyle(  
    System.bool UseDoc,  
    System.int ArrowHeadStyle  
)
```

C++/CLI

```
void SetArrowHeadStyle(  
&    System.bool UseDoc,  
&    System.int ArrowHeadStyle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDoc

ArrowHeadStyle

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetArrowHeadStyle](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetArrowHeadStyle2 Method (IDisplayDimension)

[See Also](#)



Sets the arrowhead style of this display dimension.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function SetArrowHeadStyle2( _  
    ByVal UseDoc As System.Boolean, _  
    ByVal Style1 As System.Integer, _  
    ByVal Style2 As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim UseDoc As System.Boolean  
Dim Style1 As System.Integer  
Dim Style2 As System.Integer  
Dim value As System.Boolean  
  
value = instance.SetArrowHeadStyle2(UseDoc, Style1, Style2)
```

C#

```
System.bool SetArrowHeadStyle2(  
    System.bool UseDoc,  
    System.int Style1,  
    System.int Style2  
)
```

C++/CLI

```
System.bool SetArrowHeadStyle2(  
& System.bool UseDoc,  
& System.int Style1,  
& System.int Style2  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDoc

True uses the document setting for arrowhead style, false uses the settings specified in *Style1* and *Style2*

Style1

Arrowhead style of first arrowhead as defined in [swArrowStyle_e](#)

Style2

Arrowhead style of second arrowhead as defined in [swArrowStyle_e](#)

Return Value

True if the arrowhead styles are set, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetArrowHeadStyle2](#).

Remarks

The arrowhead style for a display dimension is controlled by a value stored in one of two places: on the owning document or on the individual display dimension. Use [IDisplayDimension::GetUseDocArrowHeadStyle](#) and [IDisplayDimension::GetArrowHeadStyle2](#) to get the current values for these settings.

Setting *UseDoc* to True indicates that the document default setting for arrowhead style should be used, and *Style1* and *Style2* will be ignored.

After using this method, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetBentLeaderLength Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetBentLeaderLength Method (IDisplayDimension)

Sets the bent leader length to use for this dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function SetBentLeaderLength( _  
    ByVal UseDoc As System.Boolean, _  
    ByVal Length As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim UseDoc As System.Boolean  
Dim Length As System.Double  
Dim value As System.Boolean  
  
value = instance.SetBentLeaderLength(UseDoc, Length)
```

C#

```
System.bool SetBentLeaderLength(  
    System.bool UseDoc,  
    System.double Length  
)
```

C++/CLI

```
System.bool SetBentLeaderLength(  
& System.bool UseDoc,  
& System.double Length  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDoc

True to use the document default setting for dimension bent leader, false to use the length argument for the bent leader length

Length

Length of the bent leader in system units

Return Value

True if the bent leader length is set, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetBentLeaderLength](#).

Remarks

The dimension bent leader length only applies to these types of dimensions: radial and linear. If this method is used on any other type of dimension, no action is taken, and the return value is false.

Use:

- [IDisplayDimension::GetUseDocBentLeaderLength](#) to determine whether this dimension is using the document default setting for dimension bent leader length or not.

- [IDisplayDimension::GetBentLeaderLength](#) to determine the bent leader length for this dimension.
- After using this method, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

SetBrokenLeader2 Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetBrokenLeader2 Method (IDisplayDimension)

Sets the broken leader display characteristic of this display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function SetBrokenLeader2( _
    ByVal UseDoc As System.Boolean, _
    ByVal Broken As System.Integer _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim UseDoc As System.Boolean
Dim Broken As System.Integer
Dim value As System.Integer

value = instance.SetBrokenLeader2(UseDoc, Broken)
```

C#

```
System.int SetBrokenLeader2(
    System.bool UseDoc,
    System.int Broken
)
```

C++/CLI

```
System.int SetBrokenLeader2(
    & System.bool UseDoc,
    & System.int Broken
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDoc
True uses the document default setting, false uses the setting specified in the Broken argument

Broken
Broken leader value as defined in [swDisplayDimensionLeaderText_e](#) if UseDoc is false

Return Value

Return status:

-1	Command failed, no broken leader values were set
0	Command was successful, all precision values were set
1	Specified broken value is invalid, the display dimension was set to use the document default

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetBrokenLeader2](#).

Remarks

Dimension text can be displayed above a solid, unbroken leader line, or broken with the text displayed horizontally or aligned with the leader line. This method allows you to determine if this [IDisplayDimension](#) uses the default document setting for this value or if the user has applied a specific setting.

If UseDoc is True, then SOLIDWORKS ignores the broken value.

The return value indicates the success or failure of this method. In general, a value less than 0 indicates that the command failed, and no broken leader values were set. A value of 0 indicates success.

Use [IDisplayDimension::GetUseDocBrokenLeader](#) and [IDisplayDimension::GetBrokenLeader2](#) to get these values.

After using this method, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::SetBrokenLeader2 Method](#)
[IDisplayDimension::GetUseDocBrokenLeader Method](#)
[IDisplayDimension::SolidLeader Property](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDual Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetDual Method (IDisplayDimension)

Obsolete. Superseded by [IDisplayDimension::SetDual2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDual( _  
    ByVal UseDoc As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim UseDoc As System.Boolean  
  
instance.SetDual(UseDoc)
```

C#

```
void SetDual(  
    System.bool UseDoc  
)
```

C++/CLI

```
void SetDual(  
& System.bool UseDoc  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDoc

True uses the document setting, false uses the opposite of the document setting (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetDual](#).

Remarks

Dual dimensions can use either the same top, bottom, right, or left setting as the document or an opposite top, bottom, right, or left setting. This method allows you to set a dual dimension to use the current document setting or the opposite setting.

Use [IDisplayDimension::GetUseDocDual](#) to get the current value of this setting.

After using this method, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::Split Property \(\)](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDual2 Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetDual2 Method (IDisplayDimension)

Controls the display of dual dimensions of this display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDual2( _  
    ByVal UseDoc As System.Boolean, _  
    ByVal InwardRounding As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim UseDoc As System.Boolean  
Dim InwardRounding As System.Boolean  
  
instance.SetDual2(UseDoc, InwardRounding)
```

C#

```
void SetDual2(  
    System.bool UseDoc,  
    System.bool InwardRounding  
)
```

C++/CLI

```
void SetDual2(  
& System.bool UseDoc,  
& System.bool InwardRounding  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDoc

True uses the document setting, false uses the opposite of the document setting (see **Remarks**)

InwardRounding

True for inward rounding of secondary unit tolerances, false for current document rounding (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetDual2](#).

Example

[Set Rounding of Decimal Units in Display Dimensions \(VBA\)](#)
[Set Rounding of Decimal Units in Display Dimensions \(VB.NET\)](#)
[Set Rounding of Decimal Units in Display Dimensions \(C#\)](#)

Remarks

Dual dimensions can use either the same top, bottom, right, or left setting as the document or an opposite top, bottom, right, or left setting. This method allows you to set a dual dimension to use the current document setting or the opposite setting.

If InwardRounding is false and an override unit is...	Then...
Not specified	Current document rounding prevails
Specified	Rounding setting under Override Units in the Dimensions PropertyManager page prevails

Use [IDisplayDimension::GetUseDocDual](#) to get the current value of this setting.

After using this method, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::Split Property\(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetExtensionLineAsCenterline Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetExtensionLineAsCenterline Method (IDisplayDimension)

Sets whether the specified extension line is a centerline.

.NET Syntax

Visual Basic (Declaration)

```
Function SetExtensionLineAsCenterline( _  
    ByVal ExtIndex As System.Short, _  
    ByVal Centerline As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim ExtIndex As System.Short  
Dim Centerline As System.Boolean  
Dim value As System.Boolean  
  
value = instance.SetExtensionLineAsCenterline(ExtIndex, Centerline)
```

C#

```
System.bool SetExtensionLineAsCenterline(  
    System.short ExtIndex,  
    System.bool Centerline  
)
```

C++/CLI

```
System.bool SetExtensionLineAsCenterline(  
& System.short ExtIndex,  
& System.bool Centerline  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ExtIndex

Index of extension line to set

Centerline

True to make extension line a centerline, false to not

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetExtensionLineAsCenterline](#).

See Also

[IDisplayDimension Interface](#)

[IDisplayDimension Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetHorizontal Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetHorizontal Method (IDisplayDimension)

Displays this linear dimension on the horizontal.

.NET Syntax

Visual Basic (Declaration)

```
Function SetHorizontal() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
```

```
Dim value As System.Boolean
```

```
value = instance.SetHorizontal()
```

C#

```
System.bool SetHorizontal()
```

C++/CLI

```
System.bool SetHorizontal();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetHorizontal](#).

See Also

[IDisplayDimension Interface](#)

[IDisplayDimension Members](#)

[IDisplayDimension::AlignToEdge Method \(\)](#)

[IDisplayDimension::SetVertical Method \(\)](#)

Availability

SetJogParameters Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetJogParameters Method (IDisplayDimension)

Set the linear dimension extension line to be jogged.

.NET Syntax

Visual Basic (Declaration)

```

Function SetJogParameters( _
    ByVal WitnessIndex As System.Short, _
    ByVal Jogged As System.Boolean, _
    ByVal Offset1 As System.Double, _
    ByVal Offset2 As System.Double, _
    ByVal Offset1to2 As System.Double _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As IDisplayDimension
Dim WitnessIndex As System.Short
Dim Jogged As System.Boolean
Dim Offset1 As System.Double
Dim Offset2 As System.Double
Dim Offset1to2 As System.Double
Dim value As System.Boolean

value = instance.SetJogParameters(WitnessIndex, Jogged, Offset1, Offset2, Offset1to2)

```

C#

```

System.bool SetJogParameters(
    System.short WitnessIndex,
    System.bool Jogged,
    System.double Offset1,
    System.double Offset2,
    System.double Offset1to2
)

```

C++/CLI

```

System.bool SetJogParameters(
    & System.short WitnessIndex,
    & System.bool Jogged,
    & System.double Offset1,
    & System.double Offset2,
    & System.double Offset1to2
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WitnessIndex

Index of the linear dimension extension line to jog

Jogged

True whether the linear dimension extension is jogged, false if not

Offset1

First line segment of the linear dimension extension line

Offset2

Second line segment of the linear dimension extension line; this is the line segment to jog

Offset1to2

Distance by which to offset Offset1 and Offset2 for the jog

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetJogParameters](#).

Example

[Add and Offset Dimension Lines Jogs \(VBA\)](#)

Remarks

Call [IModelView::GraphicsRedraw](#) after calling this method to redraw the graphics area.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IModelDocExtension::JogDimension Method](#)
[IDisplayDimension::GetJogParameters Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetLineFontDimensionStyle Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetLineFontDimensionStyle Method (IDisplayDimension)

Sets the style of leader for this display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function SetLineFontDimensionStyle( _  
    ByVal UseDoc As System.Boolean, _  
    ByVal Style As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim UseDoc As System.Boolean  
Dim Style As System.Integer  
Dim value As System.Boolean
```

```
value = instance.SetLineFontDimensionStyle(UseDoc, Style)
```

C#

```
System.bool SetLineFontDimensionStyle(  
    System.bool UseDoc,  
    System.int Style  
)
```

C++/CLI

```
System.bool SetLineFontDimensionStyle(  
& System.bool UseDoc,  
& System.int Style  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDoc

True uses the document setting for the leader style, false uses the setting specified in *Style*

Style

Leader style as defined in [swLineStyles_e](#); valid only if *UseDoc* = false

Return Value

True if the leader style is set, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetLineFontDimensionStyle](#).

Remarks

After calling this method, call [IModelView::GraphicsRedraw](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::SetLineFontDimensionThickness Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetLineFontDimensionThickness Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetLineFontDimensionThickness Method (IDisplayDimension)

Sets the thickness of leaders of this display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function SetLineFontDimensionThickness( _  
    ByVal UseDoc As System.Boolean, _  
    ByVal Style As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim UseDoc As System.Boolean  
Dim Style As System.Integer  
Dim value As System.Boolean  
  
value = instance.SetLineFontDimensionThickness(UseDoc, Style)
```

C#

```
System.bool SetLineFontDimensionThickness(  
    System.bool UseDoc,  
    System.int Style  
)
```

C++/CLI

```
System.bool SetLineFontDimensionThickness(  
& System.bool UseDoc,  
& System.int Style  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDoc
True uses the document setting for the thickness of leaders, false uses the setting specified in *Style*
Style
Leader thickness as defined in [swLineWeights_e](#); valid only if *UseDoc* = false

Return Value

True if the leader thickness is set, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetLineFontDimensionThickness](#).

Remarks

After calling this method, call [IModelView::GraphicsRedraw](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::SetLineFontDimensionStyle Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetLineFontExtensionStyle Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetLineFontExtensionStyle Method (IDisplayDimension)

Sets the line font style for the extension lines of this display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function SetLineFontExtensionStyle( _  
    ByVal UseDoc As System.Boolean, _  
    ByVal Style As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim UseDoc As System.Boolean  
Dim Style As System.Integer  
Dim value As System.Boolean  
  
value = instance.SetLineFontExtensionStyle(UseDoc, Style)
```

C#

```
System.bool SetLineFontExtensionStyle(  
    System.bool UseDoc,  
    System.int Style  
)
```

C++/CLI

```
System.bool SetLineFontExtensionStyle(  
& System.bool UseDoc,  
& System.int Style  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDoc
True uses the document setting for the font style of extension lines, false uses the setting specified in *Style*
Style
Extension line font style as defined in [swLineStyles_e](#); valid only if UseDoc = false

Return Value

True if the extension line font style is set, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetLineFontExtensionStyle](#).

Remarks

After calling this method, call [IModelView::GraphicsRedraw](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::SetLineFontExtensionThickness Method\(\)](#)
[IDisplayDimension::ExtensionLineExtendsFromCenterOfSet Property\(\)](#)
[IDisplayDimension::ExtensionLineSameAsLeaderStyle Property\(\)](#)
[IDisplayDimension::ExtensionLineUseDocumentDisplay Property\(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetLineFontExtensionThickness Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetLineFontExtensionThickness Method (IDisplayDimension)

Sets the thickness of the extension lines of this display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function SetLineFontExtensionThickness( _  
    ByVal UseDoc As System.Boolean, _  
    ByVal Style As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim UseDoc As System.Boolean  
Dim Style As System.Integer  
Dim value As System.Boolean
```

```
value = instance.SetLineFontExtensionThickness(UseDoc, Style)
```

C#

```
System.bool SetLineFontExtensionThickness(  
    System.bool UseDoc,  
    System.int Style  
)
```

C++/CLI

```
System.bool SetLineFontExtensionThickness(  
& System.bool UseDoc,  
& System.int Style  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDoc
True uses the document setting for the thickness of extension lines, false uses the setting specified in *Style*
Style
Extension line font thickness as defined in [swLineWeights_e](#); valid only if *UseDoc* = false

Return Value

True if the extension line font thickness is set, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetLineFontExtensionThickness](#).

Remarks

After calling this method, call [IModelView::GraphicsRedraw](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::SetLineFontExtensionStyle Method \(\)](#)
[IDisplayDimension::ExtensionLineExtendsFromCenterOfSet Property \(\)](#)
[IDisplayDimension::ExtensionLineSameAsLeaderStyle Property \(\)](#)
[IDisplayDimension::ExtensionLineUseDocumentDisplay Property \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetLinkedText Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetLinkedText Method (IDisplayDimension)

Sets the text to link to this display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function SetLinkedText( _  
    ByVal BstrLinkedText As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim BstrLinkedText As System.String  
Dim value As System.Integer  
  
value = instance.SetLinkedText(BstrLinkedText)
```

C#

```
System.int SetLinkedText(  
    System.string BstrLinkedText  
)
```

C++/CLI

```
System.int SetLinkedText(  
& System.String^ BstrLinkedText  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BstrLinkedText

Text to link to this display dimension

Return Value

Error code as defined in [swLinkDimensionError_e](#)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetLinkedText](#).

Remarks

- Dimension types must be the same, for example: linear to linear, angular to angular, and so on.
- Angular dimensions must be in the same quadrant.
- Dimensions cannot be shared by another named group.
- Dimensions with dissimilar ranges cannot be shared.
- Dimensions cannot be driven by equations, read-only, driven sketch dimensions, or reference dimensions.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetLinkedText Method](#)
[IDisplayDimension::Unlink Method](#)
[IDisplayDimension::IsLinked Property](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetLowerText Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetLowerText Method (IDisplayDimension)

Sets the text below the dimension line in a display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetLowerText( _  
    ByVal Text As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim Text As System.String  
  
instance.SetLowerText(Text)
```

C#

```
void SetLowerText(  
    System.string Text  
)
```

C++/CLI

```
void SetLowerText(  
& System.String^ Text  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Text

Text to create below the dimension line

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetLowerText](#).

Example

[Get Chamfer Display Dimension \(C#\)](#)
[Get Chamfer Display Dimension \(VB.NET\)](#)
[Get Chamfer Display Dimension \(VBA\)](#)

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetLowerText Method \(\)](#)
[IModelDocExtension::EditDimensionProperties Method \(\)](#)
[IModelDocExtension::IEditDimensionProperties Method \(\)](#)
[IDisplayDimension::GetText Method \(\)](#)
[IDisplayDimension::SetText Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetOrdinateDimensionArrowSize Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetOrdinateDimensionArrowSize Method (IDisplayDimension)

Sets the diameter of the circle for the arrow of the base ordinate dimension if the base ordinate dimension standard is set to DIN.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetOrdinateDimensionArrowSize( _  
    ByVal UseDoc As System.Boolean, _  
    ByVal ArrowSize As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim UseDoc As System.Boolean  
Dim ArrowSize As System.Double  
  
instance.SetOrdinateDimensionArrowSize(UseDoc, ArrowSize)
```

C#

```
void SetOrdinateDimensionArrowSize(  
    System.bool UseDoc,  
    System.double ArrowSize  
)
```

C++/CLI

```
void SetOrdinateDimensionArrowSize(  
& System.bool UseDoc,  
& System.double ArrowSize  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDoc

True to use the document setting for the diameter of the circle for the arrow of the base ordinate dimension, false to use the diameter of the circle for the arrow of the base ordinate dimension set by this method if the base ordinate dimension standard is set to DIN

ArrowSize

Diameter of the circle for the arrow of the base ordinate dimension if the base ordinate dimension standard is set to DIN

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetOrdinateDimensionArrowSize](#).

Example

[Create Ordinate Dimensions \(C#\)](#)
[Create Ordinate Dimensions \(VB.NET\)](#)
[Create Ordinate Dimensions \(VBA\)](#)

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetOrdinateDimensionArrowSize Method \(\)](#)
[IDisplayDimension::AutoJogOrdinate Method \(\)](#)
[IDisplayDimension::DisplayAsChain Property \(\)](#)
[IDisplayDimension::Elevation Property \(\)](#)
[IDisplayDimension::EndSymbol Property \(\)](#)
[IDisplayDimension::GridBubble Property \(\)](#)
[IDisplayDimension::Jogged Property \(\)](#)
[IModelDocExtension::AddOrdinateDimension Method \(\)](#)
[IDrawingDoc::CreateOrdinateDim4 Method \(\)](#)
[IDrawingDoc::InsertOrdinate Method \(\)](#)
[IDrawingDoc::InsertHorizontalOrdinate Method \(\)](#)
[IDrawingDoc::InsertVerticalOrdinate Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetOverride Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetOverride Method (IDisplayDimension)

Sets whether to display the actual dimension value or to display another value, and, if so, that value.

.NET Syntax

Visual Basic (Declaration)

```
Function SetOverride( _  
    ByVal Override As System.Boolean, _  
    ByVal Value As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim Override As System.Boolean  
Dim Value As System.Double  
Dim value As System.Boolean  
  
value = instance.SetOverride(Override, Value)
```

C#

```
System.bool SetOverride(  
    System.bool Override,  
    System.double Value  
)
```

C++/CLI

```
System.bool SetOverride(  
& System.bool Override,  
& System.double Value  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Override
True to display a value other than the actual dimension value, false to display the actual value
Value
Value to display instead of the actual dimension value

Return Value

True if setting an override value is successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetOverride](#).

Remarks

This method can only be used on a display dimension in a drawing. In a part or assembly, this method takes no action and returns false.

If Override is set to false, then the Value argument is ignored.

Use [IDisplayDimension::GetOverride](#) to get whether the actual dimension value or another value is displayed.

Use [IDisplayDimension::GetOverrideValue](#) to get the value to display instead of the actual dimension value.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetPrecision Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetPrecision Method (IDisplayDimension)

Obsolete. Superseded by [IDisplayDimension::SetPrecision2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetPrecision( _  
    ByVal UseDoc As System.Boolean, _  
    ByVal Primary As System.Integer, _  
    ByVal Alternate As System.Integer, _  
    ByVal PrimaryTol As System.Integer, _  
    ByVal AlternateTol As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim UseDoc As System.Boolean  
Dim Primary As System.Integer  
Dim Alternate As System.Integer  
Dim PrimaryTol As System.Integer  
Dim AlternateTol As System.Integer  
Dim value As System.Integer  
  
value = instance.SetPrecision(UseDoc, Primary, Alternate, PrimaryTol, AlternateTol)
```

C#

```
System.int SetPrecision(  
    System.bool UseDoc,  
    System.int Primary,  
    System.int Alternate,  
    System.int PrimaryTol,  
    System.int AlternateTol  
)
```

C++/CLI

```
System.int SetPrecision(  
& System.bool UseDoc,  
& System.int Primary,  
& System.int Alternate,  
& System.int PrimaryTol,
```

```
& System.int AlternateTol
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDoc

Primary

Alternate

PrimaryTol

AlternateTol

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetPrecision](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetPrecision2 Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetPrecision2 Method (IDisplayDimension)

Obsolete. Superseded by [IDisplayDimension::SetPrecision3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetPrecision2( _
    ByVal Primary As System.Integer, _
    ByVal Dual As System.Integer, _
    ByVal PrimaryTol As System.Integer, _
    ByVal DualTol As System.Integer _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim Primary As System.Integer
Dim Dual As System.Integer
Dim PrimaryTol As System.Integer
Dim DualTol As System.Integer
Dim value As System.Integer
```

```
value = instance.SetPrecision2(Primary, Dual, PrimaryTol, DualTol)
```

C#

```
System.int SetPrecision2(
    System.int Primary,
    System.int Dual,
    System.int PrimaryTol,
    System.int DualTol
)
```

C++/CLI

```
System.int SetPrecision2(
    & System.int Primary,
    & System.int Dual,
    & System.int PrimaryTol,
```

& System.int *DualTol*
)

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Primary
Number of digits displayed after the decimal point in the dimension value (see **Remarks**)
Dual
Number of digits displayed after the decimal point in the dual dimension value
PrimaryTol
Number of digits displayed after the decimal point in the tolerance value (see **Remarks**)
DualTol
Number of digits displayed after the decimal point in the dual tolerance value

Return Value

Return status (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetPrecision2](#).

Remarks

The specified precision values must be in the range from 0 to 8, which indicates the number of digits after the decimal place to display that value. Alternatively, the precision values can be defined by [swDimensionPrecisionSettings_e](#).

Parameter	swDimensionPrecisionSettings_e value	Result
- Primary - Dual - PrimaryTol - DualTol	swDoNotChangePrecisionSetting	The current setting is not changed.
- Primary - Dual - PrimaryTol - DualTol	swPrecisionFollowsDocumentSetting	The number of decimal places to display adheres to the document setting. Use IModelDocExtension::GetUserPreferenceInteger / IModelDocExtension::SetUserPreferenceInteger .swDetailingLinearDimPrecision, swDetailingAngularDimPrecision, or swDetailingAltLinearDimPrecision to get or set that value.
- PrimaryTol - DualTol	swTolerancePrecisionFollowsNominal	The number of decimal places to display is the same as for the dimension or dual dimension value.

The return value indicates the success or failure of this method. In general, a value less than 0 indicates that the method failed and SOLIDWORKS did not set any precision values. A value of 0 indicates success. A value greater than 0 indicates that a problem occurred, but the method did not fail.

- 1 Method failed; no precision values were set.
- 0 Method was successful; all precision values were set.
- 1 Primary precision value was invalid.
- 2 Alternate precision value was invalid.
- 3 Primary tolerance precision value was invalid.
- 4 Alternate tolerance precision value was invalid.

After using this method, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetPrecision3 Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetPrecision3 Method (IDisplayDimension)

Sets the number of digits to display after the decimal point for precision and tolerance values in this display dimension.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function SetPrecision3( _  
    ByVal Primary As System.Integer, _  
    ByVal Dual As System.Integer, _  
    ByVal PrimaryTol As System.Integer, _  
    ByVal DualTol As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim Primary As System.Integer  
Dim Dual As System.Integer  
Dim PrimaryTol As System.Integer  
Dim DualTol As System.Integer  
Dim value As System.Integer  
  
value = instance.SetPrecision3(Primary, Dual, PrimaryTol, DualTol)
```

C#

```
System.int SetPrecision3(  
    System.int Primary,  
    System.int Dual,  
    System.int PrimaryTol,  
    System.int DualTol  
)
```

C++/CLI

```
System.int SetPrecision3(  
& System.int Primary,  
& System.int Dual,  
& System.int PrimaryTol,  
& System.int DualTol  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Primary
Number of digits displayed after the decimal point in the primary precision value (see **Remarks**)

Dual
Number of digits displayed after the decimal point in the dual precision value

PrimaryTol
Number of digits displayed after the decimal point in the primary tolerance value (see **Remarks**)

DualTol
Number of digits displayed after the decimal point in the dual tolerance value

Return Value

Return status (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetPrecision3](#).

Remarks

The specified values must be in the range from 0 to 8, which indicates the number of digits after the decimal place to display that value. Alternatively, the values can be defined by [swDimensionPrecisionSettings_e](#).

Parameter	swDimensionPrecisionSettings_e value	Result
• <i>Primary</i> • <i>Dual</i> • <i>PrimaryTol</i> • <i>DualTol</i>	swDoNotChangePrecisionSetting	The current setting is not changed.
• <i>Primary</i> • <i>Dual</i> • <i>PrimaryTol</i> • <i>DualTol</i>	swPrecisionFollowsDocumentSetting	The number of decimal places to display adheres to the document setting. Use IModelDocExtension::GetUserPreferenceInteger/

Parameter	swDimensionPrecisionSettings_e value	Result
		IModelDocExtension::SetUserPreferenceInteger .swDetailingLinearDimPrecision, swDetailingAngularDimPrecision, or swDetailingAltLinearDimPrecision to get or set that value.
- PrimaryTol - DualTol	swTolerancePrecisionFollowsNominal	The number of decimal places to display is the same as for the dimension or dual dimension value.

This method does not support setting the Primary and PrimaryTol values for [hole callouts](#). Use [ICalloutLengthVariable::Precision](#) and [ICalloutLengthVariable::TolerancePrecision](#) to set these values for hole callouts. However, you must use this method to set Dual and DualTol values for hole callouts, because Dual and DualTol are global settings.

The return value indicates the success or failure of this method. In general, a value less than 0 indicates that the method failed and SOLIDWORKS did not set any precision values. A value of 0 indicates success. A value greater than 0 indicates that a problem occurred, but the method did not fail.

- 1 Method failed; no precision values were set.
- 0 Method was successful; all precision values were set.
- 1 Primary precision value was invalid.
- 2 Alternate precision value was invalid.
- 3 Primary tolerance precision value was invalid.
- 4 Alternate tolerance precision value was invalid.

After using this method, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetAlternatePrecision2 Method \(\)](#)
[IDisplayDimension::GetAlternateTolPrecision2 Method \(\)](#)
[IDisplayDimension::GetPrimaryPrecision2 Method \(\)](#)
[IDisplayDimension::GetPrimaryTolPrecision2 Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetSecondArrow Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetSecondArrow Method (IDisplayDimension)

Sets the second arrow characteristics of this diameter display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetSecondArrow( _
    ByVal UseDoc As System.Boolean, _
    ByVal SecondArrow As System.Boolean _
)
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim UseDoc As System.Boolean
Dim SecondArrow As System.Boolean
```

```
instance.SetSecondArrow(UseDoc, SecondArrow)
```

C#

```
void SetSecondArrow(
    System.bool UseDoc,
```

```
        System.bool SecondArrow  
    )
```

C++/CLI

```
void SetSecondArrow(  
    & System.bool UseDoc,  
    & System.bool SecondArrow  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDoc

True uses the document setting for second arrows, false uses the setting specified by the SecondArrow argument

SecondArrow

Enables or disables the display of the second arrow on this display dimension if UseDoc is false

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetSecondArrow](#).

Remarks

For diameter dimensions, the second outside arrow is the arrow that appears on the opposite side of the arc from the dimension text. This occurs only when the text is outside of the arc.

Display of this arrow is optional, and is controlled by a value stored in one of two places: on the owning document or on the individual display dimension. This method allows you to determine which setting to use: the document default or the value specified in the secondArrow argument.

The UseDoc argument indicates whether to use the document default setting for second arrows. If it is false, then the SecondArrow argument indicates whether or not the second arrow is enabled.

Use [IDisplayDimension::GetUseDocSecondArrow](#) and [IDisplayDimension::GetSecondArrow](#) to get the current values for these settings.

This method applies to only diameter dimensions. If you execute this method with any other types of dimensions, SOLIDWORKS returns false.

After using this method, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::ArrowSide Property](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetText Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetText Method (IDisplayDimension)

Sets the text above the dimension line in a display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetText( _  
    ByVal WhichText As System.Integer, _  
    ByVal Text As System.String _  
)
```

Visual Basic (Usage)

```
Dim instance As IDisplayDimension  
Dim WhichText As System.Integer  
Dim Text As System.String
```



```
instance.SetText(WhichText, Text)
```

C#

```
void SetText(  
    System.int WhichText,  
    System.string Text  
)
```

C++/CLI

```
void SetText(  
& System.int WhichText,  
& System.String^ Text  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichText

Aspect of the text to get as defined in [swDimensionTextParts_e](#) (see **Remarks**)

Text

Text to create above the dimension line

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetText](#).

Example

[Display Grid Bubble \(VBA\)](#)

Remarks

Use `swDimensionTextParts_e.swDimensionTextAll` to create or replace the entire dimension text. SOLIDWORKS places the input text in the prefix portion of the dimension text, clears the suffix and callout texts, and turns off the dimension value (see [IDisplayDimension::ShowDimensionValue](#)).

After using this method, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

NOTE: This method does not support [hole callouts](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetText Method](#)
[IDisplayDimension::SetLowerText Method](#)
[IDisplayDimension::GetLowerText Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetTextFormat Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetTextFormat Method (IDisplayDimension)

Obsolete. Superseded by [IAnnotation::ISetTextFormat](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetTextFormat( _  
    ByVal TextFormatType As System.Integer, _  
    ByVal TextFormat As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim TextFormatType As System.Integer
Dim TextFormat As System.Object
Dim value As System.Boolean

value = instance.SetTextFormat(TextFormatType, TextFormat)
```

C#

```
System.bool SetTextFormat(
    System.int TextFormatType,
    System.object TextFormat
)
```

C++/CLI

```
System.bool SetTextFormat(
    & System.int TextFormatType,
    & System.Object^ TextFormat
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TextFormatType

TextFormat

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetTextFormat](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetUnits Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetUnits Method (IDisplayDimension)

Obsolete. Superseded by [IDisplayDimension::SetUnits2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetUnits(
    ByVal UseDoc As System.Boolean, _
    ByVal UType As System.Integer, _
    ByVal FractBase As System.Integer, _
    ByVal FractDenom As System.Integer, _
    ByVal RoundToFraction As System.Boolean _
) As System.Integer
```

Visual Basic (Usage)

 Copy Code

```

Dim instance As IDisplayDimension
Dim UseDoc As System.Boolean
Dim UType As System.Integer
Dim FractBase As System.Integer
Dim FractDenom As System.Integer
Dim RoundToFraction As System.Boolean
Dim value As System.Integer

```

```

value = instance.SetUnits(UseDoc, UType, FractBase, FractDenom, RoundToFraction)

```

C#

```

System.int SetUnits(
    System.bool UseDoc,
    System.int UType,
    System.int FractBase,
    System.int FractDenom,
    System.bool RoundToFraction
)

```

C++/CLI

```

System.int SetUnits(
    & System.bool UseDoc,
    & System.int UType,
    & System.int FractBase,
    & System.int FractDenom,
    & System.bool RoundToFraction
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDoc

True uses the document settings for units, false uses the setting values passed to the arguments (see **Remarks**)

UType

Unit display setting as defined in [swLengthUnits_e](#) or [swAngleUnits_e](#)

FractBase

Decimal or fraction display setting as defined in [swFractionDisplay_e](#)

FractDenom

Denominator for fraction display

RoundToFraction

True rounds values to the nearest fraction, false displays fractions only if the values are exact

Return Value

Return status (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetUnits](#).

Remarks

The unit display settings of a display dimension are controlled by a value stored in one of two places: on the owning document, or on the individual display dimension. This method allows you to determine which setting to use, the document default or the values specified by UType, FractBase, FractDenom, and RoundToFraction.

If the UseDoc argument is true, then the display dimension unit information follows the document settings, and SOLIDWORKS ignores the remaining arguments. SOLIDWORKS also removes any local settings so that if you switch back to the local settings, they are set to default values.

The UType argument indicates the units. Depending on the type of dimension (angular or linear), this parameter takes a value from [swLengthUnits_e](#) or [swAngleUnits_e](#). If the specified value is invalid, SOLIDWORKS does not change the existing setting and returns an error in the return value.

The FractBase argument indicates whether the dimension is displayed as a fraction or a decimal. This must take a value from [swFractionDisplay_e](#). SOLIDWORKS displays this value as a fraction only if it can be precisely represented as a fraction based on the fraction denominator setting specified in FractDenom. However, if the RoundToFraction argument is true, then SOLIDWORKS forces fraction display by rounding the value to the nearest fraction.

The FractDenom argument indicates the fraction precision by specifying the largest fraction denominator used (for example, 4 for 1/4 or 32 for 1/32). Fraction display is valid only if UType is swINCHES or swFEETINCHES.

The return value indicates the success or failure of this function. It may take one of the following values:

-2	Command failed because UType is invalid
-1	Command failed for an unknown reason
0	Command was successful

After using this method, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetUnits Method](#)
[IDisplayDimension::GetUseDocUnits Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetUnits2 Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetUnits2 Method (IDisplayDimension)

Sets the unit display characteristics of this display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function SetUnits2( _  
    ByVal UseDoc As System.Boolean, _  
    ByVal UType As System.Integer, _  
    ByVal FractBase As System.Integer, _  
    ByVal FractDenom As System.Integer, _  
    ByVal RoundToFraction As System.Boolean, _  
    ByVal DecimalRounding As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim UseDoc As System.Boolean  
Dim UType As System.Integer  
Dim FractBase As System.Integer  
Dim FractDenom As System.Integer  
Dim RoundToFraction As System.Boolean  
Dim DecimalRounding As System.Integer  
Dim value As System.Integer
```

```
value = instance.SetUnits2(UseDoc, UType, FractBase, FractDenom, RoundToFraction, DecimalRounding)
```

C#

```
System.int SetUnits2(  
    System.bool UseDoc,  
    System.int UType,  
    System.int FractBase,  
    System.int FractDenom,  
    System.bool RoundToFraction,  
    System.int DecimalRounding,  
)
```

C++/CLI

```

System.int SetUnits2(
& System.bool UseDoc,
& System.int UType,
& System.int FractBase,
& System.int FractDenom,
& System.bool RoundToFraction,
& System.int DecimalRounding
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDoc

True to use the document settings for units, false to use the setting values passed to this method (see **Remarks**)

UType

Unit display setting as defined in [swLengthUnit_e](#) or [swAngleUnit_e](#); valid only if UseDoc is false

FractBase

Decimal or fraction display setting as defined in [swFractionDisplay_e](#); valid only if UseDoc is false

FractDenom

Denominator for fraction display; valid only if UseDoc is false

RoundToFraction

True to round values to the nearest fraction, false to display fractions only if the values are exact; valid only if UseDoc is false

DecimalRounding

Decimal rounding as defined by [swUnitsDecimalRounding_e](#); valid only if FractBase is swFractionDisplay_e.swDECIMAL and UseDoc is false

Return Value

Return status (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetUnits2](#).

Example

[Set Rounding of Decimal Units in Display Dimensions \(VBA\)](#)

[Set Rounding of Decimal Units in Display Dimensions \(VB.NET\)](#)

[Set Rounding of Decimal Units in Display Dimensions \(C#\)](#)

Remarks

The unit display settings of a display dimension are controlled by a value stored in one of two places: in the owning document or in the individual display dimension. This method allows you to determine which setting to use, the document default or the values specified by UType, FractBase, FractDenom, RoundToFraction, and DecimalRounding.

If UseDoc is true, then the display dimension unit information follows the document settings, and SOLIDWORKS ignores the remaining arguments. SOLIDWORKS also removes any local settings so that if you switch back to the local settings, they are set to default values.

UType indicates the units. Depending on the type of dimension (angular or linear), this parameter takes a value from [swLengthUnit_e](#) or [swAngleUnit_e](#). If the specified value is invalid, SOLIDWORKS does not change the existing setting, and this method returns an error.

FractBase indicates whether the dimension is displayed as a fraction or a decimal. SOLIDWORKS displays the dimension as a fraction only if it can precisely represent the dimension as a fraction based on the FractDenom setting. However, if the RoundToFraction argument is true, then SOLIDWORKS displays the dimension rounded to the nearest fraction.

FractDenom indicates the fraction precision by specifying the largest fraction denominator used (for example, 4 for 1/4 or 32 for 1/32). Fraction display is valid only if UType is swINCHES or swFEETINCHES.

The return value indicates the success or failure of this method as follows:

If Return Value is...	Then this method...
2	Failed because UType is invalid
1	Failed for an unknown reason
0	Succeeded

After using this method, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)

[IDisplayDimension Members](#)

[IDisplayDimension::GetUnits Method \(\)](#)

[IDisplayDimension::GetUseDocUnits Method \(\)](#)

Availability

SetVertical Method (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetVertical Method (IDisplayDimension)

Displays this linear dimension on the vertical.

.NET Syntax

Visual Basic (Declaration)

Function SetVertical() As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean
```

```
value = instance.SetVertical()
```

C#

```
System.bool SetVertical()
```

C++/CLI

```
System.bool SetVertical();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetVertical](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::AlignToEdge Method \(\)](#)
[IDisplayDimension::SetHorizontal Method \(\)](#)

Availability

SOLIDWORKS 2024 SP03, Revision Number 32.3

SetWitnessLineGap Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SetWitnessLineGap Method (IDisplayDimension)

Sets the gap for the specified dimension extension line.

.NET Syntax

Visual Basic (Declaration)

```
Function SetWitnessLineGap( _  
    ByVal WitnessIndex As System.Short, _  
    ByVal UseDoc As System.Boolean, _  
    ByVal Gap As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```

Dim instance As IDisplayDimension
Dim WitnessIndex As System.Short
Dim UseDoc As System.Boolean
Dim Gap As System.Double
Dim value As System.Boolean

value = instance.SetWitnessLineGap(WitnessIndex, UseDoc, Gap)

```

C#

```

System.bool SetWitnessLineGap(
    System.short WitnessIndex,
    System.bool UseDoc,
    System.double Gap
)

```

C++/CLI

```

System.bool SetWitnessLineGap(
    & System.short WitnessIndex,
    & System.bool UseDoc,
    & System.double Gap
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WitnessIndex
Index of the extension line whose gap to get

UseDoc
True to use the document default value of the gap, false to not (see **Remarks**)

Gap
Gap value in system units; ignored if UseDoc is true

Return Value

True if the operation succeeds, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SetWitnessLineGap](#).

Example

[Get and Set Dimension Extension Lines Gaps \(VBA\)](#)

Remarks

The UseDoc argument is dependent on the detailing standard. You can retrieve the document default value using the [document-level user-preference swDetailingWitnessLineGap](#).

Call [IModelView::GraphicsRedraw](#) after calling this method to redraw the graphics area.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::SetWitnessLineGap Method](#)
[IView::GetDimensionInfo6 Method](#)
[IView::IGetDimensionInfo6 Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0



Gets or sets whether to display this radius display dimension with a foreshortened radius.

Visual Basic Syntax

Visual Basic (Declaration)

Property ShortenedRadius As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.Boolean

instance.ShortenedRadius = value

value = instance.ShortenedRadius
```

C#

```
System.bool ShortenedRadius {get; set;}
```

C++/CLI

```
property System.bool ShortenedRadius {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True displays a foreshortened radius, false does not display a foreshortened radius

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::ShortenedRadius](#).

Remarks

In certain instances, you might want to show a radius dimension where the leader goes towards the center of the arc, but stops just before reaching the center. This is commonly used when the center of the arc is beyond the bounds of a drawing, or interferes with another view. This method controls that display characteristic.

This property applies only to radius dimensions. It does not affect other types of dimensions.

After using this property, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowDimensionValue Property (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : ShowDimensionValue Property (IDisplayDimension)

Gets or sets whether the dimension value is displayed as part of the dimension text.

Visual Basic Syntax

Visual Basic (Declaration)

Property ShowDimensionValue As System.Boolean

```
Dim instance As IDisplayDimension
Dim value As System.Boolean

instance.ShowDimensionValue = value
value = instance.ShowDimensionValue
```

C#

```
System.bool ShowDimensionValue {get; set;}
```

C++/CLI

```
property System.bool ShowDimensionValue {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True displays the dimension value, false does not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::ShowDimensionValue](#).

Example

[Get Display Dimension Properties \(VBA\)](#)

Remarks

After using this property, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::SetText Method](#)
[IDisplayDimension::GetText Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowLowerParenthesis Property (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : ShowLowerParenthesis Property (IDisplayDimension)

Gets or sets whether to enclose the text below the dimension line of the display dimension in parentheses.

.NET Syntax

Visual Basic (Declaration)

```
Property ShowLowerParenthesis As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IDisplayDimension
Dim value As System.Boolean

instance.ShowLowerParenthesis = value
value = instance.ShowLowerParenthesis
```

C#

```
System.bool ShowLowerParenthesis {get; set;}
```

C++/CLI

```
property System.bool ShowLowerParenthesis {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to enclose the text below the dimension line of the display dimension in parentheses, false to not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::ShowLowerParenthesis](#).

Example

[Get Chamfer Display Dimension \(C#\)](#)
[Get Chamfer Display Dimension \(VB.NET\)](#)
[Get Chamfer Display Dimension \(VBA\)](#)

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetLowerText Method \(\)](#)
[IDisplayDimension::SetLowerText Method \(\)](#)
[IDisplayDimension::ShowParenthesis Property \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowParenthesis Property (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : ShowParenthesis Property (IDisplayDimension)

Gets or sets whether to enclose the text above the dimension line of the display dimension in parentheses.

.NET Syntax

Visual Basic (Declaration)

```
Property ShowParenthesis As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean
```

```
instance.ShowParenthesis = value
```

```
value = instance.ShowParenthesis
```

C#

```
System.bool ShowParenthesis {get; set;}
```

C++/CLI

```
property System.bool ShowParenthesis {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to enclose the text above the dimension line of the display dimension in parentheses, false to not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::ShowParenthesis](#).

Example

[Get Display Dimension Properties \(VBA\)](#)

Remarks

After using this property, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::SetText Method](#)
[IDisplayDimension::GetText Method](#)
[IDisplayDimension::ShowLowerParenthesis Property\(\)](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ShowTolParenthesis Property (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : ShowTolParenthesis Property (IDisplayDimension)

Obsolete. Superseded by [IDisplayDimension::ShowParenthesis](#).

.NET Syntax

Visual Basic (Declaration)

Property ShowTolParenthesis As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.Boolean

instance.ShowTolParenthesis = value
value = instance.ShowTolParenthesis
```

C#

```
System.bool ShowTolParenthesis {get; set;}
```

C++/CLI

```
property System.bool ShowTolParenthesis {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::ShowTolParenthesis](#).

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)

SmartWitness Property (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SmartWitness Property (IDisplayDimension)

Gets or sets the smart display of extension lines.

.NET Syntax

Visual Basic (Declaration)

Property SmartWitness As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean
```

```
instance.SmartWitness = value
```

```
value = instance.SmartWitness
```

C#

```
System.bool SmartWitness {get; set;}
```

C++/CLI

```
property System.bool SmartWitness {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True uses extension line smart display, false does not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SmartWitness](#).

Example

[Get Display Dimension Properties \(VBA\)](#)

Remarks

After using this property, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::MaxWitnessLineLength Property](#)
[IDisplayDimension::WitnessVisibility Property](#)

SolidLeader Property (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SolidLeader Property (IDisplayDimension)

Gets or sets whether this display dimension is displayed with a solid leader for arc and radial dimensions.

.NET Syntax

Visual Basic (Declaration)

Property SolidLeader As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean
```

```
instance.SolidLeader = value
```

```
value = instance.SolidLeader
```

C#

```
System.bool SolidLeader {get; set;}
```

C++/CLI

```
property System.bool SolidLeader {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True displays a solid leader, false does not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SolidLeader](#).

Remarks

After using this property, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::SetBrokenLeader2 Method](#)
[IDisplayDimension::GetUseDocBrokenLeader Method](#)
[IDisplayDimension::GetBrokenLeader2 Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments](#) on this topic.

Split Property (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : Split Property (IDisplayDimension)

Gets or sets whether to split a dual dimension above and below an unbroken dimension line (also called a leader).

.NET Syntax

Visual Basic (Declaration)

```
Property Split As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean
```

```
instance.Split = value
```

```
value = instance.Split
```

C#

```
System.bool Split {get; set;}
```

C++/CLI

```
property System.bool Split {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to split a dual dimension above and below an unbroken dimension line, false to not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::Split](#).

Example

[Get Chamfer Display Dimension \(C#\)](#)
[Get Chamfer Display Dimension \(VB.NET\)](#)
[Get Chamfer Display Dimension \(VBA\)](#)

Requirements

Setting this method to true only affects the following types of dual dimensions when the **Split when text position** is "Solid Leader, Aligned Text" option is selected in their **Tools > Options > Dimensions** dialog boxes:

- Arc Length
- Chamfer
- Diameter
- Linear
- Radius

To open the Help topic containing instructions on how to get and set the **Split when text position** is "Solid Leader, Aligned Text" option programmatically:

1. Click **Help > Use SOLIDWORKS Web Help**, if this menu item is checked.
2. Click **Help > API Help**.
3. Type **Document**.
4. Scroll down to the **properties** index subentry.
5. Scroll down to the **dimensions** index sub-subentry.
6. Double-click the type of dimension listed below **dimensions** whose dual dimension's **Split when text position** is "Solid Leader, Aligned Text" option you want to get or set.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetUseDocDual Method \(\)](#)
[IDisplayDimension::SetDual Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SupplementaryAngle Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : SupplementaryAngle Method (IDisplayDimension)

Changes the angle in the selected angular dimension to its supplementary angle.

.NET Syntax

Visual Basic (Declaration)

```
Function SupplementaryAngle() As System.Boolean
```

Visual Basic (Usage)



Copy Code

```
Dim instance As IDisplayDimension
Dim value As System.Boolean

value = instance.SupplementaryAngle()
```

C#

```
System.bool SupplementaryAngle()
```

C++/CLI

```
System.bool SupplementaryAngle();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the angle in the selected angular dimension changes to its supplementary angle, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::SupplementaryAngle](#).

Example

[Change Angle to Supplementary Angle \(C#\)](#)
[Change Angle to Supplementary Angle \(VB.NET\)](#)
[Change Angle to Supplementary Angle \(VBA\)](#)

Remarks

If the angle in the selected angular dimension is...	Then the supplementary angle is its...
>180 degrees (i.e., exterior)	Interior angle
<180 degrees (i.e., interior)	Exterior angle

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IModelDocExtension::AddDimension Method \(\)](#)
[IModelDoc2::AddDimension2 Method \(\)](#)

Availability

SOLIDWORKS 2016 SP3, Revision Number 24.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

Type2 Property (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : Type2 Property (IDisplayDimension)

Gets the type of dimension.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Type2 As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.Integer

value = instance.Type2
```

C#

```
System.int Type2 {get;}
```

C++/CLI

```
property System.int Type2 {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of dimension as defined by [swDimensionType_e](#)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::Type2](#).

Example

[Get Chamfer Display Dimension \(C#\)](#)
[Get Chamfer Display Dimension \(VB.NET\)](#)
[Get Chamfer Display Dimension \(VBA\)](#)
[Get DimXpert Display Dimensions and Feature \(C#\)](#)
[Get DimXpert Display Dimensions and Feature \(VB.NET\)](#)
[Get DimXpert Display Dimensions and Feature \(VBA\)](#)

Remarks

After using this property, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetType Method](#)
[IDisplayDimension::Diametric Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Unlink Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : Unlink Method (IDisplayDimension)

Unlinks a previously linked display dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function Unlink() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Integer  
  
value = instance.Unlink()
```

C#

```
System.int Unlink()
```

C++/CLI

```
System.int Unlink();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Error code as defined by [swLinkDimensionError_e](#)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::Unlink](#).

Example

[Unlink Dimensions \(VBA\)](#)

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::GetLinkedText Method](#)
[IDisplayDimension::SetLinkedText Method](#)
[IDisplayDimension::IsLinked Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

VerticalJustification Property (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : VerticalJustification Property (IDisplayDimension)

Gets the dimension text's vertical justification.

.NET Syntax

Visual Basic (Declaration)

Property VerticalJustification As System.Integer

Visual Basic (Usage)



```
Dim instance As IDisplayDimension
Dim value As System.Integer

instance.VerticalJustification = value
value = instance.VerticalJustification
```

C#

```
System.int VerticalJustification {get; set;}
```

C++/CLI

```
property System.int VerticalJustification {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Vertical justification as defined in [swVerticalJustification_e](#)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::VerticalJustification](#).

Remarks

After using this property, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::HorizontalJustification Property](#)
[IDisplayDimension::AddDisplayText Method](#)
[IDisplayDimension::!AddDisplayText Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

VerticallyOppositeAngle Method (IDisplayDimension)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : VerticallyOppositeAngle Method (IDisplayDimension)

Flips an angular dimension to its vertically opposite angle.

.NET Syntax

Visual Basic (Declaration)

```
Function VerticallyOppositeAngle() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Boolean
```

```
value = instance.VerticallyOppositeAngle()
```

C#

```
System.bool VerticallyOppositeAngle()
```

C++/CLI

```
System.bool VerticallyOppositeAngle();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::VerticallyOppositeAngle](#).

Example

[Create Angular Dimension \(VBA\)](#)
[Create Angular Dimension \(VB.NET\)](#)
[Create Angular Dimension \(C#\)](#)

See Also

[IDisplayDimension Interface](#)
[IDisplayDimension Members](#)
[IDisplayDimension::ExplementaryAngle Method \(\)](#)

Availability

WitnessVisibility Property (IDisplayDimension)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayDimension Interface](#) : WitnessVisibility Property (IDisplayDimension)

Gets or sets which extension lines are visible.

.NET Syntax

Visual Basic (Declaration)

Property WitnessVisibility As System.Integer

Visual Basic (Usage)



```
Dim instance As IDisplayDimension  
Dim value As System.Integer
```

```
instance.WitnessVisibility = value
```

```
value = instance.WitnessVisibility
```

C#

```
System.int WitnessVisibility {get; set;}
```

C++/CLI

```
property System.int WitnessVisibility {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Extension-line visibility state as defined in [swWitnessLineVisibility_e](#)

Visual Basic for Applications (VBA) Syntax

See [DisplayDimension::WitnessVisibility](#).

Remarks

After using this property, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window to see your changes.

See Also

[IDisplayDimension Interface](#)

[IDisplayDimension Members](#)

[IDisplayDimension::SmartWitness Property](#)

[IDisplayDimension::MaxWitnessLineLength Property](#)