

SOLIDWORKS API (.NET VBA C#) — Reference

(79/337): IDisplayStateSetting- IDocumentSpecification

SOLIDWORKS API Documentation (converted from CHM)

IDisplayStateSetting (Type)

IDisplayStateSetting Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDisplayStateSetting Interface

Allows access to display state settings.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IDisplayStateSetting
```

Visual Basic (Usage)



```
Dim instance As IDisplayStateSetting
```

C#

```
public interface IDisplayStateSetting
```

C++/CLI

```
public interface class IDisplayStateSetting
```

Visual Basic for Applications (VBA) Syntax

See [DisplayStateSetting](#).

Example

[Get Display State Settings \(VBA\)](#)
[Get Display State Settings \(VB.NET\)](#)
[Get Display State Settings \(C#\)](#)
[Change Color of Component in Specific Display State \(C#\)](#)
[Change Color of Component in Specific Display State \(VB.NET\)](#)
[Change Color of Component in Specific Display State \(VBA\)](#)

Remarks

After accessing this interface:

1. Call [IDisplayStateSetting::Names](#) or [IDisplayStateSetting::ISetNames](#) to specify the display states.
2. Call [IDisplayStateSetting::Entities](#) or [IDisplayStateSetting::ISetEntities](#) to specify the entities.
3. Call [IDisplayStateSetting::Option](#) to specify the display state scope of the setting.
4. Get or set one or more of the following properties for the specified display states, entities, and scope:
 - [IModelDocExtension::DisplayMode](#)
 - [IModelDocExtension::Transparency](#)
 - [IModelDocExtension::Visibility](#)
5. Call [IModelDocExtension::GetAppearanceSetting](#) to obtain an [IAppearanceSetting](#) object.
6. Set the properties in the [IAppearanceSetting](#) object.
7. Get or set the material properties for the specified display states, entities, and scope using [IModelDocExtension::DisplayStateSpecMaterialPropertyValues](#).

Accessors

[IModelDocExtension::GetDisplayStateSetting](#)

Access Diagram

[DisplayStateSetting](#)

See Also

[IDisplayStateSetting Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IDisplayStateSetting Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : IDisplayStateSetting Interface

The following tables list the members exposed by [IDisplayStateSetting](#).

Public Properties

Name	Description
Entities	Gets and sets the entities for this display state setting.
Names	Gets and sets the display state names for this display state setting.
Option	Gets and sets the display state scope for this display state setting.
PartLevel	Gets or sets whether to set at the part level.
RemoveAppearance	Gets or sets whether to remove appearances for this display state setting.

[Top](#)

Public Methods

Name	Description
GetEntityCount	Gets the number of entities for this display state setting.
GetNameCount	Gets the number of display states for this display state setting.
IGetEntities	Gets the entities for this display state setting.
IGetNames	Gets the display state names for this display state setting.
ISetEntities	Sets the entities for this display state setting.
ISetNames	Sets the display state names for this display state setting.

[Top](#)

See Also

[IDisplayStateSetting Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IDisplayStateSetting Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IDisplayStateSetting Interface

For a list of all members of this type, see [IDisplayStateSetting members](#).

Public Methods

Name	Description
GetEntityCount	Gets the number of entities for this display state setting.
GetNameCount	Gets the number of display states for this display state setting.
IGetEntities	Gets the entities for this display state setting.
IGetNames	Gets the display state names for this display state setting.
ISetEntities	Sets the entities for this display state setting.
ISetNames	Sets the display state names for this display state setting.

[Top](#)

See Also

[IDisplayStateSetting Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IDisplayStateSetting Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IDisplayStateSetting Interface

For a list of all members of this type, see [IDisplayStateSetting members](#).

Public Properties

Name	Description
 Entities	Gets and sets the entities for this display state setting.
 Names	Gets and sets the display state names for this display state setting.
 Option	Gets and sets the display state scope for this display state setting.
 PartLevel	Gets or sets whether to set at the part level.
 RemoveAppearance	Gets or sets whether to remove appearances for this display state setting.

[Top](#)

See Also

[IDisplayStateSetting Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

Entities Property (IDisplayStateSetting)

[See Also](#) [Example](#)

  [SolidWorks.Interop.sldworks Namespace](#) > [IDisplayStateSetting Interface](#) : Entities Property (IDisplayStateSetting)

Gets and sets the entities for this display state setting.

.NET Syntax

Visual Basic (Declaration)

Property Entities As System.Object

Visual Basic (Usage)



```
Dim instance As IDisplayStateSetting  
Dim value As System.Object
```

```
instance.Entities = value
```

```
value = instance.Entities
```

C#

```
System.object Entities {get; set;}
```

C++/CLI

```
property System.Object^ Entities {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of entities

Visual Basic for Applications (VBA) Syntax

See [DisplayStateSetting::Entities](#).

Example

[Get Display State Settings \(C#\)](#)
[Get Display State Settings \(VB.NET\)](#)
[Get Display State Settings \(VBA\)](#)
[Change Color of Component in Specific Display State \(C#\)](#)
[Change Color of Component in Specific Display State \(VB.NET\)](#)
[Change Color of Component in Specific Display State \(VBA\)](#)

Remarks

After calling this method:

1. Call [IDisplayStateSetting::Names](#) to specify the display states.
2. Call [IDisplayStateSetting::Option](#) to specify the display state scope of the setting.
3. Get or set one or more of the following properties for the specified display states, entities, and scope:
 - [IModelDocExtension::DisplayMode](#)
 - [IModelDocExtension::Transparency](#)
 - [IModelDocExtension::Visibility](#)
4. Call [IModelDocExtension::GetAppearanceSetting](#) to obtain an [IAppearanceSetting](#) object.
5. Set the properties in the [IAppearanceSetting](#) object.
6. Get or set the material properties for the specified display states, entities, and scope using [IModelDocExtension::DisplayStateSpecMaterialPropertyValues](#).

See Also

[IDisplayStateSetting Interface](#)
[IDisplayStateSetting Members](#)
[IDisplayStateSetting::IGetEntities Method](#)
[IDisplayStateSetting::ISetEntities Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEntityCount Method (IDisplayStateSetting)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayStateSetting Interface](#) : GetEntityCount Method (IDisplayStateSetting)

Gets the number of entities for this display state setting.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEntityCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayStateSetting
Dim value As System.Integer

value = instance.GetEntityCount()
```

C#

```
System.int GetEntityCount()
```

C++/CLI

```
System.int GetEntityCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of entities

Visual Basic for Applications (VBA) Syntax

See [DisplayStateSetting::GetEntityCount](#).

Remarks

Call this method to get the size of the array returned by [IDisplayStateSetting::IGetEntities](#).

See Also

[IDisplayStateSetting Interface](#)
[IDisplayStateSetting Members](#)
[IDisplayStateSetting.Entities Property](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNameCount Method (IDisplayStateSetting)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayStateSetting Interface](#) : GetNameCount Method (IDisplayStateSetting)

Gets the number of display states for this display state setting.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNameCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayStateSetting  
Dim value As System.Integer  
  
value = instance.GetNameCount()
```

C#

```
System.int GetNameCount()
```

C++/CLI

```
System.int GetNameCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DisplayStateSetting.GetNameCount](#).

Remarks

Call this method to get the size of the array returned by [IDisplayStateSetting.IGetNames](#).

See Also

[IDisplayStateSetting Interface](#)
[IDisplayStateSetting Members](#)
[IDisplayStateSetting.Names Property](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetEntities Method (IDisplayStateSetting)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayStateSetting Interface](#) : IGetEntities Method (IDisplayStateSetting)

Gets the entities for this display state setting.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetEntities( _  
    ByVal EntityCount As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDisplayStateSetting  
Dim EntityCount As System.Integer  
Dim value As System.Object  
  
value = instance.IGetEntities(EntityCount)
```

C#

```
System.object IGetEntities(  
    System.int EntityCount  
)
```

C++/CLI

```
System.Object^ IGetEntities(  
& System.int EntityCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EntityCount
Number of entities

Return Value

- in-process, unmanaged C++: Pointer to an array entities
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IDisplayStateSetting::GetEntityCount](#) to populate EntityCount.

See Also

[IDisplayStateSetting Interface](#)
[IDisplayStateSetting Members](#)
[IDisplayStateSetting::Entities Property](#)
[IDisplayStateSetting::ISetEntities Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNames Method (IDisplayStateSetting)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayStateSetting Interface](#) : IGetNames Method (IDisplayStateSetting)

Gets the display state names for this display state setting.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNames( _  
    ByVal DsNameCount As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IDisplayStateSetting
Dim DsNameCount As System.Integer
Dim value As System.String

value = instance.IGetNames(DsNameCount)
```

C#

```
System.string IGetNames(
    System.int DsNameCount
)
```

C++/CLI

```
System.String^ IGetNames(
    & System.int DsNameCount
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DsNameCount
Number of display state names

Return Value

- in-process, unmanaged C++: Pointer to an array display state names
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IDisplayStateSetting::GetNameCount](#) to populate DsNameCount.

See Also

[IDisplayStateSetting Interface](#)
[IDisplayStateSetting Members](#)
[IDisplayStateSetting::Names Property](#)
[IDisplayStateSetting::ISetNames Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetEntities Method (IDisplayStateSetting)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayStateSetting Interface](#) : ISetEntities Method (IDisplayStateSetting)

Sets the entities for this display state setting.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetEntities( _
    ByVal EntityCount As System.Integer, _
    ByRef Entities As System.Object _
)
```

Visual Basic (Usage)



```
Dim instance As IDisplayStateSetting
Dim EntityCount As System.Integer
Dim Entities As System.Object

instance.ISetEntities(EntityCount, Entities)
```

C#

```
void ISetEntities(  
    System.int EntityCount,  
    ref System.object Entities  
)
```

C++/CLI

```
void ISetEntities(  
& System.int EntityCount,  
& System.Object^% Entities  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EntityCount

Number of entities in the Entities array

Entities

- in-process, unmanaged C++: Pointer to an array of entities
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

After calling this method:

1. Call [IDisplayStateSetting::ISetNames](#) to specify the display states.
2. Call [IDisplayStateSetting::Option](#) to specify the display state scope of the setting.
3. Get or set one or more of the following properties for the specified display states, components, and scope:
 - [IModelDocExtension::DisplayMode](#)
 - [IModelDocExtension::Transparency](#)
 - [IModelDocExtension::Visibility](#)
4. Call [IModelDocExtension::GetAppearanceSetting](#) to obtain an [IAppearanceSetting](#) object.
5. Set the properties in the IAppearanceSetting object.
6. Get or set the material properties for the specified display states, components, and scope:
 - [IModelDocExtension::DisplayStateSpecMaterialPropertyValues](#)

See Also

[IDisplayStateSetting Interface](#)

[IDisplayStateSetting Members](#)

[IDisplayStateSetting::Entities Property](#)

[IDisplayStateSetting::IGetEntities Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetNames Method (IDisplayStateSetting)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayStateSetting Interface](#) : ISetNames Method (IDisplayStateSetting)

Sets the display state names for this display state setting.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetNames( _  
    ByVal DsNameCount As System.Integer, _  
    ByRef DSNames As System.String _  
)
```

Visual Basic (Usage)

```
Dim instance As IDisplayStateSetting  
Dim DsNameCount As System.Integer  
Dim DSNames As System.String  
  
instance.ISetNames(DsNameCount, DSNames)
```



C#

```
void ISetNames(  
    System.int DsNameCount,  
    ref System.string DSNames  
)
```

C++/CLI

```
void ISetNames(  
& System.int DsNameCount,  
& System.String^% DSNames  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DsNameCount

Number of names in the DSNames array

DSNames

- in-process, unmanaged C++: Pointer to an array display state names
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

After calling this method:

1. Call [IDisplayStateSetting::ISetEntities](#) to specify the entities.
2. Call [IDisplayStateSetting::Option](#) to specify the display state scope of the setting.
3. Get or set one or more of the following properties for the specified display states, entities, and scope:
 - [IModelDocExtension::DisplayMode](#)
 - [IModelDocExtension::Transparency](#)
 - [IModelDocExtension::Visibility](#)
4. Call [IModelDocExtension::GetAppearanceSetting](#) to obtain an [IAppearanceSetting](#) object.
5. Set the properties in the [IAppearanceSetting](#) object.
6. Get or set the material properties for the specified display states, entities, and scope:
 - [IModelDocExtension::DisplayStateSpecMaterialPropertyValues](#)

See Also

[IDisplayStateSetting Interface](#)

[IDisplayStateSetting Members](#)

[IDisplayStateSetting::Names Property](#)

[IDisplayStateSetting::IGetNames Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Names Property (IDisplayStateSetting)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayStateSetting Interface](#) : Names Property (IDisplayStateSetting)

Gets and sets the display state names for this display state setting.

.NET Syntax

Visual Basic (Declaration)

Property Names As System.Object

Visual Basic (Usage)



```
Dim instance As IDisplayStateSetting  
Dim value As System.Object
```

```
instance.Names = value
```

```
value = instance.Names
```

C#

```
System.Object Names {get; set;}
```

C++/CLI

```
property System.Object^ Names {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of display state names

Visual Basic for Applications (VBA) Syntax

See [DisplayStateSetting::Names](#).

Example

[Get Display State Settings \(VBA\)](#)
[Get Display State Settings \(VB.NET\)](#)
[Get Display State Settings \(C#\)](#)
[Change Color of Component in Specific Display State \(C#\)](#)
[Change Color of Component in Specific Display State \(VB.NET\)](#)
[Change Color of Component in Specific Display State \(VBA\)](#)

Remarks

After calling this method:

1. Call [IDisplayStateSetting::Entities](#) to specify the entities.
2. Call [IDisplayStateSetting::Option](#) to specify the display state scope of the setting.
3. Get or set one or more of the following properties for the specified display states, entities, and scope:
 - [IModelDocExtension::DisplayMode](#)
 - [IModelDocExtension::Transparency](#)
 - [IModelDocExtension::Visibility](#)
4. Call [IModelDocExtension::GetAppearanceSetting](#) to obtain an [IAppearanceSetting](#) object.
5. Set the properties in the [IAppearanceSetting](#) object.
6. Get or set the material properties for the specified display states, entities, and scope using [IModelDocExtension::DisplayStateSpecMaterialPropertyValues](#).

See Also

[IDisplayStateSetting Interface](#)
[IDisplayStateSetting Members](#)
[IDisplayStateSetting::IGetNames Method](#)
[IDisplayStateSetting::ISetNames Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Option Property (IDisplayStateSetting)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayStateSetting Interface](#) : Option Property (IDisplayStateSetting)

Gets and sets the display state scope for this display state setting.

.NET Syntax

Visual Basic (Declaration)

```
Property Option As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDisplayStateSetting  
Dim value As System.Integer  
  
instance.Option = value
```

```
value = instance.Option
```

C#

```
System.int Option {get; set;}
```

C++/CLI

```
property System.int Option {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Scope for this setting as defined in [swDisplayStateOpts_e](#)

Visual Basic for Applications (VBA) Syntax

See [DisplayStateSetting::Option](#).

Example

[Get Display State Settings \(C#\)](#)
[Get Display State Settings \(VB.NET\)](#)
[Get Display State Settings \(VBA\)](#)
[Change Color of Component in Specific Display State \(C#\)](#)
[Change Color of Component in Specific Display State \(VB.NET\)](#)
[Change Color of Component in Specific Display State \(VBA\)](#)

Remarks

After calling this method:

1. Call [IDisplayStateSetting::Names](#) or [IDisplayStateSetting::ISetNames](#) to specify the display states.
2. Call [IDisplayStateSetting::Entities](#) or [IDisplayStateSetting::ISetEntities](#) to specify the entities.
3. Get or set one or more of the following properties for the specified display states, entities, and scope:
 - [IModelDocExtension::DisplayMode](#)
 - [IModelDocExtension::Transparency](#)
 - [IModelDocExtension::Visibility](#)
4. Call [IModelDocExtension::GetAppearanceSetting](#) to obtain an [IAppearanceSetting](#) object.
5. Set the properties in the [IAppearanceSetting](#) object.
6. Get or set the material properties for the specified display states, entities, and scope using [IModelDocExtension::DisplayStateSpecMaterialPropertyValues](#).

See Also

[IDisplayStateSetting Interface](#)
[IDisplayStateSetting Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PartLevel Property (IDisplayStateSetting)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayStateSetting Interface](#) : PartLevel Property (IDisplayStateSetting)

Gets or sets whether to set at the part level.

.NET Syntax

Visual Basic (Declaration)

```
Property PartLevel As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayStateSetting  
Dim value As System.Boolean
```

```
instance.PartLevel = value  
value = instance.PartLevel
```

C#

```
System.bool PartLevel {get; set;}
```

C++/CLI

```
property System.bool PartLevel {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to set at the part level, false to not

Visual Basic for Applications (VBA) Syntax

See [DisplayStateSetting::PartLevel](#).

Example

[Change Color of Component in Specific Display State \(C#\)](#)
[Change Color of Component in Specific Display State \(VB.NET\)](#)
[Change Color of Component in Specific Display State \(VBA\)](#)

See Also

[IDisplayStateSetting Interface](#)
[IDisplayStateSetting Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveAppearance Property (IDisplayStateSetting)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDisplayStateSetting Interface](#) : RemoveAppearance Property (IDisplayStateSetting)

Gets or sets whether to remove appearances for this display state setting.

.NET Syntax

Visual Basic (Declaration)

```
Property RemoveAppearance As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDisplayStateSetting  
Dim value As System.Boolean
```

```
instance.RemoveAppearance = value  
value = instance.RemoveAppearance
```

C#

```
System.bool RemoveAppearance {get; set;}
```

C++/CLI

```
property System.bool RemoveAppearance {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to remove appearances, false to not

Visual Basic for Applications (VBA) Syntax

See [DisplayStateSetting::RemoveAppearance](#).

See Also

[IDisplayStateSetting Interface](#)
[IDisplayStateSetting Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

IDistanceMateFeatureData (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDistanceMateFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDistanceMateFeatureData Interface

Allows access to a distance mate or a limit distance mate feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IDistanceMateFeatureData
```

Visual Basic (Usage)



```
Dim instance As IDistanceMateFeatureData
```

C#

```
public interface IDistanceMateFeatureData
```

C++/CLI

```
public interface class IDistanceMateFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [DistanceMateFeatureData](#).

Example

[Create and Edit Limit Distance Mate \(VBA\)](#)
[Create and Edit Limit Distance Mate \(C#\)](#)

Remarks

A distance mate places selected items at a specified distance. A limit distance mate is an advanced mate that allows components to move within a range of distances. Use [IDistanceMateFeatureData::IsAdvancedMate](#) to determine whether this is a limit distance mate.

[IMateFeatureData](#) is the parent of this mate interface.

To create either a distance mate or a limit distance mate:

1. Follow general instructions in the [AssemblyDoc::CreateMate](#) Remarks.
2. Specify [IDistanceMateFeatureData::EntitiesToMate](#) or use [IModelDocExtension::SelectByID2](#) to pre-select the entities using Mark = 1.
3. Specify other properties of the DistanceMateFeatureData object.

To edit a distance mate:

1. Access its feature and call [IFeature::GetDefinition](#) to get the MateFeatureData object.
2. Cast the MateFeatureData object to a DistanceMateFeatureData object.
3. Modify the DistanceMateFeatureData object.
4. Call [IFeature::ModifyDefinition](#).

To delete a distance mate, use [IModelDocExtension::DeleteSelection2](#).

Access Diagram

[DistanceMateFeatureData](#)

See Also

[IDistanceMateFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDistanceMateFeatureData Interface Members

[See Also](#) [Properties](#)



The following tables list the members exposed by [IDistanceMateFeatureData](#).

 Public Properties

Name	Description
 Distance	Gets or sets the distance of this distance mate.
 EntitiesToMate	Gets or sets the entities to mate in this distance mate.
 FlipDimension	Gets or sets whether to move entities to opposite sides of the dimension of this distance mate.
 IsAdvancedMate	Gets or sets whether this distance mate is a limit distance mate.
 MateAlignment	Gets or sets the alignment of this distance mate.
 MaximumDistance	Gets or sets the maximum distance of this limit distance mate.
 MinimumDistance	Gets or sets the minimum distance of this limit distance mate.

[Top](#)

 See Also

[IDistanceMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IDistanceMateFeatureData Interface Properties

[See Also](#)



For a list of all members of this type, see [IDistanceMateFeatureData members](#).

 Public Properties

Name	Description
 Distance	Gets or sets the distance of this distance mate.
 EntitiesToMate	Gets or sets the entities to mate in this distance mate.
 FlipDimension	Gets or sets whether to move entities to opposite sides of the dimension of this distance mate.
 IsAdvancedMate	Gets or sets whether this distance mate is a limit distance mate.
 MateAlignment	Gets or sets the alignment of this distance mate.
 MaximumDistance	Gets or sets the maximum distance of this limit distance mate.
 MinimumDistance	Gets or sets the minimum distance of this limit distance mate.

[Top](#)

 See Also

[IDistanceMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

Distance Property (IDistanceMateFeatureData)

[See Also](#)



Gets or sets the distance of this distance mate.

 .NET Syntax

Visual Basic (Declaration)

Property Distance As System.Double

Visual Basic (Usage)



```
Dim instance As IDistanceMateFeatureData
Dim value As System.Double

instance.Distance = value

value = instance.Distance
```

C#

```
System.double Distance {get; set;}
```

C++/CLI

```
property System.double Distance {
    System.double get();
    void set ( &    System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance between mates

Visual Basic for Applications (VBA) Syntax

See [DistanceMateFeatureData::Distance](#).

Example

See the [IDistanceMateFeatureData](#) examples.

Remarks

If [IDistanceMateFeatureData::IsAdvancedMate](#) is true, then this property specifies the starting distance of this mate.

See Also

[IDistanceMateFeatureData Interface](#)
[IDistanceMateFeatureData Members](#)
[IDistanceMateFeatureData::MaximumDistance Property \(\)](#)
[IDistanceMateFeatureData::MinimumDistance Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EntitiesToMate Property (IDistanceMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDistanceMateFeatureData Interface](#) : EntitiesToMate Property (IDistanceMateFeatureData)

Gets or sets the entities to mate in this distance mate.

.NET Syntax

Visual Basic (Declaration)

```
Property EntitiesToMate As System.Object
```

Visual Basic (Usage)

```
Dim instance As IDistanceMateFeatureData
Dim value As System.Object

instance.EntitiesToMate = value
```



Copy Code

```
value = instance.EntitiesToMate
```

C#

```
System.Object EntitiesToMate {get; set;}
```

C++/CLI

```
property System.Object^ EntitiesToMate {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of entities to mate (see **Remarks**)

 Visual Basic for Applications (VBA) Syntax

See [DistanceMateFeatureData::EntitiesToMate](#).

 Example

See the [IDistanceMateFeatureData](#) examples.

 Remarks

You can create distance mates with the following mate entity combinations:

Mate entity/Mate entity	IRefAxis , IFace2 (cone)	ICurve (arc, spline, helix)	IRefAxis , IFace2 (cylinder)	IEdge , IRefAxis , ICenterLine , ISketchLine (line)	IRefPlane , IFace2	IRefPoint , IVertex , ISketchPoint	ISurface , IFace2 (sphere)
IRefAxis , IFace2 (cone)	• Both cones must be of the same half angle						
ICurve (arc, spline, helix)						•	
IRefAxis , IFace2 (cylinder)			•	•	•	•	
IEdge , IRefAxis , ICenterLine , ISketchLine (line)			•	•	•	•	•
IRefPlane , IFace2			•	•	•	•	•
IRefPoint , IVertex , ISketchPoint		•	•	•	•	•	•
ISurface , IFace2 (sphere)				•	•	•	•

 See Also

[IDistanceMateFeatureData Interface](#)
[IDistanceMateFeatureData Members](#)

 Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic](#).

FlipDimension Property (IDistanceMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDistanceMateFeatureData Interface](#) : FlipDimension Property (IDistanceMateFeatureData)

Gets or sets whether to move entities to opposite sides of the dimension of this distance mate.

 .NET Syntax

Visual Basic (Declaration)

Property FlipDimension As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDistanceMateFeatureData
Dim value As System.Boolean

instance.FlipDimension = value

value = instance.FlipDimension
```

C#

```
System.bool FlipDimension {get; set;}
```

C++/CLI

```
property System.bool FlipDimension {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flip the dimension, false to not

Visual Basic for Applications (VBA) Syntax

See [DistanceMateFeatureData::FlipDimension](#).

Example

See the [IDistanceMateFeatureData](#) examples.

See Also

[IDistanceMateFeatureData Interface](#)
[IDistanceMateFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsAdvancedMate Property (IDistanceMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDistanceMateFeatureData Interface](#) : IsAdvancedMate Property (IDistanceMateFeatureData)

Gets or sets whether this distance mate is a limit distance mate.

.NET Syntax

Visual Basic (Declaration)

Property IsAdvancedMate As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDistanceMateFeatureData
Dim value As System.Boolean

instance.IsAdvancedMate = value

value = instance.IsAdvancedMate
```

C#

```
System.bool IsAdvancedMate {get; set;}
```

C++/CLI

```
property System.bool IsAdvancedMate {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if a limit distance mate, false if a standard distance mate

Visual Basic for Applications (VBA) Syntax

See [DistanceMateFeatureData::IsAdvancedMate](#).

See Also

[IDistanceMateFeatureData Interface](#)
[IDistanceMateFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MateAlignment Property (IDistanceMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDistanceMateFeatureData Interface](#) : MateAlignment Property (IDistanceMateFeatureData)

Gets or sets the alignment of this distance mate.

.NET Syntax

Visual Basic (Declaration)

```
Property MateAlignment As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDistanceMateFeatureData  
Dim value As System.Integer  
  
instance.MateAlignment = value  
value = instance.MateAlignment
```

C#

```
System.int MateAlignment {get; set;}
```

C++/CLI

```
property System.int MateAlignment {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Mate alignment as defined in [swMateAlign_e](#)

Visual Basic for Applications (VBA) Syntax

See [DistanceMateFeatureData::MateAlignment](#).

Example

See the [IDistanceMateFeatureData](#) examples.

See Also

[IDistanceMateFeatureData Interface](#)
[IDistanceMateFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MaximumDistance Property (IDistanceMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDistanceMateFeatureData Interface](#) : MaximumDistance Property (IDistanceMateFeatureData)

Gets or sets the maximum distance of this limit distance mate.

.NET Syntax

Visual Basic (Declaration)

```
Property MaximumDistance As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDistanceMateFeatureData  
Dim value As System.Double  
  
instance.MaximumDistance = value  
  
value = instance.MaximumDistance
```

C#

```
System.double MaximumDistance {get; set;}
```

C++/CLI

```
property System.double MaximumDistance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Maximum distance

Visual Basic for Applications (VBA) Syntax

See [DistanceMateFeatureData::MaximumDistance](#).

Example

See the [IDistanceMateFeatureData](#) examples.

Remarks

This property is valid only if [IDistanceMateFeatureData::IsAdvancedMate](#) is set to true.

See Also

[IDistanceMateFeatureData Interface](#)
[IDistanceMateFeatureData Members](#)
[IDistanceMateFeatureData::Distance Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MinimumDistance Property (IDistanceMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDistanceMateFeatureData Interface](#) : MinimumDistance Property (IDistanceMateFeatureData)

Gets or sets the minimum distance of this limit distance mate.

.NET Syntax

Visual Basic (Declaration)

Property MinimumDistance As System.Double

Visual Basic (Usage)



```
Dim instance As IDistanceMateFeatureData  
Dim value As System.Double
```

```
instance.MinimumDistance = value
```

```
value = instance.MinimumDistance
```

C#

```
System.double MinimumDistance {get; set;}
```

C++/CLI

```
property System.double MinimumDistance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Minimum distance

Visual Basic for Applications (VBA) Syntax

See [DistanceMateFeatureData::MinimumDistance](#).

Example

See the [IDistanceMateFeatureData](#) examples.

Remarks

This property is valid only if [IDistanceMateFeatureData::IsAdvancedMate](#) is set to true.

See Also

[IDistanceMateFeatureData Interface](#)
[IDistanceMateFeatureData Members](#)
[IDistanceMateFeatureData::Distance Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

IDocumentSpecification (Type)

IDocumentSpecification Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDocumentSpecification Interface

Allows you to specify how to open a model document. Use this interface's properties before calling [ISldWorks::OpenDoc7](#) to specify how you want to open a model document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IDocumentSpecification
```

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification
```

C#

```
public interface IDocumentSpecification
```

C++/CLI

```
public interface class IDocumentSpecification
```

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification](#).

Example

See the [IPLMObjectSpecification](#) examples.

Example

[Hide All Edges in Drawing View \(VBA\)](#)
[Open Drawing Document Read-only \(VBA\)](#)
[Get Whether Components Are Loaded \(C#\)](#)
[Get Whether Components Are Loaded \(VB.NET\)](#)
[Get Whether Components Are Loaded \(VBA\)](#)
[Open Assembly Document \(C#\)](#)
[Open Assembly Document \(VB.NET\)](#)
[Open Assembly Document \(VBA\)](#)

Remarks

The following properties are not valid when opening a 3DEXPERIENCE file using [SOLIDWORKS Design connected to the 3DEXPERIENCE platform](#):

- [IDocumentSpecification::FileName](#)
- [IDocumentSpecification::ConfigurationName](#)
- [IDocumentSpecification::DocumentType](#)
- [IDocumentSpecification::DisplayState](#)
- [IDocumentSpecification::InteractiveAdvancedOpen](#)
- [IDocumentSpecification::InteractiveComponentSelection](#)
- [IDocumentSpecification::LoadExternalReferencesInMemory](#)

Accessors

[ISldWorks::GetOpenDocSpec](#)

Access Diagram

[DocumentSpecification](#)

See Also

[IDocumentSpecification Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISldWorks::OpenDoc6 Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDocumentSpecification Interface Members

[See Also](#) [Properties](#)

[SolidWorks.Interop.sldworks Namespace](#) : IDocumentSpecification Interface

The following tables list the members exposed by [IDocumentSpecification](#).

Public Properties

Name	Description
 AddToRecentDocumentList	Gets or sets whether to add the opened document to the Recent Documents list.
 AutoRepair	Gets or sets whether to automatically repair non-critical custom properties errors in the file to be opened.
 ComponentList	Gets or sets the selected components to load when opening an assembly document.
 ConfigurationName	Gets or sets the name of the configuration to load when opening a model document.
 CriticalDataRepair	Gets or sets whether to automatically repair critical data errors in the file to be opened.
 DetailingMode	Gets or sets whether this drawing document is in detailing mode.
 DisplayState	Gets or sets the name of the display state to use when opening a model document.
 DocumentType	Gets or sets the type of model document to open.
 Error	Gets or sets the file load errors when opening a model document.
 FileName	Gets or sets the path and filename of the model document to open.
 IgnoreHiddenComponents	Gets or sets whether to load hidden components when opening an assembly or drawing document.
 InteractiveAdvancedOpen	Gets whether to display an intermediate dialog, which allows the interactive user to set options before opening a document.
 InteractiveComponentSelection	Gets whether to display the Selective Open dialog, which allows the interactive user to either select and open specific components or open all of the displayed components.
 LightWeight	Gets or sets whether to open an assembly or drawing document with lightweight parts.
 LoadExternalReferencesInMemory	Gets or sets whether to load external references in memory when opening a document.
 LoadModel	Gets or sets whether to load the model if the document is a detached drawing.
 PLMObjectSpecification	Gets the specification of this SOLIDWORKS Design connected to the 3DEXPERIENCE platform document.
 Query	Gets or sets whether the options passed during a document's open, load, and save can be retrieved by this API.
 ReadOnly	Gets or sets whether the model document is opened read-only or read-write.
 Selective	Gets or sets whether to open a document in Quick view (parts and drawings) or Quick view / Selective (assemblies) mode.
 SheetName	Gets or sets the name of the sheet in a drawing document to open.
 Silent	Gets or sets whether to open the model document silently.
 UseLightWeightDefault	Gets or sets whether to use the system default lightweight setting.
 UseSpeedPak	Gets or sets whether to open an assembly document using the SpeedPak option.
 ViewOnly	Gets or sets whether to open the assembly document in Large Design Review mode.
 Warning	Gets or sets any file load warnings when opening a model document.

[Top](#)

See Also

[IDocumentSpecification Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISldWorks::OpenDoc6 Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDocumentSpecification Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IDocumentSpecification Interface

For a list of all members of this type, see [IDocumentSpecification members](#).

 Public Properties

Name	Description
 AddToRecentDocumentList	Gets or sets whether to add the opened document to the Recent Documents list.
 AutoRepair	Gets or sets whether to automatically repair non-critical custom properties errors in the file to be opened.
 ComponentList	Gets or sets the selected components to load when opening an assembly document.
 ConfigurationName	Gets or sets the name of the configuration to load when opening a model document.
 CriticalDataRepair	Gets or sets whether to automatically repair critical data errors in the file to be opened.
 DetailingMode	Gets or sets whether this drawing document is in detailing mode.
 DisplayState	Gets or sets the name of the display state to use when opening a model document.
 DocumentType	Gets or sets the type of model document to open.
 Error	Gets or sets the file load errors when opening a model document.
 FileName	Gets or sets the path and filename of the model document to open.
 IgnoreHiddenComponents	Gets or sets whether to load hidden components when opening an assembly or drawing document.
 InteractiveAdvancedOpen	Gets whether to display an intermediate dialog, which allows the interactive user to set options before opening a document.
 InteractiveComponentSelection	Gets whether to display the Selective Open dialog, which allows the interactive user to either select and open specific components or open all of the displayed components.
 LightWeight	Gets or sets whether to open an assembly or drawing document with lightweight parts.
 LoadExternalReferencesInMemory	Gets or sets whether to load external references in memory when opening a document.
 LoadModel	Gets or sets whether to load the model if the document is a detached drawing.
 PLMObjectSpecification	Gets the specification of this SOLIDWORKS Design connected to the 3DEXPERIENCE platform document.
 Query	Gets or sets whether the options passed during a document's open, load, and save can be retrieved by this API.
 ReadOnly	Gets or sets whether the model document is opened read-only or read-write.
 Selective	Gets or sets whether to open a document in Quick view (parts and drawings) or Quick view / Selective (assemblies) mode.
 SheetName	Gets or sets the name of the sheet in a drawing document to open.
 Silent	Gets or sets whether to open the model document silently.
 UseLightWeightDefault	Gets or sets whether to use the system default lightweight setting.
 UseSpeedPak	Gets or sets whether to open an assembly document using the SpeedPak option.
 ViewOnly	Gets or sets whether to open the assembly document in Large Design Review mode.
 Warning	Gets or sets any file load warnings when opening a model document.

[Top](#)

 See Also

[IDocumentSpecification Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISldWorks::OpenDoc6 Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddToRecentDocumentList Property (IDocumentSpecification)

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : AddToRecentDocumentList Property (IDocumentSpecification)

Gets or sets whether to add the opened document to the Recent Documents list.

 .NET Syntax

Visual Basic (Declaration)

Property AddToRecentDocumentList As System.Integer

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification  
Dim value As System.Integer  
  
instance.AddToRecentDocumentList = value  
  
value = instance.AddToRecentDocumentList
```

C#

```
System.int AddToRecentDocumentList {get; set;}
```

C++/CLI

```
property System.int AddToRecentDocumentList {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Recent Document list actions as defined by [swAddToRecentDocumentList](#) e

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::AddToRecentDocumentList](#).

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)

Availability

SOLIDWORKS 2022 SP03, Revision Number 30.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

AutoRepair Property (IDocumentSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : AutoRepair Property (IDocumentSpecification)

Gets or sets whether to automatically repair non-critical custom properties errors in the file to be opened.

.NET Syntax

Visual Basic (Declaration)

Property AutoRepair As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification  
Dim value As System.Boolean  
  
instance.AutoRepair = value  
  
value = instance.AutoRepair
```

C#

```
System.bool AutoRepair {get; set;}
```

C++/CLI

```
property System.bool AutoRepair {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to automatically repair custom properties errors, false to not (default) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::AutoRepair](#).

Remarks

This property is valid only if [IDocumentSpecification::Silent](#) is set to true.

If the document to be opened has a non-critical data error, the non-critical data error may or may not be repaired, depending on how you set this property and other conditions.

If you set this property to true, and the file to open has non-critical data corruption in:

- The custom properties area, the repair proceeds, and [ISldWorks::OpenDoc7](#) returns the document with warning, [swFileLoadWarning_e.swFileLoadWarning_AutomaticRepair](#).
- An area other than custom properties, the document is not repaired.

The following files are created in `c:\Users\user\AppData\Local\Temp`:

- **Repaired_file_name.sld***
- **Backup of file_name.sld***

If you set this property to false, and the file to open has non-critical data corruption:

- The document is not repaired.
- The document does not open.
- [ISldWorks::OpenDoc7](#) fails and returns null with error code, [swFileLoadError_e.FileRequiresAutoRepair](#).

If critical data corruption exists in the file, and you set [IDocumentSpecification::CriticalDataRepair](#) to true to handle critical data corruption:

- Non-critical data corruptions are ignored and not repaired.
- Repairing critical errors necessitates obliterating all non-critical data.

Use For C++ only, VARIANT_TRUE (-1) automatically repairs the file, and VARIANT_FALSE (0) does not.

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ComponentList Property (IDocumentSpecification)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : ComponentList Property (IDocumentSpecification)

Gets or sets the selected components to load when opening an assembly document.

.NET Syntax

Visual Basic (Declaration)

```
Property ComponentList As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification
Dim value As System.Object
```

```
instance.ComponentList = value
```

```
value = instance.ComponentList
```

C#

```
System.Object ComponentList {get; set;}
```

C++/CLI

```
property System.Object^ ComponentList {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Selected components to open when opening an assembly document (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::ComponentList](#).

Example

[Get Whether Components Are Loaded \(C#\)](#)
[Get Whether Components Are Loaded \(VB.NET\)](#)
[Get Whether Components Are Loaded \(VBA\)](#)
[Open Assembly Document \(C#\)](#)
[Open Assembly Document \(VB.NET\)](#)
[Open Assembly Document \(VBA\)](#)

Remarks

Use [IDocumentSpecification::Selective](#) to specify to load only selected components when opening an assembly document.

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)
[IDocumentSpecification::InteractiveComponentSelection Property](#)

Availability

SolidWorks 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ConfigurationName Property (IDocumentSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : ConfigurationName Property (IDocumentSpecification)

Gets or sets the name of the configuration to load when opening a model document.

Visual Basic .NET Syntax

Visual Basic (Declaration)

```
Property ConfigurationName As System.String
```

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification  
Dim value As System.String
```

```
instance.ConfigurationName = value
```

```
value = instance.ConfigurationName
```

C#

```
System.string ConfigurationName {get; set;}
```

C++/CLI

```
property System.String^ ConfigurationName {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of configuration to load

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::ConfigurationName](#).

Remarks

This property is not valid for opening 3DEXPERIENCE files using [SOLIDWORKS Design connected to the 3DEXPERIENCE platform](#).

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CriticalDataRepair Property (IDocumentSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : CriticalDataRepair Property (IDocumentSpecification)

Gets or sets whether to automatically repair critical data errors in the file to be opened.

.NET Syntax

Visual Basic (Declaration)

```
Property CriticalDataRepair As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification
Dim value As System.Boolean
```

```
instance.CriticalDataRepair = value
```

```
value = instance.CriticalDataRepair
```

C#

```
System.bool CriticalDataRepair {get; set;}
```

C++/CLI

```
property System.bool CriticalDataRepair {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to automatically repair critical data errors, false to not

Visual Basic for Applications (VBA) Syntax

See [IDocumentSpecification::CriticalDataRepair](#).

Remarks

This property is valid only if [IDocumentSpecification::Silent](#) is set to true.

If you set this property to true, and the file to open has critical data corruption:

- Critical data repair proceeds.
- [ISldWorks::OpenDoc7](#) returns the document with warning, [swFileLoadWarning_e.swFileLoadWarning_CriticalDataRepair](#).
- All non-critical data errors are ignored, because repairing critical errors obliterates all non-critical data in the file.

If set to true, this property instructs SOLIDWORKS to repair critical data by importing Parasolid bodies into a new file. The repaired file contains only Parasolid bodies.

The following files are created in c:\Users\user\AppData\Local\Temp:

- **Repaired_file_name.sld***
- **Backup of file_name.sld***

If you set this property to false, and the file to open has critical data corruption:

- The document does not open.
- [ISldWorks::OpenDoc7](#) fails and returns null with error code, [swFileLoadError_e.FileRequiresCriticalDataRepair](#).

Use [IDocumentSpecification::AutoRepair](#) to handle non-critical data corruption of files.

For C++ only, VARIANT_TRUE (-1) automatically repairs the file, and VARIANT_FALSE (0) does not.

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DetailingMode Property (IDocumentSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : DetailingMode Property (IDocumentSpecification)

Gets or sets whether this drawing document is in detailing mode.

.NET Syntax

Visual Basic (Declaration)

Property DetailingMode As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification  
Dim value As System.Boolean
```

```
instance.DetailingMode = value
```

```
value = instance.DetailingMode
```

C#

```
System.bool DetailingMode {get; set;}
```

C++/CLI

```
property System.bool DetailingMode {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if in detailing mode, false if not

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::DetailingMode](#).

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DisplayState Property (IDocumentSpecification)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : DisplayState Property (IDocumentSpecification)

Gets or sets the name of the display state to use when opening a model document.

.NET Syntax

Visual Basic (Declaration)

Property DisplayState As System.String

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification  
Dim value As System.String
```

```
instance.DisplayState = value
```

```
value = instance.DisplayState
```

C#

```
System.string DisplayState {get; set;}
```

C++/CLI

```
property System.String^ DisplayState {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the display state to use

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::DisplayState](#).

Example

[Get Whether Components Are Loaded \(C#\)](#)
[Get Whether Components Are Loaded \(VB.NET\)](#)
[Get Whether Components Are Loaded \(VBA\)](#)
[Open Assembly Document \(C#\)](#)
[Open Assembly Document \(VB.NET\)](#)
[Open Assembly Document \(VBA\)](#)

Remarks

This property is not valid for opening 3DEXPERIENCE files using [SOLIDWORKS Design connected to the 3DEXPERIENCE platform](#).

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DocumentType Property (IDocumentSpecification)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : DocumentType Property (IDocumentSpecification)

Gets or sets the type of model document to open.

.NET Syntax

Visual Basic (Declaration)

```
Property DocumentType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification  
Dim value As System.Integer
```

```
instance.DocumentType = value
```

```
value = instance.DocumentType
```

C#

```
System.int DocumentType {get; set;}
```

C++/CLI

```
property System.int DocumentType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of document as defined by [swDocumentTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::DocumentType](#).

Example

[Open Drawing Document Read-only \(VBA\)](#)
[Get Whether Components Are Loaded \(C#\)](#)
[Get Whether Components Are Loaded \(VB.NET\)](#)
[Get Whether Components Are Loaded \(VBA\)](#)
[Open Assembly Document \(C#\)](#)
[Open Assembly Document \(VB.NET\)](#)
[Open Assembly Document \(VBA\)](#)

Remarks

This property is not valid for opening 3DEXPERIENCE files using [SOLIDWORKS Design connected to the 3DEXPERIENCE platform](#).

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Error Property (IDocumentSpecification)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : Error Property (IDocumentSpecification)

Gets or sets the file load errors when opening a model document.

.NET Syntax

Visual Basic (Declaration)

Property Error As System.Integer

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification
Dim value As System.Integer
```

```
instance.Error = value
```

```
value = instance.Error
```

C#

```
System.int Error {get; set;}
```

C++/CLI

```
property System.int Error {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

File load errors as defined by [swFileLoadError_e](#)

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::Error](#).

Example

[Open Drawing Document Read-only \(VBA\)](#)
[Open Assembly Document \(C#\)](#)
[Open Assembly Document \(VB.NET\)](#)
[Open Assembly Document \(VBA\)](#)

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FileName Property (IDocumentSpecification)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : FileName Property (IDocumentSpecification)

Gets or sets the path and filename of the model document to open.

Visual Basic (Declaration)

```
Property FileName As System.String
```

Visual Basic (Usage)

```
Dim instance As IDocumentSpecification
Dim value As System.String

instance.FileName = value

value = instance.FileName
```

C#

```
System.string FileName {get; set;}
```

C++/CLI

```
property System.String^ FileName {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path and filename of the model document to open

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::FileName](#).

Example

[Open Drawing Document Read-only \(VBA\)](#)
[Get Whether Components Are Loaded \(C#\)](#)
[Get Whether Components Are Loaded \(VB.NET\)](#)
[Get Whether Components Are Loaded \(VBA\)](#)
[Open Assembly Document \(C#\)](#)
[Open Assembly Document \(VB.NET\)](#)
[Open Assembly Document \(VBA\)](#)

Remarks

This property is not valid for opening 3DEXPERIENCE files using [SOLIDWORKS Design connected to the 3DEXPERIENCE platform](#).

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IgnoreHiddenComponents Property (IDocumentSpecification)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : IgnoreHiddenComponents Property (IDocumentSpecification)

Gets or sets whether to load hidden components when opening an assembly or drawing document.

Visual Basic (Declaration)

Visual Basic (Declaration)

Property IgnoreHiddenComponents As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification  
Dim value As System.Boolean  
  
instance.IgnoreHiddenComponents = value  
value = instance.IgnoreHiddenComponents
```

C#

```
System.bool IgnoreHiddenComponents {get; set;}
```

C++/CLI

```
property System.bool IgnoreHiddenComponents {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to load hidden components, false to not

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::IgnoreHiddenComponents](#).

Example

[Get Whether Components Are Loaded \(C#\)](#)
[Get Whether Components Are Loaded \(VB.NET\)](#)
[Get Whether Components Are Loaded \(VBA\)](#)
[Open Assembly Document \(C#\)](#)
[Open Assembly Document \(VB.NET\)](#)
[Open Assembly Document \(VBA\)](#)

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)
[IAssemblyDoc::GetUnloadedComponentNames Method](#)
[IAssemblyDoc::HasUnloadedComponents Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InteractiveAdvancedOpen Property (IDocumentSpecification)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : InteractiveAdvancedOpen Property (IDocumentSpecification)

Gets whether to display an intermediate dialog, which allows the interactive user to set options before opening a document.

.NET Syntax

Visual Basic (Declaration)

Property InteractiveAdvancedOpen As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification  
Dim value As System.Boolean
```

```
instance.InteractiveAdvancedOpen = value  
value = instance.InteractiveAdvancedOpen
```

C#

```
System.bool InteractiveAdvancedOpen {get; set;}
```

C++/CLI

```
property System.bool InteractiveAdvancedOpen {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to display an intermediate dialog to the interactive user, false to not (default)

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::InteractiveAdvancedOpen](#).

Example

[Open Advanced Dialog On Document Open \(VBA\)](#)
[Open Advanced Dialog On Document Open \(VB.NET\)](#)
[Open Advanced Dialog On Document Open \(C#\)](#)

Remarks

This property is not valid for opening 3DEXPERIENCE files using [SOLIDWORKS Design connected to the 3DEXPERIENCE platform](#).

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InteractiveComponentSelection Property (IDocumentSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : InteractiveComponentSelection Property (IDocumentSpecification)

Gets whether to display the Selective Open dialog, which allows the interactive user to either select and open specific components or open all of the displayed components.

.NET Syntax

Visual Basic (Declaration)

```
Property InteractiveComponentSelection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification  
Dim value As System.Boolean  
  
instance.InteractiveComponentSelection = value  
value = instance.InteractiveComponentSelection
```

C#

```
System.bool InteractiveComponentSelection {get; set;}
```

C++/CLI

```
property System.bool InteractiveComponentSelection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to display the Selective Open dialog to the interactive user, false to not (default)

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::InteractiveComponentSelection](#).

Remarks

This property is not valid for opening 3DEXPERIENCE files using [SOLIDWORKS Design connected to the 3DEXPERIENCE platform](#).

If this property is set to true, than any components added to the components list by [IDocumentSpecification::ComponentList](#) are ignored.

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)
[IDocumentSpecification::Selective Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

LightWeight Property (IDocumentSpecification)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : LightWeight Property (IDocumentSpecification)

Gets or sets whether to open an assembly or drawing document with lightweight parts.

.NET Syntax

Visual Basic (Declaration)

```
Property LightWeight As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification  
Dim value As System.Boolean
```

```
instance.LightWeight = value
```

```
value = instance.LightWeight
```

C#

```
System.bool LightWeight {get; set;}
```

C++/CLI

```
property System.bool LightWeight {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to open the assembly or drawing document with lightweight parts, false to not

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::LightWeight](#).

Example

[Get Whether Components Are Loaded \(C#\)](#)
[Get Whether Components Are Loaded \(VB.NET\)](#)
[Get Whether Components Are Loaded \(VBA\)](#)
[Open Assembly Document \(C#\)](#)
[Open Assembly Document \(VB.NET\)](#)
[Open Assembly Document \(VBA\)](#)

Remarks

[IDocumentSpecification::UseLightWeightDefault](#) must be false for this property to have an effect.

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LoadExternalReferencesInMemory Property (IDocumentSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : LoadExternalReferencesInMemory Property (IDocumentSpecification)

Gets or sets whether to load external references in memory when opening a document.

.NET Syntax

Visual Basic (Declaration)

Property LoadExternalReferencesInMemory As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification  
Dim value As System.Boolean  
  
instance.LoadExternalReferencesInMemory = value  
  
value = instance.LoadExternalReferencesInMemory
```

C#

```
System.bool LoadExternalReferencesInMemory {get; set;}
```

C++/CLI

```
property System.bool LoadExternalReferencesInMemory {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to load external references in memory, false (default) to not

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::LoadExternalReferencesInMemory](#).

Remarks

This property is:

- not valid for opening 3DEXPERIENCE files using [SOLIDWORKS Design connected to the 3DEXPERIENCE platform](#).
- valid only if [swUserPreferenceIntegerValue_e.swLoadExternalReferences](#) is not set to [swLoadExternalReferences_e.swLoadExternalReferences_None](#).

Note: The **System Options > External References > Load documents in memory only** user preference and [swUserPreferenceToggle_e.swExtRefLoadRefDocsInMemory](#) are ignored when opening documents through the API because this method and [ISldWorks::OpenDoc6](#) ([swOpenDocOptions_e.swOpenDocOptions_LoadExternalReferencesInMemory](#)) have sole control of reference loading.

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LoadModel Property (IDocumentSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : LoadModel Property (IDocumentSpecification)

Gets or sets whether to load the model if the document is a detached drawing.

.NET Syntax

Visual Basic (Declaration)

```
Property LoadModel As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification  
Dim value As System.Boolean  
  
instance.LoadModel = value  
value = instance.LoadModel
```

C#

```
System.bool LoadModel {get; set;}
```

C++/CLI

```
property System.bool LoadModel {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to load the model, false to not

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::LoadModel](#).

Remarks

To avoid a warning when opening shaded modes in views, set this property to TRUE so that the view is automatically loaded in shaded.

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PLMObjectSpecification Property (IDocumentSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : PLMObjectSpecification Property (IDocumentSpecification)

Gets the specification of this [SOLIDWORKS Design connected to the 3DEXPERIENCE platform](#) document.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property PLMObjectSpecification As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification  
Dim value As System.Object  
  
value = instance.PLMObjectSpecification
```

C#

```
System.Object PLMObjectSpecification {get;}
```

C++/CLI

```
property System.Object^ PLMObjectSpecification {  
    System.Object^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IPLMObjectSpecification](#)

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::PLMObjectSpecification](#).

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)

Availability

SOLIDWORKS 2020 SP3.1, Revision Number 28.3.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Query Property (IDocumentSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : Query Property (IDocumentSpecification)

Gets or sets whether the options passed during a document's open, load, and save can be retrieved by this API.

Visual Basic Syntax

Visual Basic (Declaration)

Property Query As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification  
Dim value As System.Boolean  
  
instance.Query = value  
value = instance.Query
```

C#

```
System.bool Query {get; set;}
```

C++/CLI

```
property System.bool Query {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to retrieve options, false to not (default)

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::Query](#).

Remarks

Various options can be passed to document operation APIs such as [IModelDoc2::Save3](#), [IModelDocExtension::SaveAs4](#), and [ISldWorks::LoadFile4](#). These options can be retrieved from the document, if Query is set to true. Only silent information can be retrieved.

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReadOnly Property (IDocumentSpecification)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : ReadOnly Property (IDocumentSpecification)

Gets or sets whether the model document is opened read-only or read-write.

Visual Basic Syntax

Visual Basic (Declaration)

Property ReadOnly As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification  
Dim value As System.Boolean
```

```
instance.ReadOnly = value  
value = instance.ReadOnly
```

C#

```
System.bool ReadOnly {get; set;}
```

C++/CLI

```
property System.bool ReadOnly {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the model document is opened read-only, false if read-write

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::ReadOnly](#).

Example

[Open Drawing Document Read-only \(VBA\)](#)

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Selective Property (IDocumentSpecification)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : Selective Property (IDocumentSpecification)

Gets or sets whether to open a document in **Quick view** (parts and drawings) or **Quick view / Selective** (assemblies) mode.

.NET Syntax

Visual Basic (Declaration)

```
Property Selective As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification  
Dim value As System.Boolean
```

```
instance.Selective = value  
value = instance.Selective
```

C#

```
System.bool Selective {get; set;}
```

C++/CLI

```
property System.bool Selective {  
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to open the document in **Quick view / Selective open** mode, false to not

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::Selective](#).

Example

[Get Whether Components Are Loaded \(C#\)](#)
[Get Whether Components Are Loaded \(VB.NET\)](#)
[Get Whether Components Are Loaded \(VBA\)](#)
[Open Assembly Document \(C#\)](#)
[Open Assembly Document \(VB.NET\)](#)
[Open Assembly Document \(VBA\)](#)

Remarks

Use [IDocumentSpecification::ComponentList](#) to specify the selected components to load when opening the assembly document.

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)
[IAssemblyDoc::GetUnloadedComponentNames Method](#)
[IAssemblyDoc::HasUnloadedComponents Method](#)
[IComponent2::GetHiddenUnloadedChildrenCount Method](#)
[IComponent2::GetUnloadedComponentNames Method](#)
[IComponent2::HasUnloadedComponents Method](#)
[IDocumentSpecification::InteractiveComponentSelection Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SheetName Property (IDocumentSpecification)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : SheetName Property (IDocumentSpecification)

Gets or sets the name of the sheet in a drawing document to open.

.NET Syntax

Visual Basic (Declaration)

```
Property SheetName As System.String
```

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification  
Dim value As System.String
```

```
instance.SheetName = value
```

```
value = instance.SheetName
```

C#

```
System.string SheetName {get; set;}
```

C++/CLI

```
property System.String^ SheetName {  
    System.String^ get();
```

```
void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Sheet name

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::SheetName](#).

Example

[Open Specified Sheet in Drawing Document \(VB.NET\)](#)
[Open Specified Sheet in Drawing Document \(VBA\)](#)
[Open Specified Sheet in Drawing Document \(C#\)](#)

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)

Availability

SOLIDWORKS 2009 SP4, Revision Number 17.4

SOLIDWORKS API Help

[Send comments](#) on this topic.

Silent Property (IDocumentSpecification)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : Silent Property (IDocumentSpecification)

Gets or sets whether to open the model document silently.

.NET Syntax

Visual Basic (Declaration)

```
Property Silent As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification  
Dim value As System.Boolean
```

```
instance.Silent = value
```

```
value = instance.Silent
```

C#

```
System.bool Silent {get; set;}
```

C++/CLI

```
property System.bool Silent {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to open the model document silently, false to not

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::Silent](#).

Example

[Get Whether Components Are Loaded \(C#\)](#)
[Get Whether Components Are Loaded \(VB.NET\)](#)
[Get Whether Components Are Loaded \(VBA\)](#)
[Open Assembly Document \(C#\)](#)
[Open Assembly Document \(VB.NET\)](#)
[Open Assembly Document \(VBA\)](#)

Remarks

The software uses the last-displayed configuration if it discovers missing configurations or component references. No warnings or errors display if this property is set to true.

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)
[IDocumentSpecification::AutoRepair Property \(\)](#)
[IDocumentSpecification::CriticalDataRepair Property \(\)](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseLightWeightDefault Property (IDocumentSpecification)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : UseLightWeightDefault Property (IDocumentSpecification)

Gets or sets whether to use the system default lightweight setting.

.NET Syntax

Visual Basic (Declaration)

Property UseLightWeightDefault As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification  
Dim value As System.Boolean
```

```
instance.UseLightWeightDefault = value  
value = instance.UseLightWeightDefault
```

C#

```
System.bool UseLightWeightDefault {get; set;}
```

C++/CLI

```
property System.bool UseLightWeightDefault {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the system default lightweight setting, false to use [IDocumentSpecification::Lightweight value](#)

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::UseLightWeightDefault](#).

Example

[Get Whether Components Are Loaded \(C#\)](#)
[Get Whether Components Are Loaded \(VB.NET\)](#)
[Get Whether Components Are Loaded \(VBA\)](#)
[Open Assembly Document \(C#\)](#)
[Open Assembly Document \(VB.NET\)](#)
[Open Assembly Document \(VBA\)](#)

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseSpeedPak Property (IDocumentSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : UseSpeedPak Property (IDocumentSpecification)

Gets or sets whether to open an assembly document using the SpeedPak option.

.NET Syntax

Visual Basic (Declaration)

Property UseSpeedPak As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification  
Dim value As System.Boolean
```

```
instance.UseSpeedPak = value
```

```
value = instance.UseSpeedPak
```

C#

```
System.bool UseSpeedPak {get; set;}
```

C++/CLI

```
property System.bool UseSpeedPak {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use SpeedPak, false to not

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::UseSpeedPak](#).

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)
[IAssemblyDoc::UseSpeedPak Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ViewOnly Property (IDocumentSpecification)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : ViewOnly Property (IDocumentSpecification)

Gets or sets whether to open the assembly document in Large Design Review mode.

.NET Syntax

Visual Basic (Declaration)

```
Property ViewOnly As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification  
Dim value As System.Boolean  
  
instance.ViewOnly = value  
  
value = instance.ViewOnly
```

C#

```
System.bool ViewOnly {get; set;}
```

C++/CLI

```
property System.bool ViewOnly {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to open the assembly in Large Design Review mode, false to not

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::ViewOnly](#).

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)
[IConfiguration::LargeDesignReviewMark Property\(\)](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Warning Property (IDocumentSpecification)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDocumentSpecification Interface](#) : Warning Property (IDocumentSpecification)

Gets or sets any file load warnings when opening a model document.

.NET Syntax

Visual Basic (Declaration)

```
Property Warning As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDocumentSpecification  
Dim value As System.Integer
```

```
instance.Warning = value
```

```
value = instance.Warning
```

C#

```
System.int Warning {get; set;}
```

C++/CLI

```
property System.int Warning {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Warnings as defined by [swFileLoadWarning_e](#)

Visual Basic for Applications (VBA) Syntax

See [DocumentSpecification::Warning](#).

Example

[Open Drawing Document Read-only \(VBA\)](#)
[Open Assembly Document \(C#\)](#)
[Open Assembly Document \(VB.NET\)](#)
[Open Assembly Document \(VBA\)](#)

See Also

[IDocumentSpecification Interface](#)
[IDocumentSpecification Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0