

SOLIDWORKS API (.NET VBA C#) — Reference (80/337): IDomeFeatureData-IDraftFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IDomeFeatureData (Type)

IDomeFeatureData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDomeFeatureData Interface

Obsolete. Superseded by [IDomeFeatureData2](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IDomeFeatureData
```

Visual Basic (Usage)

```
Dim instance As IDomeFeatureData
```

C#

```
public interface IDomeFeatureData
```

C++/CLI

```
public interface class IDomeFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [DomeFeatureData](#).

See Also

[IDomeFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IDomeFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDomeFeatureData Interface

The following tables list the members exposed by [IDomeFeatureData](#).

Public Properties

Name	Description
Elliptical	Obsolete. Superseded by IDomeFeatureData2::Elliptical .
Face	Obsolete. Superseded by IDomeFeatureData2::Face .
Height	Obsolete. Superseded by IDomeFeatureData2::Height .
IFace	Obsolete. Superseded by IDomeFeatureData2::IFace .
ReverseDir	Obsolete. Superseded by IDomeFeatureData2::ReverseDir .

[Top](#)

Public Methods

Name	Description
AccessSelections	Obsolete. Superseded by IDomeFeatureData2::AccessSelections .
IAccessSelections	Obsolete. Superseded by IDomeFeatureData2::IAccessSelections .
ReleaseSelectionAccess	Obsolete. Superseded by IDomeFeatureData2::ReleaseSelectionAccess .

[Top](#)

 See Also

[IDomeFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IDomeFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDomeFeatureData Interface

For a list of all members of this type, see [IDomeFeatureData members](#).

 Public Methods

Name	Description
 AccessSelections	Obsolete. Superseded by IDomeFeatureData2::AccessSelections .
 IAccessSelections	Obsolete. Superseded by IDomeFeatureData2::IAccessSelections .
 ReleaseSelectionAccess	Obsolete. Superseded by IDomeFeatureData2::ReleaseSelectionAccess .

[Top](#)

 See Also

[IDomeFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IDomeFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDomeFeatureData Interface

For a list of all members of this type, see [IDomeFeatureData members](#).

 Public Properties

Name	Description
 Elliptical	Obsolete. Superseded by IDomeFeatureData2::Elliptical .
 Face	Obsolete. Superseded by IDomeFeatureData2::Face .
 Height	Obsolete. Superseded by IDomeFeatureData2::Height .
 IFace	Obsolete. Superseded by IDomeFeatureData2::IFace .
 ReverseDir	Obsolete. Superseded by IDomeFeatureData2::ReverseDir .

[Top](#)

 See Also

[IDomeFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AccessSelections Method (IDomeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDomeFeatureData Interface](#) : AccessSelections Method (IDomeFeatureData)

Obsolete. Superseded by [IDomeFeatureData2::AccessSelections](#).

 .NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections(  
    ByVal TopDoc As System.Object, _
```

```
ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDomeFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Component

Visual Basic for Applications (VBA) Syntax

See [DomeFeatureData::AccessSelections](#).

See Also

[IDomeFeatureData Interface](#)
[IDomeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Elliptical Property (IDomeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDomeFeatureData Interface](#) : Elliptical Property (IDomeFeatureData)

Obsolete. Superseded by [IDomeFeatureData2::Elliptical](#).

.NET Syntax

Visual Basic (Declaration)

```
Property Elliptical As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDomeFeatureData  
Dim value As System.Boolean  
  
instance.Elliptical = value  
  
value = instance.Elliptical
```

C#

```
System.bool Elliptical {get; set;}
```

C++/CLI

```
property System.bool Elliptical {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DomeFeatureData::Elliptical](#).

See Also

[IDomeFeatureData Interface](#)
[IDomeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Face Property (IDomeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDomeFeatureData Interface](#) : Face Property (IDomeFeatureData)

Obsolete. Superseded by [IDomeFeatureData2::Face](#).

.NET Syntax

Visual Basic (Declaration)

```
Property Face As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDomeFeatureData  
Dim value As System.Object
```

```
instance.Face = value
```

```
value = instance.Face
```

C#

```
System.object Face {get; set;}
```

C++/CLI

```
property System.Object^ Face {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DomeFeatureData::Face](#).

See Also

[IDomeFeatureData Interface](#)
[IDomeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Height Property (IDomeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDomeFeatureData Interface](#) : Height Property (IDomeFeatureData)

Obsolete. Superseded by [IDomeFeatureData2::Height](#).

.NET Syntax

Visual Basic (Declaration)

Property Height As System.Double

Visual Basic (Usage)



```
Dim instance As IDomeFeatureData  
Dim value As System.Double
```

```
instance.Height = value
```

```
value = instance.Height
```

C#

```
System.double Height {get; set;}
```

C++/CLI

```
property System.double Height {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DomeFeatureData::Height](#).

See Also

[IDomeFeatureData Interface](#)
[IDomeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections Method (IDomeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDomeFeatureData Interface](#) : IAccessSelections Method (IDomeFeatureData)

Obsolete. Superseded by [IDomeFeatureData2::IAccessSelections](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDomeFeatureData  
Dim TopDoc As ModelDoc  
Dim Component As Component  
Dim value As System.Boolean
```

```
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc TopDoc,  
    Component Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc^ TopDoc,  
& Component^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Component

Visual Basic for Applications (VBA) Syntax

See [DomeFeatureData::IAccessSelections](#).

See Also

[IDomeFeatureData Interface](#)
[IDomeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IFace Property (IDomeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDomeFeatureData Interface](#) : IFace Property (IDomeFeatureData)

Obsolete. Superseded by [IDomeFeatureData2::IFace](#).

.NET Syntax

Visual Basic (Declaration)

Property IFace As Face

Visual Basic (Usage)



```
Dim instance As IDomeFeatureData  
Dim value As Face
```

```
instance.IFace = value
```

```
value = instance.IFace
```

C#

```
Face IFace {get; set;}
```

C++/CLI

```
property Face^ IFace {  
    Face^ get();  
    void set ( & Face^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DomeFeatureData::IFace](#).

See Also

[IDomeFeatureData Interface](#)
[IDomeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReleaseSelectionAccess Method (IDomeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDomeFeatureData Interface](#) : ReleaseSelectionAccess Method (IDomeFeatureData)

Obsolete. Superseded by [IDomeFeatureData2::ReleaseSelectionAccess](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IDomeFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DomeFeatureData::ReleaseSelectionAccess](#).

See Also

[IDomeFeatureData Interface](#)
[IDomeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReverseDir Property (IDomeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDomeFeatureData Interface](#) : ReverseDir Property (IDomeFeatureData)

Obsolete. Superseded by [IDomeFeatureData2::ReverseDir](#).

.NET Syntax

Visual Basic (Declaration)

```
Property ReverseDir As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDomeFeatureData  
Dim value As System.Boolean  
  
instance.ReverseDir = value  
  
value = instance.ReverseDir
```

C#

```
System.bool ReverseDir {get; set;}
```

C++/CLI

```
property System.bool ReverseDir {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DomeFeatureData::ReverseDir](#).

See Also

[IDomeFeatureData Interface](#)
[IDomeFeatureData Members](#)

IDomeFeatureData2 (Type)

IDomeFeatureData2 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDomeFeatureData2 Interface

Allows access to a dome feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IDomeFeatureData2
```

Visual Basic (Usage)

```
Dim instance As IDomeFeatureData2
```

C#

```
public interface IDomeFeatureData2
```

C++/CLI

```
public interface class IDomeFeatureData2
```

Visual Basic for Applications (VBA) Syntax

See [DomeFeatureData2](#).

Example

[Create and Modify Dome Feature \(C#\)](#)
[Create and Modify Dome Feature \(VB.NET\)](#)
[Create and Modify Dome Feature \(VBA\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[DomeFeatureData2](#)

See Also

[IDomeFeatureData2 Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertDome Method](#)

IDomeFeatureData2 Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDomeFeatureData2 Interface

For a list of all members of this type, see [IDomeFeatureData2 members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to selections used to define the dome.
 GetFaceCount	Gets the number of planar and non-planar faces of this dome feature.

 AccessSelections	Gains access to selections used to define the dome.
 GetFaces	Gets the planar or non-planar faces of this dome feature.
 SetFaces	Sets the planar or non-planar faces of this dome feature.
 ReleaseSelectionAccess	Releases access to the selections used to define this dome feature.

[Top](#)

 See Also

[IDomeFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertDome Method](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

IDomeFeatureData2 Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDomeFeatureData2 Interface

The following tables list the members exposed by [IDomeFeatureData2](#).

 Public Properties

Name	Description
 ConstraintPointOrSketch	Gets or sets the constraining point or sketch for a dome feature.
 Direction	Gets or sets the direction of the dome feature.
 Elliptical	Gets or sets whether this dome is a half ellipsoid, with a height equal to one of the ellipsoid radii.
 Face	Obsolete. Superseded by IDomeFeatureData2::Faces .
 Faces	Gets or sets the planar or non-planar faces of this dome feature.
 Height	Gets or sets the height of the dome.
 IFace	Obsolete. Superseded by IDomeFeatureData2::Faces .
 ReverseDir	Gets or sets whether this dome is convex or concave.

[Top](#)

 Public Methods

Name	Description
 AccessSelections	Gains access to selections used to define the dome.
 GetFaceCount	Gets the number of planar and non-planar faces of this dome feature.
 AccessSelections	Gains access to selections used to define the dome.
 GetFaces	Gets the planar or non-planar faces of this dome feature.
 SetFaces	Sets the planar or non-planar faces of this dome feature.
 ReleaseSelectionAccess	Releases access to the selections used to define this dome feature.

[Top](#)

 See Also

[IDomeFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertDome Method](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

IDomeFeatureData2 Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDomeFeatureData2 Interface

For a list of all members of this type, see [IDomeFeatureData2 members](#).

Public Properties

Name	Description
 ConstrainPointOrSketch	Gets or sets the constraining point or sketch for a dome feature.
 Direction	Gets or sets the direction of the dome feature.
 Elliptical	Gets or sets whether this dome is a half ellipsoid, with a height equal to one of the ellipsoid radii.
 Face	Obsolete. Superseded by IDomeFeatureData2.Faces .
 Faces	Gets or sets the planar or non-planar faces of this dome feature.
 Height	Gets or sets the height of the dome.
 IFace	Obsolete. Superseded by IDomeFeatureData2.Faces .
 ReverseDir	Gets or sets whether this dome is convex or concave.

[Top](#)

See Also

[IDomeFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2.InsertDome Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IDomeFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDomeFeatureData2 Interface](#) : AccessSelections Method (IDomeFeatureData2)

Gains access to selections used to define the dome.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections(  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDomeFeatureData2  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top level document (see **Remarks**)

Component
Component for the feature (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [DomeFeatureData2::AccessSelections](#).

Example

[Change Height of Dome Feature \(VBA\)](#)
[Get and Set Constraint for Dome Feature \(VBA\)](#)
[Create and Modify Dome Feature \(C#\)](#)
[Create and Modify Dome Feature \(VB.NET\)](#)
[Create and Modify Dome Feature \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is <code>NULL</code>
Assembly	- TopDoc is the <code>IModelDoc2</code> object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IDomeFeatureData2::ReleaseSelectionAccess](#) if you did not

See Also

[IDomeFeatureData2 Interface](#)
[IDomeFeatureData2 Members](#)
[IDomeFeatureData2::IAccessSelections Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ConstraintPointOrSketch Property (IDomeFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDomeFeatureData2 Interface](#) : ConstraintPointOrSketch Property (IDomeFeatureData2)

Gets or sets the constraining point or sketch for a dome feature.

.NET Syntax

Visual Basic (Declaration)

Property ConstraintPointOrSketch As System.Object

Visual Basic (Usage)



```
Dim instance As IDomeFeatureData2  
Dim value As System.Object  
  
instance.ConstraintPointOrSketch = value  
  
value = instance.ConstraintPointOrSketch
```

C#

```
System.object ConstraintPointOrSketch {get; set;}
```

C++/CLI

```
property System.Object^ ConstraintPointOrSketch {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Point or sketch for the dome feature

Visual Basic for Applications (VBA) Syntax

See [DomeFeatureData2::ConstraintPointOrSketch](#).

Example

[Get and Set Constraint for Dome Feature \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IDomeFeatureData2 Interface](#)
[IDomeFeatureData2 Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Direction Property (IDomeFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDomeFeatureData2 Interface](#) : Direction Property (IDomeFeatureData2)

Gets or sets the direction of the dome feature.

.NET Syntax

Visual Basic (Declaration)

Property Direction As System.Object

Visual Basic (Usage)



```
Dim instance As IDomeFeatureData2  
Dim value As System.Object
```

```
instance.Direction = value
```

```
value = instance.Direction
```

C#

```
System.object Direction {get; set;}
```

C++/CLI

```
property System.Object^ Direction {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Edge indicating the direction of dome feature

Visual Basic for Applications (VBA) Syntax

See [DomeFeatureData2::Direction](#).

Example

[Get and Set Direction for Dome Feature \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IDomeFeatureData2 Interface](#)
[IDomeFeatureData2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Elliptical Property (IDomeFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDomeFeatureData2 Interface](#) : Elliptical Property (IDomeFeatureData2)

Gets or sets whether this dome is a half ellipsoid, with a height equal to one of the ellipsoid radii.

.NET Syntax

Visual Basic (Declaration)

```
Property Elliptical As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDomeFeatureData2  
Dim value As System.Boolean
```

```
instance.Elliptical = value
```

```
value = instance.Elliptical
```

C#

```
System.bool Elliptical {get; set;}
```

C++/CLI

```
property System.bool Elliptical {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the dome is elliptical, false if it is not

Visual Basic for Applications (VBA) Syntax

See [DomeFeatureData2::Elliptical](#).

Example

[Change Height of Dome \(VBA\)](#)
[Create and Modify Dome Feature \(C#\)](#)
[Create and Modify Dome Feature \(VB.NET\)](#)
[Create and Modify Dome Feature \(VBA\)](#)

Remarks

This property does not affect geometry until you call [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefintion2](#).

See Also

[IDomeFeatureData2 Interface](#)
[IDomeFeatureData2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Face Property (IDomeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDomeFeatureData2 Interface](#) : Face Property (IDomeFeatureData2)

Obsolete. Superseded by [IDomeFeatureData2::Faces](#).

.NET Syntax

Visual Basic (Declaration)

Property Face As System.Object

Visual Basic (Usage)



```
Dim instance As IDomeFeatureData2  
Dim value As System.Object
```

```
instance.Face = value
```

```
value = instance.Face
```

C#

```
System.Object Face {get; set;}
```

C++/CLI

```
property System.Object^ Face {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DomeFeatureData2::Face](#).

See Also

[IDomeFeatureData2 Interface](#)
[IDomeFeatureData2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Faces Property (IDomeFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDomeFeatureData2 Interface](#) : Faces Property (IDomeFeatureData2)

Gets or sets the planar or non-planar faces of this dome feature.

.NET Syntax

Visual Basic (Declaration)

Property Faces As System.Object

Visual Basic (Usage)



```
Dim instance As IDomeFeatureData2  
Dim value As System.Object
```

```
instance.Faces = value
```

```
value = instance.Faces
```

C#

```
System.Object Faces {get; set;}
```

C++/CLI

```
property System.Object^ Faces {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of planar or non-planar [faces](#) of this dome feature

Visual Basic for Applications (VBA) Syntax

See [DomeFeatureData2::Faces](#).

Example

[Create and Modify Dome Feature \(C#\)](#)
[Create and Modify Dome Feature \(VB.NET\)](#)
[Create and Modify Dome Feature \(VBA\)](#)

Remarks

This property does not affect geometry until you call [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefintion2](#).

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IDomeFeatureData2 Interface](#)
[IDomeFeatureData2 Members](#)
[IDomeFeatureData2::!GetFaces Method](#)
[IDomeFeatureData2::!SetFaces Method](#)
[IDomeFeatureData2::GetFaceCount Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFaceCount Method (IDomeFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDomeFeatureData2 Interface](#) : GetFaceCount Method (IDomeFeatureData2)

Gets the number of planar and non-planar faces of this dome feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFaceCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDomeFeatureData2  
Dim value As System.Integer
```

```
value = instance.GetFaceCount()
```

C#

```
System.int GetFaceCount()
```

C++/CLI

```
System.int GetFaceCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of planar and non-planar faces

Visual Basic for Applications (VBA) Syntax

See [DomeFeatureData2::GetFaceCount](#).

Example

[Create and Modify Dome Feature \(C#\)](#)
[Create and Modify Dome Feature \(VB.NET\)](#)
[Create and Modify Dome Feature \(VBA\)](#)

Remarks

Call this method before calling [IDomeFeatureData2::IGetFaces](#).

See Also

[IDomeFeatureData2 Interface](#)
[IDomeFeatureData2 Members](#)
[IDomeFeatureData2::ISetFaces Method](#)
[IDomeFeatureData2::Faces Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Height Property (IDomeFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDomeFeatureData2 Interface](#) : Height Property (IDomeFeatureData2)

Gets or sets the height of the dome.

.NET Syntax

Visual Basic (Declaration)

```
Property Height As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDomeFeatureData2  
Dim value As System.Double
```

```
instance.Height = value
```

```
value = instance.Height
```

C#

```
System.double Height {get; set;}
```

C++/CLI

```
property System.double Height {  
    System.double get();
```

```
void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Height of the dome

Visual Basic for Applications (VBA) Syntax

See [DomeFeatureData2::Height](#).

Example

[Change Height of Dome Feature \(VBA\)](#)
[Create and Modify Dome Feature \(C#\)](#)
[Create and Modify Dome Feature \(VB.NET\)](#)
[Create and Modify Dome Feature \(VBA\)](#)

Remarks

This property does not affect geometry until you call [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefintion2](#).

See Also

[IDomeFeatureData2 Interface](#)
[IDomeFeatureData2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections Method (IDomeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDomeFeatureData2 Interface](#) : IAccessSelections Method (IDomeFeatureData2)

Gains access to selections used to define the dome.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDomeFeatureData2  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top level document (see **Remarks**)

Component
Component for the feature (see **Remarks**)

Return Value

True if the selections where successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [DomeFeatureData2::IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::IModifyDefinition2](#) if you modified the feature
- [IDomeFeatureData2::ReleaseSelectionAccess](#) if you did not

See Also

[IDomeFeatureData2 Interface](#)
[IDomeFeatureData2 Members](#)
[IDomeFeatureData2::AccessSelections Method](#)

IFace Property (IDomeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDomeFeatureData2 Interface](#) : IFace Property (IDomeFeatureData2)

Obsolete. Superseded by [IDomeFeatureData2::Faces](#).

.NET Syntax

Visual Basic (Declaration)

Property IFace As Face2

Visual Basic (Usage)



```
Dim instance As IDomeFeatureData2  
Dim value As Face2  
  
instance.IFace = value  
  
value = instance.IFace
```

C#

```
Face2 IFace {get; set;}
```

C++/CLI

```
property Face2^ IFace {  
    Face2^ get();  
    void set ( &    Face2^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DomeFeatureData2::IFace](#).

See Also

[IDomeFeatureData2 Interface](#)
[IDomeFeatureData2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFaces Method (IDomeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDomeFeatureData2 Interface](#) : IGetFaces Method (IDomeFeatureData2)

Gets the planar or non-planar faces of this dome feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFaces( _  
    ByVal FaceCount As System.Integer _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As IDomeFeatureData2  
Dim FaceCount As System.Integer  
Dim value As Face2  
  
value = instance.IGetFaces(FaceCount)
```

C#

```
Face2 IGetFaces(  
    System.int FaceCount  
)
```

C++/CLI

```
Face2^ IGetFaces(  
& System.int FaceCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceCount
Number of planar or non-planar faces of this dome feature

Return Value

- in-process, unmanaged C++: Pointer to an array of planar or non-planar [faces](#) of this dome feature
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [IDomeFeatureData2::GetFaceCount](#) before using this method to determine the size of the output array.

See Also

[IDomeFeatureData2 Interface](#)
[IDomeFeatureData2 Members](#)
[IDomeFeatureData2::ISetFaces Method](#)
[IDomeFeatureData2::Faces Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetFaces Method (IDomeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDomeFeatureData2 Interface](#) : ISetFaces Method (IDomeFeatureData2)

Sets the planar or non-planar faces of this dome feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetFaces( _  
    ByVal FaceCount As System.Integer, _  
    ByRef FaceList As Face2 _  
)
```

Visual Basic (Usage)



```
Dim instance As IDomeFeatureData2  
Dim FaceCount As System.Integer  
Dim FaceList As Face2  
  
instance.ISetFaces(FaceCount, FaceList)
```

C#

```
void ISetFaces(  
    System.int FaceCount,  
    ref Face2 FaceList  
)
```

C++/CLI

```
void ISetFaces(  
& System.int FaceCount,  
& Face2^% FaceList  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceCount

Number of planar or non-planar faces

FaceList

- in-process, unmanaged C++: Pointer to an array of planar and non-planar [faces](#) of this dome feature

• VBA, VB.NET, C#, and C++/CLI: Not supported

See [in-process Methods](#) for details about this type of method.

Remarks

This method does not affect geometry until you call [IFeature::IModifyDefintion2](#).

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IDomeFeatureData2 Interface](#)

[IDomeFeatureData2 Members](#)

[IDomeFeatureData2::GetFaceCount Method](#)

[IDomeFeatureData2::IGetFaces Method](#)

[IDomeFeatureData2::Faces Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IDomeFeatureData2)

[See Also](#)



Releases access to the selections used to define this dome feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IDomeFeatureData2
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DomeFeatureData2::ReleaseSelectionAccess](#).

Remarks

[IDomeFeatureData2::AccessSelections](#) and [IDomeFeatureData2::!AccessSelections](#) put the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did.

See Also

[IDomeFeatureData2 Interface](#)
[IDomeFeatureData2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDir Property (IDomeFeatureData2)

[See Also](#) [Example](#)



SolidWorks.Interop.sldworks Namespace > IDomeFeatureData2 Interface : ReverseDir Property (IDomeFeatureData2)

Gets or sets whether this dome is convex or concave.

.NET Syntax

Visual Basic (Declaration)

```
Property ReverseDir As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDomeFeatureData2
Dim value As System.Boolean

instance.ReverseDir = value

value = instance.ReverseDir
```

C#

```
System.bool ReverseDir {get; set;}
```

C++/CLI

```
property System.bool ReverseDir {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True for concave domes, false for convex domes

Visual Basic for Applications (VBA) Syntax

See [DomeFeatureData2::ReverseDir](#).

Example

[Change Height of Dome Feature \(VBA\)](#)
[Create and Modify Dome Feature \(C#\)](#)
[Create and Modify Dome Feature \(VB.NET\)](#)
[Create and Modify Dome Feature \(VBA\)](#)

Remarks

This property does not affect geometry until you call [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefintion2](#).

See Also

[IDomeFeatureData2 Interface](#)
[IDomeFeatureData2 Members](#)

IDowelSymbol (Type)

IDowelSymbol Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDowelSymbol Interface

Allows access to a dowel symbol.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IDowelSymbol
```

Visual Basic (Usage)

```
Dim instance As IDowelSymbol
```

C#

```
public interface IDowelSymbol
```

C++/CLI

```
public interface class IDowelSymbol
```

Visual Basic for Applications (VBA) Syntax

See [DowelSymbol](#).

Example

[Flip Dowel Pin Symbol \(C#\)](#)
[Flip Dowel Pin Symbol \(VB.NET\)](#)
[Flip Dowel Pin Symbol \(VBA\)](#)

Accessors

[IDowelSymbol::GetNext](#) and [IDowelSymbol::IGetNext](#)
[IDrawingDoc::InsertDowelSymbol](#)
[IView::GetFirstDowelSymbol](#) and [IView::IGetFirstDowelSymbol](#)
[IView::GetDowelSymbols](#) and [IView::IGetDowelSymbols](#)

Access Diagram

[DowelSymbol](#)

See Also

[IDowelSymbol Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IDowelSymbol Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDowelSymbol Interface

The following tables list the members exposed by [IDowelSymbol](#).

Public Properties

Name	Description
 Flipped	Gets or sets whether to flip this dowel symbol.

[Top](#)

Public Methods

Name	Description
 GetAnnotation	Gets the IAnnotation object for this dowel symbol.
 GetArcPoints	Gets the start, mid, and end points (in 2D only) of the arc segment on which this dowel symbol is based.
 GetNext	Gets the next dowel symbol in the current sheet, view, or model.
 IGetAnnotation	Gets the IAnnotation object for this dowel symbol.
 IGetArcPoints	Gets the start, mid, and end points (in 2D only) of the arc segment on which this dowel symbol is based.
 IGetNext	Gets the next dowel symbol in the current sheet, view, or model.

[Top](#)

See Also

[IDowelSymbol Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IDowelSymbol Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDowelSymbol Interface

For a list of all members of this type, see [IDowelSymbol members](#).

Public Methods

Name	Description
 GetAnnotation	Gets the IAnnotation object for this dowel symbol.
 GetArcPoints	Gets the start, mid, and end points (in 2D only) of the arc segment on which this dowel symbol is based.
 GetNext	Gets the next dowel symbol in the current sheet, view, or model.
 IGetAnnotation	Gets the IAnnotation object for this dowel symbol.
 IGetArcPoints	Gets the start, mid, and end points (in 2D only) of the arc segment on which this dowel symbol is based.
 IGetNext	Gets the next dowel symbol in the current sheet, view, or model.

[Top](#)

See Also

[IDowelSymbol Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IDowelSymbol Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDowelSymbol Interface

For a list of all members of this type, see [IDowelSymbol members](#).

Public Properties

Name	Description
 Flipped	Gets or sets whether to flip this dowel symbol.

[Top](#)

See Also

Flipped Property (IDowelSymbol)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDowelSymbol Interface](#) : Flipped Property (IDowelSymbol)

Gets or sets whether to flip this dowel symbol.

.NET Syntax

Visual Basic (Declaration)

Property Flipped As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDowelSymbol  
Dim value As System.Boolean
```

```
instance.Flipped = value
```

```
value = instance.Flipped
```

C#

```
System.bool Flipped {get; set;}
```

C++/CLI

```
property System.bool Flipped {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the dowel is flipped, false if it is not

Visual Basic for Applications (VBA) Syntax

See [DowelSymbol::Flipped](#).

Example

[Flip Dowel Pin Symbol \(VBA\)](#)
[Flip Dowel Pin Symbol \(C#\)](#)
[Flip Dowel Pin Symbol \(VB.NET\)](#)

Remarks

Call [IModelDoc2::EditRebuild3](#) after flipping the dowel pin symbol.

See Also

[IDowelSymbol Interface](#)
[IDowelSymbol Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

GetAnnotation Method (IDowelSymbol)

[See Also](#) [Example](#)



Gets the IAnnotation object for this dowel symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAnnotation() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDowelSymbol
Dim value As System.Object

value = instance.GetAnnotation()
```

C#

```
System.object GetAnnotation()
```

C++/CLI

```
System.Object^ GetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Annotation](#)

Visual Basic for Applications (VBA) Syntax

See [DowelSymbol::GetAnnotation](#).

Example

[Get Annotation Object \(VBA\)](#)
[Get Annotation Object \(VB.NET\)](#)
[Get Annotation Object \(C#\)](#)
[Flip Dowel Pin Symbol \(C#\)](#)
[Flip Dowel Pin Symbol \(VB.NET\)](#)
[Flip Dowel Pin Symbol \(VBA\)](#)

See Also

[IDowelSymbol Interface](#)
[IDowelSymbol Members](#)
[IDowelSymbol::IGetAnnotation Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetArcPoints Method (IDowelSymbol)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > IDowelSymbol Interface : GetArcPoints Method (IDowelSymbol)

Gets the start, mid, and end points (in 2D only) of the arc segment on which this dowel symbol is based.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArcPoints() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDowelSymbol  
Dim value As System.Object  
  
value = instance.GetArcPoints()
```

C#

```
System.Object GetArcPoints()
```

C++/CLI

```
System.Object^ GetArcPoints();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of start, mid, and end point x and y coordinates

Visual Basic for Applications (VBA) Syntax

See [DowelSymbol::GetArcPoints](#).

Remarks

If the arc segment is a complete circle, the start and end points are the same, and the midpoint is at the 180 position.

See Also

[IDowelSymbol Interface](#)
[IDowelSymbol Members](#)
[IDowelSymbol::IGetArcPoints Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNext Method (IDowelSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDowelSymbol Interface](#) : GetNext Method (IDowelSymbol)

Gets the next dowel symbol in the current sheet, view, or model.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDowelSymbol  
Dim value As System.Object  
  
value = instance.GetNext()
```

C#

```
System.Object GetNext()
```

C++/CLI

```
System.Object^ GetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next dowel symbol

Visual Basic for Applications (VBA) Syntax

See [DowelSymbol::GetNext](#).

See Also

[IDowelSymbol Interface](#)
[IDowelSymbol Members](#)
[IDowelSymbol::IGetNext Method](#)
[IView::GetFirstDowelSymbol Method](#)
[IView::IGetFirstDowelSymbol Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetAnnotation Method (IDowelSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDowelSymbol Interface](#) : IGetAnnotation Method (IDowelSymbol)

Gets the IAnnotation object for this dowel symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetAnnotation() As Annotation
```

Visual Basic (Usage)



```
Dim instance As IDowelSymbol  
Dim value As Annotation  
  
value = instance.IGetAnnotation()
```

C#

```
Annotation IGetAnnotation()
```

C++/CLI

```
Annotation^ IGetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to an [IAnnotation](#) object

Visual Basic for Applications (VBA) Syntax

See [DowelSymbol::IGetAnnotation](#).

See Also

[IDowelSymbol Interface](#)
[IDowelSymbol Members](#)
[IDowelSymbol::GetAnnotation Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetArcPoints Method (IDowelSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDowelSymbol Interface](#) : IGetArcPoints Method (IDowelSymbol)

Gets the start, mid, and end points (in 2D only) of the arc segment on which this dowel symbol is based.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetArcPoints() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDowelSymbol  
Dim value As System.Double  
  
value = instance.IGetArcPoints()
```

C#

```
System.double IGetArcPoints()
```

C++/CLI

```
System.double IGetArcPoints();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of size 6 containing start, mid, and end point x and y coordinates
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

If the arc segment is a complete circle, the start and end points are the same, and the midpoint is at the 180 position.

See Also

[IDowelSymbol Interface](#)
[IDowelSymbol Members](#)
[IDowelSymbol::GetArcPoints Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNext Method (IDowelSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDowelSymbol Interface](#) : IGetNext Method (IDowelSymbol)

Gets the next dowel symbol in the current sheet, view, or model.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNext() As DowelSymbol
```

Visual Basic (Usage)



```
Dim instance As IDowelSymbol  
Dim value As DowelSymbol  
  
value = instance.IGetNext()
```

C#

```
DowelSymbol IGetNext()
```

C++/CLI

```
DowelSymbol^ IGetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the next [dowel symbol](#)

Visual Basic for Applications (VBA) Syntax

See [DowelSymbol::IGetNext](#).

See Also

[IDowelSymbol Interface](#)
[IDowelSymbol Members](#)
[IDowelSymbol::IGetNext Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

IDraftFeatureData (Type)

IDraftFeatureData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDraftFeatureData Interface

Obsolete. Superseded by [IDraftFeatureData2](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IDraftFeatureData
```

Visual Basic (Usage)

```
Dim instance As IDraftFeatureData
```

C#

```
public interface IDraftFeatureData
```

C++/CLI

```
public interface class IDraftFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData](#).

See Also

[IDraftFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IDraftFeatureData Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDraftFeatureData Interface

The following tables list the members exposed by [IDraftFeatureData](#).

Public Properties

Name	Description
Angle	Obsolete. Superseded by IDraftFeatureData2::Angle .
ReverseDirection	Obsolete. Superseded by IDraftFeatureData2::ReverseDirection .
Type	Obsolete. Superseded by IDraftFeatureData2::Type .

[Top](#)

See Also

[IDraftFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IDraftFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDraftFeatureData Interface

For a list of all members of this type, see [IDraftFeatureData members](#).

Public Properties

Name	Description
 Angle	Obsolete. Superseded by IDraftFeatureData2::Angle .
 ReverseDirection	Obsolete. Superseded by IDraftFeatureData2::ReverseDirection .
 Type	Obsolete. Superseded by IDraftFeatureData2::Type .

[Top](#)

See Also

[IDraftFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Angle Property (IDraftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData Interface](#) : Angle Property (IDraftFeatureData)

Obsolete. Superseded by [IDraftFeatureData2::Angle](#).

.NET Syntax

Visual Basic (Declaration)

Property Angle As System.Double

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData  
Dim value As System.Double
```

```
instance.Angle = value
```

```
value = instance.Angle
```

C#

```
System.double Angle {get; set;}
```

C++/CLI

```
property System.double Angle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData::Angle](#).

See Also

[IDraftFeatureData Interface](#)
[IDraftFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReverseDirection Property (IDraftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData Interface](#) : ReverseDirection Property (IDraftFeatureData)

Obsolete. Superseded by [IDraftFeatureData2::ReverseDirection](#).

.NET Syntax

Visual Basic (Declaration)

```
Property ReverseDirection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData  
Dim value As System.Boolean  
  
instance.ReverseDirection = value  
  
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData::ReverseDirection](#).

See Also

[IDraftFeatureData Interface](#)
[IDraftFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Type Property (IDraftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData Interface](#) : Type Property (IDraftFeatureData)

Obsolete. Superseded by [IDraftFeatureData2::Type](#).

.NET Syntax

Visual Basic (Declaration)

```
Property Type As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData  
Dim value As System.Integer  
  
instance.Type = value  
  
value = instance.Type
```

C#

```
System.int Type {get; set;}
```

C++/CLI

```
property System.int Type {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData::Type](#).

See Also

[IDraftFeatureData Interface](#)
[IDraftFeatureData Members](#)