

SOLIDWORKS API (.NET VBA C#) — Reference

(81/337): IDraftFeatureData2- IDragArrowManipulator

SOLIDWORKS API Documentation (converted from CHM)

IDraftFeatureData2 (Type)

IDraftFeatureData2 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDraftFeatureData2 Interface

Allows access to a draft feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IDraftFeatureData2
```

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2
```

C#

```
public interface IDraftFeatureData2
```

C++/CLI

```
public interface class IDraftFeatureData2
```

Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData2](#).

Example

[Get Faces Affected by Draft Feature \(VBA\)](#)
[Get Faces Affected by Draft Feature \(VB.NET\)](#)
[Get Faces Affected by Draft Feature \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[DraftFeatureData2](#)

See Also

[IDraftFeatureData2 Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IDraftFeatureData2 Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDraftFeatureData2 Interface

For a list of all members of this type, see [IDraftFeatureData2 members](#).

Public Methods

Name	Description
 AccessSelections	Accesses the selections that define this draft feature.
 GetDraftedEntities	Gets the drafted entities (faces or edges) for this draft feature.

	GetDraftedEntityCount	Gets the number of drafted entities for this draft feature.
	GetFacesToDraftCount	Gets the number of faces that define the draft feature.
	GetOtherFacesFlagAtIndex	Gets the value of the Other Face option at the specified index.
	GetPartingLinesCount	Gets the number of parting lines for this draft feature.
	IAccessSelections	Accesses the selections that define this draft feature.
	IGetDraftedEntities	Gets the drafted entities (faces or edges) for this draft feature.
	IGetFacesToDraft	Gets the faces that define this draft feature.
	IGetPartingLines	Gets the parting lines that define this draft feature.
	ISetFacesToDraft	Sets the faces to which to apply the draft feature.
	ISetPartingLines	Sets the parting lines for this draft feature.
	ReleaseSelectionAccess	Releases access to the selections for this draft feature.
	SetOtherFacesFlagAtIndex	Sets the Other Face option.

[Top](#)

See Also

[IDraftFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDraftFeatureData2 Interface Members

[See Also](#) [Properties](#) [Methods](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IDraftFeatureData2 Interface

The following tables list the members exposed by [IDraftFeatureData2](#).

Public Properties

Name	Description
 AllowReducedAngle	Gets or sets the Allow reduced angle option for this draft feature.
 Angle	Gets or sets the angle for this draft feature.
 DirectionPull	Gets or sets the direction in which to pull this draft feature.
 FacePropagation	Gets or sets the face propagation for this draft feature.
 FacesToDraft	Gets or sets the faces that define this draft feature.
 NeutralPlane	Gets or sets the neutral plane for this draft feature.
 PartingLines	Gets or sets the parting lines for this draft feature.
 ReverseDirection	Gets or sets whether the direction of the draft feature is reversed.
 StepType	Gets or sets the step type for this draft feature.
 Type	Gets the type of draft feature.

[Top](#)

Public Methods

Name	Description
	AccessSelections Accesses the selections that define this draft feature.
	GetDraftedEntities Gets the drafted entities (faces or edges) for this draft feature.
	GetDraftedEntityCount Gets the number of drafted entities for this draft feature.
	GetFacesToDraftCount Gets the number of faces that define the draft feature.
	GetOtherFacesFlagAtIndex Gets the value of the Other Face option at the specified index.
	GetPartingLinesCount Gets the number of parting lines for this draft feature.

 IAccessSelections	Accesses the selections that define this draft feature.
 IGetDraftedEntities	Gets the drafted entities (faces or edges) for this draft feature.
 IGetFacesToDraft	Gets the faces that define this draft feature.
 IGetPartingLines	Gets the parting lines that define this draft feature.
 ISetFacesToDraft	Sets the faces to which to apply the draft feature.
 ISetPartingLines	Sets the parting lines for this draft feature.
 ReleaseSelectionAccess	Releases access to the selections for this draft feature.
 SetOtherFacesFlagAtIndex	Sets the Other Face option.

[Top](#)

 See Also

[IDraftFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

[Send comments on this topic.](#)

SOLIDWORKS API Help

IDraftFeatureData2 Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDraftFeatureData2 Interface

For a list of all members of this type, see [IDraftFeatureData2 members](#).

 Public Properties

Name	Description
 AllowReducedAngle	Gets or sets the Allow reduced angle option for this draft feature.
 Angle	Gets or sets the angle for this draft feature.
 DirectionPull	Gets or sets the direction in which to pull this draft feature.
 FacePropagation	Gets or sets the face propagation for this draft feature.
 FacesToDraft	Gets or sets the faces that define this draft feature.
 NeutralPlane	Gets or sets the neutral plane for this draft feature.
 PartingLines	Gets or sets the parting lines for this draft feature.
 ReverseDirection	Gets or sets whether the direction of the draft feature is reversed.
 StepType	Gets or sets the step type for this draft feature.
 Type	Gets the type of draft feature.

[Top](#)

 See Also

[IDraftFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

[Send comments on this topic.](#)

SOLIDWORKS API Help

AccessSelections Method (IDraftFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : AccessSelections Method (IDraftFeatureData2)

Accesses the selections that define this draft feature.

 .NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _
```

```
ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document

Component
Component in which the feature is to be modified

Return Value

True if the selections were successfully accessed, false if not

 Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData2::AccessSelections](#).

 Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IDraftFeatureData2::ReleaseSelectionAccess](#) if you did not

 See Also

[IDraftFeatureData2 Interface](#)
[IDraftFeatureData2 Members](#)
[IDraftFeatureData2::IAccessSelections Method](#)

 Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AllowReducedAngle Property (IDraftFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : AllowReducedAngle Property (IDraftFeatureData2)

Gets or sets the **Allow reduced angle** option for this draft feature.

.NET Syntax

Visual Basic (Declaration)

Property AllowReducedAngle As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2  
Dim value As System.Boolean
```

```
instance.AllowReducedAngle = value
```

```
value = instance.AllowReducedAngle
```

C#

```
System.bool AllowReducedAngle {get; set;}
```

C++/CLI

```
property System.bool AllowReducedAngle {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reduce the angle of the draft, false to not

Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData2::AllowReducedAngle](#).

Remarks

See SOLIDWORKS Help for details about the **Allow reduced angle** setting.

See Also

[IDraftFeatureData2 Interface](#)
[IDraftFeatureData2 Members](#)
[IDraftFeatureData2::Angle Property](#)
[IDraftFeatureData2::GetPartingLinesCount Method](#)
[IDraftFeatureData2::GetPartingLines Method](#)
[IDraftFeatureData2::SetPartingLines Method](#)
[IDraftFeatureData2::PartingLines Property](#)
[IPartingLineFeatureData Interface](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Angle Property (IDraftFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : Angle Property (IDraftFeatureData2)

Gets or sets the angle for this draft feature.

.NET Syntax

Visual Basic (Declaration)

Property Angle As System.Double

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2  
Dim value As System.Double
```

```
instance.Angle = value
```

```
value = instance.Angle
```

C#

```
System.double Angle {get; set;}
```

C++/CLI

```
property System.double Angle {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Draft angle in radians

Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData2::Angle](#).

See Also

[IDraftFeatureData2 Interface](#)
[IDraftFeatureData2 Members](#)
[IDraftFeatureData2::AllowReducedAngle Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DirectionPull Property (IDraftFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : DirectionPull Property (IDraftFeatureData2)

Gets or sets the direction in which to pull this draft feature.

.NET Syntax

Visual Basic (Declaration)

```
Property DirectionPull As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2  
Dim value As System.Object
```

```
instance.DirectionPull = value
```

```
value = instance.DirectionPull
```

C#

```
System.object DirectionPull {get; set;}
```

C++/CLI

```
property System.Object^ DirectionPull {  
    System.Object^ get();
```

```
void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Face from which to pull this draft feature

Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData2::DirectionPull](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IDraftFeatureData2 Interface](#)
[IDraftFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FacePropagation Property (IDraftFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : FacePropagation Property (IDraftFeatureData2)

Gets or sets the face propagation for this draft feature.

.NET Syntax

Visual Basic (Declaration)

```
Property FacePropagation As System.Short
```

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2  
Dim value As System.Short
```

```
instance.FacePropagation = value
```

```
value = instance.FacePropagation
```

C#

```
System.short FacePropagation {get; set;}
```

C++/CLI

```
property System.short FacePropagation {  
    System.short get();  
    void set ( & System.short value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Face propagation type as defined in [swDraftFacePropagationType](#)

Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData2::FacePropagation](#).

See Also

[IDraftFeatureData2 Interface](#)
[IDraftFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

FacesToDraft Property (IDraftFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : FacesToDraft Property (IDraftFeatureData2)

Gets or sets the faces that define this draft feature.

.NET Syntax

Visual Basic (Declaration)

```
Property FacesToDraft As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2  
Dim value As System.Object
```

```
instance.FacesToDraft = value
```

```
value = instance.FacesToDraft
```

C#

```
System.Object FacesToDraft {get; set;}
```

C++/CLI

```
property System.Object^ FacesToDraft {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [faces](#)

Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData2::FacesToDraft](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IDraftFeatureData2 Interface](#)
[IDraftFeatureData2 Members](#)
[IDraftFeatureData2::GetFacesToDraftCount Method](#)
[IDraftFeatureData2::IGetFacesToDraft Method](#)
[IDraftFeatureData2::ISetFacesToDraft Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDraftedEntities Method (IDraftFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : GetDraftedEntities Method (IDraftFeatureData2)

Gets the drafted entities (faces or edges) for this draft feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDraftedEntities() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2  
Dim value As System.Object  
  
value = instance.GetDraftedEntities()
```

C#

```
System.object GetDraftedEntities()
```

C++/CLI

```
System.Object^ GetDraftedEntities();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [entities](#)

Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData2::GetDraftedEntities](#).

Example

[Get Faces Affected by Draft Feature \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IDraftFeatureData2 Interface](#)
[IDraftFeatureData2 Members](#)
[IDraftFeatureData2::IGetDraftedEntities Method](#)
[IDraftFeatureData2::GetDraftedEntityCount Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDraftedEntityCount Method (IDraftFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : GetDraftedEntityCount Method (IDraftFeatureData2)

Gets the number of drafted entities for this draft feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDraftedEntityCount() As System.Short
```

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2  
Dim value As System.Short  
  
value = instance.GetDraftedEntityCount()
```

C#

```
System.short GetDraftedEntityCount()
```

C++/CLI

```
System.short GetDraftedEntityCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of drafted entities

Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData2::GetDraftedEntityCount](#).

Remarks

Call this method before calling [IDraftFeatureData2::IGetDraftedEntities](#) to determine the size of the array for that method.

See Also

[IDraftFeatureData2 Interface](#)
[IDraftFeatureData2 Members](#)
[IDraftFeatureData2::GetDraftedEntities Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFacesToDraftCount Method (IDraftFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : GetFacesToDraftCount Method (IDraftFeatureData2)

Gets the number of faces that define the draft feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFacesToDraftCount() As System.Short
```

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2  
Dim value As System.Short  
  
value = instance.GetFacesToDraftCount()
```

C#

```
System.short GetFacesToDraftCount()
```

C++/CLI

```
System.short GetFacesToDraftCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of faces that define the draft feature

Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData2::GetFacesToDraftCount](#).

Remarks

Call this method before calling [IDraftFeatureData2::!GetFacesToDraft](#) to determine the size of the array for that method.

See Also

[IDraftFeatureData2 Interface](#)
[IDraftFeatureData2 Members](#)
[IDraftFeatureData2::FacesToDraft Property](#)
[IDraftFeatureData2::!SetFacesToDraft Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetOtherFacesFlagAtIndex Method (IDraftFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : GetOtherFacesFlagAtIndex Method (IDraftFeatureData2)

Gets the value of the **Other Face** option at the specified index.

.NET Syntax

Visual Basic (Declaration)

```
Function GetOtherFacesFlagAtIndex( _  
    ByVal Index As System.Short _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2  
Dim Index As System.Short  
Dim value As System.Boolean  
  
value = instance.GetOtherFacesFlagAtIndex(Index)
```

C#

```
System.bool GetOtherFacesFlagAtIndex(  
    System.short Index  
)
```

C++/CLI

```
System.bool GetOtherFacesFlagAtIndex(  
&    System.short Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Number indicating a segment of the parting line

Return Value

True to specify a different draft direction for each segment of the parting line, false to not

Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData2::GetOtherFacesFlagAtIndex](#).

Permissions

Permission	Description
[New Item]	

See Also

[IDraftFeatureData2 Interface](#)
[IDraftFeatureData2 Members](#)
[IDraftFeatureData2::SetOtherFacesFlagAtIndex Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPartingLinesCount Method (IDraftFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : GetPartingLinesCount Method (IDraftFeatureData2)

Gets the number of parting lines for this draft feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPartingLinesCount() As System.Short
```

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2  
Dim value As System.Short  
  
value = instance.GetPartingLinesCount()
```

C#

```
System.short GetPartingLinesCount()
```

C++/CLI

```
System.short GetPartingLinesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of parting lines

Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData2::GetPartingLinesCount](#).

Remarks

Call this method before calling [IDraftFeatureData2::!GetPartingLines](#) to determine the size of the array for that method.

See Also

[IDraftFeatureData2 Interface](#)
[IDraftFeatureData2 Members](#)
[IDraftFeatureData2::ISetPartingLines Method](#)
[IDraftFeatureData2::PartingLines Property](#)

 Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (IDraftFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : IAccessSelections Method (IDraftFeatureData2)

Accesses the selections that define this draft feature.

 .NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document

Component

Component in which the feature is to be modified

Return Value

True if the selections were successfully accessed, false if not

 Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData2::IAccessSelections](#).

 Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::IModifyDefintion2](#) if you modified the feature
- [IDraftFeatureData2::ReleaseSelectionAccess](#) if you did not

See Also

[IDraftFeatureData2 Interface](#)
[IDraftFeatureData2 Members](#)
[IDraftFeatureData2::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDraftedEntities Method (IDraftFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : IGetDraftedEntities Method (IDraftFeatureData2)

Gets the drafted entities (faces or edges) for this draft feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDraftedEntities( _  
    ByVal Count As System.Short _  
) As Entity
```

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2  
Dim Count As System.Short  
Dim value As Entity  
  
value = instance.IGetDraftedEntities(Count)
```

C#

```
Entity IGetDraftedEntities(  
    System.short Count  
)
```

C++/CLI

```
Entity^ IGetDraftedEntities(  
& System.short Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of entities

Return Value

- in-process, unmanaged C++: Pointer to an array of [entities](#) of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IDraftFeatureData2::GetDraftedEntityCount](#) to determine the size of the array.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IDraftFeatureData2 Interface](#)
[IDraftFeatureData2 Members](#)
[IDraftFeatureData2::GetDraftedEntities Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFacesToDraft Method (IDraftFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : IGetFacesToDraft Method (IDraftFeatureData2)

Gets the faces that define this draft feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFacesToDraft( _  
    ByVal Count As System.Short _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2  
Dim Count As System.Short  
Dim value As Face2  
  
value = instance.IGetFacesToDraft(Count)
```

C#

```
Face2 IGetFacesToDraft(  
    System.short Count  
)
```

C++/CLI

```
Face2^ IGetFacesToDraft(  
&    System.short Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of faces

Return Value

- in-process, unmanaged C++: Pointer to an array of [faces](#) of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IDraftFeatureData2::GetFacesToDraftCount](#) to determine the size of returned array.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IDraftFeatureData2 Interface](#)
[IDraftFeatureData2 Members](#)
[IDraftFeatureData2::ISetFacesToDraft Method](#)
[IDraftFeatureData2::FacesToDraft Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetPartingLines Method (IDraftFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : IGetPartingLines Method (IDraftFeatureData2)

Gets the parting lines that define this draft feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetPartingLines( _  
    ByVal Count As System.Short _  
) As Edge
```

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2  
Dim Count As System.Short  
Dim value As Edge  
  
value = instance.IGetPartingLines(Count)
```

C#

```
Edge IGetPartingLines(  
    System.short Count  
)
```

C++/CLI

```
Edge^ IGetPartingLines(  
& System.short Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of parting lines

Return Value

- in-process, unmanaged C++: Pointer to an array of [parting lines](#) of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IDraftFeatureData2::GetPartingLinesCount](#) to determine the size of the returned array.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IDraftFeatureData2 Interface](#)
[IDraftFeatureData2 Members](#)
[IDraftFeatureData2::ISetPartingLines Method](#)
[IDraftFeatureData2::PartingLines Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetFacesToDraft Method (IDraftFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : ISetFacesToDraft Method (IDraftFeatureData2)

Sets the faces to which to apply the draft feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetFacesToDraft( _  
    ByVal Count As System.Short, _  
    ByRef FaceArray As Face2 _  
)
```

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2  
Dim Count As System.Short  
Dim FaceArray As Face2  
  
instance.ISetFacesToDraft(Count, FaceArray)
```

C#

```
void ISetFacesToDraft(  
    System.short Count,  
    ref Face2 FaceArray  
)
```

C++/CLI

```
void ISetFacesToDraft(  
& System.short Count,  
& Face2^% FaceArray  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of faces

FaceArray

- in-process, unmanaged C++: Pointer to an array of [faces](#) of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IDraftFeatureData2 Interface](#)
[IDraftFeatureData2 Members](#)
[IDraftFeatureData2::GetFacesToDraftCount Method](#)
[IDraftFeatureData2::IGetFacesToDraft Method](#)
[IDraftFeatureData2::FacesToDraft Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetPartingLines Method (IDraftFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : ISetPartingLines Method (IDraftFeatureData2)

Sets the parting lines for this draft feature.

 .NET Syntax

Visual Basic (Declaration)

```
Sub ISetPartingLines( _  
    ByVal Count As System.Short, _  
    ByRef LineArray As Edge _  
)
```

Visual Basic (Usage)  

```
Dim instance As IDraftFeatureData2  
Dim Count As System.Short  
Dim LineArray As Edge  
  
instance.ISetPartingLines(Count, LineArray)
```

C#

```
void ISetPartingLines(  
    System.short Count,  
    ref Edge LineArray  
)
```

C++/CLI

```
void ISetPartingLines(  
&    System.short Count,  
&    Edge^% LineArray  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

- Count*
Number of parting lines
- LineArray*
- in-process, unmanaged C++: Pointer to an array of [parting lines](#) of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

 Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

 See Also

- [IDraftFeatureData2 Interface](#)
- [IDraftFeatureData2 Members](#)
- [IDraftFeatureData2::GetPartingLinesCount Method](#)
- [IDraftFeatureData2::ISetPartingLines Method](#)
- [IDraftFeatureData2::PartingLines Property](#)

 Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

NeutralPlane Property (IDraftFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : NeutralPlane Property (IDraftFeatureData2)

Gets or sets the neutral plane for this draft feature.

 .NET Syntax

Visual Basic (Declaration)

Property NeutralPlane As System.Object

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2  
Dim value As System.Object
```

```
instance.NeutralPlane = value
```

```
value = instance.NeutralPlane
```

C#

```
System.object NeutralPlane {get; set;}
```

C++/CLI

```
property System.Object^ NeutralPlane {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Face to serve as the neutral plane

Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData2::NeutralPlane](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IDraftFeatureData2 Interface](#)
[IDraftFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PartingLines Property (IDraftFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : PartingLines Property (IDraftFeatureData2)

Gets or sets the parting lines for this draft feature.

.NET Syntax

Visual Basic (Declaration)

```
Property PartingLines As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2  
Dim value As System.Object
```

```
instance.PartingLines = value
```

```
value = instance.PartingLines
```

C#

```
System.Object PartingLines {get; set;}
```

C++/CLI

```
property System.Object^ PartingLines {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [parting lines](#)

Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData2::PartingLines](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IDraftFeatureData2 Interface](#)
[IDraftFeatureData2 Members](#)
[IDraftFeatureData2::GetPartingLinesCount Method](#)
[IDraftFeatureData2::IGetPartingLines Method](#)
[IDraftFeatureData2::ISetPartingLines Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReleaseSelectionAccess Method (IDraftFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : ReleaseSelectionAccess Method (IDraftFeatureData2)

Releases access to the selections for this draft feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData2::ReleaseSelectionAccess](#).

Remarks

[IDraftFeatureData2::AccessSelections](#) and [IDraftFeatureData2::IAccessSelections](#) put the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did.

See Also

[IDraftFeatureData2 Interface](#)
[IDraftFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (IDraftFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : ReverseDirection Property (IDraftFeatureData2)

Gets or sets whether the direction of the draft feature is reversed.

.NET Syntax

Visual Basic (Declaration)

Property ReverseDirection As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2
Dim value As System.Boolean

instance.ReverseDirection = value
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True reverses the direction of the draft feature, false does not

Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData2::ReverseDirection](#).

See Also

[IDraftFeatureData2 Interface](#)
[IDraftFeatureData2 Members](#)

Availability

SetOtherFacesFlagAtIndex Method (IDraftFeatureData2)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : SetOtherFacesFlagAtIndex Method (IDraftFeatureData2)Sets the **Other Face** option.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetOtherFacesFlagAtIndex( _
    ByVal Index As System.Short, _
    ByVal Flag As System.Boolean _
)
```

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2
Dim Index As System.Short
Dim Flag As System.Boolean

instance.SetOtherFacesFlagAtIndex(Index, Flag)
```

C#

```
void SetOtherFacesFlagAtIndex(
    System.short Index,
    System.bool Flag
)
```

C++/CLI

```
void SetOtherFacesFlagAtIndex(
    & System.short Index,
    & System.bool Flag
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Number indicating a segment of the parting line

Flag

True to specify a different draft direction for each segment of the parting line, false to not

Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData2::SetOtherFacesFlagAtIndex](#).

See Also

[IDraftFeatureData2 Interface](#)[IDraftFeatureData2 Members](#)[IDraftFeatureData2::GetOtherFacesFlagAtIndex Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

StepType Property (IDraftFeatureData2)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : StepType Property (IDraftFeatureData2)

Gets or sets the step type for this draft feature.

.NET Syntax

Visual Basic (Declaration)

```
Property StepType As System.Short
```

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2  
Dim value As System.Short
```

```
instance.StepType = value  
value = instance.StepType
```

C#

```
System.short StepType {get; set;}
```

C++/CLI

```
property System.short StepType {  
    System.short get();  
    void set ( & System.short value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Step type as defined in [swDraftStepType_e](#)

Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData2::StepType](#).

See Also

[IDraftFeatureData2 Interface](#)
[IDraftFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Type Property (IDraftFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDraftFeatureData2 Interface](#) : Type Property (IDraftFeatureData2)

Gets the type of draft feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Type As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDraftFeatureData2  
Dim value As System.Integer
```

```
instance.Type = value  
value = instance.Type
```

C#

```
System.int Type {get; set;}
```

C++/CLI

```
property System.int Type {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of draft feature as defined in [swDraftType_e](#)

Visual Basic for Applications (VBA) Syntax

See [DraftFeatureData2::Type](#).

Example

See [IDraftFeatureData2](#) examples.

See Also

[IDraftFeatureData2 Interface](#)
[IDraftFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

IDragArrowManipulator (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IDragArrowManipulator Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDragArrowManipulator Interface

Allows access to drag arrows, which are called handles in the SOLIDWORKS Design user interface.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IDragArrowManipulator
```

Visual Basic (Usage)



```
Dim instance As IDragArrowManipulator
```

C#

```
public interface IDragArrowManipulator
```

C++/CLI

```
public interface class IDragArrowManipulator
```

Visual Basic for Applications (VBA) Syntax

See [DragArrowManipulator](#).

Example

[Create Drag Arrow Manipulator \(VBA\)](#)
[Create Drag Arrow Manipulator \(VB.NET\)](#)
[Create Drag Arrow Manipulator \(C#\)](#)

Remarks

When the user clicks and drags the arrow of a handle, the length of that handle changes.

An add-in application must create the handler for the manipulator. See [ISwManipulatorHandler2](#) and [Manipulators](#) for details.

Accessors

[IManipulator::GetSpecificManipulator](#)

Access Diagram

[DragArrowManipulator](#)

See Also

[IDragArrowManipulator Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IManipulator Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IDragArrowManipulator Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDragArrowManipulator Interface

For a list of all members of this type, see [IDragArrowManipulator members](#).

Public Methods

Name	Description
 Update	Displays a handle after having modified the length of the handle.

[Top](#)

See Also

[IDragArrowManipulator Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IManipulator Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDragArrowManipulator Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDragArrowManipulator Interface

The following tables list the members exposed by [IDragArrowManipulator](#).

Public Properties

Name	Description
 AllowFlip	Gets or sets whether the unidirectional handle can change direction when dragged past length = 0.
 Direction	Gets or sets the direction of the handle.
 FixedLength	Gets or sets whether the origin can be changed.
 Length	Gets or sets the length of the handle.
 LengthOppositeDirection	Gets or sets the length of the opposite handle.
 Origin	Gets or sets the origin of the handle.
 ShowOppositeDirection	Gets or sets whether to display the bidirectional handle.
 ShowRuler	Gets or sets whether to display a ruler when the handle moves.

[Top](#)

Public Methods

Name	Description
 Update	Displays a handle after having modified the length of the handle.

[Top](#)

See Also

[IDragArrowManipulator Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IManipulator Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDragArrowManipulator Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDragArrowManipulator Interface

For a list of all members of this type, see [IDragArrowManipulator members](#).

Public Properties

Name	Description
 AllowFlip	Gets or sets whether the unidirectional handle can change direction when dragged past length = 0.
 Direction	Gets or sets the direction of the handle.
 FixedLength	Gets or sets whether the origin can be changed.
 Length	Gets or sets the length of the handle.

 LengthOppositeDirection	Gets or sets the length of the opposite handle.
 Origin	Gets or sets the origin of the handle.
 ShowOppositeDirection	Gets or sets whether to display the bidirectional handle.
 ShowRuler	Gets or sets whether to display a ruler when the handle moves.

[Top](#)

See Also

[IDragArrowManipulator Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IManipulator Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AllowFlip Property (IDragArrowManipulator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragArrowManipulator Interface](#) : AllowFlip Property (IDragArrowManipulator)

Gets or sets whether the unidirectional handle can change direction when dragged past length = 0.

.NET Syntax

Visual Basic (Declaration)

Property AllowFlip As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDragArrowManipulator
Dim value As System.Boolean

instance.AllowFlip = value
value = instance.AllowFlip
```

C#

```
System.bool AllowFlip {get; set;}
```

C++/CLI

```
property System.bool AllowFlip {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to allow the unidirectional handle to change direction when dragged past length = 0, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DragArrowManipulator::AllowFlip](#).

Example

See [IDragArrowManipulator](#) examples.

Remarks

This property is valid only if [IDragArrowManipulator::ShowOppositeDirection](#) is false.

See Also

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Direction Property (IDragArrowManipulator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragArrowManipulator Interface](#) : Direction Property (IDragArrowManipulator)

Gets or sets the direction of the handle.

.NET Syntax

Visual Basic (Declaration)

Property Direction As MathVector

Visual Basic (Usage)



```
Dim instance As IDragArrowManipulator  
Dim value As MathVector
```

```
instance.Direction = value
```

```
value = instance.Direction
```

C#

```
MathVector Direction {get; set;}
```

C++/CLI

```
property MathVector^ Direction {  
    MathVector^ get();  
    void set ( & MathVector^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pointer to [IMathVector](#) object

Visual Basic for Applications (VBA) Syntax

See [DragArrowManipulator::Direction](#).

Example

See [IDragArrowManipulator](#) examples.

See Also

[IDragArrowManipulator Interface](#)
[IDragArrowManipulator Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FixedLength Property (IDragArrowManipulator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragArrowManipulator Interface](#) : FixedLength Property (IDragArrowManipulator)

Gets or sets whether the origin can be changed.

.NET Syntax

Visual Basic (Declaration)

Property FixedLength As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDragArrowManipulator  
Dim value As System.Boolean  
  
instance.FixedLength = value  
value = instance.FixedLength
```

C#

```
System.bool FixedLength {get; set;}
```

C++/CLI

```
property System.bool FixedLength {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to permit changing the origin, false to not

Visual Basic for Applications (VBA) Syntax

See [DragArrowManipulator::FixedLength](#).

Example

See [IDragArrowManipulator](#) examples.

Remarks

Set this property to true before calling [IDragArrowManipulator::Origin](#) to change the origin.

See Also

[IDragArrowManipulator Interface](#)
[IDragArrowManipulator Members](#)
[IDragArrowManipulator::Length Property](#)
[IDragArrowManipulator::LengthOppositeDirection Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Length Property (IDragArrowManipulator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragArrowManipulator Interface](#) : Length Property (IDragArrowManipulator)

Gets or sets the length of the handle.

.NET Syntax

Visual Basic (Declaration)

Property Length As System.Double

```
Dim instance As IDragArrowManipulator
Dim value As System.Double

instance.Length = value

value = instance.Length
```

C#

```
System.double Length {get; set;}
```

C++/CLI

```
property System.double Length {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Length of handle

Visual Basic for Applications (VBA) Syntax

See [DragArrowManipulator::Length](#).

Example

See [IDragArrowManipulator](#) examples.

Remarks

If you change the length of the handle using this property, then use [IDragArrowMainpulator::Update](#) to display the modified handle in the graphic area.

See Also

[IDragArrowManipulator Interface](#)
[IDragArrowManipulator Members](#)
[IDragArrowManipulator::LengthOppositeDirection Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

LengthOppositeDirection Property (IDragArrowManipulator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragArrowManipulator Interface](#) : LengthOppositeDirection Property (IDragArrowManipulator)

Gets or sets the length of the opposite handle.

.NET Syntax

Visual Basic (Declaration)

```
Property LengthOppositeDirection As System.Double
```

Visual Basic (Usage)

```
Dim instance As IDragArrowManipulator
Dim value As System.Double

instance.LengthOppositeDirection = value
```

```
value = instance.LengthOppositeDirection
```

C#

```
System.double LengthOppositeDirection {get; set;}
```

C++/CLI

```
property System.double LengthOppositeDirection {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Length of opposite handle

Visual Basic for Applications (VBA) Syntax

See [DragArrowManipulator::LengthOppositeDirection](#).

Example

See [IDragArrowManipulator](#) examples.

Remarks

If you change the length of the handle using this property, then use [IDragArrowMainpulator::Update](#) to display the modified handle in the graphic area.

See Also

[IDragArrowManipulator Interface](#)
[IDragArrowManipulator Members](#)
[IDragArrowManipulator::Length Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Origin Property (IDragArrowManipulator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragArrowManipulator Interface](#) : Origin Property (IDragArrowManipulator)

Gets or sets the origin of the handle.

.NET Syntax

Visual Basic (Declaration)

```
Property Origin As MathPoint
```

Visual Basic (Usage)



```
Dim instance As IDragArrowManipulator  
Dim value As MathPoint
```

```
instance.Origin = value
```

```
value = instance.Origin
```

C#

```
MathPoint Origin {get; set;}
```

C++/CLI

```
property MathPoint^ Origin {
    MathPoint^ get();
    void set ( & MathPoint^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pointer to [IMathPoint](#) object

Visual Basic for Applications (VBA) Syntax

See [DragArrowManipulator::Origin](#).

Example

See [IDragArrowManipulator](#) examples.

Remarks

Before calling this property to change the origin setting, set [IDragArrowManipulator::FixedLength](#) to true.

See Also

[IDragArrowManipulator Interface](#)
[IDragArrowManipulator Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowOppositeDirection Property (IDragArrowManipulator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragArrowManipulator Interface](#) : ShowOppositeDirection Property (IDragArrowManipulator)

Gets or sets whether to display the bidirectional handle.

.NET Syntax

Visual Basic (Declaration)

```
Property ShowOppositeDirection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDragArrowManipulator
Dim value As System.Boolean

instance.ShowOppositeDirection = value

value = instance.ShowOppositeDirection
```

C#

```
System.bool ShowOppositeDirection {get; set;}
```

C++/CLI

```
property System.bool ShowOppositeDirection {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to display the bidirectional handle, false to display the unidirectional handle

Visual Basic for Applications (VBA) Syntax

See [DragArrowManipulator::ShowOppositeDirection](#).

Example

See [IDragArrowManipulator](#) examples.

See Also

[IDragArrowManipulator Interface](#)
[IDragArrowManipulator Members](#)
[IDragArrowManipulator::AllowFlip Property\(\)](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowRuler Property (IDragArrowManipulator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragArrowManipulator Interface](#) : ShowRuler Property (IDragArrowManipulator)

Gets or sets whether to display a ruler when the handle moves.

.NET Syntax

Visual Basic (Declaration)

Property ShowRuler As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDragArrowManipulator  
Dim value As System.Boolean
```

```
instance.ShowRuler = value
```

```
value = instance.ShowRuler
```

C#

```
System.bool ShowRuler {get; set;}
```

C++/CLI

```
property System.bool ShowRuler {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to display a ruler when the handle moves, false to not

Visual Basic for Applications (VBA) Syntax

See [DragArrowManipulator::ShowRuler](#).

Example

See [IDragArrowManipulator](#) examples.

See Also

[IDragArrowManipulator Interface](#)
[IDragArrowManipulator Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Update Method (IDragArrowManipulator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragArrowManipulator Interface](#) : Update Method (IDragArrowManipulator)

Displays a handle after having modified the length of the handle.

.NET Syntax

Visual Basic (Declaration)

```
Function Update() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDragArrowManipulator  
Dim value As System.Boolean
```

```
value = instance.Update()
```

C#

```
System.bool Update()
```

C++/CLI

```
System.bool Update();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the length of the handle was updated, false if not

Visual Basic for Applications (VBA) Syntax

See [DragArrowManipulator.Update](#).

Example

See [IDragArrowManipulator](#) examples.

Remarks

To change the length of a handle, use [IDragArrowManipulator::Length](#) or [IDragArrowManipulator::LengthOppositeDirection](#), then use this method to see display the modified handle in the graphics area.

See Also

[IDragArrowManipulator Interface](#)
[IDragArrowManipulator Members](#)
[IDragArrowManipulator::Length Property](#)
[IDragArrowManipulator::LengthOppositeDirection Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0