

SOLIDWORKS API (.NET VBA C#) — Reference

(82/337): IDragOperator

SOLIDWORKS API Documentation (converted from CHM)

IDragOperator (Type)

IDragOperator Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDragOperator Interface

Allows access to settings for the **Move Components** command in the SOLIDWORKS Design user-interface.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IDragOperator
```

Visual Basic (Usage)



```
Dim instance As IDragOperator
```

C#

```
public interface IDragOperator
```

C++/CLI

```
public interface class IDragOperator
```

Visual Basic for Applications (VBA) Syntax

See [DragOperator](#).

Example

[Rotate Assembly Component on Axis Using IDragOperator::Drag \(C#\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::Drag \(VB.NET\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::Drag \(VBA\)](#)

Accessors

[IAssemblyDoc::GetDragOperator](#) and [IAssemblyDoc::!GetDragOperator](#)

Access Diagram

[DragOperator](#)

See Also

[IDragOperator Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IDragOperator Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDragOperator Interface

For a list of all members of this type, see [IDragOperator members](#).

Public Methods

Name	Description
AddComponent	Adds a component to the list of components to drag.
AddDynamicClearance	Adds a dynamic clearance detector.

	BeginDrag	Initiates the drag operation.
	CollisionDetection	Sets the collision detection parameters.
	Drag	Sets the transform matrix for this drag operation.
	DragAsUi	Sets the transform matrix for this drag operation.
	EndDrag	Terminates the drag operation.
	GetDragPoint	Gets the drag point.
	IAddComponent	Adds a component to the list of components to drag.
	IAddDynamicClearance	Adds a dynamic clearance detector.
	ICollisionDetection	Sets the collision detection parameters.
	IDrag	Sets the transform matrix for this drag operation.
	IGetDragPoint	Gets the drag point.
	ISetDragPoint	Sets the drag point.
	SetDragPoint	Sets the drag point.

[Top](#)

See Also

[IDragOperator Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDragOperator Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDragOperator Interface

The following tables list the members exposed by [IDragOperator](#).

Public Properties

Name	Description
 ApplyToThisConfiguration	Gets or sets the configurations to which to apply the movement of the components.
 Clearance	Gets the clearance distance between the components.
 CollisionDetectionEnabled	Gets or sets the collision detection setting.
 DragCorrected	Gets whether or not the drag operation was corrected.
 DragMode	Gets or sets the drag mode for this drag operation.
 DynamicClearanceEnabled	Gets or sets the dynamic clearance setting.
 GraphicsRedrawEnabled	Gets or sets whether or not to update the graphics display after moving components.
 HearClashes	Gets or sets whether sound is associated with entity clashes.
 HighlightClashes	Gets or sets whether to highlight clashes.
 IgnoreComplexSurfaces	Gets or sets whether complex surfaces are ignored.
 IsDragByRay	Gets or sets the drag-by-ray setting.
 IsDragSpecific	Gets or sets the drag-specific setting.
 IsRelaxationEval	Gets or sets the relaxation evaluation.
 SmartMating	Gets or sets SmartMates.
 TransformType	Gets or sets the type of transformation.
 UseAbsoluteTransform	Gets or sets whether the transforms to use with IDragOperator.Drag or IDragOperator.IDrag are absolute or relative.

[Top](#)

Public Methods

Name	Description
 AddComponent	Adds a component to the list of components to drag.
 AddDynamicClearance	Adds a dynamic clearance detector.
 BeginDrag	Initiates the drag operation.
 CollisionDetection	Sets the collision detection parameters.
 Drag	Sets the transform matrix for this drag operation.
 DragAsUi	Sets the transform matrix for this drag operation.
 EndDrag	Terminates the drag operation.
 GetDragPoint	Gets the drag point.
 IAddComponent	Adds a component to the list of components to drag.
 IAddDynamicClearance	Adds a dynamic clearance detector.
 ICollisionDetection	Sets the collision detection parameters.
 IDrag	Sets the transform matrix for this drag operation.
 IGetDragPoint	Gets the drag point.
 ISetDragPoint	Sets the drag point.
 SetDragPoint	Sets the drag point.

[Top](#)

See Also

[IDragOperator Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDragOperator Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IDragOperator Interface

For a list of all members of this type, see [IDragOperator members](#).

Public Properties

Name	Description
 ApplyToThisConfiguration	Gets or sets the configurations to which to apply the movement of the components.
 Clearance	Gets the clearance distance between the components.
 CollisionDetectionEnabled	Gets or sets the collision detection setting.
 DragCorrected	Gets whether or not the drag operation was corrected.
 DragMode	Gets or sets the drag mode for this drag operation.
 DynamicClearanceEnabled	Gets or sets the dynamic clearance setting.
 GraphicsRedrawEnabled	Gets or sets whether or not to update the graphics display after moving components.
 HearClashes	Gets or sets whether sound is associated with entity clashes.
 HighlightClashes	Gets or sets whether to highlight clashes.
 IgnoreComplexSurfaces	Gets or sets whether complex surfaces are ignored.
 IsDragByRay	Gets or sets the drag-by-ray setting.
 IsDragSpecific	Gets or sets the drag-specific setting.
 IsRelaxationEval	Gets or sets the relaxation evaluation.
 SmartMating	Gets or sets SmartMates.
 TransformType	Gets or sets the type of transformation.
 UseAbsoluteTransform	Gets or sets whether the transforms to use with IDragOperator::Drag or IDragOperator::iDrag are absolute or relative.

[Top](#)

See Also

[IDragOperator Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddComponent Method (IDragOperator)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : AddComponent Method (IDragOperator)

Adds a component to the list of components to drag.

.NET Syntax

Visual Basic (Declaration)

```
Function AddComponent( _  
    ByVal PDisp As System.Object, _  
    ByVal AppendFlag As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDragOperator  
Dim PDisp As System.Object  
Dim AppendFlag As System.Boolean  
Dim value As System.Boolean  
  
value = instance.AddComponent(PDisp, AppendFlag)
```

C#

```
System.bool AddComponent(  
    System.object PDisp,  
    System.bool AppendFlag  
)
```

C++/CLI

```
System.bool AddComponent(  
    & System.Object^ PDisp,  
    & System.bool AppendFlag  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PDisp

Component to add to the list

AppendFlag

True to append the component to the list, false to clear the list before adding the component

Return Value

True if successful, false for failure; fixed components always return false (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DragOperator::AddComponent](#).

Example

[Rotate Assembly Component on Axis Using IDragOperator::DragAsUI \(VBA\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::DragAsUI \(VB.NET\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::DragAsUI \(C#\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::Drag \(VBA\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::Drag \(VB.NET\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::Drag \(C#\)](#)

Remarks

Components that are constrained via mates are not considered fixed.

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)
[IDragOperator::IAddComponent Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddDynamicClearance Method (IDragOperator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : AddDynamicClearance Method (IDragOperator)

Adds a dynamic clearance detector.

.NET Syntax

Visual Basic (Declaration)

```
Function AddDynamicClearance( _  
    ByVal Comp1 As System.Object, _  
    ByVal Comp2 As System.Object, _  
    ByVal Value As System.Double, _  
    ByVal AppendFlag As System.Boolean, _  
    ByVal ShowDim As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDragOperator  
Dim Comp1 As System.Object  
Dim Comp2 As System.Object  
Dim Value As System.Double  
Dim AppendFlag As System.Boolean  
Dim ShowDim As System.Boolean  
Dim value As System.Integer
```

```
value = instance.AddDynamicClearance(Comp1, Comp2, Value, AppendFlag, ShowDim)
```

C#

```
System.int AddDynamicClearance(  
    System.object Comp1,  
    System.object Comp2,  
    System.double Value,  
    System.bool AppendFlag,  
    System.bool ShowDim  
)
```

C++/CLI

```
System.int AddDynamicClearance(  
& System.Object^ Comp1,  
& System.Object^ Comp2,  
& System.double Value,  
& System.bool AppendFlag,  
& System.bool ShowDim  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Comp1
First component of the clearance pair
Comp2
Second component of the clearance pair
Value
Minimum clearance distance

AppendFlag
True appends the component to the list, false overwrites the list

ShowDim
True displays a dynamic reference dimension of the minimum clearance distance

Return Value
Newly added clearance pair

Visual Basic for Applications (VBA) Syntax

See [DragOperator::AddDynamicClearance](#).

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)
[IDragOperator::AddDynamicClearance Method](#)
[IDragOperator::DynamicClearanceEnabled Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ApplyToThisConfiguration Property (IDragOperator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : ApplyToThisConfiguration Property (IDragOperator)

Gets or sets the configurations to which to apply the movement of the components.

.NET Syntax

Visual Basic (Declaration)

```
Property ApplyToThisConfiguration As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDragOperator  
Dim value As System.Boolean  
  
instance.ApplyToThisConfiguration = value  
  
value = instance.ApplyToThisConfiguration
```

C#

```
System.bool ApplyToThisConfiguration {get; set;}
```

C++/CLI

```
property System.bool ApplyToThisConfiguration {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True applies the movement of the components only to the active configuration, false applies it to all configurations

Visual Basic for Applications (VBA) Syntax

See [DragOperator::ApplyToThisConfiguration](#).

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

BeginDrag Method (IDragOperator)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : BeginDrag Method (IDragOperator)

Initiates the drag operation.

.NET Syntax

Visual Basic (Declaration)

```
Function BeginDrag() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDragOperator  
Dim value As System.Boolean  
  
value = instance.BeginDrag()
```

C#

```
System.bool BeginDrag()
```

C++/CLI

```
System.bool BeginDrag();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the drag operation started successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [DragOperator::BeginDrag](#).

Example

[Rotate Assembly Component on Axis Using IDragOperator::Drag \(VBA\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::Drag \(C#\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::Drag \(VB.NET\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::DragAsUI \(VBA\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::DragAsUI \(VB.NET\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::DragAsUI \(C#\)](#)

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)
[IDragOperator::EndDrag Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Clearance Property (IDragOperator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : Clearance Property (IDragOperator)

Gets the clearance distance between the components.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Clearance( _  
    ByVal NIndex As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDragOperator  
Dim NIndex As System.Integer  
Dim value As System.Double  
  
value = instance.Clearance(NIndex)
```

C#

```
System.double Clearance(  
    System.int NIndex  
) {get;}
```

C++/CLI

```
property System.double Clearance {  
    System.double get(System.int NIndex);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NIndex
Index of the components

Property Value

Clearance value

Visual Basic for Applications (VBA) Syntax

See [DragOperator::Clearance](#).

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CollisionDetection Method (IDragOperator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : CollisionDetection Method (IDragOperator)

Sets the collision detection parameters.

.NET Syntax

Visual Basic (Declaration)

```
Function CollisionDetection( _
    ByVal EntityArray As System.Object, _
    ByVal PartOnly As System.Boolean, _
    ByVal StopAt As System.Boolean _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDragOperator
Dim EntityArray As System.Object
Dim PartOnly As System.Boolean
Dim StopAt As System.Boolean
Dim value As System.Boolean
```

```
value = instance.CollisionDetection(EntityArray, PartOnly, StopAt)
```

C#

```
System.bool CollisionDetection(
    System.object EntityArray,
    System.bool PartOnly,
    System.bool StopAt
)
```

C++/CLI

```
System.bool CollisionDetection(
    & System.Object^ EntityArray,
    & System.bool PartOnly,
    & System.bool StopAt
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EntityArray

Array of [components](#) for collision detection

PartOnly

True checks for collisions with only the components that you selected to move, false check for collisions in all affected components

StopAt

True stops the motion of the component when it touches any other entity, false does not

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DragOperator::CollisionDetection](#).

See Also

[IDragOperator Interface](#)

[IDragOperator Members](#)

[IDragOperator::CollisionDetectionEnabled Property](#)

[IDragOperator::ICollisionDetection Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CollisionDetectionEnabled Property (IDragOperator)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : CollisionDetectionEnabled Property (IDragOperator)

Gets or sets the collision detection setting.

.NET Syntax

Property CollisionDetectionEnabled As System.Boolean



```
Dim instance As IDragOperator
Dim value As System.Boolean

instance.CollisionDetectionEnabled = value

value = instance.CollisionDetectionEnabled
```

```
System.bool CollisionDetectionEnabled {get; set;}
```

```
property System.bool CollisionDetectionEnabled {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if collision detection is enabled, false if it is disabled

Visual Basic for Applications (VBA) Syntax

See [DragOperator::CollisionDetectionEnabled](#).

Example

[Rotate Assembly Component on Axis Using IDragOperator::Drag \(VBA\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::Drag \(VB.NET\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::Drag \(C#\)](#)

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)
[IDragOperator::CollisionDetection Method](#)
[IDragOperator.Drag Method](#)
[IDragOperator.DragAsUI Method](#)
[IDragOperator.DynamicClearanceEnabled Property](#)
[IDragOperator.ICollisionDetection Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

Drag Method (IDragOperator)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : Drag Method (IDragOperator)

Sets the transform matrix for this drag operation.

.NET Syntax

```
Function Drag( _
    ByVal PXform As System.Object _
) As System.Boolean
```



```
Dim instance As IDragOperator
Dim PXform As System.Object
Dim value As System.Boolean

value = instance.Drag(PXform)
```

C#

```
System.bool Drag(
    System.object PXform
)
```

C++/CLI

```
System.bool Drag(
    & System.Object^ PXform
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PXform

Math transform that specifies the desired motion for this step

Return Value

True if the move was successful, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DragOperator::Drag](#).

Example

[Rotate Assembly Component on Axis Using IDragOperator::Drag \(VBA\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::Drag \(VB.NET\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::Drag \(C#\)](#)

Remarks

This method is more precise than the [IDragOperator::DragAsUI](#) method. [IDragOperator::DragAsUI](#) is more like an interactive drag operation performed in the SOLIDWORKS 2001Plus software and it may give better graphics performance than [IDragOperator::Drag](#).

You will see an improvement in performance when this method is used in the default state. If [collision detection](#) or [clearance](#) is enabled, then the original mode is used. This method is more efficient than making multiple calls to [IComponent2::SetTransformAndSolve](#) because this method reuses the solver.

Use [IDragOperator::UseAbsoluteTransforms](#) to set the transforms type to absolute or relative.

If the desired orientation set by this method was not honored and remedial action occurred, then the [IDragOperation::DragCorrected](#) property is set.

This method returns false if the drag cannot be performed. This typically occurs because of a collision.

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)
[IDragOperator::CollisionDetectionEnabled Property](#)
[IDragOperator::DragAsUI Method](#)
[IDragOperator::DynamicClearanceEnabled Property](#)
[IDragOperator::IDrag Method](#)
[IDragOperator::UseAbsoluteTransform Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

Sets the transform matrix for this drag operation.

.NET Syntax

Visual Basic (Declaration)

```
Function DragAsUI( _
    ByVal PXform As MathTransform _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IDragOperator
Dim PXform As MathTransform
Dim value As System.Boolean

value = instance.DragAsUI(PXform)
```

C#

```
System.bool DragAsUI(
    MathTransform PXform
)
```

C++/CLI

```
System.bool DragAsUI(
    & MathTransform^ PXform
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PXform

Pointer to [IMathTransform](#) that specifies the desired motion for this step

Return Value

True if the move was successful, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DragOperator::DragAsUI](#).

Example

[Rotate Assembly Component on Axis Using IDragOperator::DragAsUI \(VBA\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::DragAsUI \(VB.NET\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::DragAsUI \(C#\)](#)

Remarks

This method returns false if the drag cannot be performed. This typically occurs because of a collision.

This method does not set [IDragOperator::DragCorrected](#).

This method is not as precise as the [IDragOperator::Drag](#) or [IDragOperator::IDrag](#) method. IDragOperator::DragAsUI is more like an interactive drag operation performed in the SOLIDWORKS 2001Plus software. This method may give better graphics performance than IDragOperator::Drag.

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)
[IDragOperator::CollisionDetection Method](#)
[IDragOperator::DynamicClearanceEnabled Property](#)

Availability

DragCorrected Property (IDragOperator)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : DragCorrected Property (IDragOperator)

Gets whether or not the drag operation was corrected.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property DragCorrected As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDragOperator
Dim value As System.Boolean

value = instance.DragCorrected
```

C#

```
System.bool DragCorrected {get;}
```

C++/CLI

```
property System.bool DragCorrected {
    System.bool get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if remedial action occurred, false if not

Visual Basic for Applications (VBA) Syntax

See [DragOperator::DragCorrected](#).

Remarks

If the desired orientation set by [IDragOperator::Drag](#) or [IDragOperator::IDrag](#) was not honored and remedial action occurred, then this property is set. This property is not set by [IDragOperator::DragAsUI](#).

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)

Availability

SOLIDWORKS 2004 SP3, Revision Number 12.3

DragMode Property (IDragOperator)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : DragMode Property (IDragOperator)

Gets or sets the drag mode for this drag operation.

.NET Syntax

Visual Basic (Declaration)

Property DragMode As System.Short

Visual Basic (Usage)



```
Dim instance As IDragOperator  
Dim value As System.Short
```

```
instance.DragMode = value
```

```
value = instance.DragMode
```

C#

```
System.short DragMode {get; set;}
```

C++/CLI

```
property System.short DragMode {  
    System.short get();  
    void set ( & System.short value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

- 0 = Maximum move (move geometries rigidly, if possible)
- 1 = Minimum move (move the smallest number of geometries)
- 2 = Relaxation (solve geometries using relaxation)
- 3 = No propagation (move geometries with minimal transform propagation)

Visual Basic for Applications (VBA) Syntax

See [DragOperator::DragMode](#).

Example

[Rotate Assembly Component on Axis Using IDragOperator::Drag \(VBA\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::Drag \(VB.NET\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::Drag \(C#\)](#)

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DynamicClearanceEnabled Property (IDragOperator)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : DynamicClearanceEnabled Property (IDragOperator)

Gets or sets the dynamic clearance setting.

.NET Syntax

Visual Basic (Declaration)

```
Property DynamicClearanceEnabled As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDragOperator
Dim value As System.Boolean

instance.DynamicClearanceEnabled = value
value = instance.DynamicClearanceEnabled
```

C#

```
System.bool DynamicClearanceEnabled {get; set;}
```

C++/CLI

```
property System.bool DynamicClearanceEnabled {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True enables the dynamic clearance option, false disables it

Visual Basic for Applications (VBA) Syntax

See [DragOperator::DynamicClearanceEnabled](#).

Example

[Rotate Assembly Component on Axis Using IDragOperator::Drag \(VBA\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::Drag \(VB.NET\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::Drag \(C#\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::DragAsUI \(VBA\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::DragAsUI \(VB.NET\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::DragAsUI \(C#\)](#)

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)
[IDragOperator::AddDynamicClearance Method](#)
[IDragOperator::CollisionDetection Method](#)
[IDragOperator::Drag Method](#)
[IDragOperator::DragAsUI Method](#)
[IDragOperator::IDrag Method](#)
[IDragOperator::IAddDynamicClearance Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

EndDrag Method (IDragOperator)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : EndDrag Method (IDragOperator)

Terminates the drag operation.

.NET Syntax

Visual Basic (Declaration)

```
Function EndDrag() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDragOperator  
Dim value As System.Boolean
```

```
value = instance.EndDrag()
```

C#

```
System.bool EndDrag()
```

C++/CLI

```
System.bool EndDrag();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the drag operation ended successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [DragOperator::EndDrag](#).

Example

[Rotate Assembly Component on Axis Using IDragOperator::Drag \(VBA\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::Drag \(VB.NET\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::Drag \(C#\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::DragAsUI \(VBA\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::DragAsUI \(VB.NET\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::DragAsUI \(C#\)](#)

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)
[IDragOperator::BeginDrag Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDragPoint Method (IDragOperator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : GetDragPoint Method (IDragOperator)

Gets the drag point.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDragPoint( _  
    ByRef Point As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDragOperator  
Dim Point As System.Object  
Dim value As System.Boolean  
  
value = instance.GetDragPoint(Point)
```

C#

```
System.bool GetDragPoint(  
    out System.object Point
```

```
)
```

C++/CLI

```
System.bool GetDragPoint(  
& [Out] System.Object^ Point  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Point

Array containing the X, Y, Z coordinates of the drag point

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DragOperator::GetDragPoint](#).

Remarks

Unless set to another value by [IDragOperator::SetDragPoint](#), this value is the origin of the component.

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)
[IDragOperator::IGetDragPoint Method](#)
[IDragOperator::ISetDragPoint Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GraphicsRedrawEnabled Property (IDragOperator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : GraphicsRedrawEnabled Property (IDragOperator)

Gets or sets whether or not to update the graphics display after moving components.

.NET Syntax

Visual Basic (Declaration)

```
Property GraphicsRedrawEnabled As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDragOperator  
Dim value As System.Boolean  
  
instance.GraphicsRedrawEnabled = value  
  
value = instance.GraphicsRedrawEnabled
```

C#

```
System.bool GraphicsRedrawEnabled {get; set;}
```

C++/CLI

```
property System.bool GraphicsRedrawEnabled {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to update the graphics display after moving components, false to not

Visual Basic for Applications (VBA) Syntax

See [DragOperator::GraphicsRedrawEnabled](#).

Remarks

If this property is set to false, call [IModelDoc2::GraphicsRedraw2](#) when you want to update the graphics display. This property is set to True by default.

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)

Availability

SOLIDWORKS 2004 SP4, Revision Number 12.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

HearClashes Property (IDragOperator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : HearClashes Property (IDragOperator)

Gets or sets whether sound is associated with entity clashes.

.NET Syntax

Visual Basic (Declaration)

Property HearClashes As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDragOperator  
Dim value As System.Boolean
```

```
instance.HearClashes = value
```

```
value = instance.HearClashes
```

C#

```
System.bool HearClashes {get; set;}
```

C++/CLI

```
property System.bool HearClashes {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the sound for clashes is enabled, false if it is disabled

Visual Basic for Applications (VBA) Syntax

See [DragOperator::HearClashes](#).

Remarks

This property enables audio feedback when collisions occur between components selected for collision detection.

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)
[IDragOperator::HighlightClashes Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

HighlightClashes Property (IDragOperator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : HighlightClashes Property (IDragOperator)

Gets or sets whether to highlight clashes.

.NET Syntax

Visual Basic (Declaration)

Property HighlightClashes As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDragOperator
Dim value As System.Boolean

instance.HighlightClashes = value

value = instance.HighlightClashes
```

C#

```
System.bool HighlightClashes {get; set;}
```

C++/CLI

```
property System.bool HighlightClashes {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if clash highlighting is enabled, false if it is disabled

Visual Basic for Applications (VBA) Syntax

See [DragOperator::HighlightClashes](#).

Remarks

This property enables visual feedback when collisions occur between components selected for collision detection.

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)
[IDragOperator::HearClashes Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

IAddComponent Method (IDragOperator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : IAddComponent Method (IDragOperator)

Adds a component to the list of components to drag.

.NET Syntax

Visual Basic (Declaration)

```
Function IAddComponent( _  
    ByVal PComp As Component2, _  
    ByVal AppendFlag As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDragOperator  
Dim PComp As Component2  
Dim AppendFlag As System.Boolean  
Dim value As System.Boolean  
  
value = instance.IAddComponent(PComp, AppendFlag)
```

C#

```
System.bool IAddComponent(  
    Component2 PComp,  
    System.bool AppendFlag  
)
```

C++/CLI

```
System.bool IAddComponent(  
& Component2^ PComp,  
& System.bool AppendFlag  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PComp

[Component](#) to add to the list

AppendFlag

True to append the component to the list, false to clear the list before adding the component

Return Value

True if successful, false for failure; fixed components always return false (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DragOperator.IAddComponent](#).

Remarks

Components that are constrained via mates are not considered fixed.

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)
[IDragOperator.IAddComponent Method](#)

Availability

IAddDynamicClearance Method (IDragOperator)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : IAddDynamicClearance Method (IDragOperator)

Adds a dynamic clearance detector.

 .NET Syntax

Visual Basic (Declaration)

```
Function IAddDynamicClearance( _
    ByVal Comp1 As Component2, _
    ByVal Comp2 As Component2, _
    ByVal Value As System.Double, _
    ByVal AppendFlag As System.Boolean, _
    ByVal ShowDim As System.Boolean _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDragOperator
Dim Comp1 As Component2
Dim Comp2 As Component2
Dim Value As System.Double
Dim AppendFlag As System.Boolean
Dim ShowDim As System.Boolean
Dim value As System.Integer

value = instance.IAddDynamicClearance(Comp1, Comp2, Value, AppendFlag, ShowDim)
```

C#

```
System.int IAddDynamicClearance(
    Component2 Comp1,
    Component2 Comp2,
    System.double Value,
    System.bool AppendFlag,
    System.bool ShowDim
)
```

C++/CLI

```
System.int IAddDynamicClearance(
    & Component2^ Comp1,
    & Component2^ Comp2,
    & System.double Value,
    & System.bool AppendFlag,
    & System.bool ShowDim
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

*Comp1*First [component](#) of the clearance pair*Comp2*Second [component](#) of the clearance pair*Value*

Minimum clearance distance

AppendFlag

True appends the component to the list, false overwrites the list

ShowDim

True displays a dynamic reference dimension of the minimum clearance distance

Return Value

Newly added clearance pair

 Visual Basic for Applications (VBA) Syntax

See [DragOperator::AddDynamicClearance](#).

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)
[IDragOperator::AddDynamicClearance Method](#)
[IDragOperator::DynamicClearanceEnabled Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICollisionDetection Method (IDragOperator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : ICollisionDetection Method (IDragOperator)

Sets the collision detection parameters.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function ICollisionDetection( _  
    ByVal Count As System.Integer, _  
    ByRef ComponentArray As Component2, _  
    ByVal PartOnly As System.Boolean, _  
    ByVal StopAt As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDragOperator  
Dim Count As System.Integer  
Dim ComponentArray As Component2  
Dim PartOnly As System.Boolean  
Dim StopAt As System.Boolean  
Dim value As System.Boolean  
  
value = instance.ICollisionDetection(Count, ComponentArray, PartOnly, StopAt)
```

C#

```
System.bool ICollisionDetection(  
    System.int Count,  
    ref Component2 ComponentArray,  
    System.bool PartOnly,  
    System.bool StopAt  
)
```

C++/CLI

```
System.bool ICollisionDetection(  
& System.int Count,  
& Component2^% ComponentArray,  
& System.bool PartOnly,  
& System.bool StopAt  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of components for collision detection

ComponentArray

Array of [components](#) for collision detection

PartOnly

True checks for collisions with only the components that you selected to move, false check for collisions in all affected components

StopAt

True stops the motion of the component when it touches any other entity, false does not

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DragOperator::ICollisionDetection](#).

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)
[IDragOperator::CollisionDetection Method](#)
[IDragOperator::CollisionDetectionEnabled Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDrag Method (IDragOperator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : IDrag Method (IDragOperator)

Sets the transform matrix for this drag operation.

.NET Syntax

Visual Basic (Declaration)

```
Function IDrag( _  
    ByVal PXform As MathTransform _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDragOperator  
Dim PXform As MathTransform  
Dim value As System.Boolean
```

```
value = instance.IDrag(PXform)
```

C#

```
System.bool IDrag(  
    MathTransform PXform  
)
```

C++/CLI

```
System.bool IDrag(  
& MathTransform^ PXform  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PXform

Pointer to an [IMathTransform](#) that specifies the desired motion for this step

Return Value

True if the move was successful, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DragOperator::IDrag](#).

Remarks

This method is more precise than the [IDragOperator::DragAsUI](#) method. IDragOperator::DragAsUI is more like an interactive drag operation performed in the SOLIDWORKS 2001Plus software and it may give better graphics performance than IDragOperator::Drag.

You will see an improvement in performance when this method is used in the default state. If [collision detection](#) or [clearance](#) is enabled, then the original mode is used. This method is more efficient than making multiple calls to [IComponent2::SetTransformAndSolve](#) because this method reuses the solver.

Use [IDragOperator::UseAbsoluteTransforms](#) to set the transforms type to absolute or relative.

If the desired orientation set by this method was not honored and remedial action occurred, then the [IDragOperation::DragCorrected](#) property is set.

This method returns false if the drag cannot be performed. This typically occurs because of a collision.

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)
[IDragOperator::Drag Method](#)
[IDragOperator::CollisionDetectionEnabled Property](#)
[IDragOperator::DynamicClearanceEnabled Property](#)
[IDragOperator::UseAbsoluteTransform Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDragPoint Method (IDragOperator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : IGetDragPoint Method (IDragOperator)

Gets the drag point.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDragPoint( _  
    ByRef Point As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDragOperator  
Dim Point As System.Double  
Dim value As System.Boolean  
  
value = instance.IGetDragPoint(Point)
```

C#

```
System.bool IGetDragPoint(  
    out System.double Point  
)
```

C++/CLI

```
System.bool IGetDragPoint(  
& [Out] System.double Point  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Point

Array containing the X, Y, Z coordinates of the drag point

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DragOperator::IGetDragPoint](#).

Remarks

Unless set to another value by [IDragOperator::ISetDragPoint](#), this value is the origin of the component.

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)
[IDragOperator::GetDragPoint Method](#)
[IDragOperator::SetDragPoint Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IgnoreComplexSurfaces Property (IDragOperator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : IgnoreComplexSurfaces Property (IDragOperator)

Gets or sets whether complex surfaces are ignored.

.NET Syntax

Visual Basic (Declaration)

```
Property IgnoreComplexSurfaces As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDragOperator  
Dim value As System.Boolean  
  
instance.IgnoreComplexSurfaces = value  
value = instance.IgnoreComplexSurfaces
```

C#

```
System.bool IgnoreComplexSurfaces {get; set;}
```

C++/CLI

```
property System.bool IgnoreComplexSurfaces {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True ignores complex surfaces, false does not

Visual Basic for Applications (VBA) Syntax

See [DragOperator::IgnoreComplexSurfaces](#).

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsDragByRay Property (IDragOperator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : IsDragByRay Property (IDragOperator)

Gets or sets the drag-by-ray setting.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property IsDragByRay As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDragOperator  
Dim value As System.Boolean
```

```
instance.IsDragByRay = value
```

```
value = instance.IsDragByRay
```

C#

```
System.bool IsDragByRay {get; set;}
```

C++/CLI

```
property System.bool IsDragByRay {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True uses drag-by-ray, false uses drag-by-transform (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DragOperator::IsDragByRay](#).

Remarks

- Drag-by-ray Tries to find a solution that keeps a specified geometry on, or close to, a ray (defined by a point on the ray and its direction)
- Drag-by-transform Uses a transform matrix, which is any combination of translations and rotations.

NOTE: IDragOperator does not define the drag ray; it only performs drag-by-transform. If this property is set to True, the user-interface component move honors this setting. The default mode for the user interface is drag-by-transform.

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsDragSpecific Property (IDragOperator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : IsDragSpecific Property (IDragOperator)

Gets or sets the drag-specific setting.

.NET Syntax

Visual Basic (Declaration)

```
Property IsDragSpecific As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDragOperator  
Dim value As System.Boolean
```

```
instance.IsDragSpecific = value
```

```
value = instance.IsDragSpecific
```

C#

```
System.bool IsDragSpecific {get; set;}
```

C++/CLI

```
property System.bool IsDragSpecific {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True sets drag specific, false sets drag possible

Visual Basic for Applications (VBA) Syntax

See [DragOperator.IsDragSpecific](#).

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetDragPoint Method (IDragOperator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : ISetDragPoint Method (IDragOperator)

Sets the drag point.

.NET Syntax

Visual Basic (Declaration)

```
Function ISetDragPoint( _  
    ByRef Point As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDragOperator  
Dim Point As System.Double
```

```
Dim value As System.Boolean

value = instance.ISetDragPoint(Point)
```

C#

```
System.bool ISetDragPoint(
    ref System.double Point
)
```

C++/CLI

```
System.bool ISetDragPoint(
    & System.double% Point
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Point
Array containing the X, Y, Z coordinate of the drag point

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DragOperator::ISetDragPoint](#).

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)
[IDragOperator::GetDragPoint Method](#)
[IDragOperator::IGetDragPoint Method](#)
[IDragOperator::SetDragPoint Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsRelaxationEval Property (IDragOperator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : IsRelaxationEval Property (IDragOperator)

Gets or sets the relaxation evaluation.

.NET Syntax

Visual Basic (Declaration)

```
Property IsRelaxationEval As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDragOperator
Dim value As System.Boolean

instance.IsRelaxationEval = value

value = instance.IsRelaxationEval
```

C#

```
System.bool IsRelaxationEval {get; set;}
```

C++/CLI

```
property System.bool IsRelaxationEval {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True for relaxation evaluation, false for standard evaluation

Visual Basic for Applications (VBA) Syntax

See [DragOperator::IsRelaxationEval](#).

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDragPoint Method (IDragOperator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : SetDragPoint Method (IDragOperator)

Sets the drag point.

.NET Syntax

Visual Basic (Declaration)

```
Function SetDragPoint( _
    ByVal Point As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDragOperator
Dim Point As System.Object
Dim value As System.Boolean

value = instance.SetDragPoint(Point)
```

C#

```
System.bool SetDragPoint(
    System.object Point
)
```

C++/CLI

```
System.bool SetDragPoint(
    & System.Object^ Point
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Point

Array of size 3 containing the X, Y, Z coordinate of the drag point

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DragOperator::SetDragPoint](#).

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)
[IDragOperator::GetDragPoint Method](#)
[IDragOperator::!GetDragPoint Method](#)
[IDragOperator::!SetDragPoint Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SmartMating Property (IDragOperator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : SmartMating Property (IDragOperator)

Gets or sets SmartMates.

.NET Syntax

Visual Basic (Declaration)

```
Property SmartMating As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDragOperator  
Dim value As System.Boolean
```

```
instance.SmartMating = value
```

```
value = instance.SmartMating
```

C#

```
System.bool SmartMating {get; set;}
```

C++/CLI

```
property System.bool SmartMating {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

RUE enables SmartMates, false disables it

Visual Basic for Applications (VBA) Syntax

See [DragOperator::SmartMating](#).

Remarks

SmartMates is an assembly mating relation that SOLIDWORKS creates automatically.

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TransformType Property (IDragOperator)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : TransformType Property (IDragOperator)

Gets or sets the type of transformation.

.NET Syntax

Visual Basic (Declaration)

Property TransformType As System.Short

Visual Basic (Usage)



```
Dim instance As IDragOperator
Dim value As System.Short
```

```
instance.TransformType = value
```

```
value = instance.TransformType
```

C#

```
System.short TransformType {get; set;}
```

C++/CLI

```
property System.short TransformType {
    System.short get();
    void set ( & System.short value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Translation	0	Transform is translation only
Axial Rotation	1	Transform is rotation only
General	2	Transform can be translation or rotation or both

Visual Basic for Applications (VBA) Syntax

See [DragOperator::TransformType](#).

Example

[Rotate Assembly Component on Axis Using IDragOperator::Drag \(VBA\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::Drag \(VB.NET\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::Drag \(C#\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::DragAsUI \(VBA\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::DragAsUI \(VB.NET\)](#)
[Rotate Assembly Component on Axis Using IDragOperator::DragAsUI \(C#\)](#)

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)
[IDragOperator::UseAbsoluteTransform Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseAbsoluteTransform Property (IDragOperator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDragOperator Interface](#) : UseAbsoluteTransform Property (IDragOperator)

Gets or sets whether the transforms to use with [IDragOperator::Drag](#) or [IDragOperator::IDrag](#) are absolute or relative.

.NET Syntax

Visual Basic (Declaration)

Property UseAbsoluteTransform As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDragOperator
Dim value As System.Boolean

instance.UseAbsoluteTransform = value

value = instance.UseAbsoluteTransform
```

C#

```
System.bool UseAbsoluteTransform {get; set;}
```

C++/CLI

```
property System.bool UseAbsoluteTransform {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use absolute transforms, false to use relative transforms

Visual Basic for Applications (VBA) Syntax

See [DragOperator::UseAbsoluteTransform](#).

See Also

[IDragOperator Interface](#)
[IDragOperator Members](#)
[IDragOperator::TransformType Property](#)

Availability

SOLIDWORKS 2004 SP3, Revision Number 12.3