

SOLIDWORKS API (.NET VBA C#) — Reference (84/337): IDrawingDoc (part 1 of 7)

SOLIDWORKS API Documentation (converted from CHM)

IDrawingDoc (part 1 of 7) (Type)

IDrawingDoc Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDrawingDoc Interface

Allows access to functions that perform drawing operations.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IDrawingDoc

Visual Basic (Usage)



Dim instance As [IDrawingDoc](#)

C#

public interface IDrawingDoc

C++/CLI

public interface class IDrawingDoc

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc](#).

Example

[Copy and Paste Drawing Sheet \(C#\)](#)
[Copy and Paste Drawing Sheet \(VB.NET\)](#)
[Copy and Paste Drawing Sheet \(VBA\)](#)
[Manage Drawing Document Line Styles \(C#\)](#)
[Manage Drawing Document Line Styles \(VB.NET\)](#)
[Manage Drawing Document Line Styles \(VBA\)](#)
[Activate Each View on Current Sheet \(VBA\)](#)
[Insert Spline in Drawing \(C++\)](#)
[Get Notes from New or Existing Title Block \(C#\)](#)
[Get Notes from New or Existing Title Block \(VB.NET\)](#)
[Get Notes from New or Existing Title Block \(VBA\)](#)
[Insert Revision Cloud into a Drawing \(VBA\)](#)

Remarks

Creating, aligning, and accessing drawing views are a few of the functions you find on the IDrawingDoc object.

The SOLIDWORKS API also includes functions that are common to all document types. For example, determining the file name associated with a document is a common operation. The SOLIDWORKS API uses the [IModelDoc2](#) object to expose common document-level functions.

Events are implemented with delegates in the Microsoft .NET Framework. See the [Overview](#) topic for a list of delegates for this interface.

Access Diagram

[DrawingDoc](#)

See Also

[IDrawingDoc Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IDrawingDoc Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDrawingDoc Interface

The following tables list the members exposed by [IDrawingDoc](#).

Public Properties

Name	Description
 ActiveDrawingView	Gets the currently active drawing view.
 AutomaticViewUpdate	Gets or sets whether the drawing views in this drawing are automatically updated if the underlying model in that drawing view changes.
 BackgroundProcessingOption	Gets or sets the background processing option for this drawing.
 HiddenViewsVisible	Shows or hides all of the hidden drawing views.
 IActiveDrawingView	Gets the currently active drawing view.
 Sheet	Gets the specified sheet.

[Top](#)

Public Methods

Name	Description
 ActivateSheet	Activates the specified drawing sheet.
 ActivateView	Activates the specified drawing view.
 AddCenterMark	Obsolete. Superseded by IDrawingDoc::InsertCenterMark2 .
 AddChamferDim	Adds a chamfer dimension.
 AddHoleCallout	Obsolete. Superseded by IDrawingDoc::AddHoleCallout2 .
 AddHoleCallout2	Adds a hole callout at the specified position to the hole whose edge is selected.
 AddLineStyle	Adds a line style to the current drawing.
 AddOrdinateDimension	Obsolete. Superseded by IModelDocExtension::AddOrdinateDimension .
 AddOrdinateDimension2	Obsolete. Superseded by IModelDocExtension::AddOrdinateDimension .
 AlignHorz	Uses the selected edge to align the current drawing view.
 AlignOrdinate	Aligns the ordinate dimension.
 AlignVert	Uses the selected edge to align the current drawing view.
 AttachAnnotation	Attaches an existing annotation to a drawing sheet or view.
 AttachDimensions	Attaches unattached dimensions.
 AutoBalloon	Obsolete. Superseded by IDrawingDoc::AutoBalloon3 .
 AutoBalloon2	Obsolete. Superseded by IDrawingDoc::AutoBalloon3 .
 AutoBalloon3	Obsolete. Superseded by IDrawingDoc::AutoBalloon4 .
 AutoBalloon4	Obsolete. Superseded by IDrawingDoc::AutoBalloon5 .
 AutoBalloon5	Automatically inserts BOM balloons in selected drawing views.
 AutoDimension	Automatically dimensions the selected drawing view.
 BreakLineSplineCut	Obsolete. Superseded by IBreakLine::Style .
 BreakLineStraightCut	Obsolete. Superseded by IBreakLine::Style .
 BreakLineZigZagCut	Obsolete. Superseded by IBreakLine::Style .
 BreakView	Breaks the drawing view along the existing break lines.
 CenterMark	Obsolete. Not superseded.
 ChangeComponentLayer	Puts the selected components on the specified layer.
 ChangeOrdDir	Changes the ordinate direction.
 ChangeRefConfigurationOffFlatPatternView	Changes the configuration of the selected flat-pattern view of the specified model.
 Create1stAngleViews	Obsolete. Superseded by IDrawingDoc::1stAngleViews2 .
Create1stAngleViews2	Creates standard three orthographic views (first angle projection) for the specified model.

		
	Create3rdAngleViews	Obsolete. Superseded by IDrawingDoc::Create3rdAngleViews2 .
	Create3rdAngleViews2	Creates standard three orthographic views (third angle projection) for the specified model.
	CreateAngDim	Obsolete. Superseded by IDrawingDoc::CreateAngDim4 .
	CreateAngDim2	Obsolete. Superseded by IDrawingDoc::CreateAngDim4 .
	CreateAngDim3	Obsolete. Superseded by IDrawingDoc::CreateAngDim4 .
	CreateAngDim4	Creates a non-associative angular dimension.
	CreateAutoBalloonOptions	Creates an object that stores auto balloon options.
	CreateAuxiliaryViewAt	Obsolete. Superseded by IDrawingDoc::CreateAuxiliaryViewAt2 .
	CreateAuxiliaryViewAt2	Creates an auxiliary view based on a selected edge in a drawing view.
	CreateBlockDefinition	Obsolete. Superseded by ISketchManager::MakeSketchBlockFromFile , ISketchManager::MakeSketchBlockSelected , and ISketchManager::MakeSketchBlockFromSketch .
	CreateBreakOutSection	Creates a broken-out section in a drawing document.
	CreateCompoundNote	Obsolete for documents created in SOLIDWORKS 2016 and later. Superseded by ISketchBlockDefinition and ISketchBlockInstance . Creates and returns a compound note.
	CreateConstructionGeometry	Sets the selected sketch segments to be construction geometry instead of sketch geometry.
	CreateCustomSymbol	Obsolete. Superseded by ISketchManager::MakeSketchBlockFromFile , ISketchManager::MakeSketchBlockSelected , and ISketchManager::MakeSketchBlockFromSketch .
	CreateDetailView	Obsolete. Superseded by IDrawingDoc::CreateDetailViewAt3 .
	CreateDetailViewAt	Obsolete. Superseded by IDrawingDoc::CreateDetailViewAt3 .
	CreateDetailViewAt2	Obsolete. Superseded by IDrawingDoc::CreateDetailViewAt3 .
	CreateDetailViewAt3	Obsolete. Superseded by IDrawingDoc::CreateDetailViewAt4 .
	CreateDetailViewAt4	Creates a detail view in a drawing document.
	CreateDiamDim	Obsolete. Superseded by IDrawingDoc::CreateDiamDim4 .
	CreateDiamDim2	Obsolete. Superseded by IDrawingDoc::CreateDiamDim4 .
	CreateDiamDim3	Obsolete. Superseded by IDrawingDoc::CreateDiamDim4 .
	CreateDiamDim4	Creates a non-associative diameter dimension.
	CreateDrawViewFromModelView	Obsolete. Superseded by IDrawingDoc::CreateDrawViewFromModelView3 .
	CreateDrawViewFromModelView2	Obsolete. Superseded by IDrawingDoc::CreateDrawViewFromModelView3 .
	CreateDrawViewFromModelView3	Creates a drawing view on the current drawing sheet using the specified model view.
	CreateFlatPatternViewFromModelView	Obsolete. Superseded by IDrawingDoc::CreateFlatPatternViewFromModelView2 .
	CreateFlatPatternViewFromModelView2	Obsolete. Superseded by IDrawingDoc::CreateFlatPatternViewFromModelView3 .
	CreateFlatPatternViewFromModelView3	Creates a flat-pattern view from a model view.
	CreateLayer	Obsolete. Superseded by IDrawingDoc::CreateLayer2 .
	CreateLayer2	Creates a layer for this document.
	CreateLinearDim	Obsolete. Superseded by IDrawingDoc::CreateLinearDim4 .
	CreateLinearDim2	Obsolete. Superseded by IDrawingDoc::CreateLinearDim4 .
	CreateLinearDim3	Obsolete. Superseded by IDrawingDoc::CreateLinearDim4 .
	CreateLinearDim4	Creates a non-associative linear dimension.
	CreateOrdinateDim	Obsolete. Superseded by IDrawingDoc::CreateOrdinateDim4 .
	CreateOrdinateDim2	Obsolete. Superseded by IDrawingDoc::CreateOrdinateDim4 .
	CreateOrdinateDim3	Obsolete. Superseded by IDrawingDoc::CreateOrdinateDim4 .
	CreateOrdinateDim4	Creates a non-associative ordinate dimension.
	CreateRelativeView	Creates a relative drawing view.
	CreateSectionView	Creates a section view in the drawing using the selected section line.
	CreateSectionViewAt	Obsolete. Superseded by IDrawingDoc::CreateSectionViewAt4 .

		
	CreateSectionViewAt2	Obsolete. Superseded by IDrawingDoc::CreateSectionViewAt4 .
	CreateSectionViewAt3	Obsolete. Superseded by IDrawingDoc::CreateSectionViewAt4 .
	CreateSectionViewAt4	Obsolete. Superseded by IDrawingDoc::CreateSectionViewAt5 .
	CreateSectionViewAt5	Creates the specified section view.
	CreateText	Obsolete. Superseded by IDrawingDoc::CreateText2 .
	CreateText2	Creates a note containing the specified text at a given location.
	CreateUnfoldedViewAt	Obsolete. Superseded by IDrawingDoc::CreateUnfoldedViewAt3 .
	CreateUnfoldedViewAt2	Obsolete. Superseded by IDrawingDoc::CreateUnfoldedViewAt3 .
	CreateUnfoldedViewAt3	Creates an unfolded drawing view from the selected drawing view and places it in the drawing at the specified location.
	CreateViewport	Obsolete. Superseded by IDrawingDoc::CreateViewport3 .
	CreateViewport2	Obsolete. Superseded by IDrawingDoc::CreateViewport3 .
	CreateViewport3	Creates a an empty view in a drawing.
	DeleteAllCosmeticThreads	Deletes all cosmetic threads, which do not have callouts, in a drawing of an assembly only.
	DeleteLineStyle	Deletes the specified line style from the current drawing.
	Dimensions	Adds dimensions to the drawing from model.
	DragModelDimension	Copies or moves dimensions to a different drawing view.
	DrawingViewRotate	Rotates the selected drawing view.
	DropDrawingViewFromPalette	Obsolete. Superseded by IDrawingDoc::DropDrawingViewFromPalette2 .
	DropDrawingViewFromPalette2	Moves the specified drawing view from the View Palette to the current drawing sheet.
	EditCenterMarkProperties	Edits center mark properties.
	EditOrdinate	Edits an ordinate dimension.
	EditRebuild	Obsolete. Superseded by IModelDoc2::EditRebuild3 .
	EditSelectedGtol	Gets the selected GTol to edit.
	EditSheet	Obsolete. Superseded by IDrawingDoc::EditSheet2 .
	EditSheet2	Puts the current drawing sheet in edit mode.
	EditSketch	Allows editing of a sketch in the selected drawing view or sheet.
	EditTemplate	Puts the template of the current drawing sheet in edit mode.
	EndDrawing	Provides faster creation of entities in a drawing when used with IDrawingDoc::StartDrawing .
	ExplodeBlockInstance	Obsolete. Superseded by ISketchManager::ExplodeSketchBlockInstance .
	ExplodeCustomSymbol	Obsolete. Superseded by ISketchManager::ExplodeSketchBlockInstance .
	FeatureByName	Gets the specified feature in the drawing.
	FlipSectionLine	Flips the cut direction of the selected section line.
	ForceRebuild	Obsolete. Superseded by IModel2::ForceRebuild3 .
	GenerateViewPaletteViews	Adds the specified document's predefined drawing views to the View Palette.
	GetBlockDefinition	Obsolete. Superseded by ISketchManager::GetSketchBlockDefinitions .
	GetBlockDefinitionCount	Obsolete. Superseded by ISketchManager::GetSketchBlockDefinitionCount .
	GetBlockDefinitions	Obsolete. Superseded by ISketchManager::GetSketchBlockDefinitions .
	GetCurrentSheet	Gets the currently active drawing sheet.
	GetDrawingPaletteViewNames	Gets the names of drawing views in the View Palette for the active drawing sheet.
	GetEditBlock	Obsolete. Superseded by ISketchManager::EditSketchBlock and ISketchManager::EndEditSketchBlock .
	GetEditSheet	Gets whether the current drawing is in edit sheet mode or edit template mode.
	GetFirstView	Gets the first drawing view on the current sheet.

		
	GetInsertionPoint	Gets the current insertion (pick) point in a drawing.
	GetLineFontCount	Obsolete. Superseded by IDrawingDoc::GetLineFontCount2 .
	GetLineFontCount2	Gets the a number line fonts supported by this drawing.
	GetLineFontId	Gets the associated line font ID.
	GetLineFontInfo	Obsolete. Superseded by IDrawingDoc::GetLineFontInfo2 .
	GetLineFontInfo2	Gets the detailed information about the specified line font.
	GetLineFontName	Obsolete. Superseded by IDrawingDoc::GetLineFontName2 .
	GetLineFontName2	Gets the name of the specified line font.
	GetLineStyles	Gets all of the line styles used in the current document.
	GetPenCount	Gets the number of pens currently defined in SOLIDWORKS.
	GetPenInfo	Gets information about the pens used in SOLIDWORKS.
	GetSheetCount	Gets the number of drawing sheets in this drawing.
	GetSheetNames	Gets a list of the names of the drawing sheets in this drawing.
	GetViewCount	Gets all of the number of all of views, including the number of sheets, in this drawing document.
	GetViews	Gets the all of the views, including the sheets, in this drawing document.
	HideEdge	Hides selected visible edges in a drawing document.
	HideShowDimensions	Sets whether to display suppressed dimensions as dimmed and hide them.
	HideShowDrawingViews	Sets whether to hide or show hidden drawing views.
	IAddChamferDim	Adds a chamfer dimension.
	IAddHoleCallout2	Adds a hole callout at the specified position to the hole whose edge is selected.
	ICreateAngDim	Obsolete. Superseded by IDrawingDoc::ICreateAngDim4 .
	ICreateAngDim2	Obsolete. Superseded by IDrawingDoc::ICreateAngDim4 .
	ICreateAngDim3	Obsolete. Superseded by IDrawingDoc::ICreateAngDim4 .
	ICreateAngDim4	Creates a non-associative angular dimension.
	ICreateAuxiliaryViewAt2	Creates an auxiliary view based on a selected edge in a drawing view.
	ICreateBlockDefinition	Obsolete. Superseded by ISketchManager::MakeSketchBlockFromFile , ISketchManager::MakeSketchBlockSelected , and ISketchManager::MakeSketchBlockFromSketch .
	ICreateCompoundNote	Obsolete for documents created in SOLIDWORKS 2016 and later. Creates and returns a compound note.
	ICreateCustomSymbol	Obsolete. Superseded by ISketchManager::MakeSketchBlockFromFile , ISketchManager::MakeSketchBlockSelected , and ISketchManager::MakeSketchBlockFromSketch .
	ICreateDetailViewAt3	Obsolete. Superseded by IDrawingDoc::CreateDetailViewAt4 .
	ICreateDiamDim	Obsolete. Superseded by IDrawingDoc::ICreateDiamDim4 .
	ICreateDiamDim2	Obsolete. Superseded by IDrawingDoc::ICreateDiamDim4 .
	ICreateDiamDim3	Obsolete. Superseded by IDrawingDoc::ICreateDiamDim4 .
	ICreateDiamDim4	Creates a non-associative diameter dimension.
	ICreateLinearDim	Obsolete. Superseded by IDrawingDoc::ICreateLinearDim4 .
	ICreateLinearDim2	Obsolete. Superseded by IDrawingDoc::ICreateLinearDim4 .
	ICreateLinearDim3	Obsolete. Superseded by IDrawingDoc::ICreateLinearDim4 .
	ICreateLinearDim4	Creates a non-associative linear dimension.
	ICreateOrdinateDim	Obsolete. Superseded by IDrawingDoc::ICreateOrdinateDim4 .
	ICreateOrdinateDim2	Obsolete. Superseded by IDrawingDoc::ICreateOrdinateDim4 .
	ICreateOrdinateDim3	Obsolete. Superseded by IDrawingDoc::ICreateOrdinateDim4 .
	ICreateOrdinateDim4	Creates a non-associative ordinate dimension.
	ICreateSectionViewAt2	Obsolete. Superseded by IDrawingDoc::ICreateSectionViewAt4 .

		
	iCreateSectionViewA3	Obsolete. Superseded by iDrawingDoc.iCreateSectionViewA4 .
	iCreateSectionViewA4	Obsolete. Superseded by iDrawingDoc.iCreateSectionViewA5 .
	iCreateSectionViewA5	Creates a section view from the section line up to the specified distance at the specified distance.
	iCreateText2	Creates a note containing the specified text at a given location.
	iEditSelectedGtol	Gets the selected G.Tol to edit.
	iFeatureByName	Gets the specified feature in the drawing.
	iGetBlockDefinitions	Obsolete. Superseded by SketchManager.GetSketchBlockDefinitions .
	iGetCurrentSheet	Gets the currently active drawing sheet.
	iGetFirstView	Gets the first drawing view on the current sheet.
	iGetInsertionPoint	Gets the current insertion (pick) point in a drawing.
	iGetPenInfo	Gets information about the pens used in SOLIDWORKS.
	iGetSheetNames	Gets a list of the names of the drawing sheets in this drawing.
	iInsertCustomSymbol2	Obsolete. Superseded by iSketchManager.InsertSketchBlockInstance .
	iInsertDowelSymbol	Inserts a dowel pin symbol on the currently selected edge or edges.
	iInsertMultiJogLeader2	Obsolete. Superseded by iDrawingDoc.iInsertMultiJogLeader3 .
	iInsertMultiJogLeader3	Inserts a multi-jog leader.
	iInsertRevisionCloud	Inserts a revision cloud annotation with the specified shape into a view or sheet.
	iMakeCustomSymbol2	Obsolete. Superseded by iSketchManager.MakeSketchBlockFromFile , iSketchManager.MakeSketchBlockSelected , and iSketchManager.MakeSketchBlockFromSketch .
	iNewGtol	Creates a new G.Tol.
	iInsertAngularRunningDim	Inserts an angular running dimension into this drawing.
	iInsertBaseDim	Inserts the base model dimensions into this drawing.
	iInsertBlock	Obsolete. Superseded by iSketchManager.InsertSketchBlockInstance .
	iInsertBreakHorizontal	Inserts a horizontal break in the drawing view.
	iInsertBreakVertical	Inserts a vertical break in this drawing.
	iInsertCenterLine	Obsolete. Superseded by iDrawingDoc.iInsertCenterLine2 .
	iInsertCenterLine2	Inserts a centerline on the selected entities.
	iInsertCenterMark	Obsolete. Superseded by iDrawingDoc.iInsertCenterMark2 .
	iInsertCenterMark2	Obsolete. Superseded by iDrawingDoc.iInsertCenterMark3 .
	iInsertCenterMark3	Inserts a center mark in a drawing document.
	iInsertChainDim	Obsolete. Superseded by iModelDocExtension.InsertChainDimensions .
	iInsertCircularNotePattern	Inserts a circular note pattern using the selected note .
	iInsertCustomSymbol	Obsolete. Superseded by iSketchManager.InsertSketchBlockInstance .
	iInsertCustomSymbol2	Obsolete. Superseded by iSketchManager.InsertSketchBlockInstance .
	iInsertDatumTag	Obsolete. Superseded by iModelDoc2.InsertDatumTag2 .
	iInsertDowelSymbol	Inserts a dowel pin symbol on the currently selected edge or edges in this drawing.
	iInsertGroup	Inserts the currently selected items into a group (or view).
	iInsertHorizontalOrdinate	Inserts a horizontal ordinate dimension into this drawing.
	iInsertLinearNotePattern	Inserts a linear note pattern using the selected note .
	iInsertModelAnnotations	Obsolete. Superseded by iDrawingDoc.iInsertModelAnnotations3 .
	iInsertModelAnnotations2	Obsolete. Superseded by iDrawingDoc.iInsertModelAnnotations3 .
	iInsertModelAnnotations3	Inserts model annotations into this drawing document's currently selected drawing view.
	iInsertModelAnnotations4	Inserts model annotations into this drawing document's currently selected drawing view.

		
	InsertModelDimensions	Inserts model dimensions into the selected drawing view according to the option specified.
	InsertModelInPredefinedView	Inserts the model into the predefined drawing views in the active drawing sheet.
	InsertMultiJogLeader	Obsolete. Superseded by IDrawingDoc::InsertMultiJogLeader3 .
	InsertMultiJogLeader2	Obsolete. Superseded by IDrawingDoc::InsertMultiJogLeader3 .
	InsertMultiJogLeader3	Inserts a multi-jog leader.
	InsertNewNote	Obsolete. Superseded by IDrawingDoc::InsertNewNote2 .
	InsertNewNote2	Creates a new note in this drawing.
	InsertOrdinate	Inserts an ordinate dimension into this drawing.
	InsertRefDim	Inserts reference dimensions in this drawing.
	InsertRevisionCloud	Inserts a revision cloud annotation with the specified shape into a view or sheet.
	InsertRevisionSymbol	Inserts a revision symbol note in this drawing.
	InsertSurfaceFinishSymbol	Obsolete. Superseded by IModelDocExtension::InsertSurfaceFinishSymbol3 .
	InsertTableAnnotation	Obsolete. Superseded by IDrawingDoc::InsertTableAnnotation2 .
	InsertTableAnnotation2	Inserts a table annotation in this drawing.
	InsertThreadCallout	Inserts a thread callout into this drawing.
	InsertVerticalOrdinate	Inserts a vertical ordinate dimension in this drawing.
	InsertWeldSymbol	Creates a weld symbol located at the last edge selection.
	IReorderSheets	Reorders the drawing sheets per their positions in the input array.
	IsDetailingMode	Gets whether this drawing is in detailing mode.
	IsolateChangedDimensions	Isolates changed dimensions.
	LoadLineStyle	Loads the specified line styles into the current drawing.
	MakeBlockDefinition	Obsolete. Superseded by ISketchManager::MakeSketchBlockFromFile , ISketchManager::MakeSketchBlockSelected , and ISketchManager::MakeSketchBlockFromSketch .
	MakeCustomSymbol	Obsolete. Superseded by ISketchManager::MakeSketchBlockFromFile , ISketchManager::MakeSketchBlockSelected , and ISketchManager::MakeSketchBlockFromSketch .
	MakeCustomSymbol2	Obsolete. Superseded by ISketchManager::MakeSketchBlockFromFile , ISketchManager::MakeSketchBlockSelected , and ISketchManager::MakeSketchBlockFromSketch .
	MakeSectionLine	Makes a section line from a set of connected sketch lines.
	ModifySurfaceFinishSymbol	Modifies the selected surface finish symbol.
	NewGtol	Creates a new Gtol object and returns the pointer to that object.
	NewNote	Creates a new note at the selected location.
	NewSheet	Obsolete. Superseded by IDrawingDoc::NewSheet3 .
	NewSheet2	Obsolete. Superseded by IDrawingDoc::NewSheet3 .
	NewSheet3	Obsolete. Superseded by IDrawingDoc::NewSheet4 .
	NewSheet4	Creates a new drawing sheet in this drawing document.
	OnComponentProperties	Displays the Component Properties dialog for the selected view.
	PasteSheet	Copies and pastes a drawing sheet to the specified location of the drawing document, optionally renaming whenever duplicate names occur.
	ReorderSheets	Reorders the drawing sheets per their positions in the input array.
	ReplaceViewModel	Replaces the specified instances of a model in the specified drawing views.
	ResolveOutOfDateLightWeightComponents	Resolves out-of-date lightweight components in the selected drawing view or drawing sheet.
	RestoreRotation	Restores rotation for the selected drawing view.
	SaveBlock	Obsolete. Superseded by ISketchBlockDefinition::Save .
	SaveLineStyle	Exports to a file the specified line styles in the current drawing.
	SetCurrentLayer	Sets the current layer used by this document.
	SetLineColor	Sets the line color for a selected edge or sketch entity.

		
	SetLineStyle	Sets the style or font for the line for a selected edge or sketch entity.
	SetLineWidth	Sets the line thickness for a selected edge or sketch entity to a SOLIDWORKS-supplied weight (width).
	SetLineWidthCustom	Sets the line thickness to the specified custom width for a selected edge or sketch entity.
	SetSheetsSelected	Sets the specified drawing sheets whose setups to modify.
	SetupSheet	Obsolete. Superseded by IDrawingDoc.SetupSheet4 .
	SetupSheet2	Obsolete. Superseded by IDrawingDoc.SetupSheet4 .
	SetupSheet3	Obsolete. Superseded by IDrawingDoc.SetupSheet4 .
	SetupSheet4	Obsolete. Superseded by IDrawingDoc.SetupSheet5 .
	SetupSheet5	Obsolete. Superseded by IDrawingDoc.SetupSheet6 .
	SetupSheet6	Sets up the specified drawing sheet.
	SheetNext	Moves to the next sheet in the drawing.
	SheetPrevious	Returns to the previous sheet in a drawing.
	ShowEdge	Shows the selected hidden edges in a drawing document.
	SketchDim	Inserts a sketch dimension in this drawing.
	StartDrawing	Provides faster creation of entities within a drawing.
	SuppressView	Hides the selected drawing view.
	ToggleGrid	Obsolete. Superseded by IModelDocExtension.GetUserPreferenceToggle and IModelDocExtension.SetUserPreferenceToggle and swUserPreferenceToggle_e.swGridDisplay .
	TranslateDrawing	Translates the entire drawing.
	UnBreakView	Removes a break in the selected drawing view.
	UnsuppressView	Hides the selected drawing view.
	ViewDisplayHidden	Sets the current display mode to Hidden Lines Removed .
	ViewDisplayHiddenGreyed	Sets the current display mode to Hidden Lines Visible .
	ViewDisplayShaded	Sets the current display mode to Shaded .
	ViewDisplayWireframe	Sets the current display mode to Wireframe .
	ViewFullPage	Fits the drawing to the full page.
	ViewHtrQuality	Toggles the Hidden Lines Removed mode for the drawing view.
	ViewModelEdges	Toggles the mode for viewing model edges when in shaded mode.
	ViewTangentEdges	Toggles display of tangent edges in the selected drawing view.

[Top](#)

See Also

[IDrawingDoc Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IDrawingDoc Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDrawingDoc Interface

For a list of all members of this type, see [IDrawingDoc members](#).

Public Methods

Name	Description
 ActivateSheet	Activates the specified drawing sheet.
 ActivateView	Activates the specified drawing view.

	AddCenterMark	Obsolete. Superseded by IDrawingDoc.InsertCenterMark2 .
	AddChamferDim	Adds a chamfer dimension.
	AddHoleCallout	Obsolete. Superseded by IDrawingDoc.AddHoleCallout2 .
	AddHoleCallout2	Adds a hole callout at the specified position to the hole whose edge is selected.
	AddLineStyle	Adds a line style to the current drawing.
	AddOrdinateDimension	Obsolete. Superseded by IModelDocExtension.AddOrdinateDimension .
	AddOrdinateDimension2	Obsolete. Superseded by IModelDocExtension.AddOrdinateDimension .
	AlignHorz	Uses the selected edge to align the current drawing view.
	AlignOrdinate	Aligns the ordinate dimension.
	AlignVert	Uses the selected edge to align the current drawing view.
	AttachAnnotation	Attaches an existing annotation to a drawing sheet or view.
	AttachDimensions	Attaches unattached dimensions.
	AutoBalloon	Obsolete. Superseded by IDrawingDoc.AutoBalloon3 .
	AutoBalloon2	Obsolete. Superseded by IDrawingDoc.AutoBalloon3 .
	AutoBalloon3	Obsolete. Superseded by IDrawingDoc.AutoBalloon4 .
	AutoBalloon4	Obsolete. Superseded by IDrawingDoc.AutoBalloon5 .
	AutoBalloon5	Automatically inserts BOM balloons in selected drawing views.
	AutoDimension	Automatically dimensions the selected drawing view.
	BreakLineSplineCut	Obsolete. Superseded by IBreakLine.Style .
	BreakLineStraightCut	Obsolete. Superseded by IBreakLine.Style .
	BreakLineZigZagCut	Obsolete. Superseded by IBreakLine.Style .
	BreakView	Breaks the drawing view along the existing break lines.
	CenterMark	Obsolete. Not superseded.
	ChangeComponentLayer	Puts the selected components on the specified layer.
	ChangeOrdDir	Changes the ordinate direction.
	ChangeRefConfigurationOfFlatPatternView	Changes the configuration of the selected flat-pattern view of the specified model.
	Create1stAngleViews	Obsolete. Superseded by IDrawingDoc.1stAngleViews2 .
	Create1stAngleViews2	Creates standard three orthographic views (first angle projection) for the specified model.
	Create3rdAngleViews	Obsolete. Superseded by IDrawingDoc.Create3rdAngleViews2 .
	Create3rdAngleViews2	Creates standard three orthographic views (third angle projection) for the specified model.
	CreateAngDim	Obsolete. Superseded by IDrawingDoc.CreateAngDim4 .
	CreateAngDim2	Obsolete. Superseded by IDrawingDoc.CreateAngDim4 .
	CreateAngDim3	Obsolete. Superseded by IDrawingDoc.CreateAngDim4 .
	CreateAngDim4	Creates a non-associative angular dimension.
	CreateAutoBalloonOptions	Creates an object that stores auto balloon options.
	CreateAuxiliaryViewAt	Obsolete. Superseded by IDrawingDoc.CreateAuxiliaryViewAt2 .
	CreateAuxiliaryViewAt2	Creates an auxiliary view based on a selected edge in a drawing view.
	CreateBlockDefinition	Obsolete. Superseded by ISketchManager.MakeSketchBlockFromFile , ISketchManager.MakeSketchBlockSelected , and ISketchManager.MakeSketchBlockFromSketch .
	CreateBreakOutSection	Creates a broken-out section in a drawing document.
	CreateCompoundNote	Obsolete for documents created in SOLIDWORKS 2016 and later. Superseded by ISketchBlockDefinition and ISketchBlockInstance . Creates and returns a compound note.
	CreateConstructionGeometry	Sets the selected sketch segments to be construction geometry instead of sketch geometry.
	CreateCustomSymbol	Obsolete. Superseded by ISketchManager.MakeSketchBlockFromFile , ISketchManager.MakeSketchBlockSelected , and ISketchManager.MakeSketchBlockFromSketch .
	CreateDetailView	Obsolete. Superseded by IDrawingDoc.CreateDetailViewA13 .

		
	CreateDetailViewAt	Obsolete. Superseded by IDrawingDoc::CreateDetailViewAt3 .
	CreateDetailViewAt2	Obsolete. Superseded by IDrawingDoc::CreateDetailViewAt3 .
	CreateDetailViewAt3	Obsolete. Superseded by IDrawingDoc::CreateDetailViewAt4 .
	CreateDetailViewAt4	Creates a detail view in a drawing document.
	CreateDiamDim	Obsolete. Superseded by IDrawingDoc::CreateDiamDim4 .
	CreateDiamDim2	Obsolete. Superseded by IDrawingDoc::CreateDiamDim4 .
	CreateDiamDim3	Obsolete. Superseded by IDrawingDoc::CreateDiamDim4 .
	CreateDiamDim4	Creates a non-associative diameter dimension.
	CreateDrawViewFromModelView	Obsolete. Superseded by IDrawingDoc::CreateDrawViewFromModelView3 .
	CreateDrawViewFromModelView2	Obsolete. Superseded by IDrawingDoc::CreateDrawViewFromModelView3 .
	CreateDrawViewFromModelView3	Creates a drawing view on the current drawing sheet using the specified model view.
	CreateFlatPatternViewFromModelView	Obsolete. Superseded by IDrawingDoc::CreateFlatPatternViewFromModelView2 .
	CreateFlatPatternViewFromModelView2	Obsolete. Superseded by IDrawingDoc::CreateFlatPatternViewFromModelView3 .
	CreateFlatPatternViewFromModelView3	Creates a flat-pattern view from a model view.
	CreateLayer	Obsolete. Superseded by IDrawingDoc::CreateLayer2 .
	CreateLayer2	Creates a layer for this document.
	CreateLinearDim	Obsolete. Superseded by IDrawingDoc::CreateLinearDim4 .
	CreateLinearDim2	Obsolete. Superseded by IDrawingDoc::CreateLinearDim4 .
	CreateLinearDim3	Obsolete. Superseded by IDrawingDoc::CreateLinearDim4 .
	CreateLinearDim4	Creates a non-associative linear dimension.
	CreateOrdinateDim	Obsolete. Superseded by IDrawingDoc::CreateOrdinateDim4 .
	CreateOrdinateDim2	Obsolete. Superseded by IDrawingDoc::CreateOrdinateDim4 .
	CreateOrdinateDim3	Obsolete. Superseded by IDrawingDoc::CreateOrdinateDim4 .
	CreateOrdinateDim4	Creates a non-associative ordinate dimension.
	CreateRelativeView	Creates a relative drawing view.
	CreateSectionView	Creates a section view in the drawing using the selected section line.
	CreateSectionViewAt	Obsolete. Superseded by IDrawingDoc::CreateSectionViewAt4 .
	CreateSectionViewAt2	Obsolete. Superseded by IDrawingDoc::CreateSectionViewAt4 .
	CreateSectionViewAt3	Obsolete. Superseded by IDrawingDoc::CreateSectionViewAt4 .
	CreateSectionViewAt4	Obsolete. Superseded by IDrawingDoc::CreateSectionViewAt5 .
	CreateSectionViewAt5	Creates the specified section view.
	CreateText	Obsolete. Superseded by IDrawingDoc::CreateText2 .
	CreateText2	Creates a note containing the specified text at a given location.
	CreateUnfoldedViewAt	Obsolete. Superseded by IDrawingDoc::CreateUnfoldedViewAt3 .
	CreateUnfoldedViewAt2	Obsolete. Superseded by IDrawingDoc::CreateUnfoldedViewAt3 .
	CreateUnfoldedViewAt3	Creates an unfolded drawing view from the selected drawing view and places it in the drawing at the specified location.
	CreateViewport	Obsolete. Superseded by IDrawingDoc::CreateViewport3 .
	CreateViewport2	Obsolete. Superseded by IDrawingDoc::CreateViewport3 .
	CreateViewport3	Creates a an empty view in a drawing.
	DeleteAllCosmeticThreads	Deletes all cosmetic threads, which do not have callouts, in a drawing of an assembly only.
	DeleteLineStyle	Deletes the specified line style from the current drawing.
	Dimensions	Adds dimensions to the drawing from model.

		
	DragModelDimension	Copies or moves dimensions to a different drawing view.
	DrawingViewRotate	Rotates the selected drawing view.
	DropDrawingViewFromPalette	Obsolete. Superseded by IDrawingDoc::DropDrawingViewFromPalette2
	DropDrawingViewFromPalette2	Moves the specified drawing view from the View Palette to the current drawing sheet.
	EditCenterMarkProperties	Edits center mark properties.
	EditOrdinate	Edits an ordinate dimension.
	EditRebuild	Obsolete. Superseded by IModelDoc2::EditRebuild3 .
	EditSelectedGtol	Gets the selected Gtol to edit.
	EditSheet	Obsolete. Superseded by IDrawingDoc::EditSheet2
	EditSheet2	Puts the current drawing sheet in edit mode.
	EditSketch	Allows editing of a sketch in the selected drawing view or sheet.
	EditTemplate	Puts the template of the current drawing sheet in edit mode.
	EndDrawing	Provides faster creation of entities in a drawing when used with IDrawingDoc::StartDrawing .
	ExplodeBlockInstance	Obsolete. Superseded by ISketchManager::ExplodeSketchBlockInstance .
	ExplodeCustomSymbol	Obsolete. Superseded by ISketchManager::ExplodeSketchBlockInstance .
	FeatureByName	Gets the specified feature in the drawing.
	FlipSectionLine	Flips the cut direction of the selected section line.
	ForceRebuild	Obsolete. Superseded by IModel2::ForceRebuild3 .
	GenerateViewPaletteViews	Adds the specified document's predefined drawing views to the View Palette.
	GetBlockDefinition	Obsolete. Superseded by SketchManager::GetSketchBlockDefinitions .
	GetBlockDefinitionCount	Obsolete. Superseded by ISketchManager::GetSketchBlockDefinitionCount .
	GetBlockDefinitions	Obsolete. Superseded by ISketchManager::GetSketchBlockDefinitions .
	GetCurrentSheet	Gets the currently active drawing sheet.
	GetDrawingPaletteViewNames	Gets the names of drawing views in the View Palette for the active drawing sheet.
	GetEditBlock	Obsolete. Superseded by ISketchManager::EditSketchBlock and ISketchManager::EndEditSketchBlock .
	GetEditSheet	Gets whether the current drawing is in edit sheet mode or edit template mode.
	GetFirstView	Gets the first drawing view on the current sheet.
	GetInsertionPoint	Gets the current insertion (pick) point in a drawing.
	GetLineFontCount	Obsolete. Superseded by IDrawingDoc::GetLineFontCount2 .
	GetLineFontCount2	Gets the a number line fonts supported by this drawing.
	GetLineFontId	Gets the associated line font ID.
	GetLineFontInfo	Obsolete. Superseded by IDrawingDoc::GetLineFontInfo2 .
	GetLineFontInfo2	Gets the detailed information about the specified line font.
	GetLineFontName	Obsolete. Superseded by IDrawingDoc::GetLineFontName2 .
	GetLineFontName2	Gets the name of the specified line font.
	GetLineStyle	Gets all of the line styles used in the current document.
	GetPenCount	Gets the number of pens currently defined in SOLIDWORKS.
	GetPenInfo	Gets information about the pens used in SOLIDWORKS.
	GetSheetCount	Gets the number of drawing sheets in this drawing.
	GetSheetNames	Gets a list of the names of the drawing sheets in this drawing.
	GetViewCount	Gets all of the number of all of views, including the number of sheets, in this drawing document.
	GetViews	Gets the all of the views, including the sheets, in this drawing document.

		
	HideEdge	Hides selected visible edges in a drawing document.
	HideShowDimensions	Sets whether to display suppressed dimensions as dimmed and hide them.
	HideShowDrawingViews	Sets whether to hide or show hidden drawing views.
	IAddChamferDim	Adds a chamfer dimension.
	IAddHoleCallout2	Adds a hole callout at the specified position to the hole whose edge is selected.
	ICreateAngDim	Obsolete. Superseded by IDrawingDoc::ICreateAngDim4 .
	ICreateAngDim2	Obsolete. Superseded by IDrawingDoc::ICreateAngDim4 .
	ICreateAngDim3	Obsolete. Superseded by IDrawingDoc::ICreateAngDim4 .
	ICreateAngDim4	Creates a non-associative angular dimension.
	ICreateAuxiliaryViewAt2	Creates an auxiliary view based on a selected edge in a drawing view.
	ICreateBlockDefinition	Obsolete. Superseded by ISketchManager::MakeSketchBlockFromFile , ISketchManager::MakeSketchBlockSelected , and ISketchManager::MakeSketchBlockFromSketch .
	ICreateCompoundNote	Obsolete for documents created in SOLIDWORKS 2016 and later. Creates and returns a compound note.
	ICreateCustomSymbol	Obsolete. Superseded by ISketchManager::MakeSketchBlockFromFile , ISketchManager::MakeSketchBlockSelected , and ISketchManager::MakeSketchBlockFromSketch .
	ICreateDetailViewAt3	Obsolete. Superseded by IDrawingDoc::CreateDetailViewAt4 .
	ICreateDiamDim	Obsolete. Superseded by IDrawingDoc::ICreateDiamDim4 .
	ICreateDiamDim2	Obsolete. Superseded by IDrawingDoc::ICreateDiamDim4 .
	ICreateDiamDim3	Obsolete. Superseded by IDrawingDoc::ICreateDiamDim4 .
	ICreateDiamDim4	Creates a non-associative diameter dimension.
	ICreateLinearDim	Obsolete. Superseded by IDrawingDoc::ICreateLinearDim4 .
	ICreateLinearDim2	Obsolete. Superseded by IDrawingDoc::ICreateLinearDim4 .
	ICreateLinearDim3	Obsolete. Superseded by IDrawingDoc::ICreateLinearDim4 .
	ICreateLinearDim4	Creates a non-associative linear dimension.
	ICreateOrdinateDim	Obsolete. Superseded by IDrawingDoc::ICreateOrdinateDim4 .
	ICreateOrdinateDim2	Obsolete. Superseded by IDrawingDoc::ICreateOrdinateDim4 .
	ICreateOrdinateDim3	Obsolete. Superseded by IDrawingDoc::ICreateOrdinateDim4 .
	ICreateOrdinateDim4	Creates a non-associative ordinate dimension.
	ICreateSectionViewAt2	Obsolete. Superseded by IDrawingDoc::ICreateSectionViewAt4 .
	ICreateSectionViewAt3	Obsolete. Superseded by IDrawingDoc::ICreateSectionViewAt4 .
	ICreateSectionViewAt4	Obsolete. Superseded by IDrawingDoc::ICreateSectionViewAt5 .
	ICreateSectionViewAt5	Creates a section view from the section line up to the specified distance at the specified distance.
	ICreateText2	Creates a note containing the specified text at a given location.
	IEditSelectedGtol	Gets the selected Gtol to edit.
	IFeatureByName	Gets the specified feature in the drawing.
	IGetBlockDefinitions	Obsolete. Superseded by SketchManager::GetSketchBlockDefinitions .
	IGetCurrentSheet	Gets the currently active drawing sheet.
	IGetFirstView	Gets the first drawing view on the current sheet.
	IGetInsertionPoint	Gets the current insertion (pick) point in a drawing.
	IGetPenInfo	Gets information about the pens used in SOLIDWORKS.
	IGetSheetNames	Gets a list of the names of the drawing sheets in this drawing.
	InsertCustomSymbol2	Obsolete. Superseded by ISketchManager::InsertSketchBlockInstance .
	InsertDowelSymbol	Inserts a dowel pin symbol on the currently selected edge or edges.
	InsertMultiJogLeader2	Obsolete. Superseded by IDrawingDoc::InsertMultiJogLeader3 .

		
	InsertMultiJogLeader3	Inserts a multi-jog leader.
	InsertRevisionCloud	Inserts a revision cloud annotation with the specified shape into a view or sheet.
	IMakeCustomSymbol2	Obsolete. Superseded by ISketchManager::MakeSketchBlockFromFile , ISketchManager::MakeSketchBlockSelected , and ISketchManager::MakeSketchBlockFromSketch .
	INewGtol	Creates a new Gtol.
	InsertAngularRunningDim	Inserts an angular running dimension into this drawing.
	InsertBaseDim	Inserts the base model dimensions into this drawing.
	InsertBlock	Obsolete. Superseded by ISketchManager::InsertSketchBlockInstance .
	InsertBreakHorizontal	Inserts a horizontal break in the drawing view.
	InsertBreakVertical	Inserts a vertical break in this drawing.
	InsertCenterLine	Obsolete. Superseded by IDrawingDoc::InsertCenterLine2 .
	InsertCenterLine2	Inserts a centerline on the selected entities.
	InsertCenterMark	Obsolete. Superseded by IDrawingDoc::InsertCenterMark2 .
	InsertCenterMark2	Obsolete. Superseded by IDrawingDoc::InsertCenterMark3 .
	InsertCenterMark3	Inserts a center mark in a drawing document.
	InsertChainDim	Obsolete. Superseded by IModelDocExtension::InsertChainDimensions .
	InsertCircularNotePattern	Inserts a circular note pattern using the selected note .
	InsertCustomSymbol	Obsolete. Superseded by ISketchManager::InsertSketchBlockInstance .
	InsertCustomSymbol2	Obsolete. Superseded by ISketchManager::InsertSketchBlockInstance .
	InsertDatumTag	Obsolete. Superseded by IModelDoc2::InsertDatumTag2 .
	InsertDowelSymbol	Inserts a dowel pin symbol on the currently selected edge or edges in this drawing.
	InsertGroup	Inserts the currently selected items into a group (or view).
	InsertHorizontalOrdinate	Inserts a horizontal ordinate dimension into this drawing.
	InsertLinearNotePattern	Inserts a linear note pattern using the selected note .
	InsertModelAnnotations	Obsolete. Superseded by IDrawingDoc::InsertModelAnnotations3 .
	InsertModelAnnotations2	Obsolete. Superseded by IDrawingDoc::InsertModelAnnotations3 .
	InsertModelAnnotations3	Inserts model annotations into this drawing document's currently selected drawing view.
	InsertModelAnnotations4	Inserts model annotations into this drawing document's currently selected drawing view.
	InsertModelDimensions	Inserts model dimensions into the selected drawing view according to the option specified.
	InsertModelInPredefinedView	Inserts the model into the predefined drawing views in the active drawing sheet.
	InsertMultiJogLeader	Obsolete. Superseded by IDrawingDoc::InsertMultiJogLeader3 .
	InsertMultiJogLeader2	Obsolete. Superseded by IDrawingDoc::InsertMultiJogLeader3 .
	InsertMultiJogLeader3	Inserts a multi-jog leader.
	InsertNewNote	Obsolete. Superseded by IDrawingDoc::InsertNewNote2 .
	InsertNewNote2	Creates a new note in this drawing.
	InsertOrdinate	Inserts an ordinate dimension into this drawing.
	InsertRefDim	Inserts reference dimensions in this drawing.
	InsertRevisionCloud	Inserts a revision cloud annotation with the specified shape into a view or sheet.
	InsertRevisionSymbol	Inserts a revision symbol note in this drawing.
	InsertSurfaceFinishSymbol	Obsolete. Superseded by IModelDocExtension::InsertSurfaceFinishSymbol3 .
	InsertTableAnnotation	Obsolete. Superseded by IDrawingDoc::InsertTableAnnotation2 .
	InsertTableAnnotation2	Inserts a table annotation in this drawing.
	InsertThreadCallout	Inserts a thread callout into this drawing.

		
	InsertVerticalOrdinate	Inserts a vertical ordinate dimension in this drawing.
	InsertWeldSymbol	Creates a weld symbol located at the last edge selection.
	IReorderSheets	Reorders the drawing sheets per their positions in the input array.
	IsDetailingMode	Gets whether this drawing is in detailing mode.
	IsolateChangedDimensions	Isolates changed dimensions.
	LoadLineStyles	Loads the specified line styles into the current drawing.
	MakeBlockDefinition	Obsolete. Superseded by ISketchManager::MakeSketchBlockFromFile , ISketchManager::MakeSketchBlockSelected , and ISketchManager::MakeSketchBlockFromSketch .
	MakeCustomSymbol	Obsolete. Superseded by ISketchManager::MakeSketchBlockFromFile , ISketchManager::MakeSketchBlockSelected , and ISketchManager::MakeSketchBlockFromSketch .
	MakeCustomSymbol2	Obsolete. Superseded by ISketchManager::MakeSketchBlockFromFile , ISketchManager::MakeSketchBlockSelected , and ISketchManager::MakeSketchBlockFromSketch .
	MakeSectionLine	Makes a section line from a set of connected sketch lines.
	ModifySurfaceFinishSymbol	Modifies the selected surface finish symbol.
	NewGtol	Creates a new GTol object and returns the pointer to that object.
	NewNote	Creates a new note at the selected location.
	NewSheet	Obsolete. Superseded by IDrawingDoc::NewSheet3 .
	NewSheet2	Obsolete. Superseded by IDrawingDoc::NewSheet3 .
	NewSheet3	Obsolete. Superseded by IDrawingDoc::NewSheet4 .
	NewSheet4	Creates a new drawing sheet in this drawing document.
	OnComponentProperties	Displays the Component Properties dialog for the selected view.
	PasteSheet	Copies and pastes a drawing sheet to the specified location of the drawing document, optionally renaming whenever duplicate names occur.
	ReorderSheets	Reorders the drawing sheets per their positions in the input array.
	ReplaceViewModel	Replaces the specified instances of a model in the specified drawing views.
	ResolveOutOfDateLightWeightComponents	Resolves out-of-date lightweight components in the selected drawing view or drawing sheet.
	RestoreRotation	Restores rotation for the selected drawing view.
	SaveBlock	Obsolete. Superseded by ISketchBlockDefinition::Save .
	SaveLineStyles	Exports to a file the specified line styles in the current drawing.
	SetCurrentLayer	Sets the current layer used by this document.
	SetLineColor	Sets the line color for a selected edge or sketch entity.
	SetLineStyle	Sets the style or font for the line for a selected edge or sketch entity.
	SetLineWidth	Sets the line thickness for a selected edge or sketch entity to a SOLIDWORKS-supplied weight (width).
	SetLineWidthCustom	Sets the line thickness to the specified custom width for a selected edge or sketch entity.
	SetSheetsSelected	Sets the specified drawing sheets whose setups to modify.
	SetupSheet	Obsolete. Superseded by IDrawingDoc::SetupSheet4 .
	SetupSheet2	Obsolete. Superseded by IDrawingDoc::SetupSheet4 .
	SetupSheet3	Obsolete. Superseded by IDrawingDoc::SetupSheet4 .
	SetupSheet4	Obsolete. Superseded by IDrawingDoc::SetupSheet5 .
	SetupSheet5	Obsolete. Superseded by IDrawingDoc::SetupSheet6 .
	SetupSheet6	Sets up the specified drawing sheet.
	SheetNext	Moves to the next sheet in the drawing.
	SheetPrevious	Returns to the previous sheet in a drawing.
	ShowEdge	Shows the selected hidden edges in a drawing document.
	SketchDim	Inserts a sketch dimension in this drawing.
	StartDrawing	Provides faster creation of entities within a drawing.

		
	SuppressView	Hides the selected drawing view.
	ToggleGrid	Obsolete. Superseded by IModelDocExtension::GetUserPreferenceToggle and IModelDocExtension::SetUserPreferenceToggle and swUserPreferenceToggle_e_swGridDisplay .
	TranslateDrawing	Translates the entire drawing.
	UnBreakView	Removes a break in the selected drawing view.
	UnsuppressView	Hides the selected drawing view.
	ViewDisplayHidden	Sets the current display mode to Hidden Lines Removed .
	ViewDisplayHiddenGreyed	Sets the current display mode to Hidden Lines Visible .
	ViewDisplayShaded	Sets the current display mode to Shaded .
	ViewDisplayWireframe	Sets the current display mode to Wireframe .
	ViewFullPage	Fits the drawing to the full page.
	ViewHirQuality	Toggles the Hidden Lines Removed mode for the drawing view.
	ViewModelEdges	Toggles the mode for viewing model edges when in shaded mode.
	ViewTangentEdges	Toggles display of tangent edges in the selected drawing view.

[Top](#)

 See Also

[IDrawingDoc Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IDrawingDoc Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDrawingDoc Interface

For a list of all members of this type, see [IDrawingDoc members](#).

 Public Properties

Name	Description
 ActiveDrawingView	Gets the currently active drawing view.
 AutomaticViewUpdate	Gets or sets whether the drawing views in this drawing are automatically updated if the underlying model in that drawing view changes.
 BackgroundProcessingOption	Gets or sets the background processing option for this drawing.
 HiddenViewsVisible	Shows or hides all of the hidden drawing views.
 IActiveDrawingView	Gets the currently active drawing view.
 Sheet	Gets the specified sheet.

[Top](#)

 See Also

[IDrawingDoc Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ActivateSheet Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ActivateSheet Method (IDrawingDoc)

Activates the specified drawing sheet.

 .NET Syntax

Visual Basic (Declaration)

```
Function ActivateSheet(  
    ByVal Name As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Name As System.String  
Dim value As System.Boolean  
  
value = instance.ActivateSheet(Name)
```

C#

```
System.bool ActivateSheet(  
    System.string Name  
)
```

C++/CLI

```
System.bool ActivateSheet(  
& System.String^ Name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Name of the sheet

Return Value

True if the sheet was activated, false if SOLIDWORKS generated an error

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ActivateSheet](#).

Example

[Copy and Paste Drawing Sheet \(C#\)](#)
[Copy and Paste Drawing Sheet \(VB.NET\)](#)
[Copy and Paste Drawing Sheet \(VBA\)](#)
[Activate Each View on Current Sheet \(VBA\)](#)
[Rebuild All Configurations \(VBA\)](#)
[Get Loaded Sheets \(C#\)](#)
[Get Loaded Sheets \(VB.NET\)](#)

Remarks

This command makes the specified sheet the active or current sheet, similar to [IDrawingDoc::SheetNext](#) or [IDrawingDoc::SheetPrevious](#). You can use [IDrawingDoc::GetCurrentSheet](#) or [IDrawingDoc::!GetCurrentSheet](#) with an active sheet to gain access to the ISheet interface.

To activate a drawing view, you can use [IDrawingView::ActivateView](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::GetSheetCount Method](#)
[IDrawingDoc::GetSheetNames Method](#)
[IDrawingDoc::!GetSheetNames Method](#)
[ISheet Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ActivateView Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ActivateView Method (IDrawingDoc)

Activates the specified drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function ActivateView( _  
    ByVal ViewName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim ViewName As System.String  
Dim value As System.Boolean  
  
value = instance.ActivateView(ViewName)
```

C#

```
System.bool ActivateView(  
    System.string ViewName  
)
```

C++/CLI

```
System.bool ActivateView(  
& System.String^ ViewName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ViewName
Name of the drawing view

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ActivateView](#).

Example

[Activate Each View on Current Sheet \(VBA\)](#)
[Create Detail View \(VBA\)](#)
[Insert Autoballoons Using IDrawingDoc::AutoBalloon2 \(VBA\)](#)
[Undo Deleted Note and Fire Undo Post-Notify Event \(VB.NET\)](#)
[Undo Deleted Note and Fire Undo Post-Notify Event \(C#\)](#)
[Undo Deleted Note and Fire Undo Post-Notify Event \(VBA\)](#)
[Insert Model Annotations \(C#\)](#)
[Insert Model Annotations \(VB.NET\)](#)
[Insert Model Annotations \(VBA\)](#)

Remarks

This method returns false when trying to activate a drawing sheet. To activate a drawing sheet, use [IDrawingDoc::ActivateSheet](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::GetFirstView Method](#)
[IDrawingDoc::IGetFirstView Method](#)
[IView::GetNextView Method](#)
[IView::IGetNextView Method](#)



Gets the currently active drawing view.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ActiveDrawingView As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim value As System.Object  
  
value = instance.ActiveDrawingView
```

C#

```
System.Object ActiveDrawingView {get;}
```

C++/CLI

```
property System.Object^ ActiveDrawingView {  
    System.Object^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Currently active drawing view

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ActiveDrawingView](#).

Example

[Activate Each View on Current Sheet \(VBA\)](#)
[Get Number of Polylines in Shaded Mode in Drawing View \(VBA\)](#)
[Get Visible Components and Entities in Drawing View \(VBA\)](#)
[Insert and Show BOM Table and BOM Balloon \(C#\)](#)
[Insert and Show BOM Table and BOM Balloon \(VB.NET\)](#)
[Insert and Show BOM Table and BOM Balloon \(VBA\)](#)

Remarks

This property returns the active drawing view, if one is active. If the drawing sheet is active, the property returns NULL and you can use [IDrawingDoc::GetCurrentSheet](#) to get the current sheet for this drawing.

This is a read-only property. Use [IDrawingDoc::ActivateView](#) to set the active drawing view.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::Create3rdAngleViews2 Method](#)
[IDrawingDoc::CreateAuxiliaryViewAt2 Method](#)
[IDrawingDoc::CreateDetailViewAt3 Method](#)
[IDrawingDoc::CreateDrawViewFromModelView3 Method](#)
[IDrawingDoc::CreateFlatPatternViewFromModelView2 Method](#)
[IDrawingDoc::CreateSectionViewAt4 Method](#)
[IDrawingDoc::CreateRelativeView Method](#)
[IDrawingDoc::CreateSectionView Method](#)
[IDrawingDoc::CreateUnfoldedViewAt3 Method](#)
[IDrawingDoc::CreateViewport3 Method](#)
[IDrawingDoc::GetFirstView Method](#)
[IDrawingDoc::IDrawingDoc::ICreateDetailViewAt3 Method](#)
[IDrawingDoc::InsertModelInPredefinedView Method](#)
[IDrawingDoc::IActiveDrawingView Property](#)
[IDrawingDoc::ICreateAuxiliaryViewAt2 Method](#)
[IView::GetNextView Method](#)
[IView::IGetNextView Method](#)
[IDrawingDoc::IGetFirstView Method](#)

Availability

AddCenterMark Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : AddCenterMark Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::InsertCenterMark2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddCenterMark( _  
    ByVal CmSize As System.Double, _  
    ByVal CmShowLines As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim CmSize As System.Double  
Dim CmShowLines As System.Boolean  
Dim value As System.Boolean  
  
value = instance.AddCenterMark(CmSize, CmShowLines)
```

C#

```
System.bool AddCenterMark(  
    System.double CmSize,  
    System.bool CmShowLines  
)
```

C++/CLI

```
System.bool AddCenterMark(  
& System.double CmSize,  
& System.bool CmShowLines  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CmSize

CmShowLines

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::AddCenterMark](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

AddChamferDim Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : AddChamferDim Method (IDrawingDoc)

Adds a chamfer dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function AddChamferDim( _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim value As System.Object

value = instance.AddChamferDim(X, Y, Z)
```

C#

```
System.object AddChamferDim(
    System.double X,
    System.double Y,
    System.double Z
)
```

C++/CLI

```
System.Object^ AddChamferDim(
    & System.double X,
    & System.double Y,
    & System.double Z
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X
X dimension

Y
Y dimension

Z
Z dimension

Return Value

Pointer to the newly created chamfer [dimension](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::AddChamferDim](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::IAddChamferDim Method](#)
[IDimension::GetSystemChamferValues Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddHoleCallout Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : AddHoleCallout Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::AddHoleCallout2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub AddHoleCallout()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.AddHoleCallout()
```

C#

```
void AddHoleCallout()
```

C++/CLI

```
void AddHoleCallout();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::AddHoleCallout](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddHoleCallout2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : AddHoleCallout2 Method (IDrawingDoc)

Adds a hole callout at the specified position to the hole whose edge is selected.

.NET Syntax

Visual Basic (Declaration)

```
Function AddHoleCallout2( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Object  
  
value = instance.AddHoleCallout2(X, Y, Z)
```

C#

```
System.object AddHoleCallout2(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
System.Object^ AddHoleCallout2(
& System.double X,
& System.double Y,
& System.double Z
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X
X position of hole callout in meters
Y
Y position of hole callout in meters
Z
Z position of hole callout in meters

Return Value

[Display dimension](#) representing the hole callout

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::AddHoleCallout2](#).

Example

'VBA

```
'-----
' This example shows how to add a hole callout to
' a hole in a drawing.
'
' Preconditions:
' 1. Open the drawing of a part that contains a hole.
' 2. Select the edge of the hole where to add the callout in the graphics area.
' 3. Open the Immediate window.
'
' Postconditions:
' 1. A hole callout is added to the hole in the drawing.
' 2. Examine the drawing and Immediate window to verify.
' 3. Close the drawing without saving any changes.
'
' Tested using SolidWorks 2011 SP1.
'-----
```

Option Explicit

```
Const Xpos           As Double = 0.165
Const Ypos           As Double = 0.435
Const Zpos           As Double = 0#

Sub main()
    Dim swApp          As SldWorks.SldWorks
    Dim swModel         As SldWorks.ModelDoc2
    Dim swModelDocExt    As SldWorks.ModelDocExtension
    Dim swDraw          As SldWorks.DrawingDoc
    Dim swDispDim        As SldWorks.DisplayDimension
    Dim swAnn           As SldWorks.Annotation
    Dim status          As Boolean
    Dim annType         As Long

    Set swApp = CreateObject("SldWorks.Application")
    Set swModel = swApp.ActiveDoc
    Set swModelDocExt = swModel.Extension
    Set swDraw = swModel

    status = swDraw.ActivateView("Drawing View1")
    ' Select the edge of the hole where to add the callout
    ' status = swModelDocExt.SelectById2("", "EDGE", 0.6280838894175, 0.4565734807731, -499.9234340021, False, 0, Nothing, 0)
    Set swDispDim = swDraw.AddHoleCallout2(Xpos, Ypos, Zpos)

    Debug.Print "All          = " + swDispDim.GetText(swDimensionTextAll)
    Debug.Print "Prefix      = " + swDispDim.GetText(swDimensionTextPrefix)
    Debug.Print "Suffix       = " + swDispDim.GetText(swDimensionTextSuffix)
    Debug.Print "CalloutAbove = " + swDispDim.GetText(swDimensionTextCalloutAbove)
    Debug.Print "CalloutBelow = " + swDispDim.GetText(swDimensionTextCalloutBelow)

    Set swAnn = swDispDim.GetAnnotation
```

```
annType = swAnn.GetType
Debug.Print "Annotation Type" = " + Str(annType)
End Sub
```

Remarks

When you call this method, the user must click **OK** in the dialog that shows the system-generated hole callout.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc.AddHoleCallout2 Method](#)
[IDisplayDimension.IsHoleCallout Method](#)
[IDisplayDimension.GetHoleCalloutVariables Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddLineStyle Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : AddLineStyle Method (IDrawingDoc)

Adds a line style to the current drawing.

.NET Syntax

Visual Basic (Declaration)

```
Function AddLineStyle( _  
    ByVal StyleName As System.String, _  
    ByVal StyleDefinition As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim StyleName As System.String  
Dim StyleDefinition As System.String  
Dim value As System.Boolean
```

```
value = instance.AddLineStyle(StyleName, StyleDefinition)
```

C#

```
System.bool AddLineStyle(  
    System.string StyleName,  
    System.string StyleDefinition  
)
```

C++/CLI

```
System.bool AddLineStyle(  
& System.String^ StyleName,  
& System.String^ StyleDefinition  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StyleName

Name of line style

StyleDefinition

Comma-delimited string of line lengths and spacing values for the line style

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::AddLineStyle](#).

Example

[Manage Drawing Document Line Styles \(C#\)](#)
[Manage Drawing Document Line Styles \(VB.NET\)](#)
[Manage Drawing Document Line Styles \(VBA\)](#)

Remarks

Read about line style options in SOLIDWORKS Help.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::DeleteLineStyle Method](#)
[IDrawingDoc::LoadLineStyles Method](#)
[IDrawingDoc::GetLineStyles Method](#)
[IDrawingDoc::SaveLineStyles Method](#)
[ISldWorks::GetLineStyles Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddOrdinateDimension Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : AddOrdinateDimension Method (IDrawingDoc)

Obsolete. Superseded by [IModelDocExtension::AddOrdinateDimension](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddOrdinateDimension( _  
    ByVal DimType As System.Integer, _  
    ByVal LocX As System.Double, _  
    ByVal LocY As System.Double, _  
    ByVal LocZ As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IDrawingDoc  
Dim DimType As System.Integer  
Dim LocX As System.Double  
Dim LocY As System.Double  
Dim LocZ As System.Double  
Dim value As System.Boolean
```

```
value = instance.AddOrdinateDimension(DimType, LocX, LocY, LocZ)
```

C#

```
System.bool AddOrdinateDimension(  
    System.int DimType,  
    System.double LocX,  
    System.double LocY,  
    System.double LocZ  
)
```

C++/CLI

```
System.bool AddOrdinateDimension(  
& System.int DimType,  
& System.double LocX,  
& System.double LocY,  
& System.double LocZ  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DimType

LocX

LocY

LocZ

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::AddOrdinateDimension](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddOrdinateDimension2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : AddOrdinateDimension2 Method (IDrawingDoc)

Obsolete. Superseded by [IModelDocExtension::AddOrdinateDimension](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddOrdinateDimension2( _  
    ByVal DimType As System.Integer, _  
    ByVal LocX As System.Double, _  
    ByVal LocY As System.Double, _  
    ByVal LocZ As System.Double _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim DimType As System.Integer  
Dim LocX As System.Double  
Dim LocY As System.Double  
Dim LocZ As System.Double  
Dim value As System.Integer
```

```
value = instance.AddOrdinateDimension2(DimType, LocX, LocY, LocZ)
```

C#

```
System.int AddOrdinateDimension2(  
    System.int DimType,  
    System.double LocX,  
    System.double LocY,  
    System.double LocZ  
)
```

C++/CLI

```
System.int AddOrdinateDimension2(  
& System.int DimType,  
& System.double LocX,  
& System.double LocY,  
& System.double LocZ  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DimType

LocX

LocY

LocZ

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::AddOrdinateDimension2](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AlignHorz Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : AlignHorz Method (IDrawingDoc)

Uses the selected edge to align the current drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Sub AlignHorz()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.AlignHorz()
```

C#

```
void AlignHorz()
```

C++/CLI

```
void AlignHorz();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::AlignHorz](#).

Remarks

This method aligns the drawing view so that the selected edge is horizontal.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::AlignVert Method](#)
[IDrawingDoc::DrawingViewRotate Method](#)
[IDrawingDoc::RestoreRotation Method](#)
[IView::RemoveAlignment Method](#)
[IView::Position Property](#)
[IView::UseDefaultAlignment Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AlignOrdinate Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : AlignOrdinate Method (IDrawingDoc)

Aligns the ordinate dimension.

.NET Syntax

Visual Basic (Declaration)

```
Sub AlignOrdinate()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
  
instance.AlignOrdinate()
```

C#

```
void AlignOrdinate()
```

C++/CLI

```
void AlignOrdinate();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::AlignOrdinate](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDisplayDimension::AutoJogOrdinate Method](#)
[IDrawingDoc::CreateOrdinateDim4 Method](#)
[IDrawingDoc::EditOrdinate Method](#)
[IDrawingDoc::InsertOrdinate Method](#)
[IDrawingDoc::InsertHorizontalOrdinate Method](#)
[IDrawingDoc::InsertVerticalOrdinate Method](#)
[IModelDoc2::EditOrdinate Method](#)
[IModelDoc2::ReattachOrdinate Method](#)
[IModelDocExtension::AddOrdinateDimension Method](#)
[IDrawingDoc::ChangeOrdDir Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AlignVert Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : AlignVert Method (IDrawingDoc)

Uses the selected edge to align the current drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Sub AlignVert()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
```

```
instance.AlignVert()
```

C#

```
void AlignVert()
```

C++/CLI

```
void AlignVert();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::AlignVert](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::AlignHorz Method](#)
[IDrawingDoc::DrawingViewRotate Method](#)
[IDrawingDoc::RestoreRotation Method](#)
[IView::Position Property](#)
[IView::RemoveAlignment Method](#)
[IView::UseDefaultAlignment Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AttachAnnotation Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : AttachAnnotation Method (IDrawingDoc)

Attaches an existing annotation to a drawing sheet or view.

.NET Syntax

Visual Basic (Declaration)

```
Function AttachAnnotation( _  
    ByVal Option As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Option As System.Integer  
Dim value As System.Boolean
```

```
value = instance.AttachAnnotation(Option)
```

C#

```
System.bool AttachAnnotation(  
    System.int Option  
)
```

C++/CLI

```
System.bool AttachAnnotation(  
& System.int Option  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Option
Annotation attachment option as defined in [swAttachAnnotationOption_e](#)

Return Value

True if attachment is successful, false if not

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::AttachAnnotation](#).

Example

[Attach Annotation \(VBA\)](#)
[Attach Annotation \(VB.NET\)](#)
[Attach Annotation \(C#\)](#)

Remarks

To attach an annotation to a drawing view:

1. Multi-select the annotation and drawing view.
2. Call this method with Option set to swAttachAnnotationOption_e.swAttachAnnotationOption_View.

To attach an annotation to a drawing sheet:

1. Select the annotation.
2. Call this method with Option set to swAttachAnnotationOption_e.swAttachAnnotationOption_Sheet.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::InsertModelAnnotations3 Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

AttachDimensions Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : AttachDimensions Method (IDrawingDoc)

Attaches unattached dimensions.

.NET Syntax

Visual Basic (Declaration)

```
Sub AttachDimensions()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.AttachDimensions()
```

C#

```
void AttachDimensions()
```

C++/CLI

```
void AttachDimensions();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::AttachDimensions](#).

Remarks

This method tries to reattach dimensions, for example, in an imported DXF file.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::Dimensions Method](#)
[IDrawingDoc::InsertBaseDim Method](#)
[IDrawingDoc::InsertModelAnnotations3 Method](#)
[IDrawingDoc::InsertModelDimensions Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AutoBalloon Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : AutoBalloon Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::AutoBalloon3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AutoBalloon( _  
    ByVal Layout As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Layout As System.Integer  
Dim value As System.Object  
  
value = instance.AutoBalloon(Layout)
```

C#

```
System.object AutoBalloon(  
    System.int Layout  
)
```

C++/CLI

```
System.Object^ AutoBalloon(  
& System.int Layout  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Layout

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::AutoBalloon](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AutoBalloon2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : AutoBalloon2 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::AutoBalloon3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AutoBalloon2( _  
    ByVal Layout As System.Integer, _  
    ByVal IgnoreMultiple As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Layout As System.Integer  
Dim IgnoreMultiple As System.Boolean  
Dim value As System.Object  
  
value = instance.AutoBalloon2(Layout, IgnoreMultiple)
```

C#

```
System.object AutoBalloon2(  
    System.int Layout,  
    System.bool IgnoreMultiple  
)
```

C++/CLI

```
System.Object^ AutoBalloon2(  
& System.int Layout,  
& System.bool IgnoreMultiple  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Layout

IgnoreMultiple

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::AutoBalloon2](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AutoBalloon3 Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : AutoBalloon3 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::AutoBalloon4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AutoBalloon3( _  
    ByVal Layout As System.Integer, _  
    ByVal IgnoreMultiple As System.Boolean, _  
    ByVal Style As System.Integer, _  
    ByVal Size As System.Integer, _  
    ByVal UpperTextContent As System.Integer, _  
    ByVal UpperText As System.String, _  
    ByVal LowerTextContent As System.Integer, _  
    ByVal LowerText As System.String, _  
    ByVal Layername As System.String _  
) As System.Object
```

```

Dim instance As IDrawingDoc
Dim Layout As System.Integer
Dim IgnoreMultiple As System.Boolean
Dim Style As System.Integer
Dim Size As System.Integer
Dim UpperTextContent As System.Integer
Dim UpperText As System.String
Dim LowerTextContent As System.Integer
Dim LowerText As System.String
Dim Layername As System.String
Dim value As System.Object

```

```

value = instance.AutoBalloon3(Layout, IgnoreMultiple, Style, Size, UpperTextContent, UpperText,
LowerTextContent, LowerText, Layername)

```

C#

```

System.object AutoBalloon3(
    System.int Layout,
    System.bool IgnoreMultiple,
    System.int Style,
    System.int Size,
    System.int UpperTextContent,
    System.string UpperText,
    System.int LowerTextContent,
    System.string LowerText,
    System.string Layername
)

```

C++/CLI

```

System.Object^ AutoBalloon3(
    & System.int Layout,
    & System.bool IgnoreMultiple,
    & System.int Style,
    & System.int Size,
    & System.int UpperTextContent,
    & System.String^ UpperText,
    & System.int LowerTextContent,
    & System.String^ LowerText,
    & System.String^ Layername
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Layout

Layout style of the balloons as defined by [swBalloonLayoutType e](#) or specify -1 for this argument to use the document default layout style

IgnoreMultiple

True to apply a balloon to only one instance of a component, false to apply balloons to all instances of that component

Style

Style of the balloons as defined by [swBalloonStyle e](#) or specify -1 to use the document default balloon style

Size

Fit of balloon as defined by [swBalloonFit e](#) or specify -1 to use the document default balloon fit

UpperTextContent

Upper-text content style as defined by [swBalloonTextContent e](#) or specify -1 to use the document default upper text content

UpperText

Text for upper balloon

LowerTextContent

Lower-text content style as defined by [swBalloonTextContent e](#) or specify -1 to use the document default lower text content

NOTE: This and the next argument are only effective when Style is set to swBS_SplitCirc. See the SOLIDWORKS Help for additional details about autoballoons.

LowerText

Text for lower balloon

Layername

Name of the layer for this balloon

Return Value

Array of newly created [notes](#)

See [DrawingDoc::AutoBalloon3](#).

 Example

[Insert AutoBalloons \(VBA\)](#)

 Remarks

This method automatically creates the BOM balloons for the selected drawing views. If a drawing sheet is selected, BOM balloons are automatically created for all of the drawing views on that drawing sheet.

To get or set default values for...	Use...
Layout	IModelDocExtension::GetUserPreferenceInteger (swUserPreferenceIntegerValue_e.swDetailingAutoBalloonLayout, swUserPreferenceOption_e.swDetailingNoOptionSpecified) - or - IModelDocExtension::SetUserPreferenceInteger (swUserPreferenceIntegerValue_e.swDetailingAutoBalloonLayout, swUserPreferenceOption_e.swDetailingNoOptionSpecified, swBalloonLayoutType_e.<Value>)
Style	IModelDocExtension::GetUserPreferenceInteger ((swUserPreferenceIntegerValue_e.swDetailingBOMBalloonStyle, swUserPreferenceOption_e.swDetailingNoOptionSpecified) - or - IModelDocExtension::SetUserPreferenceInteger (swUserPreferenceIntegerValue_e.swDetailingBOMBalloonFit, swUserPreferenceOption_e.swDetailingNoOptionSpecified, swBalloonFit_e.<Value>)
Size	IModelDocExtension::GetUserPreferenceInteger ((swUserPreferenceIntegerValue_e.swDetailingBOMBalloonFit, swUserPreferenceOption_e.swDetailingNoOptionSpecified) - or - (swUserPreferenceIntegerValue_e.swDetailingBOMStackedBalloonFit, swUserPreferenceOption_e.swDetailingNoOptionSpecified, swBalloonFit_e.<Value>)
UpperTextContent	IModelDocExtension::GetUserPreferenceInteger (swUserPreferenceIntegerValue_e.swDetailingBOMUpperText, swUserPreferenceOption_e.swDetailingNoOptionSpecified) - or - IModelDocExtension::SetUserPreferenceInteger (swUserPreferenceIntegerValue_e.swDetailingBOMUpperText, swUserPreferenceOption_e.swDetailingNoOptionSpecified, swBalloonTextContent_e.<Value>)
LowerTextContent	IModelDocExtension::GetUserPreferenceInteger (swUserPreferenceIntegerValue_e.swDetailingBOMLowerText, swUserPreferenceOption_e.swDetailingNoOptionSpecified) - or - IModelDocExtension::SetUserPreferenceInteger (swUserPreferenceIntegerValue_e.swDetailingBOMLowerText, swUserPreferenceOption_e.swDetailingNoOptionSpecified, swBalloonTextContent_e.<Value>)

This method also allows you to get only the balloons just created.

 See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IModelDocExtension::InsertBOMBalloon Method](#)

 Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AutoBalloon4 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : AutoBalloon4 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::AutoBalloon5](#).

 .NET Syntax

Visual Basic (Declaration)

```
Function AutoBalloon4( _  
    ByVal Layout As System.Integer, _
```

```

ByVal IgnoreMultiple As System.Boolean, _
ByVal Style As System.Integer, _
ByVal Size As System.Integer, _
ByVal UpperTextContent As System.Integer, _
ByVal UpperText As System.String, _
ByVal LowerTextContent As System.Integer, _
ByVal LowerText As System.String, _
ByVal Layername As System.String, _
ByVal BalloonsToFaces As System.Boolean _
) As System.Object

```

Visual Basic (Usage)



```

Dim instance As IDrawingDoc
Dim Layout As System.Integer
Dim IgnoreMultiple As System.Boolean
Dim Style As System.Integer
Dim Size As System.Integer
Dim UpperTextContent As System.Integer
Dim UpperText As System.String
Dim LowerTextContent As System.Integer
Dim LowerText As System.String
Dim Layername As System.String
Dim BalloonsToFaces As System.Boolean
Dim value As System.Object

```

```

value = instance.AutoBalloon4(Layout, IgnoreMultiple, Style, Size, UpperTextContent, UpperText,
LowerTextContent, LowerText, Layername, BalloonsToFaces)

```

C#

```

System.object AutoBalloon4(
    System.int Layout,
    System.bool IgnoreMultiple,
    System.int Style,
    System.int Size,
    System.int UpperTextContent,
    System.string UpperText,
    System.int LowerTextContent,
    System.string LowerText,
    System.string Layername,
    System.bool BalloonsToFaces
)

```

C++/CLI

```

System.Object^ AutoBalloon4(
    & System.int Layout,
    & System.bool IgnoreMultiple,
    & System.int Style,
    & System.int Size,
    & System.int UpperTextContent,
    & System.String^ UpperText,
    & System.int LowerTextContent,
    & System.String^ LowerText,
    & System.String^ Layername,
    & System.bool BalloonsToFaces
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Layout

Layout style of the balloons as defined by [swBalloonLayoutType](#) e or specify -1 for this argument to use the document default layout style

IgnoreMultiple

True to apply a balloon to only one instance of a component, false to apply balloons to all instances of that component

Style

Style of the balloons as defined by [swBalloonStyle](#) e or specify -1 to use the document default balloon style

Size

Fit of balloon as defined by [swBalloonFit](#) e or specify -1 to use the document default balloon fit

UpperTextContent

Upper-text content style as defined by [swBalloonTextContent](#) e or specify -1 to use the document default upper text content

UpperText

Text for upper balloon

LowerTextContent
Lower-text content style as defined by [swBalloonTextContent_e](#) or specify -1 to use the document default lower text content

NOTE: This and the next argument are only effective when Style is set to swBS_SplitCirc. See the SOLIDWORKS Help for additional details about autoballoons.

LowerText
Text for lower balloon
Layername
Name of the layer for this balloon
BalloonsToFaces
True to attach balloons to faces; false to attach balloons to edges

Return Value

Array of newly created [notes](#)

 Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::AutoBalloon4](#).

 Remarks

This method automatically creates the BOM balloons for the selected drawing views. If a drawing sheet is selected, BOM balloons are automatically created for all of the drawing views on that drawing sheet.

To get or set default values for...	Use...
Layout	IModelDocExtension::GetUserPreferenceInteger (swUserPreferenceIntegerValue_e.swDetailingAutoBalloonLayout, swUserPreferenceOption_e.swDetailingNoOptionSpecified) - or - IModelDocExtension::SetUserPreferenceInteger (swUserPreferenceIntegerValue_e.swDetailingAutoBalloonLayout, swUserPreferenceOption_e.swDetailingNoOptionSpecified, swBalloonLayoutType_e.<Value>)
Style	IModelDocExtension::GetUserPreferenceInteger ((swUserPreferenceIntegerValue_e.swDetailingBOMBalloonStyle, swUserPreferenceOption_e.swDetailingNoOptionSpecified) - or - IModelDocExtension::SetUserPreferenceInteger (swUserPreferenceIntegerValue_e.swDetailingBOMBalloonFit, swUserPreferenceOption_e.swDetailingNoOptionSpecified, swBalloonFit_e.<Value>)
Size	IModelDocExtension::GetUserPreferenceInteger ((swUserPreferenceIntegerValue_e.swDetailingBOMBalloonFit, swUserPreferenceOption_e.swDetailingNoOptionSpecified) - or - (swUserPreferenceIntegerValue_e.swDetailingBOMStackedBalloonFit, swUserPreferenceOption_e.swDetailingNoOptionSpecified, swBalloonFit_e.<Value>)
UpperTextContent	IModelDocExtension::GetUserPreferenceInteger (swUserPreferenceIntegerValue_e.swDetailingBOMUpperText, swUserPreferenceOption_e.swDetailingNoOptionSpecified) - or - IModelDocExtension::SetUserPreferenceInteger (swUserPreferenceIntegerValue_e.swDetailingBOMUpperText, swUserPreferenceOption_e.swDetailingNoOptionSpecified, swBalloonTextContent_e.<Value>)
LowerTextContent	IModelDocExtension::GetUserPreferenceInteger (swUserPreferenceIntegerValue_e.swDetailingBOMLowerText, swUserPreferenceOption_e.swDetailingNoOptionSpecified) - or - IModelDocExtension::SetUserPreferenceInteger (swUserPreferenceIntegerValue_e.swDetailingBOMLowerText, swUserPreferenceOption_e.swDetailingNoOptionSpecified, swBalloonTextContent_e.<Value>)

This method also allows you to get only the balloons just created.

 See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IModelDocExtension::InsertBOMBalloon Method](#)

 Availability

SOLIDWORKS 2008 SP4, Revision Number 18.4



Automatically inserts BOM balloons in selected drawing views.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function AutoBalloon5( _  
    ByVal BalloonOptions As AutoBalloonOptions _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim BalloonOptions As AutoBalloonOptions  
Dim value As System.Object  
  
value = instance.AutoBalloon5(BalloonOptions)
```

C#

```
System.object AutoBalloon5(  
    AutoBalloonOptions BalloonOptions  
)
```

C++/CLI

```
System.Object^ AutoBalloon5(  
& AutoBalloonOptions^ BalloonOptions  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BalloonOptions
[IAutoBalloonOptions](#)

Return Value

Array of [INotes](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::AutoBalloon5](#).

Example

[Add Autoballoons to Drawing \(VBA\)](#)
[Add Autoballoons to Drawing \(VB.NET\)](#)
[Add Autoballoons to Drawing \(C#\)](#)

Remarks

This method automatically inserts BOM balloons for bill of materials items in selected drawing views. If a drawing sheet is selected, BOM balloons are automatically inserted for all of the drawing views on that drawing sheet.

To automatically insert BOM balloons:

1. Select one or more views or sheets for which to automatically create BOM balloons.
2. Call [IDrawingDoc::CreateAutoBalloonOptions](#) to create an [IAutoBalloonOptions](#) object.
3. Set the properties on the IAutoBalloonOptions object.
4. Call this method using the IAutoBalloonOptions object in the BalloonOptions argument.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IModelDocExtension::InsertBOMBalloon2 Method](#)
[IModelDocExtension::InsertStackedBalloon2 Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AutoDimension Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : AutoDimension Method (IDrawingDoc)

Automatically dimensions the selected drawing view.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function AutoDimension( _  
    ByVal EntitiesToDimension As System.Integer, _  
    ByVal HorizontalScheme As System.Integer, _  
    ByVal HorizontalPlacement As System.Integer, _  
    ByVal VerticalScheme As System.Integer, _  
    ByVal VerticalPlacement As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim EntitiesToDimension As System.Integer  
Dim HorizontalScheme As System.Integer  
Dim HorizontalPlacement As System.Integer  
Dim VerticalScheme As System.Integer  
Dim VerticalPlacement As System.Integer  
Dim value As System.Integer  
  
value = instance.AutoDimension(EntitiesToDimension, HorizontalScheme, HorizontalPlacement,  
    VerticalScheme, VerticalPlacement)
```

C#

```
System.int AutoDimension(  
    System.int EntitiesToDimension,  
    System.int HorizontalScheme,  
    System.int HorizontalPlacement,  
    System.int VerticalScheme,  
    System.int VerticalPlacement  
)
```

C++/CLI

```
System.int AutoDimension(  
& System.int EntitiesToDimension,  
& System.int HorizontalScheme,  
& System.int HorizontalPlacement,  
& System.int VerticalScheme,  
& System.int VerticalPlacement  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EntitiesToDimension

Entities to dimension as defined in [swAutodimEntities_e](#)

HorizontalScheme

Horizontal dimensioning scheme as defined in [swAutodimScheme_e](#)

HorizontalPlacement

Placement relative to the drawing view as defined in [swAutodimHorizontalPlacement_e](#)

VerticalScheme

Vertical dimensioning scheme as defined in [swAutodimScheme_e](#)

VerticalPlacement

Placement relative to the drawing view as defined in [swAutodimVerticalPlacement_e](#)

Return Value

swAutodimStatusSuccess if the view is automatically dimensioned; see [swAutodimStatus_e](#) for reasons for possible failures

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::AutoDimension](#).

Example

[Autodimension Selected Drawing View \(C#\)](#)
[Autodimension Selected Drawing View \(VB.NET\)](#)
[Autodimension Selected Drawing View \(VBA\)](#)

Remarks

This method requires information about the:

- drawing view to autodimension. This information can be supplied by selecting the drawing view to use. No mark is necessary.

If a drawing view is not selected, then this method attempts to determine the drawing view information from the other entities that are selected. If no other selections exist, then this method defaults to using the first drawing view, which is consistent with how the SOLIDWORKS Design user interface works.

- datums to use for the dimensioning baseline. These can be supplied by selecting a vertical edge, vertical sketch line, vertex, or sketch point as the datum for the horizontal dimensioning scheme. Mark the selection with [swAutodimMarkHorizontalDatum](#) from [swAutodimMark_e](#). Similarly a horizontal edge, horizontal sketch line, vertex, or sketch point should be selected and marked with [swAutodimMark_e.swAutodimMarkVerticalDatum](#) for defining the datum for the vertical dimensioning scheme. If only one of these datums is supplied, only the appropriate dimensions are created for that datum.

Instead of selecting the horizontal and vertical datum separately, you can select a vertex or sketch point to use to define both datums. Mark the selected vertex or sketch point selection with [swAutodimMark_e.swAutodimMarkOriginDatum](#). If no datums are selected, then this method automatically uses the left- and bottom-most entities in the view to determine default datums, which is consistent with how the SOLIDWORKS Design user interface works.

- entities to autodimension. This information is supplied by the [entitiesToDimension](#) argument and the selected entities marked with [swAutodimMark_e.swAutodimMarkEntities](#). The [entitiesToDimension](#) argument takes a value from the [swAutodimEntities_e](#) enumeration:
 - [swAutodimEntitiesSelected](#) indicates that only selected entities marked with a value of [swAutodimMarkEntities](#) are considered for autodimensioning.
 - [swAutodimEntitiesAll](#) indicates that all entities in the drawing view are autodimensioned.
 - [swAutodimEntitiesBasedOnPreselect](#) indicates that SOLIDWORKS figures out what to do based on the selected entities marked with [swAutodimMarkEntities](#). If any exist, then autodimension them, just like [swAutodimEntitiesSelected](#). If none exist, then autodimension all entities, just like [swAutodimEntitiesAll](#).

Supported entities for dimensioning are lines, points, vertices, faces, and sketch entities.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc.AddChamferDim Method](#)
[IDrawingDoc.CreateAngDim4 Method](#)
[IDrawingDoc.CreateDiamDim4 Method](#)
[IDrawingDoc.CreateLinearDim4 Method](#)
[IDrawingDoc.CreateOrdinateDim4 Method](#)
[IDrawingDoc.Dimensions Method](#)
[IDrawingDoc.DragModelDimension Method](#)
[IDrawingDoc.HideShowDimensions Method](#)
[IDrawingDoc.InsertChamferDim Method](#)
[IDrawingDoc.InsertAngDim4 Method](#)
[IDrawingDoc.InsertDiamDim4 Method](#)
[IDrawingDoc.InsertLinearDim4 Method](#)
[IDrawingDoc.InsertOrdinateDim4 Method](#)
[IDrawingDoc.InsertBaseDim Method](#)
[IDrawingDoc.InsertHorizontalOrdinate Method](#)
[IDrawingDoc.InsertModelAnnotations3 Method](#)
[IDrawingDoc.InsertModelDimensions Method](#)
[IDrawingDoc.InsertOrdinate Method](#)
[IDrawingDoc.InsertRefDim Method](#)
[IDrawingDoc.InsertVerticalOrdinate Method](#)
[IDrawingDoc.SketchDim Method](#)
[IDisplayDimension Interface](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

AutomaticViewUpdate Property (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : AutomaticViewUpdate Property (IDrawingDoc)

Gets or sets whether the drawing views in this drawing are automatically updated if the underlying model in that drawing view changes.

.NET Syntax

Visual Basic (Declaration)

Property AutomaticViewUpdate As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim value As System.Boolean

instance.AutomaticViewUpdate = value

value = instance.AutomaticViewUpdate
```

C#

```
System.bool AutomaticViewUpdate {get; set;}
```

C++/CLI

```
property System.bool AutomaticViewUpdate {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True updates the views automatically, false does not

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::AutomaticViewUpdate](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

BackgroundProcessingOption Property (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : BackgroundProcessingOption Property (IDrawingDoc)

Gets or sets the background processing option for this drawing.

.NET Syntax

Visual Basic (Declaration)

Property BackgroundProcessingOption As System.Integer

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim value As System.Integer

instance.BackgroundProcessingOption = value

value = instance.BackgroundProcessingOption
```

C#

```
System.int BackgroundProcessingOption {get; set;}
```

C++/CLI

```
property System.int BackgroundProcessingOption {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Background processing option as defined in [swBackgroundProcessOption_e](#) (see [Remarks](#))

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::BackgroundProcessingOption](#).

Example

[Fire Notifications for Background Processing Events \(VBA\)](#)
[Fire Notifications for Background Processing Events \(VB.NET\)](#)
[Fire Notifications for Background Processing Events \(C#\)](#)

Remarks

SOLIDWORKS recommends that you only use this property with [ISldWorks::IsBackgroundProcessingCompleted](#) and [ISldWorks::EnableBackgroundProcessing](#) when you can quickly open a drawing document via the user interface, but that same drawing takes significantly more time to open programmatically.

To more efficiently and programmatically open a drawing document that requires a lot of CPU time and no user input:

1. Set [ISldWorks::EnableBackgroundProcessing](#) to true.
2. Use [ISldWorks Event BackgroundProcessingStartNotify](#) to handle the background processing start event.
3. Open the drawing document by calling either [ISldWorks::OpenDoc6](#) or [ISldWorks::OpenDoc7](#).
4. Set [IDrawingDoc::BackgroundProcessingOption](#) to [swBackgroundProcessOption_e.swBackgroundProcessing_DeferToApplication](#).
5. Call [ISldWorks::IsBackgroundProcessingCompleted](#) repeatedly, which polls the status of the open operation.
6. Use [ISldWorks Event BackgroundProcessingEndNotify](#) to handle the background processing end event.
7. When the open operation is finished, set [ISldWorks::EnableBackgroundProcessing](#) to false.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

BreakLineSplineCut Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : BreakLineSplineCut Method (IDrawingDoc)

Obsolete. Superseded by [IBreakLine::Style](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub BreakLineSplineCut()
```

```
Dim instance As IDrawingDoc  
  
instance.BreakLineSplineCut()
```

C#

```
void BreakLineSplineCut()
```

C++/CLI

```
void BreakLineSplineCut();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::BreakLineSplineCut](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

BreakLineStraightCut Method (IDrawingDoc)

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : BreakLineStraightCut Method (IDrawingDoc)

Obsolete. Superseded by [IBreakLine::Style](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub BreakLineStraightCut()
```

Visual Basic (Usage)

```
Dim instance As IDrawingDoc  
  
instance.BreakLineStraightCut()
```

C#

```
void BreakLineStraightCut()
```

C++/CLI

```
void BreakLineStraightCut();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::BreakLineStraightCut](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

BreakLineZigZagCut Method (IDrawingDoc)

[See Also](#)

Obsolete. Superseded by [IBreakLine::Style](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub BreakLineZigZagCut()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.BreakLineZigZagCut()
```

C#

```
void BreakLineZigZagCut()
```

C++/CLI

```
void BreakLineZigZagCut();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::BreakLineZigZagCut](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

BreakView Method (IDrawingDoc)

[See Also](#) [Example](#)



SolidWorks.Interop.sldworks Namespace > [IDrawingDoc Interface](#) : BreakView Method (IDrawingDoc)

Breaks the drawing view along the existing break lines.

.NET Syntax

Visual Basic (Declaration)

```
Sub BreakView()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.BreakView()
```

C#

```
void BreakView()
```

C++/CLI

```
void BreakView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::BreakView](#).

Example

[Create Break View \(C#\)](#)
[Create Break View \(VB.NET\)](#)
[Create Break View \(VBA\)](#)

Remarks

Use [IDrawingDoc::InsertBreakHorizontal](#) or [IDrawingDoc::InsertBreakVertical](#) to insert break lines to a drawing view. Customize the break by dragging and repositioning the break lines. Then, call this method to create the break view.

You can set the font of the break lines using [IBreakLine::Style](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::InsertBreakHorizontal Method](#)
[IDrawingDoc::InsertBreakVertical Method](#)
[IDrawingDoc::UnBreakView Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CenterMark Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : CenterMark Method (IDrawingDoc)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Sub CenterMark()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.CenterMark()
```

C#

```
void CenterMark()
```

C++/CLI

```
void CenterMark();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::CenterMark](#).

Remarks

SOLIDWORKS creates center marks inside subsequently selected edges.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[ICenterMark Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ChangeComponentLayer Method (IDrawingDoc)

[See Also](#) [Example](#)



Puts the selected components on the specified layer.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub ChangeComponentLayer( _  
    ByVal Layername As System.String, _  
    ByVal AllViews As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Layername As System.String  
Dim AllViews As System.Boolean  
  
instance.ChangeComponentLayer(Layername, AllViews)
```

C#

```
void ChangeComponentLayer(  
    System.string Layername,  
    System.bool AllViews  
)
```

C++/CLI

```
void ChangeComponentLayer(  
& System.String^ Layername,  
& System.bool AllViews  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Layername

Name of layer for components

AllViews

True changes the component layer for all views in the drawing, false changes only the selected view

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ChangeComponentLayer](#).

Example

[Create Layer for Selected View \(VBA\)](#)

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::OnComponentProperties Method](#)
[IDrawingDoc::ResolveOutOfDateLightWeightComponents Method](#)
[IComponent2 Interface](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0



Changes the ordinate direction.

.NET Syntax

Visual Basic (Declaration)

```
Sub ChangeOrdDir()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
  
instance.ChangeOrdDir()
```

C#

```
void ChangeOrdDir()
```

C++/CLI

```
void ChangeOrdDir();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ChangeOrdDir](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::AlignOrdinate Method](#)
[IDrawingDoc::CreateOrdinateDim4 Method](#)
[IDrawingDoc::EditOrdinate Method](#)
[IDrawingDoc::ICreateOrdinateDim4 Method](#)
[IDrawingDoc::InsertOrdinate Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ChangeRefConfigurationOfFlatPatternView Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ChangeRefConfigurationOfFlatPatternView Method (IDrawingDoc)

Changes the configuration of the selected flat-pattern view of the specified model.

.NET Syntax

Visual Basic (Declaration)

```
Function ChangeRefConfigurationOfFlatPatternView( _  
    ByVal ModelName As System.String, _  
    ByVal ConfigName As System.String _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim ModelName As System.String  
Dim ConfigName As System.String  
Dim value As System.Boolean  
  
value = instance.ChangeRefConfigurationOfFlatPatternView(ModelName, ConfigName)
```

C#

```
System.bool ChangeRefConfigurationOfFlatPatternView(  
    System.string ModelName,  
    System.string ConfigName  
)
```

```
System.bool ChangeRefConfigurationOfFlatPatternView(  
& System.String^ ModelName,  
& System.String^ ConfigName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ModelName

Name of the model in the flat-pattern view

ConfigName

Name of the configuration

Return Value

True if the configuration was successfully changed, false if not

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ChangeRefConfigurationOfFlatPatternView](#).

Remarks

Before calling this method, you must select the flat-pattern view of the model.

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

[DrawingDoc::CreateFlatPatternViewFromModelView2 Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0