

SOLIDWORKS API (.NET VBA C#) — Reference (871337): IDrawingDoc (part 4 of 7)

SOLIDWORKS API Documentation (converted from CHM)

IDrawingDoc (part 4 of 7) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetPenCount Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : GetPenCount Method (IDrawingDoc)

Gets the number of pens currently defined in SOLIDWORKS.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPenCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim value As System.Integer  
  
value = instance.GetPenCount()
```

C#

```
System.int GetPenCount()
```

C++/CLI

```
System.int GetPenCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of pens

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GetPenCount](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::GetPenInfo Method](#)
[IDrawingDoc::IGetPenInfo Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetPenInfo Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : GetPenInfo Method (IDrawingDoc)

Gets information about the pens used in SOLIDWORKS.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPenInfo() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim value As System.Object  
  
value = instance.GetPenInfo()
```

C#

System.object GetPenInfo()

C++/CLI

System.Object^ GetPenInfo();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array containing an array of longs or integers (see [Long vs. Integer](#) and see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GetPenInfo](#).

Remarks

The return value is the following array: [*font*, *weight*, *color*]

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::GetPenInfo Method](#)
[IDrawingDoc::IGetPenInfo Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetSheetCount Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : GetSheetCount Method (IDrawingDoc)

Gets the number of drawing sheets in this drawing.

.NET Syntax

Visual Basic (Declaration)

Function GetSheetCount() As System.Integer

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim value As System.Integer

value = instance.GetSheetCount()
```

C#

System.int GetSheetCount()

C++/CLI

System.int GetSheetCount();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of drawing sheets in the drawing

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GetSheetCount](#).

Example

[Print Drawing Document to File \(VBA\)](#).

Remarks

Call this method before call [IDrawingDoc::!GetSheetNames](#) to determine the size of that method's return array.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::ActivateSheet Method](#)
[IDrawingDoc::EditSheet Method](#)
[IDrawingDoc::GetCurrentSheet Method](#)
[IDrawingDoc::!GetSheetNames Method](#)
[IDrawingDoc::GetEditSheet Method](#)
[IDrawingDoc::GetSheetNames Method](#)
[IDrawingDoc::!GetCurrentSheet Method](#)
[IDrawingDoc::!ReorderSheets Method](#)
[IDrawingDoc::NewSheet3 Method](#)
[IDrawingDoc::ReorderSheets Method](#)
[IDrawingDoc::SetupSheet4 Method](#)
[IDrawingDoc::SheetNext Method](#)
[IDrawingDoc::SheetPrevious Method](#)
[ISheet Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSheetNames Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : GetSheetNames Method (IDrawingDoc)

Gets a list of the names of the drawing sheets in this drawing.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSheetNames() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim value As System.Object  
  
value = instance.GetSheetNames()
```

C#

```
System.object GetSheetNames()
```

C++/CLI

```
System.Object^ GetSheetNames();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array containing the names of the drawing sheets in this drawing

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GetSheetNames](#).

Example

[Get Sheet Names \(VBA\)](#)
[Rebuild All Configurations \(VBA\)](#)
[Get Loaded Sheets \(C#\)](#)
[Get Loaded Sheets \(VB.NET\)](#)
[Modify and Reload Sheet Format Template \(C#\)](#)
[Modify and Reload Sheet Format Template \(VB.NET\)](#)
[Modify and Reload Sheet Format Template \(VBA\)](#)

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::ActivateSheet Method](#)
[IDrawingDoc::EditSheet Method](#)
[IDrawingDoc::GetCurrentSheet Method](#)
[IDrawingDoc::GetEditSheet Method](#)
[IDrawingDoc::GetSheetCount Method](#)
[IDrawingDoc::IGetCurrentSheet Method](#)
[IDrawingDoc::IGetSheetNames Method](#)
[IDrawingDoc::IReorderSheets Method](#)
[IDrawingDoc::NewSheet3 Method](#)
[IDrawingDoc::SetupSheet4 Method](#)
[IDrawingDoc::SheetNext Method](#)
[IDrawingDoc::SheetPrevious Method](#)
[ISheet Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetViewCount Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : GetViewCount Method (IDrawingDoc)

Gets all of the number of all of views, including the number of sheets, in this drawing document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetViewCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim value As System.Integer  
  
value = instance.GetViewCount()
```

C#

```
System.int GetViewCount()
```

C++/CLI

```
System.int GetViewCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of views, including the number of sheets, in this drawing document (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GetViewCount](#).

Example

[Get Views and Notes \(VBA\)](#)

Remarks

For example, when:

Number of sheets in drawing document	= 2
Number of views on Sheet1	= 6
Number of views on Sheet2	= 2
Return value	= 10

The active sheet might not be the first sheet in the return value.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::GetViews Method](#)

[IDrawingDoc::GetFirstView Method](#)
[IDrawingDoc::IGetFirstView Method](#)
[ISheet::GetViews Method](#)
[IView::GetNextView Method](#)
[IView::IGetNextView Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetViews Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : GetViews Method (IDrawingDoc)

Gets the all of the views, including the sheets, in this drawing document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetViews() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim value As System.Object  
  
value = instance.GetViews()
```

C#

```
System.object GetViews()
```

C++/CLI

```
System.Object^ GetViews();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

An array of arrays (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::GetViews](#).

Example

[Get Views and Notes \(VBA\)](#)

Remarks

The return value is an array of arrays with a length equal to the number of sheets in the drawing document. Each of those arrays is a list of view: with the first view in the list being the sheet itself.

If there are multiple sheets in the drawing document, then the order in which the sheets are returned is undetermined. So, the active sheet and its views might not be returned in the first array.

For example, when there are three sheets in the drawing document:

One sheet contains 6 views, so first array has this number of elements	= 7 (sheet + 6 views)
Another sheet contains 2 views, so second array has this number of elements	= 3 (sheet + 2 views)
Another sheet contains no views, so third array has this number of elements	= 1 (sheet + 0 views)

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::GetViewCount Method](#)
[IDrawingDoc::GetFirstView Method](#)
[IDrawingDoc::!GetFirstView Method](#)
[ISheet::GetViews Method](#)
[IView::GetNextView Method](#)
[IView::!GetNextView Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

HiddenViewsVisible Property (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : HiddenViewsVisible Property (IDrawingDoc)

Shows or hides all of the hidden drawing views.

.NET Syntax

Visual Basic (Declaration)

Property HiddenViewsVisible As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim value As System.Boolean  
  
instance.HiddenViewsVisible = value  
value = instance.HiddenViewsVisible
```

C#

```
System.bool HiddenViewsVisible {get; set;}
```

C++/CLI

```
property System.bool HiddenViewsVisible {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if views are visible, false if they are hidden

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::HiddenViewsVisible](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::HideShowDimensions Method](#)
[IDrawingDoc::SuppressView Method](#)
[IDrawingDoc::UnsuppressView Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

HideEdge Method (IDrawingDoc)

[See Also](#) [Example](#)



Hides selected visible edges in a drawing document.

.NET Syntax

Visual Basic (Declaration)

```
Sub HideEdge()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
```

```
instance.HideEdge()
```

C#

```
void HideEdge()
```

C++/CLI

```
void HideEdge();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::HideEdge](#).

Example

[Hide and Show All Edges in Drawing View \(VBA\)](#)
[Hide and Show all Edges in Drawing View \(VB.NET\)](#)
[Hide and Show all Edges in Drawing View \(C#\)](#)

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::ShowEdge Method](#)
[IDrawingDoc::ViewModelEdges Method](#)
[IDrawingDoc::ViewTangentEdges Method](#)
[IView::HiddenEdges Property](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

HideShowDimensions Method (IDrawingDoc)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > IDrawingDoc Interface : HideShowDimensions Method (IDrawingDoc)

Sets whether to display suppressed dimensions as dimmed and hide them.

.NET Syntax

Visual Basic (Declaration)

```
Sub HideShowDimensions()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
```

```
instance.HideShowDimensions()
```

C#

```
void HideShowDimensions()
```

C++/CLI

```
void HideShowDimensions();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::HideShowDimensions](#).

Remarks

When SOLIDWORKS displays a suppressed dimension as dimmed, users can select it to turn off suppression.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::AttachDimensions Method](#)
[IDrawingDoc::DragModelDimension Method](#)
[IDrawingDoc::Dimensions Method](#)
[IDrawingDoc::InsertModelDimensions Method](#)
[IDrawingDoc::InsertRefDim Method](#)
[IDrawingDoc::InsertBaseDim Method](#)
[IDrawingDoc::InsertModelAnnotations3 Method](#)
[IDrawingDoc::SketchDim Method](#)
[IDrawingDoc::AutoDimension Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

HideShowDrawingViews Method (IDrawingDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : HideShowDrawingViews Method (IDrawingDoc)

Sets whether to hide or show hidden drawing views.

.NET Syntax

Visual Basic (Declaration)

```
Sub HideShowDrawingViews()
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
instance.HideShowDrawingViews()
```

C#

```
void HideShowDrawingViews()
```

C++/CLI

```
void HideShowDrawingViews();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::HideShowDrawingViews](#).

Example

[Display Hidden Lines in Drawing \(VBA\)](#)
[Display Hidden Lines in Drawing \(VB.NET\)](#)
[Display Hidden Lines in Drawing \(C#\)](#)

Remarks

If this setting is enabled, then SOLIDWORKS shows drawing views that were hidden using [IDrawingDoc::SuppressView](#) with an X.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::ActivateView Method](#)
[IDrawingDoc::SuppressView Method](#)
[IDrawingDoc::UnsuppressView Method](#)
[IDrawingDoc::ViewDisplayHidden Method](#)
[IDrawingDoc::ViewDisplayHiddenGreyed Method](#)
[IDrawingDoc::ViewDisplayShaded Method](#)
[IDrawingDoc::ViewDisplayWireframe Method](#)
[IDrawingDoc::ViewFullPage Method](#)
[IDrawingDoc::ViewHirQuality Method](#)
[IDrawingDoc::ActiveDrawingView Property](#)
[IDrawingDoc::AutomaticViewUpdate Property](#)
[IDrawingDoc::HiddenViewsVisible Property](#)
[IDrawingDoc::!ActiveDrawingView Property](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IActiveDrawingView Property (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : IActiveDrawingView Property (IDrawingDoc)

Gets the currently active drawing view.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property IActiveDrawingView As View
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim value As View  
  
value = instance.IActiveDrawingView
```

C#

```
View IActiveDrawingView {get;}
```

C++/CLI

```
property View^ IActiveDrawingView {  
    View^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pointer to interface object of the currently active drawing [view](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::!ActiveDrawingView](#).

Remarks

This property returns the active drawing view, if one is active. If the drawing sheet is active, the property returns NULL and you can use [IDrawingDoc::!GetCurrentSheet](#) to get the current sheet for this drawing.

This is a read-only property. Use [IDrawingDoc::ActivateView](#) to set the active drawing view.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

[IDrawingDoc::ActiveDrawingView Property](#)
[IDrawingDoc::Create1stAngleViews2 Method](#)
[IDrawingDoc::Create3rdAngleViews2 Method](#)
[IDrawingDoc::CreateAuxiliaryViewAt2 Method](#)
[IDrawingDoc::CreateDetailViewAt3 Method](#)
[IDrawingDoc::CreateDrawViewFromModelView3 Method](#)
[IDrawingDoc::CreateFlatPatternViewFromModelView2 Method](#)
[IDrawingDoc::CreateRelativeView Method](#)
[IDrawingDoc::CreateSectionView Method](#)
[IDrawingDoc::CreateSectionViewAt4 Method](#)
[IDrawingDoc::CreateUnfoldedViewAt3 Method](#)
[IDrawingDoc::CreateViewport3 Method](#)
[IDrawingDoc::GetFirstView Method](#)
[IDrawingDoc::!CreateAuxiliaryViewAt2 Method](#)
[IDrawingDoc::!CreateDetailViewAt3 Method](#)
[IDrawingDoc::!CreateSectionViewAt4 Method](#)
[IDrawingDoc::!GetFirstView Method](#)
[IView::GetNextView Method](#)
[IView::!GetNextView Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAddChamferDim Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : IAddChamferDim Method (IDrawingDoc)

Adds a chamfer dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function IAddChamferDim(  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As DisplayDimension
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As DisplayDimension  
  
value = instance.IAddChamferDim(X, Y, Z)
```

C#

```
DisplayDimension IAddChamferDim(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
DisplayDimension^ IAddChamferDim(  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X
X dimension
Y
Y dimension
Z

Z dimension

Return Value

Pointer to the newly created chamfer [dimension](#).

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::IAddChamferDim](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::AddChamferDim Method](#)
[IDimension::GetSystemChamferValues Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAddHoleCallout2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : IAddHoleCallout2 Method (IDrawingDoc)

Adds a hole callout at the specified position to the hole whose edge is selected.

.NET Syntax

Visual Basic (Declaration)

```
Function IAddHoleCallout2( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As DisplayDimension
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As DisplayDimension  
  
value = instance.IAddHoleCallout2(X, Y, Z)
```

C#

```
DisplayDimension IAddHoleCallout2(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
DisplayDimension^ IAddHoleCallout2(  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

X position of hole callout in meters

Y
Y position of hole callout in meters

Z
Z position of hole callout in meters

Return Value

Pointer to [DisplayDimension](#) object representing the hole callout

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::IAddHoleCallout2](#).

Remarks

When you call this method, the user must click **OK** in the dialog that shows the system-generated hole callout.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDisplayDimension::IsHoleCallout Method](#)
[IDrawingDoc::AddHoleCallout2 Method](#)
[IDisplayDimension::GetHoleCalloutVariables Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreateAngDim Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateAngDim Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::ICreateAngDim4](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ICreateAngDim( _  
    ByRef P0 As System.Double, _  
    ByRef P1 As System.Double, _  
    ByRef P2 As System.Double, _  
    ByRef P3 As System.Double, _  
    ByRef P4 As System.Double, _  
    ByRef P5 As System.Double, _  
    ByRef P6 As System.Double, _  
    ByVal ArrowSize As System.Double, _  
    ByVal Text As System.String, _  
    ByVal TextHeight As System.Double, _  
    ByVal WitnessGap As System.Double, _  
    ByVal WitnessOvershoot As System.Double _  
)
```

Visual Basic (Usage)

```
Dim instance As IDrawingDoc  
Dim P0 As System.Double  
Dim P1 As System.Double  
Dim P2 As System.Double  
Dim P3 As System.Double  
Dim P4 As System.Double  
Dim P5 As System.Double  
Dim P6 As System.Double  
Dim ArrowSize As System.Double  
Dim Text As System.String  
Dim TextHeight As System.Double
```



```
Dim WitnessGap As System.Double
Dim WitnessOvershoot As System.Double
```

```
instance.ICreateAngDim(P0, P1, P2, P3, P4, P5, P6, ArrowSize, Text, TextHeight, WitnessGap,
WitnessOvershoot)
```

C#

```
void ICreateAngDim(
    ref System.double P0,
    ref System.double P1,
    ref System.double P2,
    ref System.double P3,
    ref System.double P4,
    ref System.double P5,
    ref System.double P6,
    System.double ArrowSize,
    System.string Text,
    System.double TextHeight,
    System.double WitnessGap,
    System.double WitnessOvershoot
)
```

C++/CLI

```
void ICreateAngDim(
    & System.double% P0,
    & System.double% P1,
    & System.double% P2,
    & System.double% P3,
    & System.double% P4,
    & System.double% P5,
    & System.double% P6,
    & System.double ArrowSize,
    & System.String^ Text,
    & System.double TextHeight,
    & System.double WitnessGap,
    & System.double WitnessOvershoot
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P0

P1

P2

P3

P4

P5

P6

ArrowSize

Text

TextHeight

WitnessGap

WitnessOvershoot

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ICreateAngDim](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

ICreateAngDim2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateAngDim2 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc.ICreateAngDim4](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ICreateAngDim2( _
    ByRef P0 As System.Double, _
    ByRef P1 As System.Double, _
    ByRef P2 As System.Double, _
    ByRef P3 As System.Double, _
    ByRef P4 As System.Double, _
    ByRef P5 As System.Double, _
    ByRef P6 As System.Double, _
    ByVal ArrowSize As System.Double, _
    ByVal Text As System.String, _
    ByVal TextHeight As System.Double, _
    ByVal WitnessGap As System.Double, _
    ByVal WitnessOvershoot As System.Double, _
    ByRef TextPoint As System.Double _
)
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim P0 As System.Double
Dim P1 As System.Double
Dim P2 As System.Double
Dim P3 As System.Double
Dim P4 As System.Double
Dim P5 As System.Double
Dim P6 As System.Double
Dim ArrowSize As System.Double
Dim Text As System.String
Dim TextHeight As System.Double
Dim WitnessGap As System.Double
Dim WitnessOvershoot As System.Double
Dim TextPoint As System.Double

instance.ICreateAngDim2(P0, P1, P2, P3, P4, P5, P6, ArrowSize, Text, TextHeight, WitnessGap,
WitnessOvershoot, TextPoint)
```

C#

```
void ICreateAngDim2(
    ref System.double P0,
    ref System.double P1,
    ref System.double P2,
    ref System.double P3,
    ref System.double P4,
    ref System.double P5,
    ref System.double P6,
    System.double ArrowSize,
    System.string Text,
    System.double TextHeight,
    System.double WitnessGap,
    System.double WitnessOvershoot,
    ref System.double TextPoint
)
```

C++/CLI

```
void ICreateAngDim2(
    & System.double% P0,
```

```

& System.double% P1,
& System.double% P2,
& System.double% P3,
& System.double% P4,
& System.double% P5,
& System.double% P6,
& System.double ArrowSize,
& System.String^ Text,
& System.double TextHeight,
& System.double WitnessGap,
& System.double WitnessOvershoot,
& System.double% TextPoint
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P0

P1

P2

P3

P4

P5

P6

ArrowSize

Text

TextHeight

WitnessGap

WitnessOvershoot

TextPoint

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::!CreateAngDim2](#).

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateAngDim3 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateAngDim3 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::!CreateAngDim4](#).

.NET Syntax

Visual Basic (Declaration)

```

Function ICreateAngDim3( _
    ByRef P0 As System.Double, _
    ByRef P1 As System.Double, _
    ByRef P2 As System.Double, _
    ByRef P3 As System.Double, _
    ByRef P4 As System.Double, _
    ByRef P5 As System.Double, _
    ByRef P6 As System.Double, _
    ByVal ArrowSize As System.Double, _
    ByVal Text As System.String, _
    ByVal TextHeight As System.Double, _
    ByVal WitnessGap As System.Double, _
    ByVal WitnessOvershoot As System.Double, _

```

```
ByRef TextPoint As System.Double _  
) As DisplayDimension
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim P0 As System.Double  
Dim P1 As System.Double  
Dim P2 As System.Double  
Dim P3 As System.Double  
Dim P4 As System.Double  
Dim P5 As System.Double  
Dim P6 As System.Double  
Dim ArrowSize As System.Double  
Dim Text As System.String  
Dim TextHeight As System.Double  
Dim WitnessGap As System.Double  
Dim WitnessOvershoot As System.Double  
Dim TextPoint As System.Double  
Dim value As DisplayDimension
```

```
value = instance.ICreateAngDim3(P0, P1, P2, P3, P4, P5, P6, ArrowSize, Text, TextHeight,  
WitnessGap, WitnessOvershoot, TextPoint)
```

C#

```
DisplayDimension ICreateAngDim3(  
    ref System.double P0,  
    ref System.double P1,  
    ref System.double P2,  
    ref System.double P3,  
    ref System.double P4,  
    ref System.double P5,  
    ref System.double P6,  
    System.double ArrowSize,  
    System.string Text,  
    System.double TextHeight,  
    System.double WitnessGap,  
    System.double WitnessOvershoot,  
    ref System.double TextPoint  
)
```

C++/CLI

```
DisplayDimension^ ICreateAngDim3(  
& System.double% P0,  
& System.double% P1,  
& System.double% P2,  
& System.double% P3,  
& System.double% P4,  
& System.double% P5,  
& System.double% P6,  
& System.double ArrowSize,  
& System.String^ Text,  
& System.double TextHeight,  
& System.double WitnessGap,  
& System.double WitnessOvershoot,  
& System.double% TextPoint  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P0

P1

P2

P3

P4

P5

P6

ArrowSize

Text

TextHeight

WitnessGap

WitnessOvershoot

TextPoint

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ICreateAngDim3](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreateAngDim4 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateAngDim4 Method (IDrawingDoc)

Creates a non-associative angular dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateAngDim4( _  
    ByRef P0 As System.Double, _  
    ByRef P1 As System.Double, _  
    ByRef P2 As System.Double, _  
    ByRef P3 As System.Double, _  
    ByRef P4 As System.Double, _  
    ByRef P5 As System.Double, _  
    ByRef P6 As System.Double, _  
    ByRef TextPoint As System.Double, _  
    ByVal TextHeight As System.Double _  
) As DisplayDimension
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim P0 As System.Double  
Dim P1 As System.Double  
Dim P2 As System.Double  
Dim P3 As System.Double  
Dim P4 As System.Double  
Dim P5 As System.Double  
Dim P6 As System.Double  
Dim TextPoint As System.Double  
Dim TextHeight As System.Double  
Dim value As DisplayDimension
```

```
value = instance.ICreateAngDim4(P0, P1, P2, P3, P4, P5, P6, TextPoint, TextHeight)
```

C#

```
DisplayDimension ICreateAngDim4(  
    ref System.double P0,  
    ref System.double P1,  
    ref System.double P2,  
    ref System.double P3,  
    ref System.double P4,  
    ref System.double P5,
```

```

    ref System.double P6,
    ref System.double TextPoint,
    System.double TextHeight
)

```

C++/CLI

```

DisplayDimension^ ICreateAngDim4(
& System.double% P0,
& System.double% P1,
& System.double% P2,
& System.double% P3,
& System.double% P4,
& System.double% P5,
& System.double% P6,
& System.double% TextPoint,
& System.double TextHeight
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P0

Pointer to an array of 3 doubles (x,y,z); dimension end point

P1

Pointer to an array of 3 doubles (x,y,z); dimension point

P2

Pointer to an array of 3 doubles (x,y,z); extension1 start point

P3

Pointer to an array of 3 doubles (x,y,z); extension1 end point

P4

Pointer to an array of 3 doubles (x,y,z); extension2 start point

P5

Pointer to an array of 3 doubles (x,y,z); extension2 end point

P6

Pointer to an array of 3 doubles (x,y,z); plane normal

TextPoint

Pointer to an array of 3 doubles (x,y,z); position of text

TextHeight

Text height in meters

Return Value

Pointer to [IDisplayDimension](#) object

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ICreateAngDim4](#).

Remarks

SOLIDWORKS creates this type of dimension between the two points that you specify. It has no relation to your geometry.

This method does not replace [IDrawingDoc::ICreateDiamDim4](#); it changes the number of arguments required to construct the [IDisplayDimension](#) object.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::CreateAngDim4 Method](#)
[IDrawingDoc::CreateDiamDim4 Method](#)
[IDrawingDoc::CreateLinearDim4 Method](#)
[IDrawingDoc::CreateOrdinateDim4 Method](#)
[IDrawingDoc::ICreateLinearDim4 Method](#)
[IDrawingDoc::ICreateOrdinateDim4 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

ICreateAuxiliaryViewAt2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateAuxiliaryViewAt2 Method (IDrawingDoc)

Creates an auxiliary view based on a selected edge in a drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateAuxiliaryViewAt2( _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double, _
    ByVal NotAligned As System.Boolean, _
    ByVal Label As System.String, _
    ByVal Showarrow As System.Boolean, _
    ByVal Flip As System.Boolean _
) As View
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim NotAligned As System.Boolean
Dim Label As System.String
Dim Showarrow As System.Boolean
Dim Flip As System.Boolean
Dim value As View
```

```
value = instance.ICreateAuxiliaryViewAt2(X, Y, Z, NotAligned, Label, Showarrow, Flip)
```

C#

```
View ICreateAuxiliaryViewAt2(
    System.double X,
    System.double Y,
    System.double Z,
    System.bool NotAligned,
    System.string Label,
    System.bool Showarrow,
    System.bool Flip
)
```

C++/CLI

```
View^ ICreateAuxiliaryViewAt2(
    & System.double X,
    & System.double Y,
    & System.double Z,
    & System.bool NotAligned,
    & System.String^ Label,
    & System.bool Showarrow,
    & System.bool Flip
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X
X position for the auxiliary view

Y
Y position for the auxiliary view

Z
Z position for the auxiliary view

NotAligned

True aligns the view from its owner, false does not

Label

String that holds label of the auxiliary view

Showarrow

True shows the arrow, false hides the arrow

Flip

True flips the side shown in the auxiliary view, false does not

Return Value

Pointer to the newly created auxiliary [view](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ICreateAuxiliaryViewAt2](#).

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

[IDrawingDoc::CreateAuxiliaryViewAt2 Method](#)

[IDrawingDoc::CreateDetailViewAt3 Method](#)

[IDrawingDoc::ICreateDetailViewAt3 Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreateBlockDefinition Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateBlockDefinition Method (IDrawingDoc)

Obsolete. Superseded by [ISketchManager::MakeSketchBlockFromFile](#), [ISketchManager::MakeSketchBlockSelected](#), and [ISketchManager::MakeSketchBlockFromSketch](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateBlockDefinition( _  
    ByVal Name As System.String, _  
    ByVal XRefFileName As System.String, _  
    ByVal Instance As System.Boolean, _  
    ByVal SegmentCount As System.Integer, _  
    ByRef Segments As SketchSegment, _  
    ByVal PointCount As System.Integer, _  
    ByRef Points As SketchPoint, _  
    ByVal NoteCount As System.Integer, _  
    ByRef Notes As Note, _  
    ByVal DimensionCount As System.Integer, _  
    ByRef Dimensions As DisplayDimension, _  
    ByVal BlockCount As System.Integer, _  
    ByRef Blocks As BlockInstance _  
) As BlockDefinition
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Name As System.String  
Dim XRefFileName As System.String  
Dim Instance As System.Boolean  
Dim SegmentCount As System.Integer  
Dim Segments As SketchSegment  
Dim PointCount As System.Integer  
Dim Points As SketchPoint  
Dim NoteCount As System.Integer  
Dim Notes As Note  
Dim DimensionCount As System.Integer
```

```

Dim Dimensions As DisplayDimension
Dim BlockCount As System.Integer
Dim Blocks As BlockInstance
Dim value As BlockDefinition

```

```

value = instance.ICreateBlockDefinition(Name, XRefFileName, Instance, SegmentCount, Segments,
PointCount, Points, NoteCount, Notes, DimensionCount, Dimensions, BlockCount, Blocks)

```

C#

```

BlockDefinition ICreateBlockDefinition(
    System.string Name,
    System.string XRefFileName,
    System.bool Instance,
    System.int SegmentCount,
    ref SketchSegment Segments,
    System.int PointCount,
    ref SketchPoint Points,
    System.int NoteCount,
    ref Note Notes,
    System.int DimensionCount,
    ref DisplayDimension Dimensions,
    System.int BlockCount,
    ref BlockInstance Blocks
)

```

C++/CLI

```

BlockDefinition^ ICreateBlockDefinition(
    & System.String^ Name,
    & System.String^ XRefFileName,
    & System.bool Instance,
    & System.int SegmentCount,
    & SketchSegment^% Segments,
    & System.int PointCount,
    & SketchPoint^% Points,
    & System.int NoteCount,
    & Note^% Notes,
    & System.int DimensionCount,
    & DisplayDimension^% Dimensions,
    & System.int BlockCount,
    & BlockInstance^% Blocks
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

XRefFileName

Instance

SegmentCount

Segments

PointCount

Points

NoteCount

Notes

DimensionCount

Dimensions

BlockCount

Blocks

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ICreateBlockDefinition](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateCompoundNote Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateCompoundNote Method (IDrawingDoc)

Obsolete for documents created in SOLIDWORKS 2016 and later. Creates and returns a compound note.

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateCompoundNote(  
    ByVal Height As System.Double, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As Note
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Height As System.Double  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As Note  
  
value = instance.ICreateCompoundNote(Height, X, Y, Z)
```

C#

```
Note ICreateCompoundNote(  
    System.double Height,  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
Note^ ICreateCompoundNote(  
& System.double Height,  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Height
Note height in meters
X
x location of note in meters
Y
y location of note in meters
Z
z location of note in meters

Return Value

Pointer to the newly created compound [note](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ICreateCompoundNote](#).

Remarks

A compound note is a note that can contain multiple text strings and sketch geometry.

Compound notes are equivalent to a user-defined symbol. After creating a compound note, you can use the other compound note methods to add text and sketch geometry to the object.

This object appears to the end-user as though it were one item. If the user selects the compound note and drags it, all of the entities and text move together.

Because a compound note can have multiple pieces of text, many of the compound note methods require that you specify the index value of the text. For example, the first piece of text added to the compound note using [INote::AddText](#) has index number 1, the second text added has index number 2, and so on.

SOLIDWORKS adds the note to the view of the current selection, so you must make a selection before you call this method.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::CreateCompoundNote Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreateCustomSymbol Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateCustomSymbol Method (IDrawingDoc)

Obsolete. Superseded by [ISketchManager::MakeSketchBlockFromFile](#), [ISketchManager::MakeSketchBlockSelected](#), and [ISketchManager::MakeSketchBlockFromSketch](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateCustomSymbol( _  
    ByVal SegmentCount As System.Integer, _  
    ByRef Segments As SketchSegment, _  
    ByVal PointCount As System.Integer, _  
    ByRef Points As SketchPoint, _  
    ByVal NoteCount As System.Integer, _  
    ByRef Notes As Note _  
) As CustomSymbol
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim SegmentCount As System.Integer  
Dim Segments As SketchSegment  
Dim PointCount As System.Integer  
Dim Points As SketchPoint  
Dim NoteCount As System.Integer  
Dim Notes As Note  
Dim value As CustomSymbol
```

```
value = instance.ICreateCustomSymbol(SegmentCount, Segments, PointCount, Points, NoteCount, Notes)
```

C#

```
CustomSymbol ICreateCustomSymbol(  
    System.int SegmentCount,  
    ref SketchSegment Segments,  
    System.int PointCount,  
    ref SketchPoint Points,  
    System.int NoteCount,  
    ref Note Notes  
)
```

C++/CLI

```
CustomSymbol^ ICreateCustomSymbol(  
& System.int SegmentCount,
```

```
& SketchSegment^% Segments,  
& System.int PointCount,  
& SketchPoint^% Points,  
& System.int NoteCount,  
& Note^% Notes  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SegmentCount

Segments

PointCount

Points

NoteCount

Notes

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ICreateCustomSymbol](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreateDetailViewAt3 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateDetailViewAt3 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::CreateDetailViewAt4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateDetailViewAt3( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double, _  
    ByVal Style As System.Integer, _  
    ByVal Scale1 As System.Double, _  
    ByVal Scale2 As System.Double, _  
    ByVal LabelIn As System.String, _  
    ByVal Showtype As System.Integer, _  
    ByVal FullOutline As System.Boolean _  
) As View
```

Visual Basic (Usage)

```
Dim instance As IDrawingDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim Style As System.Integer  
Dim Scale1 As System.Double  
Dim Scale2 As System.Double  
Dim LabelIn As System.String  
Dim Showtype As System.Integer  
Dim FullOutline As System.Boolean  
Dim value As View
```

```
value = instance.ICreateDetailViewAt3(X, Y, Z, Style, Scale1, Scale2, LabelIn, Showtype,  
FullOutline)
```



C#

```
View ICreateDetailViewAt3(  
    System.double X,  
    System.double Y,  
    System.double Z,  
    System.int Style,  
    System.double Scale1,  
    System.double Scale2,  
    System.string LabelIn,  
    System.int Showtype,  
    System.bool FullOutline  
)
```

C++/CLI

```
View^ ICreateDetailViewAt3(  
& System.double X,  
& System.double Y,  
& System.double Z,  
& System.int Style,  
& System.double Scale1,  
& System.double Scale2,  
& System.String^ LabelIn,  
& System.int Showtype,  
& System.bool FullOutline  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

X position for the detail view

Y

Y position for the detail view

Z

Z position for the detail view

Style

Style for the detail view as defined in [swDetViewStyle_e](#)

Scale1

Scale numerator

Scale2

Scale denominator

LabelIn

String for the detail view label

Showtype

Type of sketch as defined in [swDetCircleShowType_e](#)

FullOutline

True shows the full outline of the detail view, false does not

Return Value

Pointer to the newly created detail [view](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ICreateDetailViewAt3](#).

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

[IDrawingDoc::CreateDetailViewAt3 Method](#)

[IDrawingDoc::Create1stAngleViews2 Method](#)

[IDrawingDoc::Create3rdAngleViews2 Method](#)

[IDrawingDoc::CreateDrawViewFromModelView3 Method](#)

[IDrawingDoc::CreateFlatPatternViewFromModelView2 Method](#)

[IDrawingDoc::CreateRelativeView Method](#)

[IDrawingDoc::CreateSectionView Method](#)

[IDrawingDoc::CreateSectionViewAt4 Method](#)

[IDrawingDoc::CreateUnfoldedViewAt3 Method](#)

[IDrawingDoc::CreateViewport3 Method](#)

[IDrawingDoc::ICreateAuxiliaryViewAt2 Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateDiamDim Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateDiamDim Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::ICreateDiamDim4](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ICreateDiamDim( _  
    ByVal DimValue As System.Double, _  
    ByRef P0 As System.Double, _  
    ByRef P1 As System.Double, _  
    ByRef P2 As System.Double, _  
    ByRef P3 As System.Double, _  
    ByVal ArrowSize As System.Double, _  
    ByVal Text As System.String, _  
    ByVal TextHeight As System.Double, _  
    ByVal WitnessGap As System.Double, _  
    ByVal WitnessOvershoot As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim DimValue As System.Double  
Dim P0 As System.Double  
Dim P1 As System.Double  
Dim P2 As System.Double  
Dim P3 As System.Double  
Dim ArrowSize As System.Double  
Dim Text As System.String  
Dim TextHeight As System.Double  
Dim WitnessGap As System.Double  
Dim WitnessOvershoot As System.Double
```

```
instance.ICreateDiamDim(DimValue, P0, P1, P2, P3, ArrowSize, Text, TextHeight, WitnessGap,  
WitnessOvershoot)
```

C#

```
void ICreateDiamDim(  
    System.double DimValue,  
    ref System.double P0,  
    ref System.double P1,  
    ref System.double P2,  
    ref System.double P3,  
    System.double ArrowSize,  
    System.string Text,  
    System.double TextHeight,  
    System.double WitnessGap,  
    System.double WitnessOvershoot  
)
```

C++/CLI

```
void ICreateDiamDim(  
& System.double DimValue,  
& System.double% P0,  
& System.double% P1,
```

```

& System.double% P2,
& System.double% P3,
& System.double ArrowSize,
& System.String^ Text,
& System.double TextHeight,
& System.double WitnessGap,
& System.double WitnessOvershoot
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DimValue

P0

P1

P2

P3

ArrowSize

Text

TextHeight

WitnessGap

WitnessOvershoot

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ICreateDiamDim](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateDiamDim2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateDiamDim2 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::ICreateDiamDim4](#).

.NET Syntax

Visual Basic (Declaration)

```

Sub ICreateDiamDim2( _
    ByVal DimValue As System.Double, _
    ByRef P0 As System.Double, _
    ByRef P1 As System.Double, _
    ByRef P2 As System.Double, _
    ByRef P3 As System.Double, _
    ByVal ArrowSize As System.Double, _
    ByVal Text As System.String, _
    ByVal TextHeight As System.Double, _
    ByVal WitnessGap As System.Double, _
    ByVal WitnessOvershoot As System.Double, _
    ByRef TextPoint As System.Double _
)

```

Visual Basic (Usage)

```

Dim instance As IDrawingDoc
Dim DimValue As System.Double
Dim P0 As System.Double
Dim P1 As System.Double
Dim P2 As System.Double

```



```

Dim P3 As System.Double
Dim ArrowSize As System.Double
Dim Text As System.String
Dim TextHeight As System.Double
Dim WitnessGap As System.Double
Dim WitnessOvershoot As System.Double
Dim TextPoint As System.Double

```

```

instance.ICreateDiamDim2(DimValue, P0, P1, P2, P3, ArrowSize, Text, TextHeight, WitnessGap,
WitnessOvershoot, TextPoint)

```

C#

```

void ICreateDiamDim2(
    System.double DimValue,
    ref System.double P0,
    ref System.double P1,
    ref System.double P2,
    ref System.double P3,
    System.double ArrowSize,
    System.string Text,
    System.double TextHeight,
    System.double WitnessGap,
    System.double WitnessOvershoot,
    ref System.double TextPoint
)

```

C++/CLI

```

void ICreateDiamDim2(
    & System.double DimValue,
    & System.double% P0,
    & System.double% P1,
    & System.double% P2,
    & System.double% P3,
    & System.double ArrowSize,
    & System.String^ Text,
    & System.double TextHeight,
    & System.double WitnessGap,
    & System.double WitnessOvershoot,
    & System.double% TextPoint
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DimValue

P0

P1

P2

P3

ArrowSize

Text

TextHeight

WitnessGap

WitnessOvershoot

TextPoint

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::!CreateDiamDim2](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

ICreateDiamDim3 Method (IDrawingDoc)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateDiamDim3 Method (IDrawingDoc)**Obsolete.** Superseded by [IDrawingDoc::ICreateDiamDim4](#).

.NET Syntax

Visual Basic (Declaration)

```

Function ICreateDiamDim3( _
    ByVal DimValue As System.Double, _
    ByRef P0 As System.Double, _
    ByRef P1 As System.Double, _
    ByRef P2 As System.Double, _
    ByRef P3 As System.Double, _
    ByVal ArrowSize As System.Double, _
    ByVal Text As System.String, _
    ByVal TextHeight As System.Double, _
    ByVal WitnessGap As System.Double, _
    ByVal WitnessOvershoot As System.Double, _
    ByRef TextPoint As System.Double _
) As DisplayDimension

```

Visual Basic (Usage)



```

Dim instance As IDrawingDoc
Dim DimValue As System.Double
Dim P0 As System.Double
Dim P1 As System.Double
Dim P2 As System.Double
Dim P3 As System.Double
Dim ArrowSize As System.Double
Dim Text As System.String
Dim TextHeight As System.Double
Dim WitnessGap As System.Double
Dim WitnessOvershoot As System.Double
Dim TextPoint As System.Double
Dim value As DisplayDimension

```

```

value = instance.ICreateDiamDim3(DimValue, P0, P1, P2, P3, ArrowSize, Text, TextHeight,
WitnessGap, WitnessOvershoot, TextPoint)

```

C#

```

DisplayDimension ICreateDiamDim3(
    System.double DimValue,
    ref System.double P0,
    ref System.double P1,
    ref System.double P2,
    ref System.double P3,
    System.double ArrowSize,
    System.string Text,
    System.double TextHeight,
    System.double WitnessGap,
    System.double WitnessOvershoot,
    ref System.double TextPoint
)

```

C++/CLI

```

DisplayDimension^ ICreateDiamDim3(
    & System.double DimValue,
    & System.double% P0,
    & System.double% P1,
    & System.double% P2,
    & System.double% P3,
    & System.double ArrowSize,

```

```

& System.String^ Text,
& System.double TextHeight,
& System.double WitnessGap,
& System.double WitnessOvershoot,
& System.double% TextPoint
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DimValue

P0

P1

P2

P3

ArrowSize

Text

TextHeight

WitnessGap

WitnessOvershoot

TextPoint

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ICreateDiamDim3](#).

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreateDiamDim4 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateDiamDim4 Method (IDrawingDoc)

Creates a non-associative diameter dimension.

.NET Syntax

Visual Basic (Declaration)

```

Function ICreateDiamDim4(
    ByRef P0 As System.Double, _
    ByRef P1 As System.Double, _
    ByRef P2 As System.Double, _
    ByRef P3 As System.Double, _
    ByRef TextPoint As System.Double, _
    ByVal Val As System.Double, _
    ByVal TextHeight As System.Double _
) As DisplayDimension

```

Visual Basic (Usage)

```

Dim instance As IDrawingDoc
Dim P0 As System.Double
Dim P1 As System.Double
Dim P2 As System.Double
Dim P3 As System.Double
Dim TextPoint As System.Double
Dim Val As System.Double
Dim TextHeight As System.Double
Dim value As DisplayDimension

```



```
value = instance.ICreateDiamDim4(P0, P1, P2, P3, TextPoint, Val, TextHeight)
```

C#

```
DisplayDimension ICreateDiamDim4(  
    ref System.double P0,  
    ref System.double P1,  
    ref System.double P2,  
    ref System.double P3,  
    ref System.double TextPoint,  
    System.double Val,  
    System.double TextHeight  
)
```

C++/CLI

```
DisplayDimension^ ICreateDiamDim4(  
& System.double% P0,  
& System.double% P1,  
& System.double% P2,  
& System.double% P3,  
& System.double% TextPoint,  
& System.double Val,  
& System.double TextHeight  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P0

Pointer to an array of 3 doubles (x,y,z); location of dimension point

P1

Pointer to an array of 3 doubles (x,y,z); nearest point on circle

P2

Pointer to an array of 3 doubles (x,y,z); farthest point on circle diametrically opposite to P1

P3

Pointer to an array of 3 doubles (x,y,z); plane normal

TextPoint

Pointer to an array of 3 doubles (x,y,z); position of text

Val

Dimension value in meters

TextHeight

Text height in meters

Return Value

Pointer to the new [IDisplayDimension](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ICreateDiamDim4](#).

Remarks

SOLIDWORKS creates this type of dimension between the two points you specify. It has no relation to your geometry.

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

[IDrawingDoc::CreateLinearDim4 Method](#)

[IDrawingDoc::CreateDiamDim4 Method](#)

[IDrawingDoc::CreateOrdinateDim4 Method](#)

[IDrawingDoc::ICreateDiamDim4 Method](#)

[IDrawingDoc::ICreateLinearDim4 Method](#)

[IDrawingDoc::ICreateOrdinateDim4 Method](#)

[IDrawingDoc::ICreateAngDim4 Method](#)

[IDrawingDoc::CreateAngDim4 Method](#)

Availability

ICreateLinearDim Method (IDrawingDoc)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateLinearDim Method (IDrawingDoc)Obsolete. Superseded by [IDrawingDoc::ICreateLinearDim4](#). .NET Syntax

Visual Basic (Declaration)

```

Sub ICreateLinearDim( _
    ByRef P0 As System.Double, _
    ByRef P1 As System.Double, _
    ByRef P2 As System.Double, _
    ByRef P3 As System.Double, _
    ByRef P4 As System.Double, _
    ByVal Angle As System.Double, _
    ByVal ArrowSize As System.Double, _
    ByVal Text As System.String, _
    ByVal TextHeight As System.Double, _
    ByVal WitnessGap As System.Double, _
    ByVal WitnessOvershoot As System.Double _
)

```

Visual Basic (Usage)



```

Dim instance As IDrawingDoc
Dim P0 As System.Double
Dim P1 As System.Double
Dim P2 As System.Double
Dim P3 As System.Double
Dim P4 As System.Double
Dim Angle As System.Double
Dim ArrowSize As System.Double
Dim Text As System.String
Dim TextHeight As System.Double
Dim WitnessGap As System.Double
Dim WitnessOvershoot As System.Double

```

```

instance.ICreateLinearDim(P0, P1, P2, P3, P4, Angle, ArrowSize, Text, TextHeight, WitnessGap,
WitnessOvershoot)

```

C#

```

void ICreateLinearDim(
    ref System.double P0,
    ref System.double P1,
    ref System.double P2,
    ref System.double P3,
    ref System.double P4,
    System.double Angle,
    System.double ArrowSize,
    System.string Text,
    System.double TextHeight,
    System.double WitnessGap,
    System.double WitnessOvershoot
)

```

C++/CLI

```

void ICreateLinearDim(
    & System.double% P0,
    & System.double% P1,
    & System.double% P2,
    & System.double% P3,
    & System.double% P4,

```

```

& System.double Angle,
& System.double ArrowSize,
& System.String^ Text,
& System.double TextHeight,
& System.double WitnessGap,
& System.double WitnessOvershoot
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P0

P1

P2

P3

P4

Angle

ArrowSize

Text

TextHeight

WitnessGap

WitnessOvershoot

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ICreateLinearDim](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreateLinearDim2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateLinearDim2 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::ICreateLinearDim4](#).

.NET Syntax

Visual Basic (Declaration)

```

Sub ICreateLinearDim2( _
    ByRef P0 As System.Double, _
    ByRef P1 As System.Double, _
    ByRef P2 As System.Double, _
    ByRef P3 As System.Double, _
    ByRef P4 As System.Double, _
    ByVal Val As System.Double, _
    ByVal PrimPrec As System.Integer, _
    ByVal Text As System.String, _
    ByRef TextPoint As System.Double, _
    ByVal Angle As System.Double, _
    ByVal TextHeight As System.Double, _
    ByVal Prefix As System.String, _
    ByVal Suffix As System.String, _
    ByVal Callout1 As System.String, _
    ByVal Callout2 As System.String, _
    ByVal TolType As System.Integer, _
    ByVal TolMin As System.String, _
    ByVal TolMax As System.String, _
    ByVal TolPrec As System.Integer, _
    ByVal ArrowSize As System.Double, _
    ByVal ArrowStyle As System.Integer, _

```

```

ByVal ArrowDir As System.Integer, _
ByVal WitnessGap As System.Double, _
ByVal WitnessOvershoot As System.Double, _
ByVal DualDisplay As System.Boolean, _
ByVal DualPrecision As System.Integer _
)

```

Visual Basic (Usage)



```

Dim instance As IDrawingDoc
Dim P0 As System.Double
Dim P1 As System.Double
Dim P2 As System.Double
Dim P3 As System.Double
Dim P4 As System.Double
Dim Val As System.Double
Dim PrimPrec As System.Integer
Dim Text As System.String
Dim TextPoint As System.Double
Dim Angle As System.Double
Dim TextHeight As System.Double
Dim Prefix As System.String
Dim Suffix As System.String
Dim Callout1 As System.String
Dim Callout2 As System.String
Dim TolType As System.Integer
Dim TolMin As System.String
Dim TolMax As System.String
Dim TolPrec As System.Integer
Dim ArrowSize As System.Double
Dim ArrowStyle As System.Integer
Dim ArrowDir As System.Integer
Dim WitnessGap As System.Double
Dim WitnessOvershoot As System.Double
Dim DualDisplay As System.Boolean
Dim DualPrecision As System.Integer

```

```

instance.ICreateLinearDim2(P0, P1, P2, P3, P4, Val, PrimPrec, Text, TextPoint, Angle, TextHeight,
Prefix, Suffix, Callout1, Callout2, TolType, TolMin, TolMax, TolPrec, ArrowSize, ArrowStyle,
ArrowDir, WitnessGap, WitnessOvershoot, DualDisplay, DualPrecision)

```

C#

```

void ICreateLinearDim2(
    ref System.double P0,
    ref System.double P1,
    ref System.double P2,
    ref System.double P3,
    ref System.double P4,
    System.double Val,
    System.int PrimPrec,
    System.string Text,
    ref System.double TextPoint,
    System.double Angle,
    System.double TextHeight,
    System.string Prefix,
    System.string Suffix,
    System.string Callout1,
    System.string Callout2,
    System.int TolType,
    System.string TolMin,
    System.string TolMax,
    System.int TolPrec,
    System.double ArrowSize,
    System.int ArrowStyle,
    System.int ArrowDir,
    System.double WitnessGap,
    System.double WitnessOvershoot,
    System.bool DualDisplay,

```

```
        System.int DualPrecision
    )
```

C++/CLI

```
void ICreateLinearDim2(
&    System.double% P0,
&    System.double% P1,
&    System.double% P2,
&    System.double% P3,
&    System.double% P4,
&    System.double Val,
&    System.int PrimPrec,
&    System.String^ Text,
&    System.double% TextPoint,
&    System.double Angle,
&    System.double TextHeight,
&    System.String^ Prefix,
&    System.String^ Suffix,
&    System.String^ Callout1,
&    System.String^ Callout2,
&    System.int TolType,
&    System.String^ TolMin,
&    System.String^ TolMax,
&    System.int TolPrec,
&    System.double ArrowSize,
&    System.int ArrowStyle,
&    System.int ArrowDir,
&    System.double WitnessGap,
&    System.double WitnessOvershoot,
&    System.bool DualDisplay,
&    System.int DualPrecision
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P0

P1

P2

P3

P4

Val

PrimPrec

Text

TextPoint

Angle

TextHeight

Prefix

Suffix

Callout1

Callout2

TolType

TolMin

TolMax

TolPrec

ArrowSize

ArrowStyle

ArrowDir

WitnessGap

WitnessOvershoot

DualDisplay

DualPrecision

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ICreateLinearDim2](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateLinearDim3 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateLinearDim3 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::ICreateLinearDim4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateLinearDim3( _  
    ByRef P0 As System.Double, _  
    ByRef P1 As System.Double, _  
    ByRef P2 As System.Double, _  
    ByRef P3 As System.Double, _  
    ByRef P4 As System.Double, _  
    ByVal Val As System.Double, _  
    ByVal PrimPrec As System.Integer, _  
    ByVal Text As System.String, _  
    ByRef TextPoint As System.Double, _  
    ByVal Angle As System.Double, _  
    ByVal TextHeight As System.Double, _  
    ByVal Prefix As System.String, _  
    ByVal Suffix As System.String, _  
    ByVal Callout1 As System.String, _  
    ByVal Callout2 As System.String, _  
    ByVal TolType As System.Integer, _  
    ByVal TolMin As System.String, _  
    ByVal TolMax As System.String, _  
    ByVal TolPrec As System.Integer, _  
    ByVal ArrowSize As System.Double, _  
    ByVal ArrowStyle As System.Integer, _  
    ByVal ArrowDir As System.Integer, _  
    ByVal WitnessGap As System.Double, _  
    ByVal WitnessOvershoot As System.Double, _  
    ByVal DualDisplay As System.Boolean, _  
    ByVal DualPrecision As System.Integer _  
) As DisplayDimension
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim P0 As System.Double  
Dim P1 As System.Double  
Dim P2 As System.Double  
Dim P3 As System.Double  
Dim P4 As System.Double  
Dim Val As System.Double  
Dim PrimPrec As System.Integer  
Dim Text As System.String  
Dim TextPoint As System.Double  
Dim Angle As System.Double  
Dim TextHeight As System.Double  
Dim Prefix As System.String  
Dim Suffix As System.String
```

```

Dim Callout1 As System.String
Dim Callout2 As System.String
Dim TolType As System.Integer
Dim TolMin As System.String
Dim TolMax As System.String
Dim TolPrec As System.Integer
Dim ArrowSize As System.Double
Dim ArrowStyle As System.Integer
Dim ArrowDir As System.Integer
Dim WitnessGap As System.Double
Dim WitnessOvershoot As System.Double
Dim DualDisplay As System.Boolean
Dim DualPrecision As System.Integer
Dim value As DisplayDimension

```

```

value = instance.ICreateLinearDim3(P0, P1, P2, P3, P4, Val, PrimPrec, Text, TextPoint, Angle,
TextHeight, Prefix, Suffix, Callout1, Callout2, TolType, TolMin, TolMax, TolPrec, ArrowSize,
ArrowStyle, ArrowDir, WitnessGap, WitnessOvershoot, DualDisplay, DualPrecision)

```

C#

```

DisplayDimension ICreateLinearDim3(
    ref System.double P0,
    ref System.double P1,
    ref System.double P2,
    ref System.double P3,
    ref System.double P4,
    System.double Val,
    System.int PrimPrec,
    System.string Text,
    ref System.double TextPoint,
    System.double Angle,
    System.double TextHeight,
    System.string Prefix,
    System.string Suffix,
    System.string Callout1,
    System.string Callout2,
    System.int TolType,
    System.string TolMin,
    System.string TolMax,
    System.int TolPrec,
    System.double ArrowSize,
    System.int ArrowStyle,
    System.int ArrowDir,
    System.double WitnessGap,
    System.double WitnessOvershoot,
    System.bool DualDisplay,
    System.int DualPrecision
)

```

C++/CLI

```

DisplayDimension^ ICreateLinearDim3(
    & System.double% P0,
    & System.double% P1,
    & System.double% P2,
    & System.double% P3,
    & System.double% P4,
    & System.double Val,
    & System.int PrimPrec,
    & System.String^ Text,
    & System.double% TextPoint,
    & System.double Angle,
    & System.double TextHeight,
    & System.String^ Prefix,
    & System.String^ Suffix,
    & System.String^ Callout1,
    & System.String^ Callout2,
    & System.int TolType,
    & System.String^ TolMin,

```

```
& System.String^ TolMax,  
& System.int TolPrec,  
& System.double ArrowSize,  
& System.int ArrowStyle,  
& System.int ArrowDir,  
& System.double WitnessGap,  
& System.double WitnessOvershoot,  
& System.bool DualDisplay,  
& System.int DualPrecision  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P0

P1

P2

P3

P4

Val

PrimPrec

Text

TextPoint

Angle

TextHeight

Prefix

Suffix

Callout1

Callout2

TolType

TolMin

TolMax

TolPrec

ArrowSize

ArrowStyle

ArrowDir

WitnessGap

WitnessOvershoot

DualDisplay

DualPrecision

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ICreateLinearDim3](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreateLinearDim4 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateLinearDim4 Method (IDrawingDoc)

Creates a non-associative linear dimension.

.NET Syntax

Visual Basic (Declaration)

```

Function ICreateLinearDim4( _
    ByRef P0 As System.Double, _
    ByRef P1 As System.Double, _
    ByRef P2 As System.Double, _
    ByRef P3 As System.Double, _
    ByRef P4 As System.Double, _
    ByRef TextPoint As System.Double, _
    ByVal Val As System.Double, _
    ByVal Angle As System.Double, _
    ByVal TextHeight As System.Double _
) As DisplayDimension

```

Visual Basic (Usage)



```

Dim instance As IDrawingDoc
Dim P0 As System.Double
Dim P1 As System.Double
Dim P2 As System.Double
Dim P3 As System.Double
Dim P4 As System.Double
Dim TextPoint As System.Double
Dim Val As System.Double
Dim Angle As System.Double
Dim TextHeight As System.Double
Dim value As DisplayDimension

```

```
value = instance.ICreateLinearDim4(P0, P1, P2, P3, P4, TextPoint, Val, Angle, TextHeight)
```

C#

```

DisplayDimension ICreateLinearDim4(
    ref System.double P0,
    ref System.double P1,
    ref System.double P2,
    ref System.double P3,
    ref System.double P4,
    ref System.double TextPoint,
    System.double Val,
    System.double Angle,
    System.double TextHeight
)

```

C++/CLI

```

DisplayDimension^ ICreateLinearDim4(
    & System.double% P0,
    & System.double% P1,
    & System.double% P2,
    & System.double% P3,
    & System.double% P4,
    & System.double% TextPoint,
    & System.double Val,
    & System.double Angle,
    & System.double TextHeight
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P0

Pointer to an array of 3 doubles (x,y,z), dimension point

P1

Pointer to an array of 3 doubles (x,y,z), dimension end

P2

Pointer to an array of 3 doubles (x,y,z), normal to the plane of sketch

P3

Pointer to an array of 3 doubles (x,y,z), extension line 1 reference point

P4

Pointer to an array of 3 doubles (x,y,z), extension line 2 reference point

TextPoint

Pointer to an array of 3 doubles (x,y,z), position of text

Val

Value for the non-associative linear dimension

Angle

Inclination angle of the text in radians

TextHeight

Text height in meters

Return Value

Pointer to [IDisplayDimension](#) object

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::!CreateLinearDim4](#).

Remarks

SOLIDWORKS creates this type of dimension between the two points you specify. It has no relation to your geometry.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::CreateAngDim4 Method](#)
[IDrawingDoc::CreateDetailViewAt3 Method](#)
[IDrawingDoc::CreateDiamDim4 Method](#)
[IDrawingDoc::CreateLinearDim4 Method](#)
[IDrawingDoc::CreateOrdinateDim4 Method](#)
[IDrawingDoc::!CreateAngDim4 Method](#)
[IDrawingDoc::!CreateDiamDim4 Method](#)
[IDrawingDoc::!CreateOrdinateDim4 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreateOrdinateDim Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateOrdinateDim Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::!CreateOrdinateDim4](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ICreateOrdinateDim( _  
    ByRef P0 As System.Double, _  
    ByRef P1 As System.Double, _  
    ByRef P2 As System.Double, _  
    ByRef P3 As System.Double, _  
    ByRef P4 As System.Double, _  
    ByVal Angle As System.Double, _  
    ByVal ArrowSize As System.Double, _  
    ByVal Text As System.String, _  
    ByVal TextHeight As System.Double, _  
    ByVal WitnessGap As System.Double, _  
    ByVal WitnessOvershoot As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim P0 As System.Double  
Dim P1 As System.Double  
Dim P2 As System.Double  
Dim P3 As System.Double  
Dim P4 As System.Double
```

```

Dim Angle As System.Double
Dim ArrowSize As System.Double
Dim Text As System.String
Dim TextHeight As System.Double
Dim WitnessGap As System.Double
Dim WitnessOvershoot As System.Double

```

```

instance.ICreateOrdinateDim(P0, P1, P2, P3, P4, Angle, ArrowSize, Text, TextHeight, WitnessGap,
WitnessOvershoot)

```

C#

```

void ICreateOrdinateDim(
    ref System.double P0,
    ref System.double P1,
    ref System.double P2,
    ref System.double P3,
    ref System.double P4,
    System.double Angle,
    System.double ArrowSize,
    System.string Text,
    System.double TextHeight,
    System.double WitnessGap,
    System.double WitnessOvershoot
)

```

C++/CLI

```

void ICreateOrdinateDim(
    & System.double% P0,
    & System.double% P1,
    & System.double% P2,
    & System.double% P3,
    & System.double% P4,
    & System.double Angle,
    & System.double ArrowSize,
    & System.String^ Text,
    & System.double TextHeight,
    & System.double WitnessGap,
    & System.double WitnessOvershoot
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P0

P1

P2

P3

P4

Angle

ArrowSize

Text

TextHeight

WitnessGap

WitnessOvershoot

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ICreateOrdinateDim](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

ICreateOrdinateDim2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateOrdinateDim2 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::ICreateOrdinateDim4](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ICreateOrdinateDim2( _
    ByRef P0 As System.Double, _
    ByRef P1 As System.Double, _
    ByRef P2 As System.Double, _
    ByRef P3 As System.Double, _
    ByRef P4 As System.Double, _
    ByVal Angle As System.Double, _
    ByVal ArrowSize As System.Double, _
    ByVal Text As System.String, _
    ByVal TextHeight As System.Double, _
    ByVal WitnessGap As System.Double, _
    ByVal WitnessOvershoot As System.Double, _
    ByRef P5 As System.Double _
)
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim P0 As System.Double
Dim P1 As System.Double
Dim P2 As System.Double
Dim P3 As System.Double
Dim P4 As System.Double
Dim Angle As System.Double
Dim ArrowSize As System.Double
Dim Text As System.String
Dim TextHeight As System.Double
Dim WitnessGap As System.Double
Dim WitnessOvershoot As System.Double
Dim P5 As System.Double
```

```
instance.ICreateOrdinateDim2(P0, P1, P2, P3, P4, Angle, ArrowSize, Text, TextHeight, WitnessGap,
WitnessOvershoot, P5)
```

C#

```
void ICreateOrdinateDim2(
    ref System.double P0,
    ref System.double P1,
    ref System.double P2,
    ref System.double P3,
    ref System.double P4,
    System.double Angle,
    System.double ArrowSize,
    System.string Text,
    System.double TextHeight,
    System.double WitnessGap,
    System.double WitnessOvershoot,
    ref System.double P5
)
```

C++/CLI

```
void ICreateOrdinateDim2(
    & System.double% P0,
    & System.double% P1,
    & System.double% P2,
    & System.double% P3,
```

```

& System.double% P4,
& System.double Angle,
& System.double ArrowSize,
& System.String^ Text,
& System.double TextHeight,
& System.double WitnessGap,
& System.double WitnessOvershoot,
& System.double% P5
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P0

P1

P2

P3

P4

Angle

ArrowSize

Text

TextHeight

WitnessGap

WitnessOvershoot

P5

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::!CreateOrdinateDim2](#).

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateOrdinateDim3 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateOrdinateDim3 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::!CreateOrdinateDim4](#).

.NET Syntax

Visual Basic (Declaration)

```

Function ICreateOrdinateDim3( _
    ByRef P0 As System.Double, _
    ByRef P1 As System.Double, _
    ByRef P2 As System.Double, _
    ByRef P3 As System.Double, _
    ByRef P4 As System.Double, _
    ByVal Angle As System.Double, _
    ByVal ArrowSize As System.Double, _
    ByVal Text As System.String, _
    ByVal TextHeight As System.Double, _
    ByVal WitnessGap As System.Double, _
    ByVal WitnessOvershoot As System.Double, _
    ByRef P5 As System.Double _
) As DisplayDimension

```

Visual Basic (Usage)



```

Dim instance As IDrawingDoc
Dim P0 As System.Double
Dim P1 As System.Double
Dim P2 As System.Double
Dim P3 As System.Double
Dim P4 As System.Double
Dim Angle As System.Double
Dim ArrowSize As System.Double
Dim Text As System.String
Dim TextHeight As System.Double
Dim WitnessGap As System.Double
Dim WitnessOvershoot As System.Double
Dim P5 As System.Double
Dim value As DisplayDimension

```

```

value = instance.ICreateOrdinateDim3(P0, P1, P2, P3, P4, Angle, ArrowSize, Text, TextHeight,
WitnessGap, WitnessOvershoot, P5)

```

C#

```

DisplayDimension ICreateOrdinateDim3(
    ref System.double P0,
    ref System.double P1,
    ref System.double P2,
    ref System.double P3,
    ref System.double P4,
    System.double Angle,
    System.double ArrowSize,
    System.string Text,
    System.double TextHeight,
    System.double WitnessGap,
    System.double WitnessOvershoot,
    ref System.double P5
)

```

C++/CLI

```

DisplayDimension^ ICreateOrdinateDim3(
    & System.double% P0,
    & System.double% P1,
    & System.double% P2,
    & System.double% P3,
    & System.double% P4,
    & System.double Angle,
    & System.double ArrowSize,
    & System.String^ Text,
    & System.double TextHeight,
    & System.double WitnessGap,
    & System.double WitnessOvershoot,
    & System.double% P5
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P0

P1

P2

P3

P4

Angle

ArrowSize

Text

TextHeight

WitnessGap

WitnessOvershoot

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ICreateOrdinateDim3](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateOrdinateDim4 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateOrdinateDim4 Method (IDrawingDoc)

Creates a non-associative ordinate dimension.

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateOrdinateDim4( _
    ByRef P0 As System.Double, _
    ByRef P1 As System.Double, _
    ByRef P2 As System.Double, _
    ByRef P3 As System.Double, _
    ByRef P4 As System.Double, _
    ByRef P5 As System.Double, _
    ByVal Val As System.Double, _
    ByVal Angle As System.Double, _
    ByVal TextHeight As System.Double _
) As DisplayDimension
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim P0 As System.Double
Dim P1 As System.Double
Dim P2 As System.Double
Dim P3 As System.Double
Dim P4 As System.Double
Dim P5 As System.Double
Dim Val As System.Double
Dim Angle As System.Double
Dim TextHeight As System.Double
Dim value As DisplayDimension
```

```
value = instance.ICreateOrdinateDim4(P0, P1, P2, P3, P4, P5, Val, Angle, TextHeight)
```

C#

```
DisplayDimension ICreateOrdinateDim4(
    ref System.double P0,
    ref System.double P1,
    ref System.double P2,
    ref System.double P3,
    ref System.double P4,
    ref System.double P5,
    System.double Val,
    System.double Angle,
    System.double TextHeight
)
```

C++/CLI

```

DisplayDimension^ ICreateOrdinateDim4(
& System.double% P0,
& System.double% P1,
& System.double% P2,
& System.double% P3,
& System.double% P4,
& System.double% P5,
& System.double Val,
& System.double Angle,
& System.double TextHeight
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

P0

Pointer to an array of 3 doubles (x,y,z); dimension point

P1

Pointer to an array of 3 doubles (x,y,z); unit vector that specifies the direction of the ordinate dimension

P2

Pointer to an array of 3 doubles (x,y,z); extension line start point

P3

Pointer to an array of 3 doubles (x,y,z); extension line end point

P4

Pointer to an array of 3 doubles (x,y,z); unit vector and specifies the orientation of the text; for example, (1, 0, 0) results in horizontal text read from left to right

P5

Pointer to an array of 3 doubles (x,y,z); position of text

Val

Value for the ordinate dimension

Angle

Inclination angle of the text in radians (character slant)

TextHeight

Text height in meters

Return Value

[Display dimension](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ICreateOrdinateDim4](#).

Remarks

SOLIDWORKS creates this type of dimension between the two points you specify. It has no relation to your geometry.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::AddOrdinateDimension2 Method](#)
[IDrawingDoc::CreateAngDim4 Method](#)
[IDrawingDoc::CreateDiamDim4 Method](#)
[IDrawingDoc::CreateLinearDim4 Method](#)
[IDrawingDoc::ICreateAngDim4 Method](#)
[IDrawingDoc::ICreateDiamDim4 Method](#)
[IDrawingDoc::ICreateLinearDim4 Method](#)
[IDrawingDoc::CreateOrdinateDim4 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreateSectionViewAt2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateSectionViewAt2 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::ICreateSectionViewAt4](#).

Visual Basic (Declaration)

```
Function ICreateSectionViewAt2( _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double, _
    ByVal NotAligned As System.Boolean, _
    ByVal IsOffsetSection As System.Boolean, _
    ByVal Label As System.String, _
    ByVal Chgdirection As System.Boolean, _
    ByVal Scwithmodel As System.Boolean, _
    ByVal Partial As System.Boolean, _
    ByVal Dispsurfcut As System.Boolean _
) As View
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim NotAligned As System.Boolean
Dim IsOffsetSection As System.Boolean
Dim Label As System.String
Dim Chgdirection As System.Boolean
Dim Scwithmodel As System.Boolean
Dim Partial As System.Boolean
Dim Dispsurfcut As System.Boolean
Dim value As View
```

```
value = instance.ICreateSectionViewAt2(X, Y, Z, NotAligned, IsOffsetSection, Label, Chgdirection,
Scwithmodel, Partial, Dispsurfcut)
```

C#

```
View ICreateSectionViewAt2(
    System.double X,
    System.double Y,
    System.double Z,
    System.bool NotAligned,
    System.bool IsOffsetSection,
    System.string Label,
    System.bool Chgdirection,
    System.bool Scwithmodel,
    System.bool Partial,
    System.bool Dispsurfcut
)
```

C++/CLI

```
View^ ICreateSectionViewAt2(
    & System.double X,
    & System.double Y,
    & System.double Z,
    & System.bool NotAligned,
    & System.bool IsOffsetSection,
    & System.String^ Label,
    & System.bool Chgdirection,
    & System.bool Scwithmodel,
    & System.bool Partial,
    & System.bool Dispsurfcut
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

NotAligned

IsOffsetSection

Label

Chgdirection

Scwithmodel

Partial

Dispsurfcut

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ICreateSectionViewAt2](#).

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateSectionViewAt3 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateSectionViewAt3 Method (IDrawingDoc)

Obsolete. Superseded by [IDrawingDoc::ICreateSectionViewAt4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateSectionViewAt3( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double, _  
    ByVal NotAligned As System.Boolean, _  
    ByVal IsOffsetSection As System.Boolean, _  
    ByVal Label As System.String, _  
    ByVal Chgdirection As System.Boolean, _  
    ByVal Scwithmodel As System.Boolean, _  
    ByVal Partial As System.Boolean, _  
    ByVal Dispsurfcut As System.Boolean, _  
    ByVal NumExcludedComponents As System.Integer, _  
    ByRef PExcludedComponents As System.Object _  
) As View
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim NotAligned As System.Boolean  
Dim IsOffsetSection As System.Boolean  
Dim Label As System.String  
Dim Chgdirection As System.Boolean  
Dim Scwithmodel As System.Boolean  
Dim Partial As System.Boolean  
Dim Dispsurfcut As System.Boolean  
Dim NumExcludedComponents As System.Integer  
Dim PExcludedComponents As System.Object  
Dim value As View
```

```
value = instance.ICreateSectionViewAt3(X, Y, Z, NotAligned, IsOffsetSection, Label, Chgdirection,  
Scwithmodel, Partial, Dispsurfcut, NumExcludedComponents, PExcludedComponents)
```

C#

```
View ICreateSectionViewAt3(  
    System.double X,  
    System.double Y,  
    System.double Z,  
    System.bool NotAligned,  
    System.bool IsOffsetSection,  
    System.string Label,  
    System.bool Chgdirection,  
    System.bool Scwithmodel,  
    System.bool Partial,  
    System.bool Dispsurfcut,  
    System.int NumExcludedComponents,  
    ref System.object PExcludedComponents  
)
```

C++/CLI

```
View^ ICreateSectionViewAt3(  
& System.double X,  
& System.double Y,  
& System.double Z,  
& System.bool NotAligned,  
& System.bool IsOffsetSection,  
& System.String^ Label,  
& System.bool Chgdirection,  
& System.bool Scwithmodel,  
& System.bool Partial,  
& System.bool Dispsurfcut,  
& System.int NumExcludedComponents,  
& System.Object^% PExcludedComponents  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

NotAligned

IsOffsetSection

Label

Chgdirection

Scwithmodel

Partial

Dispsurfcut

NumExcludedComponents

PExcludedComponents

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ICreateSectionViewAt3](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreateSectionViewAt4 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : [ICreateSectionViewAt4 Method \(IDrawingDoc\)](#)

Obsolete. Superseded by [IDrawingDoc::ICreateSectionViewAt5](#).

Visual Basic (Declaration)

```
Function ICreateSectionViewAt4( _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double, _
    ByVal SectionLabel As System.String, _
    ByVal Options As System.Integer, _
    ByVal NumExcludedComponents As System.Integer, _
    ByRef ExcludedComponents As System.Object _
) As View
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim SectionLabel As System.String
Dim Options As System.Integer
Dim NumExcludedComponents As System.Integer
Dim ExcludedComponents As System.Object
Dim value As View
```

```
value = instance.ICreateSectionViewAt4(X, Y, Z, SectionLabel, Options, NumExcludedComponents, ExcludedComponents)
```

C#

```
View ICreateSectionViewAt4(
    System.double X,
    System.double Y,
    System.double Z,
    System.string SectionLabel,
    System.int Options,
    System.int NumExcludedComponents,
    ref System.object ExcludedComponents
)
```

C++/CLI

```
View^ ICreateSectionViewAt4(
    & System.double X,
    & System.double Y,
    & System.double Z,
    & System.String^ SectionLabel,
    & System.int Options,
    & System.int NumExcludedComponents,
    & System.Object^% ExcludedComponents
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X
x position on the drawing sheet for the center of the section view

Y
y position on the drawing sheet for the center of the section view

Z
z position on the drawing sheet for the center of the section view

SectionLabel
Letter for the label for the section view

Options
Options that affect the section view as defined in [swCreateSectionViewAtOptions_e](#)

NumExcludedComponents
Number of components to exclude from the section view

ExcludedComponents
Array of components to exclude from the section view

Return Value

Pointer to the newly created [IView](#) object

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ICreateSectionViewAt4](#).

Remarks

Before calling this method, select the section line or the lines to use as a section line.

This method runs silently; the end-user is not prompted for a label.

Use [IView::IGetSection](#) to get the [IDrSection](#) object, and use [IDrSection::SetLabel2](#) to set the name for the label, which provides a warning if the name is a duplicate and the standard does not accept duplicate names.

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::CreateSectionView Method](#)
[IDrawingDoc::CreateSectionViewAt4 Method](#)
[IDrawingDoc::Create1stAngleViews2 Method](#)
[IDrawingDoc::Create3rdAngleViews2 Method](#)
[IDrawingDoc::CreateAuxiliaryViewAt2 Method](#)
[IDrawingDoc::CreateDetailViewAt3 Method](#)
[IDrawingDoc::CreateDrawViewFromModelView3 Method](#)
[IDrawingDoc::CreateFlatPatternViewFromModelView2 Method](#)
[IDrawingDoc::CreateRelativeView Method](#)
[IDrawingDoc::CreateUnfoldedViewAt3 Method](#)
[IDrawingDoc::CreateViewport3 Method](#)
[IDrawingDoc::ICreateDetailViewAt3 Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreateSectionViewAt5 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateSectionViewAt5 Method (IDrawingDoc)

Creates a section view from the section line up to the specified distance at the specified distance.

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateSectionViewAt5( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double, _  
    ByVal SectionLabel As System.String, _  
    ByVal Options As System.Integer, _  
    ByVal NumExcludedComponents As System.Integer, _  
    ByRef ExcludedComponents As System.Object, _  
    ByVal SectionDepth As System.Double _  
) As View
```

Visual Basic (Usage)

```
Dim instance As IDrawingDoc  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim SectionLabel As System.String  
Dim Options As System.Integer  
Dim NumExcludedComponents As System.Integer  
Dim ExcludedComponents As System.Object  
Dim SectionDepth As System.Double  
Dim value As View
```



```
value = instance.ICreateSectionViewAt5(X, Y, Z, SectionLabel, Options, NumExcludedComponents, ExcludedComponents, SectionDepth)
```

C#

```
View ICreateSectionViewAt5(  
    System.double X,  
    System.double Y,  
    System.double Z,  
    System.string SectionLabel,  
    System.int Options,  
    System.int NumExcludedComponents,  
    ref System.object ExcludedComponents,  
    System.double SectionDepth  
)
```

C++/CLI

```
View^ ICreateSectionViewAt5(  
& System.double X,  
& System.double Y,  
& System.double Z,  
& System.String^ SectionLabel,  
& System.int Options,  
& System.int NumExcludedComponents,  
& System.Object^% ExcludedComponents,  
& System.double SectionDepth  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

x position on the drawing sheet for the center of the section view

Y

y position on the drawing sheet for the center of the section view

Z

z position on the drawing sheet for the center of the section view

SectionLabel

Letter for the label for the section view

Options

Options that affect the section view as defined in [swCreateSectionViewAtOptions_e](#)

NumExcludedComponents

Number of components to exclude from the section view

ExcludedComponents

Array of components to exclude from the section view

SectionDepth

Distance from the section line to create the section view

Return Value

Section [view](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ICreateSectionViewAt5](#).

Remarks

Before calling this method, select the section line or lines to use as a section line.

This method runs silently; the end-user is not prompted for a label.

Use [IView::IGetSection](#) to get the [IDrSection](#) object, and use [IDrSection::SetLabel2](#) to set the name for the label, which provides a warning if the name is a duplicate and the standard does not accept duplicate names.

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

[IDrawingDoc::CreateSectionViewAt5 Method](#)

[IDrawingDoc::CreateSectionView Method](#)

[IDrawingDoc::Create1stAngleViews2 Method](#)

[IDrawingDoc::Create3rdAngleViews2 Method](#)

[IDrawingDoc::CreateAuxiliaryViewAt2 Method](#)

[IDrawingDoc::CreateDetailViewAt3 Method](#)
[IDrawingDoc::CreateDrawViewFromModelView3 Method](#)
[IDrawingDoc::CreateFlatPatternViewFromModelView3 Method](#)
[IDrawingDoc::CreateRelativeView Method](#)
[IDrawingDoc::CreateUnfoldedViewAt3 Method](#)
[IDrawingDoc::CreateViewport3 Method](#)
[IDrawingDoc::ICreateAuxiliaryViewAt2 Method](#)
[IDrawingDoc::ICreateDetailViewAt3 Method](#)
[IDrSection Interface](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreateText2 Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : ICreateText2 Method (IDrawingDoc)

Creates a [note](#) containing the specified text at a given location.

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateText2( _  
    ByVal TextString As System.String, _  
    ByVal TextX As System.Double, _  
    ByVal TextY As System.Double, _  
    ByVal TextZ As System.Double, _  
    ByVal TextHeight As System.Double, _  
    ByVal TextAngle As System.Double _  
) As Note
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim TextString As System.String  
Dim TextX As System.Double  
Dim TextY As System.Double  
Dim TextZ As System.Double  
Dim TextHeight As System.Double  
Dim TextAngle As System.Double  
Dim value As Note
```

```
value = instance.ICreateText2(TextString, TextX, TextY, TextZ, TextHeight, TextAngle)
```

C#

```
Note ICreateText2(  
    System.string TextString,  
    System.double TextX,  
    System.double TextY,  
    System.double TextZ,  
    System.double TextHeight,  
    System.double TextAngle  
)
```

C++/CLI

```
Note^ ICreateText2(  
& System.String^ TextString,  
& System.double TextX,  
& System.double TextY,  
& System.double TextZ,  
& System.double TextHeight,  
& System.double TextAngle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TextString

User input text

TextX

X text location in meters (see **Remarks**)

TextY

Y text location in meters (see **Remarks**)

TextZ

Z text location in meters (see **Remarks**)

TextHeight

Text height in meters

TextAngle

Text angle for rotated text in radians

Return Value

Pointer to the [note](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::ICreateText2](#).

Remarks

The location specifies the position of the upper-left corner of the box containing the text with respect to the lower-left corner of the drawing.

See Also

[IDrawingDoc Interface](#)

[IDrawingDoc Members](#)

[IDrawingDoc::CreateText2 Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IEditSelectedGtol Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : IEditSelectedGtol Method (IDrawingDoc)

Gets the selected GTol to edit.

.NET Syntax

Visual Basic (Declaration)

```
Function IEditSelectedGtol() As Gtol
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc
```

```
Dim value As Gtol
```

```
value = instance.IEditSelectedGtol()
```

C#

```
Gtol IEditSelectedGtol()
```

C++/CLI

```
Gtol^ IEditSelectedGtol();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to an existing [Gtol](#)

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::IEditSelectedGtol](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::EditSelectedGtol Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IFeatureByName Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : IFeatureByName Method (IDrawingDoc)

Gets the specified feature in the drawing.

.NET Syntax

Visual Basic (Declaration)

```
Function IFeatureByName( _  
    ByVal Name As System.String _  
) As Feature
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Name As System.String  
Dim value As Feature  
  
value = instance.IFeatureByName(Name)
```

C#

```
Feature IFeatureByName(  
    System.string Name  
)
```

C++/CLI

```
Feature^ IFeatureByName(  
& System.String^ Name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name
Name of the feature

Return Value

Pointer to the [IFeature](#) object

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::IFeatureByName](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)
[IDrawingDoc::FeatureByName Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetBlockDefinitions Method (IDrawingDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrawingDoc Interface](#) : IGetBlockDefinitions Method (IDrawingDoc)

Obsolete. Superseded by [SketchManager::GetSketchBlockDefinitions](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBlockDefinitions( _  
    ByVal Count As System.Integer _  
) As BlockDefinition
```

Visual Basic (Usage)



```
Dim instance As IDrawingDoc  
Dim Count As System.Integer  
Dim value As BlockDefinition  
  
value = instance.IGetBlockDefinitions(Count)
```

C#

```
BlockDefinition IGetBlockDefinitions(  
    System.int Count  
)
```

C++/CLI

```
BlockDefinition^ IGetBlockDefinitions(  
&    System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Visual Basic for Applications (VBA) Syntax

See [DrawingDoc::IGetBlockDefinitions](#).

See Also

[IDrawingDoc Interface](#)
[IDrawingDoc Members](#)