

SOLIDWORKS API (NET VBA C#) — Reference

(91/337): IDrSection

SOLIDWORKS API Documentation (converted from CHM)

IDrSection (Type)

IDrSection Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDrSection Interface

Allows access to a section view in a drawing.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IDrSection
```

Visual Basic (Usage)



```
Dim instance As IDrSection
```

C#

```
public interface IDrSection
```

C++/CLI

```
public interface class IDrSection
```

Visual Basic for Applications (VBA) Syntax

See [DrSection](#).

Example

[Create Section View and Get Some Data \(C#\)](#)
[Create Section View and Get Some Data \(VB.NET\)](#)
[Create Section View and Get Some Data \(VBA\)](#)

Accessors

[IEnumDrSections::Next](#)
[IFeature::GetSpecificFeature2](#)
[IView::GetSection](#) and [IView::!GetSection](#)

Access Diagram

[DrSection](#)

See Also

[IDrSection Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IEnumDrSections Interface](#)
[ISectionViewData Interface](#)

IDrSection Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDrSection Interface

For a list of all members of this type, see [IDrSection members](#).

Public Methods

Name	Description
 EnumExcludedComponents	Obsolete. Superseded by IDrSection::EnumExcludedComponent2
 EnumExcludedComponents2	Gets all of the assembly components that are excluded from this section view.
 GetArrowInfo	Gets the position of the arrows for the section line.
 GetAutoHatch	Gets whether auto hatching is enabled for the section view resulting from this section cut.
 GetDisplayOnlySpeedPakBodies	Gets whether to display in this section view only the bodies included in the SpeedPak configuration.
 GetDisplayOnlySurfaceCut	Gets whether to display only the surface cut by the section line.
 GetDontCutAllInstances	Gets whether all instances of the specified component are uncut in this section view or only in the specified component.
 GetExcludedComponents	Gets all of the assembly components that are excluded from this section view.
 GetLabel	Gets the label for this section view.
 GetLineInfo	Gets the vertices of the section line.
 GetName	Gets the name of the section line.
 GetPartialSection	Gets whether this is a partial section cut.
 GetReversedCutDirection	Gets whether the section cut direction is reversed from the default direction.
 GetScaleWithModelChanges	Gets whether the section line scales with changes to the model.
 GetSectionView	Gets the section view of this section cut.
 GetTextFormat	Gets the text format for the text for this section line.
 GetTextInfo	Gets the location of the section line text.
 GetUseDocTextFormat	Gets whether SOLIDWORKS is currently using the document default setting for text format.
 GetView	Gets the drawing view where the section line appears.
 IGetArrowInfo	Gets the position of the arrows for this section line.
 IGetLineInfo	Gets the vertices of the section line.
 IGetLineSegmentCount	Gets the number of line segments making up this section line.
 IGetSectionView	Gets the section view of this section cut.
 IGetTextFormat	Gets the text format for the text for this section line.
 IGetTextInfo	Gets the location of the section line text.
 IGetView	Gets the drawing view where the section line appears.
 IsAligned	Gets whether this is an aligned section view.
 ISetExcludedComponents	Excludes the specified components from this section view.
 ISetLineInfo	Sets the location (both position and arrow heads) of the section line.
 ISetTextFormat	Sets the text format for the text for this section line.
 SetAutoHatch	Sets whether auto hatching is enabled for the section view resulting from this section cut.
 SetDisplayOnlySpeedPakBodies	Sets whether to display in this section view only the bodies included in the SpeedPak configuration.
 SetDisplayOnlySurfaceCut	Sets whether to display only the surface cut by the section line.
 SetDontCutAllInstances	Sets whether all instances of the specified component are uncut in this section view or only in the specified component.
 SetExcludedComponents	Excludes the specified components from this section view.
 SetLabel	Obsolete. Superseded by IDrSection::ISetLabel2
 SetLabel2	Sets the label for this section view.
 SetLineInfo	Sets the location (both position and arrow heads) of the section line.
 SetPartialSection	Sets whether this is a partial section cut.
 SetReversedCutDirection	Sets whether the section cut direction is reversed from the default.
 SetScaleWithModelChanges	Sets whether the section line scales with changes to the model.
 SetTextFormat	Sets the text format for the text for this section line.

[Top](#)

See Also

[IDrSection Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IEnumDrSections Interface](#)
[ISectionViewData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDrSection Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : IDrSection Interface

The following tables list the members exposed by [IDrSection](#).

Public Properties

Name	Description
 CutSurfaceBodies	Gets or sets whether to hide cut surface bodies in this section view.
 CuttingLineShoulders	Gets or sets whether to hide cutting line shoulders in this section view.
 DisplaySurfaceBodies	Gets or sets whether to display surface bodies in this section view.
 ExcludeFasteners	Gets or sets whether to exclude fasteners in the section view.
 ExcludeSliceSectionBodies	Gets or sets whether to exclude slice section bodies in this section view.
 Layer	Gets or sets the name of the layer on which the section line lies.
 RandomizeScale	Gets or sets whether to randomize the scale when auto hatching this section view.
 ScaleHatchPattern	Gets or sets whether to scale the hatch pattern to the section view.
 SectionDepth	Gets or sets the distance from the section line of the section view.

[Top](#)

Public Methods

Name	Description
 EnumExcludedComponents	Obsolete. Superseded by IDrSection.EnumExcludedComponent2
 EnumExcludedComponents2	Gets all of the assembly components that are excluded from this section view.
 GetArrowInfo	Gets the position of the arrows for the section line.
 GetAutoHatch	Gets whether auto hatching is enabled for the section view resulting from this section cut.
 GetDisplayOnlySpeedPakBodies	Gets whether to display in this section view only the bodies included in the SpeedPak configuration.
 GetDisplayOnlySurfaceCut	Gets whether to display only the surface cut by the section line.
 GetDontCutAllInstances	Gets whether all instances of the specified component are uncut in this section view or only in the specified component.
 GetExcludedComponents	Gets all of the assembly components that are excluded from this section view.
 GetLabel	Gets the label for this section view.
 GetLineInfo	Gets the vertices of the section line.
 GetName	Gets the name of the section line.
 GetPartialSection	Gets whether this is a partial section cut.
 GetReversedCutDirection	Gets whether the section cut direction is reversed from the default direction.
 GetScaleWithModelChanges	Gets whether the section line scales with changes to the model.
 GetSectionView	Gets the section view of this section cut.
 GetTextFormat	Gets the text format for the text for this section line.
 GetTextInfo	Gets the location of the section line text.
 GetUseDocTextFormat	Gets whether SOLIDWORKS is currently using the document default setting for text format.
 GetView	Gets the drawing view where the section line appears.

		
	IGetArrowInfo	Gets the position of the arrows for this section line.
	IGetLineInfo	Gets the vertices of the section line.
	IGetLineSegmentCount	Gets the number of line segments making up this section line.
	IGetSectionView	Gets the section view of this section cut.
	IGetTextFormat	Gets the text format for the text for this section line.
	IGetTextInfo	Gets the location of the section line text.
	IGetView	Gets the drawing view where the section line appears.
	IsAligned	Gets whether this is an aligned section view.
	ISetExcludedComponents	Excludes the specified components from this section view.
	ISetLineInfo	Sets the location (both position and arrow heads) of the section line.
	ISetTextFormat	Sets the text format for the text for this section line.
	SetAutoHatch	Sets whether auto hatching is enabled for the section view resulting from this section cut.
	SetDisplayOnlySpeedPakBodies	Sets whether to display in this section view only the bodies included in the SpeedPak configuration.
	SetDisplayOnlySurfaceCut	Sets whether to display only the surface cut by the section line.
	SetDontCutAllInstances	Sets whether all instances of the specified component are uncut in this section view or only in the specified component.
	SetExcludedComponents	Excludes the specified components from this section view.
	SetLabel	Obsolete. Superseded by IDrSection.ISetLabel2
	SetLabel2	Sets the label for this section view.
	SetLineInfo	Sets the location (both position and arrow heads) of the section line.
	SetPartialSection	Sets whether this is a partial section cut.
	SetReversedCutDirection	Sets whether the section cut direction is reversed from the default.
	SetScaleWithModelChanges	Sets whether the section line scales with changes to the model.
	SetTextFormat	Sets the text format for the text for this section line.

[Top](#)

See Also

[IDrSection Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IEnumDrSections Interface](#)
[ISectionViewData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDrSection Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDrSection Interface

For a list of all members of this type, see [IDrSection members](#).

Public Properties

Name	Description
 CutSurfaceBodies	Gets or sets whether to hide cut surface bodies in this section view.
 CuttingLineShoulders	Gets or sets whether to hide cutting line shoulders in this section view.
 DisplaySurfaceBodies	Gets or sets whether to display surface bodies in this section view.
 ExcludeFasteners	Gets or sets whether to exclude fasteners in the section view.
 ExcludeSliceSectionBodies	Gets or sets whether to exclude slice section bodies in this section view.
 Layer	Gets or sets the name of the layer on which the section line lies.
 RandomizeScale	Gets or sets whether to randomize the scale when auto hatching this section view.

 ScaleHatchPattern	Gets or sets whether to scale the hatch pattern to the section view.
 SectionDepth	Gets or sets the distance from the section line of the section view.

[Top](#)

See Also

[IDrSection Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IEnumDrSections Interface](#)
[ISectionViewData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CutSurfaceBodies Property (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : CutSurfaceBodies Property (IDrSection)

Gets or sets whether to hide cut surface bodies in this section view.

.NET Syntax

Visual Basic (Declaration)

```
Property CutSurfaceBodies As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrSection
Dim value As System.Boolean

instance.CutSurfaceBodies = value
value = instance.CutSurfaceBodies
```

C#

```
System.bool CutSurfaceBodies {get; set;}
```

C++/CLI

```
property System.bool CutSurfaceBodies {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to hide cut surface bodies in this section view, false to show them

Visual Basic for Applications (VBA) Syntax

See [DrSection::CutSurfaceBodies](#).

Example

See the [IDrSection](#) examples.

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::GetDisplayOnlySurfaceCut Method \(\)](#)
[IDrSection::SetDisplayOnlySurfaceCut Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

CuttingLineShoulders Property (IDrSection)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : CuttingLineShoulders Property (IDrSection)

Gets or sets whether to hide cutting line shoulders in this section view.

.NET Syntax

Visual Basic (Declaration)

Property CuttingLineShoulders As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDrSection
Dim value As System.Boolean

instance.CuttingLineShoulders = value

value = instance.CuttingLineShoulders
```

C#

```
System.bool CuttingLineShoulders {get; set;}
```

C++/CLI

```
property System.bool CuttingLineShoulders {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to hide cutting line shoulders, false to not

Visual Basic for Applications (VBA) Syntax

See [DrSection::CuttingLineShoulders](#).

Example

[Get and Set Whether to Hide Cutting Line Shoulders \(C#\)](#)
[Get and Set Whether to Hide Cutting Line Shoulders \(VB.NET\)](#)
[Get and Set Whether to Hide Cutting Line Shoulders \(VBA\)](#)

See Also

[IDrSection Interface](#)
[IDrSection Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

DisplaySurfaceBodies Property (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : DisplaySurfaceBodies Property (IDrSection)

Gets or sets whether to display surface bodies in this section view.

.NET Syntax

Visual Basic (Declaration)

Property DisplaySurfaceBodies As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim value As System.Boolean  
  
instance.DisplaySurfaceBodies = value  
value = instance.DisplaySurfaceBodies
```

C#

```
System.bool DisplaySurfaceBodies {get; set;}
```

C++/CLI

```
property System.bool DisplaySurfaceBodies {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to display surface bodies, false to not

Visual Basic for Applications (VBA) Syntax

See [DrSection::DisplaySurfaceBodies](#).

Example

See the [IDrSection](#) examples.

See Also

[IDrSection Interface](#)
[IDrSection Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

EnumExcludedComponents Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : EnumExcludedComponents Method (IDrSection)

Obsolete. Superseded by [IDrSection::EnumExcludedComponent2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function EnumExcludedComponents() As EnumComponents
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim value As EnumComponents  
  
value = instance.EnumExcludedComponents()
```

C#

```
EnumComponents EnumExcludedComponents()
```

C++/CLI

```
EnumComponents^ EnumExcludedComponents();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrSection::EnumExcludedComponents](#).

See Also

[IDrSection Interface](#)
[IDrSection Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

EnumExcludedComponents2 Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : EnumExcludedComponents2 Method (IDrSection)

Gets all of the assembly components that are excluded from this section view.

.NET Syntax

Visual Basic (Declaration)

```
Function EnumExcludedComponents2() As EnumComponents2
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim value As EnumComponents2  
  
value = instance.EnumExcludedComponents2()
```

C#

```
EnumComponents2 EnumExcludedComponents2()
```

C++/CLI

```
EnumComponents2^ EnumExcludedComponents2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [IEnumComponents2](#) object

Visual Basic for Applications (VBA) Syntax

See [DrSection::EnumExcludedComponents2](#).

Remarks

The ability to exclude components applies only to assembly section views. This method returns NULL for section views of parts.

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::GetExcludedComponents Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ExcludeFasteners Property (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : ExcludeFasteners Property (IDrSection)

Gets or sets whether to exclude fasteners in the section view.

.NET Syntax

Visual Basic (Declaration)

Property ExcludeFasteners As System.Boolean

Visual Basic (Usage)



```
Dim instance As IDrSection
Dim value As System.Boolean

instance.ExcludeFasteners = value
value = instance.ExcludeFasteners
```

C#

```
System.bool ExcludeFasteners {get; set;}
```

C++/CLI

```
property System.bool ExcludeFasteners {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to exclude fasteners, false to include them

Visual Basic for Applications (VBA) Syntax

See [DrSection::ExcludeFasteners](#).

Remarks

Call [IModelDoc2::EditRebuild3](#) after calling this property.

See Also

[IDrSection Interface](#)
[IDrSection Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ExcludeSliceSectionBodies Property (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : ExcludeSliceSectionBodies Property (IDrSection)

Gets or sets whether to exclude slice section bodies in this section view.

.NET Syntax

Visual Basic (Declaration)

```
Property ExcludeSliceSectionBodies As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim value As System.Boolean  
  
instance.ExcludeSliceSectionBodies = value  
value = instance.ExcludeSliceSectionBodies
```

C#

```
System.bool ExcludeSliceSectionBodies {get; set;}
```

C++/CLI

```
property System.bool ExcludeSliceSectionBodies {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to exclude slice section bodies, false to include them

Visual Basic for Applications (VBA) Syntax

See [DrSection::ExcludeSliceSectionBodies](#).

Example

See the [IDrSection](#) examples.

See Also

[IDrSection Interface](#)
[IDrSection Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetArrowInfo Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : GetArrowInfo Method (IDrSection)

Gets the position of the arrows for the section line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArrowInfo() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim value As System.Object
```

```
value = instance.GetArrowInfo()
```

C#

```
System.object GetArrowInfo()
```

C++/CLI

```
System.Object^ GetArrowInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of objects (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [IDrSection::GetArrowInfo](#).

Remarks

The section line in a drawing view has arrows at each end of the line. This method returns an array that consists of 12 doubles, the (X, Y, Z) of the start and end point of one arrow followed by the (X, Y, Z) of the start and end point of the other arrow.

These values are the same as some of the information in the array returned by [IView::GetSectionLineInfo2](#). The arrow information in that array also contains the arrow width, height and style. That information is not included in the array returned by this method, but you can get it from the document preference settings because these values are controlled only at the document level, not on an individual section line basis.

See:

- [IModelDocExtension::GetUserPreferenceDouble](#) with swDetailingSectionArrowHeight, swDetailingSectionArrowWidth, or swDetailingSectionArrowLength
- [IModelDocExtension::GetUserPreferenceInteger](#) with swDetailingArrowStyleForDimensions

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::IGetArrowInfo Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAutoHatch Method (IDrSection)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : GetAutoHatch Method (IDrSection)

Gets whether auto hatching is enabled for the section view resulting from this section cut.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAutoHatch() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim value As System.Boolean  
  
value = instance.GetAutoHatch()
```

C#

```
System.bool GetAutoHatch()
```

C++/CLI

```
System.bool GetAutoHatch();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if auto hatching is enabled for the section view, false if it is disabled

Visual Basic for Applications (VBA) Syntax

See [DrSection::GetAutoHatch](#).

Example

[Create Section View and Get Some Data \(C#\)](#)
[Create Section View and Get Some Data \(VB.NET\)](#)
[Create Section View and Get Some Data \(VBA\)](#)

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::SetAutoHatch Method](#)
[IDrSection::ScaleHatchPattern Property](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDisplayOnlySpeedPakBodies Method (IDrSection)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : GetDisplayOnlySpeedPakBodies Method (IDrSection)

Gets whether to display in this section view only the bodies included in the SpeedPak configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayOnlySpeedPakBodies() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim value As System.Boolean
```

```
value = instance.GetDisplayOnlySpeedPakBodies()
```

C#

```
System.bool GetDisplayOnlySpeedPakBodies()
```

C++/CLI

```
System.bool GetDisplayOnlySpeedPakBodies();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True to display only the bodies included in the SpeedPak configuration, false to not

Visual Basic for Applications (VBA) Syntax

See [DrSection::GetDisplayOnlySpeedPakBodies](#).

Example

[Create Section View and Get Some Data \(VBA\)](#)
[Create Section View and Get Some Data \(VB.NET\)](#)
[Create Section View and Get Some Data \(C#\)](#)

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::SetDisplayOnlySpeedPakBodies Method](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDisplayOnlySurfaceCut Method (IDrSection)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : GetDisplayOnlySurfaceCut Method (IDrSection)

Gets whether to display only the surface cut by the section line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayOnlySurfaceCut() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim value As System.Boolean
```

```
value = instance.GetDisplayOnlySurfaceCut()
```

C#

```
System.bool GetDisplayOnlySurfaceCut()
```

C++/CLI

```
System.bool GetDisplayOnlySurfaceCut();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True to display only the surface cut by the section line, false to not

Visual Basic for Applications (VBA) Syntax

See [DrSection::GetDisplayOnlySurfaceCut](#).

Example

[Create Section View and Get Some Data \(C#\)](#)
[Create Section View and Get Some Data \(VB.NET\)](#)
[Create Section View and Get Some Data \(VBA\)](#)

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::SetDisplayOnlySurfaceCut Method](#)
[IDrSection::CutSurfaceBodies Property \(\)](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

GetDontCutAllInstances Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : GetDontCutAllInstances Method (IDrSection)

Gets whether all instances of the specified component are uncut in this section view or only in the specified component.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDontCutAllInstances( _  
    ByVal LpComp As Component _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim LpComp As Component  
Dim value As System.Boolean
```

```
value = instance.GetDontCutAllInstances(LpComp)
```

C#

```
System.bool GetDontCutAllInstances(  
    Component LpComp  
)
```

C++/CLI

```
System.bool GetDontCutAllInstances(  
& Component^ LpComp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

LpComp

Pointer to the [IComponent2](#) object

Return Value

True if all instances of the selected component are left uncut, false if only the selected component is left uncut

Visual Basic for Applications (VBA) Syntax

See [DrSection::GetDontCutAllInstances](#).

See Also

[IDrSection Interface](#)

[IDrSection Members](#)

[IDrSection::SetDontCutAllInstances Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

GetExcludedComponents Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : GetExcludedComponents Method (IDrSection)

Gets all of the assembly components that are excluded from this section view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetExcludedComponents() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim value As System.Object  
  
value = instance.GetExcludedComponents()
```

C#

```
System.object GetExcludedComponents()
```

C++/CLI

```
System.Object^ GetExcludedComponents();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of excluded [components](#)

Visual Basic for Applications (VBA) Syntax

See [DrSection::GetExcludedComponents](#).

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::EnumExcludedComponents2 Method](#)
[IDrSection::ISetExcludedComponents Method](#)
[IDrSection::SetExcludedComponents Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetLabel Method (IDrSection)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : GetLabel Method (IDrSection)

Gets the label for this section view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLabel() As System.String
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim value As System.String  
  
value = instance.GetLabel()
```

C#

```
System.string GetLabel()
```

C++/CLI

```
System.String^ GetLabel();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [DrSection::GetLabel](#).

Example

[Create Section View and Get Some Data \(VB.NET\)](#)
[Create Section View and Get Some Data \(VBA\)](#)
[Create Section View and Get Some Data \(C#\)](#)

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::SetLabel2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLineInfo Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : GetLineInfo Method (IDrSection)

Gets the vertices of the section line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLineInfo() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim value As System.Object  
  
value = instance.GetLineInfo()
```

C#

```
System.object GetLineInfo()
```

C++/CLI

```
System.Object^ GetLineInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DrSection::GetLineInfo](#).

Remarks

This method returns an array that consists of several coordinate pairs. The number of coordinate pairs is determined by the number of line segments in the section line.

These values are the same as some of the information in the array returned by the [IView::GetSectionLineInfo2](#). The line segment information in that array also contains the line style. The array returned by this method does not contain that information because it is a document-level setting and cannot be controlled per section line. Use [IModelDocExtension::GetUserPreferenceInteger](#) or [IModelDocExtension::SetUserPreferenceInteger](#) with `swLineFontSectionLineStyle` to get or set that value.

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::SetLineInfo Method](#)
[IDrSection::IGetLineInfo Method](#)
[IDrSection::SetLineInfo Method](#)
[IView::GetSectionLines Method](#)
[IView::EnumSectionLines Method](#)
[IDrSection::IGetLineSegmentCount Method](#)
[IView::GetSectionLineInfo2 Method](#)
[IView::IGetSectionLineInfo2 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetName Method (IDrSection)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : GetName Method (IDrSection)

Gets the name of the section line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim value As System.String  
  
value = instance.GetName()
```

C#

```
System.string GetName()
```

C++/CLI

```
System.String^ GetName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Name of the section line

Visual Basic for Applications (VBA) Syntax

See [DrSection::GetName](#).

Example

[Get Section View \(VBA\)](#)
[Create Section View and Get Some Data \(C#\)](#)
[Create Section View and Get Some Data \(VB.NET\)](#)
[Create Section View and Get Some Data \(VBA\)](#)

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IView::EnumSectionLines Method](#)
[IView::GetSectionLines Method](#)

Availability

GetPartialSection Method (IDrSection)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : GetPartialSection Method (IDrSection)

Gets whether this is a partial section cut.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPartialSection() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrSection
Dim value As System.Boolean

value = instance.GetPartialSection()
```

C#

```
System.bool GetPartialSection()
```

C++/CLI

```
System.bool GetPartialSection();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this is a partial section cut, false if it is not

Visual Basic for Applications (VBA) Syntax

See [DrSection::GetPartialSection](#).

Example

[Create Section View and Get Some Data \(C#\)](#)
[Create Section View and Get Some Data \(VB.NET\)](#)
[Create Section View and Get Some Data \(VBA\)](#)

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::SetPartialSection Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

GetReversedCutDirection Method (IDrSection)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : GetReversedCutDirection Method (IDrSection)

Gets whether the section cut direction is reversed from the default direction.

.NET Syntax

Visual Basic (Declaration)

```
Function GetReversedCutDirection() As System.Boolean
```

```
Dim instance As IDrSection
Dim value As System.Boolean

value = instance.GetReversedCutDirection()
```

C#

```
System.bool GetReversedCutDirection()
```

C++/CLI

```
System.bool GetReversedCutDirection();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the section cut direction is reversed from the default, false if it is not

Visual Basic for Applications (VBA) Syntax

See [DrSection::GetReversedCutDirection](#).

Example

[Create Section View and Get Some Data \(C#\)](#)
[Create Section View and Get Some Data \(VB.NET\)](#)
[Create Section View and Get Some Data \(VBA\)](#)

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::SetPartialSection Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetScaleWithModelChanges Method (IDrSection)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : GetScaleWithModelChanges Method (IDrSection)

Gets whether the section line scales with changes to the model.

.NET Syntax

Visual Basic (Declaration)

```
Function GetScaleWithModelChanges() As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IDrSection
Dim value As System.Boolean

value = instance.GetScaleWithModelChanges()
```

C#

```
System.bool GetScaleWithModelChanges()
```

C++/CLI

```
System.bool GetScaleWithModelChanges();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the section line scales with changes to the model, false if it does not

Visual Basic for Applications (VBA) Syntax

See [DrSection::GetScaleWithModelChanges](#).

Example

[Create Section View and Get Some Data \(C#\)](#)
[Create Section View and Get Some Data \(VB.NET\)](#)
[Create Section View and Get Some Data \(VBA\)](#)

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::SetScaleWithModelChanges Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSectionView Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : GetSectionView Method (IDrSection)

Gets the section view of this section cut.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSectionView() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim value As System.Object  
  
value = instance.GetSectionView()
```

C#

```
System.object GetSectionView()
```

C++/CLI

```
System.Object^ GetSectionView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Section view of this section cut

Visual Basic for Applications (VBA) Syntax

See [DrSection::GetSectionView](#).

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::IGetSectionView Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextFormat Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : GetTextFormat Method (IDrSection)

Gets the text format for the text for this section line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextFormat() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim value As System.Object  
  
value = instance.GetTextFormat()
```

C#

```
System.object GetTextFormat()
```

C++/CLI

```
System.Object^ GetTextFormat();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Text format for this section line

Visual Basic for Applications (VBA) Syntax

See [DrSection::GetTextFormat](#).

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::IGetTextFormat Method](#)
[IDrSection::ISetTextFormat Method](#)
[IDrSection::GetTextFormat Method](#)
[IDrSection::GetUseDocTextFormat Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextInfo Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : GetTextInfo Method (IDrSection)

Gets the location of the section line text.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextInfo() As System.Object
```

Visual Basic (Usage)

```
Dim instance As IDrSection  
Dim value As System.Object  
  
value = instance.GetTextInfo()
```

C#

```
System.Object GetTextInfo()
```

C++/CLI

```
System.Object^ GetTextInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [DrSection::GetTextInfo](#).

Remarks

The section line in a drawing view usually has a piece of text near each end of the line, typically the section view label ([IDrSection::GetLabel](#)). The array returned by this method consists of 6 doubles, the (X, Y, Z) origin of one text followed by the (X, Y, Z) origin of the other text. The origin is the upper-left corner of the text.

These values are the same as some of the information in the array returned by [IView::GetSectionLineInfo2](#). The text information in that array also contains the text height. This method returns an array that does not include that information, but you can get it using [IDrSection::GetTextFormat](#) and [ITextFormat::CharHeight](#).

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::IGetTextInfo Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUseDocTextFormat Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : GetUseDocTextFormat Method (IDrSection)

Gets whether SOLIDWORKS is currently using the document default setting for text format.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUseDocTextFormat() As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IDrSection  
Dim value As System.Boolean  
  
value = instance.GetUseDocTextFormat()
```

C#

```
System.bool GetUseDocTextFormat()
```

C++/CLI

```
System.bool GetUseDocTextFormat();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if using the document default setting for text format, false if not

Visual Basic for Applications (VBA) Syntax

See [DrSection::GetUseDocTextFormat](#).

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::GetTextFormat Method](#)
[IDrSection::IGetTextFormat Method](#)
[IDrSection::ISetTextFormat Method](#)
[IDrSection::SetTextFormat Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetView Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : GetView Method (IDrSection)

Gets the drawing view where the section line appears.

.NET Syntax

Visual Basic (Declaration)

```
Function GetView() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim value As System.Object  
  
value = instance.GetView()
```

C#

```
System.object GetView()
```

C++/CLI

```
System.Object^ GetView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Drawing view where the section line appears

Visual Basic for Applications (VBA) Syntax

See [DrSection::GetView](#).

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::IGetView Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetArrowInfo Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : IGetArrowInfo Method (IDrSection)

Gets the position of the arrows for this section line.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetArrowInfo() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDrSection
Dim value As System.Double

value = instance.IGetArrowInfo()
```

C#

```
System.double IGetArrowInfo()
```

C++/CLI

```
System.double IGetArrowInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of 3 doubles (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

The section line in a drawing view has arrows at each end of the line. This method returns an array that consists of 12 doubles, the (X, Y, Z) of the start and end point of one arrow followed by the (X, Y, Z) of the start and end point of the other arrow.

These values are the same as some of the information in the array returned by `View::GetSectionLineInfo`. The arrow information in that array also contains the arrow width, height and style. That information is not included in the array returned by this method, but you can get it from the document preference settings because these values are controlled only at the document level, not on an individual section line basis.

See:

- [IModelDocExtension::GetUserPreferenceDouble](#) with `swDetailingSectionArrowHeight`, `swDetailingSectionArrowWidth`, or `swDetailingSectionArrowLength`
- [IModelDocExtension::GetUserPreferenceInteger](#) with `swDetailingArrowStyleForDimensions`

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::GetArrowInfo Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetLineInfo Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : IGetLineInfo Method (IDrSection)

Gets the vertices of the section line.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetLineInfo() As System.Double
```

Visual Basic (Usage)

```
Dim instance As IDrSection
Dim value As System.Double

value = instance.IGetLineInfo()
```

C#

```
System.double IGetLineInfo()
```

C++/CLI

```
System.double IGetLineInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

This method returns an array that consists of several coordinate pairs. The number of coordinate pairs is determined by the number of line segments in the section line.

Call [IDrSection::IGetLineSegmentCount](#) and multiply that number by 6 to get the size for the array. Each coordinate pair consists of 6 doubles, the (X, Y, Z) coordinate of each end point of the segment.

These values are the same as some of the information in the array returned by the [IView::IGetSectionLineInfo2](#). The line segment information in that array also contains the line style. The array returned by this method does not contain that information because it is a document-level setting and cannot be controlled per section line. Use [IModelDocExtension::GetUserPreferenceInteger](#) or [IModelDocExtension::SetUserPreferenceInteger](#) with `swLineFontSectionLineStyle` to get or set that value.

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::IGetLineInfo Method](#)
[IDrSection::ISetLineInfo Method](#)
[IDrSection::SetLineInfo Method](#)
[IView::EnumSectionLines Method](#)
[IView::GetSectionLines Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetLineSegmentCount Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : IGetLineSegmentCount Method (IDrSection)

Gets the number of line segments making up this section line.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetLineSegmentCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDrSection
Dim value As System.Integer

value = instance.IGetLineSegmentCount()
```

C#

```
System.int IGetLineSegmentCount()
```

C++/CLI

```
System.int IGetLineSegmentCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of line segments in this section line

Visual Basic for Applications (VBA) Syntax

See [DrSection::IGetLineSegmentCount](#).

Remarks

Use this method to determine the size of the array you need to allocate for the output of [IDrSection::IGetLineInfo](#). The size of the array to allocate is (6 * the value returned by this method).

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::GetLineInfo Method](#)
[IDrSection::ISetLineInfo Method](#)
[IDrSection::SetLineInfo Method](#)
[IView::GetSectionLines Method](#)
[IView::EnumSectionLines Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSectionView Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : IGetSectionView Method (IDrSection)

Gets the section view of this section cut.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSectionView() As View
```

Visual Basic (Usage)



```
Dim instance As IDrSection
Dim value As View

value = instance.IGetSectionView()
```

C#

```
View IGetSectionView()
```

C++/CLI

```
View^ IGetSectionView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the section [view](#) of this section cut

Visual Basic for Applications (VBA) Syntax

See [DrSection::IGetSectionView](#).

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::GetSectionView Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTextFormat Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : IGetTextFormat Method (IDrSection)

Gets the text format for the text for this section line.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTextFormat() As TextFormat
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim value As TextFormat
```

```
value = instance.IGetTextFormat()
```

C#

```
TextFormat IGetTextFormat()
```

C++/CLI

```
TextFormat^ IGetTextFormat();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [ITextFormat](#) object for this section line

Visual Basic for Applications (VBA) Syntax

See [DrSection::IGetTextFormat](#).

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::GetTextFormat Method](#)
[IDrSection::GetUseDocTextFormat Method](#)
[IDrSection::ISetTextFormat Method](#)
[IDrSection::SetTextFormat Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetTextInfo Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : IGetTextInfo Method (IDrSection)

Gets the location of the section line text.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTextInfo() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDrSection
Dim value As System.Double

value = instance.IGetTextInfo()
```

C#

```
System.double IGetTextInfo()
```

C++/CLI

```
System.double IGetTextInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of 3 doubles (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

The section line in a drawing view usually has a piece of text near each end of the line, typically the section view label ([IDrSection::GetLabel](#)). The array returned by this method consists of 6 doubles, the (X, Y, Z) origin of one text followed by the (X, Y, Z) origin of the other text. The origin is the upper-left corner of the text.

These values are the same as some of the information in the array returned by [IView::IGetSectionLineInfo2](#). The text information in that array also contains the text height. This method returns an array that does not include that information, but you can get it using [IDrSection::IGetTextFormat](#) and [ITextFormat::CharHeight](#).

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::GetTextInfo Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetView Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : IGetView Method (IDrSection)

Gets the drawing view where the section line appears.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetView() As View
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim value As View  
  
value = instance.IGetView()
```

C#

```
View IGetView()
```

C++/CLI

```
View^ IGetView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [drawing view](#) where the section line appears

Visual Basic for Applications (VBA) Syntax

See [DrSection::IGetView](#).

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::GetView Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsAligned Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : IsAligned Method (IDrSection)

Gets whether this is an aligned section view.

.NET Syntax

Visual Basic (Declaration)

```
Function IsAligned() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim value As System.Boolean  
  
value = instance.IsAligned()
```

C#

```
System.bool IsAligned()
```

C++/CLI

```
System.bool IsAligned();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this is an aligned section view, false if it is not

Visual Basic for Applications (VBA) Syntax

See [DrSection::IsAligned](#).

See Also

[IDrSection Interface](#)
[IDrSection Members](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetExcludedComponents Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : ISetExcludedComponents Method (IDrSection)

Excludes the specified components from this section view.

.NET Syntax

Visual Basic (Declaration)

```
Function ISetExcludedComponents( _  
    ByVal Number As System.Integer, _  
    ByRef LpComps As Component _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim Number As System.Integer  
Dim LpComps As Component  
Dim value As System.Boolean
```

```
value = instance.ISetExcludedComponents(Number, LpComps)
```

C#

```
System.bool ISetExcludedComponents(  
    System.int Number,  
    ref Component LpComps  
)
```

C++/CLI

```
System.bool ISetExcludedComponents(  
& System.int Number,  
& Component^% LpComps  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Number

Number of components

LpComps

- in-process, unmanaged C++: Pointer to array of [IComponent2](#) objects of size Number
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

True if the specified components are excluded, false if not

Remarks

Call [IModelDoc2::EditRebuild3](#) after calling this method.

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::EnumExcludedComponents2 Method](#)
[IDrSection::GetExcludedComponents Method](#)
[IDrSection::SetExcludedComponents Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetLineInfo Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : ISetLineInfo Method (IDrSection)

Sets the location (both position and arrow heads) of the section line.

.NET Syntax

Visual Basic (Declaration)

```
Function ISetLineInfo( _  
    ByVal Count As System.Integer, _  
    ByRef PLineInfo As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim Count As System.Integer  
Dim PLineInfo As System.Double  
Dim value As System.Boolean  
  
value = instance.ISetLineInfo(Count, PLineInfo)
```

C#

```
System.bool ISetLineInfo(  
    System.int Count,  
    ref System.double PLineInfo  
)
```

C++/CLI

```
System.bool ISetLineInfo(  
& System.int Count,  
& System.double% PLineInfo  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of the point coordinates of the section line

PLineInfo

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)

- VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Return Value

True if the location is set, false if not

Remarks

The PLineInfo argument is an array consisting of several coordinate pairs and is of the same format as the array returned by [IDrSection::IGetLineInfo](#). The number of coordinate pairs is determined by the number of line segments in the section line. Each coordinate pair

consists of 6 doubles, the x,y,z coordinate of each end point of the segment.

The formatted array should include the start point and end point of each line segment, including the z position even though the z position is irrelevant.

Any section line containing more than one segment contains at least one set of duplicate points. These points represent the end point of one line segment and the coincident start point of another line segment. If you change either set of points, then you must change the other set of points at the same time. These points must always be coincident when calling this method.

To update the section view, call [IModelDoc2::EditRebuild3](#) after calling this method.

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::SetLineInfo Method](#)
[IDrSection::GetLineInfo Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetTextFormat Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : ISetTextFormat Method (IDrSection)

Sets the text format for the text for this section line.

.NET Syntax

Visual Basic (Declaration)

```
Function ISetTextFormat( _  
    ByVal UseDoc As System.Boolean, _  
    ByVal TextFormat As TextFormat _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim UseDoc As System.Boolean  
Dim TextFormat As TextFormat  
Dim value As System.Boolean  
  
value = instance.ISetTextFormat(UseDoc, TextFormat)
```

C#

```
System.bool ISetTextFormat(  
    System.bool UseDoc,  
    TextFormat TextFormat  
)
```

C++/CLI

```
System.bool ISetTextFormat(  
& System.bool UseDoc,  
& TextFormat^ TextFormat  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDoc

True if set to use the appropriate document default setting, false if it is not (see **Remarks**)

TextFormat

Pointer to the [ITextFormat](#) object for this section line text

Return Value

True if text format is successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [IDrSection::ISetTextFormat](#).

Remarks

If UseDoc is True, then use the appropriate document default setting. SOLIDWORKS will also ignore TextFormat, which you should set to NULL

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::SetTextFormat Method](#)
[IDrSection::IGetTextFormat Method](#)
[IDrSection::GetTextFormat Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Layer Property (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : Layer Property (IDrSection)

Gets or sets the name of the layer on which the section line lies.

.NET Syntax

Visual Basic (Declaration)

Property Layer As System.String

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim value As System.String
```

```
instance.Layer = value
```

```
value = instance.Layer
```

C#

```
System.string Layer {get; set;}
```

C++/CLI

```
property System.String^ Layer {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Layer name

Visual Basic for Applications (VBA) Syntax

See [IDrSection::Layer](#).

Remarks

An empty string indicates no layer. If you set the layer to a layer name that does not exist, nothing happens.

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[ILayer Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

RandomizeScale Property (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : RandomizeScale Property (IDrSection)

Gets or sets whether to randomize the scale when auto hatching this section view.

.NET Syntax

Visual Basic (Declaration)

```
Property RandomizeScale As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim value As System.Boolean  
  
instance.RandomizeScale = value  
value = instance.RandomizeScale
```

C#

```
System.bool RandomizeScale {get; set;}
```

C++/CLI

```
property System.bool RandomizeScale {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to randomize the scale when auto hatching, false to not

Visual Basic for Applications (VBA) Syntax

See [DrSection::RandomizeScale](#).

Remarks

This property is valid only if [IDrSectionView::GetAutoHatch](#) is true.

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::ScaleHatchPattern Property\(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ScaleHatchPattern Property (IDrSection)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : ScaleHatchPattern Property (IDrSection)

Gets or sets whether to scale the hatch pattern to the section view.

.NET Syntax

Visual Basic (Declaration)

```
Property ScaleHatchPattern As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrSection
Dim value As System.Boolean

instance.ScaleHatchPattern = value

value = instance.ScaleHatchPattern
```

C#

```
System.bool ScaleHatchPattern {get; set;}
```

C++/CLI

```
property System.bool ScaleHatchPattern {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to scale the hatch pattern to the section view, false to not

Visual Basic for Applications (VBA) Syntax

See [DrSection::ScaleHatchPattern](#).

Example

[Scale Hatch Pattern to Section View \(C#\)](#)
[Scale Hatch Pattern to Section View \(VB.NET\)](#)
[Scale Hatch Pattern to Section View \(VBA\)](#)

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::GetAutoHatch Method \(\)](#)
[IDrSection::SetAutoHatch Method \(\)](#)
[IDrSection::RandomizeScale Property \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SectionDepth Property (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : SectionDepth Property (IDrSection)

Gets or sets the distance from the section line of the section view.

.NET Syntax

```
Property SectionDepth As System.Double
```



```
Dim instance As IDrSection
Dim value As System.Double

instance.SectionDepth = value

value = instance.SectionDepth
```

```
System.double SectionDepth {get; set;}
```

```
property System.double SectionDepth {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance from the section line of the section view

Visual Basic for Applications (VBA) Syntax

See [DrSection::SectionLayer](#).

Example

See the [IDrSection](#) examples.

See Also

[IDrSection Interface](#)
[IDrSection Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SetAutoHatch Method (IDrSection)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : SetAutoHatch Method (IDrSection)

Sets whether auto hatching is enabled for the section view resulting from this section cut.

.NET Syntax

```
Sub SetAutoHatch( _
    ByVal AutoHatch As System.Boolean _
)
```



```
Dim instance As IDrSection
Dim AutoHatch As System.Boolean

instance.SetAutoHatch(AutoHatch)
```

C#

```
void SetAutoHatch(  
    System.bool AutoHatch  
)
```

C++/CLI

```
void SetAutoHatch(  
& System.bool AutoHatch  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AutoHatch

True enables auto hatching for the section view, false disables it

Visual Basic for Applications (VBA) Syntax

See [DrSection::SetAutoHatch](#).

Example

[Create Section View and Get Some Data \(C#\)](#)
[Create Section View and Get Some Data \(VB.NET\)](#)
[Create Section View and Get Some Data \(VBA\)](#)

Remarks

Automatic hatching applies only to assembly section views. For section views of parts, this method has no effect.

When the auto hatching setting is changed, regenerate the section view to see the results of this change in the user interface.

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::GetAutoHatch Method](#)
[IDrSection::ScaleHatchPattern Property](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDisplayOnlySpeedPakBodies Method (IDrSection)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : SetDisplayOnlySpeedPakBodies Method (IDrSection)

Sets whether to display in this section view only the bodies included in the SpeedPak configuration.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDisplayOnlySpeedPakBodies( _  
    ByVal Display As System.Boolean _  
)
```

Visual Basic (Usage)

```
Dim instance As IDrSection  
Dim Display As System.Boolean
```

```
instance.SetDisplayOnlySpeedPakBodies(Display)
```

C#



```
void SetDisplayOnlySpeedPakBodies(  
    System.bool Display  
)
```

C++/CLI

```
void SetDisplayOnlySpeedPakBodies(  
&    System.bool Display  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Display

True to display only the bodies included in the SpeedPak configuration, false to not

Visual Basic for Applications (VBA) Syntax

See [DrSection::SetDisplayOnlySpeedPakBodies](#).

Example

[Create Section View and Get Some Data \(VBA\)](#)
[Create Section View and Get Some Data \(VB.NET\)](#)
[Create Section View and Get Some Data \(C#\)](#)

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::GetDisplayOnlySpeedPakBodies Method](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDisplayOnlySurfaceCut Method (IDrSection)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : SetDisplayOnlySurfaceCut Method (IDrSection)

Sets whether to display only the surface cut by the section line.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDisplayOnlySurfaceCut(  
    ByVal Display As System.Boolean  
)
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim Display As System.Boolean  
  
instance.SetDisplayOnlySurfaceCut(Display)
```

C#

```
void SetDisplayOnlySurfaceCut(  
    System.bool Display  
)
```

C++/CLI

```
void SetDisplayOnlySurfaceCut(
& System.bool Display
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Display

True displays only the surface cut by the section line, false does not

Visual Basic for Applications (VBA) Syntax

See [DrSection::SetDisplayOnlySurfaceCut](#).

Example

[Create Section View and Get Some Data \(C#\)](#)
[Create Section View and Get Some Data \(VB.NET\)](#)
[Create Section View and Get Some Data \(VBA\)](#)

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::GetDisplayOnlySurfaceCut Method](#)
[IDrSection::CutSurfaceBodies Property\(\)](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetDontCutAllInstances Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : SetDontCutAllInstances Method (IDrSection)

Sets whether all instances of the specified component are uncut in this section view or only in the specified component.

.NET Syntax

Visual Basic (Declaration)

```
Function SetDontCutAllInstances( _
    ByVal LpComp As Component, _
    ByVal VbCut As System.Boolean _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrSection
Dim LpComp As Component
Dim VbCut As System.Boolean
Dim value As System.Boolean
```

```
value = instance.SetDontCutAllInstances(LpComp, VbCut)
```

C#

```
System.bool SetDontCutAllInstances(
    Component LpComp,
    System.bool VbCut
)
```

C++/CLI

```
System.bool SetDontCutAllInstances(
    & Component^ LpComp,
```

```
& System.bool VbCut
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

LpComp

Pointer to the [IComponent2](#) object

VbCut

True if all instances of the selected component are left uncut, false if only the selected component is left uncut

Visual Basic for Applications (VBA) Syntax

See [DrSection::SetDontCutAllInstances](#).

See Also

[IDrSection Interface](#)

[IDrSection Members](#)

[IDrSection::GetDontCutAllInstances Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetExcludedComponents Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : SetExcludedComponents Method (IDrSection)

Excludes the specified components from this section view.

.NET Syntax

Visual Basic (Declaration)

```
Function SetExcludedComponents( _
    ByVal VComponents As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrSection
Dim VComponents As System.Object
Dim value As System.Boolean
```

```
value = instance.SetExcludedComponents(VComponents)
```

C#

```
System.bool SetExcludedComponents(
    System.object VComponents
)
```

C++/CLI

```
System.bool SetExcludedComponents(
& System.Object^ VComponents
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

VComponents

Array of [components](#)

Return Value

True if the specified components are excluded, false if not

Visual Basic for Applications (VBA) Syntax

See [IDrSection::SetExcludedComponents](#).

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::EnumExcludedComponents2 Method](#)
[IDrSection::GetExcludedComponents Method](#)
[IDrSection::!SetExcludedComponents Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetLabel Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : SetLabel Method (IDrSection)

Obsolete. Superseded by [IDrSection::!SetLabel2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetLabel( _  
    ByVal Label As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim Label As System.String  
Dim value As System.Boolean  
  
value = instance.SetLabel(Label)
```

C#

```
System.bool SetLabel(  
    System.string Label  
)
```

C++/CLI

```
System.bool SetLabel(  
& System.String^ Label  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Label

Visual Basic for Applications (VBA) Syntax

See [IDrSection::SetLabel](#).

See Also

[IDrSection Interface](#)
[IDrSection Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetLabel2 Method (IDrSection)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : SetLabel2 Method (IDrSection)

Sets the label for this section view.

.NET Syntax

Visual Basic (Declaration)

```
Function SetLabel2( _  
    ByVal Label As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim Label As System.String  
Dim value As System.Integer  
  
value = instance.SetLabel2(Label)
```

C#

```
System.int SetLabel2(  
    System.string Label  
)
```

C++/CLI

```
System.int SetLabel2(  
& System.String^ Label  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Label
Label for this section view

Return Value

Value as defined in [swSetSectionLabelStatus_e](#)

Visual Basic for Applications (VBA) Syntax

See [DrSection::SetLabel2](#).

Example

[Create Section View and Get Some Data \(C#\)](#)
[Create Section View and Get Some Data \(VB.NET\)](#)
[Create Section View and Get Some Data \(VBA\)](#)

Remarks

If the return status...	Then the operation...
< 0	Failed
= 0	Succeeded
> 0	Succeeded. However: - If you attempt to set the section label to the same value as an existing section label and the drawing standard does allow duplicate section labels, then status = 1. That is, the label is changed, but the status indicates that the label is a duplicate, which is not allowed by the drawing standard. - If the dimensioning standard allows duplicate section labels, then status = 0.

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::GetLabel Method](#)

Availability

SOLIDWORKS 2003 SP2, Revision Number 11.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetLineInfo Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : SetLineInfo Method (IDrSection)

Sets the location (both position and arrow heads) of the section line.

.NET Syntax

Visual Basic (Declaration)

```
Function SetLineInfo( _  
    ByVal VLineInfo As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim VLineInfo As System.Object  
Dim value As System.Boolean  
  
value = instance.SetLineInfo(VLineInfo)
```

C#

```
System.bool SetLineInfo(  
    System.object VLineInfo  
)
```

C++/CLI

```
System.bool SetLineInfo(  
& System.Object^ VLineInfo  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

VLineInfo
Array (see [Remarks](#))

Visual Basic for Applications (VBA) Syntax

See [DrSection::SetLineInfo](#).

Remarks

The *VLineInfo* argument is an array consisting of several coordinate pairs and is of the same format as the array returned by [IDrSection::GetLineInfo](#). The number of coordinate pairs is determined by the number of line segments in the section line. Each coordinate pair consists of 6 doubles, the x,y,z coordinate of each end point of the segment.

The formatted array should include the start point and end point of each line segment, including the z position even though the z position is irrelevant.

Any section line containing more than one segment contains at least one set of duplicate points. These points represent the end point of one line segment and the coincident start point of another line segment. If you change either set of points, then you must change the other set of points as

the same time. These points must always be coincident when calling this method.

To update the section view, call [IModelDoc2::EditRebuild3](#) after calling this method.

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::IGetLineInfo Method](#)
[IDrSection::!IGetLineInfo Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetPartialSection Method (IDrSection)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : SetPartialSection Method (IDrSection)

Sets whether this is a partial section cut.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetPartialSection( _  
    ByVal Partial As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim Partial As System.Boolean  
  
instance.SetPartialSection(Partial)
```

C#

```
void SetPartialSection(  
    System.bool Partial  
)
```

C++/CLI

```
void SetPartialSection(  
& System.bool Partial  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Partial

True sets a partial section cut, false does not

Visual Basic for Applications (VBA) Syntax

See [DrSection::SetPartialSection](#).

Example

[Create Section View and Get Some Data \(C#\)](#)
[Create Section View and Get Some Data \(VB.NET\)](#)
[Create Section View and Get Some Data \(VBA\)](#)

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::GetPartialSection Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetReversedCutDirection Method (IDrSection)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : SetReversedCutDirection Method (IDrSection)

Sets whether the section cut direction is reversed from the default.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetReversedCutDirection( _  
    ByVal Reversed As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim Reversed As System.Boolean  
  
instance.SetReversedCutDirection(Reversed)
```

C#

```
void SetReversedCutDirection(  
    System.bool Reversed  
)
```

C++/CLI

```
void SetReversedCutDirection(  
& System.bool Reversed  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Reversed

True reverses the section cut direction from the default, false does not

Visual Basic for Applications (VBA) Syntax

See [DrSection::SetReversedCutDirection](#).

Example

[Create Section View and Get Some Data \(C#\)](#)
[Create Section View and Get Some Data \(VB.NET\)](#)
[Create Section View and Get Some Data \(VBA\)](#)

Remarks

Call [IModelDoc2::EditRebuild3](#) after calling this method.

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::GetReversedCutDirection Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SetScaleWithModelChanges Method (IDrSection)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : SetScaleWithModelChanges Method (IDrSection)

Sets whether the section line scales with changes to the model.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetScaleWithModelChanges( _  
    ByVal ScaleWithChanges As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim ScaleWithChanges As System.Boolean  
  
instance.SetScaleWithModelChanges(ScaleWithChanges)
```

C#

```
void SetScaleWithModelChanges(  
    System.bool ScaleWithChanges  
)
```

C++/CLI

```
void SetScaleWithModelChanges(  
& System.bool ScaleWithChanges  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ScaleWithChanges

True scales the section line with changes to the model, false does not

Visual Basic for Applications (VBA) Syntax

See [DrSection::SetScaleWithModelChanges](#).

Example

[Create Section View and Get Some Data \(C#\)](#)
[Create Section View and Get Some Data \(VB.NET\)](#)
[Create Section View and Get Some Data \(VBA\)](#)

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::GetScaleWithModelChanges Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SetTextFormat Method (IDrSection)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDrSection Interface](#) : SetTextFormat Method (IDrSection)

Sets the text format for the text for this section line.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function SetTextFormat( _  
    ByVal UseDoc As System.Boolean, _  
    ByVal TextFormat As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IDrSection  
Dim UseDoc As System.Boolean  
Dim TextFormat As System.Object  
Dim value As System.Boolean  
  
value = instance.SetTextFormat(UseDoc, TextFormat)
```

C#

```
System.bool SetTextFormat(  
    System.bool UseDoc,  
    System.object TextFormat  
)
```

C++/CLI

```
System.bool SetTextFormat(  
& System.bool UseDoc,  
& System.Object^ TextFormat  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDoc

True if set to use the appropriate document default setting, false if it is not (see **Remarks**)

TextFormat

Text format for this section line text

Return Value

True if text format is successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [DrSection::SetTextFormat](#).

Remarks

If UseDoc is True, then use the appropriate document default setting. SOLIDWORKS will also ignore TextFormat, which you should set to NULL

See Also

[IDrSection Interface](#)
[IDrSection Members](#)
[IDrSection::ISetTextFormat Method](#)
[IDrSection::IGetTextFormat Method](#)
[IDrSection::GetTextFormat Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0