

SOLIDWORKS API (.NET VBA C#) — Reference (92/337): IDSPBRMaterial

SOLIDWORKS API Documentation (converted from CHM)

IDSPBRMaterial (Type)

IDSPBRMaterial Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDSPBRMaterial Interface

Allows access to Dassault Systemes Physically Based Rendering (DSPBR) material object.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IDSPBRMaterial

Visual Basic (Usage)

Dim instance As [IDSPBRMaterial](#)

C#

public interface IDSPBRMaterial

C++/CLI

public interface class IDSPBRMaterial

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial](#).

Remarks

The Enterprise PBR Shading Model (DSPBR) is a high-quality, easy-to-use material optimized for performance in real-time and interactive scenarios, suitable for rasterization and ray tracing. Inspired by the Disney Principled BRDF and the Unreal Shading Model, it combines a metallic and a dielectric bidirectional scattering distribution function (BSDF), including transparency for thin-walled and volumetric objects. In addition, it provides effects like emission, clear coat, metallic flakes and sheen to cover a wide range of appearances.

For the DSPBR design rationale and detailed mathematical description in terms of BSDF and related concepts, open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser.

The properties in IDSPBRMaterial map to the appearance settings in the user interface, if the DSPBR appearance is activated in the user interface.

To activate the DSPBR appearance in the SOLIDWORKS Design user interface:

1. Select **System Options > Display > Appearance Visual Style > DSPBR (Dassault Systemes Physically Based Rendering)**.
2. Open a model.
3. Select MMGS in the unit system dropdown below the graphics area.
4. Click **Edit Appearance** in the graphics toolbar.
5. Click the **DSPBR** tab in the FeatureManager.
6. Select **Enterprise PBR Shading Model** from the DSPBR Appearance Type dropdown.

Accessors

[IRenderMaterial::GetDSPBRMaterial](#)

Access Diagram

[DSPBRMaterial](#)

See Also

[IDSPBRMaterial Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

[See Also](#) [Properties](#)

 [SolidWorks.Interop.sldworks](#) Namespace : IDSPBRMaterial Interface

The following tables list the members exposed by [IDSPBRMaterial](#).

Public Properties

Name	Description
 AbbeNumber	Gets or sets the dispersion of this material.
 Albedo	Gets or sets the ratio of reflected radiation to incident radiation.
 AlbedoTexture	Gets or sets the Albedo texture map for this material.
 Anisotropy	Gets or sets the anisotropy strength of this material.
 AnisotropyRotation	Gets or sets the anisotropy rotation angle (counter-clockwise rotation of the tangent space around local normal).
 AttenuationColor	Gets or sets the attenuation color of this material.
 AttenuationDistance	Gets or sets the distance of attenuation in this material.
 Clearcoat	Gets or sets the clearcoat reflectivity of this material.
 ClearcoatNormalStrength	Gets or sets the clearcoat normal strength of this material.
 ClearcoatNormalTexture	Gets or sets the clear coat normal texture map of this material.
 ClearcoatRoughness	Gets or sets the roughness of clearcoat's microfacet distribution in this material.
 CutoutOpacity	Gets or sets the cut-out opacity of this material.
 CutoutOpacityTexture	Gets or sets the cut-out opacity texture map of this material.
 Displacement	Gets or sets the displacement in the direction of the surface normal to add details to the geomtry of this material.
 DisplacementTexture	Gets or sets the displacement texture map for this material.
 EmissionColor	Gets or sets the emission color of this material.
 EmissionColorTexture	Gets or sets the emission color texture map for this material.
 EmissionEnergyNormalization	Gets or sets the emission energy normalization value for this material.
 EmissionMode	Gets or sets the emission mode for this material.
 EmissionValue	Gets or sets the amount of light projected from this appearance.
 FlakeColor	Gets or sets the flake color of this material.
 FlakeCoverage	Gets or sets the flake coverage of this material.
 FlakeRoughness	Gets or sets the roughness of distribution that controls flake orientation in this material.
 FlakeSize	Gets or sets the flake diameter in world space of this material.
 FlakeTexture	Gets or sets the flake texture map of this material.
 FlipFlop	Gets or sets the directional-dependent color (flip flop) effects of this material.
 FlipFlopColor	Gets or sets the flake color at normal incidence if flip flop effect is enabled for this material.
 IndexOfRefraction	Gets or sets the index of refraction for illuminating this appearance.
 Metallic	Gets or sets the metallic-ness of this material.
 MetallicTexture	Gets or sets the metallic texture of this material.
 NormalStrength	Gets or sets the normal strength for this material.
 NormalTexture	Gets or sets the normal texture map for this material.
 RealViewToDSPBRTextureScale	Gets or sets the RealView to DSPBR texture map scale for this material.
 Roughness	Gets or sets the specular spread (roughness) of the appearance.
 RoughnessTexture	Sets or sets the surface roughness texture map for this material.
 SheenColor	Gets or sets the sheen color value for this material.
 SheenRoughness	Gets or sets the roughness of sheen microfacet distribution for this material.

 Specular	Gets or sets the intensity of the light surface for illuminating the appearance.
 SpecularTintColor	Gets or sets the specular tint to adjust the color of the specular lobe near theta = zero degrees for this material.
 SubsurfaceAnisotropy	Gets or sets the subsurface scattering anisotropy value for this material.
 SubsurfaceColor	Gets or sets the subsurface scattering color value for this material.
 SubType	Gets or sets the subtype of this material.
 ThinFilm	Gets or sets the thin film layer weight for this material.
 ThinFilmIOR	Gets or sets the thin film layer index of refraction for this material.
 ThinFilmThickness	Gets or sets the thin film layer thickness for this material.
 ThinFilmThicknessTexture	Gets or sets the thin film layer thickness texture map for this material.
 ThinWalled	Gets or sets whether this material is thin walled.
 Translucency	Gets or sets the degree to which this material is able to filter and diffuse light for illuminating the appearance.
 TranslucencyColor	Gets or sets the translucency color for this material.
 Transparency	Gets or sets the degree to which this material allows light to pass through for illuminating the appearance.
 TransparencyTexture	Gets or sets the transparency texture of this material.
 Version	Gets or sets the version of the model specification used for this material.

[Top](#)

See Also

[IDSPBRMaterial Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDSPBRMaterial Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IDSPBRMaterial Interface

For a list of all members of this type, see [IDSPBRMaterial members](#).

Public Properties

Name	Description
 AbbeNumber	Gets or sets the dispersion of this material.
 Albedo	Gets or sets the ratio of reflected radiation to incident radiation.
 AlbedoTexture	Gets or sets the Albedo texture map for this material.
 Anisotropy	Gets or sets the anisotropy strength of this material.
 AnisotropyRotation	Gets or sets the anisotropy rotation angle (counter-clockwise rotation of the tangent space around local normal).
 AttenuationColor	Gets or sets the attenuation color of this material.
 AttenuationDistance	Gets or sets the distance of attenuation in this material.
 Clearcoat	Gets or sets the clearcoat reflectivity of this material.
 ClearcoatNormalStrength	Gets or sets the clearcoat normal strength of this material.
 ClearcoatNormalTexture	Gets or sets the clear coat normal texture map of this material.
 ClearcoatRoughness	Gets or sets the roughness of clearcoat's microfacet distribution in this material.
 CutoutOpacity	Gets or sets the cut-out opacity of this material.
 CutoutOpacityTexture	Gets or sets the cut-out opacity texture map of this material.
 Displacement	Gets or sets the displacement in the direction of the surface normal to add details to the geomtry of this material.
 DisplacementTexture	Gets or sets the displacement texture map for this material.
 EmissionColor	Gets or sets the emission color of this material.
 EmissionColorTexture	Gets or sets the emission color texture map for this material.

		
	EmissionEnergyNormalization	Gets or sets the emission energy normalization value for this material.
	EmissionMode	Gets or sets the emission mode for this material.
	EmissionValue	Gets or sets the amount of light projected from this appearance.
	FlakeColor	Gets or sets the flake color of this material.
	FlakeCoverage	Gets or sets the flake coverage of this material.
	FlakeRoughness	Gets or sets the roughness of distribution that controls flake orientation in this material.
	FlakeSize	Gets or sets the flake diameter in world space of this material.
	FlakeTexture	Gets or sets the flake texture map of this material.
	FlipFlop	Gets or sets the directional-dependent color (flip flop) effects of this material.
	FlipFlopColor	Gets or sets the flake color at normal incidence if flip flop effect is enabled for this material.
	IndexOfRefraction	Gets or sets the index of refraction for illuminating this appearance.
	Metallic	Gets or sets the metallic-ness of this material.
	MetallicTexture	Gets or sets the metallic texture of this material.
	NormalStrength	Gets or sets the normal strength for this material.
	NormalTexture	Gets or sets the normal texture map for this material.
	RealViewToDSPBRTextureScale	Gets or sets the RealView to DSPBR texture map scale for this material.
	Roughness	Gets or sets the specular spread (roughness) of the appearance.
	RoughnessTexture	Sets or sets the surface roughness texture map for this material.
	SheenColor	Gets or sets the sheen color value for this material.
	SheenRoughness	Gets or sets the roughness of sheen microfacet distribution for this material.
	Specular	Gets or sets the intensity of the light surface for illuminating the appearance.
	SpecularTintColor	Gets or sets the specular tint to adjust the color of the specular lobe near theta = zero degrees for this material.
	SubsurfaceAnisotropy	Gets or sets the subsurface scattering anisotropy value for this material.
	SubsurfaceColor	Gets or sets the subsurface scattering color value for this material.
	SubType	Gets or sets the subtype of this material.
	ThinFilm	Gets or sets the thin film layer weight for this material.
	ThinFilmIOR	Gets or sets the thin film layer index of refraction for this material.
	ThinFilmThickness	Gets or sets the thin film layer thickness for this material.
	ThinFilmThicknessTexture	Gets or sets the thin film layer thickness texture map for this material.
	ThinWalled	Gets or sets whether this material is thin walled.
	Translucency	Gets or sets the degree to which this material is able to filter and diffuse light for illuminating the appearance.
	TranslucencyColor	Gets or sets the translucency color for this material.
	Transparency	Gets or sets the degree to which this material allows light to pass through for illuminating the appearance.
	TransparencyTexture	Gets or sets the transparency texture of this material.
	Version	Gets or sets the version of the model specification used for this material.

[Top](#)

See Also

[IDSPBRMaterial Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : AbbeNumber Property (IDSPBRMaterial)

Gets or sets the dispersion of this material.

.NET Syntax

Visual Basic (Declaration)

```
Property AbbeNumber As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Double
```

```
instance.AbbeNumber = value
```

```
value = instance.AbbeNumber
```

C#

```
System.double AbbeNumber {get; set;}
```

C++/CLI

```
property System.double AbbeNumber {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 (default) <= Abbe number < 500.0

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::AbbeNumber](#).

Remarks

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Abbe number" in the pop up. Click **Next result** repeatedly.
- Search for "Abbe number" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

Albedo Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : Albedo Property (IDSPBRMaterial)

Gets or sets the ratio of reflected radiation to incident radiation.

.NET Syntax

Visual Basic (Declaration)

Property Albedo As System.Integer

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Integer
```

```
instance.Albedo = value
```

```
value = instance.Albedo
```

C#

```
System.int Albedo {get; set;}
```

C++/CLI

```
property System.int Albedo {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Albedo number

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::Albedo](#).

Remarks

This property returns a [COLORREF](#) that is represented as a decimal. The DSPBR tab in the user interface shows colors in RGB format. You can find online converters to convert RGB to hexadecimal or decimal.

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Albedo" in the pop up. Click **Next result** repeatedly.
- Search for "Albedo" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

AlbedoTexture Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : AlbedoTexture Property (IDSPBRMaterial)

Gets or sets the Albedo texture map for this material.

.NET Syntax

Visual Basic (Declaration)

```
Property AlbedoTexture As System.String
```

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.String
```

```
instance.AlbedoTexture = value  
value = instance.AlbedoTexture
```

C#

```
System.string AlbedoTexture {get; set;}
```

C++/CLI

```
property System.String^ AlbedoTexture {  
    System.String^ get();  
    void set ( &    System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the Albedo texture map for this material.

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::AlbedoTexture](#).

Remarks

Search for "Albedo texture" in the web to obtain more information about this property.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments](#) on this topic.

Anisotropy Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : Anisotropy Property (IDSPBRMaterial)

Gets or sets the anisotropy strength of this material.

.NET Syntax

Visual Basic (Declaration)

```
Property Anisotropy As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Double
```

```
instance.Anisotropy = value
```

```
value = instance.Anisotropy
```

C#

```
System.double Anisotropy {get; set;}
```

C++/CLI

```
property System.double Anisotropy {  
    System.double get();
```



```
void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 (default) <= Anisotropy strength <= 1.0

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::Anisotropy](#).

Remarks

For more information about this property:

- Open <https://dassaultsystems-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Anisotropy" in the pop up. Click **Next result** repeatedly.
- Search for "Anisotropy strength" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

AnisotropyRotation Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : AnisotropyRotation Property (IDSPBRMaterial)

Gets or sets the anisotropy rotation angle (counter-clockwise rotation of the tangent space around local normal).

.NET Syntax

Visual Basic (Declaration)

Property AnisotropyRotation As System.Double

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Double  
  
instance.AnisotropyRotation = value  
  
value = instance.AnisotropyRotation
```

C#

```
System.double AnisotropyRotation {get; set;}
```

C++/CLI

```
property System.double AnisotropyRotation {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 (0 degrees) default <= Anisotropy rotation value <= 1.0 (360 degrees)

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::AnisotropyRotation](#).

Remarks

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Anisotropy rotation" in the pop up. Click **Next result** repeatedly.
- Search for "Anisotropy rotation values of materials" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

AttenuationColor Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : AttenuationColor Property (IDSPBRMaterial)

Gets or sets the attenuation color of this material.

.NET Syntax

Visual Basic (Declaration)

```
Property AttenuationColor As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Integer  
  
instance.AttenuationColor = value  
value = instance.AttenuationColor
```

C#

```
System.int AttenuationColor {get; set;}
```

C++/CLI

```
property System.int AttenuationColor {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Attenuation color

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::AttenuationColor](#).

Remarks

This property returns a [COLORREF](#) that is represented as a decimal. The DSPBR tab in the user interface shows colors in RGB format. You can find online converters to convert RGB to hexadecimal or decimal.

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Attenuation color" in the pop up. Click **Next result** repeatedly.
- Search for "attenuation color" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

AttenuationDistance Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : AttenuationDistance Property (IDSPBRMaterial)

Gets or sets the distance of attenuation in this material.

.NET Syntax

Visual Basic (Declaration)

Property AttenuationDistance As System.Double

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Double
```

```
instance.AttenuationDistance = value
```

```
value = instance.AttenuationDistance
```

C#

```
System.double AttenuationDistance {get; set;}
```

C++/CLI

```
property System.double AttenuationDistance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 <= Distance of attenuation < 500000.0 (default)

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::AttenuationDistance](#).

Remarks

If this property is 0.0, the surface is opaque.

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Attenuation distance" in the po
- up. Click **Next result** repeatedly.
- Search for "attenuation distance" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

Clearcoat Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : Clearcoat Property (IDSPBRMaterial)

Gets or sets the clearcoat reflectivity of this material.

.NET Syntax

Visual Basic (Declaration)

Property Clearcoat As System.Double

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial
Dim value As System.Double
```

```
instance.Clearcoat = value
```

```
value = instance.Clearcoat
```

C#

```
System.double Clearcoat {get; set;}
```

C++/CLI

```
property System.double Clearcoat {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 (default) <= Clearcoat reflectivity <= 1.0

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::Clearcoat](#).

Remarks

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Clearcoat" in the pop up. Click **Next result** repeatedly.
- Search for "clearcoat" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

ClearcoatNormalStrength Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : ClearcoatNormalStrength Property (IDSPBRMaterial)

Gets or sets the clearcoat normal strength of this material.

.NET Syntax

Visual Basic (Declaration)

Property ClearcoatNormalStrength As System.Double

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial
Dim value As System.Double

instance.ClearcoatNormalStrength = value

value = instance.ClearcoatNormalStrength
```

C#

```
System.double ClearcoatNormalStrength {get; set;}
```

C++/CLI

```
property System.double ClearcoatNormalStrength {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Clearcoat normal strength

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::ClearcoatNormalStrength](#).

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 SP01, Revision Number 34.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ClearcoatNormalTexture Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : ClearcoatNormalTexture Property (IDSPBRMaterial)

Gets or sets the clear coat normal texture map of this material.

.NET Syntax

Visual Basic (Declaration)

Property ClearcoatNormalTexture As System.String

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial
Dim value As System.String

instance.ClearcoatNormalTexture = value

value = instance.ClearcoatNormalTexture
```

C#

```
System.string ClearcoatNormalTexture {get; set;}
```

C++/CLI

```
property System.String^ ClearcoatNormalTexture {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the clear coat normal texture map

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::ClearcoatNormalTexture](#).

Remarks

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Clearcoat normal" in the pop up. Click **Next result** repeatedly.
- Search for "clearcoat normal texture" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

ClearcoatRoughness Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : ClearcoatRoughness Property (IDSPBRMaterial)

Gets or sets the roughness of clearcoat's microfacet distribution in this material.

.NET Syntax

Visual Basic (Declaration)

```
Property ClearcoatRoughness As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial
Dim value As System.Double

instance.ClearcoatRoughness = value
value = instance.ClearcoatRoughness
```

C#

```
System.double ClearcoatRoughness {get; set;}
```

C++/CLI

```
property System.double ClearcoatRoughness {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 (default) <= Clear coat roughness value <= 1.0

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::ClearcoatRoughness](#).

Remarks

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Clearcoat" in the pop up. Click **Next result** repeatedly.
- Search for "clearcoat roughness" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

CutoutOpacity Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : CutoutOpacity Property (IDSPBRMaterial)

Gets or sets the cut-out opacity of this material.

.NET Syntax

Visual Basic (Declaration)

Property CutoutOpacity As System.Double

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Double
```

```
instance.CutoutOpacity = value
```

```
value = instance.CutoutOpacity
```

C#

```
System.double CutoutOpacity {get;set;}
```

C++/CLI

```
property System.double CutoutOpacity {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 (transparent) <= Cut-out opacity <= 1.0 (opaque) default

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::CutoutOpacity](#).

Remarks

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Cut-out opacity" in the pop up. Click **Next result** repeatedly.
- Search for "cut-out opacity" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

CutoutOpacityTexture Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : CutoutOpacityTexture Property (IDSPBRMaterial)

Gets or sets the cut-out opacity texture map of this material.

.NET Syntax

Visual Basic (Declaration)

```
Property CutoutOpacityTexture As System.String
```

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.String  
  
instance.CutoutOpacityTexture = value  
value = instance.CutoutOpacityTexture
```

C#

```
System.string CutoutOpacityTexture {get; set;}
```

C++/CLI

```
property System.String^ CutoutOpacityTexture {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the cut-out opacity texture map

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::CutoutOpacityTexture](#).

Remarks

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Cut-out texture" in the pop up. Click **Next result** repeatedly.
- Search for "cut-out opacity texture map" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

Displacement Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : Displacement Property (IDSPBRMaterial)

Gets or sets the displacement in the direction of the surface normal to add details to the geomtry of this material.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property Displacement As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial
Dim value As System.Double
```

```
instance.Displacement = value
```

```
value = instance.Displacement
```

C#

```
System.double Displacement {get; set;}
```

C++/CLI

```
property System.double Displacement {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 (default) < Displacement value (mm) < 500000.0

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::Displacement](#).

Remarks

For more information about this property:

- Open <https://dassaultsystems-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Displacement" in the pop up. Click **Next result** repeatedly.
- Search for "displacement texture map" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

DisplacementTexture Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : DisplacementTexture Property (IDSPBRMaterial)

Gets or sets the displacement texture map for this material.

Visual Basic Syntax

Visual Basic (Declaration)

Property DisplacementTexture As System.String

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial
Dim value As System.String

instance.DisplacementTexture = value
value = instance.DisplacementTexture
```

C#

```
System.string DisplacementTexture {get; set;}
```

C++/CLI

```
property System.String^ DisplacementTexture {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Displacement texture map

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::DisplacementTexture](#).

Remarks

For more information about this property, search for "displacement texture map" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

EmissionColor Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : EmissionColor Property (IDSPBRMaterial)

Gets or sets the emission color of this material.

Visual Basic Syntax

Visual Basic (Declaration)

Property EmissionColor As System.Integer

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial
Dim value As System.Integer
```

```
instance.EmissionColor = value  
value = instance.EmissionColor
```

C#

```
System.int EmissionColor {get; set;}
```

C++/CLI

```
property System.int EmissionColor {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Emission color

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::EmissionColor](#).

Remarks

This property returns a [COLORREF](#) that is represented as a decimal. The DSPBR tab in the user interface shows colors in RGB format. You can find online converters to convert RGB to hexadecimal or decimal.

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Emission color" in the pop up. Click **Next result** repeatedly.
- Search for "emission color" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments](#) on this topic.

EmissionColorTexture Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : EmissionColorTexture Property (IDSPBRMaterial)

Gets or sets the emission color texture map for this material.

.NET Syntax

Visual Basic (Declaration)

```
Property EmissionColorTexture As System.String
```

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.String
```

```
instance.EmissionColorTexture = value
```

```
value = instance.EmissionColorTexture
```

C#

```
System.string EmissionColorTexture {get; set;}
```

C++/CLI

```
property System.String^ EmissionColorTexture {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the emission color texture map

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::EmissionColorTexture](#).

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 SP01, Revision Number 34.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

EmissionEnergyNormalization Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : EmissionEnergyNormalization Property (IDSPBRMaterial)

Gets or sets the emission energy normalization value for this material.

.NET Syntax

Visual Basic (Declaration)

```
Property EmissionEnergyNormalization As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Integer
```

```
instance.EmissionEnergyNormalization = value  
value = instance.EmissionEnergyNormalization
```

C#

```
System.int EmissionEnergyNormalization {get; set;}
```

C++/CLI

```
property System.int EmissionEnergyNormalization {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True (1) to enable emission energy normalization, default false (0) to not

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::EmissionEnergyNormalization](#).

Remarks

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Normalize emission color" in the pop up. Click **Next result** repeatedly.
- Search for "Emission energy normalization in materials" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

EmissionMode Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : EmissionMode Property (IDSPBRMaterial)

Gets or sets the emission mode for this material.

.NET Syntax

Visual Basic (Declaration)

```
Property EmissionMode As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Integer
```

```
instance.EmissionMode = value
```

```
value = instance.EmissionMode
```

C#

```
System.int EmissionMode {get; set;}
```

C++/CLI

```
property System.int EmissionMode {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0 = luminous emittance (default) or 1 = luminous power

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::EmissionMode](#).

Remarks

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Emission mode" in the pop up. Click **Next result** repeatedly.
- Search for "emission mode" on the web.

See Also

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments](#) on this topic.

EmissionValue Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : EmissionValue Property (IDSPBRMaterial)

Gets or sets the amount of light projected from this appearance.

.NET Syntax

Visual Basic (Declaration)

Property EmissionValue As System.Double

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Double
```

```
instance.EmissionValue = value
```

```
value = instance.EmissionValue
```

C#

```
System.double EmissionValue {get; set;}
```

C++/CLI

```
property System.double EmissionValue {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 (default) <= Emission (w/srm^2) < 500.0

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::EmissionValue](#).

Remarks

The [IDSPBRMaterial::EmissionMode](#) determines the units of this property's value.

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Emission value" in the pop up. Click **Next result** repeatedly.
- Search for "emissivity in materials" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments](#) on this topic.

FlakeColor Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : FlakeColor Property (IDSPBRMaterial)

Gets or sets the flake color of this material.

.NET Syntax

Visual Basic (Declaration)

Property FlakeColor As System.Integer

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Integer
```

```
instance.FlakeColor = value
```

```
value = instance.FlakeColor
```

C#

```
System.int FlakeColor {get; set;}
```

C++/CLI

```
property System.int FlakeColor {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Flake color

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::FlakeColor](#).

Remarks

This property returns a [COLORREF](#) that is represented as a decimal. The DSPBR tab in the user interface shows colors in RGB format. You can find online converters to convert RGB to hexadecimal or decimal.

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Flake color" in the pop up. Click **Next result** repeatedly.
- Search for "flake color in materials science" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

FlakeCoverage Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : FlakeCoverage Property (IDSPBRMaterial)

Gets or sets the flake coverage of this material.

.NET Syntax

Visual Basic (Declaration)

Property FlakeCoverage As System.Double

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Double
```

```
instance.FlakeCoverage = value  
value = instance.FlakeCoverage
```

C#

```
System.double FlakeCoverage {get; set;}
```

C++/CLI

```
property System.double FlakeCoverage {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 (no flakes) default <= Flake coverage <= 1.0 (only flakes)

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::FlakeCoverage](#).

Remarks

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Flake coverage" in the pop up. Click **Next result** repeatedly.
- Search for "flake coverage in materials science" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

FlakeRoughness Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : FlakeRoughness Property (IDSPBRMaterial)

Gets or sets the roughness of distribution that controls flake orientation in this material.

.NET Syntax

Visual Basic (Declaration)

Property FlakeRoughness As System.Double

Visual Basic (Usage)




```
Dim instance As IDSPBRMaterial  
Dim value As System.Double
```

```
instance.FlakeRoughness = value
```

```
value = instance.FlakeRoughness
```

C#

```
System.double FlakeRoughness {get; set;}
```

C++/CLI

```
property System.double FlakeRoughness {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 (default) <= Flake roughness <= 1.0

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::FlakeRoughness](#).

Remarks

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Flake" in the pop up. Click **Nex result** repeatedly.
- Search for "flake roughness in materials science" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

FlakeSize Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : FlakeSize Property (IDSPBRMaterial)

Gets or sets the flake diameter in world space of this material.

.NET Syntax

Visual Basic (Declaration)

```
Property FlakeSize As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Double
```

```
instance.FlakeSize = value
```

```
value = instance.FlakeSize
```

C#

```
System.double FlakeSize {get; set;}
```

C++/CLI

```
property System.double FlakeSize {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 (default) <= Flake size (mm) < 500000.0

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::FlakeSize](#).

Remarks

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Flake size" in the pop up. Click **Next result** repeatedly.
- Search for "flake size in materials science" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

FlakeTexture Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : FlakeTexture Property (IDSPBRMaterial)

Gets or sets the flake texture map of this material.

.NET Syntax

Visual Basic (Declaration)

```
Property FlakeTexture As System.String
```

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.String
```

```
instance.FlakeTexture = value
```

```
value = instance.FlakeTexture
```

C#

```
System.string FlakeTexture {get; set;}
```

C++/CLI

```
property System.String^ FlakeTexture {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Flake texture map

 Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::FlakeTexture](#).

 Remarks

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Flake texture" in the pop up. Click **Next result** repeatedly.
- Search for "flake texture in materials science" on the web.

 See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

 Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

FlipFlop Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : FlipFlop Property (IDSPBRMaterial)

Gets or sets the directional-dependent color (flip flop) effects of this material.

 .NET Syntax

Visual Basic (Declaration)

Property FlipFlop As System.Double

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Double
```

```
instance.FlipFlop = value
```

```
value = instance.FlipFlop
```

C#

```
System.double FlipFlop {get; set;}
```

C++/CLI

```
property System.double FlipFlop {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 (none) default <= Flip flop value <= 1.0 (full)

 Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::FlipFlop](#).

Remarks

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Flip-flop" in the pop up. Click **Next result** repeatedly.
- Search for "Flipflop in materials science and engineering" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

FlipFlopColor Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : FlipFlopColor Property (IDSPBRMaterial)

Gets or sets the flake color at normal incidence if flip flop effect is enabled for this material.

.NET Syntax

Visual Basic (Declaration)

Property FlipFlopColor As System.Integer

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Integer
```

```
instance.FlipFlopColor = value
```

```
value = instance.FlipFlopColor
```

C#

```
System.int FlipFlopColor {get; set;}
```

C++/CLI

```
property System.int FlipFlopColor {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Flip flop color

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::FlipFlopColor](#).

Remarks

This property:

- is valid only if [IDSPBRMaterial::FlipFlop](#) is enabled.
- returns a [COLORREF](#) that is represented as a decimal. The DSPBR tab in the user interface shows colors in RGB format. You can find online converters to convert RGB to hexadecimal or decimal. Search for "Flipflop color in materials science and engineering" in your browser to obtain more information about this property.

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Flake color at normal incidence" in the pop up. Click **Next result** repeatedly.
- Search for "Flipflop in materials science and engineering" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

IndexOfRefraction Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : IndexOfRefraction Property (IDSPBRMaterial)

Gets or sets the index of refraction for illuminating this appearance.

.NET Syntax

Visual Basic (Declaration)

Property IndexOfRefraction As System.Double

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Double  
  
instance.IndexOfRefraction = value  
  
value = instance.IndexOfRefraction
```

C#

```
System.double IndexOfRefraction {get; set;}
```

C++/CLI

```
property System.double IndexOfRefraction {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

1.0 <= Refractive index < 500.0; 1.5 is the default

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::IndexOfRefraction](#).

Remarks

This property controls the bending of light as it passes through a transparent object. Although actually dependent on the ratio of indices between the transparent material entered and the material exited, in practice, the higher the index of refraction, the more the light is bent. Typical values are 1.0 for air, 1.33 for water, and 1.44 for glass.

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Index of refraction" in the pop up. Click **Next result** repeatedly.
- Search for "Refractive index" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

Metallic Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : Metallic Property (IDSPBRMaterial)

Gets or sets the metallic-ness of this material.

.NET Syntax

Visual Basic (Declaration)

Property Metallic As System.Double

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial
Dim value As System.Double
```

```
instance.Metallic = value
```

```
value = instance.Metallic
```

C#

```
System.double Metallic {get; set;}
```

C++/CLI

```
property System.double Metallic {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 (dielectric) default <= Metallic-ness value <= 1.0 (metallic)

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::Metallic](#).

Remarks

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Metallic" in the pop up. Click **Next result** repeatedly.
- Search for "Metallic vs metal" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

MetallicTexture Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : MetallicTexture Property (IDSPBRMaterial)

Gets or sets the metallic texture of this material.

.NET Syntax

Visual Basic (Declaration)

Property MetallicTexture As System.String

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.String  
  
instance.MetallicTexture = value  
  
value = instance.MetallicTexture
```

C#

```
System.string MetallicTexture {get; set;}
```

C++/CLI

```
property System.String^ MetallicTexture {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the metallic texture map

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial.MetallicTexture](#).

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 SP01, Revision Number 34.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

NormalStrength Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : NormalStrength Property (IDSPBRMaterial)

Gets or sets the normal strength for this material.

.NET Syntax

Visual Basic (Declaration)

Property NormalStrength As System.Double

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Double  
  
instance.NormalStrength = value  
  
value = instance.NormalStrength
```

C#

```
System.double NormalStrength {get; set;}
```

C++/CLI

```
property System.double NormalStrength {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Normal strength

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::NormalStrength](#).

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 SP01, Revision Number 34.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

NormalTexture Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : NormalTexture Property (IDSPBRMaterial)

Gets or sets the normal texture map for this material.

.NET Syntax

Visual Basic (Declaration)

```
Property NormalTexture As System.String
```

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.String  
  
instance.NormalTexture = value  
value = instance.NormalTexture
```

C#

```
System.string NormalTexture {get; set;}
```

C++/CLI

```
property System.String^ NormalTexture {  
    System.String^ get();  
    void set ( &    System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the normal texture map

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::NormalTexture](#).

Remarks

Search for "Normal texture map" on the web to obtain more information about this property.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

RealViewToDSPBRTextureScale Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : RealViewToDSPBRTextureScale Property (IDSPBRMaterial)

Gets or sets the RealView to DSPBR texture map scale for this material.

.NET Syntax

Visual Basic (Declaration)

```
Property RealViewToDSPBRTextureScale As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Double
```

```
instance.RealViewToDSPBRTextureScale = value
```

```
value = instance.RealViewToDSPBRTextureScale
```

C#

```
System.double RealViewToDSPBRTextureScale {get; set;}
```

C++/CLI

```
property System.double RealViewToDSPBRTextureScale {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

RealView to DSPBR texture map scale

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::RealViewToDSPBRTextureScale](#).

Remarks

Search for "RealView texture map scale" on the web to obtain more information about this property.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

Roughness Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : Roughness Property (IDSPBRMaterial)

Gets or sets the specular spread (roughness) of the appearance.

.NET Syntax

Visual Basic (Declaration)

Property Roughness As System.Double

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial
Dim value As System.Double
```

```
instance.Roughness = value
```

```
value = instance.Roughness
```

C#

```
System.double Roughness {get; set;}
```

C++/CLI

```
property System.double Roughness {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 (default) <= Specular spread <= 1.0

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::Roughness](#).

Remarks

This property controls the size of any highlights on a surface. It is also known as the specular exponent. Increasing roughness makes highlights larger and softer.

The [specular](#) value must not be zero, the [specular tint color](#) must not be black, and at least one light other than an ambient light must be illuminating the model.

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Roughness" in the pop up. Click **Next result** repeatedly.
- Search for "roughness in materials" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

RoughnessTexture Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : RoughnessTexture Property (IDSPBRMaterial)

Sets or sets the surface roughness texture map for this material.

.NET Syntax

Visual Basic (Declaration)

Property RoughnessTexture As System.String

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial
Dim value As System.String

instance.RoughnessTexture = value

value = instance.RoughnessTexture
```

C#

```
System.string RoughnessTexture {get; set;}
```

C++/CLI

```
property System.String^ RoughnessTexture {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the roughness texture map

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::RoughnessTexture](#).

Remarks

Search for "Roughness texture maps in materials" on the web to obtain more information about this property.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SheenColor Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : SheenColor Property (IDSPBRMaterial)

Gets or sets the sheen color value for this material.

.NET Syntax

Visual Basic (Declaration)

Property SheenColor As System.Integer

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Integer  
  
instance.SheenColor = value  
  
value = instance.SheenColor
```

C#

```
System.int SheenColor {get; set;}
```

C++/CLI

```
property System.int SheenColor {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Sheen color

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::SheenColor](#).

Remarks

This property returns a [COLORREF](#) that is represented as a decimal. The DSPBR tab in the user interface shows colors in RGB format. You can find online converters to convert RGB to hexadecimal or decimal.

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Sheen color" in the pop up. Click **Next result** repeatedly.
- Search for "Sheen color in materials science" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

SheenRoughness Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : SheenRoughness Property (IDSPBRMaterial)

Gets or sets the roughness of sheen microfacet distribution for this material.

.NET Syntax

Visual Basic (Declaration)

```
Property SheenRoughness As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Double
```

```
instance.SheenRoughness = value
```

```
value = instance.SheenRoughness
```

C#

```
System.double SheenRoughness {get; set;}
```

C++/CLI

```
property System.double SheenRoughness {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 <= Sheen roughness <= 1.0; 0.5 is the default

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::SheenRoughness](#).

Remarks

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Sheen" in the pop up. Click **Ne result** repeatedly.
- Search for "Sheen roughness in materials science" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

Specular Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : Specular Property (IDSPBRMaterial)

Gets or sets the intensity of the light surface for illuminating the appearance.

.NET Syntax

Visual Basic (Declaration)

```
Property Specular As System.Double
```

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Double
```

```
instance.Specular = value
```

```
value = instance.Specular
```

C#

```
System.double Specular {get; set;}
```

C++/CLI

```
property System.double Specular {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 <= Specular value <= 1.0 (default)

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::Specular](#).

Remarks

This property depends on the position of the light source and the position of the viewer. Increasing specular makes the material appear shinier.

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Specular" in the pop up. Click **Next result** repeatedly.
- Search for "Specular in materials science" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

SpecularTintColor Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : SpecularTintColor Property (IDSPBRMaterial)

Gets or sets the specular tint to adjust the color of the specular lobe near theta = zero degrees for this material.

.NET Syntax

Visual Basic (Declaration)

```
Property SpecularTintColor As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial
Dim value As System.Integer

instance.SpecularTintColor = value
value = instance.SpecularTintColor
```

C#

```
System.int SpecularTintColor {get; set;}
```

C++/CLI

```
property System.int SpecularTintColor {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Specular tint

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::SpecularTintColor](#).

Remarks

This property returns a [COLORREF](#) that is represented as a decimal. The DSPBR tab in the user interface shows colors in RGB format. You can find online converters to convert RGB to hexadecimal or decimal.

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Specular tint" in the pop up. Click **Next result** repeatedly.
- Search for "Specular tint color in materials science" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

SubsurfaceAnisotropy Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : SubsurfaceAnisotropy Property (IDSPBRMaterial)

Gets or sets the subsurface scattering anisotropy value for this material.

.NET Syntax

Visual Basic (Declaration)

Property SubsurfaceAnisotropy As System.Double

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial
Dim value As System.Double

instance.SubsurfaceAnisotropy = value
value = instance.SubsurfaceAnisotropy
```

C#

```
System.double SubsurfaceAnisotropy {get; set;}
```

C++/CLI

```
property System.double SubsurfaceAnisotropy {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

- 1.0 (backward scattering) <= Subsurface scattering anisotropy value <= 1.0 (forward scattering)

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::SubsurfaceAnisotropy](#).

Remarks

The default value of this property is 0.0 for isotropic scattering.

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Subsurface anisotropy" in the pop up. Click **Next result** repeatedly.
- Search for "Subsurface scattering anisotropy in materials science" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

SubsurfaceColor Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : SubsurfaceColor Property (IDSPBRMaterial)

Gets or sets the subsurface scattering color value for this material.

.NET Syntax

Visual Basic (Declaration)

Property SubsurfaceColor As System.Integer

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Integer
```

```
instance.SubsurfaceColor = value
```

```
value = instance.SubsurfaceColor
```

C#

```
System.int SubsurfaceColor {get; set;}
```

C++/CLI

```
property System.int SubsurfaceColor {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Subsurface scattering color

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::SubsurfaceColor](#).

Remarks

This property returns a [COLORREF](#) that is represented as a decimal. The DSPBR tab in the user interface shows colors in RGB format. You can find online converters to convert RGB to hexadecimal or decimal.

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Subsurface color" in the pop up. Click **Next result** repeatedly.
- Search for "Subsurface scattering color in materials science" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

SubType Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : SubType Property (IDSPBRMaterial)

Gets or sets the subtype of this material.

.NET Syntax

Visual Basic (Declaration)

```
Property SubType As System.String
```

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.String
```

```
instance.SubType = value
```

```
value = instance.SubType
```

C#

```
System.string SubType {get; set;}
```

C++/CLI

```
property System.String^ SubType {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of this material's subtype

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::SubType](#).

Remarks

Use the following subtypes to expose subsets of parameters:

"Car Paint"

"Metal"

"Emissive"

"Textile"

"Leather"

"Wood"

"Glass"

"Plastic"

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Material Subtypes" in the pop up. Click **Next result** repeatedly.
- Search for "Accessing Material Types" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

ThinFilm Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : ThinFilm Property (IDSPBRMaterial)

Gets or sets the thin film layer weight for this material.

.NET Syntax

Visual Basic (Declaration)

Property ThinFilm As System.Double

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Double
```

```
instance.ThinFilm = value
```

```
value = instance.ThinFilm
```

C#

```
System.double ThinFilm {get; set;}
```

C++/CLI

```
property System.double ThinFilm {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 (default) <= Thin film layer weight <= 1.0

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::ThinFilm](#).

Remarks

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Thin film" in the pop up. Click **Next result** repeatedly.
- Search for "Thin films" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

ThinFilmIOR Property (IDSPBRMaterial)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : ThinFilmIOR Property (IDSPBRMaterial)

Gets or sets the thin film layer index of refraction for this material.

.NET Syntax

Visual Basic (Declaration)

Property ThinFilmIOR As System.Double

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial
Dim value As System.Double
```

```
instance.ThinFilmIOR = value
```

```
value = instance.ThinFilmIOR
```

C#

```
System.double ThinFilmIOR {get; set;}
```

C++/CLI

```
property System.double ThinFilmIOR {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).**Property Value**

1.0 <= Thin film layer index of refraction <= 2.5; 1.3 is the default

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::ThinFilmThicknessIOR](#).

Remarks

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Index of refraction of the thin-film layer" in the pop up. Click **Next result** repeatedly.
- Search for "Thin film index of refraction" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

ThinFilmThickness Property (IDSPBRMaterial)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : ThinFilmThickness Property (IDSPBRMaterial)

Gets or sets the thin film layer thickness for this material.

.NET Syntax

Visual Basic (Declaration)

Property ThinFilmThickness As System.Double

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial
Dim value As System.Double

instance.ThinFilmThickness = value
value = instance.ThinFilmThickness
```

C#

```
System.double ThinFilmThickness {get; set;}
```

C++/CLI

```
property System.double ThinFilmThickness {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 <= Thin film layer thickness in microns <= 1.0; 0.4 is the default

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::ThinFilmThickness](#).

Remarks

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Thickness of the thin-film layer" in the pop up. Click **Next result** repeatedly.
- Search for "Thin films" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

ThinFilmThicknessTexture Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : ThinFilmThicknessTexture Property (IDSPBRMaterial)

Gets or sets the thin film layer thickness texture map for this material.

.NET Syntax

Visual Basic (Declaration)

Property ThinFilmThicknessTexture As System.String

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial
Dim value As System.String

instance.ThinFilmThicknessTexture = value

value = instance.ThinFilmThicknessTexture
```

C#

```
System.string ThinFilmThicknessTexture {get; set;}
```

C++/CLI

```
property System.String^ ThinFilmThicknessTexture {
    System.String^ get();
    void set ( &    System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the thin film layer thickness texture map

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::ThinFilmThicknessTexture](#).

Remarks

For more information about this property, search for "Thin film thickness texture map" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments](#) on this topic.

ThinWalled Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : ThinWalled Property (IDSPBRMaterial)

Gets or sets whether this material is thin walled.

.NET Syntax

Visual Basic (Declaration)

```
Property ThinWalled As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial
Dim value As System.Integer

instance.ThinWalled = value

value = instance.ThinWalled
```

C#

```
System.int ThinWalled {get; set;}
```

C++/CLI

```
property System.int ThinWalled {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True (1) if thin walled (default), false (0) if material describes volume boundary

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::ThinWalled](#).

Remarks

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Thin-walled" in the pop up. Click **Next result** repeatedly.
- Search for "Thin walled value in materials science" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments](#) on this topic.

Translucency Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : Translucency Property (IDSPBRMaterial)

Gets or sets the degree to which this material is able to filter and diffuse light for illuminating the appearance.

.NET Syntax

Visual Basic (Declaration)

Property Translucency As System.Double

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial
Dim value As System.Double
```

```
instance.Translucency = value
```

```
value = instance.Translucency
```

C#

```
System.double Translucency {get; set;}
```

C++/CLI

```
property System.double Translucency {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 (opaque) default <= Translucency <= 1.0 (translucent)

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::Translucency](#).

Remarks

Increasing translucency gives the material more backlighting.

A light must be behind the model relative to the position of the viewer.

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Translucency" in the pop up. Click **Next result** repeatedly.
- Search for "Translucency in materials science" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

TranslucencyColor Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : TranslucencyColor Property (IDSPBRMaterial)

Gets or sets the translucency color for this material.

.NET Syntax

Visual Basic (Declaration)

Property TranslucencyColor As System.Integer

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Integer
```

```
instance.TranslucencyColor = value
```

```
value = instance.TranslucencyColor
```

C#

```
System.int TranslucencyColor {get; set;}
```

C++/CLI

```
property System.int TranslucencyColor {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Translucency color

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::TranslucencyColor](#).

Remarks

This property returns a [COLORREF](#) that is represented as a decimal. The DSPBR tab in the user interface shows colors in RGB format. You can find online converters to convert RGB to hexadecimal or decimal.

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Translucency color" in the pop up. Click **Next result** repeatedly.
- Search for "Translucency color in materials science" on the web.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

Transparency Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : Transparency Property (IDSPBRMaterial)

Gets or sets the degree to which this material allows light to pass through for illuminating the appearance.

.NET Syntax

Visual Basic (Declaration)

Property Transparency As System.Double

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.Double
```

```
instance.Transparency = value  
value = instance.Transparency
```

C#

```
System.double Transparency {get; set;}
```

C++/CLI

```
property System.double Transparency {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.0 (opaque) default <= Transparency <= 1.0 (translucent)

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::Transparency](#).

Remarks

For more information about this property:

- Open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Transparency" in the pop up. Click **Next result** repeatedly.
- Search for "Transparency in materials science" on the web.

See Also

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments](#) on this topic.

TransparencyTexture Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : TransparencyTexture Property (IDSPBRMaterial)

Gets or sets the transparency texture of this material.

.NET Syntax

Visual Basic (Declaration)

Property TransparencyTexture As System.String

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.String  
  
instance.TransparencyTexture = value  
value = instance.TransparencyTexture
```

C#

```
System.string TransparencyTexture {get; set;}
```

C++/CLI

```
property System.String^ TransparencyTexture {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the transparency texture map

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::TransparencyTexture](#).

See Also

Availability

SOLIDWORKS 2026 SP01, Revision Number 34.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

Version Property (IDSPBRMaterial)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IDSPBRMaterial Interface](#) : Version Property (IDSPBRMaterial)

Gets or sets the version of the model specification used for this material.

.NET Syntax

Visual Basic (Declaration)

Property Version As System.String

Visual Basic (Usage)



```
Dim instance As IDSPBRMaterial  
Dim value As System.String
```

```
instance.Version = value
```

```
value = instance.Version
```

C#

```
System.string Version {get; set;}
```

C++/CLI

```
property System.String^ Version {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Version 2025x

Visual Basic for Applications (VBA) Syntax

See [DSPBRMaterial::Version](#).

Remarks

For more information about versions of the DSPBR Shading Model, open <https://dassaultsystemes-technology.github.io/EnterprisePBRShadingModel/spec-2025x.md.html> in an internet browser, click CTRL-F and type "Changelog" in the pop up. Click **Next result** repeatedly.

See Also

[IDSPBRMaterial Interface](#)
[IDSPBRMaterial Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34