

SOLIDWORKS API (.NET VBA C#) — Reference (947337): IEdgeFlangeFeatureData-IEdgePoint

SOLIDWORKS API Documentation (converted from CHM)

IEdgeFlangeFeatureData (Type)

IEdgeFlangeFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IEdgeFlangeFeatureData Interface

Allows access to a sheet metal edge flange feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IEdgeFlangeFeatureData

Visual Basic (Usage)

Dim instance As [IEdgeFlangeFeatureData](#)

C#

public interface IEdgeFlangeFeatureData

C++/CLI

public interface class IEdgeFlangeFeatureData

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData](#).

Example

```
'VBA
'-----
' Preconditions: Open install_dir\samples\tutorial\sheetmetallformtools\cover.sldprt.
'
' Postconditions: Creates Edge-Flange1 in the FeatureManager design tree.
'-----

Option Explicit

Sub main()

    Dim swApp As SldWorks.SldWorks
    Dim swModel      As SldWorks.ModelDoc2
    Dim bValue       As Boolean
    Dim swEdge       As SldWorks.Edge
    Dim dAngle       As Double
    Dim dLength      As Double
    Dim swFeature     As SldWorks.Feature
    Dim swEntity      As SldWorks.Entity
    Dim swSketch      As SldWorks.Sketch
    Dim vSketchSegments As Variant
    Dim swSketchLine  As SldWorks.SketchLine
    Dim swStartPoint  As SldWorks.SketchPoint
    Dim swEndPoint    As SldWorks.SketchPoint
    Dim dSize         As Double
    Dim dFactor1      As Double
    Dim dFactor2      As Double
    Dim aFlangeEdges(0) As SldWorks.Edge
    Dim vFlangeEdges  As Variant
    Dim aSketchFeats(0) As SldWorks.Sketch
    Dim vSketchFeats  As Variant
    Dim FeatData      As EdgeFlangeFeatureData
    Dim edgeFlangeFeat As SldWorks.Feature
    Dim PBendData As SldWorks.CustomBendAllowance

    Set swApp = Application.SldWorks
    Set swModel = swApp.ActiveDoc
```

```

' Flange angle
dAngle = (90# / 180#) * 3.1415926535897

' Flange length
dLength = 0.02

swModel.ShowNamedView2 "**Back", -1
swModel.ViewZoomtofit2

' Select edge
bValue = swModel.Extension.SelectByRay(3.53852695288734E-02, 5.27495553160953E-02, 4.85267999999905E-02, 0, 0, 1,
2.83299018635423E-04, 1, False, 0, 0)
Set swEdge = swModel.SelectionManager.GetSelectedObject6(1, -1)

' Insert a sketch of the edge flange
Set swFeature = swModel.InsertSketchForEdgeFlange(swEdge, dAngle, False)
bValue = swFeature.Select2(False, 0)

swModel.EditSketch
Set swSketch = swModel.GetActiveSketch2

Set swEntity = swEdge

' Select edge
bValue = swEntity.Select4(False, Nothing)

' Use the edge in the sketch
bValue = swModel.SketchManager.SketchUseEdge(False)

' Get the created sketch line
vSketchSegments = swSketch.GetSketchSegments
Set swSketchLine = vSketchSegments(0)

' Get start and end point
Set swStartPoint = swSketchLine.GetStartPoint2
Set swEndPoint = swSketchLine.GetEndPoint2

' Create additional lines to define sketch

' Set parameters defining the sketch geometry

dSize = swEndPoint.X - swStartPoint.X
dFactor1 = 0.1
dFactor2 = 1.25

' Add directly and do not display to speed things up
swModel.SetAddToDB True
swModel.SetDisplayWhenAdded False

swModel.CreateLine2 swStartPoint.X, swStartPoint.Y, 0#, swStartPoint.X, swStartPoint.Y + dLength, 0#
swModel.CreateLine2 swStartPoint.X, swStartPoint.Y + dLength, 0#, swStartPoint.X + dFactor1 * dSize, swStartPoint.Y + dFactor2 * dLength
0#
swModel.CreateLine2 swStartPoint.X + dFactor1 * dSize, swStartPoint.Y + dFactor2 * dLength, 0#, swEndPoint.X - dFactor1 * dSize,
swStartPoint.Y + dFactor2 * dLength, 0#
swModel.CreateLine2 swEndPoint.X - dFactor1 * dSize, swStartPoint.Y + dFactor2 * dLength, 0#, swEndPoint.X, swEndPoint.Y + dLength, 0#
swModel.CreateLine2 swEndPoint.X, swEndPoint.Y, 0#, swEndPoint.X, swEndPoint.Y + dLength, 0#

swModel.SetDisplayWhenAdded True
swModel.SetAddToDB False

' Commit changes made to the sketch
swModel.InsertSketch2 True

' Insert the edge flange

Set aFlangeEdges(0) = swEdge
Set aSketchFeats(0) = swSketch

vFlangeEdges = aFlangeEdges
vSketchFeats = aSketchFeats

Set FeatData = swModel.FeatureManager.CreateDefinition(swFmEdgeFlange)

Call FeatData.AddEdges(vFlangeEdges, vSketchFeats)
FeatData.UseDefaultBendRadius = False
FeatData.BendRadius = 0.0007366
FeatData.GapDistance = 0.001
FeatData.BendAngle = dAngle
FeatData.LockAngle = True
FeatData.OffsetType = swFlangeOffsetBlind
FeatData.OffsetDistance = dLength
FeatData.OffsetDimType = swFlangeDimTypeInnerVirtualSharp
FeatData.PositionType = swFlangePositionTypeMaterialInside
FeatData.UsePositionOffset = True
FeatData.PositionOffsetType = swFlangeOffsetBlind
FeatData.PositionOffsetDistance = 0.01
FeatData.UseDefaultBendAllowance = False
Set PBendData = FeatData.GetCustomBendAllowance

```

```
PBendData.KFactor = 0.5
PBendData.Type = swBendAllowanceDeduction
FeatData.SetCustomBendAllowance PBendData
FeatData.UseDefaultBendRelief = False
FeatData.UseReliefRatio = True
FeatData.ReliefRatio = 0.5
FeatData.AutoReliefType = swSheetMetalReliefTear
FeatData.ReliefTearType = swReliefTearTypeRip
```

```
Set edgeFlangeFeat = swModel.FeatureManager.CreateFeature(FeatData)
```

End Sub

Example

[Create Edge Flange \(VB.NET\)](#)
[Create Edge Flange \(C#\)](#)

Remarks

For more information, see the **SOLIDWORKS Design user-interface help** > **Sheet Metal** > **Using Sheet Metal Tools** > **Edge Flanges** > **Edge-Flange PropertyManager** topic.

Accessors

[IFeature::GetDefinition](#)
[IFeatureManager::CreateDefinition](#)

Access Diagram

[EdgeFlangeFeatureData](#)

See Also

[IEdgeFlangeFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IEdgeFlangeFeatureData Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IEdgeFlangeFeatureData Interface

For a list of all members of this type, see [IEdgeFlangeFeatureData members](#).

Public Methods

Name	Description
AccessSelections	Gains access to the selections that describe this edge flange.
AddEdges	Adds edges to this edge flange.
GetCustomBendAllowance	Gets the custom bend allowance for this edge flange.
GetEdgeCount	Gets the number of edges for this edge flange.
GetPositionReferenceType	Gets the position reference type from the edge flange.
IAccessSelections	Obsolete. Superseded by IEdgeFlangeFeatureData.IAccessSelections2 .
IAccessSelections2	Gains access to the selections that describe this edge flange.
IGetEdges	Gets the edges for this edge flange.
ISetEdges	Sets the edges for this edge flange.
ReleaseSelectionAccess	Releases access to selections that describe this edge flange feature.
RemoveEdges	Removes edges from this edge flange.
SetCustomBendAllowance	Sets the custom bend allowance for this edge flange.

[Top](#)

See Also

[IEdgeFlangeFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IEdgeFlangeFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : IEdgeFlangeFeatureData Interface

The following tables list the members exposed by [IEdgeFlangeFeatureData](#).

Public Properties

Name	Description
 AngleReference	Gets or sets the reference face used to define the bend angle of this edge flange.
 AutoReliefType	Gets or sets the auto-relief type for this edge flange.
 BendAngle	Gets or sets the bend angle of the edge flange.
 BendRadius	Gets or sets the bend radius of the edge flange.
 Edge	Obsolete. Superseded by IEdgeFlangeFeatureData.Edges , IEdgeFlangeFeatureData.IGetEdges , and IEdgeFlangeFeatureData.ISetEdges .
 Edges	Gets the edges for this edge flange. NOTE: This property is a get-only property. Set is not implemented.
 GapDistance	Gets or sets the gap distance of the tear for this edge flange.
 LockAngle	Gets or sets whether to lock the flange angle for the Up To Edge and Merge option of this edge flange.
 NormalToFlangePlane	Gets or sets whether the Up To Vertex is on a plane that is normal to the end face of this edge flange.
 OffsetDimType	Gets or sets the flange length origin type for dimensioning this edge flange.
 OffsetDistance	Gets or sets the flange length for this edge flange.
 OffsetReference	Gets or sets the flange length reference for this edge flange.
 OffsetType	Gets or sets the flange length end condition for this edge flange.
 PerpendicularToFace	Gets or sets whether to set this edge flange perpendicular to the angle reference face.
 PositionOffsetDistance	Gets or sets the flange position offset for this edge flange.
 PositionOffsetReference	Gets or sets the flange position offset reference for this edge flange.
 PositionOffsetType	Gets or sets the flange position offset end condition of this edge flange.
 PositionType	Gets or sets the flange position of this edge flange.
 ReliefDepth	Gets or sets the relief depth of the edge flange.
 ReliefRatio	Gets or sets the relief ratio for this edge flange.
 ReliefTearType	Gets or sets the type of relief tear for this edge flange.
 ReliefWidth	Gets or sets the width of the relief for this edge flange.
 ReverseOffset	Gets or sets whether to flip the flange length for this edge flange.
 ReversePositionOffset	Gets or sets whether to reverse the flange position offset for this edge flange.
 UseDefaultBendAllowance	Gets or sets whether to use the default bend allowance for this edge flange.
 UseDefaultBendRadius	Gets or sets whether to use the default sheet metal bend radius for this edge flange.
 UseDefaultBendRelief	Gets or sets whether to use the default bend relief for this edge flange.
 UsePositionOffset	Gets or sets whether to offset this edge flange from the sheet metal body.
 UsePositionTrimSideBends	Gets or sets whether to trim side bends for this edge flange.
 UseReliefRatio	Gets or sets whether to use the relief ratio for this edge flange.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that describe this edge flange.
 AddEdges	Adds edges to this edge flange.
 GetCustomBendAllowance	Gets the custom bend allowance for this edge flange.
 GetEdgeCount	Gets the number of edges for this edge flange.
 GetPositionReferenceType	Gets the position reference type from the edge flange.
 IAccessSelections	Obsolete. Superseded by IEdgeFlangeFeatureData.IAccessSelections2.
 IAccessSelections2	Gains access to the selections that describe this edge flange.
 IGetEdges	Gets the edges for this edge flange.
 ISetEdges	Sets the edges for this edge flange.
 ReleaseSelectionAccess	Releases access to selections that describe this edge flange feature.
 RemoveEdges	Removes edges from this edge flange.
 SetCustomBendAllowance	Sets the custom bend allowance for this edge flange.

[Top](#)

See Also

[IEdgeFlangeFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IEdgeFlangeFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IEdgeFlangeFeatureData Interface

For a list of all members of this type, see [IEdgeFlangeFeatureData members](#).

Public Properties

Name	Description
 AngleReference	Gets or sets the reference face used to define the bend angle of this edge flange.
 AutoReliefType	Gets or sets the auto-relief type for this edge flange.
 BendAngle	Gets or sets the bend angle of the edge flange.
 BendRadius	Gets or sets the bend radius of the edge flange.
 Edge	Obsolete. Superseded by IEdgeFlangeFeatureData.Edges, IEdgeFlangeFeatureData.IGetEdges, and IEdgeFlangeFeatureData.ISetEdges.
 Edges	Gets the edges for this edge flange. NOTE: This property is a get-only property. Set is not implemented.
 GapDistance	Gets or sets the gap distance of the tear for this edge flange.
 LockAngle	Gets or sets whether to lock the flange angle for the Up To Edge and Merge option of this edge flange.
 NormalToFlangePlane	Gets or sets whether the Up To Vertex is on a plane that is normal to the end face of this edge flange.
 OffsetDimType	Gets or sets the flange length origin type for dimensioning this edge flange.
 OffsetDistance	Gets or sets the flange length for this edge flange.
 OffsetReference	Gets or sets the flange length reference for this edge flange.
 OffsetType	Gets or sets the flange length end condition for this edge flange.
 PerpendicularToFace	Gets or sets whether to set this edge flange perpendicular to the angle reference face.
 PositionOffsetDistance	Gets or sets the flange position offset for this edge flange.
 PositionOffsetReference	Gets or sets the flange position offset reference for this edge flange.

 PositionOffsetType	Gets or sets the flange position offset end condition of this edge flange.
 PositionType	Gets or sets the flange position of this edge flange.
 ReliefDepth	Gets or sets the relief depth of the edge flange.
 ReliefRatio	Gets or sets the relief ratio for this edge flange.
 ReliefTearType	Gets or sets the type of relief tear for this edge flange.
 ReliefWidth	Gets or sets the width of the relief for this edge flange.
 ReverseOffset	Gets or sets whether to flip the flange length for this edge flange.
 ReversePositionOffset	Gets or sets whether to reverse the flange position offset for this edge flange.
 UseDefaultBendAllowance	Gets or sets whether to use the default bend allowance for this edge flange.
 UseDefaultBendRadius	Gets or sets whether to use the default sheet metal bend radius for this edge flange.
 UseDefaultBendRelief	Gets or sets whether to use the default bend relief for this edge flange.
 UsePositionOffset	Gets or sets whether to offset this edge flange from the sheet metal body.
 UsePositionTrimSideBends	Gets or sets whether to trim side bends for this edge flange.
 UseReliefRatio	Gets or sets whether to use the relief ratio for this edge flange.

[Top](#)

See Also

[IEdgeFlangeFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : AccessSelections Method (IEdgeFlangeFeatureData)

Gains access to the selections that describe this edge flange.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _
    ByVal TopDoc As System.Object, _
    ByVal Component As System.Object _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IEdgeFlangeFeatureData
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.Object^ TopDoc,
    & System.Object^ Component
)
```



NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document (see **Remarks**)

Component
Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections are successfully accessed, false if not

 Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::AccessSelections](#).

 Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [EdgeFlangeFeatureData::ReleaseSelectionAccess](#) if you did not

 See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::AccessSelections2 Method](#)

 Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddEdges Method (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : AddEdges Method (IEdgeFlangeFeatureData)

Adds edges to this edge flange.

 .NET Syntax

Visual Basic (Declaration)

```
Function AddEdges( _  
    ByVal EdgeArray As System.Object, _  
    ByVal SketchArray As System.Object _  
) As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IEdgeFlangeFeatureData  
Dim EdgeArray As System.Object  
Dim SketchArray As System.Object  
Dim value As System.Integer  
  
value = instance.AddEdges(EdgeArray, SketchArray)
```

C#

```
System.int AddEdges(  
    System.object EdgeArray,  
    System.object SketchArray  
)
```

C++/CLI

```
System.int AddEdges(  
& System.Object^ EdgeArray,  
& System.Object^ SketchArray  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EdgeArray

Array of [edges](#) associated with SketchArray

SketchArray

Array of [sketches](#) associated with EdgeArray

Return Value

Error code as defined by [swEdgeFlangeError_e](#)

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::AddEdges](#).

Example

See the [IEdgeFlangeFeatureData](#) examples.

Remarks

Before calling this method, call [IModelDoc2::InsertSketchForEdgeFlange](#) to associate the sketches with the edges.

See Also

[IEdgeFlangeFeatureData Interface](#)

[IEdgeFlangeFeatureData Members](#)

[IEdgeFlangeFeatureData::Edges Property](#)

[IEdgeFlangeFeatureData::RemoveEdges Method](#)

[IEdgeFlangeFeatureData::IGetEdges Method](#)

[IEdgeFlangeFeatureData::ISetEdges Method](#)

Availability

SOLIDWORKS 2012 SP02, Revision Number 20.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

AngleReference Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : AngleReference Property (IEdgeFlangeFeatureData)

Gets or sets the reference face used to define the bend angle of this edge flange.

.NET Syntax

Visual Basic (Declaration)

Property AngleReference As System.Object

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim value As System.Object
```

```
instance.AngleReference = value  
value = instance.AngleReference
```

C#

```
System.Object AngleReference {get; set;}
```

C++/CLI

```
property System.Object^ AngleReference {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Reference [face](#)

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::AngleReference](#).

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::PerpendicularToFace Property\(\)](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

AutoReliefType Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : AutoReliefType Property (IEdgeFlangeFeatureData)

Gets or sets the auto-relief type for this edge flange.

.NET Syntax

Visual Basic (Declaration)

```
Property AutoReliefType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim value As System.Integer
```

```
instance.AutoReliefType = value
```

```
value = instance.AutoReliefType
```

C#

```
System.int AutoReliefType {get; set;}
```

C++/CLI

```
property System.int AutoReliefType {  
    System.int get();  
    void set ( &    System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Auto-relief type as defined in [swSheetMetalReliefTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::AutoReliefType](#).

Example

See the [IEdgeFlangeFeatureData](#) examples.

Remarks

This property supports swSheetMetalReliefTypes_e.:

- swSheetMetalReliefRectangular (default)
- swSheetMetalReliefObround
- swSheetMetalReliefTear

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::UseReliefRatio Property](#)
[IEdgeFlangeFeatureData::ReliefDepth Property](#)
[IEdgeFlangeFeatureData::ReliefRatio Property](#)
[IEdgeFlangeFeatureData::ReliefTearType Property](#)
[IEdgeFlangeFeatureData::ReliefWidth Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

BendAngle Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : BendAngle Property (IEdgeFlangeFeatureData)

Gets or sets the bend angle of the edge flange.

.NET Syntax

Visual Basic (Declaration)

```
Property BendAngle As System.Double
```

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim value As System.Double
```

```
instance.BendAngle = value
```

```
value = instance.BendAngle
```

C#

```
System.double BendAngle {get; set;}
```

C++/CLI

```
property System.double BendAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Flange angle; default value is 1.5707963267949 radians

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::BendAngle](#).

Example

See the [IEdgeFlangeFeatureData](#) examples.

Remarks

If [IEdgeFlangeFeatureData::OffsetType](#) is set to [swFlangeOffsetTypes_e.swFlangeOffsetUptoEdgeAndMerge](#) to merge two bodies in a multibody part, then [IEdgeFlangeFeatureData::LockAngle](#) is automatically set to true. You must set [IEdgeFlangeFeatureData::LockAngle](#) to false before you can use this property to set a new bend angle.

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

BendRadius Property (IEdgeFlangeFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : BendRadius Property (IEdgeFlangeFeatureData)

Gets or sets the bend radius of the edge flange.

.NET Syntax

Visual Basic (Declaration)

```
Property BendRadius As System.Double
```

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData
Dim value As System.Double

instance.BendRadius = value

value = instance.BendRadius
```

C#

```
System.double BendRadius {get; set;}
```

C++/CLI

```
property System.double BendRadius {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Value of the bend radius; default value is 0.00073666 m

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::BendRadius](#).

Example

See the [IEdgeFlangeFeatureData](#) examples.

Example

[Get All Sheet Metal Feature Data \(VBA\)](#)
[Get All Sheet Metal Feature Data \(VB.NET\)](#)
[Get All Sheet Metal Feature Data \(C#\)](#)

Remarks

The setter of this property is valid only if [IEdgeFlangeFeatureData::UseDefaultBendRadius](#) is set to false.

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

Edge Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : Edge Property (IEdgeFlangeFeatureData)

Obsolete. Superseded by [IEdgeFlangeFeatureData::Edges](#), [IEdgeFlangeFeatureData::IGetEdges](#), and [IEdgeFlangeFeatureData::ISetEdges](#).

.NET Syntax

Visual Basic (Declaration)

Property Edge As System.Object

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim value As System.Object
```

```
instance.Edge = value
```

```
value = instance.Edge
```

C#

```
System.object Edge {get; set;}
```

C++/CLI

```
property System.Object^ Edge {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::Edge](#).

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Edges Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : Edges Property (IEdgeFlangeFeatureData)

Gets the edges for this edge flange.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property Edges As System.Object

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData
Dim value As System.Object
```

```
instance.Edges = value
```

```
value = instance.Edges
```

C#

```
System.object Edges {get; set;}
```

C++/CLI

```
property System.Object^ Edges {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [edges](#) for this edge flange (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::Edges](#).

Remarks

Use [IEdgeFlangeFeatureData::AddEdges](#) and [IEdgeFlangeFeatureData::RemoveEdges](#) to add or remove edges from an edge flange.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::GetEdgeCount Method](#)
[IEdgeFlangeFeatureData::IGetEdges Method](#)
[IEdgeFlangeFeatureData::ISetEdges Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GapDistance Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : GapDistance Property (IEdgeFlangeFeatureData)

Gets or sets the gap distance of the tear for this edge flange.

.NET Syntax

Visual Basic (Declaration)

Property GapDistance As System.Double

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData
Dim value As System.Double

instance.GapDistance = value

value = instance.GapDistance
```

C#

```
System.double GapDistance {get; set;}
```

C++/CLI

```
property System.double GapDistance {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance in meters between the edges in the flange; default value is 0.001 m

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::GapDistance](#).

Example

See the [IEdgeFlangeFeatureData](#) examples.

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCustomBendAllowance Method (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : GetCustomBendAllowance Method (IEdgeFlangeFeatureData)

Gets the custom bend allowance for this edge flange.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomBendAllowance() As CustomBendAllowance
```

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData
Dim value As CustomBendAllowance

value = instance.GetCustomBendAllowance()
```

C#

```
CustomBendAllowance GetCustomBendAllowance()
```

C++/CLI

```
CustomBendAllowance^ GetCustomBendAllowance();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [ICustomBendAllowance](#) object

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::GetCustomBendAllowance](#).

Example

See the [IEdgeFlangeFeatureData](#) examples.

Remarks

This method is valid only if [IEdgeFlangeFeatureData::UseDefaultBendAllowance](#) is set to false.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::SetCustomBendAllowance Method](#)
[IEdgeFlangeFeatureData::UseDefaultBendAllowance Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEdgeCount Method (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : GetEdgeCount Method (IEdgeFlangeFeatureData)

Gets the number of edges for this edge flange.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEdgeCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim value As System.Integer
```

```
value = instance.GetEdgeCount()
```

C#

```
System.int GetEdgeCount()
```

C++/CLI

```
System.int GetEdgeCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of edges for this edge flange

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::GetEdgeCount](#).

Remarks

Call this method before calling [IEdgeFlangeFeatureData::IGetEdges](#) to determine the size of the array.

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::ISetEdges Method](#)
[IEdgeFlangeFeatureData::Edges Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPositionReferenceType Method (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : GetPositionReferenceType Method (IEdgeFlangeFeatureData)

Gets the position reference type from the edge flange.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPositionReferenceType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim value As System.Integer  
  
value = instance.GetPositionReferenceType()
```

C#

```
System.int GetPositionReferenceType()
```

C++/CLI

```
System.int GetPositionReferenceType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Position reference type as defined in [swSelectionReferenceTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::GetPositionReferenceType](#).

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::PositionType Property](#)
[IEdgeFlangeFeatureData::UsePositionTrimSideBends Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : IAccessSelections Method (IEdgeFlangeFeatureData)

Obsolete. Superseded by [IEdgeFlangeFeatureData.IAccessSelections2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim TopDoc As ModelDoc  
Dim Component As Component  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc TopDoc,  
    Component Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc^ TopDoc,  
& Component^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Component

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData.IAccessSelections](#).

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections2 Method (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : IAccessSelections2 Method (IEdgeFlangeFeatureData)

Gains access to the selections that describe this edge flange.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections2( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections2(TopDoc, Component)
```

C#

```
System.bool IAccessSelections2(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections2(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::IAccessSelections2](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IEdgeFlangeFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::AccessSelections Method](#)

Availability

IGetEdges Method (IEdgeFlangeFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : IGetEdges Method (IEdgeFlangeFeatureData)

Gets the edges for this edge flange.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetEdges( _  
    ByVal EdgeCount As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim EdgeCount As System.Integer  
Dim value As System.Object
```

```
value = instance.IGetEdges(EdgeCount)
```

C#

```
System.object IGetEdges(  
    System.int EdgeCount  
)
```

C++/CLI

```
System.Object^ IGetEdges(  
&    System.int EdgeCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EdgeCount

Number of edges for this edge flange

Return Value

- in-process, unmanaged C++: Pointer to an array of edges for this edge flange
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IEdgeFlangeFeatureData::GetEdgeCount](#) before calling this method to determine the size of the array.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::ISetEdges Method](#)
[IEdgeFlangeFeatureData::Edges Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

ISetEdges Method (IEdgeFlangeFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : ISetEdges Method (IEdgeFlangeFeatureData)

Sets the edges for this edge flange.

 .NET Syntax

Visual Basic (Declaration)

```
Sub ISetEdges( _  
    ByVal EdgeCount As System.Integer, _  
    ByRef EdgeArray As System.Object _  
)
```

Visual Basic (Usage)  

```
Dim instance As IEdgeFlangeFeatureData  
Dim EdgeCount As System.Integer  
Dim EdgeArray As System.Object  
  
instance.ISetEdges(EdgeCount, EdgeArray)
```

C#

```
void ISetEdges(  
    System.int EdgeCount,  
    ref System.object EdgeArray  
)
```

C++/CLI

```
void ISetEdges(  
& System.int EdgeCount,  
& System.Object^% EdgeArray  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

- EdgeCount*
Number of edges for this edge flange
- EdgeArray*
- in-process, unmanaged C++: Pointer to an array of [edges](#) for this edge flange
- VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

 Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

 See Also

- [IEdgeFlangeFeatureData Interface](#)
- [IEdgeFlangeFeatureData Members](#)
- [IEdgeFlangeFeaturData::GetEdgeCount Method](#)
- [IEdgeFlangeFeaturData::IGetEdges Method](#)
- [IEdgeFlangeFeaturData::Edges Property](#)

 Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

LockAngle Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : LockAngle Property (IEdgeFlangeFeatureData)

Gets or sets whether to lock the [flange angle](#) for the Up To Edge and Merge option of this edge flange.

 .NET Syntax

Visual Basic (Declaration)

Property LockAngle As System.Boolean

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData
Dim value As System.Boolean

instance.LockAngle = value

value = instance.LockAngle
```

C#

```
System.bool LockAngle {get; set;}
```

C++/CLI

```
property System.bool LockAngle {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to lock the flange angle (default), false to not

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::LockAngle](#).

Example

See the [IEdgeFlangeFeatureData](#) examples.

Remarks

This property is valid only when:

- merging two bodies in a multibody part,
- and -
- [IEdgeFlangeFeatureData::OffsetType](#) is set to [swFlangeOffsetTypes_e.swFlangeOffsetUptoEdgeAndMerge](#).

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

NormalToFlangePlane Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : NormalToFlangePlane Property (IEdgeFlangeFeatureData)

Gets or sets whether the Up To Vertex is on a plane that is normal to the end face of this edge flange.

.NET Syntax

Visual Basic (Declaration)

```
Property NormalToFlangePlane As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim value As System.Boolean
```

```
instance.NormalToFlangePlane = value
```

```
value = instance.NormalToFlangePlane
```

C#

```
System.bool NormalToFlangePlane {get; set;}
```

C++/CLI

```
property System.bool NormalToFlangePlane {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the Up To Vertex is on a plane that is normal to the end face of the edge flange (default), false if the Up To Vertex passes through a plane that is parallel to the face of the base flange

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::NormalToFlangePlane](#).

Remarks

This property is valid only if [IEdgeFlangeFeatureData::OffsetType](#) is set to [swFlangeOffsetTypes_e.swFlangeOffsetUpToVertex](#).

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

OffsetDimType Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : OffsetDimType Property (IEdgeFlangeFeatureData)

Gets or sets the flange length origin type for dimensioning this edge flange.

.NET Syntax

Visual Basic (Declaration)

```
Property OffsetDimType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim value As System.Integer
```

```
instance.OffsetDimType = value
```

```
value = instance.OffsetDimType
```

C#

```
System.int OffsetDimType {get; set;}
```

C++/CLI

```
property System.int OffsetDimType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Dimensioning origin type as defined in [swFlangeDimTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::OffsetDimType](#).

Example

See the [IEdgeFlangeFeatureData](#) examples.

Remarks

This property is valid only if [IEdgeFlangeFeatureData::OffsetType](#) is not set to [swFlangeOffsetTypes_e.swFlangeOffsetUpToVertex](#).

The default value of this property is [swFlangeDimTypes_e.swFlangeDimTypeInnerVirtualSharp](#).

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::OffsetDistance Property](#)
[IEdgeFlangeFeatureData::UsePositionOffset Property](#)
[IEdgeFlangeFeatureData::OffsetType Property](#)
[IEdgeFlangeFeatureData::ReverseOffset Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

OffsetDistance Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : OffsetDistance Property (IEdgeFlangeFeatureData)

Gets or sets the flange length for this edge flange.

.NET Syntax

Visual Basic (Declaration)

Property OffsetDistance As System.Double

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData
Dim value As System.Double
```

```
instance.OffsetDistance = value
```

```
value = instance.OffsetDistance
```

C#

```
System.double OffsetDistance {get; set;}
```

C++/CLI

```
property System.double OffsetDistance {
    System.double get();
```

```
void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Value of the flange length; default is 0.0022098 m

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::OffsetDistance](#).

Example

See the [IEdgeFlangeFeatureData](#) examples.

Remarks

This property is valid for all settings of [IEdgeFlangeFeatureData::OffsetType](#) except [swFlangeOffsetTypes_e.swFlangeOffsetUpToVertex](#).

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::OffsetDimType Property](#)
[IEdgeFlangeFeatureData::OffsetReference Property](#)
[IEdgeFlangeFeatureData::ReverseOffset Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

OffsetReference Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : OffsetReference Property (IEdgeFlangeFeatureData)

Gets or sets the flange length reference for this edge flange.

.NET Syntax

Visual Basic (Declaration)

Property OffsetReference As System.Object

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim value As System.Object
```

```
instance.OffsetReference = value
```

```
value = instance.OffsetReference
```

C#

```
System.object OffsetReference {get; set;}
```

C++/CLI

```
property System.Object^ OffsetReference {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Flange length reference for this edge flange

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::OffsetReference](#).

Remarks

This property is valid for all settings of [IEdgeFlangeFeatureData::OffsetType](#) except [swFlangeOffsetTypes_e.swFlangeOffsetBlind](#).

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::OffsetDimType Property](#)
[IEdgeFlangeFeatureData::OffsetDistance Property](#)
[IEdgeFlangeFeatureData::ReverseOffset Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

OffsetType Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : OffsetType Property (IEdgeFlangeFeatureData)

Gets or sets the flange length end condition for this edge flange.

.NET Syntax

Visual Basic (Declaration)

```
Property OffsetType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim value As System.Integer
```

```
instance.OffsetType = value
```

```
value = instance.OffsetType
```

C#

```
System.int OffsetType {get; set;}
```

C++/CLI

```
property System.int OffsetType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Flange length end condition as defined in [swFlangeOffsetTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::OffsetType](#).

Example

See the [IEdgeFlangeFeatureData](#) examples.

Remarks

This property can have one of the following values in `swFlangeOffsetTypes_e`:

- `swFlangeOffsetBlind` (default)
- `swFlangeOffsetUptoEdgeAndMerge`
- `swFlangeOffsetUpToVertex`

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::OffsetDimType Property](#)
[IEdgeFlangeFeatureData::OffsetDistance Property](#)
[IEdgeFlangeFeatureData::OffsetReference Property](#)
[IEdgeFlangeFeatureData::ReverseOffset Property](#)
[IEdgeFlangeFeatureData::BendAngle Property \(\)](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

PerpendicularToFace Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : PerpendicularToFace Property (IEdgeFlangeFeatureData)

Gets or sets whether to set this edge flange perpendicular to the angle reference face.

.NET Syntax

Visual Basic (Declaration)

Property PerpendicularToFace As System.Boolean

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim value As System.Boolean
```

```
instance.PerpendicularToFace = value
```

```
value = instance.PerpendicularToFace
```

C#

```
System.bool PerpendicularToFace {get; set;}
```

C++/CLI

```
property System.bool PerpendicularToFace {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to set this edge flange perpendicular to the angle reference face, false to set it parallel to the angle reference face (default)

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::PerpendicularToFace](#).

Remarks

This property is valid only if [IEdgeFlangeFeatureData::AngleReference](#) is not null.

See Also

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

PositionOffsetDistance Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : PositionOffsetDistance Property (IEdgeFlangeFeatureData)

Gets or sets the flange position offset for this edge flange.

.NET Syntax

Visual Basic (Declaration)

Property PositionOffsetDistance As System.Double

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim value As System.Double  
  
instance.PositionOffsetDistance = value  
value = instance.PositionOffsetDistance
```

C#

```
System.double PositionOffsetDistance {get; set;}
```

C++/CLI

```
property System.double PositionOffsetDistance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Flange position offset value; default value is 0.01 m

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::PositionOffsetDistance](#).

Example

See the [IEdgeFlangeFeatureData](#) examples.

Remarks

This property is valid only if:

- [IEdgeFlangeFeatureData::UsePositionOffset](#) is set to true,
- and -
- [IEdgeflangeFeatureData::PostionOffsetType](#) is set to either [swFlangeOffsetTypes_e.swFlangeOffsetFromSurface](#) or [swFlangeOffsetTypes_e.swFlangeOffsetBlind](#).

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::PositionOffsetReference Property](#)
[IEdgeFlangeFeatureData::ReversePositionOffset Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

PositionOffsetReference Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : PositionOffsetReference Property (IEdgeFlangeFeatureData)

Gets or sets the flange position offset reference for this edge flange.

.NET Syntax

Visual Basic (Declaration)

Property PositionOffsetReference As System.Object

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData
Dim value As System.Object

instance.PositionOffsetReference = value
value = instance.PositionOffsetReference
```

C#

```
System.object PositionOffsetReference {get; set;}
```

C++/CLI

```
property System.Object^ PositionOffsetReference {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Flange position offset reference for this edge flange

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::PositionOffsetReference](#).

Remarks

This property is valid only if:

- [IEdgeFlangeFeatureData::UsePositionOffset](#) is set to true,
- and -
- [IEdgeFlangeFeatureData::PositionOffsetType](#) is set to [swFlangeOffsetTypes_e](#):
 - swFlangeOffsetUpToVertex
 - swFlangeOffsetUpToSurface
 - swFlangeOffsetFromSurface

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::PositionOffsetDistance Property](#)
[IEdgeFlangeFeatureData::ReversePositionOffset Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

PositionOffsetType Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : PositionOffsetType Property (IEdgeFlangeFeatureData)

Gets or sets the flange position offset end condition of this edge flange.

.NET Syntax

Visual Basic (Declaration)

```
Property PositionOffsetType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim value As System.Integer
```

```
instance.PositionOffsetType = value
```

```
value = instance.PositionOffsetType
```

C#

```
System.int PositionOffsetType {get; set;}
```

C++/CLI

```
property System.int PositionOffsetType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Flange position offset end condition as defined in [swFlangeOffsetTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::PositionOffsetType](#).

Example

See the [IEdgeFlangeFeatureData](#) examples.

Remarks

This property is valid only if [IEdgeFlangeFeatureData::UsePositionOffset](#) is set to true.

The default value of this property is [swFlangeOffsetTypes_e.swFlangeOffsetBlind](#).

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::PositionOffsetDistance Property](#)
[IEdgeFlangeFeatureData::PositionOffsetReference Property](#)
[IEdgeFlangeFeatureData::ReversePositionOffset Property](#)
[IEdgeFlangeFeatureData::UsePositionTrimSideBends Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

PositionType Property (IEdgeFlangeFeatureData)

[See Also](#)



Gets or sets the flange position of this edge flange.

.NET Syntax

Visual Basic (Declaration)

Property PositionType As System.Integer

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData
Dim value As System.Integer
```

```
instance.PositionType = value
```

```
value = instance.PositionType
```

C#

```
System.int PositionType {get; set;}
```

C++/CLI

```
property System.int PositionType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Position type as defined in [swFlangePositionTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::PositionType](#).

Example

See the [IEdgeFlangeFeatureData](#) examples.

Remarks

The default value of this property is swFlangePositionTypes_e.swFlangePositionTypeMaterialInside.

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::GetPositionReferenceType Method](#)
[IEdgeFlangeFeatureData::PositionOffsetDistance Property](#)
[IEdgeFlangeFeatureData::PositionOffsetReference Property](#)
[IEdgeFlangeFeatureData::PositionOffsetType Property](#)
[IEdgeFlangeFeatureData::ReversePositionOffset Property](#)
[IEdgeFlangeFeatureData::UsePositionOffset Property](#)
[IEdgeFlangeFeatureData::UsePositionTrimSideBends Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

ReleaseSelectionAccess Method (IEdgeFlangeFeatureData)

[See Also](#)



Releases access to selections that describe this edge flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::ReleaseSelectionAccess](#).

Remarks

[IEdgeFlangeFeatureData::AccessSelections](#) and [IEdgeFlangeFeatureData::IAccessSelections2](#) put the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did.

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReliefDepth Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : ReliefDepth Property (IEdgeFlangeFeatureData)

Gets or sets the relief depth of the edge flange.

.NET Syntax

Visual Basic (Declaration)

```
Property ReliefDepth As System.Double
```

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim value As System.Double  
  
instance.ReliefDepth = value  
value = instance.ReliefDepth
```

C#

```
System.double ReliefDepth {get; set;}
```

C++/CLI

```
property System.double ReliefDepth {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Depth of relief; default value is 0.0003683 m

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::ReliefDepth](#).

Remarks

This property is valid only if:

- [IEdgeFlangeFeatureData::UseDefaultBendRelief](#) is set to false,
- and -
- [IEdgeFlangeFeatureData::UseReliefRatio](#) is true.
- and -
- [IEdgeFlangeFeatureData::AutoReliefType](#) is set to [swSheetMetalReliefTypes_e](#):
 - swSheetMetalReliefObround
- Or -
- swSheetMetalReliefRectangle.

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::ReliefRatio Property](#)
[IEdgeFlangeFeatureData::ReliefTearType Property](#)
[IEdgeFlangeFeatureData::ReliefWidth Property](#)

Availability

SOLIDWORKS 2201 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReliefRatio Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : ReliefRatio Property (IEdgeFlangeFeatureData)

Gets or sets the relief ratio for this edge flange.

.NET Syntax

Visual Basic (Declaration)

```
Property ReliefRatio As System.Double
```

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim value As System.Double
```

```
instance.ReliefRatio = value
```

```
value = instance.ReliefRatio
```

C#

```
System.double ReliefRatio {get; set;}
```

C++/CLI

```
property System.double ReliefRatio {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Relief ratio; default value is 0.5

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::ReliefRatio](#).

Example

See the [IEdgeFlangeFeatureData](#) examples.

Remarks

This property is valid only if:

- [IEdgeFlangeFeatureData::UseDefaultBendRelief](#) is set to false,
- and -
- [IEdgeFlangeFeatureData::UseReliefRatio](#) is true.
- and -
- [IEdgeFlangeFeatureData::AutoReliefType](#) is set to [swSheetMetalReliefTypes_e](#):
 - swSheetMetalReliefObround
- Or -
- swSheetMetalReliefRectangle.

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::ReliefDepth Property](#)
[IEdgeFlangeFeatureData::ReliefTearType Property](#)
[IEdgeFlangeFeatureData::ReliefWidth Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReliefTearType Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : ReliefTearType Property (IEdgeFlangeFeatureData)

Gets or sets the type of relief tear for this edge flange.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property ReliefTearType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim value As System.Integer
```

```
instance.ReliefTearType = value
```

```
value = instance.ReliefTearType
```

C#

```
System.int ReliefTearType {get; set;}
```

C++/CLI

```
property System.int ReliefTearType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Relief tear type as defined in [swReliefTearType_e](#)

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::ReliefTearType](#).

Example

See the [IEdgeFlangeFeatureData](#) examples.

Remarks

This property is valid only if:

- [IEdgeFlangeFeatureData::UseDefaultBendRelief](#) is set to false,
- and -
- [IEdgeFlangeFeatureData::AutoReliefType](#) is set to swSheetMetalReliefTypes_e.swSheetMetalReliefTear.

The default value of this property is swReliefTearType_e.swReliefTearTypeRip.

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::ReliefDepth Property](#)
[IEdgeFlangeFeatureData::ReliefRatio Property](#)
[IEdgeFlangeFeatureData::ReliefWidth Property](#)
[IEdgeFlangeFeatureData::UseReliefRatio Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReliefWidth Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : ReliefWidth Property (IEdgeFlangeFeatureData)

Gets or sets the width of the relief for this edge flange.

.NET Syntax

Visual Basic (Declaration)

```
Property ReliefWidth As System.Double
```

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim value As System.Double  
  
instance.ReliefWidth = value
```

```
value = instance.ReliefWidth
```

C#

```
System.double ReliefWidth {get; set;}
```

C++/CLI

```
property System.double ReliefWidth {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Relief width; default value is 0.0003683 m

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::ReliefWidth](#).

Remarks

This property is valid only if:

- [IEdgeFlangeFeatureData::UseDefaultBendRelief](#) is set to false,
- and -
- [IEdgeFlangeFeatureData::UseReliefRatio](#) is true.
- and -
- [IEdgeFlangeFeatureData::AutoReliefType](#) is set to [swSheetMetalReliefTypes_e](#):
 - swSheetMetalReliefObround
- Or -
- swSheetMetalReliefRectangle.

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::PositionType Property](#)
[IEdgeFlangeFeatureData::ReliefDepth Property](#)
[IEdgeFlangeFeatureData::ReliefRatio Property](#)
[IEdgeFlangeFeatureData::ReliefTearType Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

RemoveEdges Method (IEdgeFlangeFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : RemoveEdges Method (IEdgeFlangeFeatureData)

Removes edges from this edge flange.

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveEdges ( _  
    ByVal EdgeArray As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim EdgeArray As System.Object  
Dim value As System.Integer
```

```
value = instance.RemoveEdges(EdgeArray)
```

C#

```
System.int RemoveEdges(  
    System.object EdgeArray  
)
```

C++/CLI

```
System.int RemoveEdges(  
& System.Object^ EdgeArray  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EdgeArray
Array of [edges](#) to remove

Return Value

Error code as defined by [swEdgeFlangeError_e](#)

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::RemoveEdges](#).

Example

[Remove Edge from Edge Flange Feature \(C#\)](#)
[Remove Edge from Edge Flange Feature \(VB.NET\)](#)
[Remove Edge from Edge Flange Feature \(VBA\)](#)

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::Edges Property](#)
[IEdgeFlangeFeatureData::AddEdges Method](#)
[IEdgeFlangeFeatureData::GetEdges Method](#)
[IEdgeFlangeFeatureData::SetEdges Method](#)

Availability

SOLIDWORKS 2012 SP02, Revision Number 20.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseOffset Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : ReverseOffset Property (IEdgeFlangeFeatureData)

Gets or sets whether to flip the flange length for this edge flange.

.NET Syntax

Visual Basic (Declaration)

```
Property ReverseOffset As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim value As System.Boolean
```

```
instance.ReverseOffset = value
```

```
value = instance.ReverseOffset
```

C#

```
System.bool ReverseOffset {get; set;}
```

C++/CLI

```
property System.bool ReverseOffset {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True flips the flange length, false does not (default)

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::ReverseOffset](#).

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::OffsetDimType Property](#)
[IEdgeFlangeFeatureData::OffsetDistance Property](#)
[IEdgeFlangeFeatureData::OffsetReference Property](#)
[IEdgeFlangeFeatureData::OffsetType Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReversePositionOffset Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : ReversePositionOffset Property (IEdgeFlangeFeatureData)

Gets or sets whether to reverse the flange position offset for this edge flange.

.NET Syntax

Visual Basic (Declaration)

```
Property ReversePositionOffset As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim value As System.Boolean
```

```
instance.ReversePositionOffset = value
```

```
value = instance.ReversePositionOffset
```

C#

```
System.bool ReversePositionOffset {get; set;}
```

C++/CLI

```
property System.bool ReversePositionOffset {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True reverses the flange position offset, false does not (default)

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::ReversePositionOffset](#).

Remarks

This property is valid only if [IEdgeFlangeFeatureData::UsePositionOffset](#) is set to true.

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::PositionOffsetDistance Property](#)
[IEdgeFlangeFeatureData::PositionOffsetReference Property](#)
[IEdgeFlangeFeatureData::PositionOffsetType Property](#)
[IEdgeFlangeFeatureData::UsePositionOffset Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetCustomBendAllowance Method (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : SetCustomBendAllowance Method (IEdgeFlangeFeatureData)

Sets the custom bend allowance for this edge flange.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetCustomBendAllowance( _  
    ByVal PBendData As CustomBendAllowance _  
)
```

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim PBendData As CustomBendAllowance  
  
instance.SetCustomBendAllowance(PBendData)
```

C#

```
void SetCustomBendAllowance(  
    CustomBendAllowance PBendData  
)
```

C++/CLI

```
void SetCustomBendAllowance(  
    & CustomBendAllowance^ PBendData  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PBendData
Pointer to the [ICustomBendAllowance](#) object

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::SetCustomBendAllowance](#).

Example

See the [IEdgeFlangeFeatureData](#) examples.

Remarks

This method is valid only if [IEdgeFlangeFeatureData::UseDefaultBendAllowance](#) is set to false.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::GetCustomBendAllowance Method](#)
[IEdgeFlangeFeatureData::UseDefaultBendAllowance Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

UseDefaultBendAllowance Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : UseDefaultBendAllowance Property (IEdgeFlangeFeatureData)

Gets or sets whether to use the default bend allowance for this edge flange.

.NET Syntax

Visual Basic (Declaration)

Property UseDefaultBendAllowance As System.Boolean

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData
Dim value As System.Boolean

instance.UseDefaultBendAllowance = value

value = instance.UseDefaultBendAllowance
```

C#

```
System.bool UseDefaultBendAllowance {get; set;}
```

C++/CLI

```
property System.bool UseDefaultBendAllowance {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True uses the default bend allowance (default), false uses a custom bend allowance

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::UseDefaultBendAllowance](#).

Example

See the [IEdgeFlangeFeatureData](#) examples.

Remarks

If this property is set to true, then the default KFactor is 0.5.

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::GetCustomBendAllowance Method](#)
[IEdgeFlangeFeatureData::SetCustomBendAllowance Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseDefaultBendRadius Property (IEdgeFlangeFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : UseDefaultBendRadius Property (IEdgeFlangeFeatureData)

Gets or sets whether to use the default sheet metal bend radius for this edge flange.

.NET Syntax

Visual Basic (Declaration)

```
Property UseDefaultBendRadius As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData  
Dim value As System.Boolean
```

```
instance.UseDefaultBendRadius = value
```

```
value = instance.UseDefaultBendRadius
```

C#

```
System.bool UseDefaultBendRadius {get; set;}
```

C++/CLI

```
property System.bool UseDefaultBendRadius {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True uses the default sheet metal bend radius of the edge flange (default), false uses a custom bend radius

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::UseDefaultBendRadius](#).

Example

See the [IEdgeFlangeFeatureData](#) examples.

Example

[Get All Sheet Metal Feature Data \(VBA\)](#)
[Get All Sheet Metal Feature Data \(VB.NET\)](#)
[Get All Sheet Metal Feature Data \(C#\)](#)

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::BendRadius Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseDefaultBendRelief Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : UseDefaultBendRelief Property (IEdgeFlangeFeatureData)

Gets or sets whether to use the default bend relief for this edge flange.

.NET Syntax

Visual Basic (Declaration)

Property UseDefaultBendRelief As System.Boolean

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData
Dim value As System.Boolean
```

```
instance.UseDefaultBendRelief = value
```

```
value = instance.UseDefaultBendRelief
```

C#

```
System.bool UseDefaultBendRelief {get; set;}
```

C++/CLI

```
property System.bool UseDefaultBendRelief {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True uses the default bend relief (default), false does not

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::UseDefaultBendRelief](#).

Example

See the [IEdgeFlangeFeatureData](#) examples.

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::AutoReliefType Property](#)
[IEdgeFlangeFeatureData::ReliefDepth Property](#)
[IEdgeFlangeFeatureData::ReliefRatio Property](#)
[IEdgeFlangeFeatureData::ReliefTearType Property](#)
[IEdgeFlangeFeatureData::ReliefWidth Property](#)
[IEdgeFlangeFeatureData::UseReliefRatio Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UsePositionOffset Property (IEdgeFlangeFeatureData)

[See Also](#)



Gets or sets whether to offset this edge flange from the sheet metal body.

.NET Syntax

Visual Basic (Declaration)

Property UsePositionOffset As System.Boolean

Visual Basic (Usage)



```
Dim instance As IEdgeFlangeFeatureData
Dim value As System.Boolean
```

```
instance.UsePositionOffset = value
```

```
value = instance.UsePositionOffset
```

C#

```
System.bool UsePositionOffset {get; set;}
```

C++/CLI

```
property System.bool UsePositionOffset {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True offsets the flange position, false does not (default)

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::UsePositionOffset](#).

Example

See the [IEdgeFlangeFeatureData](#) examples.

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::PositionOffsetDistance Property](#)
[IEdgeFlangeFeatureData::PositionOffsetReference Property](#)
[IEdgeFlangeFeatureData::PositionOffsetType Property](#)
[IEdgeFlangeFeatureData::ReversePositionOffset Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

UsePositionTrimSideBends Property (IEdgeFlangeFeatureData)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > IEdgeFlangeFeatureData Interface : UsePositionTrimSideBends Property (IEdgeFlangeFeatureData)

Gets or sets whether to trim side bends for this edge flange.

.NET Syntax

Visual Basic (Declaration)

Property UsePositionTrimSideBends As System.Boolean

Visual Basic (Usage)

```
Dim instance As IEdgeFlangeFeatureData
Dim value As System.Boolean

instance.UsePositionTrimSideBends = value
value = instance.UsePositionTrimSideBends
```

C#

```
System.bool UsePositionTrimSideBends {get; set;}
```

C++/CLI

```
property System.bool UsePositionTrimSideBends {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True trims side bends, false does not (default)

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::UsePositionTrimSideBends](#).

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::GetPositionReferenceType Method](#)
[IEdgeFlangeFeatureData::PositionType Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

UseReliefRatio Property (IEdgeFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgeFlangeFeatureData Interface](#) : UseReliefRatio Property (IEdgeFlangeFeatureData)

Gets or sets whether to use the relief ratio for this edge flange.

.NET Syntax

Visual Basic (Declaration)

```
Property UseReliefRatio As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IEdgeFlangeFeatureData
Dim value As System.Boolean

instance.UseReliefRatio = value
value = instance.UseReliefRatio
```

C#

```
System.bool UseReliefRatio {get; set;}
```

C++/CLI

```
property System.bool UseReliefRatio {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True uses the relief ratio (default), false does not

Visual Basic for Applications (VBA) Syntax

See [EdgeFlangeFeatureData::UseReliefRatio](#).

Example

See the [IEdgeFlangeFeatureData](#) examples.

Remarks

This property is valid only if

- [IEdgeFlangeFeatureData::UseDefaultBendRelief](#) is false
- and -
- [IEdgeFlangeFeatureData::AutoReliefType](#) is set to [swSheetMetalReliefTypes_e](#):
 - swSheetMetalReliefObround
- or -
- swSheetMetalReliefRectangle.

See Also

[IEdgeFlangeFeatureData Interface](#)
[IEdgeFlangeFeatureData Members](#)
[IEdgeFlangeFeatureData::ReliefRatio Property](#)
[IEdgeFlangeFeatureData::ReliefTearType Property](#)
[IEdgeFlangeFeatureData::ReliefWidth Property](#)
[IEdgeFlangeFeatureData::ReliefDepth Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

IEdgePoint (Type)

IEdgePoint Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IEdgePoint Interface

Allows access to a midpoint on an [edge](#) or an endpoint or midpoint on a [reference curve](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IEdgePoint
```

Visual Basic (Usage)

```
Dim instance As IEdgePoint
```

C#

```
public interface IEdgePoint
```

C++/CLI

```
public interface class IEdgePoint
```

Visual Basic for Applications (VBA) Syntax

See [EdgePoint](#).

Example

[Get Edge Points \(VBA\)](#)
[Create Reference Curve \(C#\)](#)
[Create Reference Curve \(VB.NET\)](#)
[Create Reference Curve \(VBA\)](#)

Accessors

[ISelectionMgr::GetSelectedObject6](#)

Access Diagram

[EdgePoint](#)

See Also

[IEdgePoint Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IEdgePoint Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IEdgePoint Interface

The following tables list the members exposed by [IEdgePoint](#).

Public Properties

Name	Description
 Entity	Gets or sets edge or reference curve on which the point is located.
 Position	Gets or sets the position of the midpoint on an edge or an endpoint or midpoint on a reference curve .

[Top](#)

 Public Methods

Name	Description
 GetPointCoordinates	Gets the coordinates for this midpoint on an edge or an endpoint or midpoint on a reference curve .
 Select	Selects a midpoint on an edge or an endpoint or midpoint on a reference curve .

[Top](#)

 See Also

[IEdgePoint Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

IEdgePoint Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IEdgePoint Interface

For a list of all members of this type, see [IEdgePoint members](#).

 Public Methods

Name	Description
 GetPointCoordinates	Gets the coordinates for this midpoint on an edge or an endpoint or midpoint on a reference curve .
 Select	Selects a midpoint on an edge or an endpoint or midpoint on a reference curve .

[Top](#)

 See Also

[IEdgePoint Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

IEdgePoint Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IEdgePoint Interface

For a list of all members of this type, see [IEdgePoint members](#).

 Public Properties

Name	Description
 Entity	Gets or sets edge or reference curve on which the point is located.
 Position	Gets or sets the position of the midpoint on an edge or an endpoint or midpoint on a reference curve .

[Top](#)

 See Also

[IEdgePoint Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

Entity Property (IEdgePoint)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgePoint Interface](#) : Entity Property (IEdgePoint)

Gets or sets edge or reference curve on which the point is located.

 .NET Syntax

Visual Basic (Declaration)

Property Entity As System.Object

Visual Basic (Usage)



```
Dim instance As IEdgePoint  
Dim value As System.Object
```

```
instance.Entity = value
```

```
value = instance.Entity
```

C#

```
System.object Entity {get; set;}
```

C++/CLI

```
property System.Object^ Entity {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Edge](#) or [reference curve](#)

Visual Basic for Applications (VBA) Syntax

See [EdgePoint::Entity](#).

See Also

[IEdgePoint Interface](#)
[IEdgePoint Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPointCoordinates Method (IEdgePoint)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgePoint Interface](#) : GetPointCoordinates Method (IEdgePoint)

Gets the coordinates for this midpoint on an [edge](#) or an endpoint or midpoint on a [reference curve](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub GetPointCoordinates( _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IEdgePoint  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double
```

```
instance.GetPointCoordinates(X, Y, Z)
```

C#

```

void GetPointCoordinates(
    out System.double X,
    out System.double Y,
    out System.double Z
)

```

C++/CLI

```

void GetPointCoordinates(
    & [Out] System.double X,
    & [Out] System.double Y,
    & [Out] System.double Z
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X
x coordinate for this midpoint or endpoint

Y
y coordinate for this midpoint or endpoint

Z
z coordinate for this midpoint or endpoint

Visual Basic for Applications (VBA) Syntax

See [EdgePoint::GetPointCoordinates](#).

Example

[Create Reference Curve \(C#\)](#)
[Create Reference Curve \(VB.NET\)](#)
[Create Reference Curve \(VBA\)](#)

See Also

[IEdgePoint Interface](#)
[IEdgePoint Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Position Property (IEdgePoint)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgePoint Interface](#) : Position Property (IEdgePoint)

Gets or sets the position of the midpoint on an [edge](#) or an endpoint or midpoint on a [reference curve](#).

.NET Syntax

Visual Basic (Declaration)

```
Property Position As System.Double
```

Visual Basic (Usage)

```

Dim instance As IEdgePoint
Dim value As System.Double

instance.Position = value

value = instance.Position

```

C#



```
System.double Position {get; set;}
```

C++/CLI

```
property System.double Position {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0 (start) to 100 (end)

Visual Basic for Applications (VBA) Syntax

See [EdgePoint::Position](#).

Example

[Create Reference Curve \(C#\)](#)
[Create Reference Curve \(VB.NET\)](#)
[Create Reference Curve \(VBA\)](#)

See Also

[IEdgePoint Interface](#)
[IEdgePoint Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Select Method (IEdgePoint)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEdgePoint Interface](#) : Select Method (IEdgePoint)

Selects a midpoint on an [edge](#) or an endpoint or midpoint on a [reference curve](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Select( _  
    ByVal BAppend As System.Boolean, _  
    ByVal SelMark As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IEdgePoint  
Dim BAppend As System.Boolean  
Dim SelMark As System.Integer  
Dim value As System.Boolean  
  
value = instance.Select(BAppend, SelMark)
```

C#

```
System.bool Select(  
    System.bool BAppend,  
    System.int SelMark  
)
```

C++/CLI

```
System.bool Select(  
& System.bool BAppend,  
& System.int SelMark  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BAppend

True to add this selection to the current selection, false to replace the current selection list with this selection

SelMark

Selection mark to assign to this midpoint or endpoint

Return Value

True if an endpoint or midpoint is selected, false if not

Visual Basic for Applications (VBA) Syntax

See [EdgePoint::Select](#).

See Also

[IEdgePoint Interface](#)

[IEdgePoint Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0