

SOLIDWORKS API (.NET VBA C#) — Reference

(99/337): IExplodeStep-IExportPdfData

SOLIDWORKS API Documentation (converted from CHM)

IExplodeStep (Type)

IExplodeStep Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IExplodeStep Interface

Allows access to an explode step in the explode view of the active assembly configuration.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IExplodeStep

Visual Basic (Usage)

Dim instance As [IExplodeStep](#)

C#

public interface IExplodeStep

C++/CLI

public interface class IExplodeStep

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep](#).

Example

[Add Regular Explode Step \(VBA\)](#)
[Edit Radial Explode Step \(VBA\)](#)

Remarks

This interface is valid only for assemblies. To access the explode steps of an explode view of multibody parts, see [IPartExplodeStep](#).

If this is a subassembly explode step, then you can call only one method on this interface, [IExplodeStep::GetSubAssemblyExplodeSteps](#), to retrieve the nested explode steps of this subassembly explode step.

The setter properties and methods of this interface:

- Always clear selection lists.
- Do not work if the Explode PropertyManager is open.
- Do not work if any component is being edited in the context of the assembly.

To edit an explode step that is not a subassembly explode step:

1. Use [IConfigurationManager::ActiveConfiguration](#) to get the active configuration of the assembly.
2. Access the explode step. See the **Accessors** section.
3. Call [IModelDocExtension::SelectByID2](#) to select:
 - a. Components to move with Mark = 1.
 - b. An explode direction entity (cylindrical [face](#), conical face, linear [edge](#), or [axis](#)) with Mark = 2 (regular explode steps) or Mark = 34 (radial explode steps).
 - c. A rotation axis with Mark = 32, if RotateAboutOrigin is set to false (regular explode steps only).
 - d. A diverge direction entity with Mark = 64 (radial explode steps only).
4. Call [ISelectionMgr::GetSelectedObject6](#) to get the components selected in step 3a.
5. Call [IExplodeStep::SetComponents](#), passing in the components gotten in step 4.
6. Call [IExplodeStep::SetExplodeDirection](#), passing in the explode direction entity that was selected in step 3b. See **Notes**.
7. Call [IExplodeStep::SetRotationAxis](#), passing in the rotation axis that was selected in step 3c (for regular explode steps only).
8. Set [IExplodeStep::DivergeDirection](#) to the diverge direction entity that was selected in step 3d (for radial explode steps only). See **Notes**.
9. Modify other explode step properties.

Notes:

When editing the object entity for the explode direction or rotation axis, please bear in mind:

If...	Then...
Both object and manipulator index are valid	Both object and manipulator index are set.
Manipulator index is valid, but object is invalid	Manipulator index is set, and object is unchanged.
Object is valid, but manipulator index is invalid	Object is set, but the manipulator index is reset to: • Z direction index for explode direction. • XY ring index for rotation axis.
Both object and manipulator index are invalid	No values change.

When editing the diverge direction object entity or the diverge from axis flag, please bear in mind:

If...	Then...
Diverge direction object is valid	IEExplodeStep::DivergeDirection properly sets the diverge direction, and IEExplodeStep::DivergeFromAxis is set to true.
Diverge direction object is null	IEExplodeStep::DivergeDirection is set to null, and IEExplodeStep::DivergeFromAxis is set to false.
Diverge direction object is invalid	Direction object entity is unchanged.
IEExplodeStep::DivergeFromAxis is set to false	IEExplodeStep::DivergeFromAxis is set to false, and the diverge direction object is set to null.
IEExplodeStep::DivergeFromAxis is set to true	No values change.

 Accessors

- [IConfiguration::AddExplodeStep2](#)
- [IConfiguration::AddRadialExplodeStep](#)
- [IConfiguration::GetExplodeStep](#) and [IConfiguration::IGetExplodeStep](#)

 Access Diagram

[ExplodeStep](#)

 See Also

- [IEExplodeStep Members](#)
- [SolidWorks.Interop.sldworks Namespace](#)
- [IAssemblyDoc::ShowExploded Method](#)
- [IModelDoc2::IsExploded Method](#)

IEExplodeStep Interface Methods

[See Also](#)

 SolidWorks.Interop.sldworks Namespace : IEExplodeStep Interface

For a list of all members of this type, see [IEExplodeStep members](#).

 Public Methods

Name	Description
 GetComponent	Gets the specified component in this explode step.
 GetComponentName	Gets the name of the specified component in this explode step.
 GetComponents	Gets the components of this explode step.
 GetComponentXform	Gets the transform of this explode step.
 GetExplodeDirection	Gets the explode direction (manipulator index and entity) for this explode step.
 GetNumOfComponents	Gets the number of components in this explode step.
 GetRotationAxis	Gets the rotation axis (manipulator index and entity) for this regular explode step.
 GetSpecificComponentXForm	Gets the transformation matrix of the specified component in this explode step.
 GetSubAssemblyExplodeSteps	Gets the explode steps of this subassembly explode step.
 IGetComponent	Gets the specified component in this explode step.
 IGetComponentXform	Gets the transform for this explode step.
 IsSubAssemblyRigid	Gets whether the subassembly is rigid or flexible.
 SetComponents	Specifies the components of this explode step.
 SetExplodeDirection	Sets the explode direction (manipulator index and entity) for this explode step.
 SetRotationAxis	Sets the rotation axis (manipulator index and entity) for this regular explode step.

[Top](#)

 See Also

- [IEExplodeStep Interface](#)
- [SolidWorks.Interop.sldworks Namespace](#)

ExplodeStep Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IExplodeStep Interface

The following tables list the members exposed by [IExplodeStep](#).

Public Properties

Name	Description
 AutoSpaceComponentsOnDrag	Gets or sets whether to automatically space a group of components equally along an axis as you drag them.
 DivergeDirection	Gets or sets the diverge direction entity for this radial explode step.
 DivergeFromAxis	Gets or sets whether to move components at an angle from the explode direction of this radial explode step.
 ExplodeDistance	Gets or sets the distance to move components in this regular or radial explode step.
 ExplodeStepType	Gets the type of this explode step.
 Name	Gets or sets the name of this explode step.
 ReverseRotationDirection	Gets or sets whether to reverse the direction of rotation of components in this regular explode step.
 ReverseTranslationDirection	Gets or sets whether to reverse the explode direction in this regular explode step.
 RotateAboutEachComponentOrigin	Gets or sets whether components rotate about their origins in this regular explode step.
 RotationAngle	Gets or sets the angle of component rotation in this regular or radial explode step.

[Top](#)

Public Methods

Name	Description
 GetComponent	Gets the specified component in this explode step.
 GetComponentName	Gets the name of the specified component in this explode step.
 GetComponents	Gets the components of this explode step.
 GetComponentXForm	Gets the transform of this explode step.
 GetExplodeDirection	Gets the explode direction (manipulator index and entity) for this explode step.
 GetNumOfComponents	Gets the number of components in this explode step.
 GetRotationAxis	Gets the rotation axis (manipulator index and entity) for this regular explode step.
 GetSpecificComponentXForm	Gets the transformation matrix of the specified component in this explode step.
 GetSubAssemblyExplodeSteps	Gets the explode steps of this subassembly explode step.
 IGetComponent	Gets the specified component in this explode step.
 IGetComponentXForm	Gets the transform for this explode step.
 IsSubAssemblyRigid	Gets whether the subassembly is rigid or flexible.
 SetComponents	Specifies the components of this explode step.
 SetExplodeDirection	Sets the explode direction (manipulator index and entity) for this explode step.
 SetRotationAxis	Sets the rotation axis (manipulator index and entity) for this regular explode step.

[Top](#)

See Also

[IExplodeStep Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAssemblyDoc::ShowExploded Method](#)
[IModelDoc2::IsExploded Method](#)

IExplodeStep Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IExplodeStep Interface

For a list of all members of this type, see [IExplodeStep members](#).

Public Properties

Name	Description
 AutoSpaceComponentsOnDrag	Gets or sets whether to automatically space a group of components equally along an axis as you drag them.
 DivergeDirection	Gets or sets the diverge direction entity for this radial explode step.
 DivergeFromAxis	Gets or sets whether to move components at an angle from the explode direction of this radial explode step.
 ExplodeDistance	Gets or sets the distance to move components in this regular or radial explode step.
 ExplodeStepType	Gets the type of this explode step.
 Name	Gets or sets the name of this explode step.
 ReverseRotationDirection	Gets or sets whether to reverse the direction of rotation of components in this regular explode step.
 ReverseTranslationDirection	Gets or sets whether to reverse the explode direction in this regular explode step.
 RotateAboutEachComponentOrigin	Gets or sets whether components rotate about their origins in this regular explode step.
 RotationAngle	Gets or sets the angle of component rotation in this regular or radial explode step.

[Top](#)

See Also

[IExplodeStep Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAssemblyDoc::ShowExploded Method](#)
[IModelDoc2::IsExploded Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AutoSpaceComponentsOnDrag Property (IExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : AutoSpaceComponentsOnDrag Property (IExplodeStep)

Gets or sets whether to automatically space a group of components equally along an axis as you drag them.

.NET Syntax

Visual Basic (Declaration)

Property AutoSpaceComponentsOnDrag As System.Boolean

Visual Basic (Usage)



```
Dim instance As IExplodeStep
Dim value As System.Boolean

instance.AutoSpaceComponentsOnDrag = value

value = instance.AutoSpaceComponentsOnDrag
```

C#

```
System.bool AutoSpaceComponentsOnDrag {get; set;}
```

C++/CLI

```
property System.bool AutoSpaceComponentsOnDrag {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to automatically space components equally along an axis as you drag them, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep::AutoSpaceComponentsOnDrag](#).

Remarks

If this property is set to true, then, by default, [IEExplodeStep::RotateAboutEachComponentOrigin](#) is false and [IEExplodeStep::RotationAngle](#) is 0.0.

If you set this property to false during editing of this step, then you must re-set the values for [IEExplodeStep::RotateAboutEachComponentOrigin](#) and [IEExplodeStep::RotationAngle](#).

See Also

[IEExplodeStep Interface](#)
[IEExplodeStep Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DivergeDirection Property (IEExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IEExplodeStep Interface](#) : DivergeDirection Property (IEExplodeStep)

Gets or sets the diverge direction entity for this radial explode step.

.NET Syntax

Visual Basic (Declaration)

Property DivergeDirection As System.Object

Visual Basic (Usage)



```
Dim instance As IEExplodeStep
Dim value As System.Object

instance.DivergeDirection = value
value = instance.DivergeDirection
```

C#

```
System.object DivergeDirection {get; set;}
```

C++/CLI

```
property System.Object^ DivergeDirection {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Cylindrical [face](#), conical face, linear [edge](#), or [axis](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep::DivergeDirection](#).

Example

See the [IExplodeStep](#) examples.

Remarks

This property is valid only if:

- [IExplodeStep::ExplodeStepType](#) is set to [swAssemblyExplodeStepType_e.swAssemblyExplodeStepType_Radial](#),
- and -
- the selected entity creates an angle with the explode direction.

If you set this property to a valid diverge direction entity, then [IExplodeStep::DivergeFromAxis](#) is automatically set to true.

If you set this property to Nothing or null, then [IExplodeStep::DivergeFromAxis](#) is automatically set to false.

See Also

[IExplodeStep Interface](#)
[IExplodeStep Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DivergeFromAxis Property (IExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : DivergeFromAxis Property (IExplodeStep)

Gets or sets whether to move components at an angle from the explode direction of this radial explode step.

.NET Syntax

Visual Basic (Declaration)

Property DivergeFromAxis As System.Boolean

Visual Basic (Usage)



```
Dim instance As IExplodeStep  
Dim value As System.Boolean  
  
instance.DivergeFromAxis = value  
  
value = instance.DivergeFromAxis
```

C#

```
System.bool DivergeFromAxis {get; set;}
```

C++/CLI

```
property System.bool DivergeFromAxis {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to move components at an angle from the explode direction, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep::DivergeFromAxis](#).

Example

See the [IExplodeStep](#) examples.

Remarks

This property is valid only if [IExplodeStep::ExplodeStepType](#) is set to [swAssemblyExplodeStepType_e.swAssemblyExplodeStepType_Radial](#). If you set this property to false, then [IExplodeStep::DivergeDirection](#) is automatically set to nothing or null. If you want to set this property to true, then you must first set [IExplodeStep::DivergeDirection](#) to a valid diverge direction entity.

See Also

[IExplodeStep Interface](#)
[IExplodeStep Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ExplodeDistance Property (IExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : ExplodeDistance Property (IExplodeStep)

Gets or sets the distance to move components in this regular or radial explode step.

.NET Syntax

Visual Basic (Declaration)

Property ExplodeDistance As System.Double

Visual Basic (Usage)



```
Dim instance As IExplodeStep
Dim value As System.Double

instance.ExplodeDistance = value
value = instance.ExplodeDistance
```

C#

```
System.double ExplodeDistance {get; set;}
```

C++/CLI

```
property System.double ExplodeDistance {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance in meters to move components

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep::ExplodeDistance](#).

Example

See the [IExplodeStep](#) examples.

See Also

[IExplodeStep Interface](#)
[IExplodeStep Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ExplodeStepType Property (IExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : ExplodeStepType Property (IExplodeStep)

Gets the type of this explode step.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ExplodeStepType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IExplodeStep
Dim value As System.Integer

value = instance.ExplodeStepType
```

C#

```
System.int ExplodeStepType {get;}
```

C++/CLI

```
property System.int ExplodeStepType {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Explode step type as defined in [swAssemblyExplodeStepType_e](#)

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep::ExplodeStepType](#).

Example

See the [IExplodeStep](#) examples.

See Also

[IExplodeStep Interface](#)
[IExplodeStep Members](#)
[IExplodeStep::DivergeDirection Property \(\)](#)
[IExplodeStep::DivergeFromAxis Property \(\)](#)
[IExplodeStep::ReverseRotationDirection Property \(\)](#)
[IExplodeStep::ReverseTranslationDirection Property \(\)](#)
[IExplodeStep::RotateAboutEachComponentOrigin Property \(\)](#)
[IExplodeStep::RotationAngle Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetComponent Method (IExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : GetComponent Method (IExplodeStep)

Gets the specified component in this explode step.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetComponent( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IExplodeStep  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetComponent(Index)
```

C#

```
System.object GetComponent(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetComponent(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of a component in this explode step

Return Value

Specified [component](#) in the explode step

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep::GetComponent](#).

Remarks

Before calling this method, call [IExplodeStep::GetNumOfComponents](#) to get a valid value for Index.

See Also

[IExplodeStep Interface](#)
[IExplodeStep Members](#)
[IExplodeStep::GetComponentName Method](#)
[IExplodeStep::GetNumOfComponents Method](#)
[IExplodeStep::GetComponent Method](#)
[IExplodeStep::GetComponents Method \(\)](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetComponentName Method (IExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : GetComponentName Method (IExplodeStep)

Gets the name of the specified component in this explode step.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetComponentName( _  
    ByVal Index As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IExplodeStep  
Dim Index As System.Integer  
Dim value As System.String  
  
value = instance.GetComponentName(Index)
```

C#

```
System.string GetComponentName(  
    System.int Index  
)
```

C++/CLI

```
System.String^ GetComponentName(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the component in this explode step

Return Value

Name of the component

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep::GetComponentName](#).

Remarks

Before calling this method, call [IExplodeStep::GetNumOfComponents](#) to get a valid value for Index.

See Also

[IExplodeStep Interface](#)

[IExplodeStep Members](#)

[IExplodeStep::GetComponents Method \(\)](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetComponents Method (IExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : GetComponents Method (IExplodeStep)

Gets the components of this explode step.

.NET Syntax

Visual Basic (Declaration)

```
Function GetComponents() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IExplodeStep
Dim value As System.Object

value = instance.GetComponents()
```

C#

```
System.Object GetComponents()
```

C++/CLI

```
System.Object^ GetComponents();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [components](#)

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep::GetComponents](#).

Example

See the [IExplodeStep](#) examples.

See Also

[IExplodeStep Interface](#)
[IExplodeStep Members](#)
[IExplodeStep::GetComponent Method \(\)](#)
[IExplodeStep::GetComponentName Method \(\)](#)
[IExplodeStep::GetComponentXform Method \(\)](#)
[IExplodeStep::SetComponents Method \(\)](#)
[IExplodeStep::GetNumOfComponents Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetComponentXform Method (IExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : GetComponentXform Method (IExplodeStep)

Gets the transform of this explode step.

.NET Syntax

Visual Basic (Declaration)

```
Function GetComponentXform() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IExplodeStep
Dim value As System.Object

value = instance.GetComponentXform()
```

C#

```
System.Object GetComponentXform()
```

C++/CLI

```
System.Object^ GetComponentXform();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of 16 doubles describing the transform of the explode step

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep::GetComponentXform](#).

See Also

[IExplodeStep Interface](#)
[IExplodeStep Members](#)
[IExplodeStep::GetComponentXform Method \(\)](#)
[IExplodeStep::GetComponents Method \(\)](#)
[IExplodeStep::GetSpecificComponentXForm Method \(\)](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetExplodeDirection Method (IExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : GetExplodeDirection Method (IExplodeStep)

Gets the explode direction (manipulator index and entity) for this explode step.

.NET Syntax

Visual Basic (Declaration)

```
Function GetExplodeDirection( _  
    ByRef ExplDirIndex As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IExplodeStep  
Dim ExplDirIndex As System.Integer  
Dim value As System.Object  
  
value = instance.GetExplodeDirection(ExplDirIndex)
```

C#

```
System.object GetExplodeDirection(  
    out System.int ExplDirIndex  
)
```

C++/CLI

```
System.Object^ GetExplodeDirection(  
    & [Out] System.int ExplDirIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ExplDirIndex
Explode direction manipulator index as defined in [swExplodeDirectionIndex_e](#); valid only for regular explode steps

Return Value

Explode direction entity; Nothing or null if an explode direction entity was not selected during creation of this explode step

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep::GetExplodeDirection](#).

Remarks

This method is not valid for subassembly explode steps.

See Also

[IExplodeStep Interface](#)
[IExplodeStep Members](#)
[IExplodeStep::SetExplodeDirection Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNumOfComponents Method (IExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : GetNumOfComponents Method (IExplodeStep)

Gets the number of components in this explode step.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNumOfComponents() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IExplodeStep  
Dim value As System.Integer  
  
value = instance.GetNumOfComponents()
```

C#

```
System.int GetNumOfComponents()
```

C++/CLI

```
System.int GetNumOfComponents();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of components in this explode step

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep::GetNumOfComponents](#).

See Also

[IExplodeStep Interface](#)
[IExplodeStep Members](#)
[IExplodeStep::GetComponent Method](#)
[IExplodeStep::GetComponentName Method](#)
[IExplodeStep::IGetComponent Method](#)
[IExplodeStep::GetComponents Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRotationAxis Method (IExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : GetRotationAxis Method (IExplodeStep)

Gets the rotation axis (manipulator index and entity) for this regular explode step.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetRotationAxis( _  
    ByRef RotAxisIndex As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IExplodeStep  
Dim RotAxisIndex As System.Integer  
Dim value As System.Object  
  
value = instance.GetRotationAxis(RotAxisIndex)
```

C#

```
System.object GetRotationAxis(  
    out System.int RotAxisIndex  
)
```

C++/CLI

```
System.Object^ GetRotationAxis(  
    & [Out] System.int RotAxisIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RotAxisIndex
Rotation manipulator index as defined in [swRotationAxisIndex_e](#)

Return Value

Rotation axis entity; Nothing or null if a rotation axis entity was not selected during creation of this explode step

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep::GetRotationAxis](#).

Remarks

This method is not valid for subassembly explode steps.

See Also

[IExplodeStep Interface](#)
[IExplodeStep Members](#)
[IExplodeStep::SetRotationAxis Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSpecificComponentXForm Method (IExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : GetSpecificComponentXForm Method (IExplodeStep)

Gets the transformation matrix of the specified component in this explode step.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetSpecificComponentXForm( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IExplodeStep  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetSpecificComponentXForm(Index)
```

C#

```
System.Object GetSpecificComponentXForm(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetSpecificComponentXForm(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of a component in the selection list

Return Value

Transformation matrix array of 16 doubles

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep::GetSpecificComponentXForm](#).

Remarks

Before calling this method, call [IExplodeStep::GetNumOfComponents](#) to get a valid value for Index.

For regular explode steps, this method works just like [IExplodeStep::GetComponentXform](#) to get the transformation of the entire explode step. This method also works for radial explode steps by getting the transformation of an individual radial explode component.

See Also

[IExplodeStep Interface](#)
[IExplodeStep Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSubAssemblyExplodeSteps Method (IExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : GetSubAssemblyExplodeSteps Method (IExplodeStep)

Gets the explode steps of this subassembly explode step.

Visual Basic Syntax

Visual Basic (Declaration)

Function GetSubAssemblyExplodeSteps() As System.Object

Visual Basic (Usage)



```
Dim instance As IExplodeStep
Dim value As System.Object

value = instance.GetSubAssemblyExplodeSteps()
```

C#

```
System.Object GetSubAssemblyExplodeSteps()
```

C++/CLI

```
System.Object^ GetSubAssemblyExplodeSteps();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [IExplodeSteps](#) in the subassembly explode view

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep::GetSubAssemblyExplodeSteps](#).

Example

See the [IExplodeStep](#) examples.

Remarks

A subassembly explode step is created when you click **Reuse Subassembly Explode** on the Explode PropertyManager. This method retrieves the nested explode steps of the subassembly.

This method is valid only if [IExplodeStep::ExplodeStepType](#) returns [swAssemblyExplodeStepType_e.swAssemblyExplodeStepType_SubAssembly](#).

See Also

[IExplodeStep Interface](#)
[IExplodeStep Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetComponent Method (IExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : IGetComponent Method (IExplodeStep)

Gets the specified component in this explode step.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetComponent( _
    ByVal Index As System.Integer _
) As Component
```

Visual Basic (Usage)



```
Dim instance As IExplodeStep
Dim Index As System.Integer
Dim value As Component

value = instance.IGetComponent(Index)
```

C#

```
Component IGetComponent(
    System.int Index
)
```

C++/CLI

```
Component^ IGetComponent(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the component in this explode step

Return Value

Specified [component](#) in the explode step

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep.IGetComponent](#).

Remarks

Before calling this method, call [IExplodeStep.GetNumOfComponents](#) to get a valid value for Index.

See Also

[IExplodeStep Interface](#)
[IExplodeStep Members](#)
[IExplodeStep.GetComponent Method](#)
[IExplodeStep.GetComponentName Method](#)
[IExplodeStep.GetNumOfComponents Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetComponentXform Method (IExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : IGetComponentXform Method (IExplodeStep)

Gets the transform for this explode step.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetComponentXform() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IExplodeStep
Dim value As System.Double

value = instance.IGetComponentXform()
```

C#

```
System.double IGetComponentXform()
```

C++/CLI

```
System.double IGetComponentXform();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of 16 doubles describing the transform of the component
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

See Also

[IExplodeStep Interface](#)
[IExplodeStep Members](#)
[IExplodeStep::GetComponentXform Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsSubAssemblyRigid Method (IExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : IsSubAssemblyRigid Method (IExplodeStep)

Gets whether the subassembly is rigid or flexible.

.NET Syntax

Visual Basic (Declaration)

```
Function IsSubAssemblyRigid() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExplodeStep  
Dim value As System.Boolean  
  
value = instance.IsSubAssemblyRigid()
```

C#

```
System.bool IsSubAssemblyRigid()
```

C++/CLI

```
System.bool IsSubAssemblyRigid();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the subassembly is rigid, false if it is flexible

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep::IsSubAssemblyRigid](#).

Remarks

See the SOLIDWORKS Help for more information about flexible and rigid subassemblies.

See Also

[IExplodeStep Interface](#)
[IExplodeStep Members](#)
[IComponent2::Solving Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Name Property (IExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : Name Property (IExplodeStep)

Gets or sets the name of this explode step.

.NET Syntax

Visual Basic (Declaration)

```
Property Name As System.String
```

Visual Basic (Usage)



```
Dim instance As IExplodeStep  
Dim value As System.String
```

```
instance.Name = value
```

```
value = instance.Name
```

C#

```
System.string Name {get; set;}
```

C++/CLI

```
property System.String^ Name {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of this explode step

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep::Name](#).

Example

See the [IExplodeStep](#) examples.

See Also

[IExplodeStep Interface](#)
[IExplodeStep Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseRotationDirection Property (IExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : ReverseRotationDirection Property (IExplodeStep)

Gets or sets whether to reverse the direction of rotation of components in this regular explode step.

Visual Basic (Declaration)

Property ReverseRotationDirection As System.Boolean

Visual Basic (Usage)

Dim instance As IExplodeStep

Dim value As System.Boolean

instance.ReverseRotationDirection = value

value = instance.ReverseRotationDirection

C#

System.bool ReverseRotationDirection {get; set;}

C++/CLI

property System.bool ReverseRotationDirection {
 System.bool get();
 void set (& System.bool value);
}

NOTE:

See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the direction of rotation of components, false to not

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep::ReverseRotationDirection](#).

Example

See the [IExplodeStep](#) examples.

Remarks

This property is valid only if [IExplodeStep::ExplodeStepType](#) is set to [swAssemblyExplodeStepType_e.swAssemblyExplodeStepType_Translate](#)

See Also

[IExplodeStep Interface](#)

[IExplodeStep Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

ReverseTranslationDirection Property (IExplodeStep)

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : ReverseTranslationDirection Property (IExplodeStep)

Gets or sets whether to reverse the explode direction in this regular explode step.

Visual Basic (Declaration)

Property ReverseTranslationDirection As System.Boolean

```
Dim instance As IExplodeStep
Dim value As System.Boolean

instance.ReverseTranslationDirection = value

value = instance.ReverseTranslationDirection
```

C#

```
System.bool ReverseTranslationDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseTranslationDirection {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the explode direction, false to not

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep.ReverseTranslationDirection](#).

Example

See the [IExplodeStep](#) examples.

Remarks

This property is valid only if [IExplodeStep.ExplodeStepType](#) is set to [swAssemblyExplodeStepType_e.swAssemblyExplodeStepType_Translate](#)

See Also

[IExplodeStep Interface](#)
[IExplodeStep Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RotateAboutEachComponentOrigin Property (IExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : RotateAboutEachComponentOrigin Property (IExplodeStep)

Gets or sets whether components rotate about their origins in this regular explode step.

.NET Syntax

Visual Basic (Declaration)

```
Property RotateAboutEachComponentOrigin As System.Boolean
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IExplodeStep
Dim value As System.Boolean

instance.RotateAboutEachComponentOrigin = value
```

```
value = instance.RotateAboutEachComponentOrigin
```

C#

```
System.bool RotateAboutEachComponentOrigin {get; set;}
```

C++/CLI

```
property System.bool RotateAboutEachComponentOrigin {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if components rotate about their origins, false if not

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep::RotateAboutEachComponentOrigin](#).

Example

See the [IExplodeStep](#) examples.

Remarks

If [IExplodeStep::AutoSpaceComponentsOnDrag](#) is set to true, then this property is automatically false.

This property is valid only if [IExplodeStep::ExplodeStepType](#) is set to [swAssemblyExplodeStepType_e.swAssemblyExplodeStepType_Translate](#)

If this property is set to true, then the rotation axis is automatically populated.

See Also

[IExplodeStep Interface](#)
[IExplodeStep Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RotationAngle Property (IExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : RotationAngle Property (IExplodeStep)

Gets or sets the angle of component rotation in this regular or radial explode step.

.NET Syntax

Visual Basic (Declaration)

```
Property RotationAngle As System.Double
```

Visual Basic (Usage)



```
Dim instance As IExplodeStep  
Dim value As System.Double  
  
instance.RotationAngle = value  
  
value = instance.RotationAngle
```

C#

```
System.double RotationAngle {get; set;}
```

C++/CLI

```
property System.double RotationAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle in radians of component rotation

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep::RotationAngle](#).

Example

See the [IExplodeStep](#) examples.

Remarks

If [IExplodeStep::AutoSpaceComponentsOnDrag](#) is set to true, then this property is automatically 0.0.

If [IExplodeStep::ExplodeStepType](#) is set to [swAssemblyExplodeStepType_e](#):

- [swAssemblyExplodeStepType_Radial](#), then this property sets the degree of rotation of components about their origins.
- [swAssemblyExplodeStepType_Translate](#), then this property sets the degree of rotation of components about the rotation axis.

See Also

[IExplodeStep Interface](#)
[IExplodeStep Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetComponents Method (IExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : SetComponents Method (IExplodeStep)

Specifies the components of this explode step.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetComponents( _  
    ByVal Components As System.Object _  
)
```

Visual Basic (Usage)

```
Dim instance As IExplodeStep  
Dim Components As System.Object  
  
instance.SetComponents(Components)
```

C#

```
void SetComponents(  
    System.object Components  
)
```



```
void SetComponents(
& System.Object^ Components
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Components
Array of [components](#)

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep::SetComponents](#).

Remarks

Modifying components during editing of this regular explode step modifies the rotational axis if:

- the rotational axis was not provided during creation,
- and -
- the component to which it referred (the last component in the selection list) was removed during editing.

In that case, a rotational axis using the last selected component in the selection list is created.

See Also

[IExplodeStep Interface](#)
[IExplodeStep Members](#)
[IExplodeStep::GetComponents Method\(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetExplodeDirection Method (IExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : SetExplodeDirection Method (IExplodeStep)

Sets the explode direction (manipulator index and entity) for this explode step.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetExplodeDirection( _
    ByVal ExplodeDirection As System.Object, _
    ByVal ExplDirIndex As System.Integer _
)
```

Visual Basic (Usage)

```
Dim instance As IExplodeStep
Dim ExplodeDirection As System.Object
Dim ExplDirIndex As System.Integer

instance.SetExplodeDirection(ExplodeDirection, ExplDirIndex)
```

C#

```
void SetExplodeDirection(
    System.object ExplodeDirection,
    System.int ExplDirIndex
)
```

```
void SetExplodeDirection(
& System.Object^ ExplodeDirection,
& System.int ExplDirIndex
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ExplodeDirection

Explode direction entity

ExplDirIndex

Explode direction manipulator index as defined in [swExplodeDirectionIndex_e](#); valid only for regular explode steps

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep::SetExplodeDirection](#).

Example

See the [IExplodeStep](#) examples.

See Also

[IExplodeStep Interface](#)

[IExplodeStep Members](#)

[IExplodeStep::GetExplodeDirection Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetRotationAxis Method (IExplodeStep)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExplodeStep Interface](#) : SetRotationAxis Method (IExplodeStep)

Sets the rotation axis (manipulator index and entity) for this regular explode step.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetRotationAxis( _
    ByVal RotationAxis As System.Object, _
    ByVal RotAxisIndex As System.Integer _
)
```

Visual Basic (Usage)



```
Dim instance As IExplodeStep
Dim RotationAxis As System.Object
Dim RotAxisIndex As System.Integer

instance.SetRotationAxis(RotationAxis, RotAxisIndex)
```

C#

```
void SetRotationAxis(
    System.object RotationAxis,
    System.int RotAxisIndex
)
```

C++/CLI

```
void SetRotationAxis(
& System.Object^ RotationAxis,
```

```
& System.int RotAxisIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RotationAxis

Rotation axis entity

RotAxisIndex

Rotation manipulator index as defined in [swRotationAxisIndex_e](#)

Visual Basic for Applications (VBA) Syntax

See [ExplodeStep.SetRotationAxis](#).

See Also

[IExplodeStep Interface](#)

[IExplodeStep Members](#)

[IExplodeStep.GetRotationAxis Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

IExportPdfData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IExportPdfData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IExportPdfData Interface

Allows access to the PDF export data interface, which allows you to save:

- one or more drawing sheets to PDF.
- parts and assemblies to 3D PDF.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IExportPdfData

Visual Basic (Usage)



Dim instance As [IExportPdfData](#)

C#

public interface IExportPdfData

C++/CLI

public interface class IExportPdfData

Visual Basic for Applications (VBA) Syntax

See [ExportPdfData](#).

Example

[Save File as PDF \(VBA\)](#)
[Save File as PDF \(C#\)](#)
[Save File as PDF \(VB.NET\)](#)

Remarks

To export one or more drawing sheets to PDF:

1. Get the IExportPdfData object using [ISldWorks::GetExportFileData](#).
2. Set the sheets to export to PDF using [IExportPdfData::SetSheets](#).
3. Set whether to view the PDF after saving using [IExportPdfData::ViewPdfAfterSaving](#).
4. Save the sheets using [IModelDocExtension::SaveAs](#).

To export a part or assembly to 3D PDF:

1. Get the IExportPdfData object using [ISldWorks::GetExportFileData](#).
2. Set [IExportPdfData::ExportAs3D](#) to true.
3. Set whether to view the PDF after saving using [IExportPdfData::ViewPdfAfterSaving](#).
4. Save the part or assembly using [IModelDocExtension::SaveAs](#).

Accessors

[ISldWorks::GetExportFileData](#)

Access Diagram

See Also

[IExportPdfData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IExportPdfData Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : IExportPdfData Interface

The following tables list the members exposed by [IExportPdfData](#).

Public Properties

Name	Description
 ExportAs3D	Gets or sets whether to export this part or drawing document to 3D PDF.
 ViewPdfAfterSaving	Gets or sets whether to view the PDF file to which a part or drawing is saved.

[Top](#)

Public Methods

Name	Description
 GetSheets	Gets the drawing sheets to export.
 GetWhichSheets	Gets the drawing sheets to export to PDF.
 SetSheets	Sets the drawing sheets to export.

[Top](#)

See Also

[IExportPdfData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IExportPdfData Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IExportPdfData Interface

For a list of all members of this type, see [IExportPdfData members](#).

Public Methods

Name	Description
 GetSheets	Gets the drawing sheets to export.
 GetWhichSheets	Gets the drawing sheets to export to PDF.
 SetSheets	Sets the drawing sheets to export.

[Top](#)

See Also

[IExportPdfData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IExportPdfData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IExportPdfData Interface

For a list of all members of this type, see [IExportPdfData members](#).

Public Properties

Name	Description
 ExportAs3D	Gets or sets whether to export this part or drawing document to 3D PDF.
 ViewPdfAfterSaving	Gets or sets whether to view the PDF file to which a part or drawing is saved.

[Top](#)

See Also

[IExportPdfData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ExportAs3D Property (IExportPdfData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExportPdfData Interface](#) : ExportAs3D Property (IExportPdfData)

Gets or sets whether to export this part or drawing document to 3D PDF.

.NET Syntax

Visual Basic (Declaration)

Property ExportAs3D As System.Boolean

Visual Basic (Usage)



```
Dim instance As IExportPdfData  
Dim value As System.Boolean
```

```
instance.ExportAs3D = value
```

```
value = instance.ExportAs3D
```

C#

```
System.bool ExportAs3D {get; set;}
```

C++/CLI

```
property System.bool ExportAs3D {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to export this part or drawing document to 3D PDF, false to not

Visual Basic for Applications (VBA) Syntax

See [ExportPdfData::ExportAs3D](#).

Remarks

Call [IModelDocExtension::SaveAs](#) after setting this property.

See Also

[IExportPdfData Interface](#)
[IExportPdfData Members](#)

Availability

GetSheets Method (IExportPdfData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IExportPdfData Interface](#) : GetSheets Method (IExportPdfData)Gets the drawing [sheets](#) to export.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSheets() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IExportPdfData  
Dim value As System.Object  
  
value = instance.GetSheets()
```

C#

```
System.object GetSheets()
```

C++/CLI

```
System.Object^ GetSheets();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of the names of the sheets to export

Visual Basic for Applications (VBA) Syntax

See [ExportPdfData::GetSheets](#).

Remarks

Call [IModelDocExtension::SaveAs](#) after calling this method.

See Also

[IExportPdfData Interface](#)
[IExportPdfData Members](#)
[IExportPdfData::GetWhichSheets Method](#)
[IExportPdfData::SetSheets Method](#)

Availability

SOLIDWORKS 2007 SP1, Revision Number 15

GetWhichSheets Method (IExportPdfData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IExportPdfData Interface](#) : GetWhichSheets Method (IExportPdfData)Gets the drawing [sheets](#) to export to PDF.

.NET Syntax

Visual Basic (Declaration)

```
Function GetWhichSheets() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IExportPdfData  
Dim value As System.Integer  
  
value = instance.GetWhichSheets()
```

C#

```
System.int GetWhichSheets()
```

C++/CLI

```
System.int GetWhichSheets();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Drawing sheets to export to PDF as defined in [swExportDataSheetsToExport](#) e

Visual Basic for Applications (VBA) Syntax

See [ExportPdfData::GetWhichSheets](#).

See Also

[IExportPdfData Interface](#)
[IExportPdfData Members](#)
[IExportPdfData::GetSheets Method](#)
[IExportPdfData::SetSheets Method](#)

Availability

SOLIDWORKS 2007 SP1, Revision Number 15

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetSheets Method (IExportPdfData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExportPdfData Interface](#) : SetSheets Method (IExportPdfData)

Sets the drawing [sheets](#) to export.

.NET Syntax

Visual Basic (Declaration)

```
Function SetSheets( _  
    ByVal Which As System.Integer, _  
    ByVal Sheets As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IExportPdfData  
Dim Which As System.Integer  
Dim Sheets As System.Object  
Dim value As System.Boolean  
  
value = instance.SetSheets(Which, Sheets)
```

C#

```
System.bool SetSheets(  
    System.int Which,  
    System.object Sheets  
)
```

C++/CLI

```
System.bool SetSheets(  
& System.int Which,  
& System.Object^ Sheets  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Which
Drawing sheets to export to PDF as defined in [swExportDataSheetsToExport_e](#)
Sheets
Array of the names of the drawing sheets to export

Return Value

True if the drawings sheets are set to export to PDF, false if not

Visual Basic for Applications (VBA) Syntax

See [ExportPdfData::SetSheets](#).

Example

[Save File as PDF \(VBA\)](#)
[Save File as PDF \(C#\)](#)
[Save File as PDF \(VB.NET\)](#)

See Also

[IExportPdfData Interface](#)
[IExportPdfData Members](#)
[IExportPdfData::GetSheets Method](#)
[IExportPdfData::GetWhichSheets Method](#)

Availability

SOLIDWORKS 2007 SP1, Revision Number 15

SOLIDWORKS API Help

[Send comments on this topic.](#)

ViewPdfAfterSaving Property (IExportPdfData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExportPdfData Interface](#) : ViewPdfAfterSaving Property (IExportPdfData)

Gets or sets whether to view the PDF file to which a part or drawing is saved.

.NET Syntax

Visual Basic (Declaration)

Property ViewPdfAfterSaving As System.Boolean

Visual Basic (Usage)



```
Dim instance As IExportPdfData  
Dim value As System.Boolean
```

```
instance.ViewPdfAfterSaving = value
```

```
value = instance.ViewPdfAfterSaving
```

C#

```
System.bool ViewPdfAfterSaving {get; set;}
```

C++/CLI

```
property System.bool ViewPdfAfterSaving {  
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to view the PDF file, false to not

Visual Basic for Applications (VBA) Syntax

See [ExportPdfData::ViewPdfAfterSaving](#).

Example

See [IExportPdfData](#) examples.

See Also

[IExportPdfData Interface](#)
[IExportPdfData Members](#)

Availability

SOLIDWORKS 2013 SP03, Revision Number 21.3