

SOLIDWORKS API (.NET, VBA, C#) — Reference

(100/337): IExtrudeFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IExtrudeFeatureData (Type)

IExtrudeFeatureData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IExtrudeFeatureData Interface

Obsolete. Superseded by [IExtrudeFeatureData2](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IExtrudeFeatureData

Visual Basic (Usage)



Dim instance As [IExtrudeFeatureData](#)

C#

public interface IExtrudeFeatureData

C++/CLI

public interface class IExtrudeFeatureData

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData](#).

See Also

[IExtrudeFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IExtrudeFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IExtrudeFeatureData Interface

For a list of all members of this type, see [IExtrudeFeatureData members](#).

Public Methods

Name	Description
AccessSelections	Obsolete. Superseded by IExtrudeFeatureData2.AccessSelections .
GetDepth	Obsolete. Superseded by IExtrudeFeatureData2.GetDepth .
GetDraftAngle	Obsolete. Superseded by IExtrudeFeatureData2.GetDraftAngle .
GetDraftOutward	Obsolete. Superseded by IExtrudeFeatureData2.GetDraftOutward .
GetDraftWhileExtruding	Obsolete. Superseded by IExtrudeFeatureData2.GetDraftWhileExtruding .
GetEndCondition	Obsolete. Superseded by IExtrudeFeatureData2.GetEndCondition .
GetFace	Obsolete. Superseded by IExtrudeFeatureData2.GetEndConditionReference .
GetVertex	Obsolete. Superseded by IExtrudeFeatureData2.GetEndConditionReference .
GetWallThickness	Obsolete. Superseded by IExtrudeFeatureData2.GetWallThickness .
IAccessSelections	Obsolete. Superseded by IExtrudeFeatureData2.IAccessSelections .
IGetFace	Obsolete. Superseded by IExtrudeFeatureData2.GetEndConditionReference .
IGetVertex	Obsolete. Superseded by IExtrudeFeatureData2.GetEndConditionReference .

		
 IsBaseExtrude	Obsolete. Superseded by IFeature.IsBase2 .	
 IsBossFeature	Obsolete. Superseded by IExtrudeFeatureData2.IsBossFeature .	
 ISetFace	Obsolete. Superseded by IExtrudeFeatureData2.SetEndConditionReference .	
 ISetVertex	Obsolete. Superseded by IExtrudeFeatureData2.SetEndConditionReference .	
 IsThinFeature	Obsolete. Superseded by IExtrudeFeatureData2.IsThinFeature .	
 ReleaseSelectionAccess	Obsolete. Superseded by IExtrudeFeatureData2.ReleaseSelectionAccess .	
 SetDepth	Obsolete. Superseded by IExtrudeFeatureData2.SetDepth .	
 SetDraftAngle	Obsolete. Superseded by IExtrudeFeatureData2.SetDraftAngle .	
 SetDraftOutward	Obsolete. Superseded by IExtrudeFeatureData2.SetDraftOutward .	
 SetDraftWhileExtruding	Obsolete. Superseded by IExtrudeFeatureData2.SetDraftWhileExtruding .	
 SetEndCondition	Obsolete. Superseded by IExtrudeFeatureData2.SetEndCondition .	
 SetFace	Obsolete. Superseded by IExtrudeFeatureData2.SetEndConditionReference .	
 SetVertex	Obsolete. Superseded by IExtrudeFeatureData2.SetEndConditionReference .	
 SetWallThickness	Obsolete. Superseded by IExtrudeFeatureData2.SetWallThickness .	

[Top](#)

 See Also

[IExtrudeFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IExtrudeFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IExtrudeFeatureData Interface

The following tables list the members exposed by [IExtrudeFeatureData](#).

 Public Properties

Name	Description
 BothDirections	Obsolete. Superseded by IExtrudeFeatureData2.BothDirections .
 CapEnds	Obsolete. Superseded by IExtrudeFeatureData2.CapEnds .
 CapThickness	Obsolete. Superseded by IExtrudeFeatureData2.CapThickness .
 FlipSideToCut	Obsolete. Superseded by IExtrudeFeatureData2.FlipSideToCut .
 ReverseDirection	Obsolete. Superseded by IExtrudeFeatureData2.ReverseDirection .
 ThinWallType	Obsolete. Superseded by IExtrudeFeatureData2.ThinWallType .

[Top](#)

 Public Methods

Name	Description
 AccessSelections	Obsolete. Superseded by IExtrudeFeatureData2.AccessSelections .
 GetDepth	Obsolete. Superseded by IExtrudeFeatureData2.GetDepth .
 GetDraftAngle	Obsolete. Superseded by IExtrudeFeatureData2.GetDraftAngle .
 GetDraftOutward	Obsolete. Superseded by IExtrudeFeatureData2.GetDraftOutward .
 GetDraftWhileExtruding	Obsolete. Superseded by IExtrudeFeatureData2.GetDraftWhileExtruding .
 GetEndCondition	Obsolete. Superseded by IExtrudeFeatureData2.GetEndCondition .
 GetFace	Obsolete. Superseded by IExtrudeFeatureData2.GetEndConditionReference .

	GetVertex	Obsolete. Superseded by IExtrudeFeatureData2::GetEndConditionReference .
	GetWallThickness	Obsolete. Superseded by IExtrudeFeatureData2::GetWallThickness .
	IAccessSelections	Obsolete. Superseded by IExtrudeFeatureData2::IAccessSelections .
	IGetFace	Obsolete. Superseded by IExtrudeFeatureData2::GetEndConditionReference .
	IGetVertex	Obsolete. Superseded by IExtrudeFeatureData2::GetEndConditionReference .
	IsBaseExtrude	Obsolete. Superseded by IFeature::IsBase2 .
	IsBossFeature	Obsolete. Superseded by IExtrudeFeatureData2::IsBossFeature .
	ISetFace	Obsolete. Superseded by IExtrudeFeatureData2::SetEndConditionReference .
	ISetVertex	Obsolete. Superseded by IExtrudeFeatureData2::SetEndConditionReference .
	IsThinFeature	Obsolete. Superseded by IExtrudeFeatureData2::IsThinFeature .
	ReleaseSelectionAccess	Obsolete. Superseded by IExtrudeFeatureData2::ReleaseSelectionAccess .
	SetDepth	Obsolete. Superseded by IExtrudeFeatureData2::SetDepth .
	SetDraftAngle	Obsolete. Superseded by IExtrudeFeatureData2::SetDraftAngle .
	SetDraftOutward	Obsolete. Superseded by IExtrudeFeatureData2::SetDraftOutward .
	SetDraftWhileExtruding	Obsolete. Superseded by IExtrudeFeatureData2::SetDraftWhileExtruding .
	SetEndCondition	Obsolete. Superseded by IExtrudeFeatureData2::SetEndCondition .
	SetFace	Obsolete. Superseded by IExtrudeFeatureData2::SetEndConditionReference .
	SetVertex	Obsolete. Superseded by IExtrudeFeatureData2::SetEndConditionReference .
	SetWallThickness	Obsolete. Superseded by IExtrudeFeatureData2::SetWallThickness .

[Top](#)

 See Also

[IExtrudeFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IExtrudeFeatureData Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IExtrudeFeatureData Interface

For a list of all members of this type, see [IExtrudeFeatureData members](#).

 Public Properties

Name	Description
 BothDirections	Obsolete. Superseded by IExtrudeFeatureData2::BothDirections .
 CapEnds	Obsolete. Superseded by IExtrudeFeatureData2::CapEnds .
 CapThickness	Obsolete. Superseded by IExtrudeFeatureData2::CapThickness .
 FlipSideToCut	Obsolete. Superseded by IExtrudeFeatureData2::FlipSideToCut .
 ReverseDirection	Obsolete. Superseded by IExtrudeFeatureData2::ReverseDirection .
 ThinWallType	Obsolete. Superseded by IExtrudeFeatureData2::ThinWallType .

[Top](#)

 See Also

[IExtrudeFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AccessSelections Method (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : AccessSelections Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::AccessSelections](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Component

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::AccessSelections](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

BothDirections Property (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : BothDirections Property (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::BothDirections](#).

.NET Syntax

Visual Basic (Declaration)

```
Property BothDirections As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData
Dim value As System.Boolean

instance.BothDirections = value

value = instance.BothDirections
```

C#

```
System.bool BothDirections {get; set;}
```

C++/CLI

```
property System.bool BothDirections {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData.BothDirections](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CapEnds Property (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : CapEnds Property (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::CapEnds](#).

.NET Syntax

Visual Basic (Declaration)

```
Property CapEnds As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData
Dim value As System.Boolean

instance.CapEnds = value

value = instance.CapEnds
```

C#

```
System.bool CapEnds {get; set;}
```

C++/CLI

```
property System.bool CapEnds {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData.CapEnds](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CapThickness Property (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : CapThickness Property (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::CapThickness](#).

.NET Syntax

Visual Basic (Declaration)

Property CapThickness As System.Double

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData
Dim value As System.Double
```

```
instance.CapThickness = value
```

```
value = instance.CapThickness
```

C#

```
System.double CapThickness {get; set;}
```

C++/CLI

```
property System.double CapThickness {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::CapThickness](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

FlipSideToCut Property (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : FlipSideToCut Property (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::FlipSideToCut](#).

.NET Syntax

Visual Basic (Declaration)

Property FlipSideToCut As System.Boolean

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData
Dim value As System.Boolean
```

```
instance.FlipSideToCut = value  
value = instance.FlipSideToCut
```

C#

```
System.bool FlipSideToCut {get; set;}
```

C++/CLI

```
property System.bool FlipSideToCut {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::FlipSideToCut](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDepth Method (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : GetDepth Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::GetDepth](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDepth(  
    ByVal Forward As System.Boolean  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim value As System.Double  
  
value = instance.GetDepth(Forward)
```

C#

```
System.double GetDepth(  
    System.bool Forward  
)
```

C++/CLI

```
System.double GetDepth(  
& System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::GetDepth](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDraftAngle Method (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : GetDraftAngle Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::GetDraftAngle](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDraftAngle( _  
    ByVal Forward As System.Boolean _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim value As System.Double  
  
value = instance.GetDraftAngle(Forward)
```

C#

```
System.double GetDraftAngle(  
    System.bool Forward  
)
```

C++/CLI

```
System.double GetDraftAngle(  
    & System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::GetDraftAngle](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDraftOutward Method (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : GetDraftOutward Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::GetDraftOutward](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDraftOutward( _  
    ByVal Forward As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim value As System.Boolean  
  
value = instance.GetDraftOutward(Forward)
```

C#

```
System.bool GetDraftOutward(  
    System.bool Forward  
)
```

C++/CLI

```
System.bool GetDraftOutward(  
& System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::GetDraftOutward](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDraftWhileExtruding Method (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : GetDraftWhileExtruding Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::GetDraftWhileExtruding](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDraftWhileExtruding( _  
    ByVal Forward As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim value As System.Boolean  
  
value = instance.GetDraftWhileExtruding(Forward)
```

C#

```
System.bool GetDraftWhileExtruding(  
    System.bool Forward  
)
```

C++/CLI

```
System.bool GetDraftWhileExtruding(  
& System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::GetDraftWhileExtruding](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetEndCondition Method (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : GetEndCondition Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::GetEndCondition](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetEndCondition( _  
    ByVal Forward As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim value As System.Integer  
  
value = instance.GetEndCondition(Forward)
```

C#

```
System.int GetEndCondition(  
    System.bool Forward  
)
```

C++/CLI

```
System.int GetEndCondition(  
& System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::GetEndCondition](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFace Method (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : GetFace Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::GetEndConditionReference](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFace( _  
    ByVal Forward As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim value As System.Object  
  
value = instance.GetFace(Forward)
```

C#

```
System.object GetFace(  
    System.bool Forward  
)
```

C++/CLI

```
System.Object^ GetFace(  
& System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::GetFace](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetVertex Method (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : GetVertex Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::GetEndConditionReference](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetVertex( _  
    ByVal Forward As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim value As System.Object  
  
value = instance.GetVertex(Forward)
```

C#

```
System.object GetVertex(  
    System.bool Forward  
)
```

C++/CLI

```
System.Object^ GetVertex(  
& System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::GetVertex](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetWallThickness Method (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : GetWallThickness Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::GetWallThickness](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetWallThickness( _  
    ByVal Forward As System.Boolean _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim value As System.Double  
  
value = instance.GetWallThickness(Forward)
```

C#

```
System.double GetWallThickness(  
    System.bool Forward  
)
```

C++/CLI

```
System.double GetWallThickness(  
&    System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::GetWallThickness](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections Method (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : IAccessSelections Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::IAccessSelections](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim TopDoc As ModelDoc  
Dim Component As Component  
Dim value As System.Boolean
```

```
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc TopDoc,  
    Component Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
&    ModelDoc^ TopDoc,  
&    Component^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

 Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::IAccessSelections](#).

 See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFace Method (IExtrudeFeatureData)

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : IGetFace Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::GetEndConditionReference](#).

 .NET Syntax

Visual Basic (Declaration)

```
Function IGetFace( _
    ByVal Forward As System.Boolean _
) As Face
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData
Dim Forward As System.Boolean
Dim value As Face
```

```
value = instance.IGetFace(Forward)
```

C#

```
Face IGetFace(
    System.bool Forward
)
```

C++/CLI

```
Face^ IGetFace(
    & System.bool Forward
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

 Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::IGetFace](#).

 See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetVertex Method (IExtrudeFeatureData)

[See Also](#)

Obsolete. Superseded by [IExtrudeFeatureData2::GetEndConditionReference](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetVertex(  
    ByVal Forward As System.Boolean  
) As Vertex
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim value As Vertex
```

```
value = instance.IGetVertex(Forward)
```

C#

```
Vertex IGetVertex(  
    System.bool Forward  
)
```

C++/CLI

```
Vertex^ IGetVertex(  
& System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::IGetVertex](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsBaseExtrude Method (IExtrudeFeatureData)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > IExtrudeFeatureData Interface : IsBaseExtrude Method (IExtrudeFeatureData)

Obsolete. Superseded by [IFeature::IsBase2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IsBaseExtrude() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim value As System.Boolean
```

```
value = instance.IsBaseExtrude()
```

C#

```
System.bool IsBaseExtrude()
```

C++/CLI

```
System.bool IsBaseExtrude();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::IsBaseExtrude](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsBossFeature Method (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : IsBossFeature Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::IsBossFeature](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IsBossFeature() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim value As System.Boolean
```

```
value = instance.IsBossFeature()
```

C#

```
System.bool IsBossFeature()
```

C++/CLI

```
System.bool IsBossFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::IsBossFeature](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetFace Method (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : ISetFace Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::SetEndConditionReference](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetFace( _  
    ByVal Forward As System.Boolean, _  
    ByVal Face As Face _  
)
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim Face As Face  
  
instance.ISetFace(Forward, Face)
```

C#

```
void ISetFace(  
    System.bool Forward,  
    Face Face  
)
```

C++/CLI

```
void ISetFace(  
& System.bool Forward,  
& Face^ Face  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Face

v

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::ISetFace](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetVertex Method (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : ISetVertex Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::SetEndConditionReference](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetVertex( _  
    ByVal Forward As System.Boolean, _  
    ByVal Face As Vertex _  
)
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim Face As Vertex  
  
instance.ISetVertex(Forward, Face)
```

C#

```
void ISetVertex(  
    System.bool Forward,  
    Vertex Face  
)
```

C++/CLI

```
void ISetVertex(  
&    System.bool Forward,  
&    Vertex^ Face  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Face

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::ISetVertex](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsThinFeature Method (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : IsThinFeature Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::IsThinFeature](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IsThinFeature() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim value As System.Boolean  
  
value = instance.IsThinFeature()
```

C#

```
System.bool IsThinFeature()
```

C++/CLI

```
System.bool IsThinFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::IsThinFeature](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReleaseSelectionAccess Method (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : ReleaseSelectionAccess Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::ReleaseSelectionAccess](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::ReleaseSelectionAccess](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReverseDirection Property (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : ReverseDirection Property (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::ReverseDirection](#).

.NET Syntax

Visual Basic (Declaration)

```
Property ReverseDirection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim value As System.Boolean  
  
instance.ReverseDirection = value  
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::ReverseDirection](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetDepth Method (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : SetDepth Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::SetDepth](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDepth( _  
    ByVal Forward As System.Boolean, _  
    ByVal Depth As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim Depth As System.Double  
  
instance.SetDepth(Forward, Depth)
```

C#

```
void SetDepth(  
    System.bool Forward,  
    System.double Depth  
)
```

C++/CLI

```
void SetDepth(  
& System.bool Forward,  
& System.double Depth  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Depth

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::SetDepth](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetDraftAngle Method (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : SetDraftAngle Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::SetDraftAngle](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDraftAngle( _  
    ByVal Forward As System.Boolean, _  
    ByVal DraftAngle As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim DraftAngle As System.Double  
  
instance.SetDraftAngle(Forward, DraftAngle)
```

C#

```
void SetDraftAngle(  
    System.bool Forward,  
    System.double DraftAngle  
)
```

C++/CLI

```
void SetDraftAngle(  
& System.bool Forward,  
& System.double DraftAngle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

DraftAngle

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::SetDraftAngle](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetDraftOutward Method (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : SetDraftOutward Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::SetDraftOutward](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDraftOutward( _  
    ByVal Forward As System.Boolean, _  
    ByVal DraftOutward As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim DraftOutward As System.Boolean  
  
instance.SetDraftOutward(Forward, DraftOutward)
```

C#

```
void SetDraftOutward(  
    System.bool Forward,  
    System.bool DraftOutward  
)
```

C++/CLI

```
void SetDraftOutward(  
& System.bool Forward,  
& System.bool DraftOutward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

DraftOutward

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::SetDraftOutward](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetDraftWhileExtruding Method (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : SetDraftWhileExtruding Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::SetDraftWhileExtruding](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDraftWhileExtruding( _  
    ByVal Forward As System.Boolean, _  
    ByVal DraftWhileExtrude As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim Forward As System.Boolean
```

```
Dim DraftWhileExtrude As System.Boolean

instance.SetDraftWhileExtruding(Forward, DraftWhileExtrude)
```

C#

```
void SetDraftWhileExtruding(
    System.bool Forward,
    System.bool DraftWhileExtrude
)
```

C++/CLI

```
void SetDraftWhileExtruding(
    & System.bool Forward,
    & System.bool DraftWhileExtrude
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

DraftWhileExtrude

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::SetDraftWhileExtruding](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetEndCondition Method (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : SetEndCondition Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::SetEndCondition](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetEndCondition( _
    ByVal Forward As System.Boolean, _
    ByVal EndCondition As System.Integer _
)
```

Visual Basic (Usage)

```
Dim instance As IExtrudeFeatureData
Dim Forward As System.Boolean
Dim EndCondition As System.Integer

instance.SetEndCondition(Forward, EndCondition)
```

C#

```
void SetEndCondition(
    System.bool Forward,
    System.int EndCondition
)
```

C++/CLI



```
void SetEndCondition(  
& System.bool Forward,  
& System.int EndCondition  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

EndCondition

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::SetEndCondition](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetFace Method (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : SetFace Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::SetEndConditionReference](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetFace( _  
    ByVal Forward As System.Boolean, _  
    ByVal Face As System.Object _  
)
```

Visual Basic (Usage)

```
Dim instance As IExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim Face As System.Object  
  
instance.SetFace(Forward, Face)
```

C#

```
void SetFace(  
    System.bool Forward,  
    System.object Face  
)
```

C++/CLI

```
void SetFace(  
& System.bool Forward,  
& System.Object^ Face  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Face

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::SetFace](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetVertex Method (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : SetVertex Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::SetEndConditionReference](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetVertex( _  
    ByVal Forward As System.Boolean, _  
    ByVal Face As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim Face As System.Object  
  
instance.SetVertex(Forward, Face)
```

C#

```
void SetVertex(  
    System.bool Forward,  
    System.object Face  
)
```

C++/CLI

```
void SetVertex(  
& System.bool Forward,  
& System.Object^ Face  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Face

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::SetVertex](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetWallThickness Method (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : SetWallThickness Method (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::SetWallThickness](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetWallThickness( _  
    ByVal Forward As System.Boolean, _  
    ByVal WallThickness As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim Forward As System.Boolean  
Dim WallThickness As System.Double  
  
instance.SetWallThickness(Forward, WallThickness)
```

C#

```
void SetWallThickness(  
    System.bool Forward,  
    System.double WallThickness  
)
```

C++/CLI

```
void SetWallThickness(  
& System.bool Forward,  
& System.double WallThickness  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

WallThickness

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::SetWallThickness](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ThinWallType Property (IExtrudeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData Interface](#) : ThinWallType Property (IExtrudeFeatureData)

Obsolete. Superseded by [IExtrudeFeatureData2::ThinWallType](#).

.NET Syntax

Visual Basic (Declaration)

```
Property ThinWallType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData  
Dim value As System.Integer  
  
instance.ThinWallType = value
```

```
value = instance.ThinWallType
```

C#

```
System.int ThinWallType {get; set;}
```

C++/CLI

```
property System.int ThinWallType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData::ThinWallType](#).

See Also

[IExtrudeFeatureData Interface](#)
[IExtrudeFeatureData Members](#)