

SOLIDWORKS API (.NET VBA C#) — Reference (101/337): IExtrudeFeatureData2 (part 1 of 2)

SOLIDWORKS API Documentation (converted from CHM)

IExtrudeFeatureData2 (part 1 of 2) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IExtrudeFeatureData2 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IExtrudeFeatureData2 Interface

Allows access to an extrusion feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IExtrudeFeatureData2
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2
```

C#

```
public interface IExtrudeFeatureData2
```

C++/CLI

```
public interface class IExtrudeFeatureData2
```

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2](#).

Example

[Create Extrude Feature Using Sketch Contours \(C#\)](#)
[Create Extrude Feature Using Sketch Contours \(VB.NET\)](#)
[Create Extrude Feature Using Sketch Contours \(VBA\)](#)

Remarks

For extrusion features, [IFeature::GetTypeName](#) returns cut, boss, boss thin, or cut thin, depending upon the type of extrusion feature.

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[ExtrudeFeatureData2](#)

See Also

[IExtrudeFeatureData2 Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::FeatureCut2 Method](#)
[IFeatureManager::FeatureCutThin Method](#)
[IFeatureManager::FeatureExtrusion2 Method](#)
[IFeatureManager::FeatureExtrusionThin2 Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IExtrudeFeatureData2 Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IExtrudeFeatureData2 Interface

For a list of all members of this type, see [IExtrudeFeatureData2 members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections used to define the extrusion feature.
 GetAutoFilletCorners	Gets whether the corners of this thin feature are automatically filleted.
 GetAutoFilletRadius	Gets the automatic corner fillet radius for this thin feature.
 GetContoursCount	Gets the number of selected contours for this extrude feature.
 GetDepth	Gets the depth of the extrusion feature in the forward or reverse direction.
 GetDirectionReference	Gets the direction of the extrusion.
 GetDraftAngle	Gets the draft angle of the extrusion in the forward or reverse direction.
 GetDraftOutward	Gets whether the extrusion feature is drafted outward in the forward or reverse direction.
 GetDraftWhileExtruding	Gets whether the feature is drafted while extruding in the forward or reverse direction.
 GetEndCondition	Gets the type of end condition of this extrusion feature for forward or reverse direction.
 GetEndConditionReference	Gets the reference entity defining the end condition in the forward or reverse direction.
 GetFace	Obsolete. Superseded by IExtrudeFeatureData2::GetEndConditionReference .
 GetFeatureScopeBodiesCount	Gets the number of solid bodies affected by the extrude feature in a multibody part.
 GetFromEntity	Gets the entity and its type from which the extrusion was created.
 GetReverseOffset	Gets the offset direction for this extrude feature.
 GetTranslateSurface	Gets the translate surface setting for this extrude feature.
 GetVertex	Obsolete. Superseded by IExtrudeFeatureData2::GetEndConditionReference .
 GetWallThickness	Gets the wall thickness of the thin extrusion feature in forward or reverse direction.
 IAccessSelections	Gains access to the selections used to define the extrusion feature.
 IGetContours	Gets the selected contours for this extrude feature.
 IGetFace	Obsolete. Superseded by IExtrudeFeatureData2::GetEndConditionReference .
 IGetFeatureScopeBodies	Gets the solid bodies that the extrude feature affects in a multibody part.
 IGetVertex	Obsolete. Superseded by IExtrudeFeatureData2::GetEndConditionReference .
 IsBaseExtrude	Obsolete. Superseded by IFeature::IsBase2 .
 IsBossFeature	Gets whether the extrusion is a boss feature.
 ISetChangeToConfigurations	Applies changes made to this extrude feature to the specified configurations.
 ISetContours	Sets the selected contours for this extrude feature.
 ISetFace	Obsolete. Superseded by IExtrudeFeatureData2::SetEndConditionReference .
 ISetFeatureScopeBodies	Sets the solid bodies that the extrude feature affects in the multibody part.
 ISetVertex	Obsolete. Superseded by IExtrudeFeatureData2::SetEndConditionReference .
 IsThinFeature	Gets whether the extrusion is a thin feature.
 ReleaseSelectionAccess	Releases access to the selections used to define the extrude feature.
 SetAutoFillet	Sets the automatic corner fillet properties of this thin feature.
 SetChangeToConfigurations	Applies changes made to this extrude feature to the specified configurations.
 SetDepth	Sets the depth of the feature in the forward or reverse direction.
 SetDirectionReference	Sets the direction of the extrusion.
 SetDraftAngle	Sets the draft angle of the extrusion in the forward or reverse direction.
 SetDraftOutward	Sets whether the extrusion feature should draft outward in the forward or reverse direction.
 SetDraftWhileExtruding	Sets whether the feature is drafted while extruding in the forward or reverse direction.
 SetEndCondition	Sets the end condition type of the extrusion feature for the forward or reverse direction.

	SetEndConditionReference	Sets the reference entity that defines the end condition in a forward or reverse direction.
	SetFace	Obsolete. Superseded by IExtrudeFeatureData2::SetEndConditionReference .
	SetFromEntity	Sets the entity from which to create an extrusion.
	SetReverseOffset	Sets the offset direction for this extrude feature.
	SetTranslateSurface	Sets the translate surface setting for this extrude feature.
	SetVertex	Obsolete. Superseded by IExtrudeFeatureData2::SetEndConditionReference .
	SetWallThickness	Sets the wall thickness of the thin extrusion feature in a forward or reverse direction.

[Top](#)

See Also

[IExtrudeFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::FeatureCut2 Method](#)
[IFeatureManager::FeatureCutThin Method](#)
[IFeatureManager::FeatureExtrusion2 Method](#)
[IFeatureManager::FeatureExtrusionThin2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IExtrudeFeatureData2 Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IExtrudeFeatureData2 Interface

The following tables list the members exposed by [IExtrudeFeatureData2](#).

Public Properties

Name	Description
 AssemblyFeatureScope	Gets or sets whether to use scope for this assembly extrude feature.
 AutoSelect	Gets or sets whether to automatically select all or only specific bodies for the extrude feature to affect in the multibody part.
 AutoSelectComponents	Gets or sets whether to auto-select all components that this assembly extrude feature affects in model.
 BothDirections	Gets or sets whether the extrusion is in both directions.
 CapEnds	Caps the ends for a thin base extrude feature.
 CapThickness	Gets or sets the end cap thickness for a thin base extrude feature.
 Contours	Gets and sets the selected contours in this extrude feature.
 FeatureScope	Gets or sets whether to use scope for the extrude feature in a multibody part.
 FeatureScopeBodies	Gets or sets the solid bodies that the extrude feature affects in a multibody part.
 FlipSideToCut	Gets or sets whether to flip the side to cut.
 FromOffsetDistance	Gets or sets the offset distance if IExtrudeFeatureData2::FromType is swExtrudeFrom_Offset.
 FromOffsetReverse	Gets or sets whether the offset is reverse for this extrusion if IExtrudeFeatureData2::FromType is swExtrudeFrom_Offset.
 FromType	Gets or sets the type from which to create an extrusion.
 LinkToThickness	Gets or sets whether to link the depth of an extruded boss to the thickness of the base feature.
 Merge	Gets or sets whether to merge the results of the extrude feature in a multibody part.
 NormalCut	Gets or sets whether the cut is created normal to the thickness of the sheet metal part.
 OptimizeGeometry	Gets or sets whether to optimize the geometry of a normal cut in a sheet metal part.
 PropagateFeatureToParts	Gets whether to propagate this assembly extrude feature to the parts that it affects in this model.
 ReverseDirection	Gets or sets whether to reverse the direction of the extrusion feature.
 ThinWallType	Gets or sets the thin wall type for a thin base extrude feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections used to define the extrusion feature.
 GetAutoFilletCorners	Gets whether the corners of this thin feature are automatically filleted.
 GetAutoFilletRadius	Gets the automatic corner fillet radius for this thin feature.
 GetContoursCount	Gets the number of selected contours for this extrude feature.
 GetDepth	Gets the depth of the extrusion feature in the forward or reverse direction.
 GetDirectionReference	Gets the direction of the extrusion.
 GetDraftAngle	Gets the draft angle of the extrusion in the forward or reverse direction.
 GetDraftOutward	Gets whether the extrusion feature is drafted outward in the forward or reverse direction.
 GetDraftWhileExtruding	Gets whether the feature is drafted while extruding in the forward or reverse direction.
 GetEndCondition	Gets the type of end condition of this extrusion feature for forward or reverse direction.
 GetEndConditionReference	Gets the reference entity defining the end condition in the forward or reverse direction.
 GetFace	Obsolete. Superseded by IExtrudeFeatureData2::GetEndConditionReference .
 GetFeatureScopeBodiesCount	Gets the number of solid bodies affected by the extrude feature in a multibody part.
 GetFromEntity	Gets the entity and its type from which the extrusion was created.
 GetReverseOffset	Gets the offset direction for this extrude feature.
 GetTranslateSurface	Gets the translate surface setting for this extrude feature.
 GetVertex	Obsolete. Superseded by IExtrudeFeatureData2::GetEndConditionReference .
 GetWallThickness	Gets the wall thickness of the thin extrusion feature in forward or reverse direction.
 IAccessSelections	Gains access to the selections used to define the extrusion feature.
 IGetContours	Gets the selected contours for this extrude feature.
 IGetFace	Obsolete. Superseded by IExtrudeFeatureData2::GetEndConditionReference .
 IGetFeatureScopeBodies	Gets the solid bodies that the extrude feature affects in a multibody part.
 IGetVertex	Obsolete. Superseded by IExtrudeFeatureData2::GetEndConditionReference .
 IsBaseExtrude	Obsolete. Superseded by IFeature::IsBase2 .
 IsBossFeature	Gets whether the extrusion is a boss feature.
 ISetChangeToConfigurations	Applies changes made to this extrude feature to the specified configurations.
 ISetContours	Sets the selected contours for this extrude feature.
 ISetFace	Obsolete. Superseded by IExtrudeFeatureData2::SetEndConditionReference .
 ISetFeatureScopeBodies	Sets the solid bodies that the extrude feature affects in the multibody part.
 ISetVertex	Obsolete. Superseded by IExtrudeFeatureData2::SetEndConditionReference .
 IsThinFeature	Gets whether the extrusion is a thin feature.
 ReleaseSelectionAccess	Releases access to the selections used to define the extrude feature.
 SetAutoFillet	Sets the automatic corner fillet properties of this thin feature.
 SetChangeToConfigurations	Applies changes made to this extrude feature to the specified configurations.
 SetDepth	Sets the depth of the feature in the forward or reverse direction.
 SetDirectionReference	Sets the direction of the extrusion.
 SetDraftAngle	Sets the draft angle of the extrusion in the forward or reverse direction.
 SetDraftOutward	Sets whether the extrusion feature should draft outward in the forward or reverse direction.
 SetDraftWhileExtruding	Sets whether the feature is drafted while extruding in the forward or reverse direction.
 SetEndCondition	Sets the end condition type of the extrusion feature for the forward or reverse direction.
 SetEndConditionReference	Sets the reference entity that defines the end condition in a forward or reverse direction.
 SetFace	Obsolete. Superseded by IExtrudeFeatureData2::SetEndConditionReference .

	SetFromEntity	Sets the entity from which to create an extrusion.
	SetReverseOffset	Sets the offset direction for this extrude feature.
	SetTranslateSurface	Sets the translate surface setting for this extrude feature.
	SetVertex	Obsolete. Superseded by IExtrudeFeatureData2::SetEndConditionReference .
	SetWallThickness	Sets the wall thickness of the thin extrusion feature in a forward or reverse direction.

[Top](#)

See Also

[IExtrudeFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::FeatureCut2 Method](#)
[IFeatureManager::FeatureCutThin Method](#)
[IFeatureManager::FeatureExtrusion2 Method](#)
[IFeatureManager::FeatureExtrusionThin2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IExtrudeFeatureData2 Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IExtrudeFeatureData2 Interface

For a list of all members of this type, see [IExtrudeFeatureData2 members](#).

Public Properties

Name	Description
 AssemblyFeatureScope	Gets or sets whether to use scope for this assembly extrude feature.
 AutoSelect	Gets or sets whether to automatically select all or only specific bodies for the extrude feature to affect in the multibody part.
 AutoSelectComponents	Gets or sets whether to auto-select all components that this assembly extrude feature affects in model.
 BothDirections	Gets or sets whether the extrusion is in both directions.
 CapEnds	Caps the ends for a thin base extrude feature.
 CapThickness	Gets or sets the end cap thickness for a thin base extrude feature.
 Contours	Gets and sets the selected contours in this extrude feature.
 FeatureScope	Gets or sets whether to use scope for the extrude feature in a multibody part.
 FeatureScopeBodies	Gets or sets the solid bodies that the extrude feature affects in a multibody part.
 FlipSideToCut	Gets or sets whether to flip the side to cut.
 FromOffsetDistance	Gets or sets the offset distance if IExtrudeFeatureData2::FromType is swExtrudeFrom_Offset .
 FromOffsetReverse	Gets or sets whether the offset is reverse for this extrusion if IExtrudeFeatureData2::FromType is swExtrudeFrom_Offset .
 FromType	Gets or sets the type from which to create an extrusion.
 LinkToThickness	Gets or sets whether to link the depth of an extruded boss to the thickness of the base feature.
 Merge	Gets or sets whether to merge the results of the extrude feature in a multibody part.
 NormalCut	Gets or sets whether the cut is created normal to the thickness of the sheet metal part.
 OptimizeGeometry	Gets or sets whether to optimize the geometry of a normal cut in a sheet metal part.
 PropagateFeatureToParts	Gets whether to propagate this assembly extrude feature to the parts that it affects in this model.
 ReverseDirection	Gets or sets whether to reverse the direction of the extrusion feature.
 ThinWallType	Gets or sets the thin wall type for a thin base extrude feature.

[Top](#)

See Also

[IExtrudeFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::FeatureCut2 Method](#)
[IFeatureManager::FeatureCutThin Method](#)

AccessSelections Method (IExtrudeFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : AccessSelections Method (IExtrudeFeatureData2)

Gains access to the selections used to define the extrusion feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were accessed successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::AccessSelections](#).

Example

[Determine If Sketch Contour or Sketch Region \(VBA\)](#)
[Create Extrude Feature Using Sketch Contours \(C#\)](#)
[Create Extrude Feature Using Sketch Contours \(VB.NET\)](#)
[Create Extrude Feature Using Sketch Contours \(VBA\)](#)

Remarks

To modify a feature in a...

Then...

Part

- TopDoc argument is the [IModelDoc2](#) for the part
- Component argument is NULL

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IExtrudeFeatureData2::ReleaseSelectionAccess](#) if you did not

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::IAccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AssemblyFeatureScope Property (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : AssemblyFeatureScope Property (IExtrudeFeatureData2)

Gets or sets whether to use scope for this assembly extrude feature.

.NET Syntax

Visual Basic (Declaration)

```
Property AssemblyFeatureScope As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2
Dim value As System.Boolean
```

```
instance.AssemblyFeatureScope = value
```

```
value = instance.AssemblyFeatureScope
```

C#

```
System.bool AssemblyFeatureScope {get; set;}
```

C++/CLI

```
property System.bool AssemblyFeatureScope {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use feature scope, false to not

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::AssemblyFeatureScope](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::AutoSelectComponents Property](#)
[IExtrudeFeatureData2::AutoSelect Property](#)
[IExtrudeFeatureData2::PropagateFeatureToParts Property](#)

Availability

AutoSelect Property (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : AutoSelect Property (IExtrudeFeatureData2)

Gets or sets whether to automatically select all or only specific bodies for the extrude feature to affect in the multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Property AutoSelect As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2
Dim value As System.Boolean

instance.AutoSelect = value

value = instance.AutoSelect
```

C#

```
System.bool AutoSelect {get; set;}
```

C++/CLI

```
property System.bool AutoSelect {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to automatically select all bodies, false to select specific bodies for [IExtrudeFeatureData2::FeatureScopeBodies](#) and [IExtrudeFeatureData2::ISetFeatureScopeBodies](#)

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::AutoSelect](#).

Remarks

This property is only available when the [IExtrudeFeatureData2::FeatureScope](#) property is true. The extrude feature is expanded along the plane on which the feature is created and selects all or only the specified bodies it intersects.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::GetFeatureScopeBodiesCount Method](#)
[IExtrudeFeatureData2::IGetFeatureScopeBodies Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

AutoSelectComponents Property (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : AutoSelectComponents Property (IExtrudeFeatureData2)

Gets or sets whether to auto-select all components that this assembly extrude feature affects in model.

.NET Syntax

Visual Basic (Declaration)

```
Property AutoSelectComponents As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2
Dim value As System.Boolean

instance.AutoSelectComponents = value
value = instance.AutoSelectComponents
```

C#

```
System.bool AutoSelectComponents {get; set;}
```

C++/CLI

```
property System.bool AutoSelectComponents {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to auto-select all affected components, false to not (use the selected components only or set [IExtrudeFeatureData2::AutoSelect](#) to true)

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::AutoSelectComponents](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::AssemblyFeatureScope Property](#)
[IExtrudeFeatureData2::PropagateFeatureToParts Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

BothDirections Property (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : BothDirections Property (IExtrudeFeatureData2)

Gets or sets whether the extrusion is in both directions.

.NET Syntax

Visual Basic (Declaration)

```
Property BothDirections As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2
Dim value As System.Boolean

instance.BothDirections = value
value = instance.BothDirections
```

C#

```
System.bool BothDirections {get; set;}
```

C++/CLI

```
property System.bool BothDirections {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if extrusion is in both directions, false if not

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::BothDirections](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CapEnds Property (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : CapEnds Property (IExtrudeFeatureData2)

Caps the ends for a thin base extrude feature.

.NET Syntax

Visual Basic (Declaration)

```
Property CapEnds As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim value As System.Boolean
```

```
instance.CapEnds = value
```

```
value = instance.CapEnds
```

C#

```
System.bool CapEnds {get; set;}
```

C++/CLI

```
property System.bool CapEnds {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True caps the ends, false does not

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::CapEnds](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::IsThinFeature Method](#)
[IExtrudeFeatureData2::CapThickness Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CapThickness Property (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : CapThickness Property (IExtrudeFeatureData2)

Gets or sets the end cap thickness for a thin base extrude feature.

.NET Syntax

Visual Basic (Declaration)

```
Property CapThickness As System.Double
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim value As System.Double
```

```
instance.CapThickness = value
```

```
value = instance.CapThickness
```

C#

```
System.double CapThickness {get; set;}
```

C++/CLI

```
property System.double CapThickness {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Thickness of the end cap

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::CapThickness](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::IsThinFeature Method](#)
[IExtrudeFeatureData2::CapEnds Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Contours Property (IExtrudeFeatureData2)

[See Also](#) [Example](#)



Gets and sets the selected contours in this extrude feature.

.NET Syntax

Visual Basic (Declaration)

Property Contours As System.Object

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim value As System.Object
```

```
instance.Contours = value
```

```
value = instance.Contours
```

C#

```
System.object Contours {get; set;}
```

C++/CLI

```
property System.Object^ Contours {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of contours (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::Contours](#).

Example

[Determine If Sketch Contour or Sketch Region \(VBA\)](#)
[Create Extrude Feature Using Sketch Contours \(C#\)](#)
[Create Extrude Feature Using Sketch Contours \(VB.NET\)](#)
[Create Extrude Feature Using Sketch Contours \(VBA\)](#)

Remarks

The array passed to or returned by this property can contain both [ISketchContour](#) and [ISketchRegion](#) objects. This method returns an empty array if sketch contours or sketch regions do not exist.

NOTE: An extrude feature has one, and only one, sketch. If the sketch does not contain sketch contours or sketch regions, then an empty array is returned. To get the sketch of an extrude feature that does not contain sketch contours or sketch regions, you can traverse the FeatureManager design tree to get the parent sketch of the extrude feature.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::GetContoursCount Method](#)
[IExtrudeFeatureData2::IGetContours Method](#)
[IExtrudeFeatureData2::ISetContours Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

FeatureScope Property (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : FeatureScope Property (IExtrudeFeatureData2)

Gets or sets whether to use scope for the extrude feature in a multibody part.

.NET Syntax

Visual Basic (Declaration)

Property FeatureScope As System.Boolean

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim value As System.Boolean
```

```
instance.FeatureScope = value
```

```
value = instance.FeatureScope
```

C#

```
System.bool FeatureScope {get; set;}
```

C++/CLI

```
property System.bool FeatureScope {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

When:

- true, only the specified bodies in the multibody part are affected by the extrude feature
- false, all of the bodies in the multibody part are affected by the extrude feature

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::FeatureScope](#).

Remarks

The extrude feature is expanded along the plane on which the feature is created and affects all or only the specified bodies it intersects.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::AutoSelect Property](#)
[IExtrudeFeatureData2::FeatureScopeBodies Property](#)
[IExtrudeFeatureData2::GetFeatureScopeBodiesCount Method](#)
[IExtrudeFeatureData2::IGetFeatureScopeBodies Method](#)
[IExtrudeFeatureData2::ISetFeatureScopeBodies Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureScopeBodies Property (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : FeatureScopeBodies Property (IExtrudeFeatureData2)

Gets or sets the solid bodies that the extrude feature affects in a multibody part.

.NET Syntax

Visual Basic (Declaration)

Property FeatureScopeBodies As System.Object

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2
Dim value As System.Object

instance.FeatureScopeBodies = value

value = instance.FeatureScopeBodies
```

C#

```
System.Object FeatureScopeBodies {get; set;}
```

C++/CLI

```
property System.Object^ FeatureScopeBodies {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of solid [bodies](#) that the feature affects

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2.FeatureScopeBodies](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::GetFeatureScopeBodiesCount Method](#)
[IExtrudeFeatureData2::IGetFeatureScopeBodies Method](#)
[IExtrudeFeatureData2::ISetFeatureScopeBodies Method](#)
[IExtrudeFeatureData2::AutoSelect Property](#)
[IExtrudeFeatureData2::FeatureScope Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FlipSideToCut Property (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : FlipSideToCut Property (IExtrudeFeatureData2)

Gets or sets whether to flip the side to cut.

.NET Syntax

Visual Basic (Declaration)

Property FlipSideToCut As System.Boolean

```
Dim instance As IExtrudeFeatureData2
Dim value As System.Boolean

instance.FlipSideToCut = value

value = instance.FlipSideToCut
```

C#

```
System.bool FlipSideToCut {get; set;}
```

C++/CLI

```
property System.bool FlipSideToCut {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True flips the side to cut, false does not

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::FlipSideToCut](#).

Remarks

This property is relevant only for cut features.

If the sketch is open, then the first edge in the array returned by [ISketch::GetContourEdges](#) and [ISketch::IGetControuEdges](#) is cut.

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

FromOffsetDistance Property (IExtrudeFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : FromOffsetDistance Property (IExtrudeFeatureData2)

Gets or sets the offset distance if [IExtrudeFeatureData2::FromType](#) is swExtrudeFrom_Offset.

.NET Syntax

Visual Basic (Declaration)

```
Property FromOffsetDistance As System.Double
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IExtrudeFeatureData2
Dim value As System.Double

instance.FromOffsetDistance = value

value = instance.FromOffsetDistance
```

C#

```
System.double FromOffsetDistance {get; set;}
```

C++/CLI

```
property System.double FromOffsetDistance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Offset distance

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::FromOffsetDistance](#).

Example

[Create Extruded Thin Feature \(VBA\)](#)

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::FromOffsetReverse Property](#)
[IExtrudeFeatureData2::GetReverseOffset Method](#)
[IExtrudeFeatureData2::SetReverseOffset Method](#)
[IExtrudeFeatureData2::SetTranslateSurface Method](#)
[IExtrudeFeatureData2::GetTranslateSurface Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.00

SOLIDWORKS API Help

[Send comments](#) on this topic.

FromOffsetReverse Property (IExtrudeFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : FromOffsetReverse Property (IExtrudeFeatureData2)

Gets or sets whether the offset is reverse for this extrusion if [IExtrudeFeatureData2::FromType](#) is swExtrudeFrom_Offset.

.NET Syntax

Visual Basic (Declaration)

```
Property FromOffsetReverse As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim value As System.Boolean
```

```
instance.FromOffsetReverse = value
```

```
value = instance.FromOffsetReverse
```

C#

```
System.bool FromOffsetReverse {get; set;}
```

C++/CLI

```
property System.bool FromOffsetReverse {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if offset reverse, false if not

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::FromOffsetReverse](#).

Example

[Create Extruded Thin Feature \(VBA\)](#)

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::FromOffsetDistance Property](#)
[IExtrudeFeatureData2::SetTranslateSurface Method](#)
[IExtrudeFeatureData2::SetReverseOffset Method](#)
[IExtrudeFeatureData2::GetTranslateSurface Method](#)
[IExtrudeFeatureData2::GetReverseOffset Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

FromType Property (IExtrudeFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : FromType Property (IExtrudeFeatureData2)

Gets or sets the type from which to create an extrusion.

.NET Syntax

Visual Basic (Declaration)

```
Property FromType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2
Dim value As System.Integer

instance.FromType = value

value = instance.FromType
```

C#

```
System.int FromType {get; set;}
```

C++/CLI

```
property System.int FromType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type from which to create an extrusion as defined in [swExtrudeFromType_e](#)

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::FromType](#).

Example

[Create Extruded Thin Feature \(VBA\)](#)

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::FromOffsetDistance Property](#)
[IExtrudeFeatureData2::FromOffsetReverse Property](#)
[IExtrudeFeatureData2::SetFromEntity Method](#)
[IExtrudeFeatureData2::GetFromEntity Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAutoFilletCorners Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : GetAutoFilletCorners Method (IExtrudeFeatureData2)

Gets whether the corners of this thin feature are automatically filleted.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAutoFilletCorners() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim value As System.Boolean  
  
value = instance.GetAutoFilletCorners()
```

C#

```
System.bool GetAutoFilletCorners()
```

C++/CLI

```
System.bool GetAutoFilletCorners();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the corners are automatically filleted, false if not

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::GetAutoFilletCorners](#).

Remarks

This method only applies to thin feature extrusions. If the feature is not a thin feature extrusion, then the return value is false, and the COM version of this method returns S_false in the status return value.

To get the fillet radius, use [IExtrudeFeatureData2::GetAutoFilletRadius](#). To set automatic fillets and radius, use [IExtrudeFeatureData2::SetAutoFillet](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::IsThinFeature Method](#)

Availability

SOLIDWORKS 2004 SP5, Revision Number 12.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAutoFilletRadius Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : GetAutoFilletRadius Method (IExtrudeFeatureData2)

Gets the automatic corner fillet radius for this thin feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAutoFilletRadius() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim value As System.Double  
  
value = instance.GetAutoFilletRadius()
```

C#

```
System.double GetAutoFilletRadius()
```

C++/CLI

```
System.double GetAutoFilletRadius();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Fillet radius, if feature has automatic corner fillets enabled

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::GetAutoFilletRadius](#).

Remarks

This method only applies to thin feature extrusions. If the feature is not a thin feature extrusion, then the return value is 0.0, and the COM version of this method returns S_false in the status return value.

If the feature does not have automatic corner fillets enabled, then the return value is 0.0 and the COM version of this method returns S_false in the status return value.

To get whether automatic corner fillet is enabled, use [IExtrudeFeatureData2::GetAutoFilletCorners](#). To set automatic fillets and radius, use [IExtrudeFeatureData2::SetAutoFillet](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::IsThinFeature Method](#)

Availability

SOLIDWORKS 2004 SP5, Revision Number 12.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetContoursCount Method (IExtrudeFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : GetContoursCount Method (IExtrudeFeatureData2)

Gets the number of selected contours for this extrude feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetContoursCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim value As System.Integer
```

```
value = instance.GetContoursCount()
```

C#

```
System.int GetContoursCount()
```

C++/CLI

```
System.int GetContoursCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of selected contours

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::GetContoursCount](#).

Example

[Create Extrude Feature Using Sketch Contours \(C#\)](#)
[Create Extrude Feature Using Sketch Contours \(VB.NET\)](#)
[Create Extrude Feature Using Sketch Contours \(VBA\)](#)

Remarks

This method returns the total number of sketch contours and sketch regions used in the base sketch for this feature.

Call this method before calling [IExtrudeFeatureData2::IGetContours](#).

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::ISetContours Method](#)
[IExtrudeFeatureData2::Contours Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDepth Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : GetDepth Method (IExtrudeFeatureData2)

Gets the depth of the extrusion feature in the forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDepth( _  
    ByVal Forward As System.Boolean _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim Forward As System.Boolean  
Dim value As System.Double  
  
value = instance.GetDepth(Forward)
```

C#

```
System.double GetDepth(  
    System.bool Forward  
)
```

C++/CLI

```
System.double GetDepth(  
&    System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True for forward feature direction, false for reverse

Return Value

Depth of the extrusion

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::GetDepth](#).

See Also

[IExtrudeFeatureData2 Interface](#)

[IExtrudeFeatureData2 Members](#)

[IExtrudeFeatureData2::SetDepth Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDirectionReference Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : GetDirectionReference Method (IExtrudeFeatureData2)

Gets the direction of the extrusion.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDirectionReference( _  
    ByRef Ref1 As System.Object, _  
    ByRef Type1 As System.Integer, _  
    ByRef Ref2 As System.Object, _
```

```
ByRef Type2 As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim Ref1 As System.Object  
Dim Type1 As System.Integer  
Dim Ref2 As System.Object  
Dim Type2 As System.Integer  
Dim value As System.Integer  
  
value = instance.GetDirectionReference(Ref1, Type1, Ref2, Type2)
```

C#

```
System.int GetDirectionReference(  
    out System.object Ref1,  
    out System.int Type1,  
    out System.object Ref2,  
    out System.int Type2  
)
```

C++/CLI

```
System.int GetDirectionReference(  
& [Out] System.Object^ Ref1,  
& [Out] System.int Type1,  
& [Out] System.Object^ Ref2,  
& [Out] System.int Type2  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Ref1
First reference entity
Type1
Type of reference entity as defined by [swSelectType_e](#) (see **Remarks**)
Ref2
Second reference entity
Type2
Type of reference entity as defined by [swSelectType_e](#)

Return Value

Number of reference entities used to define the direction of the extrusion

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::GetDirectionReference](#).

Remarks

Sometimes one reference entity defines a direction; for example, an edge or axis. Other times, two reference entities define a direction; for example, two vertices or two sketch points.

If...	Then...
One reference entity defined the direction	Ref2 is NULL and the return value is 1
Two reference entities defined the direction	Both Ref1 and Ref2 are non-NULL and the return value is 2

Valid reference entities for Type1 and Type2:

- line segment
- edge
- axis
- vertex
- face
- plane
- sketch point

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::SetDirectionReference Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDraftAngle Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : GetDraftAngle Method (IExtrudeFeatureData2)

Gets the draft angle of the extrusion in the forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDraftAngle( _  
    ByVal Forward As System.Boolean _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim Forward As System.Boolean  
Dim value As System.Double  
  
value = instance.GetDraftAngle(Forward)
```

C#

```
System.double GetDraftAngle(  
    System.bool Forward  
)
```

C++/CLI

```
System.double GetDraftAngle(  
&    System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True for forward direction, false for reverse

Return Value

Draft angle of the extrusion in radians

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::GetDraftAngle](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::GetDraftOutward Method](#)
[IExtrudeFeatureData2::GetDraftWhileExtruding Method](#)
[IExtrudeFeatureData2::SetDraftAngle Method](#)
[IExtrudeFeatureData2::SetDraftOutward Method](#)
[IExtrudeFeatureData2::SetDraftWhileExtruding Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDraftOutward Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : GetDraftOutward Method (IExtrudeFeatureData2)

Gets whether the extrusion feature is drafted outward in the forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDraftOutward( _  
    ByVal Forward As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim Forward As System.Boolean  
Dim value As System.Boolean  
  
value = instance.GetDraftOutward(Forward)
```

C#

```
System.bool GetDraftOutward(  
    System.bool Forward  
)
```

C++/CLI

```
System.bool GetDraftOutward(  
& System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True for forward direction, false for reverse

Return Value

True if feature is drafted outward, false if not

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::GetDraftOutward](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::GetDraftAngle Method](#)
[IExtrudeFeatureData2::GetDraftWhileExtruding Method](#)
[IExtrudeFeatureData2::SetDraftAngle Method](#)
[IExtrudeFeatureData2::SetDraftOutward Method](#)
[IExtrudeFeatureData2::SetDraftWhileExtruding Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDraftWhileExtruding Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : GetDraftWhileExtruding Method (IExtrudeFeatureData2)

Gets whether the feature is drafted while extruding in the forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDraftWhileExtruding( _  
    ByVal Forward As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim Forward As System.Boolean  
Dim value As System.Boolean  
  
value = instance.GetDraftWhileExtruding(Forward)
```

C#

```
System.bool GetDraftWhileExtruding(  
    System.bool Forward  
)
```

C++/CLI

```
System.bool GetDraftWhileExtruding(  
& System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True for forward direction, false for reverse

Return Value

True if feature is drafted while extruding, false if not

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::GetDraftWhileExtruding](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::GetDraftAngle Method](#)
[IExtrudeFeatureData2::GetDraftOutward Method](#)
[IExtrudeFeatureData2::SetDraftAngle Method](#)
[IExtrudeFeatureData2::SetDraftOutward Method](#)
[IExtrudeFeatureData2::SetDraftWhileExtruding Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEndCondition Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : GetEndCondition Method (IExtrudeFeatureData2)

Gets the type of end condition of this extrusion feature for forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEndCondition( _  
    ByVal Forward As System.Boolean _  
    ) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim Forward As System.Boolean  
Dim value As System.Integer  
  
value = instance.GetEndCondition(Forward)
```

C#

```
System.int GetEndCondition(  
    System.bool Forward  
)
```

C++/CLI

```
System.int GetEndCondition(  
& System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True for forward direction, false for reverse

Return Value

End condition type as defined in [swEndConditions_e](#)

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::GetEndCondition](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::GetEndConditionReference Method](#)
[IExtrudeFeatureData2::SetEndCondition Method](#)
[IExtrudeFeatureData2::SetEndConditionReference Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEndConditionReference Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : GetEndConditionReference Method (IExtrudeFeatureData2)

Gets the reference entity defining the end condition in the forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEndConditionReference( _  
    ByVal Forward As System.Boolean, _  
    ByRef ReferenceType As System.Integer _  
    ) As System.Object
```

Visual Basic (Usage)



```

Dim instance As IExtrudeFeatureData2
Dim Forward As System.Boolean
Dim ReferenceType As System.Integer
Dim value As System.Object

value = instance.GetEndConditionReference(Forward, ReferenceType)

```

C#

```

System.Object GetEndConditionReference(
    System.bool Forward,
    out System.int ReferenceType
)

```

C++/CLI

```

System.Object^ GetEndConditionReference(
    & System.bool Forward,
    & [Out] System.int ReferenceType
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True for forward direction, false for reverse

ReferenceType

Reference type as defined by [swSelectionReferenceTypes_e](#)

Return Value

Pointer to the reference entity

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::GetEndConditionReference](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::SetEndConditionReference Method](#)
[IExtrudeFeatureData2::SetEndCondition Method](#)
[IExtrudeFeatureData2::GetEndCondition Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFace Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : GetFace Method (IExtrudeFeatureData2)

Obsolete. Superseded by [IExtrudeFeatureData2::GetEndConditionReference](#).

.NET Syntax

Visual Basic (Declaration)

```

Function GetFace( _
    ByVal Forward As System.Boolean _
) As System.Object

```

```
Dim instance As IExtrudeFeatureData2
Dim Forward As System.Boolean
Dim value As System.Object

value = instance.GetFace(Forward)
```

C#

```
System.Object GetFace(
    System.bool Forward
)
```

C++/CLI

```
System.Object^ GetFace(
    & System.bool Forward
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::GetFace](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)**GetFeatureScopeBodiesCount Method (IExtrudeFeatureData2)**

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : GetFeatureScopeBodiesCount Method (IExtrudeFeatureData2)

Gets the number of solid bodies affected by the extrude feature in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeatureScopeBodiesCount() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IExtrudeFeatureData2
Dim value As System.Integer

value = instance.GetFeatureScopeBodiesCount()
```

C#

```
System.int GetFeatureScopeBodiesCount()
```

C++/CLI

```
System.int GetFeatureScopeBodiesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of solid bodies affected

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::GetFeatureScopeBodiesCount](#).

Remarks

Call this method before calling [IExtrudeFeatureData2::IGetFeatureScopeBodies](#).

If [IExtrudeFeatureData2::FeatureScope](#) is false, then count will be 0.

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::AutoSelect Property](#)
[IExtrudeFeatureData2::FeatureScopeBodies Property](#)
[IExtrudeFeatureData2::ISetFeatureScopeBodies Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFromEntity Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : GetFromEntity Method (IExtrudeFeatureData2)

Gets the entity and its type from which the extrusion was created.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetFromEntity(  
    ByRef FromEntity As System.Object, _  
    ByRef Type As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim FromEntity As System.Object  
Dim Type As System.Integer  
  
instance.GetFromEntity(FromEntity, Type)
```

C#

```
void GetFromEntity(  
    out System.object FromEntity,  
    out System.int Type  
)
```

C++/CLI

```
void GetFromEntity(  
& [Out] System.Object^ FromEntity,  
& [Out] System.int Type  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FromEntity

Entity from which the extrusion was created:

- Surface
- Face

- Plane
- Vertex
- Sketch point

Type

Type of entity from which to create the extrusion as defined in [swSelectType_e](#)

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::GetFromEntity](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::FromType Property](#)
[IExtrudeFeatureData2::SetFromEntity Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetReverseOffset Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : GetReverseOffset Method (IExtrudeFeatureData2)

Gets the offset direction for this extrude feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetReverseOffset( _
    ByVal Fwd As System.Boolean _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2
Dim Fwd As System.Boolean
Dim value As System.Boolean

value = instance.GetReverseOffset(Fwd)
```

C#

```
System.bool GetReverseOffset(
    System.bool Fwd
)
```

C++/CLI

```
System.bool GetReverseOffset(
    & System.bool Fwd
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Fwd

True gets the reverse offset setting in the forward direction, false gets it in the reverse direction

Return Value

True if the reverse offset setting is enabled, false if it is disabled

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::GetReverseOffset](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::SetReverseOffset Method](#)
[IExtrudeFeatureData2::FromOffsetReverse Property](#)
[IExtrudeFeatureData2::FromOffsetDistance Property](#)
[IExtrudeFeatureData2::GetTranslateSurface Method](#)
[IExtrudeFeatureData2::SetTranslateSurface Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTranslateSurface Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : GetTranslateSurface Method (IExtrudeFeatureData2)

Gets the translate surface setting for this extrude feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTranslateSurface( _  
    ByVal Fwd As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim Fwd As System.Boolean  
Dim value As System.Boolean  
  
value = instance.GetTranslateSurface(Fwd)
```

C#

```
System.bool GetTranslateSurface(  
    System.bool Fwd  
)
```

C++/CLI

```
System.bool GetTranslateSurface(  
&    System.bool Fwd  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Fwd

True makes the end of the extrusion a translation of the reference surface in the forward direction, false makes the end of the extrusion a translation of the reference surface in the reverse direction

Return Value

True if the translate surface setting is enabled, false if it is disabled

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::GetTranslateSurface](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::SetTranslateSurface Method](#)

[IExtrudeFeatureData2::FromOffsetDistance Property](#)
[IExtrudeFeatureData2::GetReverseOffset Method](#)
[IExtrudeFeatureData2::SetReverseOffset Method](#)
[IExtrudeFeatureData2::FromOffsetReverse Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetVertex Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : GetVertex Method (IExtrudeFeatureData2)

Obsolete. Superseded by [IExtrudeFeatureData2::GetEndConditionReference](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetVertex(  
    ByVal Forward As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim Forward As System.Boolean  
Dim value As System.Object  
  
value = instance.GetVertex(Forward)
```

C#

```
System.object GetVertex(  
    System.bool Forward  
)
```

C++/CLI

```
System.Object^ GetVertex(  
& System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::GetVertex](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetWallThickness Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : GetWallThickness Method (IExtrudeFeatureData2)

Gets the wall thickness of the thin extrusion feature in forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Function GetWallThickness( _  
    ByVal Forward As System.Boolean _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim Forward As System.Boolean  
Dim value As System.Double  
  
value = instance.GetWallThickness(Forward)
```

C#

```
System.double GetWallThickness(  
    System.bool Forward  
)
```

C++/CLI

```
System.double GetWallThickness(  
& System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True for forward feature direction, false for reverse

Return Value

Wall thickness

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::GetWallThickness](#).

Remarks

This method is relevant only for thin features.

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::IsThinFeature Method](#)
[IExtrudeFeatureData2::SetWallThickness Method](#)
[IExtrudeFeatureData2::ThinWallType Property](#)
[IExtrudeFeatureData2::CapEnds Property](#)
[IExtrudeFeatureData2::CapThickness Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : IAccessSelections Method (IExtrudeFeatureData2)

Gains access to the selections used to define the extrusion feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _
    ByVal TopDoc As ModelDoc2, _
    ByVal Component As Component2 _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2
Dim TopDoc As ModelDoc2
Dim Component As Component2
Dim value As System.Boolean

value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(
    ModelDoc2 TopDoc,
    Component2 Component
)
```

C++/CLI

```
System.bool IAccessSelections(
    & ModelDoc2^ TopDoc,
    & Component2^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were accessed successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::IModifyDefintion2](#) if you modified the feature
- [IExtrudeFeatureData2::ReleaseSelectionAccess](#) if you did not

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : IGetContours Method (IExtrudeFeatureData2)

Gets the selected contours for this extrude feature.

VB.NET Syntax

Visual Basic (Declaration)

```
Function IGetContours( _  
    ByVal Count As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim Count As System.Integer  
Dim value As System.Object  
  
value = instance.IGetContours(Count)
```

C#

```
System.object IGetContours(  
    System.int Count  
)
```

C++/CLI

```
System.Object^ IGetContours(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of selected contours

Return Value

- in-process, unmanaged C++: Pointer to an array of contours ([sketch contours](#) and [sketch regions](#)) of size count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IExtrudeFeatureData2::GetContoursCount](#) before calling this method.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::ISetContours Method](#)
[IExtrudeFeatureData2::Contours Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFace Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : IGetFace Method (IExtrudeFeatureData2)

Obsolete. Superseded by [IExtrudeFeatureData2::GetEndConditionReference](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFace( _  
    ByVal Forward As System.Boolean _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim Forward As System.Boolean  
Dim value As Face2  
  
value = instance.IGetFace(Forward)
```

C#

```
Face2 IGetFace(  
    System.bool Forward  
)
```

C++/CLI

```
Face2^ IGetFace(  
&    System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::IGetFace](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFeatureScopeBodies Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : IGetFeatureScopeBodies Method (IExtrudeFeatureData2)

Gets the solid bodies that the extrude feature affects in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFeatureScopeBodies( _  
    ByVal Count As System.Integer _  
) As Body2
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim Count As System.Integer  
Dim value As Body2  
  
value = instance.IGetFeatureScopeBodies(Count)
```

C#

```
Body2 IGetFeatureScopeBodies(  
    System.int Count  
)
```

C++/CLI

```
Body2^ IGetFeatureScopeBodies(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of solid bodies to affect

Return Value

- in-process, unmanaged C++: Pointer to an array of solid [bodies](#) of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IExtrudeFeatureData2::GetFeatureScopeBodiesCount](#) before calling this method.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::AutoSelect Property](#)
[IExtrudeFeatureData2::FeatureScope Property](#)
[IExtrudeFeatureData2::FeatureScopeBodies Property](#)
[IExtrudeFeatureData2::ISetFeatureScopeBodies Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetVertex Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : IGetVertex Method (IExtrudeFeatureData2)

Obsolete. Superseded by [IExtrudeFeatureData2::GetEndConditionReference](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetVertex(  
    ByVal Forward As System.Boolean _  
) As Vertex
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim Forward As System.Boolean  
Dim value As Vertex
```

```
value = instance.IGetVertex(Forward)
```

C#

```
Vertex IGetVertex(  
    System.bool Forward  
)
```

C++/CLI

```
Vertex^ IGetVertex(  
& System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::IGetVertex](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsBaseExtrude Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : IsBaseExtrude Method (IExtrudeFeatureData2)

Obsolete. Superseded by [IFeature::IsBase2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IsBaseExtrude() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim value As System.Boolean  
  
value = instance.IsBaseExtrude()
```

C#

```
System.bool IsBaseExtrude()
```

C++/CLI

```
System.bool IsBaseExtrude();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::IsBaseExtrude](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsBossFeature Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : IsBossFeature Method (IExtrudeFeatureData2)

Gets whether the extrusion is a boss feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IsBossFeature() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2
Dim value As System.Boolean

value = instance.IsBossFeature()
```

C#

```
System.bool IsBossFeature()
```

C++/CLI

```
System.bool IsBossFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this extrusion is a boss feature, false if not

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::IsBossFeature](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IFeature::IsBase2 Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetChangeToConfigurations Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : ISetChangeToConfigurations Method (IExtrudeFeatureData2)

Applies changes made to this extrude feature to the specified configurations.

.NET Syntax

Visual Basic (Declaration)

```
Function ISetChangeToConfigurations( _
    ByVal Config\_opt As System.Integer, _
    ByVal Config\_count As System.Integer, _
    ByRef Config\_names As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2
Dim Config_opt As System.Integer
Dim Config_count As System.Integer
Dim Config_names As System.String
Dim value As System.Boolean

value = instance.ISetChangeToConfigurations(Config_opt, Config_count, Config_names)
```

C#

```
System.bool ISetChangeToConfigurations(  
    System.int Config\_opt,  
    System.int Config\_count,  
    ref System.string Config\_names  
)
```

C++/CLI

```
System.bool ISetChangeToConfigurations(  
& System.int Config\_opt,  
& System.int Config\_count,  
& System.String^% Config\_names  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Config_opt

Configuration option as defined in [swInConfigurationOpts_e](#)

Config_count

Number of configurations to modify

Config_names

- in-process, unmanaged C++: Pointer to an array of the names of the configurations to modify

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

True if the operation succeeds, false if it fails

See Also

[IExtrudeFeatureData2 Interface](#)

[IExtrudeFeatureData2 Members](#)

[IExtrudeFeatureData2::SetChangeToConfigurations Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetContours Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : ISetContours Method (IExtrudeFeatureData2)

Sets the selected contours for this extrude feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetContours(  
    ByVal Count As System.Integer, _  
    ByRef Contours As System.Object _  
)
```

Visual Basic (Usage)

```
Dim instance As IExtrudeFeatureData2  
Dim Count As System.Integer  
Dim Contours As System.Object  
  
instance.ISetContours(Count, Contours)
```

C#



```
void ISetContours(  
    System.int Count,  
    ref System.object Contours  
)
```

C++/CLI

```
void ISetContours(  
& System.int Count,  
& System.Object^% Contours  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of selected contours

Contours

- in-process, unmanaged C++: Pointer to an array of selected contours of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IExtrudeFeatureData2 Interface](#)

[IExtrudeFeatureData2 Members](#)

[IExtrudeFeatureData2::GetContoursCount Method](#)

[IExtrudeFeatureData2::!GetContours Method](#)

[IExtrudeFeatureData2::Contours Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetFace Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : ISetFace Method (IExtrudeFeatureData2)

Obsolete. Superseded by [IExtrudeFeatureData2::SetEndConditionReference](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetFace( _  
    ByVal Forward As System.Boolean, _  
    ByVal Face As Face2 _  
)
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim Forward As System.Boolean  
Dim Face As Face2
```

```
instance.ISetFace(Forward, Face)
```

C#

```
void ISetFace(
    System.bool Forward,
    Face2 Face
)
```

C++/CLI

```
void ISetFace(
    & System.bool Forward,
    & Face2^ Face
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Face

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::ISetFace](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetFeatureScopeBodies Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : ISetFeatureScopeBodies Method (IExtrudeFeatureData2)

Sets the solid bodies that the extrude feature affects in the multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetFeatureScopeBodies( _
    ByVal Count As System.Integer, _
    ByRef BodyArr As Body2 _
)
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2
Dim Count As System.Integer
Dim BodyArr As Body2
```

```
instance.ISetFeatureScopeBodies(Count, BodyArr)
```

C#

```
void ISetFeatureScopeBodies(
    System.int Count,
    ref Body2 BodyArr
)
```

C++/CLI

```
void ISetFeatureScopeBodies(
    & System.int Count,
    & Body2^% BodyArr
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of solid bodies to affect

BodyArr

- in-process, unmanaged C++: Pointer to an array of solid [bodies](#) of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::GetFeatureScopeBodiesCount Method](#)
[IExtrudeFeatureData2::IGetFeatureScopeBodies Method](#)
[IExtrudeFeatureData2::AutoSelect Property](#)
[IExtrudeFeatureData2::FeatureScope Property](#)
[IExtrudeFeatureData2::FeatureScopeBodies Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetVertex Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : ISetVertex Method (IExtrudeFeatureData2)

Obsolete. Superseded by [IExtrudeFeatureData2::SetEndConditionReference](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetVertex( _  
    ByVal Forward As System.Boolean, _  
    ByVal Face As Vertex _  
)
```

Visual Basic (Usage)

```
Dim instance As IExtrudeFeatureData2  
Dim Forward As System.Boolean  
Dim Face As Vertex
```

```
instance.ISetVertex(Forward, Face)
```

C#

```
void ISetVertex(  
    System.bool Forward,  
    Vertex Face  
)
```

C++/CLI

```
void ISetVertex(  
& System.bool Forward,  
& Vertex^ Face  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Face

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::!SetVertex](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsThinFeature Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : IsThinFeature Method (IExtrudeFeatureData2)

Gets whether the extrusion is a thin feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IsThinFeature() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim value As System.Boolean
```

```
value = instance.IsThinFeature()
```

C#

```
System.bool IsThinFeature()
```

C++/CLI

```
System.bool IsThinFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this extrusion is a thin feature, false if not

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::IsThinFeature](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::SetWallThickness Method](#)
[IExtrudeFeatureData2::GetWallThickness Method](#)
[IExtrudeFeatureData2::ThinWallType Property](#)
[IExtrudeFeatureData2::CapEnds Property](#)
[IExtrudeFeatureData2::CapThickness Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

LinkToThickness Property (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : LinkToThickness Property (IExtrudeFeatureData2)

Gets or sets whether to link the depth of an extruded boss to the thickness of the base feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property LinkToThickness As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2
Dim value As System.Boolean

instance.LinkToThickness = value
value = instance.LinkToThickness
```

C#

```
System.bool LinkToThickness {get; set;}
```

C++/CLI

```
property System.bool LinkToThickness {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to link the depth of an extruded boss to the thickness of the base feature, false to not

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2.LinkToThickness](#).

Remarks

This property applies to [sheet metal parts](#) only.

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Merge Property (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : Merge Property (IExtrudeFeatureData2)

Gets or sets whether to merge the results of the extrude feature in a multibody part.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property Merge As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2
Dim value As System.Boolean
```

```
instance.Merge = value
```

```
value = instance.Merge
```

C#

```
System.bool Merge {get; set;}
```

C++/CLI

```
property System.bool Merge {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True enables the merge results option, false disables it

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2.Merge](#).

Remarks

The merge results option tells the SOLIDWORKS Design software whether or not to merge the new body or bodies with existing bodies in the multibody part. This property is set to True by default.

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

NormalCut Property (IExtrudeFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : NormalCut Property (IExtrudeFeatureData2)

Gets or sets whether the cut is created normal to the thickness of the sheet metal part.

.NET Syntax

Visual Basic (Declaration)

```
Property NormalCut As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim value As System.Boolean
```

```
instance.NormalCut = value
```

```
value = instance.NormalCut
```

C#

```
System.bool NormalCut {get; set;}
```

C++/CLI

```
property System.bool NormalCut {  
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the cut is created normal to the thickness of the sheet metal part, false if not

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::NormalCut](#).

Example

[Create Cut Extrude in Sheet Metal Part \(C#\)](#)
[Create Cut Extrude in Sheet Metal Part \(VB.NET\)](#)
[Create Cut Extrude in Sheet Metal Part \(VBA\)](#)

Remarks

To optimize the geometry of the normal cut in the sheet metal part, set [ExtrudeFeatureData2::OptimizeGeometry](#) to true.

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision 25.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

OptimizeGeometry Property (IExtrudeFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : OptimizeGeometry Property (IExtrudeFeatureData2)

Gets or sets whether to optimize the geometry of a normal cut in a sheet metal part.

.NET Syntax

Visual Basic (Declaration)

```
Property OptimizeGeometry As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim value As System.Boolean
```

```
instance.OptimizeGeometry = value
```

```
value = instance.OptimizeGeometry
```

C#

```
System.bool OptimizeGeometry {get; set;}
```

C++/CLI

```
property System.bool OptimizeGeometry {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to optimize the geometry of a normal cut in a sheet metal part, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::OptimizeGeometry](#).

Example

[Create Cut Extrude in Sheet Metal Part \(C#\)](#)
[Create Cut Extrude in Sheet Metal Part \(VB.NET\)](#)
[Create Cut Extrude in Sheet Metal Part \(VBA\)](#)

Remarks

Setting this property is only valid when [ExtrudeFeatureData2::NormalCut](#) is true.

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0