

SOLIDWORKS API (.NET VBA C#) — Reference (102/337): IExtrudeFeatureData2 (part 2 of 2)

SOLIDWORKS API Documentation (converted from CHM)

IExtrudeFeatureData2 (part 2 of 2) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

PropagateFeatureToParts Property (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : PropagateFeatureToParts Property (IExtrudeFeatureData2)

Gets whether to propagate this assembly extrude feature to the parts that it affects in this model.

.NET Syntax

Visual Basic (Declaration)

Property PropagateFeatureToParts As System.Boolean

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2
Dim value As System.Boolean

instance.PropagateFeatureToParts = value
value = instance.PropagateFeatureToParts
```

C#

```
System.bool PropagateFeatureToParts {get; set;}
```

C++/CLI

```
property System.bool PropagateFeatureToParts {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to propagate this assembly extrude feature to the parts that it affects in the model, false to not

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::PropagateFeatureToParts](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::AutoSelect Property](#)
[IExtrudeFeatureData2::AutoSelectComponents Property](#)
[IExtrudeFeatureData2::AssemblyFeatureScope Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReleaseSelectionAccess Method (IExtrudeFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : ReleaseSelectionAccess Method (IExtrudeFeatureData2)

Releases access to the selections used to define the extrude feature.

.NET Syntax

Visual Basic (Declaration)

Sub ReleaseSelectionAccess()

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::ReleaseSelectionAccess](#).

Example

[Create Extruded Thin Feature \(VBA\)](#)
[Determine if Sketch Contour or Sketch Region \(VBA\)](#)
[Create Extrude Feature Using Sketch Contours \(C#\)](#)
[Create Extrude Feature Using Sketch Contours \(VB.NET\)](#)
[Create Extrude Feature Using Sketch Contours \(VBA\)](#)

Remarks

[IExtrudeFeatureData2::AccessSelections](#) or [IExtrudeFeatureData2::IAccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature. Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did.

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : ReverseDirection Property (IExtrudeFeatureData2)

Gets or sets whether to reverse the direction of the extrusion feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ReverseDirection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim value As System.Boolean  
instance.ReverseDirection = value  
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True reverses the direction of the extrusion feature, false does not

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::ReverseDirection](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetAutoFillet Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : SetAutoFillet Method (IExtrudeFeatureData2)

Sets the automatic corner fillet properties of this thin feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetAutoFillet(  
    ByVal AutoFillet As System.Boolean, _  
    ByVal Radius As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim AutoFillet As System.Boolean  
Dim Radius As System.Double  
Dim value As System.Boolean  
  
value = instance.SetAutoFillet(AutoFillet, Radius)
```

C#

```
System.bool SetAutoFillet(  
    System.bool AutoFillet,  
    System.double Radius  
)
```

C++/CLI

```
System.bool SetAutoFillet(  
& System.bool AutoFillet,  
& System.double Radius  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AutoFillet

True to fillet the corners automatically, false to not

Radius

Fillet radius, if automatic corner fillets is enabled

Return Value

True if the corners are automatically filleted, false if not

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::SetAutoFillet](#).

Remarks

This method only applies to thin feature extrusions. If the feature is not a thin feature extrusion, then no action is taken and the COM version of this method returns S_false in the status return value.

If disabling the automatic corner fillets property (AutoFillet = false), then the Radius value is not used.

To get the automatic corner fillet flag, use [IExtrudeFeatureData2::GetAutoFilletCorners](#). To get the fillet radius, use [IExtrudeFeatureData2::GetAutoFilletRadius](#).

See Also

[IExtrudeFeatureData2 Interface](#)

[IExtrudeFeatureData2 Members](#)

[IExtrudeFeatureData2::IsThinFeature Method](#)

Availability

SOLIDWORKS 2004 SP5, Revision Number 12.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetChangeToConfigurations Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : SetChangeToConfigurations Method (IExtrudeFeatureData2)

Applies changes made to this extrude feature to the specified configurations.

.NET Syntax

Visual Basic (Declaration)

```
Function SetChangeToConfigurations( _  
    ByVal Config\_opt As System.Integer, _  
    ByVal Config\_names As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IExtrudeFeatureData2  
Dim Config_opt As System.Integer  
Dim Config_names As System.Object  
Dim value As System.Boolean
```

```
value = instance.SetChangeToConfigurations(Config_opt, Config_names)
```

C#

```
System.bool SetChangeToConfigurations(  
    System.int Config\_opt,  
    System.object Config\_names  
)
```

C++/CLI



```
System.bool SetChangeToConfigurations(
& System.int Config\_opt,
& System.Object^ Config\_names
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Config_opt
Configuration option as defined in [swInConfigurationOpts_e](#)
Config_names
Array of the names of the configurations to modify

Return Value

True if the operation succeeds, false if it fails

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::SetChangeToConfigurations](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::ISetChangeToConfigurations Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetDepth Method (IExtrudeFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : SetDepth Method (IExtrudeFeatureData2)

Sets the depth of the feature in the forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDepth( _
    ByVal Forward As System.Boolean, _
    ByVal Depth As System.Double _
)
```

Visual Basic (Usage)

```
Dim instance As IExtrudeFeatureData2
Dim Forward As System.Boolean
Dim Depth As System.Double

instance.SetDepth(Forward, Depth)
```

C#

```
void SetDepth(
    System.bool Forward,
    System.double Depth
)
```

C++/CLI

```
void SetDepth(
& System.bool Forward,
& System.double Depth
)
```



NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True for forward direction, false for reverse

Depth

Depth of the extrusion

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::SetDepth](#).

Example

[Access Selections \(VBA\)](#)

Remarks

Use this method to specify the surface offset distance when [end condition](#) is `swEndCondOffsetFromSurface`.

See Also

[IExtrudeFeatureData2 Interface](#)

[IExtrudeFeatureData2 Members](#)

[IExtrudeFeatureData2::GetDepth Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDirectionReference Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : SetDirectionReference Method (IExtrudeFeatureData2)

Sets the direction of the extrusion.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDirectionReference( _  
    ByVal Ref1 As System.Object, _  
    ByVal Ref2 As System.Object _  
)
```

Visual Basic (Usage)

```
Dim instance As IExtrudeFeatureData2  
Dim Ref1 As System.Object  
Dim Ref2 As System.Object  
  
instance.SetDirectionReference(Ref1, Ref2)
```

C#

```
void SetDirectionReference(  
    System.object Ref1,  
    System.object Ref2  
)
```

C++/CLI

```
void SetDirectionReference(  
& System.Object^ Ref1,
```



```
& System.Object^ Ref2  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Ref1

First reference entity

Ref2

Second reference entity

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::SetDirectionReference](#).

Remarks

Sometimes one reference entity can sufficiently define a direction; for example, an edge or axis. Other times, two reference entities are required to define a direction; for example, two vertices or two sketch points.

If...	Then...
One reference entity can sufficiently define the direction	Ref2 is NULL
Two reference entities are required to define the direction	Both Ref1 and Ref2 are non-NULL

Valid reference entities for Type1 and Type2:

- line segment
- edge
- axis
- vertex
- face
- plane
- sketch point

See Also

[IExtrudeFeatureData2 Interface](#)

[IExtrudeFeatureData2 Members](#)

[IExtrudeFeatureData2::GetDirectionReference Method](#)

[IExtrudeFeatureData2::GetDirectionReference Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDraftAngle Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : SetDraftAngle Method (IExtrudeFeatureData2)

Sets the draft angle of the extrusion in the forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDraftAngle(  
    ByVal Forward As System.Boolean, _  
    ByVal DraftAngle As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim Forward As System.Boolean  
Dim DraftAngle As System.Double
```

```
instance.SetDraftAngle(Forward, DraftAngle)
```

C#

```
void SetDraftAngle(  
    System.bool Forward,  
    System.double DraftAngle  
)
```

C++/CLI

```
void SetDraftAngle(  
& System.bool Forward,  
& System.double DraftAngle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True for forward direction, false for reverse

DraftAngle

Draft angle of the extrusion in radians

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::SetDraftAngle](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudedFeatureData2::GetDraftAngle Method](#)
[IExtrudedFeatureData2::GetDraftOutward Method](#)
[IExtrudedFeatureData2::GetDraftWhileExtruding Method](#)
[IExtrudedFeatureData2::SetDraftOutward Method](#)
[IExtrudedFeatureData2::SetDraftWhileExtruding Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDraftOutward Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : SetDraftOutward Method (IExtrudeFeatureData2)

Sets whether the extrusion feature should draft outward in the forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDraftOutward ( _  
    ByVal Forward As System.Boolean, _  
    ByVal DraftOutward As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim Forward As System.Boolean  
Dim DraftOutward As System.Boolean
```

```
instance.SetDraftOutward(Forward, DraftOutward)
```

C#

```
void SetDraftOutward(
    System.bool Forward,
    System.bool DraftOutward
)
```

C++/CLI

```
void SetDraftOutward(
    & System.bool Forward,
    & System.bool DraftOutward
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True for forward direction, false for reverse

DraftOutward

True if feature is drafted outward, false if not

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::SetDraftOutward](#).

See Also

[IExtrudeFeatureData2 Interface](#)

[IExtrudeFeatureData2 Members](#)

[IExtrudeFeatureData2::SetDraftAngle Method](#)

[IExtrudeFeatureData2::SetDraftWhileExtruding Method](#)

[IExtrudeFeatureData2::GetDraftAngle Method](#)

[IExtrudeFeatureData2::GetDraftOutward Method](#)

[IExtrudeFeatureData2::GetDraftWhileExtruding Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDraftWhileExtruding Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : SetDraftWhileExtruding Method (IExtrudeFeatureData2)

Sets whether the feature is drafted while extruding in the forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDraftWhileExtruding( _
    ByVal Forward As System.Boolean, _
    ByVal DraftWhileExtrude As System.Boolean _
)
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2
Dim Forward As System.Boolean
Dim DraftWhileExtrude As System.Boolean
```

```
instance.SetDraftWhileExtruding(Forward, DraftWhileExtrude)
```

C#

```
void SetDraftWhileExtruding(
    System.bool Forward,
    System.bool DraftWhileExtrude
)
```

C++/CLI

```
void SetDraftWhileExtruding(  
& System.bool Forward,  
& System.bool DraftWhileExtrude  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True for forward direction, false for reverse

DraftWhileExtrude

True if the feature is drafted while extruding, false if not

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::SetDraftWhileExtruding](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::GetDraftWhileExtruding Method](#)
[IExtrudeFeatureData2::GetDraftAngle Method](#)
[IExtrudeFeatureData2::GetDraftOutward Method](#)
[IExtrudeFeatureData2::SetDraftAngle Method](#)
[IExtrudeFeatureData2::SetDraftOutward Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetEndCondition Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : SetEndCondition Method (IExtrudeFeatureData2)

Sets the end condition type of the extrusion feature for the forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetEndCondition( _  
    ByVal Forward As System.Boolean, _  
    ByVal EndCondition As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim Forward As System.Boolean  
Dim EndCondition As System.Integer  
  
instance.SetEndCondition(Forward, EndCondition)
```

C#

```
void SetEndCondition(  
    System.bool Forward,  
    System.int EndCondition  
)
```

C++/CLI

```
void SetEndCondition(  
& System.bool Forward,
```

```
& System.int EndCondition
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True for forward direction, false for reverse

EndCondition

End condition type as defined in [swEndConditions_e](#)

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::SetEndCondition](#).

See Also

[IExtrudeFeatureData2 Interface](#)

[IExtrudeFeatureData2 Members](#)

[IExtrudeFeatureData2::SetEndConditionReference Method](#)

[IExtrudeFeatureData2::GetEndCondition Method](#)

[IExtrudeFeatureData2::GetEndConditionReference Method](#)

[IExtrudeFeatureData2::SetDepth Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetEndConditionReference Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : SetEndConditionReference Method (IExtrudeFeatureData2)

Sets the reference entity that defines the end condition in a forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetEndConditionReference( _
    ByVal Forward As System.Boolean, _
    ByVal PDisp As System.Object _
)
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2
Dim Forward As System.Boolean
Dim PDisp As System.Object

instance.SetEndConditionReference(Forward, PDisp)
```

C#

```
void SetEndConditionReference(
    System.bool Forward,
    System.object PDisp
)
```

C++/CLI

```
void SetEndConditionReference(
    & System.bool Forward,
    & System.Object^ PDisp
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True for forward direction, false for reverse

PDisp

Pointer to the reference entity

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::SetEndConditionReference](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::GetEndConditionReference Method](#)
[IExtrudeFeatureData2::GetEndCondition Method](#)
[IExtrudeFeatureData2::SetEndCondition Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetFace Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : SetFace Method (IExtrudeFeatureData2)

Obsolete. Superseded by [IExtrudeFeatureData2::SetEndConditionReference](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetFace( _  
    ByVal Forward As System.Boolean, _  
    ByVal Face As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim Forward As System.Boolean  
Dim Face As System.Object  
  
instance.SetFace(Forward, Face)
```

C#

```
void SetFace(  
    System.bool Forward,  
    System.object Face  
)
```

C++/CLI

```
void SetFace(  
& System.bool Forward,  
& System.Object^ Face  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Face

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::SetFace](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetFromEntity Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : SetFromEntity Method (IExtrudeFeatureData2)

Sets the entity from which to create an extrusion.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetFromEntity( _  
    ByVal FromEntity As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim FromEntity As System.Object  
  
instance.SetFromEntity(FromEntity)
```

C#

```
void SetFromEntity(  
    System.object FromEntity  
)
```

C++/CLI

```
void SetFromEntity(  
& System.Object^ FromEntity  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FromEntity

Entity from which to create the extrusion:

- Surface
- Face
- Plane
- Vertex
- Sketch point

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::SetFromEntity](#).

Remarks

You must also set the type of entity using [IExtrudeFeatureData2::FromType](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::GetFromEntity Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetReverseOffset Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : SetReverseOffset Method (IExtrudeFeatureData2)

Sets the offset direction for this extrude feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetReverseOffset( _  
    ByVal Fwd As System.Boolean, _  
    ByVal ValIn As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim Fwd As System.Boolean  
Dim ValIn As System.Boolean  
  
instance.SetReverseOffset(Fwd, ValIn)
```

C#

```
void SetReverseOffset(  
    System.bool Fwd,  
    System.bool ValIn  
)
```

C++/CLI

```
void SetReverseOffset(  
& System.bool Fwd,  
& System.bool ValIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Fwd
True sets the reverse offset setting in the forward direction, false sets it in the reverse direction
ValIn
True enables the reverse offset setting, false disables it

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::SetReverseOffset](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::SGetReverseOffset Method](#)
[IExtrudeFeatureData2::GetTranslateSurface Method](#)
[IExtrudeFeatureData2::SetTranslateSurface Method](#)
[IExtrudeFeatureData2::FromOffsetDistance Property](#)
[IExtrudeFeatureData2::FromOffsetReverse Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTranslateSurface Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : SetTranslateSurface Method (IExtrudeFeatureData2)

Sets the translate surface setting for this extrude feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetTranslateSurface( _  
    ByVal Fwd As System.Boolean, _  
    ByVal ValIn As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim Fwd As System.Boolean  
Dim ValIn As System.Boolean  
  
instance.SetTranslateSurface(Fwd, ValIn)
```

C#

```
void SetTranslateSurface(  
    System.bool Fwd,  
    System.bool ValIn  
)
```

C++/CLI

```
void SetTranslateSurface(  
& System.bool Fwd,  
& System.bool ValIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Fwd

True makes the end of the extrusion a translation of the reference surface in the forward direction, false makes the end of the extrusion a translation of the reference surface in the reverse direction

ValIn

True to enable the translate surface setting, false to disable it

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::SetTranslateSurface](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::GetTranslateSurface Method](#)
[IExtrudeFeatureData2::GetReverseOffset Method](#)
[IExtrudeFeatureData2::SetReverseOffset Method](#)
[IExtrudeFeatureData2::FromOffsetDistance Property](#)
[IExtrudeFeatureData2::FromOffsetReverse Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetVertex Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : SetVertex Method (IExtrudeFeatureData2)

Obsolete. Superseded by [IExtrudeFeatureData2::SetEndConditionReference](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetVertex( _  
    ByVal Forward As System.Boolean, _  
    ByVal Face As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim Forward As System.Boolean  
Dim Face As System.Object
```

```
instance.SetVertex(Forward, Face)
```

C#

```
void SetVertex(  
    System.bool Forward,  
    System.object Face  
)
```

C++/CLI

```
void SetVertex(  
& System.bool Forward,  
& System.Object^ Face  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

Face

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::SetVertex](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetWallThickness Method (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : SetWallThickness Method (IExtrudeFeatureData2)

Sets the wall thickness of the thin extrusion feature in a forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetWallThickness( _  
    ByVal Forward As System.Boolean, _
```

```
ByVal WallThickness As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IExtrudeFeatureData2  
Dim Forward As System.Boolean  
Dim WallThickness As System.Double  
  
instance.SetWallThickness(Forward, WallThickness)
```

C#

```
void SetWallThickness(  
    System.bool Forward,  
    System.double WallThickness  
)
```

C++/CLI

```
void SetWallThickness(  
& System.bool Forward,  
& System.double WallThickness  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True for forward direction, false for reverse

WallThickness

True for forward feature direction, false for reverse

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::SetWallThickness](#).

Remarks

This method is relevant only for thin features.

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::ThinWallType Property](#)
[IExtrudeFeatureData2::IsThinFeature Method](#)
[IExtrudeFeatureData2::GetWallThickness Method](#)
[IExtrudeFeatureData2::CapEnds Property](#)
[IExtrudeFeatureData2::CapThickness Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ThinWallType Property (IExtrudeFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IExtrudeFeatureData2 Interface](#) : ThinWallType Property (IExtrudeFeatureData2)

Gets or sets the thin wall type for a thin base extrude feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ThinWallType As System.Integer
```

```
Dim instance As IExtrudeFeatureData2  
Dim value As System.Integer  
  
instance.ThinWallType = value  
  
value = instance.ThinWallType
```

C#

```
System.int ThinWallType {get; set;}
```

C++/CLI

```
property System.int ThinWallType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Thin feature type:

- 0 = One Direction
- 1 = One Direction Reverse
- 2 = Mid Plane
- 3 = Two Direction

Visual Basic for Applications (VBA) Syntax

See [ExtrudeFeatureData2::ThinWallType](#).

See Also

[IExtrudeFeatureData2 Interface](#)
[IExtrudeFeatureData2 Members](#)
[IExtrudeFeatureData2::IsThinFeature Method](#)
[IExtrudeFeatureData2::SetWallThickness Method](#)
[IExtrudeFeatureData2::GetWallThickness Method](#)
[IExtrudeFeatureData2::CapEnds Property](#)
[IExtrudeFeatureData2::CapThickness Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0