

SOLIDWORKS API (.NET VBA C#) — Reference

(103/337): IFace (part 1 of 2)

SOLIDWORKS API Documentation (converted from CHM)

IFace (part 1 of 2) (Type)

IFace Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFace Interface

Obsolete. Superseded by [IFace2](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IFace
```

Visual Basic (Usage)



```
Dim instance As IFace
```

C#

```
public interface IFace
```

C++/CLI

```
public interface class IFace
```

Visual Basic for Applications (VBA) Syntax

See [Face](#).

See Also

[IFace Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IFace Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFace Interface

The following tables list the members exposed by [IFace](#).

Public Properties

Name	Description
IMaterialPropertyValues	Obsolete. Superseded by IFace2::IMaterialPropertyValues .
INormal	Obsolete. Superseded by IFace2::INormal . NOTE: This property is a get-only property. Set is not implemented.
MaterialIdName	Obsolete. Superseded by IFace2::MaterialIdName .
MaterialPropertyValues	Obsolete. Superseded by IFace2::MaterialPropertyValues .
MaterialUserName	Obsolete. Superseded by IFace2::MaterialUserName .
Normal	Obsolete. Superseded by IFace2::Normal . NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

Public Methods

Name	Description
 AddPropertyExtension	Obsolete. Superseded by IFace2::AddPropertyExtension .
 CreateSheetBody	Obsolete. Superseded by IFace2::CreateSheetBody .
 CreateSheetBodyByFaceExtension	Obsolete. Superseded by IFace2::CreateSheetBodyByFaceExtension .
 EnumEdges	Obsolete. Superseded by IFace2::EnumEdges .
 EnumLoops	Obsolete. Superseded by IFace2::EnumLoops .
 FaceInSurfaceSense	Obsolete. Superseded by IFace2::FaceInSurfaceSense .
 GetArea	Obsolete. Superseded by IFace2::GetArea .
 GetBody	Obsolete. Superseded by IFace2::GetBody .
 GetBox	Obsolete. Superseded by IFace2::GetBox .
 GetClosestPointOn	Obsolete. Superseded by IFace2::GetClosestPointOn .
 GetEdgeCount	Obsolete. Superseded by IFace2::GetEdgeCount .
 GetEdges	Obsolete. Superseded by IFace2::GetEdges .
 GetFaceId	Obsolete. Superseded by IFace2::GetFaceId .
 GetFeature	Obsolete. Superseded by IFace2::GetFeature .
 GetFeatureId	Obsolete. Superseded by IFace2::GetFeatureId .
 GetFirstLoop	Obsolete. Superseded by IFace2::GetFirstLoop .
 GetLoopCount	Obsolete. Superseded by IFace2::GetLoopCount .
 GetNextFace	Obsolete. Superseded by IFace2::GetNextFace .
 GetPatternSeedFeature	Obsolete. Superseded by IFace2::GetPatternSeedFeature .
 GetPropertyExtension	Obsolete. Superseded by IFace2::GetPropertyExtension .
 GetShellType	Obsolete. Superseded by IFace2::GetShellType .
 GetSilhouetteEdges	Obsolete. Superseded by IFace2::GetSilhouetteEdgesVB .
 GetSilhouetteEdgesVB	Obsolete. Superseded by IFace2::GetSilhouetteEdgesVB .
 GetSurface	Obsolete. Superseded by IFace2::GetSurface .
 GetTessNorms	Obsolete. Superseded by IFace2::GetTessNorms .
 GetTessTriangleCount	Obsolete. Superseded by IFace2::GetTessTriangleCount .
 GetTessTriangles	Obsolete. Superseded by IFace2::GetTessTriangles .
 GetTessTriStripEdges	Obsolete. Superseded by IFace2::GetTessTriStripEdges .
 GetTessTriStripNorms	Obsolete. Superseded by IFace2::GetTessTriStripNorms .
 GetTessTriStrips	Obsolete. Superseded by IFace2::GetTessTriStrips .
 GetTessTriStripSize	Obsolete. Superseded by IFace2::GetTessTriStripSize .
 GetTrimCurves	Obsolete. Superseded by IFace2::GetTrimCurves2 .
 GetTrimCurves2	Obsolete. Superseded by IFace2::GetTrimCurves2 .
 GetTrimCurveTopology	Obsolete. Superseded by IFace2::GetTrimCurveTopology .
 GetTrimCurveTopologyCount	Obsolete. Superseded by IFace2::GetTrimCurveTopologyCount .
 GetTrimCurveTopologyTypes	Obsolete. Superseded by IFace2::GetTrimCurveTopologyTypes .
 GetUVBounds	Obsolete. Superseded by IFace2::GetUVBounds .
 Highlight	Obsolete. Superseded by IFace2::Highlight .
 ICreateSheetBody	Obsolete. Superseded by IFace2::ICreateSheetBody .
 ICreateSheetBodyByFaceExtension	Obsolete. Superseded by IFace2::ICreateSheetBodyByFaceExtension .
 IGetBody	Obsolete. Superseded by IFace2::IGetBody .
 IGetBox	Obsolete. Superseded by IFace2::IGetBox .

	IGetClosestPointOn	Obsolete. Superseded by IFace2::IGetClosestPointOn .
	IGetEdges	Obsolete. Superseded by IFace2::IGetEdges .
	IGetTessData	Obsolete. Superseded by IFace2::IGetTessNorms , IFace2::IGetTessTextures , IFace2::GetTessTriangleCount , IFace2::IGetTriangles , IFace2::IGetTessTriStripEdges , IFace2::IGetTessTriStrips , and IFace2::GetTessTriStripSize .
	IGetFeature	Obsolete. Superseded by IFace2::IGetFeature .
	IGetFirstLoop	Obsolete. Superseded by IFace2::IGetFirstLoop .
	IGetNextFace	Obsolete. Superseded by IFace2::IGetNextFace .
	IGetPatternSeedFeature	Obsolete. Superseded by IFace2::IGetPatternSeedFeature .
	IGetSilhouetteEdgeCount	Obsolete. Superseded by IFace2::IGetSilhouetteEdgeCount .
	IGetSilhouetteEdges	Obsolete. Superseded by IFace2::IGetSilhouetteEdges .
	IGetSurface	Obsolete. Superseded by IFace2::IGetSurface .
	IGetTessNorms	Obsolete. Superseded by IFace2::IGetTessNorms .
	IGetTessTriangles	Obsolete. Superseded by IFace2::IGetTessTriangles .
	IGetTessTriStripEdges	Obsolete. Superseded by IFace2::IGetTessTriStripEdges .
	IGetTessTriStripEdgeSize	Obsolete. Superseded by IFace2::IGetTessTriStripEdgeSize .
	IGetTessTriStripNorms	Obsolete. Superseded by IFace2::IGetTessTriStripNorms .
	IGetTessTriStrips	Obsolete. Superseded by IFace2::IGetTessTriStrips .
	IGetTrimCurve	Obsolete. Superseded by IFace2::IGetTrimCurve .
	IGetTrimCurveSize	Obsolete. Superseded by IFace2::IGetTrimCurveSize2 .
	IGetTrimCurveSize2	Obsolete. Superseded by IFace2::IGetTrimCurveSize2 .
	IGetTrimCurveTopology	Obsolete. Superseded by IFace2::IGetTrimCurveTopology .
	IGetTrimCurveTopologyTypes	Obsolete. Superseded by IFace2::IGetTrimCurveTopologyTypes .
	IGetUVBounds	Obsolete. Superseded by IFace2::IGetUVBounds .
	IHighlight	Obsolete. Superseded by IFace2::IHighlight .
	IsSame	Obsolete. Superseded by IFace2::IsSame .
	IRemoveInnerLoops	Obsolete. Superseded by IFace2::IRemoveInnerLoops .
	IsSame	Obsolete. Superseded by IFace2::IsSame .
	RemoveFacetId	Obsolete. Superseded by IFace2::RemoveFacetId .
	RemoveInnerLoops	Obsolete. Superseded by IFace2::RemoveInnerLoops .
	RemoveMaterialProperty	Obsolete. Superseded by IFace2::RemoveMaterialProperty2 .
	RemoveRedundantTopology	Obsolete. Superseded by IFace2::RemoveRedundantTopology .
	ResetPropertyExtension	Obsolete. Superseded by IFace2::ResetPropertyExtension .
	SetFacetId	Obsolete. Superseded by IFace2::SetFacetId .

[Top](#)

See Also

[IFace Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IFace Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFace Interface

For a list of all members of this type, see [IFace members](#).

Public Methods

Name	Description
 AddPropertyExtension	Obsolete. Superseded by IFace2::AddPropertyExtension .
 CreateSheetBody	Obsolete. Superseded by IFace2::CreateSheetBody .
 CreateSheetBodyByFaceExtension	Obsolete. Superseded by IFace2::CreateSheetBodyByFaceExtension .
 EnumEdges	Obsolete. Superseded by IFace2::EnumEdges .
 EnumLoops	Obsolete. Superseded by IFace2::EnumLoops .
 FaceInSurfaceSense	Obsolete. Superseded by IFace2::FaceInSurfaceSense .
 GetArea	Obsolete. Superseded by IFace2::GetArea .
 GetBody	Obsolete. Superseded by IFace2::GetBody .
 GetBox	Obsolete. Superseded by IFace2::GetBox .
 GetClosestPointOn	Obsolete. Superseded by IFace2::GetClosestPointOn .
 GetEdgeCount	Obsolete. Superseded by IFace2::GetEdgeCount .
 GetEdges	Obsolete. Superseded by IFace2::GetEdges .
 GetFaceId	Obsolete. Superseded by IFace2::GetFaceId .
 GetFeature	Obsolete. Superseded by IFace2::GetFeature .
 GetFeatureId	Obsolete. Superseded by IFace2::GetFeatureId .
 GetFirstLoop	Obsolete. Superseded by IFace2::GetFirstLoop .
 GetLoopCount	Obsolete. Superseded by IFace2::GetLoopCount .
 GetNextFace	Obsolete. Superseded by IFace2::GetNextFace .
 GetPatternSeedFeature	Obsolete. Superseded by IFace2::GetPatternSeedFeature .
 GetPropertyExtension	Obsolete. Superseded by IFace2::GetPropertyExtension .
 GetShellType	Obsolete. Superseded by IFace2::GetShellType .
 GetSilhouetteEdges	Obsolete. Superseded by IFace2::GetSilhouetteEdgesVB .
 GetSilhouetteEdgesVB	Obsolete. Superseded by IFace2::GetSilhouetteEdgesVB .
 GetSurface	Obsolete. Superseded by IFace2::GetSurface .
 GetTessNorms	Obsolete. Superseded by IFace2::GetTessNorms .
 GetTessTriangleCount	Obsolete. Superseded by IFace2::GetTessTriangleCount .
 GetTessTriangles	Obsolete. Superseded by IFace2::GetTessTriangles .
 GetTessTriStripEdges	Obsolete. Superseded by IFace2::GetTessTriStripEdges .
 GetTessTriStripNorms	Obsolete. Superseded by IFace2::GetTessTriStripNorms .
 GetTessTriStrips	Obsolete. Superseded by IFace2::GetTessTriStrips .
 GetTessTriStripSize	Obsolete. Superseded by IFace2::GetTessTriStripSize .
 GetTrimCurves	Obsolete. Superseded by IFace2::GetTrimCurves2 .
 GetTrimCurves2	Obsolete. Superseded by IFace2::GetTrimCurves2 .
 GetTrimCurveTopology	Obsolete. Superseded by IFace2::GetTrimCurveTopology .
 GetTrimCurveTopologyCount	Obsolete. Superseded by IFace2::GetTrimCurveTopologyCount .
 GetTrimCurveTopologyTypes	Obsolete. Superseded by IFace2::GetTrimCurveTopologyTypes .
 GetUVBounds	Obsolete. Superseded by IFace2::GetUVBounds .
 Highlight	Obsolete. Superseded by IFace2::Highlight .
 ICreateSheetBody	Obsolete. Superseded by IFace2::ICreateSheetBody .
 ICreateSheetBodyByFaceExtension	Obsolete. Superseded by IFace2::ICreateSheetBodyByFaceExtension .
 IGetBody	Obsolete. Superseded by IFace2::IGetBody .
 IGetBox	Obsolete. Superseded by IFace2::IGetBox .

	IGetClosestPointOn	Obsolete. Superseded by IFace2::IGetClosestPointOn .
	IGetEdges	Obsolete. Superseded by IFace2::IGetEdges .
	IGetTessData	Obsolete. Superseded by IFace2::IGetTessNorms , IFace2::IGetTessTextures , IFace2::GetTessTriangleCount , IFace2::IGetTriangles , IFace2::IGetTessTriStripEdges , IFace2::IGetTessTriStrips , and IFace2::GetTessTriStripSize .
	IGetFeature	Obsolete. Superseded by IFace2::IGetFeature .
	IGetFirstLoop	Obsolete. Superseded by IFace2::IGetFirstLoop .
	IGetNextFace	Obsolete. Superseded by IFace2::IGetNextFace .
	IGetPatternSeedFeature	Obsolete. Superseded by IFace2::IGetPatternSeedFeature .
	IGetSilhouetteEdgeCount	Obsolete. Superseded by IFace2::IGetSilhouetteEdgeCount .
	IGetSilhouetteEdges	Obsolete. Superseded by IFace2::IGetSilhouetteEdges .
	IGetSurface	Obsolete. Superseded by IFace2::IGetSurface .
	IGetTessNorms	Obsolete. Superseded by IFace2::IGetTessNorms .
	IGetTessTriangles	Obsolete. Superseded by IFace2::IGetTessTriangles .
	IGetTessTriStripEdges	Obsolete. Superseded by IFace2::IGetTessTriStripEdges .
	IGetTessTriStripEdgeSize	Obsolete. Superseded by IFace2::IGetTessTriStripEdgeSize .
	IGetTessTriStripNorms	Obsolete. Superseded by IFace2::IGetTessTriStripNorms .
	IGetTessTriStrips	Obsolete. Superseded by IFace2::IGetTessTriStrips .
	IGetTrimCurve	Obsolete. Superseded by IFace2::IGetTrimCurve .
	IGetTrimCurveSize	Obsolete. Superseded by IFace2::IGetTrimCurveSize2 .
	IGetTrimCurveSize2	Obsolete. Superseded by IFace2::IGetTrimCurveSize2 .
	IGetTrimCurveTopology	Obsolete. Superseded by IFace2::IGetTrimCurveTopology .
	IGetTrimCurveTopologyTypes	Obsolete. Superseded by IFace2::IGetTrimCurveTopologyTypes .
	IGetUVBounds	Obsolete. Superseded by IFace2::IGetUVBounds .
	IHighlight	Obsolete. Superseded by IFace2::IHighlight .
	IsSame	Obsolete. Superseded by IFace2::IsSame .
	IRemoveInnerLoops	Obsolete. Superseded by IFace2::IRemoveInnerLoops .
	IsSame	Obsolete. Superseded by IFace2::IsSame .
	RemoveFacetId	Obsolete. Superseded by IFace2::RemoveFacetId .
	RemoveInnerLoops	Obsolete. Superseded by IFace2::RemoveInnerLoops .
	RemoveMaterialProperty	Obsolete. Superseded by IFace2::RemoveMaterialProperty2 .
	RemoveRedundantTopology	Obsolete. Superseded by IFace2::RemoveRedundantTopology .
	ResetPropertyExtension	Obsolete. Superseded by IFace2::ResetPropertyExtension .
	SetFacetId	Obsolete. Superseded by IFace2::SetFacetId .

[Top](#)

See Also

[IFace Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IFace Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFace Interface

For a list of all members of this type, see [IFace members](#).

Public Properties

Name	Description
 IMaterialPropertyValues	Obsolete. Superseded by IFace2::IMaterialPropertyValues .
 INormal	Obsolete. Superseded by IFace2::INormal . NOTE: This property is a get-only property. Set is not implemented.
 MaterialIdName	Obsolete. Superseded by IFace2::MaterialIdName .
 MaterialPropertyValues	Obsolete. Superseded by IFace2::MaterialPropertyValues .
 MaterialUserName	Obsolete. Superseded by IFace2::MaterialUserName .
 Normal	Obsolete. Superseded by IFace2::Normal . NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

See Also

[IFace Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddPropertyExtension Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : AddPropertyExtension Method (IFace)

Obsolete. Superseded by [IFace2::AddPropertyExtension](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddPropertyExtension( _
    ByVal PropertyExtension As System.Object _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFace
Dim PropertyExtension As System.Object
Dim value As System.Integer
```

```
value = instance.AddPropertyExtension(PropertyExtension)
```

C#

```
System.int AddPropertyExtension(
    System.object PropertyExtension
)
```

C++/CLI

```
System.int AddPropertyExtension(
    & System.Object^ PropertyExtension
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PropertyExtension

Visual Basic for Applications (VBA) Syntax

See [Face::AddPropertyExtension](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateSheetBody Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : CreateSheetBody Method (IFace)

Obsolete. Superseded by [IFace2::CreateSheetBody](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateSheetBody() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Object  
  
value = instance.CreateSheetBody()
```

C#

```
System.object CreateSheetBody()
```

C++/CLI

```
System.Object^ CreateSheetBody();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::CreateSheetBody](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateSheetBodyByFaceExtension Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : CreateSheetBodyByFaceExtension Method (IFace)

Obsolete. Superseded by [IFace2::CreateSheetbodyByFaceExtension](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateSheetBodyByFaceExtension( _  
    ByVal BoxLowIn As System.Object, _  
    ByVal BoxHighIn As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim BoxLowIn As System.Object  
Dim BoxHighIn As System.Object  
Dim value As System.Object
```

```
value = instance.CreateSheetBodyByFaceExtension(BoxLowIn, BoxHighIn)
```

C#

```
System.object CreateSheetBodyByFaceExtension(  
    System.object BoxLowIn,  
    System.object BoxHighIn  
)
```

C++/CLI

```
System.Object^ CreateSheetBodyByFaceExtension(  
& System.Object^ BoxLowIn,  
& System.Object^ BoxHighIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BoxLowIn

BoxHighIn

Visual Basic for Applications (VBA) Syntax

See [Face::CreateSheetBodyByFaceExtension](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

EnumEdges Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : EnumEdges Method (IFace)

Obsolete. Superseded by [IFace2::EnumEdges](#).

.NET Syntax

Visual Basic (Declaration)

```
Function EnumEdges() As EnumEdges
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As EnumEdges  
  
value = instance.EnumEdges()
```

C#

```
EnumEdges EnumEdges()
```

C++/CLI

```
EnumEdges^ EnumEdges();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::EnumEdges](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

EnumLoops Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : EnumLoops Method (IFace)

Obsolete. Superseded by [IFace2::EnumLoops](#).

.NET Syntax

Visual Basic (Declaration)

```
Function EnumLoops() As EnumLoops
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As EnumLoops  
  
value = instance.EnumLoops()
```

C#

```
EnumLoops EnumLoops()
```

C++/CLI

```
EnumLoops^ EnumLoops();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::EnumLoops](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

FaceInSurfaceSense Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : FaceInSurfaceSense Method (IFace)

Obsolete. Superseded by [IFace2::FaceInSurfaceSense](#).

.NET Syntax

Visual Basic (Declaration)

```
Function FaceInSurfaceSense() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Boolean  
  
value = instance.FaceInSurfaceSense()
```

C#

```
System.bool FaceInSurfaceSense()
```

C++/CLI

```
System.bool FaceInSurfaceSense();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::FaceInSurfaceSense](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetArea Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetArea Method (IFace)

Obsolete. Superseded by [IFace2::GetArea](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetArea() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Double  
  
value = instance.GetArea()
```

C#

```
System.double GetArea()
```

C++/CLI

```
System.double GetArea();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::GetArea](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetBody Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetBody Method (IFace)

Obsolete. Superseded by [IFace2::GetBody](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetBody() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Object  
  
value = instance.GetBody()
```

C#

```
System.object GetBody()
```

C++/CLI

```
System.Object^ GetBody();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::GetBody](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetBox Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetBox Method (IFace)

Obsolete. Superseded by [IFace2::GetBox](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetBox() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Object  
  
value = instance.GetBox()
```

C#

```
System.object GetBox()
```

C++/CLI

```
System.Object^ GetBox();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::GetBox](#).

See Also

GetClosestPointOn Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetClosestPointOn Method (IFace)

Obsolete. Superseded by [IFace2::GetClosestPointOn](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetClosestPointOn( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Object  
  
value = instance.GetClosestPointOn(X, Y, Z)
```

C#

```
System.Object GetClosestPointOn(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
System.Object^ GetClosestPointOn(  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [Face::GetClosestPointOn](#).

See Also

GetEdgeCount Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetEdgeCount Method (IFace)

Obsolete. Superseded by [IFace2::GetEdgeCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetEdgeCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Integer  
  
value = instance.GetEdgeCount()
```

C#

```
System.int GetEdgeCount()
```

C++/CLI

```
System.int GetEdgeCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::GetEdgeCount](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEdges Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetEdges Method (IFace)

Obsolete. Superseded by [IFace2::GetEdges](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetEdges() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Object  
  
value = instance.GetEdges()
```

C#

```
System.object GetEdges()
```

C++/CLI

```
System.Object^ GetEdges();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::GetEdges](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFaceId Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetFaceId Method (IFace)

Obsolete. Superseded by [IFace2::GetFaceId](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFaceId() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Integer  
  
value = instance.GetFaceId()
```

C#

```
System.int GetFaceId()
```

C++/CLI

```
System.int GetFaceId();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::GetFaceId](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFeature Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetFeature Method (IFace)

Obsolete. Superseded by [IFace2::GetFeature](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeature() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Object  
  
value = instance.GetFeature()
```

C#

```
System.object GetFeature()
```

C++/CLI

```
System.Object^ GetFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::GetFeature](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFeatureId Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetFeatureId Method (IFace)

Obsolete. Superseded by [IFace2::GetFeatureId](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeatureId() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Integer  
  
value = instance.GetFeatureId()
```

C#

```
System.int GetFeatureId()
```

C++/CLI

```
System.int GetFeatureId();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::GetFeatureId](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFirstLoop Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetFirstLoop Method (IFace)

Obsolete. Superseded by [IFace2::GetFirstLoop](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstLoop() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Object  
  
value = instance.GetFirstLoop()
```

C#

```
System.object GetFirstLoop()
```

C++/CLI

```
System.Object^ GetFirstLoop();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::GetFirstLoop](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetLoopCount Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetLoopCount Method (IFace)

Obsolete. Superseded by [IFace2::GetLoopCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetLoopCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Integer  
  
value = instance.GetLoopCount()
```

C#

```
System.int GetLoopCount()
```

C++/CLI

```
System.int GetLoopCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::GetLoopCount](#).

See Also

GetNextFace Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetNextFace Method (IFace)

Obsolete. Superseded by [IFace2::GetNextFace](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNextFace() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Object  
  
value = instance.GetNextFace()
```

C#

```
System.object GetNextFace()
```

C++/CLI

```
System.Object^ GetNextFace();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::GetNextFace](#).

See Also

[IFace Interface](#)
[IFace Members](#)

GetPatternSeedFeature Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetPatternSeedFeature Method (IFace)

Obsolete. Superseded by [IFace2::GetPatternSeedFeature](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetPatternSeedFeature() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Object  
  
value = instance.GetPatternSeedFeature()
```

C#

```
System.object GetPatternSeedFeature()
```

C++/CLI

```
System.Object^ GetPatternSeedFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::GetPatternSeedFeature](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetPropertyExtension Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetPropertyExtension Method (IFace)

Obsolete. Superseded by [IFace2::GetPropertyExtension](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetPropertyExtension( _  
    ByVal ID As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim ID As System.Integer  
Dim value As System.Object
```

```
value = instance.GetPropertyExtension(ID)
```

C#

```
System.object GetPropertyExtension(  
    System.int ID  
)
```

C++/CLI

```
System.Object^ GetPropertyExtension(  
& System.int ID  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ID

Visual Basic for Applications (VBA) Syntax

See [Face::GetPropertyExtension](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetShellType Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetShellType Method (IFace)

Obsolete. Superseded by [IFace2::GetShellType](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetShellType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Integer  
  
value = instance.GetShellType()
```

C#

```
System.int GetShellType()
```

C++/CLI

```
System.int GetShellType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::GetShellType](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSilhoutteEdges Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetSilhoutteEdges Method (IFace)

Obsolete. Superseded by [IFace2::GetSilhoutteEdgesVB](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetSilhoutteEdges( _  
    ByRef Root As System.Double, _  
    ByRef Normal As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim Root As System.Double  
Dim Normal As System.Double  
Dim value As System.Object  
  
value = instance.GetSilhoutteEdges(Root, Normal)
```

C#

```
System.object GetSilhoutteEdges(  
    ref System.double Root,  
    ref System.double Normal  
)
```

C++/CLI

```
System.Object^ GetSilhoutteEdges(  
& System.double% Root,  
& System.double% Normal  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Root

Normal

Visual Basic for Applications (VBA) Syntax

See [Face::GetSilhoutteEdges](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments on this topic](#).

GetSilhoutteEdgesVB Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetSilhoutteEdgesVB Method (IFace)

Obsolete. Superseded by [IFace2::GetSilhoutteEdgesVB](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetSilhoutteEdgesVB( _  
    ByVal Xroot As System.Double, _  
    ByVal Yroot As System.Double, _  
    ByVal Zroot As System.Double, _  
    ByVal Xnormal As System.Double, _  
    ByVal Ynormal As System.Double, _  
    ByVal Znormal As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim Xroot As System.Double  
Dim Yroot As System.Double  
Dim Zroot As System.Double  
Dim Xnormal As System.Double  
Dim Ynormal As System.Double  
Dim Znormal As System.Double  
Dim value As System.Object  
  
value = instance.GetSilhoutteEdgesVB(Xroot, Yroot, Zroot, Xnormal, Ynormal, Znormal)
```

C#

```
System.object GetSilhoutteEdgesVB(  
    System.double Xroot,  
    System.double Yroot,  
    System.double Zroot,
```

```
System.double Xnormal,  
System.double Ynormal,  
System.double Znormal  
)
```

C++/CLI

```
System.Object^ GetSilhoutteEdgesVB(  
& System.double Xroot,  
& System.double Yroot,  
& System.double Zroot,  
& System.double Xnormal,  
& System.double Ynormal,  
& System.double Znormal  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Xroot

Yroot

Zroot

Xnormal

Ynormal

Znormal

Visual Basic for Applications (VBA) Syntax

See [Face::GetSilhoutteEdgesVB](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetSurface Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetSurface Method (IFace)

Obsolete. Superseded by [IFace2::GetSurface](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetSurface() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Object  
  
value = instance.GetSurface()
```

C#

```
System.object GetSurface()
```

C++/CLI

```
System.Object^ GetSurface();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::GetSurface](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTessNorms Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetTessNorms Method (IFace)

Obsolete. Superseded by [IFace2::GetTessNorms](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTessNorms() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Object  
  
value = instance.GetTessNorms()
```

C#

```
System.object GetTessNorms()
```

C++/CLI

```
System.Object^ GetTessNorms();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::GetTessNorms](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTessTriangleCount Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetTessTriangleCount Method (IFace)

Obsolete. Superseded by [IFace2::GetTessTriangleCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTessTriangleCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Integer  
  
value = instance.GetTessTriangleCount()
```

C#

```
System.int GetTessTriangleCount()
```

C++/CLI

```
System.int GetTessTriangleCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::GetTessTriangleCount](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTessTriangles Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetTessTriangles Method (IFace)

Obsolete. Superseded by [IFace2::GetTessTriangles](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTessTriangles( _  
    ByVal NoConversion As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim NoConversion As System.Boolean  
Dim value As System.Object  
  
value = instance.GetTessTriangles(NoConversion)
```

C#

```
System.object GetTessTriangles(  
    System.bool NoConversion  
)
```

C++/CLI

```
System.Object^ GetTessTriangles(  
&    System.bool NoConversion  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NoConversion

Visual Basic for Applications (VBA) Syntax

See [Face::GetTessTriangles](#).

See Also

[IFace Interface](#)
[IFace Members](#)

GetTessTriStripEdges Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetTessTriStripEdges Method (IFace)

Obsolete. Superseded by [IFace2::GetTessTriStripEdges](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTessTriStripEdges() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Object  
  
value = instance.GetTessTriStripEdges()
```

C#

```
System.object GetTessTriStripEdges()
```

C++/CLI

```
System.Object^ GetTessTriStripEdges();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::GetTessTriStripEdges](#).

See Also

[IFace Interface](#)
[IFace Members](#)

GetTessTriStripNorms Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetTessTriStripNorms Method (IFace)

Obsolete. Superseded by [IFace2::GetTessTriStripNorms](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTessTriStripNorms() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Object  
  
value = instance.GetTessTriStripNorms()
```

C#

```
System.object GetTessTriStripNorms()
```

C++/CLI

```
System.Object^ GetTessTriStripNorms();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::GetTessTriStripNorms](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTessTriStrips Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetTessTriStrips Method (IFace)

Obsolete. Superseded by [IFace2::GetTessTriStrips](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTessTriStrips( _  
    ByVal NoConversion As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim NoConversion As System.Boolean  
Dim value As System.Object  
  
value = instance.GetTessTriStrips(NoConversion)
```

C#

```
System.object GetTessTriStrips(  
    System.bool NoConversion  
)
```

C++/CLI

```
System.Object^ GetTessTriStrips(  
&    System.bool NoConversion  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NoConversion

Visual Basic for Applications (VBA) Syntax

See [Face::GetTessTriStrips](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTessTriStripSize Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetTessTriStripSize Method (IFace)

Obsolete. Superseded by [IFace2::GetTessTriStripSize](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTessTriStripSize() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Integer  
  
value = instance.GetTessTriStripSize()
```

C#

```
System.int GetTessTriStripSize()
```

C++/CLI

```
System.int GetTessTriStripSize();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::GetTessTriStripSize](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTrimCurves Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetTrimCurves Method (IFace)

Obsolete. Superseded by [IFace2::GetTrimCurves2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTrimCurves( _  
    ByVal WantCubic As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim WantCubic As System.Boolean  
Dim value As System.Object  
  
value = instance.GetTrimCurves(WantCubic)
```

C#

```
System.object GetTrimCurves(  
    System.bool WantCubic  
)
```

C++/CLI

```
System.Object^ GetTrimCurves(  
& System.bool WantCubic  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WantCubic

Visual Basic for Applications (VBA) Syntax

See [Face::GetTrimCurves](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTrimCurves2 Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetTrimCurves2 Method (IFace)

Obsolete. Superseded by [IFace2::GetTrimCurves2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTrimCurves2( _  
    ByVal WantCubic As System.Boolean, _  
    ByVal WantNRRational As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim WantCubic As System.Boolean  
Dim WantNRRational As System.Boolean  
Dim value As System.Object  
  
value = instance.GetTrimCurves2(WantCubic, WantNRRational)
```

C#

```
System.object GetTrimCurves2(  
    System.bool WantCubic,  
    System.bool WantNRRational  
)
```

C++/CLI

```
System.Object^ GetTrimCurves2(  
& System.bool WantCubic,  
& System.bool WantNRRational  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WantCubic

WantNRRational

Visual Basic for Applications (VBA) Syntax

See [Face::GetTrimCurves2](#).

See Also

[IFace Interface](#)
[IFace Members](#)

GetTrimCurveTopology Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetTrimCurveTopology Method (IFace)

Obsolete. Superseded by [IFace2::GetTrimCurveTopology](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTrimCurveTopology() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Object  
  
value = instance.GetTrimCurveTopology()
```

C#

```
System.object GetTrimCurveTopology()
```

C++/CLI

```
System.Object^ GetTrimCurveTopology();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::GetTrimCurveTopology](#).

See Also

[IFace Interface](#)
[IFace Members](#)

GetTrimCurveTopologyCount Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetTrimCurveTopologyCount Method (IFace)

Obsolete. Superseded by [IFace2::GetTrimCurveTopologyCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTrimCurveTopologyCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Integer  
  
value = instance.GetTrimCurveTopologyCount()
```

C#

```
System.int GetTrimCurveTopologyCount()
```

C++/CLI

```
System.int GetTrimCurveTopologyCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::GetTrimCurveTopologyCount](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTrimCurveTopologyTypes Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetTrimCurveTopologyTypes Method (IFace)

Obsolete. Superseded by [IFace2::GetTrimCurveTopologyTypes](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTrimCurveTopologyTypes() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Object
```

```
value = instance.GetTrimCurveTopologyTypes()
```

C#

```
System.object GetTrimCurveTopologyTypes()
```

C++/CLI

```
System.Object^ GetTrimCurveTopologyTypes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::GetTrimCurveTopologyTypes](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUVBounds Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : GetUVBounds Method (IFace)

Obsolete. Superseded by [IFace2::GetUVBounds](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetUVBounds() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Object  
  
value = instance.GetUVBounds()
```

C#

```
System.Object GetUVBounds()
```

C++/CLI

```
System.Object^ GetUVBounds();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::GetUVBounds](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Highlight Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : Highlight Method (IFace)

Obsolete. Superseded by [IFace2::Highlight](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub Highlight(  
    ByVal State As System.Boolean  
)
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim State As System.Boolean  
  
instance.Highlight(State)
```

C#

```
void Highlight(  
    System.bool State  
)
```

C++/CLI

```
void Highlight(  
&    System.bool State  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

State

Visual Basic for Applications (VBA) Syntax

See [Face::Highlight](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateSheetBody Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : ICreateSheetBody Method (IFace)

Obsolete. Superseded by [IFace2::ICreateSheetBody](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateSheetBody() As Body
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As Body  
  
value = instance.ICreateSheetBody()
```

C#

```
Body ICreateSheetBody()
```

C++/CLI

```
Body^ ICreateSheetBody();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::ICreateSheetBody](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateSheetBodyByFaceExtension Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : ICreateSheetBodyByFaceExtension Method (IFace)

Obsolete. Superseded by [IFace2::ICreateSheetBodyByFaceExtension](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateSheetBodyByFaceExtension( _  
    ByRef BoxLowIn As System.Double, _  
    ByRef BoxHighIn As System.Double _  
    ) As Body
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim BoxLowIn As System.Double  
Dim BoxHighIn As System.Double  
Dim value As Body
```

```
value = instance.ICreateSheetBodyByFaceExtension(BoxLowIn, BoxHighIn)
```

C#

```
Body ICreateSheetBodyByFaceExtension(  
    ref System.double BoxLowIn,  
    ref System.double BoxHighIn  
)
```

C++/CLI

```
Body^ ICreateSheetBodyByFaceExtension(  
& System.double% BoxLowIn,  
& System.double% BoxHighIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BoxLowIn

BoxHighIn

Visual Basic for Applications (VBA) Syntax

See [Face::ICreateSheetBodyByFaceExtension](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetBody Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetBody Method (IFace)

Obsolete. Superseded by [IFace2::IGetBody](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBody() As Body
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As Body  
  
value = instance.IGetBody()
```

C#

```
Body IGetBody()
```

C++/CLI

```
Body^ IGetBody();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::IGetBody](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetBox Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetBox Method (IFace)

Obsolete. Superseded by [IFace2::IGetBox](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBox() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Double  
  
value = instance.IGetBox()
```

C#

```
System.double IGetBox()
```

C++/CLI

```
System.double IGetBox();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::IGetBox](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetClosestPointOn Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetClosestPointOn Method (IFace)

Obsolete. Superseded by [IFace2::IGetClosestPointOn](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetClosestPointOn( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim X As System.Double  
Dim Y As System.Double
```

```
Dim Z As System.Double
Dim value As System.Double

value = instance.IGetClosestPointOn(X, Y, Z)
```

C#

```
System.double IGetClosestPointOn(
    System.double X,
    System.double Y,
    System.double Z
)
```

C++/CLI

```
System.double IGetClosestPointOn(
    & System.double X,
    & System.double Y,
    & System.double Z
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Z

Visual Basic for Applications (VBA) Syntax

See [Face::IGetClosestPointOn](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetEdges Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetEdges Method (IFace)

Obsolete. Superseded by [IFace2::IGetEdges](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetEdges() As System.IntPtr
```

Visual Basic (Usage)



```
Dim instance As IFace
Dim value As System.IntPtr

value = instance.IGetEdges()
```

C#

```
System.IntPtr IGetEdges()
```

C++/CLI

```
System.IntPtr IGetEdges();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::IGetEdges](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFacetData Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetFacetData Method (IFace)

Obsolete. Superseded by [IFace2::IGetTessNormals](#), [IFace2::IGetTessTextures](#), [IFace2::IGetTessTriangleCount](#), [IFace2::IGetTriangles](#), [IFace2::IGetTessTriStripEdges](#), [IFace2::IGetTessTriStrips](#), and [IFace2::GetTessTriStripSize](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub IGetFacetData( _  
    ByVal FacetMesh As System.Integer, _  
    ByRef NFacets As System.Integer, _  
    ByRef NStrips As System.Integer, _  
    ByVal StripVertexNums As System.IntPtr, _  
    ByVal VertexCoords As System.IntPtr, _  
    ByVal NormalCoords As System.IntPtr _  
)
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim FacetMesh As System.Integer  
Dim NFacets As System.Integer  
Dim NStrips As System.Integer  
Dim StripVertexNums As System.IntPtr  
Dim VertexCoords As System.IntPtr  
Dim NormalCoords As System.IntPtr  
  
instance.IGetFacetData(FacetMesh, NFacets, NStrips, StripVertexNums, VertexCoords, NormalCoords)
```

C#

```
void IGetFacetData(  
    System.int FacetMesh,  
    ref System.int NFacets,  
    ref System.int NStrips,  
    System.IntPtr StripVertexNums,  
    System.IntPtr VertexCoords,  
    System.IntPtr NormalCoords  
)
```

C++/CLI

```
void IGetFacetData(  
& System.int FacetMesh,  
& System.int% NFacets,  
& System.int% NStrips,  
& System.IntPtr StripVertexNums,  
& System.IntPtr VertexCoords,  
& System.IntPtr NormalCoords  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FacetMesh

NFacets
NStrips
StripVertexNums
VertexCoords
NormalCoords

Visual Basic for Applications (VBA) Syntax

See [Face::IGetFacetData](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFeature Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetFeature Method (IFace)

Obsolete. Superseded by [IFace2::IGetFeature](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFeature() As Feature
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As Feature
```

```
value = instance.IGetFeature()
```

C#

```
Feature IGetFeature()
```

C++/CLI

```
Feature^ IGetFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::IGetFeature](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFirstLoop Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetFirstLoop Method (IFace)

Obsolete. Superseded by [IFace2::IGetFirstLoop](#).

.NET Syntax

Visual Basic (Declaration)

Function IGetFirstLoop() As Loop

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As Loop  
  
value = instance.IGetFirstLoop()
```

C#

```
Loop IGetFirstLoop()
```

C++/CLI

```
Loop^ IGetFirstLoop();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::IGetFirstLoop](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetNextFace Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetNextFace Method (IFace)

Obsolete. Superseded by [IFace2::IGetNextFace](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNextFace() As Face
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As Face  
  
value = instance.IGetNextFace()
```

C#

```
Face IGetNextFace()
```

C++/CLI

```
Face^ IGetNextFace();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::IGetNextFace](#).

See Also

[IFace Interface](#)
[IFace Members](#)

IGetPatternSeedFeature Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetPatternSeedFeature Method (IFace)

Obsolete. Superseded by [IFace2::IGetPatternSeedFeature](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetPatternSeedFeature() As Feature
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As Feature
```

```
value = instance.IGetPatternSeedFeature()
```

C#

```
Feature IGetPatternSeedFeature()
```

C++/CLI

```
Feature^ IGetPatternSeedFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::IGetPatternSeedFeature](#).

See Also

[IFace Interface](#)
[IFace Members](#)

IGetSilhoutteEdgeCount Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetSilhoutteEdgeCount Method (IFace)

Obsolete. Superseded by [IFace2::IGetSilhoutteEdgeCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSilhoutteEdgeCount( _  
    ByRef Root As System.Double, _  
    ByRef Normal As System.Double _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim Root As System.Double  
Dim Normal As System.Double  
Dim value As System.Integer
```

```
value = instance.IGetSilhoutteEdgeCount(Root, Normal)
```

C#

```
System.int IGetSilhoutteEdgeCount(  
    ref System.double Root,  
    ref System.double Normal  
)
```

C++/CLI

```
System.int IGetSilhoutteEdgeCount(  
& System.double% Root,  
& System.double% Normal  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Root

Normal

Visual Basic for Applications (VBA) Syntax

See [Face::IGetSilhoutteEdgeCount](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetSilhoutteEdges Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetSilhoutteEdges Method (IFace)

Obsolete. Superseded by [IFace2::IGetSilhoutteEdges](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSilhoutteEdges( _  
    ByRef Root As System.Double, _  
    ByRef Normal As System.Double _  
) As System.IntPtr
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim Root As System.Double  
Dim Normal As System.Double  
Dim value As System.IntPtr
```

```
value = instance.IGetSilhoutteEdges(Root, Normal)
```

C#

```
System.IntPtr IGetSilhoutteEdges(  
    ref System.double Root,  
    ref System.double Normal  
)
```

C++/CLI

```
System.IntPtr IGetSilhoutteEdges(  
& System.double% Root,  
& System.double% Normal  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Root

Normal

 Visual Basic for Applications (VBA) Syntax

See [Face::IGetSilhouetteEdges](#).

 See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSurface Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetSurface Method (IFace)

Obsolete. Superseded by [IFace2::IGetSurface](#).

 .NET Syntax

Visual Basic (Declaration)

Function IGetSurface() As Surface

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As Surface  
  
value = instance.IGetSurface()
```

C#

Surface IGetSurface()

C++/CLI

Surface^ IGetSurface();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

 Visual Basic for Applications (VBA) Syntax

See [Face::IGetSurface](#).

 See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetTessNorms Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetTessNorms Method (IFace)

Obsolete. Superseded by [IFace2::IGetTessNorms](#).

 .NET Syntax

Visual Basic (Declaration)

```
Function IGetTessNorms() As System.Single
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Single  
  
value = instance.IGetTessNorms()
```

C#

```
System.float IGetTessNorms()
```

C++/CLI

```
System.float IGetTessNorms();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::IGetTessNorms](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTessTriangles Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetTessTriangles Method (IFace)

Obsolete. Superseded by [IFace2::IGetTessTriangles](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTessTriangles( _  
    ByVal NoConversion As System.Boolean _  
) As System.Single
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim NoConversion As System.Boolean  
Dim value As System.Single  
  
value = instance.IGetTessTriangles(NoConversion)
```

C#

```
System.float IGetTessTriangles(  
    System.bool NoConversion  
)
```

C++/CLI

```
System.float IGetTessTriangles(  
& System.bool NoConversion  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NoConversion

Visual Basic for Applications (VBA) Syntax

See [Face::IGetTessTriangles](#).

See Also

[IFace Interface](#)
[IFace Members](#)