

SOLIDWORKS API (.NET VBA C#) — Reference

(104/337): IFace (part 2 of 2)

SOLIDWORKS API Documentation (converted from CHM)

IFace (part 2 of 2) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTessTriStripEdges Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetTessTriStripEdges Method (IFace)

Obsolete. Superseded by [IFace2::IGetTessTriStripEdges](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTessTriStripEdges() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Integer  
  
value = instance.IGetTessTriStripEdges()
```

C#

```
System.int IGetTessTriStripEdges()
```

C++/CLI

```
System.int IGetTessTriStripEdges();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::IGetTessTriStripEdges](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTessTriStripEdgeSize Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetTessTriStripEdgeSize Method (IFace)

Obsolete. Superseded by [IFace2::IGetTessTriStripEdgeSize](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTessTriStripEdgeSize() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Integer  
  
value = instance.IGetTessTriStripEdgeSize()
```

C#

```
System.int IGetTessTriStripEdgeSize()
```

C++/CLI

```
System.int IGetTessTriStripEdgeSize();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::IGetTessTriStripEdgeSize](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTessTriStripNorms Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetTessTriStripNorms Method (IFace)

Obsolete. Superseded by [IFace2::IGetTessTriStripNorms](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTessTriStripNorms() As System.Single
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Single  
  
value = instance.IGetTessTriStripNorms()
```

C#

```
System.float IGetTessTriStripNorms()
```

C++/CLI

```
System.float IGetTessTriStripNorms();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::IGetTessTriStripNorms](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTessTriStrips Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetTessTriStrips Method (IFace)

Obsolete. Superseded by [IFace2::IGetTessTriStrips](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTessTriStrips( _  
    ByVal NoConversion As System.Boolean _
```

```
) As System.Single
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim NoConversion As System.Boolean  
Dim value As System.Single  
  
value = instance.IGetTessTriStrips(NoConversion)
```

C#

```
System.float IGetTessTriStrips(  
    System.bool NoConversion  
)
```

C++/CLI

```
System.float IGetTessTriStrips(  
&    System.bool NoConversion  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NoConversion

Visual Basic for Applications (VBA) Syntax

See [Face.IGetTessTriStrips](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetTrimCurve Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetTrimCurve Method (IFace)

Obsolete. Superseded by [IFace2.IGetTrimCurve](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTrimCurve() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Double  
  
value = instance.IGetTrimCurve()
```

C#

```
System.double IGetTrimCurve()
```

C++/CLI

```
System.double IGetTrimCurve();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::IGetTrimCurve](#).

 See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTrimCurveSize Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetTrimCurveSize Method (IFace)

Obsolete. Superseded by [IFace2::IGetTrimCurveSize2](#).

 .NET Syntax

Visual Basic (Declaration)

```
Function IGetTrimCurveSize( _  
    ByVal WantCubic As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim WantCubic As System.Boolean  
Dim value As System.Integer  
  
value = instance.IGetTrimCurveSize(WantCubic)
```

C#

```
System.int IGetTrimCurveSize(  
    System.bool WantCubic  
)
```

C++/CLI

```
System.int IGetTrimCurveSize(  
    & System.bool WantCubic  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WantCubic

 Visual Basic for Applications (VBA) Syntax

See [Face::IGetTrimCurveSize](#).

 See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTrimCurveSize2 Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetTrimCurveSize2 Method (IFace)

Obsolete. Superseded by [IFace2::IGetTrimCurveSize2](#).

 .NET Syntax

Visual Basic (Declaration)

```
Function IGetTrimCurveSize2( _  
    ByVal WantCubic As System.Integer, _  
    ByVal WantNRational As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim WantCubic As System.Integer  
Dim WantNRational As System.Integer  
Dim value As System.Integer  
  
value = instance.IGetTrimCurveSize2(WantCubic, WantNRational)
```

C#

```
System.int IGetTrimCurveSize2(  
    System.int WantCubic,  
    System.int WantNRational  
)
```

C++/CLI

```
System.int IGetTrimCurveSize2(  
& System.int WantCubic,  
& System.int WantNRational  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WantCubic

WantNRational

Visual Basic for Applications (VBA) Syntax

See [Face::IGetTrimCurveSize2](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTrimCurveTopology Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetTrimCurveTopology Method (IFace)

Obsolete. Superseded by [IFace2::IGetTrimCurveTopology](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTrimCurveTopology() As System.IntPtr
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.IntPtr  
  
value = instance.IGetTrimCurveTopology()
```

C#

```
System.IntPtr IGetTrimCurveTopology()
```

C++/CLI

```
System.IntPtr IGetTrimCurveTopology();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::IGetTrimCurveTopology](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTrimCurveTopologyTypes Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetTrimCurveTopologyTypes Method (IFace)

Obsolete. Superseded by [IFace2::IGetTrimCurveTopologyTypes](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTrimCurveTopologyTypes() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Integer  
  
value = instance.IGetTrimCurveTopologyTypes()
```

C#

```
System.int IGetTrimCurveTopologyTypes()
```

C++/CLI

```
System.int IGetTrimCurveTopologyTypes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::IGetTrimCurveTopologyTypes](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetUVBounds Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IGetUVBounds Method (IFace)

Obsolete. Superseded by [IFace2::IGetUVBounds](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetUVBounds() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Double  
  
value = instance.IGetUVBounds()
```

C#

```
System.double IGetUVBounds()
```

C++/CLI

```
System.double IGetUVBounds();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::IGetUVBounds](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IHighlight Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IHighlight Method (IFace)

Obsolete. Superseded by [IFace2::IHighlight](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub IHighlight( _  
    ByVal State As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim State As System.Boolean  
  
instance.IHighlight(State)
```

C#

```
void IHighlight(  
    System.bool State  
)
```

C++/CLI

```
void IHighlight(  
& System.bool State  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

State

Visual Basic for Applications (VBA) Syntax

See [Face::IHighlight](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IIsSame Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IIsSame Method (IFace)

Obsolete. Superseded by [IFace2::IIsSame](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IIsSame( _  
    ByVal FaceIn As Face _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim FaceIn As Face  
Dim value As System.Boolean  
  
value = instance.IIsSame(FaceIn)
```

C#

```
System.bool IIsSame(  
    Face FaceIn  
)
```

C++/CLI

```
System.bool IIsSame(  
& Face^ FaceIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceIn

Visual Basic for Applications (VBA) Syntax

See [Face::IIsSame](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IMaterialPropertyValues Property (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IMaterialPropertyValues Property (IFace)

Obsolete. Superseded by [IFace2::IMaterialPropertyValues](#).

.NET Syntax

Visual Basic (Declaration)

```
Property IMaterialPropertyValues As System.Double
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Double  
  
instance.IMaterialPropertyValues = value  
value = instance.IMaterialPropertyValues
```

C#

```
System.double IMaterialPropertyValues {get; set;}
```

C++/CLI

```
property System.double IMaterialPropertyValues {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::IMaterialPropertyValues](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

INormal Property (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : INormal Property (IFace)

Obsolete. Superseded by [IFace2::INormal](#).

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property INormal As System.Double
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Double  
  
instance.INormal = value  
value = instance.INormal
```

C#

```
System.double INormal {get; set;}
```

C++/CLI

```
property System.double INormal {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::INormal](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IRemoveInnerLoops Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IRemoveInnerLoops Method (IFace)

Obsolete. Superseded by [IFace2::IRemoveInnerLoops](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IRemoveInnerLoops( _
    ByVal NumOfLoops As System.Integer, _
    ByRef InnerLoopsIn As Loop _
) As Face
```

Visual Basic (Usage)



```
Dim instance As IFace
Dim NumOfLoops As System.Integer
Dim InnerLoopsIn As Loop
Dim value As Face

value = instance.IRemoveInnerLoops(NumOfLoops, InnerLoopsIn)
```

C#

```
Face IRemoveInnerLoops(
    System.int NumOfLoops,
    ref Loop InnerLoopsIn
)
```

C++/CLI

```
Face^ IRemoveInnerLoops(
    & System.int NumOfLoops,
    & Loop^% InnerLoopsIn
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumOfLoops

InnerLoopsIn

Visual Basic for Applications (VBA) Syntax

See [Face::IRemoveInnerLoops](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsSame Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : IsSame Method (IFace)

Obsolete. Superseded by [IFace2::IsSame](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IsSame( _  
    ByVal FaceIn As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim FaceIn As System.Object  
Dim value As System.Boolean  
  
value = instance.IsSame(FaceIn)
```

C#

```
System.bool IsSame(  
    System.object FaceIn  
)
```

C++/CLI

```
System.bool IsSame(  
& System.Object^ FaceIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceIn

Visual Basic for Applications (VBA) Syntax

See [Face::IsSame](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

MaterialIdName Property (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : MaterialIdName Property (IFace)

Obsolete. Superseded by [IFace2::MaterialIdName](#).

.NET Syntax

Visual Basic (Declaration)

```
Property MaterialIdName As System.String
```

```
Dim instance As IFace
Dim value As System.String

instance.MaterialIdName = value

value = instance.MaterialIdName
```

C#

```
System.string MaterialIdName {get; set;}
```

C++/CLI

```
property System.String^ MaterialIdName {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::MaterialIdName](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

MaterialPropertyValues Property (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : MaterialPropertyValues Property (IFace)

Obsolete. Superseded by [IFace2::MaterialPropertyValues](#).

.NET Syntax

Visual Basic (Declaration)

```
Property MaterialPropertyValues As System.Object
```

Visual Basic (Usage)

```
Dim instance As IFace
Dim value As System.Object

instance.MaterialPropertyValues = value

value = instance.MaterialPropertyValues
```

C#

```
System.object MaterialPropertyValues {get; set;}
```

C++/CLI

```
property System.Object^ MaterialPropertyValues {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::MaterialPropertyValues](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

MaterialUserName Property (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : MaterialUserName Property (IFace)

Obsolete. Superseded by [IFace2::MaterialUserName](#).

.NET Syntax

Visual Basic (Declaration)

```
Property MaterialUserName As System.String
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.String  
  
instance.MaterialUserName = value  
value = instance.MaterialUserName
```

C#

```
System.string MaterialUserName {get; set;}
```

C++/CLI

```
property System.String^ MaterialUserName {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::MaterialUserName](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Normal Property (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : Normal Property (IFace)

Obsolete. Superseded by [IFace2::Normal](#).

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property Normal As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Object  
  
instance.Normal = value  
  
value = instance.Normal
```

C#

```
System.Object Normal {get; set;}
```

C++/CLI

```
property System.Object^ Normal {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::Normal](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

RemoveFaceId Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : RemoveFaceId Method (IFace)

Obsolete. Superseded by [IFace2::RemoveFaceId](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub RemoveFaceId( _  
    ByVal IdIn As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim IdIn As System.Integer  
  
instance.RemoveFaceId(IdIn)
```

C#

```
void RemoveFaceId(  
    System.int IdIn  
)
```

C++/CLI

```
void RemoveFaceId(  
& System.int IdIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

IdIn

Visual Basic for Applications (VBA) Syntax

See [Face::RemoveFaceId](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

RemoveInnerLoops Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : RemoveInnerLoops Method (IFace)

Obsolete. Superseded by [IFace2::RemoveInnerLoops](#).

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveInnerLoops( _  
    ByVal NumOfLoops As System.Integer, _  
    ByVal InnerLoopsIn As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim NumOfLoops As System.Integer  
Dim InnerLoopsIn As System.Object  
Dim value As System.Object  
  
value = instance.RemoveInnerLoops(NumOfLoops, InnerLoopsIn)
```

C#

```
System.object RemoveInnerLoops(  
    System.int NumOfLoops,  
    System.object InnerLoopsIn  
)
```

C++/CLI

```
System.Object^ RemoveInnerLoops(  
& System.int NumOfLoops,  
& System.Object^ InnerLoopsIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumOfLoops

InnerLoopsIn

Visual Basic for Applications (VBA) Syntax

See [Face::RemoveInnerLoops](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

RemoveMaterialProperty Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : RemoveMaterialProperty Method (IFace)

Obsolete. Superseded by [IFace2::RemoveMaterialProperty2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveMaterialProperty() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Boolean  
  
value = instance.RemoveMaterialProperty()
```

C#

```
System.bool RemoveMaterialProperty()
```

C++/CLI

```
System.bool RemoveMaterialProperty();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::RemoveMaterialProperty](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveRedundantTopology Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : RemoveRedundantTopology Method (IFace)

Obsolete. Superseded by [IFace2::RemoveRedundantTopology](#).

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveRedundantTopology() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim value As System.Boolean  
  
value = instance.RemoveRedundantTopology()
```

C#

```
System.bool RemoveRedundantTopology()
```

C++/CLI

```
System.bool RemoveRedundantTopology();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::RemoveRedundantTopology](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ResetPropertyExtension Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : ResetPropertyExtension Method (IFace)

Obsolete. Superseded by [IFace2::ResetPropertyExtension](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ResetPropertyExtension()
```

Visual Basic (Usage)



```
Dim instance As IFace  
instance.ResetPropertyExtension()
```

C#

```
void ResetPropertyExtension()
```

C++/CLI

```
void ResetPropertyExtension();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face::ResetPropertyExtension](#).

See Also

[IFace Interface](#)
[IFace Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetFaceId Method (IFace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace Interface](#) : SetFaceId Method (IFace)

Obsolete. Superseded by [IFace2::SetFaceId](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetFaceId( _  
    ByVal IdIn As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IFace  
Dim IdIn As System.Integer  
  
instance.SetFaceId(IdIn)
```

C#

```
void SetFaceId(  
    System.int IdIn  
)
```

C++/CLI

```
void SetFaceId(  
&    System.int IdIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

IdIn

Visual Basic for Applications (VBA) Syntax

See [Face::SetFaceId](#).

See Also

[IFace Interface](#)
[IFace Members](#)