

SOLIDWORKS API (.NET VBA C#) — Reference (107/337): IFace2 (part 3 of 3)

SOLIDWORKS API Documentation (converted from CHM)

IFace2 (part 3 of 3) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ImprintCurveCount Method (IFace2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : ImprintCurveCount Method (IFace2)

Gets the number of new edges and faces to create when imprinting a curve.

.NET Syntax

Visual Basic (Declaration)

```
Sub ImprintCurveCount( _  
    ByVal Curve As Curve, _  
    ByRef NewEdgeCount As System.Integer, _  
    ByRef NewFaceCount As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IFace2  
Dim Curve As Curve  
Dim NewEdgeCount As System.Integer  
Dim NewFaceCount As System.Integer  
  
instance.ImprintCurveCount(Curve, NewEdgeCount, NewFaceCount)
```

C#

```
void ImprintCurveCount(  
    Curve Curve,  
    out System.int NewEdgeCount,  
    out System.int NewFaceCount  
)
```

C++/CLI

```
void ImprintCurveCount(  
& Curve^ Curve,  
& [Out] System.int NewEdgeCount,  
& [Out] System.int NewFaceCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Curve

Pointer to the [curve](#)

NewEdgeCount

Number of new edges to create when imprinting this curve

NewFaceCount

Number of new faces to create when imprinting this curve

Visual Basic for Applications (VBA) Syntax

See [Face2::ImprintCurveCount](#).

Remarks

Call this method before calling [IFace2::ImprintCurve](#) to get the size of the edges and faces arrays.

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IFace2::ImprintCurve Method](#)

Availability

SOLIDWORKS 2004 SP2, Revision Number 12.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

INormal Property (IFace2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : INormal Property (IFace2)

Gets the unit normal vector for any planar face.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property INormal As System.Double
```

Visual Basic (Usage)



```
Dim instance As IFace2  
Dim value As System.Double  
  
instance.INormal = value  
  
value = instance.INormal
```

C#

```
System.double INormal {get; set;}
```

C++/CLI

```
property System.double INormal {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pointer to an array of 3 doubles (i,j,k)

Visual Basic for Applications (VBA) Syntax

See [Face2::INormal](#).

Remarks

This property is read-only.

If the face is not a planar face, then this property returns 0,0,0.

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IFace2::Normal Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IRemoveInnerLoops Method (IFace2)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > [IFace2 Interface](#) : IRemoveInnerLoops Method (IFace2)

Removes the inner loops on this face if the face is from a sheet (surface) body.

.NET Syntax

Visual Basic (Declaration)

```
Function IRemoveInnerLoops( _  
    ByVal NumOfLoops As System.Integer, _  
    ByRef InnerLoopsIn As Loop2 _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As IFace2  
Dim NumOfLoops As System.Integer  
Dim InnerLoopsIn As Loop2  
Dim value As Face2  
  
value = instance.IRemoveInnerLoops(NumOfLoops, InnerLoopsIn)
```

C#

```
Face2 IRemoveInnerLoops(  
    System.int NumOfLoops,  
    ref Loop2 InnerLoopsIn  
)
```

C++/CLI

```
Face2^ IRemoveInnerLoops(  
& System.int NumOfLoops,  
& Loop2^% InnerLoopsIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumOfLoops

Number of loops to remove

InnerLoopsIn

Pointer to an array of the inner [loops](#) to be removed

Return Value

Pointer to the resulting [face](#)

Visual Basic for Applications (VBA) Syntax

See [Face2::IRemoveInnerLoops](#).

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IFace2::RemoveInnerLoops Method](#)
[IFace2::EnumLoops Method](#)
[IFace2::GetFirstLoop Method](#)
[IFace2::GetLoopCount Method](#)
[IFace2::IGetFirstLoop Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IRemoveMaterialProperty2 Method (IFace2)

[See Also](#)



Removes the material property values from this face.

.NET Syntax

Visual Basic (Declaration)

```
Function IRemoveMaterialProperty2( _
    ByVal Config\_opt As System.Integer, _
    ByVal Config\_count As System.Integer, _
    ByRef Config\_names As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFace2
Dim Config_opt As System.Integer
Dim Config_count As System.Integer
Dim Config_names As System.String
Dim value As System.Boolean

value = instance.IRemoveMaterialProperty2(Config_opt, Config_count, Config_names)
```

C#

```
System.bool IRemoveMaterialProperty2(
    System.int Config\_opt,
    System.int Config\_count,
    ref System.string Config\_names
)
```

C++/CLI

```
System.bool IRemoveMaterialProperty2(
    & System.int Config\_opt,
    & System.int Config\_count,
    & System.String^% Config\_names
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Config_opt
Configuration option as defined in [swInConfigurationOpts_e](#)
Config_count
Number of configurations
Config_names
Array of configuration names

Return Value

True if material property values are removed, false if not

Visual Basic for Applications (VBA) Syntax

See [Face2::IRemoveMaterialProperty2](#).

Remarks

This method is intended to be used on faces with changed material properties, for example, color.

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IFace2::GetMaterialPropertyValues2 Method](#)
[IFace2::IGetMaterialPropertyValues2 Method](#)
[IFace2::IRemoveMaterialProperty2 Method](#)
[IFace2::ISetMaterialPropertyValues2 Method](#)
[IFace2::SetMaterialPropertyValues2 Method](#)
[IComponent2::IRemoveMaterialProperty2 Method](#)
[IComponent2::RemoveMaterialProperty2 Method](#)

[IFeature::IRemoveMaterialProperty2 Method](#)
[IFeature::RemoveMaterialProperty2 Method](#)
[IModelDocExtension::IRemoveMaterialProperty Method](#)
[IModelDocExtension::RemoveMaterialProperty Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IRverseEvaluate Method (IFace2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : IRverseEvaluate Method (IFace2)

Gets the UV parameters for the given XYZ location on this face.

.NET Syntax

Visual Basic (Declaration)

```
Function IRverseEvaluate( _  
    ByVal PositionX As System.Double, _  
    ByVal PositionY As System.Double, _  
    ByVal PositionZ As System.Double _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IFace2  
Dim PositionX As System.Double  
Dim PositionY As System.Double  
Dim PositionZ As System.Double  
Dim value As System.Double  
  
value = instance.IRverseEvaluate(PositionX, PositionY, PositionZ)
```

C#

```
System.double IRverseEvaluate(  
    System.double PositionX,  
    System.double PositionY,  
    System.double PositionZ  
)
```

C++/CLI

```
System.double IRverseEvaluate(  
& System.double PositionX,  
& System.double PositionY,  
& System.double PositionZ  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PositionX
X coordinate of this location on the face
PositionY
Y coordinate of this location on the face
PositionZ
Z coordinate of this location on the face

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles for the U and V parameters
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

This method returns corrected UV parameters for periodic surfaces; thus, you should use this method when dealing with periodic surfaces.

For example, you can have a cylindrical surface that extends from 0 to 2pi in the Udir. The face related to this surface in some cases extends from 0 to pi, then from 0 to pi again. In this case, neither [ISurface::IReverseEvaluate](#) nor [ISurface::ReverseEvaluate](#) will work for values greater than pi (the returned U value will be greater than Maximum U for the face). However, [IFace2::IReverseEvaluate](#), and [IFace2::ReverseEvaluate](#), will return the correct values.

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[ICurve::ReverseEvaluate Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsCoincident Method (IFace2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : IsCoincident Method (IFace2)

Gets whether this face and the specified face, which is located on a different body, are coincident.

.NET Syntax

Visual Basic (Declaration)

```
Function IsCoincident( _  
    ByVal FaceIn As System.Object, _  
    ByVal Tolerance As System.Double _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFace2  
Dim FaceIn As System.Object  
Dim Tolerance As System.Double  
Dim value As System.Integer  
  
value = instance.IsCoincident(FaceIn, Tolerance)
```

C#

```
System.int IsCoincident(  
    System.object FaceIn,  
    System.double Tolerance  
)
```

C++/CLI

```
System.int IsCoincident(  
& System.Object^ FaceIn,  
& System.double Tolerance  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceIn
[Face](#) located on a different body
Tolerance
Tolerance

Return Value

Result as defined in [swFaceCoincidentResult_e](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Face2::IsCoincident](#).

Remarks

For two faces to be considered coincident, they must have similar corresponding loops and all points on one face must be within the specified tolerance of the other face, and vice versa.

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IFace2::IsCoincident Method](#)

Availability

SOLIDWORKS 2007 SP3, Revision Number 15.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetMaterialPropertyValues2 Method (IFace2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : ISetMaterialPropertyValues2 Method (IFace2)

Sets the material property values for this face.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetMaterialPropertyValues2( _  
    ByRef Material\_values As System.Double, _  
    ByVal Config\_opt As System.Integer, _  
    ByVal Config\_count As System.Integer, _  
    ByRef Config\_names As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IFace2  
Dim Material_values As System.Double  
Dim Config_opt As System.Integer  
Dim Config_count As System.Integer  
Dim Config_names As System.String  
  
instance.ISetMaterialPropertyValues2(Material_values, Config_opt, Config_count, Config_names)
```

C#

```
void ISetMaterialPropertyValues2(  
    ref System.double Material\_values,  
    System.int Config\_opt,  
    System.int Config\_count,  
    ref System.string Config\_names  
)
```

C++/CLI

```
void ISetMaterialPropertyValues2(  
& System.double% Material\_values,  
& System.int Config\_opt,  
& System.int Config\_count,  
& System.String^% Config\_names  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Material_values

Array of doubles of size 9 (see **Remarks**)

Config_opt

Configuration option as defined in [swlnConfigurationOpts_e](#)

Config_count

Number of configurations

Config_names

- In-process, unmanaged C++: Pointer to an array of configuration names of size *Config_count*
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

The material property values include the color (R,G,B values), reflectivity (ambient, diffuse, specular, shininess), transparency, and emission.

The format of the *Material_values* array of doubles is:

[*R*, *G*, *B*, *Ambient*, *Diffuse*, *Specular*, *Shininess*, *Transparency*, *Emission*]

To see a color change, you must:

1. Specify *R*, *G*, and *B*, each with a value between 0.0 and 1.0, inclusive. (These values are internally multiplied by 255.0 to determine the RGB color.)
2. Specify the reflectivity properties (*Diffuse*, *Specular*, *Shininess* (1.0 - Specular spread/Blurriness)), each with a value greater than 0.0 and less than or equal to 1.0.
3. Specify *Ambient*, *Transparency* and *Emission*, each with a value between 0.0 and 1.0, inclusive.
4. Refresh the graphics area after calling this method.

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IFace2::SetMaterialPropertyValues2 Method](#)
[IFace2::MaterialPropertyValues Property](#)
[IFace2::IMaterialPropertyValues Property](#)
[IFace2::RemoveMaterialProperty2 Method](#)
[IFace2::IRemoveMaterialProperty2 Method](#)
[IFace2::IMaterialPropertyValues2 Method](#)
[IFace2::GetMaterialPropertyValues2 Method](#)
[IComponent2::SetMaterialPropertyValues2 Method](#)
[IComponent2::SetMaterialPropertyValues2 Method](#)
[IFeature::SetMaterialPropertyValues2 Method](#)
[IFeature::SetMaterialPropertyValues2 Method](#)
[IModelDocExtension::SetMaterialPropertyValues Method](#)
[IModelDocExtension::SetMaterialPropertyValues Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsSame Method (IFace2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : IsSame Method (IFace2)

Gets whether the two faces are the same.

.NET Syntax

Visual Basic (Declaration)

```
Function IsSame( _  
    ByVal FaceIn As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFace2  
Dim FaceIn As System.Object  
Dim value As System.Boolean  
  
value = instance.IsSame(FaceIn)
```

C#

```
System.bool IsSame(  
    System.object FaceIn  
)
```

C++/CLI

```
System.bool IsSame(  
& System.Object^ FaceIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceIn

[Face](#) to which to compare this face

Return Value

True if the two faces are the same, false if they are different

Visual Basic for Applications (VBA) Syntax

See [Face2::IsSame](#).

Example

[Get Gusset Feature Data \(C#\)](#)
[Get Gusset Feature Data \(VB.NET\)](#)
[Get Gusset Feature Data \(VBA\)](#)

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IFace2::IsSame Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

MaterialIdName Property (IFace2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : MaterialIdName Property (IFace2)

Gets or sets the material name.

.NET Syntax

Visual Basic (Declaration)

```
Property MaterialIdName As System.String
```

Visual Basic (Usage)



```
Dim instance As IFace2  
Dim value As System.String  
  
instance.MaterialIdName = value  
  
value = instance.MaterialIdName
```

C#

```
System.string MaterialIdName {get; set;}
```

C++/CLI

```
property System.String^ MaterialIdName {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Material name

 Visual Basic for Applications (VBA) Syntax

See [Face2::MaterialIdName](#).

 Remarks

This property is unsupported for faces obtained from reference surface bodies.

 See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IModelDoc2::MaterialIdName Property](#)
[IPartDoc::MaterialIdName Property](#)
[IFace2::MaterialUserName Property](#)

 Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MaterialPropertyValues Property (IFace2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : MaterialPropertyValues Property (IFace2)

Gets or sets the material properties for the selected face in the active configuration.

 .NET Syntax

Visual Basic (Declaration)

```
Property MaterialPropertyValues As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace2  
Dim value As System.Object  
  
instance.MaterialPropertyValues = value  
value = instance.MaterialPropertyValues
```

C#

```
System.object MaterialPropertyValues {get; set;}
```

C++/CLI

```
property System.Object^ MaterialPropertyValues {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of doubles describing the material values on this face (see **Remarks**)

 Visual Basic for Applications (VBA) Syntax

See [Face2::MaterialPropertyValues](#).

 Example

Remarks

The material values include the face color (R,G,B values), reflectivity (ambient, diffuse, specular, shininess), transparency and emission. All values can be from 0 to 1.

This method returns a NULL VARIANT (or an S_false HRESULT for COM implementations) if this face has not been explicitly modified from the material property values of the body. If you create a body and change the body color to red, then [IFace2::IGetMaterialPropertyValues2](#) and [IFace2::GetMaterialPropertyValues2](#) return a NULL array because you did not specifically change the values of the face.

The format of the parameters or return values is an array of doubles as follows:

[*R, G, B, Ambient, Diffuse, Specular, Shininess, Transparency, Emission*]

To see a color change, you must:

1. Specify *R, G, and B*, each with a value between 0.0 and 1.0, inclusive. (These values are internally multiplied by 255.0 to determine the RGB color.)
2. Specify the reflectivity properties (*Diffuse, Specular, Shininess* (1.0 - Specular spread/Blurriness)), each with a value greater than 0.0 and less than or equal to 1.0.
3. Specify *Ambient, Transparency* and *Emission*, each with a value between 0.0 and 1.0, inclusive.
4. Refresh the graphics area after setting this property.

To reset the face to use the default part material properties, use [IModelDoc2::SelectedFaceProperties](#).

This method does not support faces obtained from reference surface bodies.

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IFace2::IMaterialPropertyValues Property](#)
[IFace2::SetMaterialPropertyValues2 Method](#)
[IFace2::RemoveMaterialProperty2 Method](#)
[IFace2::ISetMaterialPropertyValues2 Method](#)
[IFace2::IRemoveMaterialProperty2 Method](#)
[IBody2::IMaterialPropertyValues2 Property](#)
[IBody2::MaterialPropertyValues2 Property](#)
[IComponent2::IMaterialPropertyValues Property](#)
[IComponent2::MaterialPropertyValues Property](#)
[IModelDoc2::IMaterialPropertyValues Property](#)
[IModelDoc2::MaterialPropertyValues Property](#)
[IPartDoc::IMaterialPropertyValues Property](#)
[IPartDoc::MaterialPropertyValues Property](#)
[IFace2::HasMaterialPropertyValues Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MaterialUserName Property (IFace2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : MaterialUserName Property (IFace2)

Gets or sets the material name, which is visible to the user.

NET Syntax

Visual Basic (Declaration)

```
Property MaterialUserName As System.String
```

Visual Basic (Usage)



```
Dim instance As IFace2  
Dim value As System.String  
  
instance.MaterialUserName = value  
  
value = instance.MaterialUserName
```

C#

```
System.string MaterialUserName {get; set;}
```

C++/CLI

```
property System.String^ MaterialUserName {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Material user name property on the face

Visual Basic for Applications (VBA) Syntax

See [Face2::MaterialUserName](#).

Remarks

This property is not supported for faces obtained from reference surface bodies.

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IFace2::MaterialIdName Property](#)
[IModelDoc2::MaterialUserName Property](#)
[IPartDoc::MaterialUserName Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Normal Property (IFace2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : Normal Property (IFace2)

Gets the unit normal vector for any planar face.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property Normal As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace2
Dim value As System.Object

instance.Normal = value

value = instance.Normal
```

C#

```
System.object Normal {get; set;}
```

C++/CLI

```
property System.Object^ Normal {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of 3 doubles (i,j,k)

Visual Basic for Applications (VBA) Syntax

See [Face2::Normal](#).

Example

[Get Normal of Planar Face \(VBA\)](#)
[Get Normal of Planar Surface \(VBA\)](#)
[Get Plane or Face for Sketch \(VBA\)](#)

Remarks

If the face is not a planar face, then this property returns 0,0,0.

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IFace2::INormal Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveFaceId Method (IFace2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : RemoveFaceId Method (IFace2)

Removes the face ID on an imported body.

.NET Syntax

Visual Basic (Declaration)

```
Sub RemoveFaceId( _  
    ByVal IdIn As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IFace2  
Dim IdIn As System.Integer  
  
instance.RemoveFaceId(IdIn)
```

C#

```
void RemoveFaceId(  
    System.int IdIn  
)
```

C++/CLI

```
void RemoveFaceId(  
& System.int IdIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

IdIn
Face ID

Visual Basic for Applications (VBA) Syntax

See [Face2::RemoveFaceld](#).

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IFace2::SetFaceld Method](#)
[IFace2::GetFaceld Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

RemoveInnerLoops Method (IFace2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : RemoveInnerLoops Method (IFace2)

Removes the inner loops on this face if the face is from a sheet (surface) body.

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveInnerLoops( _  
    ByVal NumOfLoops As System.Integer, _  
    ByVal InnerLoopsIn As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace2  
Dim NumOfLoops As System.Integer  
Dim InnerLoopsIn As System.Object  
Dim value As System.Object  
  
value = instance.RemoveInnerLoops(NumOfLoops, InnerLoopsIn)
```

C#

```
System.object RemoveInnerLoops(  
    System.int NumOfLoops,  
    System.object InnerLoopsIn  
)
```

C++/CLI

```
System.Object^ RemoveInnerLoops(  
& System.int NumOfLoops,  
& System.Object^ InnerLoopsIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumOfLoops
Number of loops to remove

InnerLoopsIn
Array of the inner loops to remove

Return Value

Resulting [face](#)

Visual Basic for Applications (VBA) Syntax

See [Face2::RemoveInnerLoops](#).

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IFace2::!RemoveInnerLoops Method](#)
[IFace2::EnumLoops Method](#)
[IFace2::GetFirstLoop Method](#)
[IFace2::GetLoopCount Method](#)
[IFace2::!GetFirstLoop Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveMaterialProperty Method (IFace2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : RemoveMaterialProperty Method (IFace2)

Obsolete. Superseded by [IFace2::RemoveMaterialProperty2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveMaterialProperty() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFace2  
Dim value As System.Boolean  
  
value = instance.RemoveMaterialProperty()
```

C#

```
System.bool RemoveMaterialProperty()
```

C++/CLI

```
System.bool RemoveMaterialProperty();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face2::RemoveMaterialProperty](#).

See Also

[IFace2 Interface](#)
[IFace2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveMaterialProperty2 Method (IFace2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : RemoveMaterialProperty2 Method (IFace2)

Removes the material property values from this face.

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveMaterialProperty2( _  
    ByVal Config\_opt As System.Integer, _  
    ByVal Config\_names As System.Object _  
) As System.Boolean
```

```
Dim instance As IFace2
Dim Config_opt As System.Integer
Dim Config_names As System.Object
Dim value As System.Boolean

value = instance.RemoveMaterialProperty2(Config_opt, Config_names)
```

C#

```
System.bool RemoveMaterialProperty2(
    System.int Config\_opt,
    System.object Config\_names
)
```

C++/CLI

```
System.bool RemoveMaterialProperty2(
    & System.int Config\_opt,
    & System.Object^ Config\_names
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Config_opt

Configuration option as defined in [swlnConfigurationOpts_e](#)

Config_names

Array of configuration names

Return Value

True if material property values are removed, false if not

Visual Basic for Applications (VBA) Syntax

See [Face2::RemoveMaterialProperty2](#).

Remarks

This method is intended to be used on faces with changed material properties, for example, color.

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IFace2::IRemoveMaterialProperty2 Method](#)
[IFace2::IMaterialPropertyValues Property](#)
[IFace2::MaterialPropertyValues Property](#)
[IFace2::GetMaterialPropertyValues2 Method](#)
[IFace2::IMaterialPropertyValues2 Method](#)
[IFace2::IMaterialPropertyValues2 Method](#)
[IFace2::SetMaterialPropertyValues2 Method](#)
[IFace2::SetMaterialPropertyValues2 Method](#)
[IComponent2::IRemoveMaterialProperty2 Method](#)
[IComponent2::RemoveMaterialProperty2 Method](#)
[IFeature::IRemoveMaterialProperty2 Method](#)
[IFeature::RemoveMaterialProperty2 Method](#)
[IModelDocExtension::IRemoveMaterialProperty Method](#)
[IModelDocExtension::RemoveMaterialProperty Method](#)
[IFace2::HasMaterialPropertyValues Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

RemoveRedundantTopology Method (IFace2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : RemoveRedundantTopology Method (IFace2)

Removes redundant topology from the face.

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveRedundantTopology() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFace2  
Dim value As System.Boolean  
  
value = instance.RemoveRedundantTopology()
```

C#

```
System.bool RemoveRedundantTopology()
```

C++/CLI

```
System.bool RemoveRedundantTopology();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the redundant topology was removed, false if not

Visual Basic for Applications (VBA) Syntax

See [Face2::RemoveRedundantTopology](#).

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IEdge::RemoveRedundantTopology Method](#)
[IBody2::RemoveRedundantTopology Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveTexture Method (IFace2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : RemoveTexture Method (IFace2)

Obsolete. Superseded by [IFace2::RemoveTexture2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveTexture( _  
    ByVal Config\_name As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFace2  
Dim Config_name As System.String  
Dim value As System.Boolean  
  
value = instance.RemoveTexture(Config_name)
```

C#

```
System.bool RemoveTexture(  
    System.string Config\_name  
)
```

C++/CLI

```
System.bool RemoveTexture(  
& System.String^ Config\_name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Config_name
Name of the configuration

Return Value

True if texture is removed, false if not

Visual Basic for Applications (VBA) Syntax

See [Face2::RemoveTexture](#).

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IFace2::GetTexture Method](#)
[IFace2::SetTexture Method](#)
[IFace2::RemoveTextureByDisplayState Method](#)
[IFace2::SetTextureByDisplayState Method](#)
[IModelDocExtension::CreateTexture Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

RemoveTexture2 Method (IFace2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : RemoveTexture2 Method (IFace2)

Removes the texture applied to this face in the specified configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveTexture2( _  
    ByVal Config\_name As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFace2  
Dim Config_name As System.String  
Dim value As System.Boolean  
  
value = instance.RemoveTexture2(Config_name)
```

C#

```
System.bool RemoveTexture2(  
    System.string Config\_name  
)
```

C++/CLI

```
System.bool RemoveTexture2(  
& System.String^ Config\_name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Config_name

Name of the configuration

Return Value

True if texture is removed, false if not

Visual Basic for Applications (VBA) Syntax

See [Face2::RemoveTexture2](#).

Example

[Apply and Remove Texture \(VBA\)](#)
[Apply and Remove Texture \(VB.NET\)](#)
[Apply and Remove Texture \(C#\)](#)

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IFace2::GetTexture Method](#)
[IFace2::SetTexture Method](#)
[IFace2::SetTextureByDisplayState Method](#)
[IFace2::RemoveTextureByDisplayState Method](#)
[IModelDocExtension::CreateTexture Method](#)
[IModelDocExtension::RemoveTexture2 Method](#)
[IFace2::HasTextureCoordinates Method \(\)](#)

Availability

SOLIDWORKS 2013 SP02, Revision Number 21.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveTextureByDisplayState Method (IFace2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : RemoveTextureByDisplayState Method (IFace2)

Removes the texture applied to this face in the specified display state.

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveTextureByDisplayState( _  
    ByVal DisplayStateName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFace2  
Dim DisplayStateName As System.String  
Dim value As System.Boolean  
  
value = instance.RemoveTextureByDisplayState(DisplayStateName)
```

C#

```
System.bool RemoveTextureByDisplayState(  
    System.string DisplayStateName  
)
```

C++/CLI

```
System.bool RemoveTextureByDisplayState(  
    & System.String^ DisplayStateName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayStateName
Display state name

Return Value

True if the texture is removed, false if not

Visual Basic for Applications (VBA) Syntax

See [Face2::RemoveTextureByDisplayState](#).

Example

[Apply and Remove Texture By Display State \(C#\)](#)
[Apply and Remove Texture By Display State \(VB.NET\)](#)
[Apply and Remove Texture By Display State \(VBA\)](#)

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IFace2::SetTextureByDisplayState Method](#)
[IFace2::SetTexture Method](#)
[IFace2::RemoveTexture Method](#)
[IFace2::GetTexture Method](#)
[IModelDocExtension::CreateTexture Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveTrackingID Method (IFace2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : RemoveTrackingID Method (IFace2)

Removes a [tracking ID assigned to this face](#).

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveTrackingID(  
    ByVal TrackingCookie As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFace2  
Dim TrackingCookie As System.Integer  
Dim value As System.Integer  
  
value = instance.RemoveTrackingID(TrackingCookie)
```

C#

```
System.int RemoveTrackingID(  
    System.int TrackingCookie  
)
```

C++/CLI

```
System.int RemoveTrackingID(  
&    System.int TrackingCookie  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TrackingCookie
Cookie obtained from [ISldWorks::RegisterTrackingDefinition](#)

Return Value

Status as defined by [swTrackingIDError_e](#)

Visual Basic for Applications (VBA) Syntax

See [Face2::RemoveTrackingID](#).

Example

[Get, Set, and Remove Tracking IDs on Face \(VBA\)](#)

Remarks

See [Tracking IDs](#) for more information.

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IFace2::GetTrackingIDs Method](#)
[IFace2::SetTrackingID Method](#)
[IFace2::GetTrackingIDsCount Method](#)
[IFace2::IGetTrackingIDs Method](#)
[IModelDocExtension::FindTrackedObjects Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ResetPropertyExtension Method (IFace2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : ResetPropertyExtension Method (IFace2)

Clears all values stored in the property extension.

.NET Syntax

Visual Basic (Declaration)

```
Sub ResetPropertyExtension()
```

Visual Basic (Usage)



```
Dim instance As IFace2  
instance.ResetPropertyExtension()
```

C#

```
void ResetPropertyExtension()
```

C++/CLI

```
void ResetPropertyExtension();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Face2::ResetPropertyExtension](#).

Remarks

This method is unsupported for faces obtained from reference surface bodies.

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IFace2::AddPropertyExtension Method](#)
[IFace2::GetPropertyExtension Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReverseEvaluate Method (IFace2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : ReverseEvaluate Method (IFace2)

Gets the UV parameters for the given XYZ location on this face.

.NET Syntax

Visual Basic (Declaration)

```
Function ReverseEvaluate( _  
    ByVal PositionX As System.Double, _  
    ByVal PositionY As System.Double, _  
    ByVal PositionZ As System.Double _  
    ) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFace2  
Dim PositionX As System.Double  
Dim PositionY As System.Double  
Dim PositionZ As System.Double  
Dim value As System.Object  
  
value = instance.ReverseEvaluate(PositionX, PositionY, PositionZ)
```

C#

```
System.object ReverseEvaluate(  
    System.double PositionX,  
    System.double PositionY,  
    System.double PositionZ  
)
```

C++/CLI

```
System.Object^ ReverseEvaluate(  
& System.double PositionX,  
& System.double PositionY,  
& System.double PositionZ  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PositionX
X coordinate of this location on the face
PositionY
Y coordinate of this location on the face
PositionZ
Z coordinate of this location on the face

Return Value

Array of two doubles representing the U and V parameters of this location on the face

Visual Basic for Applications (VBA) Syntax

See [Face2::ReverseEvaluate](#).

Example

[Get UV Parameters for XYZ Location \(VBA\)](#)
[Get UV Parameters for XYZ Location \(VB.NET\)](#)
[Get UV Parameters for XYZ Location \(C#\)](#)

Remarks

This method returns corrected UV parameters for periodic surfaces; thus, you should use this method when dealing with periodic surfaces.

For example, you can have a cylindrical surface that extends from 0 to 2pi in the Udir. The face related to this surface in some cases extends from 0 to pi, then from 0 to pi again. In this case, neither [ISurface::IReverseEvaluate](#) nor [ISurface::ReverseEvaluate](#) will work for values greater than pi (the returned U value will be greater than Maximum U for the face). However, [IFace2::IReverseEvaluate](#), and [IFace2::ReverseEvaluate](#), will return the correct values.

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[ICurve::ReverseEvaluate Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetFaceId Method (IFace2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : SetFaceId Method (IFace2)

Sets the face ID on an imported body.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetFaceId( _  
    ByVal IdIn As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IFace2  
Dim IdIn As System.Integer  
  
instance.SetFaceId(IdIn)
```

C#

```
void SetFaceId(  
    System.int IdIn  
)
```

C++/CLI

```
void SetFaceId(  
    & System.int IdIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

IdIn
Face ID

Visual Basic for Applications (VBA) Syntax

See [Face2::SetFaceId](#).

Remarks

SOLIDWORKS uses face IDs to track specific faces of imported bodies (for example, IGES imports).

Prior to setting a face ID, you should examine all faces in the model to [get their face IDs](#), if any, to ensure that the face ID you are setting is unique to the model.

Face IDs are saved with the document, but face IDs are removed whenever the document is rebuilt. Typically you assign face IDs to a read-only copy of the finalized model.

Any third-party application can change a face ID. The intent is that you assign face IDs so that you can refer to those faces within your application.

To store data with a face, use the [Attribute](#) object.

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IFace2::RemoveFaceId Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetMaterialPropertyValues2 Method (IFace2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : SetMaterialPropertyValues2 Method (IFace2)

Sets the material property values for this face.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetMaterialPropertyValues2( _  
    ByVal Material\_values As System.Object, _  
    ByVal Config\_opt As System.Integer, _  
    ByVal Config\_names As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IFace2  
Dim Material_values As System.Object  
Dim Config_opt As System.Integer  
Dim Config_names As System.Object  
  
instance.SetMaterialPropertyValues2(Material_values, Config_opt, Config_names)
```

C#

```
void SetMaterialPropertyValues2(  
    System.object Material\_values,  
    System.int Config\_opt,  
    System.object Config\_names  
)
```

C++/CLI

```
void SetMaterialPropertyValues2(  
& System.Object^ Material\_values,  
& System.int Config\_opt,  
& System.Object^ Config\_names  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Material_values

Array of material property values (see **Remarks**)

Config_opt

Configuration option as defined in [swInConfigurationOpts_e](#)

Config_names

Array of configuration names

Visual Basic for Applications (VBA) Syntax

See [Face2::SetMaterialPropertyValues2](#).

Remarks

The material property values include the color (R,G,B values), reflectivity (ambient, diffuse, specular, shininess), transparency, and emission.

The format of the Material_values array is:

[*R*, *G*, *B*, *Ambient*, *Diffuse*, *Specular*, *Shininess*, *Transparency*, *Emission*]

To see a color change, you must:

1. Specify *R*, *G*, and *B*, each with a value between 0.0 and 1.0, inclusive. (These values are internally multiplied by 255.0 to determine the RGB color.)
2. Specify the reflectivity properties (*Diffuse*, *Specular*, *Shininess* (1.0 - Specular spread/Blurriness)), each with a value greater than 0.0 and less than or equal to 1.0.
3. Specify *Ambient*, *Transparency* and *Emission*, each with a value between 0.0 and 1.0, inclusive.
4. Refresh the graphics area after calling this method.

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IFace2::SetMaterialPropertyValues2 Method](#)
[IFace2::IMaterialPropertyValues Property](#)
[IFace2::MaterialPropertyValues Property](#)
[IFace2::RemoveMaterialProperty2 Method](#)
[IFace2::IRemoveMaterialProperty2 Method](#)
[IFace2::IMaterialPropertyValues2 Method](#)
[IFace2::GetMaterialPropertyValues2 Method](#)
[IComponent2::SetMaterialPropertyValues2 Method](#)
[IComponent2::SetMaterialPropertyValues2 Method](#)
[IFeature::SetMaterialPropertyValues2 Method](#)
[IFeature::SetMaterialPropertyValues2 Method](#)
[IModelDocExtension::SetMaterialPropertyValues Method](#)
[IModelDocExtension::SetMaterialPropertyValues Method](#)
[IFace2::HasMaterialPropertyValues Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTexture Method (IFace2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : SetTexture Method (IFace2)

Applies texture to this face in the specified configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function SetTexture( _  
    ByVal Config\_name As System.String, _  
    ByVal TextureIn As Texture _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFace2  
Dim Config_name As System.String  
Dim TextureIn As Texture  
Dim value As System.Boolean
```

```
value = instance.SetTexture(Config_name, TextureIn)
```

C#

```
System.bool SetTexture(  
    System.string Config\_name,  
    Texture TextureIn  
)
```

C++/CLI

```
System.bool SetTexture(  
& System.String^ Config\_name,  
& Texture^ TextureIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Config_name
Name of configuration
TextureIn
[Texture](#)

Return Value

True if texture is applied, false if not

Visual Basic for Applications (VBA) Syntax

See [Face2::SetTexture](#).

Example

[Change Texture on Face in Specified Configuration \(VBA\)](#)
[Change Texture on Face in Specified Configuration \(VB.NET\)](#)
[Change Texture on Face in Specified Configuration \(C#\)](#)

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IFace2::GetTexture Method](#)
[IFace2::RemoveTexture Method](#)
[IModelDocExtension::CreateTexture Method](#)
[IFace2::SetTextureByDisplayState Method](#)
[IFace2::RemoveTextureByDisplayState Method](#)
[IFace2::HasTextureCoordinates Method \(\)](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetTextureByDisplayState Method (IFace2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : SetTextureByDisplayState Method (IFace2)

Applies texture to this face in the specified display state.

.NET Syntax

Visual Basic (Declaration)

```
Function SetTextureByDisplayState(  
    ByVal DisplayStateName As System.String, _  
    ByVal TextureIn As Texture _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IFace2  
Dim DisplayStateName As System.String  
Dim TextureIn As Texture
```



```
Dim value As System.Boolean
```

```
value = instance.SetTextureByDisplayState(DisplayStateName, TextureIn)
```

C#

```
System.bool SetTextureByDisplayState(  
    System.string DisplayStateName,  
    Texture TextureIn  
)
```

C++/CLI

```
System.bool SetTextureByDisplayState(  
& System.String^ DisplayStateName,  
& Texture^ TextureIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayStateName
Display state name
TextureIn
[Texture](#)

Return Value

True if texture applied to face, false if not

Visual Basic for Applications (VBA) Syntax

See [Face2::SetTextureByDisplayState](#).

Example

[Apply and Remove Texture By Display State \(C#\)](#)
[Apply and Remove Texture By Display State \(VB.NET\)](#)
[Apply and Remove Texture By Display State \(VBA\)](#)

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IFace2::RemoveTextureByDisplayState Method](#)
[IFace2::RemoveTexture Method](#)
[IFace2::SetTexture Method](#)
[IModelDocExtension::CreateTexture Method](#)
[IFace2::GetTexture Method](#)
[IFace2::HasTextureCoordinates Method \(\)](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetTrackingID Method (IFace2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFace2 Interface](#) : SetTrackingID Method (IFace2)

Assigns a tracking ID to this face.

.NET Syntax

Visual Basic (Declaration)

```
Function SetTrackingID( _  
    ByVal TrackingCookie As System.Integer, _  
    ByVal TrackingID As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```

Dim instance As IFace2
Dim TrackingCookie As System.Integer
Dim TrackingID As System.Integer
Dim value As System.Integer

value = instance.SetTrackingID(TrackingCookie, TrackingID)

```

C#

```

System.int SetTrackingID(
    System.int TrackingCookie,
    System.int TrackingID
)

```

C++/CLI

```

System.int SetTrackingID(
    & System.int TrackingCookie,
    & System.int TrackingID
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TrackingCookie
Cookie obtained from [ISldWorks::RegisterTrackingDefinition](#)
TrackingID
Application-defined value for the tracking ID

Value	Action
>0	Face is tracked
0	Tracking of face is stopped

Return Value

Status as defined by [swTrackingIDError_e](#)

Visual Basic for Applications (VBA) Syntax

See [Face2::SetTrackingID](#).

Example

[Get, Set, and Remove Tracking IDs on Face \(VBA\)](#)

Remarks

You can assign tracking IDs to [bodies](#), [edges](#), faces, [loops](#), and [vertices](#) in parts and assemblies only; you cannot assign tracking IDs to these entities in drawings. See [Tracking IDs](#) for more information.

See Also

[IFace2 Interface](#)
[IFace2 Members](#)
[IFace2::GetTrackingIDs Method](#)
[IFace2::RemoveTrackingID Method](#)
[IFace2::!GetTrackingIDs Method](#)
[IFace2::GetTrackingIDsCount Method](#)
[IModelDocExtension::FindTrackedObjects Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0