

SOLIDWORKS API (.NET VBA C#) — Reference

(108/337): IFaceDecalProperties- IFamilyTableAnnotation

SOLIDWORKS API Documentation (converted from CHM)

IFaceDecalProperties (Type)

IFaceDecalProperties Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFaceDecalProperties Interface

Allow access to the properties of [decals](#) applied to faces in models.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IFaceDecalProperties
```

Visual Basic (Usage)

```
Dim instance As IFaceDecalProperties
```

C#

```
public interface IFaceDecalProperties
```

C++/CLI

```
public interface class IFaceDecalProperties
```

Visual Basic for Applications (VBA) Syntax

See [FaceDecalProperties](#).

Example

[Add Decal \(C#\)](#)
[Add Decal \(VB.NET\)](#)
[Add Decal \(VBA\)](#)

Remarks

Accessors

[IFace2::GetAllAssemblyDecalProperties](#)
[IFace2::GetAllDecalProperties](#) and [IFace2::IGetAllDecalProperties](#)
[IFace2::IGetDecalProperties](#)

Access Diagram

[FaceDecalProperties](#)

See Also

[IFaceDecalProperties Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDecal Interface](#)
[IRenderMaterial Interface](#)

IFaceDecalProperties Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFaceDecalProperties Interface

The following tables list the members exposed by [IFaceDecalProperties](#).

Public Properties

Name	Description
 TextureAngle	Gets the angle of the texture of the decal.
 TextureAngleUV	Gets the UV angle of the texture of the decal.
 TextureFilename	Gets the file name of the texture of the decal.
 TextureFilenameID	Gets the ID of the texture file name of the decal.
 TextureID	Gets the ID of the texture of the decal.
 TextureMapID	Gets the map ID of the texture of the decal.
 TextureMirrored	Gets whether the texture of the decal is mirrored.
 TextureRenderMode	Gets the render mode of the texture of the decal.
 TextureTranslationU	Gets the translation of the decal texture in the U direction.
 TextureTranslationV	Gets the translation of the decal texture in the V direction.
 TextureTranslationX	Gets the translation of the decal texture in the X direction.
 TextureTranslationY	Gets the translation of the decal texture in the Y direction.
 TextureUScale	Gets the decal texture scale in the U direction.
 TextureVScale	Gets the decal texture scale in the V direction.

[Top](#)

See Also

[IFaceDecalProperties Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDecal Interface](#)
[IRenderMaterial Interface](#)

IFaceDecalProperties Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFaceDecalProperties Interface

For a list of all members of this type, see [IFaceDecalProperties members](#).

Public Properties		
Name	Description	
 TextureAngle	Gets the angle of the texture of the decal.	
 TextureAngleUV	Gets the UV angle of the texture of the decal.	
 TextureFilename	Gets the file name of the texture of the decal.	
 TextureFilenameID	Gets the ID of the texture file name of the decal.	
 TextureID	Gets the ID of the texture of the decal.	
 TextureMapID	Gets the map ID of the texture of the decal.	
 TextureMirrored	Gets whether the texture of the decal is mirrored.	
 TextureRenderMode	Gets the render mode of the texture of the decal.	
 TextureTranslationU	Gets the translation of the decal texture in the U direction.	
 TextureTranslationV	Gets the translation of the decal texture in the V direction.	
 TextureTranslationX	Gets the translation of the decal texture in the X direction.	
 TextureTranslationY	Gets the translation of the decal texture in the Y direction.	
 TextureUScale	Gets the decal texture scale in the U direction.	



[TextureVScale](#)

Gets the decal texture scale in the V direction.

[Top](#)

See Also

[IFaceDecalProperties Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDecal Interface](#)
[IRenderMaterial Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

TextureAngle Property (IFaceDecalProperties)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceDecalProperties Interface](#) : TextureAngle Property (IFaceDecalProperties)

Gets the angle of the texture of the decal.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property TextureAngle As System.Double

Visual Basic (Usage)



```
Dim instance As IFaceDecalProperties  
Dim value As System.Double  
  
value = instance.TextureAngle
```

C#

```
System.double TextureAngle {get;}
```

C++/CLI

```
property System.double TextureAngle {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle of the texture of the decal

Visual Basic for Applications (VBA) Syntax

See [FaceDecalProperties::TextureAngle](#).

Example

See [IFaceDecalProperties](#) examples.

See Also

[IFaceDecalProperties Interface](#)
[IFaceDecalProperties Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

TextureAngleUV Property (IFaceDecalProperties)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceDecalProperties Interface](#) : TextureAngleUV Property (IFaceDecalProperties)

Gets the UV angle of the texture of the decal.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property TextureAngleUV As System.Double
```

Visual Basic (Usage)



```
Dim instance As IFaceDecalProperties  
Dim value As System.Double  
  
value = instance.TextureAngleUV
```

C#

```
System.double TextureAngleUV {get;}
```

C++/CLI

```
property System.double TextureAngleUV {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

UV angle of the texture of the angle

Visual Basic for Applications (VBA) Syntax

See [FaceDecalProperties::TextureAngleUV](#).

Example

See [IFaceDecalProperties](#) examples.

See Also

[IFaceDecalProperties Interface](#)
[IFaceDecalProperties Members](#)
[IFaceDecalProperties::TextureTranslationU Property](#)
[IFaceDecalProperties::TextureTranslationV Property](#)
[IFaceDecalProperties::TextureUScale Property](#)
[IFaceDecalProperties::TextureVScale Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

TextureFilename Property (IFaceDecalProperties)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceDecalProperties Interface](#) : TextureFilename Property (IFaceDecalProperties)

Gets the file name of the texture of the decal.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property TextureFilename As System.String
```

Visual Basic (Usage)



```
Dim instance As IFaceDecalProperties  
Dim value As System.String
```

```
value = instance.TextureFilename
```

C#

```
System.string TextureFilename {get;}
```

C++/CLI

```
property System.String^ TextureFilename {  
    System.String^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Fully qualified path and file name of the texture

Visual Basic for Applications (VBA) Syntax

See [FaceDecalProperties::TextureFilename](#).

Example

See [IFaceDecalProperties](#) examples.

See Also

[IFaceDecalProperties Interface](#)
[IFaceDecalProperties Members](#)
[IFaceDecalProperties::TextureFilenameID Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TextureFilenameID Property (IFaceDecalProperties)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceDecalProperties Interface](#) : TextureFilenameID Property (IFaceDecalProperties)

Gets the ID of the texture file name of the decal.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property TextureFilenameID As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFaceDecalProperties  
Dim value As System.Integer
```

```
value = instance.TextureFilenameID
```

C#

```
System.int TextureFilenameID {get;}
```

C++/CLI

```
property System.int TextureFilenameID {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

ID of the texture file name

Visual Basic for Applications (VBA) Syntax

See [FaceDecalProperties::TextureFilenameID](#).

Example

See [IFaceDecalProperties](#) examples.

See Also

[IFaceDecalProperties Interface](#)
[IFaceDecalProperties Members](#)
[IFaceDecalProperties::TextureFilename Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TextureID Property (IFaceDecalProperties)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceDecalProperties Interface](#) : TextureID Property (IFaceDecalProperties)

Gets the ID of the texture of the decal.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property TextureID As System.Integer

Visual Basic (Usage)



```
Dim instance As IFaceDecalProperties  
Dim value As System.Integer
```

```
value = instance.TextureID
```

C#

```
System.int TextureID {get;}
```

C++/CLI

```
property System.int TextureID {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

ID of the texture of the decal

Visual Basic for Applications (VBA) Syntax

See [FaceDecalProperties::TextureID](#).

Example

See [IFaceDecalProperties](#) examples.

See Also

[IFaceDecalProperties Interface](#)
[IFaceDecalProperties Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TextureMapID Property (IFaceDecalProperties)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceDecalProperties Interface](#) : TextureMapID Property (IFaceDecalProperties)

Gets the map ID of the texture of the decal.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property TextureMapID As System.Integer

Visual Basic (Usage)



```
Dim instance As IFaceDecalProperties  
Dim value As System.Integer
```

```
value = instance.TextureMapID
```

C#

```
System.int TextureMapID {get;}
```

C++/CLI

```
property System.int TextureMapID {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Map ID of the texture of the decal

Visual Basic for Applications (VBA) Syntax

See [FaceDecalProperties::TextureMapID](#).

Example

See [IFaceDecalProperties](#) examples.

See Also

[IFaceDecalProperties Interface](#)
[IFaceDecalProperties Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TextureMirrored Property (IFaceDecalProperties)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceDecalProperties Interface](#) : TextureMirrored Property (IFaceDecalProperties)

Gets whether the texture of the decal is mirrored.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property TextureMirrored As System.Boolean

Visual Basic (Usage)



```
Dim instance As IFaceDecalProperties  
Dim value As System.Boolean
```

```
value = instance.TextureMirrored
```

C#

```
System.bool TextureMirrored {get;}
```

C++/CLI

```
property System.bool TextureMirrored {  
    System.bool get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the texture of the decal is mirrored, false if not

Visual Basic for Applications (VBA) Syntax

See [FaceDecalProperties::TextureMirrored](#).

Example

See [IFaceDecalProperties](#) examples.

See Also

[IFaceDecalProperties Interface](#)
[IFaceDecalProperties Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TextureRenderMode Property (IFaceDecalProperties)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceDecalProperties Interface](#) : TextureRenderMode Property (IFaceDecalProperties)

Gets the render mode of the texture of the decal.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property TextureRenderMode As System.Integer

Visual Basic (Usage)



```
Dim instance As IFaceDecalProperties  
Dim value As System.Integer
```

```
value = instance.TextureRenderMode
```

C#

```
System.int TextureRenderMode {get;}
```

C++/CLI

```
property System.int TextureRenderMode {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Render mode of the texture of the decal:

- 0 = Image
- 1 = Luminance

Visual Basic for Applications (VBA) Syntax

See [FaceDecalProperties::TextureRenderMode](#).

Example

See [IFaceDecalProperties](#) examples.

See Also

[IFaceDecalProperties Interface](#)
[IFaceDecalProperties Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TextureTranslationU Property (IFaceDecalProperties)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceDecalProperties Interface](#) : TextureTranslationU Property (IFaceDecalProperties)

Gets the translation of the decal texture in the U direction.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property TextureTranslationU As System.Double
```

Visual Basic (Usage)



```
Dim instance As IFaceDecalProperties
Dim value As System.Double
```

```
value = instance.TextureTranslationU
```

C#

```
System.double TextureTranslationU {get;}
```

C++/CLI

```
property System.double TextureTranslationU {
    System.double get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Translation of the decal texture in the U direction

Visual Basic for Applications (VBA) Syntax

See [FaceDecalProperties::TextureTranslationU](#).

Example

See [IFaceDecalProperties](#) examples.

See Also

[IFaceDecalProperties Interface](#)
[IFaceDecalProperties Members](#)
[IFaceDecalProperties::TextureAngleUV Property](#)
[IFaceDecalProperties::TextureTranslationV Property](#)
[IFaceDecalProperties::TextureUScale Property](#)
[IFaceDecalProperties::TextureVScale Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TextureTranslationV Property (IFaceDecalProperties)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceDecalProperties Interface](#) : TextureTranslationV Property (IFaceDecalProperties)

Gets the translation of the decal texture in the V direction.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property TextureTranslationV As System.Double
```

Visual Basic (Usage)



```
Dim instance As IFaceDecalProperties  
Dim value As System.Double  
  
value = instance.TextureTranslationV
```

C#

```
System.double TextureTranslationV {get;}
```

C++/CLI

```
property System.double TextureTranslationV {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Translation of the decal texture in the V direction

Visual Basic for Applications (VBA) Syntax

See [FaceDecalProperties::TextureTranslationV](#).

Example

See [IFaceDecalProperties](#) examples.

See Also

[IFaceDecalProperties Interface](#)
[IFaceDecalProperties Members](#)
[IFaceDecalProperties::TextureAngleUV Property](#)
[IFaceDecalProperties::TextureTranslationU Property](#)
[IFaceDecalProperties::TextureUScale Property](#)
[IFaceDecalProperties::TextureVScale Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TextureTranslationX Property (IFaceDecalProperties)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceDecalProperties Interface](#) : TextureTranslationX Property (IFaceDecalProperties)

Gets the translation of the decal texture in the X direction.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property TextureTranslationX As System.Double

Visual Basic (Usage)



```
Dim instance As IFaceDecalProperties  
Dim value As System.Double
```

```
value = instance.TextureTranslationX
```

C#

```
System.double TextureTranslationX {get;}
```

C++/CLI

```
property System.double TextureTranslationX {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Translation of the decal texture in the X direction

Visual Basic for Applications (VBA) Syntax

See [FaceDecalProperties::TextureTranslationX](#).

Example

See [IFaceDecalProperties](#) examples.

See Also

[IFaceDecalProperties Interface](#)
[IFaceDecalProperties Members](#)
[IFaceDecalProperties::TextureTranslationY Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TextureTranslationY Property (IFaceDecalProperties)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceDecalProperties Interface](#) : TextureTranslationY Property (IFaceDecalProperties)

Gets the translation of the decal texture in the Y direction.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property TextureTranslationY As System.Double

Visual Basic (Usage)



```
Dim instance As IFaceDecalProperties  
Dim value As System.Double
```

```
value = instance.TextureTranslationY
```

C#

```
System.double TextureTranslationY {get;}
```

C++/CLI

```
property System.double TextureTranslationY {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Translation of the decal texture in the Y direction

Visual Basic for Applications (VBA) Syntax

See [FaceDecalProperties::TextureTranslationY](#).

Example

See [IFaceDecalProperties](#) examples.

See Also

[IFaceDecalProperties Interface](#)
[IFaceDecalProperties Members](#)
[IFaceDecalProperties::TextureTranslationX Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TextureUScale Property (IFaceDecalProperties)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceDecalProperties Interface](#) : TextureUScale Property (IFaceDecalProperties)

Gets the decal texture scale in the U direction.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property TextureUScale As System.Double
```

Visual Basic (Usage)



```
Dim instance As IFaceDecalProperties  
Dim value As System.Double
```

```
value = instance.TextureUScale
```

C#

```
System.double TextureUScale {get;}
```

C++/CLI

```
property System.double TextureUScale {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Decal texture scale in the U direction

Visual Basic for Applications (VBA) Syntax

See [FaceDecalProperties::TextureUScale](#).

Example

See [IFaceDecalProperties](#) examples.

See Also

[IFaceDecalProperties Interface](#)
[IFaceDecalProperties Members](#)
[IFaceDecalProperties::TextureVScale Property](#)
[IFaceDecalProperties::TextureAngleUV Property](#)
[IFaceDecalProperties::TextureTranslationU Property](#)
[IFaceDecalProperties::TextureTranslationV Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

TextureVScale Property (IFaceDecalProperties)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceDecalProperties Interface](#) : TextureVScale Property (IFaceDecalProperties)

Gets the decal texture scale in the V direction.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property TextureVScale As System.Double
```

Visual Basic (Usage)



```
Dim instance As IFaceDecalProperties  
Dim value As System.Double  
  
value = instance.TextureVScale
```

C#

```
System.double TextureVScale {get;}
```

C++/CLI

```
property System.double TextureVScale {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Decal texture scale in the V direction

Visual Basic for Applications (VBA) Syntax

See [FaceDecalProperties::TextureVScale](#).

Example

See [IFaceDecalProperties](#) examples.

See Also

[IFaceDecalProperties Interface](#)
[IFaceDecalProperties Members](#)
[IFaceDecalProperties::TextureUScale Property](#)
[IFaceDecalProperties::TextureAngleUV Property](#)
[IFaceDecalProperties::TextureTranslationU Property](#)
[IFaceDecalProperties::TextureTranslationV Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

IFaceHatch (Type)

IFaceHatch Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFaceHatch Interface

Represents a cross-hatch, which is automatically added by SOLIDWORKS when you create a [section view](#), aligned section view, break view, or [detail view](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IFaceHatch
```

Visual Basic (Usage)



```
Dim instance As IFaceHatch
```

C#

```
public interface IFaceHatch
```

C++/CLI

```
public interface class IFaceHatch
```

Visual Basic for Applications (VBA) Syntax

See [FaceHatch](#).

Example

[Get Face Hatch Data \(C#\)](#)
[Get Face Hatch Data \(VB.NET\)](#)
[Get Face Hatch Data \(VBA\)](#)

Remarks

This interface is read-only.

Accessors

[IView::GetFaceHatches](#) and [IView::IGetFaceHatches](#)

Access Diagram

[FaceHatch](#)

See Also

[IFaceHatch Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISketchHatch Interface](#)

IFaceHatch Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFaceHatch Interface

The following tables list the members exposed by [IFaceHatch](#).

Public Properties

Name	Description
 Angle	Gets or sets the angle of the face hatch.
 Color	Gets the color of the face hatch. NOTE: This property is a get-only property. Set is not implemented.
 Definition	Gets the definition for the face hatch. NOTE: This property is a get-only property. Set is not implemented.
 Face	Gets the face that is associated with the hatch. NOTE: This property is a get-only property. Set is not implemented.
 HatchScope	Gets or sets the scope for this face hatch.
 HatchType	Gets or sets the type of this face hatch.
 Layer	Gets the drawing layer of the component to which the hatch is attached. NOTE: This property is a get-only property. Set is not implemented.
 Pattern	Gets the pattern for the face hatch. NOTE: This property is a get-only property. Set is not implemented.
 PatternId	Gets the pattern ID of this face hatch. Read-only.
 Scale	Obsolete. Superseded by IFaceHatch::Scale2 . NOTE: This property is a get-only property. Set is not implemented.
 Scale2	Gets or sets the scale for this face hatch.
 SolidFill	Gets whether the face hatch is a solid color. NOTE: This property is a get-only property. Set is not implemented.
 UseMaterialHatch	Gets or sets whether this face hatch uses material crosshatch.

[Top](#)

See Also

[IFaceHatch Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISketchHatch Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IFaceHatch Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFaceHatch Interface

For a list of all members of this type, see [IFaceHatch members](#).

Public Properties

Name	Description
 Angle	Gets or sets the angle of the face hatch.
 Color	Gets the color of the face hatch. NOTE: This property is a get-only property. Set is not implemented.
 Definition	Gets the definition for the face hatch. NOTE: This property is a get-only property. Set is not implemented.
 Face	Gets the face that is associated with the hatch. NOTE: This property is a get-only property. Set is not implemented.
HatchScope	Gets or sets the scope for this face hatch.

		
	HatchType	Gets or sets the type of this face hatch.
	Layer	Gets the drawing layer of the component to which the hatch is attached. NOTE: This property is a get-only property. Set is not implemented.
	Pattern	Gets the pattern for the face hatch. NOTE: This property is a get-only property. Set is not implemented.
	PatternId	Gets the pattern ID of this face hatch. Read-only.
	Scale	Obsolete. Superseded by IFaceHatch::Scale2 . NOTE: This property is a get-only property. Set is not implemented.
	Scale2	Gets or sets the scale for this face hatch.
	SolidFill	Gets whether the face hatch is a solid color. NOTE: This property is a get-only property. Set is not implemented.
	UseMaterialHatch	Gets or sets whether this face hatch uses material crosshatch.

[Top](#)

 See Also

[IFaceHatch Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISketchHatch Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Angle Property (IFaceHatch)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceHatch Interface](#) : Angle Property (IFaceHatch)

Gets or sets the angle of the face hatch.

 .NET Syntax

Visual Basic (Declaration)

Property Angle As System.Double

Visual Basic (Usage)



```
Dim instance As IFaceHatch  
Dim value As System.Double
```

```
instance.Angle = value
```

```
value = instance.Angle
```

C#

```
System.double Angle {get; set;}
```

C++/CLI

```
property System.double Angle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle in radians

Visual Basic for Applications (VBA) Syntax

See [FaceHatch::Angle](#).

Example

[Get Crosshatches on View \(VBA\)](#)
[Get Face Hatch Data \(C#\)](#)
[Get Face Hatch Data \(VB.NET\)](#)
[Get Face Hatch Data \(VBA\)](#)

See Also

[IFaceHatch Interface](#)
[IFaceHatch Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Color Property (IFaceHatch)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceHatch Interface](#) : Color Property (IFaceHatch)

Gets the color of the face hatch.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property Color As System.Integer

Visual Basic (Usage)



```
Dim instance As IFaceHatch  
Dim value As System.Integer
```

```
instance.Color = value
```

```
value = instance.Color
```

C#

```
System.int Color {get; set;}
```

C++/CLI

```
property System.int Color {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

COLORREF value for the color used for this face hatch

Visual Basic for Applications (VBA) Syntax

See [FaceHatch::Color](#).

Example

[Get Crosshatches on View \(VBA\)](#)
[Get Face Hatch Data \(C#\)](#)

[Get Face Hatch Data \(VB.NET\)](#)
[Get Face Hatch Data \(VBA\)](#)

See Also

[IFaceHatch Interface](#)
[IFaceHatch Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Definition Property (IFaceHatch)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceHatch Interface](#) : Definition Property (IFaceHatch)

Gets the definition for the face hatch.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property Definition As System.String

Visual Basic (Usage)



```
Dim instance As IFaceHatch
Dim value As System.String

instance.Definition = value

value = instance.Definition
```

C#

```
System.string Definition {get; set;}
```

C++/CLI

```
property System.String^ Definition {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Definition for face hatch

Visual Basic for Applications (VBA) Syntax

See [FaceHatch::Definition](#).

Example

[Get Face Hatch Data \(C#\)](#)
[Get Face Hatch Data \(VB.NET\)](#)
[Get Face Hatch Data \(VBA\)](#)

See Also

[IFaceHatch Interface](#)
[IFaceHatch Members](#)

Availability

Face Property (IFaceHatch)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceHatch Interface](#) : Face Property (IFaceHatch)

Gets the face that is associated with the hatch.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property Face As Face2

Visual Basic (Usage)



```
Dim instance As IFaceHatch  
Dim value As Face2
```

```
instance.Face = value
```

```
value = instance.Face
```

C#

```
Face2 Face {get; set;}
```

C++/CLI

```
property Face2^ Face {  
    Face2^ get();  
    void set ( & Face2^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pointer to the [face](#) associated with the hatch

Visual Basic for Applications (VBA) Syntax

See [FaceHatch.Face](#).

Example

[Get Hatching Data \(VBA\)](#)

See Also

[IFaceHatch Interface](#)
[IFaceHatch Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

HatchScope Property (IFaceHatch)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceHatch Interface](#) : HatchScope Property (IFaceHatch)

Gets or sets the scope for this face hatch.

.NET Syntax

Visual Basic (Declaration)

```
Property HatchScope As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFaceHatch  
Dim value As System.Integer  
  
instance.HatchScope = value  
  
value = instance.HatchScope
```

C#

```
System.int HatchScope {get; set;}
```

C++/CLI

```
property System.int HatchScope {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Hatch scope as defined in [swAreaHatchingScope_e](#)

Visual Basic for Applications (VBA) Syntax

See [FaceHatch::HatchScope](#).

See Also

[IFaceHatch Interface](#)
[IFaceHatch Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

HatchType Property (IFaceHatch)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceHatch Interface](#) : HatchType Property (IFaceHatch)

Gets or sets the type of this face hatch.

.NET Syntax

Visual Basic (Declaration)

```
Property HatchType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFaceHatch  
Dim value As System.Integer  
  
instance.HatchType = value  
  
value = instance.HatchType
```

C#

```
System.int HatchType {get; set;}
```

C++/CLI

```
property System.int HatchType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of face hatch as defined in [swAreaHatchFillStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [FaceHatch::HatchType](#).

See Also

[IFaceHatch Interface](#)
[IFaceHatch Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Layer Property (IFaceHatch)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceHatch Interface](#) : Layer Property (IFaceHatch)

Gets the drawing layer of the component to which the hatch is attached.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property Layer As System.String
```

Visual Basic (Usage)



```
Dim instance As IFaceHatch
Dim value As System.String
```

```
instance.Layer = value
```

```
value = instance.Layer
```

C#

```
System.string Layer {get; set;}
```

C++/CLI

```
property System.String^ Layer {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Layer for the face hatch

Visual Basic for Applications (VBA) Syntax

See [FaceHatch::Layer](#).

Example

[Get Crosshatches on View \(VBA\)](#)
[Get Face Hatch Data \(C#\)](#)
[Get Face Hatch Data \(VB.NET\)](#)
[Get Face Hatch Data \(VBA\)](#)

See Also

[IFaceHatch Interface](#)
[IFaceHatch Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Pattern Property (IFaceHatch)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceHatch Interface](#) : Pattern Property (IFaceHatch)

Gets the pattern for the face hatch.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property Pattern As System.String

Visual Basic (Usage)



```
Dim instance As IFaceHatch  
Dim value As System.String
```

```
instance.Pattern = value
```

```
value = instance.Pattern
```

C#

```
System.string Pattern {get; set;}
```

C++/CLI

```
property System.String^ Pattern {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pattern for the face hatch

Visual Basic for Applications (VBA) Syntax

See [FaceHatch::Pattern](#).

Example

[Get Crosshatches on View \(VBA\)](#)
[Get Face Hatch Data \(C#\)](#)
[Get Face Hatch Data \(VB.NET\)](#)
[Get Face Hatch Data \(VBA\)](#)

See Also

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

PatternId Property (IFaceHatch)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceHatch Interface](#) : PatternId Property (IFaceHatch)

Gets the pattern ID of this face hatch. Read-only.

.NET Syntax

Visual Basic (Declaration)

```
Property PatternId As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFaceHatch  
Dim value As System.Integer  
  
instance.PatternId = value  
value = instance.PatternId
```

C#

```
System.int PatternId {get; set;}
```

C++/CLI

```
property System.int PatternId {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pattern IDs as found in <install_dir>\lang\<language>\SLDWRKS.PTN

Visual Basic for Applications (VBA) Syntax

See [FaceHatch::PatternId](#).

See Also

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Scale Property (IFaceHatch)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceHatch Interface](#) : Scale Property (IFaceHatch)

Obsolete. Superseded by [IFaceHatch::Scale2](#).

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property Scale As System.Double

Visual Basic (Usage)



```
Dim instance As IFaceHatch  
Dim value As System.Double
```

```
instance.Scale = value
```

```
value = instance.Scale
```

C#

```
System.double Scale {get; set;}
```

C++/CLI

```
property System.double Scale {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [FaceHatch::Scale](#).

See Also

[IFaceHatch Interface](#)
[IFaceHatch Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Scale2 Property (IFaceHatch)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceHatch Interface](#) : Scale2 Property (IFaceHatch)

Gets or sets the scale for this face hatch.

.NET Syntax

Visual Basic (Declaration)

Property Scale2 As System.Double

Visual Basic (Usage)



```
Dim instance As IFaceHatch  
Dim value As System.Double
```

```
instance.Scale2 = value
```

```
value = instance.Scale2
```

C#

```
System.double Scale2 {get; set;}
```

C++/CLI

```
property System.double Scale2 {  
    System.double get();
```

```
void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Scale for this face hatch

Visual Basic for Applications (VBA) Syntax

See [FaceHatch::Scale2](#).

Example

[Get Crosshatches on View \(VBA\)](#)
[Get Face Hatch Data \(C#\)](#)
[Get Face Hatch Data \(VB.NET\)](#)
[Get Face Hatch Data \(VBA\)](#)

See Also

[IFaceHatch Interface](#)
[IFaceHatch Members](#)

Availability

SOLIDWORKS 2003 SP2, Revision Number 11.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

SolidFill Property (IFaceHatch)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceHatch Interface](#) : SolidFill Property (IFaceHatch)

Gets whether the face hatch is a solid color.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property SolidFill As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFaceHatch  
Dim value As System.Boolean  
  
instance.SolidFill = value  
  
value = instance.SolidFill
```

C#

```
System.bool SolidFill {get; set;}
```

C++/CLI

```
property System.bool SolidFill {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if face hatch is a solid color, false if not

Visual Basic for Applications (VBA) Syntax

See [FaceHatch::SolidFill](#).

Example

[Get Crosshatches on the View \(VBA\)](#)
[Get Face Hatch Data \(C#\)](#)
[Get Face Hatch Data \(VB.NET\)](#)
[Get Face Hatch Data \(VBA\)](#)

See Also

[IFaceHatch Interface](#)
[IFaceHatch Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

UseMaterialHatch Property (IFaceHatch)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaceHatch Interface](#) : UseMaterialHatch Property (IFaceHatch)

Gets or sets whether this face hatch uses material crosshatch.

.NET Syntax

Visual Basic (Declaration)

Property UseMaterialHatch As System.Boolean

Visual Basic (Usage)



```
Dim instance As IFaceHatch  
Dim value As System.Boolean  
  
instance.UseMaterialHatch = value  
  
value = instance.UseMaterialHatch
```

C#

```
System.bool UseMaterialHatch {get; set;}
```

C++/CLI

```
property System.bool UseMaterialHatch {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use material crosshatch, false to not

Visual Basic for Applications (VBA) Syntax

See [FaceHatch::UseMaterialHatch](#).

Example

[Get Face Hatch Data \(C#\)](#)
[Get Face Hatch Data \(VB.NET\)](#)
[Get Face Hatch Data \(VBA\)](#)

Remarks

Material crosshatches are valid for [section views](#) and aligned section views only.

See Also

[IFaceHatch Interface](#)
[IFaceHatch Members](#)

Availability

SOLIDWORKS 2009 SP4, Revision Number 17.4

IFacet (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IFacet Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFacet Interface

Allows access to a triangular facet of a mesh or graphics body.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IFacet
```

Visual Basic (Usage)

```
Dim instance As IFacet
```

C#

```
public interface IFacet
```

C++/CLI

```
public interface class IFacet
```

Visual Basic for Applications (VBA) Syntax

See [Facet](#).

Example

'VBA

'=====

'Preconditions:

'1. Copy *Public_Documents\SOLIDWORKS\SOLIDWORKS 2022\samples\tutorial\api\Part1.PLY* to *c:\temp*.

'2. Open the Immediate window.

'Postconditions:

'1. Press F5 five times, inspecting the Immediate window after each press.

'2. The part is imported first as a graphics body and then as a mesh body.

'3. The macro tests facets, facet edges, and facet vertexes after each import.

'=====

Option Explicit

```
Dim swApp As SldWorks.SldWorks
```

```
Dim swModelDoc As SldWorks.ModelDoc2
```

```
Sub main()
```

```
    Set swModelDoc = Nothing
```

```
    Set swApp = Application.SldWorks
```

```
    TestGraphicsBody
```

```
    TestBodies
```

```
    Set swModelDoc = Nothing
```

```
    swApp.CloseDoc "Part1"
```

```
    TestMeshBody
```

```
    TestBodies
```

```
    Set swModelDoc = Nothing
```

```
    swApp.CloseDoc "Part1"
```

```
End Sub
```

```

Sub TestGraphicsBody()
    Debug.Print "Importing Part1.PLY as a graphics body..."
    Debug.Print ""
    Dim boolstatus As Boolean
    boolstatus = swApp.SetUserPreferenceIntegerValue(swUserPreferenceIntegerValue_e.swImportStlVrmlModelType,
swImportStlVrmlModelType_e.swImportStlVrmlModelType_Graphics)
    boolstatus = swApp.SetUserPreferenceIntegerValue(swUserPreferenceIntegerValue_e.swImportStlVrmlModelType, 0)

    boolstatus = swApp.LoadFile2("c:\temp\Part1.PLY", "r")

    Set swModelDoc = swApp.ActiveDoc
    SelectGraphicsBody
End Sub

Sub TestMeshBody()
    Debug.Print "Importing Part1.PLY as a mesh body..."
    Debug.Print ""
    Dim boolstatus As Boolean
    boolstatus = swApp.SetUserPreferenceIntegerValue(swUserPreferenceIntegerValue_e.swImportStlVrmlModelType,
swImportStlVrmlModelType_e.swImportStlVrmlModelType_Surface)
    boolstatus = swApp.SetUserPreferenceIntegerValue(swUserPreferenceIntegerValue_e.swImportStlVrmlModelType, 1)
    swApp.SetUserPreferenceToggle swUserPreferenceToggle_e.swVrmlStillImportAsPSMesh, True

    boolstatus = swApp.LoadFile2("c:\temp\Part1.PLY", "r")

    Set swModelDoc = swApp.ActiveDoc
    SelectMeshBody
End Sub

Sub SelectGraphicsBody()
    Stop
    Debug.Print "Getting the graphics body, Graphic (Closed) -1..."
    Dim boolstatus As Boolean

    boolstatus = swModelDoc.Extension.SelectByID2("Graphic (Closed) -1", "MESH BODY FEATURE", -9.32538825377272E-02, 0.091,
0.033742378078639, False, 0, Nothing, 0)

    Dim swSelMgr As SldWorks.SelectionMgr
    Set swSelMgr = swModelDoc.SelectionManager

    Dim ISelType As Long
    ISelType = swSelMgr.GetSelectedObjectType3(1, -1)
    If ISelType = swSelGRAPHICSBODY Then
        Debug.Print "ISelType = swSelGRAPHICSBODY"
    End If

    Dim swFeature As SldWorks.Feature
    Set swFeature = swSelMgr.GetSelectedObject6(1, -1)

    If swFeature Is Nothing Then
        Debug.Print "swFeature is Nothing"
    ElseIf ISelType = swSelGRAPHICSBODY Then
        Debug.Print "Select GraphicsBody success"
        Dim swBody As SldWorks.Body2
        Set swBody = swFeature.GetSpecificFeature2
        If swBody Is Nothing Then
            Debug.Print "swBody Is Nothing"
        Else
            Debug.Print "Getting Body success"
            Dim IBodyType As Long
            IBodyType = swBody.GetType

            If IBodyType = swconst.swBodyType_e.swGraphicsBody Then
                Dim swGraphicsBody As SldWorks.GraphicsBody
                Set swGraphicsBody = swBody.GetGraphicsBody
                If swGraphicsBody Is Nothing Then
                    Debug.Print "Graphics body object is Nothing"
                Else
                    Debug.Print "GetGraphicsBody success"
                    Dim swBodyFromGraphics As SldWorks.Body2
                    Set swBodyFromGraphics = swGraphicsBody.GetBody
                    If swBodyFromGraphics Is Nothing Then
                        Debug.Print "swGraphicsBody.GetBody failed"
                    Else
                        Debug.Print "swGraphicsBody.GetBody success"
                    End If
                End If
            End If
        End If
    End If
End Sub

```

```

    End If
End If

Debug.Print "Selecting facet, facet edge, and facet vertex objects in graphics body..."

swModelDoc.ClearSelection2 True
boolstatus = swModelDoc.Extension.SelectByID2("Unknown", "MESHFACETREF", -0.130140285581291, 9.099999999999798E-02,
5.26687725669035E-02, False, 0, Nothing, 0)
ISelType = swSelMgr.GetSelectedObjectType3(1, -1)
If ISelType = swconst.swSelFACETS Then
    Debug.Print "Facet selected"
Else
    Debug.Print "Object selected not of type facet"
End If

swModelDoc.ClearSelection2 True
boolstatus = swModelDoc.Extension.SelectByID2("Unknown", "MESHFINREF", -7.01858537194084E-02, 9.099999999999798E-02,
5.13894806662165E-02, False, 0, Nothing, 0)
ISelType = swSelMgr.GetSelectedObjectType3(1, -1)
If ISelType = swSelMESHFACETEDGES Then
    Debug.Print "Facet edge selected"
Else
    Debug.Print "Object selected not of type facet edge"
End If

swModelDoc.ClearSelection2 True
boolstatus = swModelDoc.Extension.SelectByID2("Unknown", "MESHVERTEXREF", -0.117127148857435, 9.099999999999513E-02,
0.099920771345694, False, 0, Nothing, 0)
ISelType = swSelMgr.GetSelectedObjectType3(1, -1)
If ISelType = swSelMESHFACETVERTICES Then
    Debug.Print "Facet vertex selected"
Else
    Debug.Print "Object selected not of type facet vertex"
End If

Debug.Print ""
End Sub

Sub SelectMeshBody()
    Stop
    Debug.Print "Getting mesh body, Surface-Imported5..."
    Dim boolstatus As Boolean
    ' SW-35234
    boolstatus = swModelDoc.Extension.SelectByID2("Surface-Imported5", "SURFACEBODY", -9.55822368965755E-02, 9.10000000000082E-
02, 3.36061875443647E-02, False, 0, Nothing, 0)

    Dim swSelMgr As SldWorks.SelectionMgr
    Set swSelMgr = swModelDoc.SelectionManager

    Dim ISelType As Long
    ISelType = swSelMgr.GetSelectedObjectType3(1, -1)
    If ISelType = swSelSURFACEBODIES Then
        Dim swBody As SldWorks.Body2
        Set swBody = swSelMgr.GetSelectedObject6(1, -1)
        Dim IBodyType As Long
        IBodyType = swBody.GetType
        If IBodyType = swconst.swBodyType_e.swMeshBody Then
            Debug.Print "Select MeshBody success"
            Dim swMeshBody As SldWorks.MeshBody
            Set swMeshBody = swBody.GetMeshBody
            If swMeshBody Is Nothing Then
                Debug.Print "Mesh body object is Nothing"
            Else
                Debug.Print "Mesh body retrieved"
                Dim swMBody As SldWorks.Body2
                Set swMBody = swMeshBody.GetBody
                If swMBody Is Nothing Then
                    Debug.Print "swMeshBody.GetBody failed"
                Else
                    Debug.Print "swMeshBody.GetBody success"
                End If
            End If
        End If
    End If

    Debug.Print ""
End Sub

Sub TestBodies()
    Stop
    Debug.Print "Testing facets, facet edges, and facet vertexes..."
    Dim boolstatus As Boolean

```

```

Dim bFilter As Boolean
bFilter = swApp.GetSelectionFilter(swSelMESHFACETEDGES)
swApp.SetSelectionFilter swSelMESHFACETEDGES, (bFilter = False)
bFilter = swApp.GetSelectionFilter(swSelMESHFACETEDGES)

Dim vFilters As Variant
vFilters = swApp.GetSelectionFilters
Dim j As Integer

If Not IsNull(vFilters) Then
    For j = 0 To UBound(vFilters)
        Dim lCurFilter As Long
        lCurFilter = vFilters(j)

        If lCurFilter = swSelGRAPHICSBODY Then
            Debug.Print "Selection filter is swSelGRAPHICSBODY"
        ElseIf lCurFilter = swSelFACETS Then
            Debug.Print "Selection filter is swSelFACETS"
        ElseIf lCurFilter = swSelMESHFACETEDGES Then
            Debug.Print "Selection filter is swSelMESHFACETEDGES"
        ElseIf lCurFilter = swSelMESHFACETVERTICES Then
            Debug.Print "Selection filter is swSelMESHFACETVERTICES"
        Else
            Debug.Print "Selection filter is other than facet/facet edge/facet vertex"
        End If
    Next j
End If

Dim lSelFilters(0) As Long
Dim vSelFilters As Variant
lSelFilters(0) = swSelMESHFACETVERTICES
vSelFilters = lSelFilters
swApp.SetSelectionFilters vSelFilters, True

vSelFilters(0) = swSelFACETS
swApp.SetSelectionFilters vSelFilters, False

Dim bApplySelFilters As Boolean
bApplySelFilters = swApp.GetApplySelectionFilter
Dim bOppSelFilter As Boolean
bOppSelFilter = (bApplySelFilters = False)
swApp.SetApplySelectionFilter bOppSelFilter

swApp.SetApplySelectionFilter False

Set swModelDoc = swApp.ActiveDoc
Dim swPartDoc As SldWorks.PartDoc
Set swPartDoc = swModelDoc

Dim vBodies As Variant
vBodies = swPartDoc.GetBodies2(-1, False)

Dim swSelMgr As SldWorks.SelectionMgr
Set swSelMgr = swModelDoc.SelectionManager
Dim lSelType As Long

Dim swCurBod As SldWorks.Body2
If Not IsEmpty(vBodies) Then
    Dim i As Integer
    For i = 0 To UBound(vBodies)
        Debug.Print ""

        Set swCurBod = vBodies(i)

        Dim lCurBodyType As Long
        lCurBodyType = swCurBod.GetType
        If lCurBodyType = swBodyType_e.swMeshBody Then
            Debug.Print "Testing mesh body"
        ElseIf lCurBodyType = swBodyType_e.swGraphicsBody Then
            Debug.Print "Testing graphics body"
        Else
            Debug.Print "Some other body type"
        End If

        swCurBod.Select2 False, Nothing

        swCurBod.DeSelect

        Dim blsVisible As Boolean

```

```

blsVisible = swCurBod.Visible
Debug.Print "Visible is " & blsVisible

Dim sBodyName As String
sBodyName = swCurBod.Name
Debug.Print "Name is """" & sBodyName & """"

Dim blsMesh As Boolean
blsMesh = swCurBod.IsMeshBody
Debug.Print "IsMeshBody returned " & blsMesh

Dim blsGraphics As Boolean
blsGraphics = swCurBod.IsGraphicsBody
Debug.Print "IsGraphicsBody method returned " & blsGraphics

Dim swThisMeshBody As SldWorks.MeshBody
Set swThisMeshBody = swCurBod.GetMeshBody '
If swThisMeshBody Is Nothing Then
    Debug.Print ""
Else
    Dim swThisBodyFromMesh As SldWorks.Body2
    Set swThisBodyFromMesh = swThisMeshBody.GetBody
    If Not swThisBodyFromMesh Is Nothing Then
        Debug.Print "swThisMeshBody.GetBody returned an IBody2."
    Else
        Debug.Print "swThisMeshBody.GetBody returned Nothing."
    End If

    Debug.Print "Getting facet, facet edge, and facet vertex objects in this mesh body..."
    Dim lFacetCount As Long
    lFacetCount = swThisMeshBody.GetFacetCount
    Debug.Print "Facet count is " & lFacetCount

    Dim vMFacets As Variant
    vMFacets = swThisMeshBody.GetFacets
    Dim lMFacetIndex As Long
    For lMFacetIndex = 0 To UBound(vMFacets)
        Debug.Print ""
        Debug.Print "Facet " & lMFacetIndex + 1
        Dim swCurMFacet As SldWorks.Facet
        Set swCurMFacet = vMFacets(lMFacetIndex)
        Dim swBodyFromCurMFacet As SldWorks.Body2
        Set swBodyFromCurMFacet = swCurMFacet.GetBody
        Dim vEdges As Variant
        Dim vVerts As Variant
        vEdges = swCurMFacet.GetFacetEdges
        Dim lEdgesIndex As Long
        For lEdgesIndex = 0 To UBound(vEdges)
            Dim swCurEdge As SldWorks.Edge
            Set swCurEdge = vEdges(lEdgesIndex)
            If swCurEdge Is Nothing Then
                Debug.Print "Edge object is Nothing"
            Else
                Debug.Print "Edge retrieved"
            End If

            Next lEdgesIndex
            vVerts = swCurMFacet.GetFacetVertices
            Dim lVertsIndex As Long
            For lVertsIndex = 0 To UBound(vVerts)
                Dim swCurVert As SldWorks.Vertex
                Set swCurVert = vVerts(lVertsIndex)
                If swCurVert Is Nothing Then
                    Debug.Print "Vertex object is Nothing"
                Else
                    Debug.Print "Vertex retrieved"
                End If
            Next lVertsIndex
            swCurMFacet.Select False, Nothing
            lSelType = swSelMgr.GetSelectedObjectType3(1, -1)
            If lSelType = swconst.swSelectType_e.swSelFACETS Then
                Debug.Print "Facet selected"
            Else
                Debug.Print "Object not of type Facet"
            End If
        Next lMFacetIndex

    End If

    Dim swThisGraphicsBody As SldWorks.GraphicsBody
    Set swThisGraphicsBody = swCurBod.GetGraphicsBody
    If swThisGraphicsBody Is Nothing Then

```

```

    Debug.Print ""
Else
    Dim swThisBodyFromGraphics As SldWorks.Body2
    Set swThisBodyFromGraphics = swThisGraphicsBody.GetBody
    If Not swThisBodyFromGraphics Is Nothing Then
        Debug.Print "swThisGraphicsBody.GetBody returned an IBody2."
    Else
        Debug.Print "swThisGraphicsBody.GetBody returned Nothing."
    End If
    Debug.Print "Getting facet, facet edge, and facet vertex objects in this graphics body..."

    Dim IGFacetCount As Long
    IGFacetCount = swThisGraphicsBody.GetFacetCount
    Debug.Print "Facet count is " & IGFacetCount

    Dim vFacets As Variant
    vFacets = swThisGraphicsBody.GetFacets
    Dim IFacetIndex As Long
    For IFacetIndex = 0 To UBound(vFacets)
        Debug.Print ""
        Debug.Print "Facet " & IFacetIndex + 1
        Dim swFacet As SldWorks.Facet
        Set swFacet = vFacets(IFacetIndex)
        Dim swFacetBody As SldWorks.Body2
        Dim swFacetGraphicsBody As GraphicsBody
        Set swFacetBody = swFacet.GetBody
        If swFacetBody Is Nothing Then
            Debug.Print "swFacet.GetBody failed"
        Else
            Debug.Print "swFacet.GetBody returned an IBody2"
        End If

        Dim vGEdges As Variant
        vGEdges = swFacet.GetFacetEdges
        Dim IFacetEdgesCount As Long
        IFacetEdgesCount = UBound(vGEdges) + 1
        Dim IFacetEdgesIndex As Long
        For IFacetEdgesIndex = 0 To UBound(vGEdges)
            Dim swFacetEdge As SldWorks.Edge
            Set swFacetEdge = vGEdges(IFacetEdgesIndex)
            If swFacetEdge Is Nothing Then
                Debug.Print "Edge object is Nothing"
            Else
                Debug.Print "Edge retrieved"
            End If
        Next IFacetEdgesIndex

        Dim vGVerts As Variant
        vGVerts = swFacet.GetFacetVertices
        Dim IFacetVertsCount As Long
        IFacetVertsCount = UBound(vGVerts) + 1
        Dim IFacetVertsIndex As Long
        For IFacetVertsIndex = 0 To UBound(vGVerts)
            Dim swFacetVert As SldWorks.Vertex
            Set swFacetVert = vGVerts(IFacetVertsIndex)
            If swFacetVert Is Nothing Then
                Debug.Print "Vertex object is Nothing"
            Else
                Debug.Print "Vertex retrieved"
            End If
        Next IFacetVertsIndex

        swFacet.Select False, Nothing
        ISelType = swSelMgr.GetSelectedObjectType3(1, -1)
        If ISelType = swconst.swSelectType_e.swSelFACETS Then
            Debug.Print "Facet selected"
        Else
            Debug.Print "Object not of type Facet"
        End If
    Next IFacetIndex

End If
Next i
End If
Debug.Print ""
End Sub

```

Example

[Inspect Facets of Graphics and Mesh Bodies \(VB.NET\)](#)
[Inspect Facets of Graphics and Mesh Bodies \(C#\)](#)

Remarks

For more information about graphics bodies, read the **Graphics Mesh and Mesh BREP Bodies** topic in **SOLIDWORKS Design user-interface help > Parts and Features**.

Accessors

[IGraphicsBody::GetFacets](#)

[IMeshBody::GetFacets](#)

Access Diagram

[Facet](#)

See Also

[IFacet Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IFacet Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IFacet Interface

For a list of all members of this type, see [IFacet members](#).

Public Methods

Name	Description
 GetBody	Gets the body associated with this facet.
 GetFacetEdges	Gets the three edges of this facet.
 GetFacetVertices	Gets the three vertices of this facet.
 Select	Selects the specified facet.

[Top](#)

See Also

[IFacet Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IFacet Interface Members

[See Also](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : IFacet Interface

The following tables list the members exposed by [IFacet](#).

Public Methods

Name	Description
 GetBody	Gets the body associated with this facet.
 GetFacetEdges	Gets the three edges of this facet.
 GetFacetVertices	Gets the three vertices of this facet.
 Select	Selects the specified facet.

[Top](#)

See Also

[IFacet Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetBody Method (IFacet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFacet Interface](#) : GetBody Method (IFacet)

Gets the body associated with this facet.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBody() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFacet  
Dim value As System.Object  
  
value = instance.GetBody()
```

C#

```
System.object GetBody()
```

C++/CLI

```
System.Object^ GetBody();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IBody2](#)

Visual Basic for Applications (VBA) Syntax

See [Facet::GetBody](#).

Example

See the [IFacet](#) examples.

See Also

[IFacet Interface](#)
[IFacet Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFacetEdges Method (IFacet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFacet Interface](#) : GetFacetEdges Method (IFacet)

Gets the three edges of this facet.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFacetEdges() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFacet  
Dim value As System.Object  
  
value = instance.GetFacetEdges()
```

C#

```
System.object GetFacetEdges()
```

C++/CLI

```
System.Object^ GetFacetEdges();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of three [IEdges](#)

Visual Basic for Applications (VBA) Syntax

See [Facet::GetFacetEdges](#).

Example

See the [IFacet](#) examples.

See Also

[IFacet Interface](#)
[IFacet Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFacetVertices Method (IFacet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFacet Interface](#) : GetFacetVertices Method (IFacet)

Gets the three vertices of this facet.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFacetVertices() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFacet  
Dim value As System.Object  
  
value = instance.GetFacetVertices()
```

C#

```
System.object GetFacetVertices()
```

C++/CLI

```
System.Object^ GetFacetVertices();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of three [Vertex](#)

Visual Basic for Applications (VBA) Syntax

See [Facet::GetFacetVertices](#).

Example

See the [IFacet](#) examples.

See Also

[IFacet Interface](#)
[IFacet Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

Select Method (IFacet)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFacet Interface](#) : Select Method (IFacet)

Selects the specified facet.

.NET Syntax

Visual Basic (Declaration)

```
Function Select( _  
    ByVal Append As System.Boolean, _  
    ByVal Data As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFacet  
Dim Append As System.Boolean  
Dim Data As System.Object  
Dim value As System.Boolean  
  
value = instance.Select(Append, Data)
```

C#

```
System.bool Select(  
    System.bool Append,  
    System.object Data  
)
```

C++/CLI

```
System.bool Select(  
& System.bool Append,  
& System.Object^ Data  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Append

True to append this selection to the selection list, false to replace the selection list with this selection

Data

Pointer to the [ISelectData](#) object

Return Value

True if the facet is selected, false if not

Visual Basic for Applications (VBA) Syntax

See [Facet::Select](#).

Example

See the [IFacet](#) examples.

See Also

[IFacet Interface](#)

[IFacet Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

IFamilyTableAnnotation (Type)

IFamilyTableAnnotation Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFamilyTableAnnotation Interface

Allows access to the family table annotation.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IFamilyTableAnnotation
```

Visual Basic (Usage)

```
Dim instance As IFamilyTableAnnotation
```

C#

```
public interface IFamilyTableAnnotation
```

C++/CLI

```
public interface class IFamilyTableAnnotation
```

Visual Basic for Applications (VBA) Syntax

See [FamilyTableAnnotation](#).

Remarks

Family tables display the variations in part and assembly configurations or custom properties in table format.

For more information about family tables, see the **SOLIDWORKS Design user-interface Help > Detailing and Drawings > Tables > Family Tables** topics.

Accessors

[IFamilyTableFeature::GetTableAnnotations](#)
[ISheet::InsertFamilyTable](#)

Access Diagram

[FamilyTableAnnotation](#)

See Also

[IFamilyTableAnnotation Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IFamilyTableAnnotation Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFamilyTableAnnotation Interface

The following tables list the members exposed by [IFamilyTableAnnotation](#).

Public Properties

Name	Description
FamilyTableFeature	Gets the family table feature for this annotation.



[Top](#)

Public Methods

Name	Description
 GetSheet	Gets the drawing sheet of this family table annotation.

[Top](#)

See Also

[IFamilyTableAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IFamilyTableAnnotation Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFamilyTableAnnotation Interface

For a list of all members of this type, see [IFamilyTableAnnotation members](#).

Public Methods

Name	Description
 GetSheet	Gets the drawing sheet of this family table annotation.

[Top](#)

See Also

[IFamilyTableAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IFamilyTableAnnotation Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFamilyTableAnnotation Interface

For a list of all members of this type, see [IFamilyTableAnnotation members](#).

Public Properties

Name	Description
 FamilyTableFeature	Gets the family table feature for this annotation.

[Top](#)

See Also

[IFamilyTableAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

FamilyTableFeature Property (IFamilyTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFamilyTableAnnotation Interface](#) : FamilyTableFeature Property (IFamilyTableAnnotation)

Gets the family table feature for this annotation.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property FamilyTableFeature As System.Object

Visual Basic (Usage)

 Copy Code

```
Dim instance As IFamilyTableAnnotation
Dim value As System.Object

value = instance.FamilyTableFeature
```

C#

```
System.Object FamilyTableFeature {get;}
```

C++/CLI

```
property System.Object^ FamilyTableFeature {
    System.Object^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IFamilyTableFeature](#)

Visual Basic for Applications (VBA) Syntax

See [FamilyTableAnnotation::FamilyTableFeature](#).

See Also

[IFamilyTableAnnotation Interface](#)
[IFamilyTableAnnotation Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSheet Method (IFamilyTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFamilyTableAnnotation Interface](#) : GetSheet Method (IFamilyTableAnnotation)

Gets the drawing sheet of this family table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSheet() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFamilyTableAnnotation
Dim value As System.Object

value = instance.GetSheet()
```

C#

```
System.Object GetSheet()
```

C++/CLI

```
System.Object^ GetSheet();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[ISheet](#)

Visual Basic for Applications (VBA) Syntax

See [FamilyTableAnnotation::GetSheet](#).

See Also

[IFamilyTableAnnotation Interface](#)
[IFamilyTableAnnotation Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34