

SOLIDWORKS API (.NET VBA C#) — Reference (110/337): IFeature (part 1 of 3)

SOLIDWORKS API Documentation (converted from CHM)

IFeature (part 1 of 3) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IFeature Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFeature Interface

Allows access to the feature type, name, parameter data, and the next feature in the FeatureManager design tree.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IFeature
```

Visual Basic (Usage)



```
Dim instance As IFeature
```

C#

```
public interface IFeature
```

C++/CLI

```
public interface class IFeature
```

Visual Basic for Applications (VBA) Syntax

See [Feature](#).

Example

[Access Assembly \(C++\)](#)
[Get Names of Creators of Features \(C++\)](#)
[Get Spline Points \(C++\)](#)
[Traverse Assembly At Component and Feature Levels \(VBA\)](#)
[Get Areas of MidSurface Faces \(C#\)](#)
[Get Areas of MidSurface Faces \(VB.NET\)](#)
[Get Areas of MidSurface Faces \(VBA\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(VBA\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(C#\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(VB.NET\)](#)

Accessors

[IAssemblyDoc::GetActiveGroundPlane](#)
[IAssemblyDoc::CreateMate](#)
[IAssemblyDoc::FeatureByName](#) and [IAssemblyDoc::IFeatureByName](#)
[IBody2::GetFeatures](#) and [IBody2::IGetFeatures](#)
[IBodyFolder::GetFeature](#)
[IBodyFolder::GetTopLevelFeatures](#)
[IBomFeature::GetFeature](#)
[ICoincidentMateFeatureData::EntitiesToMate](#)
[IComment::FeatureOwner](#)
[ICommentFolder::GetFeature](#)
[IComplexCornerTreatmentFeatureData::GetTrimToolMember](#)
[IComponent2::FeatureByName](#)
[IComponent2::FirstFeature](#)
[IConfiguration::GetDisplayStateFeatureProperties](#)
[ICoreFeatureData::BoundingSketch](#)

[ICornerManagementFolder::GetFeature](#)
[ICornerManagementFolder::GetStructureSystemFolder](#)
[ICornerMember::GetUnderlyingMemberFeature](#)
[ICornerTreatmentFeatureData::GetFeature](#)
[ICornerTreatmentGroupFolder::GetCornerTreatments](#)
[ICornerTreatmentGroupFolder::GetFeature](#)
[ICosmosMotionStudyResults::GetPlotFeatures](#) and [ICosmosMotionStudyResults::IGetPlotFeatures](#)
[ICosmosMotionStudyResults::InsertPlotFeature](#)
[ICurveDrivenPatternFeatureData::PatternFeatureArray](#)
[ICutListSortOptions::GetFacesOrFeaturesToExclude](#)
[IDerivedPatternFeatureData::IGetSeedComponentArray](#)
[IDerivedPatternFeatureData::PatternFeature](#)
[IDerivedPatternFeatureData::SeedComponentArray](#)
[IDimension::GetFeatureOwner](#)
[IDimXpertAnnotation::GetModelFeature](#)
[IDimXpertFeature::GetModelFeature](#)
[IDrawingDoc::FeatureByName](#) and [IDrawingDoc::IFeatureByName](#)
[IFace2::GetFeature](#) and [IFeature::IGetFeature](#)
[IFace2::GetPatternSeedFeature](#) and [IFace2::IGetPatternSeedFeature](#)
[IFamilyTableFeature::GetFeature](#)
[IFeature::GetChildren](#) and [IFeature::IGetChildren](#)
[IFeature::GetFirstSubFeature](#) and [IFeature::IGetFirstSubFeature](#)
[IFeature::GetNextFeature](#) and [IFeature::IGetNextFeature](#)
[IFeature::GetNextSubFeature](#) and [IFeature::IGetNextSubFeature](#)
[IFeature::GetOwnerFeature](#)
[IFeature::GetParents](#) and [IFeature::IGetParents](#)
[IFeatureFolder::GetFeatures](#) and [IFeatureFolder::IGetFeatures](#)
[IFeatureManager::AdvancedHole](#)
[IFeatureManager::CreateFeature](#)
[IFeatureManager::CreateFormTool2](#)
[IFeatureManager::CreateCoordinateSystem](#)
[IFeatureManager::CreateCoordinateSystemUsingNumericalValues](#)
[IFeatureManager::CreateSaveBodyFeature](#)
[IFeatureManager::DraftXpertChange](#)
[IFeatureManager::DraftXpertRemove](#)
[IFeatureManager::EndVariablePitchHelix](#)
[IFeatureManager::FeatureAdvancedTableDrivenPattern](#)
[IFeatureManager::FeatureBossThicken](#)
[IFeatureManager::FeatureChainPattern](#)
[IFeatureManager::FeatureCircularPattern2](#)
[IFeatureManager::FeatureCut](#)
[IFeatureManager::FeatureCutThicken](#)
[IFeatureManager::FeatureCutThin](#)
[IFeatureManager::FeatureExtrusion2](#)
[IFeatureManager::FeatureExtrusionThin2](#)
[IFeatureManager::FeatureFillet](#) and [IFeatureManager::IFeatureFillet](#)
[IFeatureManager::FeatureFillPattern](#)
[IFeatureManager::FeatureFolderLocation](#)
[IFeatureManager::FeatureLinearPattern2](#)

[IFeatureManager::FeatureLocalCurveDrivenPattern](#)
[IFeatureManager::FeatureLocalSketchDrivenPattern](#)
[IFeatureManager::FeatureRevolve](#)
[IFeatureManager::FeatureRevolveCut](#)
[IFeatureManager::FeatureRevolveThin](#)
[IFeatureManager::FeatureRevolveThinCut](#)
[IFeatureManager::FeatureSketchDrivenPattern](#)
[IFeatureManager::FilletXpertChange](#)
[IFeatureManager::FilletXpertRemove](#)
[IFeatureManager::FinishCornerRelief](#)
[IFeatureManager::FinishSMNormalCut](#)
[IFeatureManager::GetCornerManagementFolders](#)
[IFeatureManager::GetFeatures](#) and [IFeatureManager::IGetFeatures](#)
[IFeatureManager::GetStructureSystemFolders](#)
[IFeatureManager::HoleWizard5](#)
[IFeatureManager::InsertCenterofMass](#)
[IFeatureManager::InsertCenterOfMassReferencePoint](#)
[IFeatureManager::InsertCombineFeature](#) and [IFeatureManager::IInsertCombineFeature](#)
[IFeatureManager::InsertCosmeticThread2](#)
[IFeatureManager::InsertCosmeticWeldBead2](#)
[IFeatureManager::InsertCrossBreak](#)
[IFeatureManager::InsertCutBlend](#)
[IFeatureManager::InsertCutSwept3](#)
[IFeatureManager::InsertCutSurface](#)
[IFeatureManager::InsertDeleteBody](#)
[IFeatureManager::InsertDeleteHoleForSurface](#)
[IFeatureManager::InsertDerivedPattern](#)
[IFeatureManager::InsertDwgOrDxfFile](#)
[IFeatureManager::InsertEdgeMerge](#)
[IFeatureManager::InsertEndCapFeature](#)
[IFeatureManager::InsertEndCapFeature2](#)
[IFeatureManager::InsertFeatureChamfer](#)
[IFeatureManager::InsertFeatureLock](#)
[IFeatureManager::InsertFeatureTreeFolder2](#)
[IFeatureManager::InsertFilletBeadFeature2](#)
[IFeatureManager::InsertFilletBeadFeature3](#)
[IFeatureManager::InsertFillSurface2](#)
[IFeatureManager::InsertFlattenSurface](#)
[IFeatureManager::InsertFlexFeature](#)
[IFeatureManager::InsertFormToolFeature](#)
[IFeatureManager::InsertFreeform](#)
[IFeatureManager::InsertGlobalBoundingBox](#)
[IFeatureManager::InsertGroundPlane](#)
[IFeatureManager::InsertGussetFeature](#)
[IFeatureManager::InsertGussetFeature2](#)
[IFeatureManager::InsertIndent](#)
[IFeatureManager::InsertMacroFeature3](#) and [IFeatureManager::IInsertMacroFeature3](#)
[IFeatureManager::InsertMateReference2](#)
[IFeatureManager::InsertMirrorFeature](#)

[IFeatureManager::InsertMoldCoreCavitySolids](#)
[IFeatureManager::InsertMoldPartingLine](#)
[IFeatureManager::InsertMoldPartingSurface](#)
[IFeatureManager::InsertMoldShutOffSurface](#)
[IFeatureManager::InsertMoveCopyBody2](#)
[IFeatureManager::InsertMoveFace](#)
[IFeatureManager::InsertMultifaceDraft](#)
[IFeatureManager::InsertNetBlend](#)
[IFeatureManager::InsertProtrusionBlend](#)
[IFeatureManager::InsertProtrusionSwept3](#)
[IFeatureManager::InsertReferencePoint](#) and [IFeatureManager::InsertReferencePoint](#)
[IFeatureManager::InsertRevolvedRefSurface](#)
[IFeatureManager::InsertRuledSurfaceFromEdge2](#)
[IFeatureManager::InsertScale](#)
[IFeatureManager::InsertSheetMetal3dBend](#)
[IFeatureManager::InsertSheetMetalBaseFlange2](#)
[IFeatureManager::InsertSheetMetalCornerTrim](#)
[IFeatureManager::InsertSheetMetalEdgeFlange2](#) and [IFeatureManager::InsertSheetMetalEdgeFlange2](#)
[IFeatureManager::InsertSheetMetalGussetFeature3](#)
[IFeatureManager::InsertSheetMetalHem2](#)
[IFeatureManager::InsertSheetMetalLoftedBend](#)
[IFeatureManager::InsertSheetMetalMiterFlange](#)
[IFeatureManager::InsertSplitLineIntersect](#)
[IFeatureManager::InsertStructuralWeldment2](#)
[IFeatureManager::InsertStructuralWeldment3](#)
[IFeatureManager::InsertSubFolder](#)
[IFeatureManager::InsertSubWeldFolder](#)
[IFeatureManager::InsertSubWeldFolder2](#)
[IFeatureManager::InsertSweepSurface2](#)
[IFeatureManager::InsertTableDrivenPattern](#) and [IFeatureManager::InsertTableDrivenPattern](#)
[IFeatureManager::InsertUntrimSurface](#)
[IFeatureManager::InsertWeldmentCutList](#)
[IFeatureManager::InsertWeldmentCutList2](#)
[IFeatureManager::InsertWeldmentFeature](#)
[IFeatureManager::InsertWeldmentTrimFeature](#)
[IFeatureManager::InsertWeldmentTrimFeature2](#)
[IFeatureManager::InsertWrapFeature](#)
[IFeatureManager::PostIntersect](#)
[IFeatureManager::PostSplitBody](#)
[IFeatureManager::PostTrimSurface](#)
[IFeatureManager::SetNetBlendCurveData](#)
[IFeatureManager::SetNetBlendDirectionData](#)
[IFeatureManager::SimpleHole](#)
[IFeatureStatistics::Features](#)
[IFillPatternFeatureData::PatternFeatureArray](#)
[IFlatPatternFeatureData::GetAddCornerTrim](#)
[IFlatPatternFeatureData::GetBreakCorners](#)
[IFlatPatternFolder::GetFeature](#)
[IFlatPatternFolder::GetFlatPatterns](#)

[IFoldsFeatureData::Bends](#)
[IFoldsFeatureData::IGetBends](#)
[IGeneralTableFeature::GetFeature](#)
[IGeneralToleranceTableFeature::GetFeature](#)
[IHoleTable::GetFeature](#)
[ILinearPatternFeatureData::PatternFeatureArray](#)
[ILocalCircularPatternFeatureData::IGetSeedComponentArray](#)
[ILocalCircularPatternFeatureData::SeedComponentArray](#)
[ILocalLinearPatternFeatureData::IGetSeedComponentArray](#)
[ILocalLinearPatternFeatureData::SeedComponentArray](#)
[ILoftFeatureData::GuideCurves](#)
[ILoftFeatureData::IGetGuideCurves](#)
[IMacroFeatureData::IGetParents](#)
[IMacroFeatureData::Parents](#)
[IModelDoc2::FeatureByPositionReverse](#)
[IModelDoc2::FirstFeature](#)
[IModelDoc2::InsertProjectedSketch2](#) and [IModelDoc2::IInsertProjectedSketch2](#)
[IModelDoc2::InsertSketchForEdgeFlange](#) and [IModelDoc2::IInsertSketchForEdgeFlange](#)
[IVersionCompatibilityItem::IncompatibleObject](#)
[IModelDocExtension::CreateStructureSystem](#)
[IModelDocExtension::GetLastFeatureAdded](#)
[IModelDocExtension::GetTemplateSheetMetal](#)
[IMotionPlotFeatureData::GetXAxis](#)
[IMotionPlotFeatureData::GetYAxis](#) and [IMotionPlotFeatureData::IGetYAxis](#)
[IPartDoc::CreateFeatureFromBody3](#)
[IPartDoc::CreateSurfaceFeatureFromBody](#) and [IPartDoc::ICreateSurfaceFeatureFromBody](#)
[IPartDoc::FeatureById](#) and [IPartDoc::IFeatureById](#)
[IPartDoc::FeatureByName](#) and [IPartDoc::IFeatureByName](#)
[IPartDoc::FirstFeature](#) and [IPartDoc::IFirstFeature](#)
[IPartDoc::ICreateFeatureFromBody4](#)
[IPartDoc::InsertPart](#)
[IPartDoc::MirrorPart2](#)
[IProfileGroupFolder::GetFeature](#)
[IProfileGroupFolder::GetStructureSystemMembers](#)
[IPunchTable::GetFeature](#)
[IReplaceFaceFeatureData::IGetReplacementSurfaces](#)
[IReplaceFaceFeatureData::ReplacementSurfaces](#)
[IR RevisionTableFeature::GetFeature](#)
[ISelectionMgr::GetSelectedObject6](#)
[ISheetMetalFolder::GetFeature](#)
[ISheetMetalFolder::GetSheetMetals](#)
[ISimpleFilletFeatureData2::IGetFeatures](#)
[ISimpleFilletFeatureData2::Features](#)
[ISimulation::GetFeature](#)
[ISketchBlockDefinition::GetFeature](#)
[ISketchPatternFeatureData::PatternFeatureArray](#)
[ISketchPicture::GetFeature](#)
[IStructureSystemFolder::GetCornerManagementFolder](#)
[IStructureSystemFolder::GetFeature](#)

[IStructureSystemMemberFeatureData::GetFeature](#)
[ISweepFeatureData::IGetGuideCurves](#)
[ISweepFeatureData::GuideCurves](#)
[ISweepFeatureData::Path](#)
[ISweepFeatureData::Profile](#)
[ITableAnchor::GetFeature](#)
[ITablePatternFeatureData::PatternFeatureArray](#)
[ITitleBlockTableFeature::GetFeature](#)
[IWeldmentCutListFeature::GetFeature](#)

 Access Diagram

[Feature](#)

 See Also

[IFeature Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IFeature Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFeature Interface

The following tables list the members exposed by [IFeature](#).

 Public Properties

Name	Description
 CreatedBy	Gets the name of the user who created the feature.
 CustomPropertyManager	Gets the custom property information for weldment and cut-list item features only.
 DateCreated	Gets the date on which the feature was created.
 DateModified	Gets the date on which the feature was last modified.
 Description	Gets or sets the description for this feature.
 ExcludeFromCutList	Gets or sets whether to exclude this feature from the cut list.
 Is3DInterconnectFeature	Gets whether this is a 3D Interconnect feature.
 Is3DInterconnectUpdateAvailable	Gets whether an update is available for this 3D Interconnect part or assembly.
 Name	Gets or sets the name of the current feature.
 Visible	Gets the visibility state of this feature.

[Top](#)

 Public Methods

Name	Description
 AddComment	Adds a comment to this feature.
 AddPropertyExtension	Adds a property extension to this feature.
 BreakLink	Breaks the link to third-party native CAD parts and assemblies.
 DeSelect	Deselects this feature.
 EnumDisplayDimensions	This method returns a display dimensions enumeration for this feature.
 GetAffectedFaceCount	Gets the number of faces modified by a feature, such as a draft feature.
 GetAffectedFaces	Gets the faces modified by a feature, such as a draft feature.
 GetBody	Obsolete. Superseded by IFeatures::GetFaces , IFeatures::IGetFaces2 , IFace2::GetBody , and IFace2::IGetBody .

	GetBox	Gets the bounding box for this feature.
	GetChildren	Gets the child features belonging to this feature.
	GetCreatedVersion	Gets the SOLIDWORKS version number in which the selected feature was created.
	GetDefinition	Gets the feature data object for a feature, such as an advanced mate, extrusion, loft, fillet, chamfer, etc., in order to access the parameters that control the definition of this feature.
	GetDisplayDimension	Gets the display dimension object for the specified pattern property.
	GetEditStatus	Gets whether the feature can currently be edited.
	GetErrorCode	Obsolete. Superseded by IFeature::GetErrorCode2 .
	GetErrorCode2	Gets the error code for this feature.
	GetFaceCount	Gets the number of faces in this feature.
	GetFaces	Gets the faces in this feature.
	GetFirstDisplayDimension	Provides access to the dimensions that belong to this feature by returning the first display dimension associated with this feature.
	GetFirstSubFeature	Gets the first sub-feature that belongs to this feature.
	GetID	Gets the feature ID of this feature.
	GetImportedFeatureParameters	Gets the data object for this 3D Interconnect part or assembly.
	GetImportedFileName	Gets the file name from an imported feature.
	GetMaterialIdName	Gets the material name.
	GetMaterialPropertyValues	Obsolete. Superseded by IFeature::GetMaterialPropertyValues2 .
	GetMaterialPropertyValues2	Gets the material property values for this feature in the specified configurations.
	GetMaterialUserName	Gets the material name for this feature, which is visible to the user.
	GetModifiedVersion	Gets the SOLIDWORKS version number in which this feature was last modified.
	GetNameForSelection	Gets the selected feature's type and name.
	GetNextDisplayDimension	Gets the next display dimension associated with this feature.
	GetNextFeature	Gets the next feature in the part.
	GetNextSubFeature	Gets the next sub-feature from the owner of this sub-feature.
	GetOwnerFeature	Gets the feature that owns this feature.
	GetParents	Gets the parent features for this feature.
	GetPropertyExtension	Gets the property extension on this feature.
	GetSpecificFeature	Obsolete. Superseded by IFeature::GetSpecificFeature2 .
	GetSpecificFeature2	Gets the more specific interface to a selected feature.
	GetTexture	Gets the texture applied to this feature in the specified configuration.
	GetType	Gets the type of feature.
	NOTE: To get the underlying type of feature of an Instant3D feature (i.e., "ICE"), call this method; otherwise, call IFeature::GetType.	
	GetType2	Gets the type of feature.
	NOTE: To get the underlying type of feature of an Instant3D feature (i.e., "ICE"), call IFeature::GetType; otherwise, call this method.	
	GetUIState	Gets the user-interface state of the current feature.
	GetUpdateStamp	Gets the current update stamp for this feature.
	HasFrozenUpdatePending	Gets whether this feature has pending freeze updates.
	HasMaterialPropertyValues	Gets whether this feature has an appearance.
	IGetAffectedFaces	Gets the faces modified by a feature, such as a draft feature.
	IGetBody	Obsolete. Superseded by IFeatures::GetFaces , IFeatures::IGetFaces2 , IFace2::GetBody , and IFace2::IGetBody .

	IGetBody2	Obsolete. Superseded by IFeatures::GetFaces , IFeatures::IGetFaces2 , IFace2::GetBody , and IFace2::IGetBody .
	IGetBox	Gets the bounding box for this feature.
	IGetChildCount	Gets the number of child features that belong to this feature.
	IGetChildren	Gets the child features belonging to this feature.
	IGetDefinition	Gets the feature data object for a feature, such as an extrusion, loft, fillet, chamfer, etc., in order to access the parameters that control the definition of this feature.
	IGetFaces	Obsolete. Superseded by IFeature::IGetFaces2 .
	IGetFaces2	Gets the faces in this feature.
	IGetFirstSubFeature	Gets the first sub-feature that belongs to this feature.
	IGetMaterialPropertyValues	Obsolete. Superseded by IFeature::IGetMaterialPropertyValues2 .
	IGetMaterialPropertyValues2	Gets the material property values for this feature in the specified configurations.
	IGetNextFeature	Gets the next feature.
	IGetNextSubFeature	Gets the next sub-feature from the owner of this sub-feature.
	IGetParentCount	Gets the number of parent features for this feature.
	IGetParents	Gets the parent features for this feature.
	IGetSpecificFeature	Obsolete. Superseded by IFeature::GetSpecificFeature2 .
	IsSuppressed2	Gets whether the feature in the specified configurations is suppressed.
	IListExternalFileReferences	Obsolete. Superseded by IFeature::IListExternalFileReferences2 .
	IListExternalFileReferences2	Gets the names and statuses of the external references for this feature in a part or assembly.
	IModifyDefinition	Obsolete. Superseded by IFeature::IModifyDefinition2 .
	IModifyDefinition2	Updates the definition of a feature with the new values in an associated feature data object obtained with IFeature::IGetDefinition .
	IParameter	Gets a pointer to the object for the specified parameter or a pointer to the specified parameter.
	IRemoveMaterialProperty2	Removes material property values from this feature.
	IsBase	Obsolete. Superseded by IFeature::IsBase2 .
	IsBase2	Gets whether this feature is a base feature.
	IsDimXpertAnnotation	Gets whether this feature is a DimXpert annotation.
	IsDimXpertFeature	Gets whether this feature is a DimXpert feature.
	ISetBody	Obsolete. Superseded by IFeature::ISetBody3 .
	ISetBody2	Obsolete. Superseded by IFeature::ISetBody3 .
	ISetBody3	Replaces the body of the base feature.
	ISetMaterialPropertyValues	Obsolete. Superseded by IFeature::ISetMaterialPropertyValues2 .
	ISetMaterialPropertyValues2	Sets the material property values for this feature in the specified configurations.
	ISetSuppression2	Sets the suppression state of this feature.
	IsFrozen	Gets whether this feature is frozen.
	IsHiddenLock	Gets whether this feature is the freeze bar.
	IsRolledBack	Gets whether this feature is rolled back.
	IsSuppressed	Obsolete. Superseded by IFeature::IsSuppressed2 .
	IsSuppressed2	Gets whether the feature in the specified configurations is suppressed.
	ListExternalFileReferences	Obsolete. Superseded by IFeature::ListExternalFileReferences2 .
	ListExternalFileReferences2	Gets the names and statuses of the external references on the feature in a part or assembly.
	ListExternalFileReferencesCount	Gets the number of external references on the feature in a part or assembly.
	MakeSubFeature	Makes a feature become a subfeature of this feature.
	ModifyDefinition	Updates the definition of a feature with the new values in an associated feature data object obtained with IFeature::GetDefinition .
	MoveFreezeBarTo	Obsolete. Superseded by IFeature::MoveFreezeBarTo2 .

		
	MoveFreezeBarTo2	Moves the freeze bar to the specified location in the FeatureManager design tree.
	Parameter	Gets a pointer to the object for the specified parameter or a pointer to the specified parameter.
	RemoveMaterialProperty	Obsolete. Superseded by IFeature.RemoveMaterialProperty2 .
	RemoveMaterialProperty2	Removes material property values from this feature.
	RemoveTexture	Removes texture from this feature in either all of the configurations or only the specified configuration.
	RemoveTextureByDisplayState	Removes texture from this feature in the specified display state.
	ResetPropertyExtension	Deletes the property extension for this feature.
	Select	Obsolete. Superseded by IFeature.Select2 .
	Select2	Selects and marks this feature.
	SelectByMark	Obsolete. Superseded by IFeature.Select2 .
	SetBodiesToKeep	Set the bodies to keep and their configurations for features that create multiple bodies in parts and assemblies.
	SetBody	Obsolete. Superseded by IFeature.SetBody2 .
	SetBody2	Replaces an imported base feature body.
	SetImportedFeatureParameters	Sets the data object for this 3D Interconnect part or assembly.
	SetImportedFileName	Sets the file name of an imported feature.
	SetMaterialIdName	Sets the material name for this feature.
	SetMaterialPropertyValues	Obsolete. Superseded by IFeature.SetMaterialPropertyValues2 .
	SetMaterialPropertyValues2	Sets the material property values for this feature in the specified configurations.
	SetMaterialUserName	Sets the material user name for this feature, which is visible to the user.
	SetSuppression	Obsolete. Superseded by IFeature.SetSuppression2 .
	SetSuppression2	Sets the suppression state of this feature.
	SetTexture	Applies texture to this feature in either all configurations or only the specified configuration.
	SetTextureByDisplayState	Applies texture to this feature in the specified display state.
	SetUIState	Sets the user-interface state of the current feature.
	Update3DInterconnectModel	Updates the model for this 3D Interconnect part or assembly.
	UpdateExternalFileReferences	Updates the external file references on this model.

[Top](#)

 See Also

[IFeature Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IFeature Interface Methods

[See Also](#)

	SolidWorks.Interop.sldworks Namespace : IFeature Interface
---	--

For a list of all members of this type, see [IFeature members](#).

 Public Methods

Name	Description
 AddComment	Adds a comment to this feature.
 AddPropertyExtension	Adds a property extension to this feature.
 BreakLink	Breaks the link to third-party native CAD parts and assemblies.
 DeSelect	Deselects this feature.

	EnumDisplayDimensions	This method returns a display dimensions enumeration for this feature.
	GetAffectedFaceCount	Gets the number of faces modified by a feature, such as a draft feature.
	GetAffectedFaces	Gets the faces modified by a feature, such as a draft feature.
	GetBody	Obsolete. Superseded by IFeatures::GetFaces , IFeatures::IGetFaces2 , IFace2::GetBody , and IFace2::IGetBody .
	GetBox	Gets the bounding box for this feature.
	GetChildren	Gets the child features belonging to this feature.
	GetCreatedVersion	Gets the SOLIDWORKS version number in which the selected feature was created.
	GetDefinition	Gets the feature data object for a feature, such as an advanced mate, extrusion, loft, fillet, chamfer, etc., in order to access the parameters that control the definition of this feature.
	GetDisplayDimension	Gets the display dimension object for the specified pattern property.
	GetEditStatus	Gets whether the feature can currently be edited.
	GetErrorCode	Obsolete. Superseded by IFeature::GetErrorCode2 .
	GetErrorCode2	Gets the error code for this feature.
	GetFaceCount	Gets the number of faces in this feature.
	GetFaces	Gets the faces in this feature.
	GetFirstDisplayDimension	Provides access to the dimensions that belong to this feature by returning the first display dimension associated with this feature.
	GetFirstSubFeature	Gets the first sub-feature that belongs to this feature.
	GetID	Gets the feature ID of this feature.
	GetImportedFeatureParameters	Gets the data object for this 3D Interconnect part or assembly.
	GetImportedFileName	Gets the file name from an imported feature.
	GetMaterialIdName	Gets the material name.
	GetMaterialPropertyValues	Obsolete. Superseded by IFeature::GetMaterialPropertyValues2 .
	GetMaterialPropertyValues2	Gets the material property values for this feature in the specified configurations.
	GetMaterialUserName	Gets the material name for this feature, which is visible to the user.
	GetModifiedVersion	Gets the SOLIDWORKS version number in which this feature was last modified.
	GetNameForSelection	Gets the selected feature's type and name.
	GetNextDisplayDimension	Gets the next display dimension associated with this feature.
	GetNextFeature	Gets the next feature in the part.
	GetNextSubFeature	Gets the next sub-feature from the owner of this sub-feature.
	GetOwnerFeature	Gets the feature that owns this feature.
	GetParents	Gets the parent features for this feature.
	GetPropertyExtension	Gets the property extension on this feature.
	GetSpecificFeature	Obsolete. Superseded by IFeature::GetSpecificFeature2 .
	GetSpecificFeature2	Gets the more specific interface to a selected feature.
	GetTexture	Gets the texture applied to this feature in the specified configuration.
	GetTypeNames	Gets the type of feature. NOTE: To get the underlying type of feature of an Instant3D feature (i.e., "ICE"), call this method; otherwise, call IFeature::GetTypeNames2 .
	GetTypeNames2	Gets the type of feature. NOTE: To get the underlying type of feature of an Instant3D feature (i.e., "ICE"), call IFeature::GetTypeNames ; otherwise, call this method.
	GetUIState	Gets the user-interface state of the current feature.
	GetUpdateStamp	Gets the current update stamp for this feature.

	HasFrozenUpdatePending	Gets whether this feature has pending freeze updates.
	HasMaterialPropertyValues	Gets whether this feature has an appearance.
	IGetAffectedFaces	Gets the faces modified by a feature, such as a draft feature.
	IGetBody	Obsolete. Superseded by IFeatures::GetFaces , IFeatures::IGetFaces2 , IFace2::GetBody , and IFace2::IGetBody .
	IGetBody2	Obsolete. Superseded by IFeatures::GetFaces , IFeatures::IGetFaces2 , IFace2::GetBody , and IFace2::IGetBody .
	IGetBox	Gets the bounding box for this feature.
	IGetChildCount	Gets the number of child features that belong to this feature.
	IGetChildren	Gets the child features belonging to this feature.
	IGetDefinition	Gets the feature data object for a feature, such as an extrusion, loft, fillet, chamfer, etc., in order to access the parameters that control the definition of this feature.
	IGetFaces	Obsolete. Superseded by IFeature::IGetFaces2 .
	IGetFaces2	Gets the faces in this feature.
	IGetFirstSubFeature	Gets the first sub-feature that belongs to this feature.
	IGetMaterialPropertyValues	Obsolete. Superseded by IFeature::IGetMaterialPropertyValues2 .
	IGetMaterialPropertyValues2	Gets the material property values for this feature in the specified configurations.
	IGetNextFeature	Gets the next feature.
	IGetNextSubFeature	Gets the next sub-feature from the owner of this sub-feature.
	IGetParentCount	Gets the number of parent features for this feature.
	IGetParents	Gets the parent features for this feature.
	IGetSpecificFeature	Obsolete. Superseded by IFeature::GetSpecificFeature2 .
	IsSuppressed2	Gets whether the feature in the specified configurations is suppressed.
	IListExternalFileReferences	Obsolete. Superseded by IFeature::IListExternalFileReferences2 .
	IListExternalFileReferences2	Gets the names and statuses of the external references for this feature in a part or assembly.
	IModifyDefinition	Obsolete. Superseded by IFeature::IModifyDefinition2 .
	IModifyDefinition2	Updates the definition of a feature with the new values in an associated feature data object obtained with IFeature::IGetDefinition .
	IParameter	Gets a pointer to the object for the specified parameter or a pointer to the specified parameter.
	IRemoveMaterialProperty2	Removes material property values from this feature.
	IsBase	Obsolete. Superseded by IFeature::IsBase2 .
	IsBase2	Gets whether this feature is a base feature.
	IsDimXpertAnnotation	Gets whether this feature is a DimXpert annotation.
	IsDimXpertFeature	Gets whether this feature is a DimXpert feature.
	ISetBody	Obsolete. Superseded by IFeature::ISetBody3 .
	ISetBody2	Obsolete. Superseded by IFeature::ISetBody3 .
	ISetBody3	Replaces the body of the base feature.
	ISetMaterialPropertyValues	Obsolete. Superseded by IFeature::ISetMaterialPropertyValues2 .
	ISetMaterialPropertyValues2	Sets the material property values for this feature in the specified configurations.
	ISetSuppression2	Sets the suppression state of this feature.
	IsFrozen	Gets whether this feature is frozen.
	IsHiddenLock	Gets whether this feature is the freeze bar.
	IsRolledBack	Gets whether this feature is rolled back.
	IsSuppressed	Obsolete. Superseded by IFeature::IsSuppressed2 .
	IsSuppressed2	Gets whether the feature in the specified configurations is suppressed.
	ListExternalFileReferences	Obsolete. Superseded by IFeature::ListExternalFileReferences2 .
	ListExternalFileReferences2	Gets the names and statuses of the external references on the feature in a part or assembly.

		
	ListExternalFileReferencesCount	Gets the number of external references on the feature in a part or assembly.
	MakeSubFeature	Makes a feature become a subfeature of this feature.
	ModifyDefinition	Updates the definition of a feature with the new values in an associated feature data object obtained with IFeature.GetDefinition .
	MoveFreezeBarTo	Obsolete. Superseded by IFeature.MoveFreezeBarTo2.
	MoveFreezeBarTo2	Moves the freeze bar to the specified location in the FeatureManager design tree.
	Parameter	Gets a pointer to the object for the specified parameter or a pointer to the specified parameter.
	RemoveMaterialProperty	Obsolete. Superseded by IFeature.RemoveMaterialProperty2.
	RemoveMaterialProperty2	Removes material property values from this feature.
	RemoveTexture	Removes texture from this feature in either all of the configurations or only the specified configuration.
	RemoveTextureByDisplayState	Removes texture from this feature in the specified display state.
	ResetPropertyExtension	Deletes the property extension for this feature.
	Select	Obsolete. Superseded by IFeature.Select2.
	Select2	Selects and marks this feature.
	SelectByMark	Obsolete. Superseded by IFeature.Select2.
	SetBodiesToKeep	Set the bodies to keep and their configurations for features that create multiple bodies in parts and assemblies.
	SetBody	Obsolete. Superseded by IFeature.SetBody2.
	SetBody2	Replaces an imported base feature body.
	SetImportedFeatureParameters	Sets the data object for this 3D Interconnect part or assembly.
	SetImportedFileName	Sets the file name of an imported feature.
	SetMaterialIdName	Sets the material name for this feature.
	SetMaterialPropertyValues	Obsolete. Superseded by IFeature.SetMaterialPropertyValues2.
	SetMaterialPropertyValues2	Sets the material property values for this feature in the specified configurations.
	SetMaterialUserName	Sets the material user name for this feature, which is visible to the user.
	SetSuppression	Obsolete. Superseded by IFeature.SetSuppression2.
	SetSuppression2	Sets the suppression state of this feature.
	SetTexture	Applies texture to this feature in either all configurations or only the specified configuration.
	SetTextureByDisplayState	Applies texture to this feature in the specified display state.
	SetUIState	Sets the user-interface state of the current feature.
	Update3DInterconnectModel	Updates the model for this 3D Interconnect part or assembly.
	UpdateExternalFileReferences	Updates the external file references on this model.

[Top](#)

See Also

[IFeature Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IFeature Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFeature Interface

For a list of all members of this type, see [IFeature members](#).

Public Properties

Name	Description
------	-------------

 CreatedBy	Gets the name of the user who created the feature.
 CustomPropertyManager	Gets the custom property information for weldment and cut-list item features only.
 DateCreated	Gets the date on which the feature was created.
 DateModified	Gets the date on which the feature was last modified.
 Description	Gets or sets the description for this feature.
 ExcludeFromCutList	Gets or sets whether to exclude this feature from the cut list.
 Is3DInterconnectFeature	Gets whether this is a 3D Interconnect feature.
 Is3DInterconnectUpdateAvailable	Gets whether an update is available for this 3D Interconnect part or assembly.
 Name	Gets or sets the name of the current feature.
 Visible	Gets the visibility state of this feature.

[Top](#)

See Also

[IFeature Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddComment Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : AddComment Method (IFeature)

Adds a comment to this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AddComment( _
    ByVal Text As System.String _
) As Comment
```

Visual Basic (Usage)

```
Dim instance As IFeature
Dim Text As System.String
Dim value As Comment

value = instance.AddComment(Text)
```

C#

```
Comment AddComment(
    System.string Text
)
```

C++/CLI

```
Comment^ AddComment(
    & System.String^ Text
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Text
Comment to add to this feature

Return Value

Pointer to the [IComment](#) object

Visual Basic for Applications (VBA) Syntax

See [Feature::AddComment](#).

Remarks

The comment is added in the [Comment folder](#), but the comment is associated with this feature. If your pointer is on the feature in the FeatureManager design tree, then the comment is displayed as a ToolTip.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IComment::Delete Method](#)
[IModelDocExtension::AddComment Method](#)
[ICommentFolder::AddComment Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddPropertyExtension Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : AddPropertyExtension Method (IFeature)

Adds a property extension to this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AddPropertyExtension( _  
    ByVal PropertyExtension As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim PropertyExtension As System.Object  
Dim value As System.Integer  
  
value = instance.AddPropertyExtension(PropertyExtension)
```

C#

```
System.int AddPropertyExtension(  
    System.object PropertyExtension  
)
```

C++/CLI

```
System.int AddPropertyExtension(  
& System.Object^ PropertyExtension  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PropertyExtension
Value of the property extension to add to this feature

Return Value

1 if the property extension is added to the feature, -1 if not

Visual Basic for Applications (VBA) Syntax

See [Feature::AddPropertyExtension](#).

Remarks

This method does not support adding multiple property extensions to the same feature.

To use this method:

1. Declare the variable.
2. Assign the variable a value: float, integer, or string.
3. Call this method to add the value to the feature.

NOTE: SOLIDWORKS recommends that you use the [IAttribute](#), [IAttributeDef](#), or [IParameter](#) interfaces instead of this method. These interfaces provide more flexibility.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetPropertyExtension Method](#)
[IFeature::ResetPropertyExtension Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

BreakLink Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : BreakLink Method (IFeature)

Breaks the link to third-party native CAD parts and assemblies.

.NET Syntax

Visual Basic (Declaration)

```
Function BreakLink( _  
    ByVal AllComponents As System.Boolean, _  
    ByVal Silent As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim AllComponents As System.Boolean  
Dim Silent As System.Boolean  
Dim value As System.Integer  
  
value = instance.BreakLink(AllComponents, Silent)
```

C#

```
System.int BreakLink(  
    System.bool AllComponents,  
    System.bool Silent  
)
```

C++/CLI

```
System.int BreakLink(  
& System.bool AllComponents,  
& System.bool Silent  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AllComponents

True to break the link for all subcomponents within a top-level subassembly, false to not (see **Remarks**)

Silent

True to suppress dialog windows, false to not

Return Value

Error codes as defined in [sw3DInterconnectImportErrors_e](#)

Visual Basic for Applications (VBA) Syntax

See [Feature::BreakLink](#).

Example

See the [IImport3DInterconnectData](#) examples.

Remarks

By default, breaking a link of an assembly component breaks the links of all instances of that component.

After you break a link, all references to the original CAD file are lost. You can no longer change the entities to transfer from the original file or update the SOLIDWORKS model with changes from the third-party authoring application.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IImport3DInterconnectData Interface](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreatedBy Property (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : CreatedBy Property (IFeature)

Gets the name of the user who created the feature.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property CreatedBy As System.String

Visual Basic (Usage)



```
Dim instance As IFeature
Dim value As System.String

value = instance.CreatedBy
```

C#

```
System.string CreatedBy {get;}
```

C++/CLI

```
property System.String^ CreatedBy {
    System.String^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the user who created the feature

Visual Basic for Applications (VBA) Syntax

See [Feature.CreatedBy](#).

Example

[Get Names of Creators of Features \(VBA\)](#)
[Get Names of Creators of Features \(C++\)](#)
[Get Names of Creators of Features \(C#\)](#)
[Get Names of Creators of Features \(VB.NET\)](#)

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::DateCreated Property](#)
[IFeature::DateModified Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CustomPropertyManager Property (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : CustomPropertyManager Property (IFeature)

Gets the custom property information for weldment and cut-list item features only.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property CustomPropertyManager As CustomPropertyManager
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As CustomPropertyManager  
  
value = instance.CustomPropertyManager
```

C#

```
CustomPropertyManager CustomPropertyManager {get;}
```

C++/CLI

```
property CustomPropertyManager^ CustomPropertyManager {  
    CustomPropertyManager^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pointer to the [ICustomPropertyManager](#) object

Visual Basic for Applications (VBA) Syntax

See [Feature::CustomPropertyManager](#).

Example

[Add and Get Custom Properties \(VBA\)](#)
[Get Custom Properties for Cut-list Item \(VBA\)](#)

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IModelDocExtension::CustomPropertyManager Property](#)
[IConfiguration::CustomPropertyManager Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DateCreated Property (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : DateCreated Property (IFeature)

Gets the date on which the feature was created.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property DateCreated As System.String
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.String  
  
value = instance.DateCreated
```

C#

```
System.string DateCreated {get;}
```

C++/CLI

```
property System.String^ DateCreated {  
    System.String^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Date on which the feature was created

Visual Basic for Applications (VBA) Syntax

See [Feature::DateCreated](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature.CreatedBy Property](#)
[IFeature.DateModified Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DateModified Property (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : DateModified Property (IFeature)

Gets the date on which the feature was last modified.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property DateModified As System.String
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.String  
  
value = instance.DateModified
```

C#

```
System.string DateModified {get;}
```

C++/CLI

```
property System.String^ DateModified {  
    System.String^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Date on which the feature was last modified

Visual Basic for Applications (VBA) Syntax

See [Feature.DateModified](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature.CreatedBy Property](#)
[IFeature.DateCreated Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Description Property (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : Description Property (IFeature)

Gets or sets the description for this feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Description As System.String
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.String  
  
instance.Description = value  
  
value = instance.Description
```

C#

```
System.string Description {get; set;}
```

C++/CLI

```
property System.String^ Description {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Feature description

Visual Basic for Applications (VBA) Syntax

See [Feature::Description](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeSelect Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : DeSelect Method (IFeature)

Deselects this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function DeSelect() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Boolean  
  
value = instance.DeSelect()
```

C#

```
System.bool DeSelect()
```

C++/CLI

```
System.bool DeSelect();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the feature is deselected successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::DeSelect](#).

Example

[Get Section Properties for Faces from Section Planes \(VBA\)](#)

Remarks

Use [IModelDoc2::DeSelectById](#) instead of this method. This method does not work well when a PropertyManager page is open or a command is running. [IModelDoc2::DeSelectById](#) handles selection correctly whether or not a command is running.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::Select2 Method](#)
[IFeature::GetSpecificFeature2 Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EnumDisplayDimensions Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : EnumDisplayDimensions Method (IFeature)

This method returns a [display dimensions enumeration](#) for this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function EnumDisplayDimensions() As EnumDisplayDimensions
```

Visual Basic (Usage)



```
Dim instance As IFeature
Dim value As EnumDisplayDimensions

value = instance.EnumDisplayDimensions()
```

C#

```
EnumDisplayDimensions EnumDisplayDimensions()
```

C++/CLI

```
EnumDisplayDimensions^ EnumDisplayDimensions();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to a [display dimensions enumeration](#) for this feature

Visual Basic for Applications (VBA) Syntax

See [Feature::EnumDisplayDimensions](#).

Remarks

Before you can get a feature's display dimensions, use [IModelDoc2::SetUserPreferenceToggle](#) and `swDisplayFeatureDimension` to display them

All dimensions on this feature and its sub-features are returned in the enumeration. In the user-interface, this is equivalent to double-clicking a feature in the FeatureManager design tree to display all of the feature and sub-feature dimensions.

If you call this method from a sub-feature (for example, the sketch of a boss-extrude), then the returned dimensions contain only the dimensions found in the sketch.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetFirstDisplayDimension Method](#)
[IFeature::GetNextDisplayDimension Method](#)
[IFeature::GetDisplayDimension Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ExcludeFromCutList Property (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : ExcludeFromCutList Property (IFeature)

Gets or sets whether to exclude this feature from the cut list.

.NET Syntax

Visual Basic (Declaration)

Property ExcludeFromCutList As System.Boolean

Visual Basic (Usage)



```
Dim instance As IFeature
Dim value As System.Boolean

instance.ExcludeFromCutList = value

value = instance.ExcludeFromCutList
```

C#

```
System.bool ExcludeFromCutList {get; set;}
```

C++/CLI

```
property System.bool ExcludeFromCutList {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to exclude, false to not

Visual Basic for Applications (VBA) Syntax

See [Feature::ExcludeFromCutList](#).

Remarks

This method only works for cut list items.

See Also

[IFeature Interface](#)
[IFeature Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetAffectedFaceCount Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetAffectedFaceCount Method (IFeature)

Gets the number of faces modified by a feature, such as a draft feature.

.NET Syntax

Visual Basic (Declaration)

Function GetAffectedFaceCount() As System.Integer

Visual Basic (Usage)



```
Dim instance As IFeature
Dim value As System.Integer

value = instance.GetAffectedFaceCount()
```

C#

```
System.int GetAffectedFaceCount()
```

C++/CLI

```
System.int GetAffectedFaceCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of faces modified by a feature

Visual Basic for Applications (VBA) Syntax

See [Feature::GetAffectedFaceCount](#).

Example

[Get Faces Affected By Feature \(VBA\)](#)

Remarks

Call this method before calling [IFeature::IGetAffectedFaces](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFace2::GetAffectedFaces Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAffectedFaces Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetAffectedFaces Method (IFeature)

Gets the faces modified by a feature, such as a draft feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAffectedFaces() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Object
```

```
value = instance.GetAffectedFaces()
```

C#

```
System.object GetAffectedFaces()
```

C++/CLI

```
System.Object^ GetAffectedFaces();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of the [faces](#) modified by a feature

Visual Basic for Applications (VBA) Syntax

See [Feature::GetAffectedFaces](#).

Example

[Get Faces Affected By Feature \(VBA\)](#)

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetAffectedFaceCount Method](#)
[IFeature::!GetAffectedFaces Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetBody Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetBody Method (IFeature)

Obsolete. Superseded by [IFeatures::GetFaces](#), [IFeatures::!GetFaces2](#), [IFace2::GetBody](#), and [IFace2::!GetBody](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetBody() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Object  
  
value = instance.GetBody()
```

C#

```
System.object GetBody()
```

C++/CLI

```
System.Object^ GetBody();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Visual Basic for Applications (VBA) Syntax

See [Feature::GetBody](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetBox Method (IFeature)

[See Also](#) [Example](#)



Gets the bounding box for this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBox( _  
    ByRef BBox As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim BBox As System.Object  
Dim value As System.Boolean  
  
value = instance.GetBox(BBox)
```

C#

```
System.bool GetBox(  
    out System.object BBox  
)
```

C++/CLI

```
System.bool GetBox(  
& [Out] System.Object^ BBox  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BBox

Array containing the two diagonal points

Return Value

True if the operation was successful, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::GetBox](#).

Example

[Get Bounding Box \(C#\)](#)
[Get Bounding Box \(VB.NET\)](#)
[Get Bounding Box \(VBA\)](#)

Remarks

IMPORTANT: The values returned are approximate and should not be used for comparison or calculation purposes. Furthermore, the bounding box may vary after rebuilding the model.

The resulting box encloses the object, but it might not be the tightest box.

The two X, Y, Z points returned are the lower- and upper-diagonal corners that bound the feature. The box is aligned with the model coordinate system. The box dimensions enclose the feature. However, the box might not be the minimum bounding box for the model.

The return value is an array of 6 doubles as follows:

[*XCorner1*, *YCorner1*, *ZCorner1*, *XCorner2*, *YCorner2*, *ZCorner2*]

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::IGetBox Method](#)
[IBody2::GetBodyBox Method](#)
[IBody2::IGetBodyBox Method](#)

[IAssemblyDoc::GetBox Method](#)
[IAssemblyDoc::IGetBox Method](#)
[IModelDocExtension::GetVisibleBox Method](#)
[IModelDocExtension::RemoveVisibleBox Method](#)
[IModelDocExtension::SetVisibleBox Method](#)
[IFace2::GetBox Method](#)
[IFace2::IGetBox Method](#)
[IComponent2::GetBox Method](#)
[IComponent2::IGetBox Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetChildren Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetChildren Method (IFeature)

Gets the child features belonging to this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetChildren() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Object  
  
value = instance.GetChildren()
```

C#

```
System.object GetChildren()
```

C++/CLI

```
System.Object^ GetChildren();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of child [features](#)

Visual Basic for Applications (VBA) Syntax

See [Feature::GetChildren](#).

Example

[Get Parent-Child Relationship for Component \(VBA\)](#)

Remarks

This method gets the direct children of this feature. It does not get children of children.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::IGetChildCount Method](#)
[IFeature::IGetChildren Method](#)
[IFeature::GetParents Method](#)
[IFeature::IGetParents Method](#)
[IFeature::IGetParentCount Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCreatedVersion Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetCreatedVersion Method (IFeature)

Gets the SOLIDWORKS version number in which the selected feature was created.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCreatedVersion() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFeature
Dim value As System.Integer

value = instance.GetCreatedVersion()
```

C#

```
System.int GetCreatedVersion()
```

C++/CLI

```
System.int GetCreatedVersion();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

SOLIDWORKS version number in which feature was created (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Feature::GetCreatedVersion](#).

Example

[Get SOLIDWORKS Version Number in which Feature Was Created \(VBA\)](#)

Remarks

SOLIDWORKS Release	Version Number
SOLIDWORKS 95	44
SOLIDWORKS 96	243
SOLIDWORKS 97	483
SOLIDWORKS 97Plus	629
SOLIDWORKS 98	822
SOLIDWORKS 98Plus	1008
SOLIDWORKS 99	1137
SOLIDWORKS 2000	1500
SOLIDWORKS 2001	1750

SOLIDWORKS Release	Version Number
SOLIDWORKS 2001Plus	1950
SOLIDWORKS 2003	2200
SOLIDWORKS 2004	2500
SOLIDWORKS 2005	2800
SOLIDWORKS 2006	3100
SOLIDWORKS 2007	3400
SOLIDWORKS 2008	3800
SOLIDWORKS 2009	4100
SOLIDWORKS 2010	4400
SOLIDWORKS 2011	4700
SOLIDWORKS 2012	5000
SOLIDWORKS 2013	6000
SOLIDWORKS 2014	7000
SOLIDWORKS 2015	8000
SOLIDWORKS 2016	9000
SOLIDWORKS 2017	10000
SOLIDWORKS 2018	11000
SOLIDWORKS 2019	12000
SOLIDWORKS 2020	13000
SOLIDWORKS 2021	14000
SOLIDWORKS 2022	15000
SOLIDWORKS 2023	16000
SOLIDWORKS 2024	17000
SOLIDWORKS 2025	18000
SOLIDWORKS 2026	19000

To get the SOLIDWORKS version number in which the feature was last modified, use [IFeature::GetModifiedVersion](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IModelDoc2::IVersionHistory Method](#)
[IModelDoc2::VersionHistory Method](#)
[ISldWorks::IVersionHistory Method](#)
[ISldWorks::VersionHistory Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision number 14.0



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetDefinition Method (IFeature)

Gets the feature data object for a feature, such as an advanced mate, extrusion, loft, fillet, chamfer, etc., in order to access the parameters that control the definition of this feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetDefinition() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFeature
Dim value As System.Object

value = instance.GetDefinition()
```

C#

```
System.Object GetDefinition()
```

C++/CLI

```
System.Object^ GetDefinition();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Feature data object (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Feature::GetDefinition](#).

Example

[Change Bend Radius of Sheet Metal Part \(VBA\)](#)
[Create Thicken Feature \(VBA\)](#)
[Get and Set Constraint for Dome Feature \(VBA\)](#)
[Insert Reference Points \(VBA\)](#)
[Set Custom Bend Allowance \(VBA\)](#)
[Traverse All Cosmetic Threads \(VBA\)](#)
[Insert and Change DeleteFace Feature \(C#\)](#)
[Insert and Change DeleteFace Feature \(VB.NET\)](#)
[Insert and Change DeleteFace Feature \(VBA\)](#)

Remarks

You can use this method to query the feature data object, and you can modify the feature data object using [IFeature::ModifyDefinition](#). Set the feature data object to Nothing or null when it is no longer needed. Not all feature types are supported, so check to see that the returned object is valid.

To:

- get the type of feature and the name of its associated interface, use [IFeature::GetType](#) or [IFeature::GetType2](#).
- see a complete list of interfaces for feature data objects (e.g., interfaces ending in FeatureData or FeatureData2, such as ISymmetricMateFeatureData, IExtrudeFeatureData2, ILoftFeatureData, ISimpleFilletFeatureData2, IChamferFeatureData2, etc.), see the **Features Interfaces** and **Assembly Interfaces - Mates** sections in [Functional Categories](#).
- get the object of a feature that is not a feature data object, use [IFeature::GetSpecificFeature2](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetDefinition Method](#)
[IFeature::ModifyDefinition2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDisplayDimension Method (IFeature)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetDisplayDimension Method (IFeature)

Gets the display dimension object for the specified pattern property.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayDimension( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetDisplayDimension(Index)
```

C#

```
System.object GetDisplayDimension(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetDisplayDimension(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Pattern property as defined by [swFeatureDimensionParameter_e](#)

Return Value

[IDisplayDimension](#)

Visual Basic for Applications (VBA) Syntax

See [Feature::GetDisplayDimension](#).

Example

[Get Pattern Display Dimension \(VBA\)](#)
[Get Pattern Display Dimension \(VB.NET\)](#)
[Get Pattern Display Dimension \(C#\)](#)

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::EnumDisplayDimensions Method \(\)](#)
[IFeature::GetFirstDisplayDimension Method \(\)](#)
[IFeature::GetNextDisplayDimension Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEditStatus Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetEditStatus Method (IFeature)

Gets whether the feature can currently be edited.

.NET Syntax

```
Function GetEditStatus() As System.Integer
```



```
Dim instance As IFeature
Dim value As System.Integer

value = instance.GetEditStatus()
```

```
System.int GetEditStatus()
```

```
System.int GetEditStatus();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Editing status of feature as defined in [swFeatureEditStatus_e](#)

Visual Basic for Applications (VBA) Syntax

See [Feature::GetEditStatus](#).

Example

[Get Editing Status of Features \(VB.NET\)](#)
[Get Editing Status of Features \(VBA\)](#)
[Get Editing Status of Features \(C#\)](#)

Remarks

Although swFeatureEditStatus_e is a bitmask, you currently cannot combine its mutually exclusive enumerators and you must examine the bit value of the return value for the editing status of the feature.

If...	Then the return value will be...
a feature and all of its dependent items are not currently being edited	0 (swFeature_Editable) for the feature and all of its dependent items
a feature is currently being edited	1 (swFeature_NonEditable); this will also be the return value for all of the feature's dependent items
a sketch is currently being edited	2 (swFeature_UnderEditing)

See Also

[IFeature Interface](#)
[IFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

GetErrorCode Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetErrorCode Method (IFeature)

Obsolete. Superseded by [IFeature::GetErrorCode2](#).

.NET Syntax

Function GetErrorCode() As System.Integer

Visual Basic (Usage)



```
Dim instance As IFeature
Dim value As System.Integer

value = instance.GetErrorCode()
```

C#

```
System.int GetErrorCode()
```

C++/CLI

```
System.int GetErrorCode();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Feature error code as defined in [swFeatureError_e](#)

Visual Basic for Applications (VBA) Syntax

See [Feature::GetErrorCode](#).

Remarks

This method returns many of the errors indicated by the "What's Wrong" icon seen with an invalid feature in the FeatureManager design tree. During feature creation, you can prevent the error dialog from appearing by using [IModelDoc2::ShowFeatureErrorDialog](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetErrorCode2 Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetErrorCode2 Method (IFeature)

Gets the error code for this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetErrorCode2( _  
    ByRef IsWarning As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFeature
Dim IsWarning As System.Boolean
Dim value As System.Integer

value = instance.GetErrorCode2(IsWarning)
```

C#

```
System.int GetErrorCode2(  
    out System.bool IsWarning  
)
```

C++/CLI

```
System.int GetErrorCode2(  
& [Out] System.bool IsWarning  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

IsWarning

True if the error is a warning, false if not

NOTE: This parameter should only be examined if the return value is non-zero.

Return Value

Feature error code as defined in [swFeatureError_e](#)

Visual Basic for Applications (VBA) Syntax

See [Feature::GetErrorCode2](#).

Example

[Get Error Codes for Features \(VBA\)](#)

Remarks

This method returns many of the errors indicated by the What's Wrong icon seen with an invalid feature in the FeatureManager design tree.

During feature creation, you can prevent the error dialog from appearing by using [IModelDoc2::ShowFeatureErrorDialog](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[ISldWorks.AllowFailedFeatureCreation Method](#)
[IModelDoc2.ShowFeatureErrorDialog Property](#)
[IModelDocExtension.GetWhatsWrong Method](#)
[IModelDocExtension.GetWhatsWrongCount Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFaceCount Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetFaceCount Method (IFeature)

Gets the number of faces in this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFaceCount() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IFeature  
Dim value As System.Integer
```



```
value = instance.GetFaceCount()
```

C#

```
System.int GetFaceCount()
```

C++/CLI

```
System.int GetFaceCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of faces in this feature

Visual Basic for Applications (VBA) Syntax

See [Feature::GetFaceCount](#).

Example

[Get Faces Affected by Draft Feature \(VBA\)](#)
[Get Faces Affected by Scale Feature \(VBA\)](#)
[Get Faces Associated with Feature \(C#\)](#)
[Get Faces Associated with Feature \(VB.NET\)](#)
[Get Faces Associated with Feature \(VBA\)](#)

Remarks

Call this method before calling [IFeature::IGetFaces2](#).

A face:

- is the result of evaluating a feature.
- can be owned by several features.

This method returns all of the faces owned by a feature. This is different from the faces highlighted in the user interface when the feature is selected. The user interface filters out multiple feature faces. This filter is only for display purposes.

NOTES:

- This method does not return any faces for draft features because draft features do not create any new faces. Drafting only modifies existing faces.
- The number of faces for rolled hems is 0 because all of the faces belong to the children bends.

To filter out multiple feature faces, call [IFace2::GetFeature](#) or [IFace2::IGetFeature](#). Only the oldest feature from the face is returned; that is, the first owning feature in the FeatureManager design tree.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFace2::GetFaces Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFaces Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetFaces Method (IFeature)

Gets the faces in this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFaces() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Object  
  
value = instance.GetFaces()
```

C#

```
System.Object GetFaces()
```

C++/CLI

```
System.Object^ GetFaces();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [faces](#)

Visual Basic for Applications (VBA) Syntax

See [Feature::GetFaces](#).

Example

[Get Faces Associated with Feature \(VBA\)](#)
[Get Part for Corresponding Component \(VBA\)](#)
[Add Attribute to Feature and Include in Library Feature \(VB.NET\)](#)
[Add Attribute to Feature and Include in Library Feature \(C#\)](#)
[Add Attribute to Feature and Include in Library Feature \(VBA\)](#)
[Roll Back Model \(C#\)](#)
[Roll Back Model \(VB.NET\)](#)
[Roll Back Model \(VBA\)](#)

Remarks

A face:

- is the result of evaluating a feature.
- can be owned by several features.

This method returns all of the faces owned by a feature. This is different from the faces highlighted in the user interface when the feature is selected. The user interface filters out multiple feature faces. This filter is only for display purposes.

NOTES:

- This method does not return any faces for draft features because draft features do not create any new faces. Drafting only modifies existing faces.
- The number of faces for rolled hems is 0 because all of the faces belong to the children bends.

To filter out multiple feature faces, call [IFace2::GetFeature](#) or [IFace2::IGetFeature](#). Only the oldest feature from the face is returned; that is, the first owning feature in the FeatureManager design tree.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::IGetFaces2 Method](#)
[IFeature::GetFaceCount Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstDisplayDimension Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetFirstDisplayDimension Method (IFeature)

Provides access to the dimensions that belong to this feature by returning the first display dimension associated with this feature.

Visual Basic Syntax

Visual Basic (Declaration)

Function GetFirstDisplayDimension() As System.Object

Visual Basic (Usage)



```
Dim instance As IFeature
Dim value As System.Object

value = instance.GetFirstDisplayDimension()
```

C#

```
System.object GetFirstDisplayDimension()
```

C++/CLI

```
System.Object^ GetFirstDisplayDimension();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First [IDisplayDimension](#) object for this feature, or Nothing or null if there are no dimensions for this feature

Visual Basic for Applications (VBA) Syntax

See [Feature::GetFirstDisplayDimension](#).

Example

[Traverse Annotations \(C#\)](#)
[Traverse Annotations \(VB.NET\)](#)
[Traverse Annotations \(VBA\)](#)

Remarks

Before you can get a feature's IDisplayDimension, use [IModelDoc2::SetUserPreferenceToggle](#) and swDisplayFeatureDimensions to display them.

All dimensions on this feature its sub-features are returned by either IFeature::GetFirstDisplayDimension and [IFeature::GetNextDisplayDimension](#) or [IFeature::EnumDisplayDimensions](#). In the user-interface, this is equivalent to double-clicking a feature in the FeatureManager design tree to display all of the feature and sub-feature dimensions.

If you call this method from a sub-feature (for example, the sketch of a boss-extrude), then the IDisplayDimension object returned by IFeature::GetFirstDisplayDimension and IFeature::GetNextDisplayDimension contain only the dimensions found in the sketch.

Do not use [IAnnotation::Visible](#) property to modify this method's return value.

This method might not return the same display dimension every time it is called.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetDisplayDimension Method \(\)](#)

Availability

SOLIDWORKS 98Plus, datecode 1998319

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstSubFeature Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetFirstSubFeature Method (IFeature)

Gets the first sub-feature that belongs to this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstSubFeature() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Object
```

```
value = instance.GetFirstSubFeature()
```

C#

```
System.Object GetFirstSubFeature()
```

C++/CLI

```
System.Object^ GetFirstSubFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First sub-feature of this [feature](#)

Visual Basic for Applications (VBA) Syntax

See [Feature::GetFirstSubFeature](#).

Example

[Iterate Through Dimensions in Model \(VBA\)](#)
[Traverse All Cosmetic Threads \(VBA\)](#)
[Traverse Subfeatures \(VBA\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(C#\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(VB.NET\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(VBA\)](#)

Remarks

If no sub-features exist for this feature, then this method returns NULL.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetNextSubFeature Method](#)
[IFeature::IGetNextFeature Method](#)
[IFeature::IGetNextSubFeature Method](#)
[IFeatureManager::GetFeatures Method](#)
[IFeatureManager::IGetFeatures Method](#)
[IModelDoc2::FirstFeature Method](#)
[IModelDoc2::IGetFirstFeature Method](#)
[IPartDoc::FirstFeature Method](#)
[IPartDoc::IGetFirstFeature Method](#)
[IComponent2::FirstFeature Method](#)
[IFeature::MakeSubFeature Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetID Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetID Method (IFeature)

Gets the feature ID of this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetID() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Integer  
  
value = instance.GetID()
```

C#

```
System.int GetID()
```

C++/CLI

```
System.int GetID();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Feature ID of this feature

Visual Basic for Applications (VBA) Syntax

See [Feature::GetID](#).

Example

[Get Type of Instant3D Feature \(C#\)](#)
[Get Type of Instant3D Feature \(VB.NET\)](#)
[Get Type of Instant3D Feature \(VBA\)](#)

Remarks

A feature ID:

- is unique within the document.
- is persistent across SOLIDWORKS Design sessions and never changes, even if you [change the name of the feature](#).
- can be used to identify a specific feature when multiple features exist in a model.
- cannot be assigned by users.
- is not the same as a [persistent reference ID](#). You can get a feature using its persistent reference ID, but you cannot get a feature using this method.

See Also

[IFeature Interface](#)
[IFeature Members](#)

Availability

SOLIDWORKS 2014, FCS Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetImportedFeatureParameters Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetImportedFeatureParameters Method (IFeature)

Gets the data object for this 3D Interconnect part or assembly.

.NET Syntax

Visual Basic (Declaration)

```
Function GetImportedFeatureParameters( _  
    ByRef DataObj As System.Object _  
) As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IFeature  
Dim DataObj As System.Object  
Dim value As System.Integer
```



```
value = instance.GetImportedFeatureParameters(DataObj)
```

C#

```
System.int GetImportedFeatureParameters(  
    out System.object DataObj  
)
```

C++/CLI

```
System.int GetImportedFeatureParameters(  
& [Out] System.Object^ DataObj  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[DataObj](#)
[Import3DInterconnectData](#)

Return Value

Error codes as defined in [sw3DInterconnectImportErrors_e](#)

Visual Basic for Applications (VBA) Syntax

See [Feature::GetImportedFeatureParameters](#).

Example

See the [Import3DInterconnectData](#) examples.

Remarks

Before calling this method, use [IFeature::Is3DInterconnectFeature](#) to ensure that this is a 3D Interconnect feature.

See Also

[IFeature Interface](#)
[IFeature Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetImportedFileName Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetImportedFileName Method (IFeature)

Gets the file name from an imported feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetImportedFileName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.String
```

```
value = instance.GetImportedFileName()
```

C#


```
System.string GetImportedFileName()
```

C++/CLI

```
System.String^ GetImportedFileName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

File name of the imported feature

Visual Basic for Applications (VBA) Syntax

See [Feature::GetImportedFileName](#).

Remarks

This method applies only to imported features. All other features return an empty string. To get the type of this feature, use [IFeature::GetTypeName](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::SetImportedFileName Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetMaterialIdName Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetMaterialIdName Method (IFeature)

Gets the material name.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMaterialIdName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.String  
  
value = instance.GetMaterialIdName()
```

C#

```
System.string GetMaterialIdName()
```

C++/CLI

```
System.String^ GetMaterialIdName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Material name

Visual Basic for Applications (VBA) Syntax

See [Feature::GetMaterialIdName](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetMaterialUserName Method](#)
[IFeature::SetMaterialIdName Method](#)
[IFeature::SetMaterialUserName Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetMaterialPropertyValues Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetMaterialPropertyValues Method (IFeature)

Obsolete. Superseded by [IFeature::GetMaterialPropertyValues2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetMaterialPropertyValues() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Object  
  
value = instance.GetMaterialPropertyValues()
```

C#

```
System.object GetMaterialPropertyValues()
```

C++/CLI

```
System.Object^ GetMaterialPropertyValues();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Feature::GetMaterialPropertyValues](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetMaterialPropertyValues2 Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetMaterialPropertyValues2 Method (IFeature)

Gets the material property values for this feature in the specified configurations.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMaterialPropertyValues2( _  
    ByVal Config\_opt As System.Integer, _  
    ByVal Config\_names As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim Config_opt As System.Integer  
Dim Config_names As System.Object
```

```
Dim value As System.Object
```

```
value = instance.GetMaterialPropertyValues2(Config_opt, Config_names)
```

C#

```
System.Object GetMaterialPropertyValues2(  
    System.int Config\_opt,  
    System.Object Config\_names  
)
```

C++/CLI

```
System.Object^ GetMaterialPropertyValues2(  
& System.int Config\_opt,  
& System.Object^ Config\_names  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Config_opt

Configuration options as defined by [swInConfigurationOpts_e](#)

Config_names

Array of configuration names for this component (see **Remarks**)

Return Value

Array of material property values for this component

Visual Basic for Applications (VBA) Syntax

See [Feature::GetMaterialPropertyValues2](#).

Example

[Get Material Properties \(VBA\)](#)

Remarks

The material property values returned include the face color (R,G,B values), reflectivity (ambient, diffuse, specular, shininess), transparency, and emission. Valid values are between 0.0 and 1.0, inclusive, for all material properties. If a return value is -1, then that material property was not set for this feature.

If you set Config_opt to swThisConfiguration or swAllConfiguration, then Config_names is ignored. The size of the returned array depends on how you specify Config_opt and Config_names. See the example.

The format of the returned array:

[*R, G, B, Ambient, Diffuse, Specular, Shininess, Transparency, Emission*] * *number_of_configurations*

where:

number_of_configurations = number of configurations specified by Config_opt and Config_names

See Also

[IFeature Interface](#)

[IFeature Members](#)

[IFeature::GetMaterialPropertyValues2 Method](#)

[IFeature::SetMaterialPropertyValues2 Method](#)

[IFeature::RemoveMaterialProperty2 Method](#)

[IFeature::RemoveMaterialProperty2 Method](#)

[IFeature::SetMaterialPropertyValues2 Method](#)

[IFeature::HasMaterialPropertyValues Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

Gets the material name for this feature, which is visible to the user.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMaterialUserName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IFeature
Dim value As System.String

value = instance.GetMaterialUserName()
```

C#

```
System.string GetMaterialUserName()
```

C++/CLI

```
System.String^ GetMaterialUserName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Material user name property on this feature

Visual Basic for Applications (VBA) Syntax

See [Feature::GetMaterialUserName](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetMaterialIdName Method](#)
[IFeature::SetMaterialIdName Method](#)
[IFeature::SetMaterialUserName Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetModifiedVersion Method (IFeature)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > IFeature Interface : GetModifiedVersion Method (IFeature)

Gets the SOLIDWORKS version number in which this feature was last modified.

.NET Syntax

Visual Basic (Declaration)

```
Function GetModifiedVersion() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFeature
Dim value As System.Integer

value = instance.GetModifiedVersion()
```

C#

```
System.int GetModifiedVersion()
```

C++/CLI

```
System.int GetModifiedVersion();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

SOLIDWORKS version number in which this feature was last modified (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Feature::GetModifiedVersion](#).

Remarks

SOLIDWORKS Release	Version Number
SOLIDWORKS 95	44
SOLIDWORKS 96	243
SOLIDWORKS 97	483
SOLIDWORKS 97Plus	629
SOLIDWORKS 98	822
SOLIDWORKS 98Plus	1008
SOLIDWORKS 99	1137
SOLIDWORKS 2000	1500
SOLIDWORKS 2001	1750
SOLIDWORKS 2001Plus	1950
SOLIDWORKS 2003	2200
SOLIDWORKS 2004	2500
SOLIDWORKS 2005	2800
SOLIDWORKS 2006	3100
SOLIDWORKS 2007	3400
SOLIDWORKS 2008	3800
SOLIDWORKS 2009	4100
SOLIDWORKS 2010	4400
SOLIDWORKS 2011	4700
SOLIDWORKS 2012	5000
SOLIDWORKS 2013	6000
SOLIDWORKS 2014	7000
SOLIDWORKS 2015	8000
SOLIDWORKS 2016	9000
SOLIDWORKS 2017	10000
SOLIDWORKS 2018	11000
SOLIDWORKS 2019	12000
SOLIDWORKS 2020	13000
SOLIDWORKS 2021	14000

SOLIDWORKS Release	Version Number
SOLIDWORKS 2022	15000
SOLIDWORKS 2023	16000
SOLIDWORKS 2024	17000
SOLIDWORKS 2025	18000
SOLIDWORKS 2026	19000

To get the SOLIDWORKS version number in which the feature was created, use [IFeature::GetCreatedVersion](#).

 See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetCreatedVersion Method](#)
[ISldWorks::VersionHistory Method](#)
[ISldWorks::IVersionHistory Method](#)
[IModelDoc2::IVersionHistory Method](#)
[IModelDoc2::VersionHistory Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNameForSelection Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetNameForSelection Method (IFeature)

Gets the selected feature's type and name.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetNameForSelection( _  
    ByRef Type As System.String _  
) As System.String
```

Visual Basic (Usage)

```
Dim instance As IFeature  
Dim Type As System.String  
Dim value As System.String  
  
value = instance.GetNameForSelection(Type)
```

C#

```
System.string GetNameForSelection(  
    out System.string Type  
)
```

C++/CLI

```
System.String^ GetNameForSelection(  
& [Out] System.String^ Type  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Type
Type of feature as defined in [swSelectType_e](#)

Return Value

Name of feature

 Visual Basic for Applications (VBA) Syntax

See [Feature::GetNameForSelection](#).

Example

[Get Feature Type and Name \(C#\)](#)
[Get Feature Type and Name \(VB.NET\)](#)
[Get Feature Type and Name \(VBA\)](#)
[Get Selections for Reference Axis Feature \(C#\)](#)
[Get Selections for Reference Axis Feature \(VB.NET\)](#)
[Get Selections for Reference Axis Feature \(VBA\)](#)

Remarks

Call this method before calling [IModelDocExtension::SelectById2](#) to get the type and name to pass to that method.

NOTE: [IFeature::GetTypeName](#), [IFeature::GetTypeName2](#), and [IFeature::Name](#) do not return the type and name required by [IModelDocExtension::SelectById2](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeatureStatistics::FeatureTypes Property](#)
[IFeatureStatistics::FeatureNames Property](#)
[ISelectionMgr::GetSelectedObject6 Method](#)
[ISelectionMgr::GetSelectionSpecification Method](#)
[ISelectionMgr::GetSelectByIdSpecification Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNextDisplayDimension Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetNextDisplayDimension Method (IFeature)

Gets the next display dimension associated with this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNextDisplayDimension( _  
    ByVal DispIn As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim DispIn As System.Object  
Dim value As System.Object  
  
value = instance.GetNextDisplayDimension(DispIn)
```

C#

```
System.object GetNextDisplayDimension(  
    System.object DispIn  
)
```

C++/CLI

```
System.Object^ GetNextDisplayDimension(  
& System.Object^ DispIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DispIn

[IDisplayDimension](#) object obtained with [IFeature::GetFirstDisplayDimension](#) or from your previous call to this method

Return Value

Next [IDisplayDimension](#) object based on the Displn argument, or NULL if there are no more dimensions

Visual Basic for Applications (VBA) Syntax

See [Feature::GetNextDisplayDimension](#).

Example

[Traverse Annotations \(C#\)](#)
[Traverse Annotations \(VB.NET\)](#)
[Traverse Annotations \(VBA\)](#)

Remarks

Before you can get a feature's IDisplayDimension, use [IModelDoc2::SetUserPreferenceToggle](#) and swDisplayFeatureDimension to display them

All dimensions on this feature and its sub-features are returned by either [IFeature::GetFirstDisplayDimension](#) and IFeature::GetNextDisplayDimension or [IFeature::EnumDisplayDimensions](#). In the user-interface, this is equivalent to double-clicking a feature in the FeatureManager design tree to display all of the feature and sub-feature dimensions.

If you call this method from a sub-feature (for example, the sketch of a boss-extrude), then the IDisplayDimension object returned by IFeature::GetFirstDisplayDimension and IFeature::GetNextDisplayDimension contain only the dimensions found in the sketch.

This method might not always return display dimensions in the same order.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetDisplayDimension Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNextFeature Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetNextFeature Method (IFeature)

Gets the next feature in the part.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNextFeature() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Object  
  
value = instance.GetNextFeature()
```

C#

```
System.object GetNextFeature()
```

C++/CLI

```
System.Object^ GetNextFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next [feature](#)

Visual Basic for Applications (VBA) Syntax

See [Feature::GetNextFeature](#).

Example

[Iterate through Dimensions in Model \(VBA\)](#)
[Select Plane \(VBA\)](#)
[Set Dimensions to Mid-tolerance \(VBA\)](#)
[Suppress or Unsuppress Feature \(VBA\)](#)
[Traverse All Cosmetic Threads \(VBA\)](#)
[Traverse Assembly at Component and Feature Level \(VBA\)](#)
[Traverse Subfeatures \(VBA\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(C#\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(VB.NET\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(VBA\)](#)

Remarks

This method:

- allows you to access suppressed features.
- returns features in the current order for the model, and this order changes when the model is edited.

Your application should not assume that:

- features retain the same relative or absolute position throughout the model's lifetime. For example, you should not assume that Sketch1 always appears before Sketch2.
- any feature has a specific name. Because features can be renamed, you cannot assume that the first reference plane feature is named Plane1.

When traversing the FeatureManager design tree, your application should use [IFeature::GetTypeName2](#) and [IFeature::GetSpecificFeature2](#) to identify specific features instead of relying solely on [IFeature::Name](#).

This method returns features in the model definition order, which is not the same as the order displayed in the user interface.

See [ITreeControlItem](#) for details.

[IFeature::GetFirstSubFeature](#) and [IFeature::IGetFirstSubFeature](#) provide access to subfeatures.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetNextSubFeature Method](#)
[IFeature::IGetNextFeature Method](#)
[IFeature::IGetNextSubFeature Method](#)
[IComponent::FirstFeature Method](#)
[IPartDoc::FirstFeature Method](#)
[IPartDoc::IGetFirstFeature Method](#)
[IModelDoc2::FirstFeature Method](#)
[IModelDoc2::IGetFirstFeature Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNextSubFeature Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetNextSubFeature Method (IFeature)

Gets the next sub-feature from the owner of this sub-feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNextSubFeature() As System.Object
```

Visual Basic (Usage)

```
Dim instance As IFeature  
Dim value As System.Object  
  
value = instance.GetNextSubFeature()
```

C#

```
System.Object GetNextSubFeature()
```

C++/CLI

```
System.Object^ GetNextSubFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next sub-[feature](#)

Visual Basic for Applications (VBA) Syntax

See [Feature::GetNextSubFeature](#).

Example

[Iterate Through Dimensions in Model \(VBA\)](#)
[Traverse All Cosmetic Threads \(VBA\)](#)
[Traverse Assembly at Component and Feature Levels \(VBA\)](#)
[Traverse Subfeatures \(VBA\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(VBA\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(VB.NET\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(C#\)](#)

Remarks

If no sub-feature exists, then this method returns NULL.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetNextSubFeature Method](#)
[IFeature::MakeSubFeature Method](#)
[IFeature::GetChildren Method](#)
[IFeature::GetFirstSubFeature Method](#)
[IFeature::GetNextFeature Method](#)
[IFeature::GetFirstSubFeature Method](#)
[IFeature::GetNextFeature Method](#)
[IComponent2::FirstFeature Method](#)
[IModelDoc2::FirstFeature Method](#)
[IModelDoc2::IFirstFeature Method](#)
[IPartDoc::FirstFeature Method](#)
[IPartDoc::IFirstFeature Method](#)
[IFeature::GetOwnerFeature Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetOwnerFeature Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetOwnerFeature Method (IFeature)

Gets the feature that owns this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetOwnerFeature() As Feature
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As Feature
```

```
value = instance.GetOwnerFeature()
```

C#

```
Feature GetOwnerFeature()
```

C++/CLI

```
Feature^ GetOwnerFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [feature](#) that owns this feature

Visual Basic for Applications (VBA) Syntax

See [Feature::GetOwnerFeature](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetChildren Method](#)
[IFeature::GetFirstSubFeature Method](#)
[IFeature::GetNextSubFeature Method](#)
[IFeature::GetParents Method](#)
[IFeature::IGetChildren Method](#)
[IFeature::IGetFirstSubFeature Method](#)
[IFeature::IGetNextSubFeature Method](#)
[IFeature::IGetParents Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetParents Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetParents Method (IFeature)

Gets the parent features for this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetParents() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Object  
  
value = instance.GetParents()
```

C#

```
System.object GetParents()
```

C++/CLI

```
System.Object^ GetParents();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array pointers to the parent [features](#)

Visual Basic for Applications (VBA) Syntax

See [Feature::GetParents](#).

Example

[Get Parent Feature Using Collections \(VBA\)](#)
[Get Parent-Child Relationship for Component \(VBA\)](#)
[Get Plane Where Sketch Was Created \(VBA\)](#)

Remarks

This method gets only the direct parents of this feature. It does not get parents of parents.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetChildren Method](#)
[IFeature::GetOwnerFeature Method](#)

[IFeature::IGetChildCount Method](#)
[IFeature::IGetChildren Method](#)
[IFeature::IGetParents Method](#)
[IFeature::IGetParentCount Method](#)

Availability

SOLIDWORKS 99, datecode 1999207