

SOLIDWORKS API (.NET VBA C#) — Reference (111/337): IFeature (part 2 of 3)

SOLIDWORKS API Documentation (converted from CHM)

IFeature (part 2 of 3) (Type)

GetPropertyExtension Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetPropertyExtension Method (IFeature)

Gets the property extension on this feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetPropertyExtension( _  
    ByVal ID As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim ID As System.Integer  
Dim value As System.Object  
  
value = instance.GetPropertyExtension(ID)
```

C#

```
System.object GetPropertyExtension(  
    System.int ID  
)
```

C++/CLI

```
System.Object^ GetPropertyExtension(  
& System.int ID  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ID
0

Return Value

Value of the property extension on this feature

Visual Basic for Applications (VBA) Syntax

See [Feature::GetPropertyExtension](#).

Remarks

SOLIDWORKS recommends that you use the [IAttribute](#), [IAttributeDef](#), or [IParameter](#) interfaces instead of this method. These interfaces provide more flexibility.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::AddPropertyExtension Method](#)
[IFeature::ResetPropertyExtension Method](#)

GetSpecificFeature Method (IFeature)

[See Also](#)



Obsolete. Superseded by [IFeature::GetSpecificFeature2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetSpecificFeature() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Object  
  
value = instance.GetSpecificFeature()
```

C#

```
System.object GetSpecificFeature()
```

C++/CLI

```
System.Object^ GetSpecificFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Feature::GetSpecificFeature](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSpecificFeature2 Method (IFeature)

[See Also](#) [Example](#)



SolidWorks.Interop.sldworks Namespace > IFeature Interface : GetSpecificFeature2 Method (IFeature)

Gets the more specific interface to a selected feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSpecificFeature2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Object  
  
value = instance.GetSpecificFeature2()
```

C#

```
System.object GetSpecificFeature2()
```

C++/CLI

```
System.Object^ GetSpecificFeature2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Specific interface (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Feature::GetSpecificFeature2](#).

Example

[Get Spline Points \(C++\)](#)
[Determine if Sketch Suitable for Feature \(VBA\)](#)
[Find Total Length of Sketch Segments in Sketch \(VBA\)](#)
[Get Parameters for Reference Axis \(VBA\)](#)
[Get Sketch Constraints \(VBA\)](#)
[Insert and Position DXF File in Drawing \(VBA\)](#)
[Insert DXF File and Add Dimension \(VBA\)](#)
[Insert Reference Points \(VBA\)](#)
[Get Areas of MidSurface Faces \(C#\)](#)
[Get Areas of MidSurface Faces \(VB.NET\)](#)
[Get Areas of MidSurface Faces \(VBA\)](#)

Remarks

This method gets these interfaces to a corresponding selected feature:

- [IAttribute](#)
- [IBodyFolder](#)
- [IBomFeature](#)
- [ICamera](#)
- [ICommentFolder](#)
- [ICosmeticWeldBeadFolder](#)
- [IDetailCircle](#)
- [IDrSection](#)
- [IFeatureFolder](#)
- [IFlatPatternFolder](#)
- [ILight](#)
- [IMate2](#)
- [IMateInPlace](#)
- [IMateReference](#)
- [IMidSurface3](#)
- [IProfileGroupFolder](#)
- [IRadius](#)
- [IRelativeCurve](#)
- [IRelPlane](#)
- [IRelPoint](#)
- [ISelectorSetFolder](#)
- [ISensor](#)
- [ISheetMetalFolder](#)
- [ISketch](#)
- [ISketchBlockDefinition](#)
- [ISketchBlockInstance](#)
- [ISketchPicture](#)
- [IStructureSystemFolder](#)
- [IWeldmentCutListFeature](#)

If...	Then...
You start with an IFeature object and want to get a more specific object	A call to IFeature::GetSpecificFeature2 is required. If you have the more specific object, then a call to QueryInterface in C++ or an assignment to a IFeature-typed variable allows an application to get back to the IFeature object.
You are writing a Dispatch application	You can use IFeature::GetTypeName or IFeature::GetTypeName2 to identify the type of Dispatch object returned so that you can call the appropriate properties and methods for that object.
You are writing a COM application	You can use the return value with QueryInterface to determine the object returned.
No interface exists or there is no specific object for the type of feature	This method returns Nothing or null.

For some feature types, this method returns Nothing or null because there is no specific object for that type of feature (e.g., features such as extrusions, lofts, fillets, chamfers, etc.). For these types of features, call [IFeature::GetDefinition](#) to get their feature data objects.

For other entities selected in the FeatureManager design tree, you must know its interface in advance and cast the return value of [ISelectionMgr::GetSelectedObject6](#) to the correct interface.

For all functions that return objects, always check whether the return value is Nothing or null before you try to use it.

See Also

[IFeature Interface](#)
[IFeature Members](#)

Availability

GetTexture Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetTexture Method (IFeature)

Gets the texture applied to this feature in the specified configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTexture( _  
    ByVal Config\_name As System.String _  
) As Texture
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim Config_name As System.String  
Dim value As Texture  
  
value = instance.GetTexture(Config_name)
```

C#

```
Texture GetTexture(  
    System.string Config\_name  
)
```

C++/CLI

```
Texture^ GetTexture(  
& System.String^ Config\_name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Config_name
Name of the configuration

Return Value

If texture is...	Then retval is...
Applied to this feature in Cofig_name	Pointer to ITexture object
Not present	NULL

Visual Basic for Applications (VBA) Syntax

See [Feature::GetTexture](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::RemoveTexture Method](#)
[IFeature::SetTexture Method](#)
[IFeature::RemoveTextureByDisplayState Method](#)
[IFeature::SetTextureByDisplayState Method](#)
[IModelDocExtension::CreateTexture Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetTypeName Method (IFeature)

Gets the type of feature.

NOTE: To get the underlying type of feature of an Instant3D feature (i.e., "ICE"), call this method; otherwise, call [IFeature::GetTypeName2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTypeName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.String  
  
value = instance.GetTypeName()
```

C#

```
System.string GetTypeName()
```

C++/CLI

```
System.String^ GetTypeName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

String identifying the type of feature (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Feature::GetTypeName](#).

Example

[Get Faces Associated with Feature \(VBA\)](#)
[Select Origin of Assembly Component \(VBA\)](#)
[Set Custom Bend Deduction \(VBA\)](#)
[Traverse All Cosmetic Threads \(VBA\)](#)
[Traverse Assembly at Component and Feature Level \(VBA\)](#)
[Get Info on Plane Axis \(C++\)](#)
[Get Parent Features \(C++\)](#)
[Get Selected Feature \(C++\)](#)
[Get Type of Instant3D Feature \(C#\)](#)
[Get Type of Instant3D Feature \(VB.NET\)](#)
[Get Type of Instant3D Feature \(VBA\)](#)

Remarks

Use [IFeature::GetDefinition](#) to get a feature data object (i.e., an object whose interface name ends in FeatureData or FeatureData2, such as ISymmetricMateFeatureData, IExtrudeFeatureData2, ILoftFeatureData, ISimpleFilletFeatureData2, IChamferFeatureData2, etc.); otherwise, use [IFeature::GetSpecificFeature2](#) to get an object for a feature.

Type of feature	String returned by this method	Interface
Assembly	AsmExploder	None (Assembly exploded view in ConfigurationManager)
	CompExplodeStep	None (Explode step in assembly exploded view)
	ExplodeLineProfileFeature	ISketch
	InContextFeathHolder	IFeature
	MagneticGroundPlane	IFeature
	MateCamTangent	ICamFollowerMateFeatureData
	MateCoincident	ICoincidentMateFeatureData
	MateConcentric	IConcentricMateFeatureData
	MateDistanceDim	IDistanceMateFeatureData
	MateGearDim	IGearMateFeatureData
	MateHinge	IHingeMateFeatureData
	MateInPlace	IMate2
	MateLimitDistanceDim	IDistanceMateFeatureData
	MateLinearCoupler	ILinearCouplerMateFeatureData
	MateLock	ILockMateFeatureData

Type of feature	String returned by this method	Interface
	MateParallel	IParallelMateFeatureData
	MatePerpendicular	IPerpendicularMateFeatureData
	MatePlanarAngleDim	IAngleMateFeatureData
	MateProfileCenter	IProfileCenterMateFeatureData
	MateRackPinionDim	IRackPinionMateFeatureData
	MateScrew	IScrewMateFeatureData
	MateSlot	ISlotMateFeatureData
	MateSymmetric	ISymmetricMateFeatureData
	MateTangent	ITangentMateFeatureData
	MateUniversalJoint	IUniversalJointMateFeatureData
	MateWidth	IWidthMateFeatureData
	PosGroupFolder	IMateReference
	Reference	IComponent2
	ReferencePattern	IComponent2
	SmartComponentFeature	ISmartComponentFeatureData
Body	AdvHoleWzd	IAdvancedHoleFeatureData
	APattern	IFillPatternFeatureData
	BaseBody	IExtrudeFeatureData2
	Bending	None (Flex feature)
	Blend	ILoftFeatureData
	BlendCut	ILoftFeatureData
	BodyExplodeStep	None (Explode step of multi-body part exploded view)
	Boss	IExtrudeFeatureData2
	BossThin	IExtrudeFeatureData2
	Chamfer	IChamferFeatureData2
	CirPattern	ICircularPatternFeatureData
	CombineBodies	ICombineBodiesFeatureData
	CosmeticThread	ICosmeticThreadFeatureData
	CosmeticWeldBead	ICosmeticWeldBeadFeatureData
	CreateAssemFeat	ISaveBodyFeatureData
	CurvePattern	ICurveDrivenPatternFeatureData
	Cut	IExtrudeFeatureData2
	CutThin	IExtrudeFeatureData2
	Deform	None (Deform feature)
	DeleteBody	IDeleteBodyFeatureData
	DelFace	IDeleteFaceFeatureData
	DerivedCirPattern	IDerivedPatternFeatureData
	DerivedHolePattern	IDerivedPatternFeatureData
	DerivedLPattern	IDerivedPatternFeatureData
	DimPattern	IDimPatternFeatureData
	Dome	IDomeFeatureData2
	Draft	IDraftFeatureData2
	EdgeMerge	IHealEdgesFeatureData
	Emboss	IWrapSketchFeatureData
	Extrusion	IExtrudeFeatureData2
	Fillet	ISimpleFilletFeatureData2
	Helix	IHelixFeatureData
	HoleSeries	IHoleSeriesFeatureData2
	HoleWzd	IWizardHoleFeatureData2
	Imported	None (Imported feature)
	LocalChainPattern	IChainPatternFeatureData
	LocalCirPattern	ILocalCircularPatternFeatureData
	LocalCurvePattern	ILocalCurvePatternFeatureData
	LocalLPattern	ILocalLinearPatternFeatureData
	LocalSketchPattern	ILocalSketchPatternFeatureData
	LPattern	ILinearPatternFeatureData
	MacroFeature	IMacroFeatureData
	MirrorCompFeat	IMirrorComponentFeatureData
	MirrorPattern	IMirrorPatternFeatureData
	MirrorSolid	IMirrorSolidFeatureData
	MirrorStock	IMirrorPartFeatureData
	MoveCopyBody	IMoveCopyBodyFeatureData
	NetBlend	IBoundaryBossFeatureData
	PrtExploder	None (Multi-body part exploded view)
	Punch	IIndentFeatureData
	ReplaceFace	IReplaceFaceFeatureData
	RevCut	IRevolveFeatureData2
	Revolution	IRevolveFeatureData2
	RevolutionThin	IRevolveFeatureData2
	Rib	IRibFeatureData2
	Rip	IRipFeatureData
	Round fillet corner	ISimpleFilletFeatureData2
	Sculpt	IIntersectFeatureData
	Shape	Obsolete

Type of feature	String returned by this method	Interface
	Shell	IShellFeatureData
	SketchHole	ISimpleHoleFeatureData2
	SketchPattern	ISketchPatternFeatureData
	Split	ISplitBodyFeatureData for a feature that was created by splitting a part into multiple parts using either IFeatureManager.PostSplitBody or the Split feature in the user interface
	SplitBody	None; returned for a body created by splitting a part and saving the body to a part; you cannot access the data of a split body saved to a part
	Stock	IDerivedPartFeatureData
	Sweep	ISweepFeatureData
	SweepCut	ISweepFeatureData
	SweepThread	IThreadFeatureData
	TablePattern	ITablePatternFeatureData
	Thicken	IThickenFeatureData
	ThickenCut	IThickenFeatureData
	VarFillet	IVariableFilletFeatureData2
	BendTableAnchor	ITableAnchor
Drawing	BomFeat	IBomFeature
	BomTemplate	ITableAnchor
	DetailCircle	IDetailCircle
	DrBreakoutSectionLine	IDrSection or IBrokenOutSectionFeatureData
	DrSectionLine	IDrSection
	GeneralTableAnchor	ITableAnchor
	HoleTableAnchor	ITableAnchor
	LiveSection	IRefPlane
	PunchTableAnchor	ITableAnchor
	RevisionTableAnchor	ITableAnchor
	WeldmentTableAnchor	ITableAnchor
	WeldTableAnchor	ITableAnchor
	FamilyTableFeat	IFamilyTableFeature
	BlockFolder	Obsolete
	CommentsFolder	ICommentFolder
Folder	CosmeticWeldSubFolder	ICosmeticWeldBeadFolder
	CutListFolder	IBodyFolder
	FeatSolidBodyFolder	IBodyFolder
	FeatSurfaceBodyFolder	IBodyFolder
	FtrFolder	IFeatureFolder
	InsertedFeatureFolder	IFeatureFolder
	MateReferenceGroupFolder	IFeatureFolder
	ProfileFtrFolder	IFeatureFolder
	RefAxisFtrFolder	IFeatureFolder
	RefPlaneFtrFolder	IFeatureFolder
	SketchSliceFolder	IFeatureFolder
	SolidBodyFolder	IBodyFolder
	SubAtomFolder	IBodyFolder if a body
	SubWeldFolder	IBodyFolder
	SurfaceBodyFolder	IBodyFolder
	TemplateFlatPattern	IFlatPatternFolder
Imported File	MBImport	IImport3DInterconnectData
Miscellaneous	Attribute	IAttribute
	BlockDef	Obsolete
	CurveInFile	IFreePointCurveFeatureData
	GridFeature	None (Grid feature)
	LibraryFeature	ILibraryFeatureData
	Scale	IScaleFeatureData
	Sensor	ISensor
	ViewBodyFeature	Obsolete
Mold	Cavity	ICavityFeatureData
	MoldCoreCavitySolids	IToolingSplitFeatureData
	MoldPartingGeom	IPartingSurfaceFeatureData
	MoldPartLine	IPartingLineFeatureData
	MoldShutOffSrf	IShutOffSurfaceFeatureData
	SideCore	ICoreFeatureData
Motion and Simulation	XformStock	DerivedPartFeatureData
	AEM3DContact	ISimulation3DContactFeatureData
	AEMGravity	ISimulationGravityFeatureData
	AEMLinearDamper	ISimulationDamperFeatureData
	AEMLinearMotor	ISimulationMotorFeatureData
	AEMLinearSpring	ISimulationLinearSpringFeatureData
	AEMRotationalMotor	ISimulationMotorFeatureData
	AEMTorque	ISimulationForceFeatureData
	AEMTorsionalDamper	ISimulationDamperFeatureData
	AEMTorsionalSpring	None (TorsionalSpring feature)
	SimPlotFeature	IMotionPlotFeatureData
	SimPlotXAxisFeature	IMotionPlotAxisFeatureData

Type of feature	String returned by this method	Interface
Reference Geometry	SimPlotAxisFeature	IMotionPlotAxisFeatureData
	SimResultFolder	IMotionStudyResults
	BoundingBox	IBoundingBoxFeatureData
	CenterOfMass	ICenterOfMass
	CoordSys	ICoordinateSystemFeatureData
	GroundPlane	IGroundPlaneFeatureData
Scenes, Lights, and Cameras	RefAxis	IRefAxis or IRefAxisFeatureData
	RefPlane	IRefPlane or IRefPlaneFeatureData
	AmbientLight	ILight
	CameraFeature	ICamera
	DirectionLight	ILight
Sheet Metal	PointLight	ILight
	SpotLight	ILight
	SMBaseFlange	IBaseFlangeFeatureData
	BreakCorner	IBreakCornerFeatureData
	CornerTrim	IBreakCornerFeatureData
	CrossBreak	ICrossBreakFeatureData
	EdgeFlange	IEdgeFlangeFeatureData
	FlatPattern	IFlatPatternFeatureData
	FlattenBends	IBendsFeatureData
	Fold	IFoldsFeatureData
	FormToolInstance	None (FormTool feature)
	Hem	IHemFeatureData
	Jog	IJogFeatureData
	LoftedBend	ILOftedBendsFeatureData
	Normal Cut	ISMNormalCutFeatureData2
	OneBend	IOneBendFeatureData
	ProcessBends	IBendsFeatureData
	SheetMetal	ISheetMetalFeatureData
	SketchBend	IOneBendFeatureData
	SM3dBend	ISketchedBendFeatureData
	SMGusset	ISMGussetFeatureData
	SMMiteredFlange	IMiterFlangeFeatureData
	SolidToSheetMetal	IConvertSolidFeatureData
	TemplateSheetMetal	ISheetMetalFolder
	ToroidalBend	IOneBendFeatureData
	UnFold	IFoldsFeatureData
Sketch	3DProfileFeature	ISketch
	3DSplineCurve	IReferenceCurve or IReferencePointCurveFeatureData
	CompositeCurve	IReferenceCurve or ICompositeCurveFeatureData
	ImportedCurve	IReferenceCurve or IImportedCurveFeatureData
	PLine	ISplitLineFeatureData
	ProfileFeature	ISketch
	RefCurve	IReferenceCurve or IProjectionCurveFeatureData
	RefPoint	IRefPoint or IRefPointFeatureData
	SketchBlockDef	ISketchBlockDefinition
	SketchBlockInst	ISketchBlockInstance
	SketchBitmap	ISketchPicture
Surface	BlendRefSurface	None (Surface-Loft feature)
	ExtendRefSurface	ISurfaceExtendFeatureData
	ExtruRefSurface	ISurfExtrudeFeatureData
	FillRefSurface	IFillSurfaceFeatureData
	FlattenSurface	ISurfaceFlattenFeatureData
	MidRefSurface	IMidSurface3
	OffsetRefSurface	ISurfaceOffsetFeatureData
	PlanarSurface	ISurfacePlanarFeatureData
	RadiateRefSurface	ISurfaceRadiateFeatureData
	RefSurface	None (Surface-Imported feature)
	RevolvRefSurf	ISurfRevolveFeatureData
	RuledSrfFromEdge	IRuledSurfaceFeatureData
	SewRefSurface	ISurfaceKnitFeatureData
	SurfCut	ISurfaceCutFeatureData
	SweepRefSurface	ISweepFeatureData
	TrimRefSurface	ISurfaceTrimFeatureData
	UnTrimRefSurf	None (Surface-Untrim feature)
Weldment and Structure System	EndCap	IEndCapFeatureData
	StrctSysBtwPtsMbrFeat	ISecondaryMemberBetweenPointsFeatureData
	StrctSysCnrFeat	ICornerMember
	StrctSysCnrGrpFeat	ICornerTreatmentGroupFolder
	StrctSysCnrMgmtFeat	ICornerManagementFolder
	StrctSysFeat	IStructureSystemFolder
	StrctSysGrpFeat	IProfileGroupFolder
	StrctSysPathSegMbrFeat	IPrimaryMemberPathSegmentFeatureData
	StrctSysPtToMem	ISecondaryMemberUpToMembersFeatureData

Type of feature	String returned by this method	Interface
	StrctSysRefPinMbrFeat	IPrimaryMemberRefPlaneFeatureData
	StrctSysSkPtlLenMbrFeat	IPrimaryMemberPointLengthFeatureData
	StrctSysSupPinMbrFeat	ISecondaryMemberSupportPlaneFeatureData
	StrctSysSurfPinMbrFeat	IPrimaryMemberFacePlaneIntersectionFeatureData
	AdvStructMember	IStructureSystemMemberFeatureData
	Gusset	IGussetFeatureData
	WeldBeadFeat	IWeldmentBeadFeatureData
	WeldCornerFeat	IWeldmentTrimExtendFeatureData
	WeldMemberFeat	IStructuralMemberFeatureData
	WeldmentFeature	IStructuralMemberFeatureData
	WeldmentTableFeat	IWeldmentCurlListFeature

NOTE: This method returns strings for some features shown in the FeatureManager design (e.g., **MateGroup**, **Weldment**, etc.) that set up the design functionality environment and, thus, do not have interfaces.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::Name Property](#)
[IFeature::GetNameForSelection Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTypeName2 Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetTypeName2 Method (IFeature)

Gets the type of feature.

NOTE: To get the underlying type of feature of an Instant3D feature (i.e., "ICE"), call [IFeature::GetTypeName](#); otherwise, call this method.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTypeName2() As System.String
```

Visual Basic (Usage)



```
Dim instance As IFeature
Dim value As System.String

value = instance.GetTypeName2()
```

C#

```
System.string GetTypeName2()
```

C++/CLI

```
System.String^ GetTypeName2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

String identifying the type of feature (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Feature::GetTypeName2](#).

Example

[Create Ellipse \(VBA\)](#)
[Add Spring to Motion Study \(C#\)](#)
[Add Spring to Motion Study \(VB.NET\)](#)
[Add Spring to Motion Study \(VBA\)](#)
[Get Type of Instant3D Feature \(C#\)](#)
[Get Type of Instant3D Feature \(VB.NET\)](#)
[Get Type of Instant3D Feature \(VBA\)](#)

Remarks

Use [IFeature::GetDefinition](#) to get a feature data object (i.e., an object whose interface name ends in FeatureData or FeatureData2, such as ISymmetricMateFeatureData, IExtrudeFeatureData2, ILoftFeatureData, ISimpleFilletFeatureData2, IChamferFeatureData2, etc.); otherwise, use [IFeature::GetSpecificFeature2](#) to get an object for a feature.

Type of feature	String returned by this method	Interface
Assembly	AsmExploder	None (Assembly exploded view in ConfigurationManager)
	CompExplodeStep	None (Explode step for assembly exploded view)
	ExplodeLineProfileFeature	ISketch
	InContextFeatHolder	IFeature
	MagneticGroundPlane	IFeature
	MateCamTangent	ICamFollowerMateFeatureData
	MateCoincident	ICoincidentMateFeatureData
	MateConcentric	IConcentricMateFeatureData
	MateDistanceDim	IDistanceMateFeatureData
	MateGearDim	IGearMateFeatureData
	MateHinge	IHingeMateFeatureData
	MateInPlace	IMate2
	MateLimitDistanceDim	IDistanceMateFeatureData
	MateLinearCoupler	ILinearCouplerMateFeatureData
	MateLock	ILockMateFeatureData
	MateParallel	IParallelMateFeatureData
	MatePerpendicular	IPerpendicularMateFeatureData
	MatePlanarAngleDim	IAngleMateFeatureData
	MateProfileCenter	IProfileCenterMateFeatureData
	MateRackPinionDim	IRackPinionMateFeatureData
	MateScrew	IScrewMateFeatureData
	MateSlot	ISlotMateFeatureData
	MateSymmetric	ISymmetricMateFeatureData
	MateTangent	ITangentMateFeatureData
	MateUniversalJoint	IUniversalJointMateFeatureData
	MateWidth	IWidthMateFeatureData
	PosGroupFolder	IMateReference
	Reference	IComponent2
	ReferencePattern	IComponent2
	SmartComponentFeature	ISmartComponentFeatureData
Body	AdvHoleWzd	IAdvancedHoleFeatureData
	APattern	IFillPatternFeatureData
	BaseBody	IExtrudeFeatureData2
	Bending	None (Flex feature)
	Blend	ILoftFeatureData
	BlendCut	ILoftFeatureData
	BodyExplodeStep	None (Explode step in multi-body part exploded view)
	Boss	IExtrudeFeatureData2
	BossThin	IExtrudeFeatureData2
	Chamfer	IChamferFeatureData2
	CirPattern	ICircularPatternFeatureData
	CombineBodies	ICombineBodiesFeatureData
	CosmeticThread	ICosmeticThreadFeatureData
	CosmeticWeldBead	ICosmeticWeldBeadFeatureData
	CreateAssemFeat	ISaveBodyFeatureData
	CurvePattern	ICurveDrivenPatternFeatureData
	Cut	IExtrudeFeatureData2
	CutThin	IExtrudeFeatureData2
	Deform	None (Deform feature)
	DeleteBody	IDeleteBodyFeatureData
	DelFace	IDeleteFaceFeatureData
	DerivedCirPattern	IDerivedPatternFeatureData
	DerivedHolePattern	IDerivedPatternFeatureData
	DerivedLPattern	IDerivedPatternFeatureData
	DimPattern	IDimPatternFeatureData
	Dome	IDomeFeatureData2
	Draft	IDraftFeatureData2
	EdgeMerge	IHealEdgesFeatureData
	Emboss	IWrapSketchFeatureData
	Extrusion	IExtrudeFeatureData2
	Fillet	ISimpleFilletFeatureData2
	Helix	IHelixFeatureData
	HoleSeries	IHoleSeriesFeatureData2
	HoleWzd	IWizardHoleFeatureData2
	Imported	None (Imported feature)
	LocalChainPattern	IChainPatternFeatureData
	LocalCirPattern	ILocalCircularPatternFeatureData

Type of feature	String returned by this method	Interface
	LocalCurvePattern	ILocalCurvePatternFeatureData
	LocalLPattern	ILocalLinearPatternFeatureData
	LocalSketchPattern	ILocalSketchPatternFeatureData
	LPattern	ILinearPatternFeatureData
	MacroFeature	IMacroFeatureData
	MirrorCompFeat	IMirrorComponentFeatureData
	MirrorPattern	IMirrorPatternFeatureData
	MirrorSolid	IMirrorSolidFeatureData
	MirrorStock	IMirrorPartFeatureData
	MoveCopyBody	IMoveCopyBodyFeatureData
	NetBlend	IBoundaryBossFeatureData
	PrtExploder	None (Multi-body part exploded view in ConfigurationManager)
	Punch	IIndentFeatureData
	ReplaceFace	IReplaceFaceFeatureData
	RevCut	IRevolveFeatureData2
	Revolution	IRevolveFeatureData2
	RevolutionThin	IRevolveFeatureData2
	Rib	IRibFeatureData2
	Rip	IRipFeatureData
	Round fillet corner	ISimpleFilletFeatureData2
	Sculpt	IIntersectFeatureData
	Shape	Obsolete
	Shell	IShellFeatureData
	SketchHole	ISimpleHoleFeatureData2
	SketchPattern	ISketchPatternFeatureData
	Split	ISplitBodyFeatureData for a feature that was created by splitting a part into multiple parts using either IFeatureManager.PostSplitBody or the Split feature in the user interface
	SplitBody	None; returned for a body created by splitting a part and saving the body to a part; you cannot access the data of a split body saved to a part
	Stock	IDerivedPartFeatureData
	Sweep	ISweepFeatureData
	SweepCut	ISweepFeatureData
	SweepThread	IThreadFeatureData
	TablePattern	ITablePatternFeatureData
	Thicken	IThickenFeatureData
	ThickenCut	IThickenFeatureData
	VarFillet	IVariableFilletFeatureData2
Drawing	BendTableAnchor	ITableAnchor
	BomFeat	IBomFeature
	BomTemplate	ITableAnchor
	DetailCircle	IDetailCircle
	DrBreakoutSectionLine	IDrSection or IBrokenOutSectionFeatureData
	DrSectionLine	IDrSection
	GeneralTableAnchor	ITableAnchor
	HoleTableAnchor	ITableAnchor
	LiveSection	IRefPlane
	PunchTableAnchor	ITableAnchor
	RevisionTableAnchor	ITableAnchor
	WeldmentTableAnchor	ITableAnchor
	FamilyTableFeat	IFamilyTableFeature
	WeldTableAnchor	ITableAnchor
Folder	BlockFolder	Obsolete
	CommentsFolder	ICommentFolder
	CosmeticWeldSubFolder	ICosmeticWeldBeadFolder
	CutListFolder	IBodyFolder
	FeatSolidBodyFolder	IBodyFolder
	FeatSurfaceBodyFolder	IBodyFolder
	FtrFolder	IFeatureFolder
	InsertedFeatureFolder	IFeatureFolder
	MateReferenceGroupFolder	IFeatureFolder
	ProfileFtrFolder	IFeatureFolder
	RefAxisFtrFolder	IFeatureFolder
	RefPlaneFtrFolder	IFeatureFolder
	SketchSliceFolder	IFeatureFolder
	SolidBodyFolder	IBodyFolder
	SubAtomFolder	IBodyFolder if a body
	SubWeldFolder	IBodyFolder
	SurfaceBodyFolder	IBodyFolder
	TemplateFlatPattern	IFlatPatternFolder
Imported File	MBImport	IImport3DInterconnectData
Miscellaneous	Attribute	IAttribute
	BlockDef	Obsolete
	CurveInFile	IFreePointCurveFeatureData
	GridFeature	None (Grid feature)

Type of feature	String returned by this method	Interface
	LibraryFeature	ILibraryFeatureData
	Scale	IScaleFeatureData
	Sensor	ISensor
	ViewBodyFeature	Obsolete
	Cavity	ICavityFeatureData
	MoldCoreCavitySolids	IToolingSplitFeatureData
	MoldPartingGeom	IPartingSurfaceFeatureData
Mold	MoldPartLine	IPartingLineFeatureData
	MoldShutOffSrf	IShutOffSurfaceFeatureData
	SideCore	ICoreFeatureData
	XformStock	DerivedPartFeatureData
	AEM3DContact	ISimulation3DContactFeatureData
	AEMGravity	ISimulationGravityFeatureData
	AEMLinearDamper	ISimulationDamperFeatureData
Motion and Simulation	AEMLinearMotor	ISimulationMotorFeatureData
	AEMLinearSpring	ISimulationLinearSpringFeatureData
	AEMRotationalMotor	ISimulationMotorFeatureData
	AEMTorque	ISimulationForceFeatureData
	AEMTorsionalDamper	ISimulationDamperFeatureData
	AEMTorsionalSpring	None (TorsionalSpring feature)
	SimPlotFeature	IMotionPlotFeatureData
	SimPlotXAxisFeature	IMotionPlotAxisFeatureData
	SimPlotYAxisFeature	IMotionPlotAxisFeatureData
	SimResultFolder	IMotionStudyResults
	BoundingBox	IBoundingBoxFeatureData
	CenterOfMass	ICenterOfMass
Reference Geometry	CoordSys	ICoordinateSystemFeatureData
	GroundPlane	IGroundPlaneFeatureData
	RefAxis	IRefAxis or IRefAxisFeatureData
	RefPlane	IRefPlane or IRefPlaneFeatureData
Scenes, Lights, and Cameras	AmbientLight	ILight
	CameraFeature	ICamera
	DirectionLight	ILight
	PointLight	ILight
	SpotLight	ILight
Sheet Metal	SMBaseFlange	IBaseFlangeFeatureData
	BreakCorner	IBreakCornerFeatureData
	CornerTrim	IBreakCornerFeatureData
	CrossBreak	ICrossBreakFeatureData
	EdgeFlange	IEdgeFlangeFeatureData
	FlatPattern	IFlatPatternFeatureData
	FlattenBends	IBendsFeatureData
	Fold	IFoldsFeatureData
	FormToolInstance	None (FormTool feature)
	Hem	IHemFeatureData
	Jog	IJogFeatureData
	LoftedBend	ILOftedBendsFeatureData
	NormalCut	ISMNormalCutFeatureData2
	OneBend	IOneBendFeatureData
	ProcessBends	IBendsFeatureData
	SheetMetal	ISheetMetalFeatureData
	SketchBend	IOneBendFeatureData
	SM3dBend	ISketchdBendFeatureData
	SMGusset	ISMGussetFeatureData
	SMMiteredFlange	IMiterFlangeFeatureData
	SolidToSheetMetal	IConvertSolidFeatureData
	TemplateSheetMetal	ISheetMetalFolder
	ToroidalBend	IOneBendFeatureData
	UnFold	IFoldsFeatureData
Sketch	3DProfileFeature	ISketch
	3DSplineCurve	IReferenceCurve or IReferencePointCurveFeatureData
	CompositeCurve	IReferenceCurve or ICompositeCurveFeatureData
	ImportedCurve	IReferenceCurve or IImportedCurveFeatureData
	PLine	ISplitLineFeatureData
	ProfileFeature	ISketch
	RefCurve	IReferenceCurve or IProjectionCurveFeatureData
	RefPoint	IRefPoint or IRefPointFeatureData
	SketchBlockDef	ISketchBlockDefinition
	SketchBlockInst	ISketchBlockInstance
	SketchBitmap	ISketchPicture
Surface	BlendRefSurface	None (Surface-Loft feature)
	ExtendRefSurface	ISurfaceExtendFeatureData
	ExtruRefSurface	ISurfExtrudeFeatureData
	FillRefSurface	IFillSurfaceFeatureData

Type of feature	String returned by this method	Interface
	FlattenSurface	ISurfaceFlattenFeatureData
	MidRefSurface	IMidSurface3
	OffsetRefSurface	ISurfaceOffsetFeatureData
	PlanarSurface	ISurfacePlanarFeatureData
	RadiateRefSurface	ISurfaceRadiateFeatureData
	RefSurface	None (Surface-Imported feature)
	RevolveRefSurf	ISurfRevolveFeatureData
	RuledSrfFromEdge	IRuledSurfaceFeatureData
	SewRefSurface	ISurfaceKnitFeatureData
	SurfCut	ISurfaceCutFeatureData
	SweepRefSurface	ISweepFeatureData
	TrimRefSurface	ISurfaceTrimFeatureData
	UnTrimRefSurf	None (Surface-Untrim feature)
Weldment and Structure System	EndCap	IEndCapFeatureData
	StrctSysBtwPtsMbrFeat	ISecondaryMemberBetweenPointsFeatureData
	StrctSysCnrFeat	ICornerMember
	StrctSysCnrGrpFeat	ICornerTreatmentGroupFolder
	StrctSysCnrMgmtFeat	ICornerManagementFolder
	StrctSysFeat	IStructureSystemFolder
	StrctSysGrpFeat	IProfileGroupFolder
	StrctSysPathSegMbrFeat	IPrimaryMemberPathSegmentFeatureData
	StrctSysPToMem	ISecondaryMemberUpToMembersFeatureData
	StrctSysRefPinMbrFeat	IPrimaryMemberRefPlaneFeatureData
	StrctSysSKPILenMbrFeat	IPrimaryMemberPointLengthFeatureData
	StrctSysSupPinMbrFeat	ISecondaryMemberSupportPlaneFeatureData
	StrctSysSurfPinMbrFeat	IPrimaryMemberFacePlaneIntersectionFeatureData
	AdvStructMember	IStructureSystemMemberFeatureData
	Gusset	IGussetFeatureData
	WeldBeadFeat	IWeldmentBeadFeatureData
	WeldCornerFeat	IWeldmentTrimExtendFeatureData
	WeldMemberFeat	IStructuralMemberFeatureData
	WeldmentFeature	IStructuralMemberFeatureData
	WeldmentTableFeat	IWeldmentCutListFeature

NOTE: This method returns strings for some features shown in the FeatureManager design tree (e.g., **MateGroup**, **Weldment**, etc.) that set up the design functionality environment and, thus, do not have interfaces.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::Name Property](#)
[IFeature::GetNameForSelection Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help [Send comments on this topic.](#)

GetUIState Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature interface](#) : GetUIState Method (IFeature)

Gets the user-interface state of the current feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUIState( _  
    ByVal StateType As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim StateType As System.Integer  
Dim value As System.Boolean  
  
value = instance.GetUIState(StateType)
```

C#

```
System.bool GetUIState(  
    System.int StateType  
)
```

C++/CLI

```
System.bool GetUIState(  
& System.int StateType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StateType

User interface state type as defined in [swUIStates_e](#)

Return Value

True if the state type is set, false if it is not

Visual Basic for Applications (VBA) Syntax

See [Feature::GetUIState](#).

Example

[Hide Feature in FeatureManager Design Tree \(VBA\)](#)
[Display of Item in FeatureManager Design Tree \(C++\)](#)

Remarks

If you pass in the user-interface state type of `swIsHiddenInFeatureMgr`, this method returns True if the current feature is hidden in the FeatureManager design tree or false if the current feature is visible in the FeatureManager design tree.

The user-interface state is not a property.

To see your changes in the FeatureManager design tree, call [IModelDoc2::EditRebuild3](#). Currently, the user-interface state data is runtime only.

Features are initialized with all user-interface state type values set to false.

A change in a feature state setting causes all the dependents of the feature to inherit the same behavior, without actually setting the state type values of those dependents. Therefore, to get the actual user-interface state value of a feature, you must check the owning feature.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::SetUIState Method](#)
[IFeature::Visible Property](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUpdateStamp Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : GetUpdateStamp Method (IFeature)

Gets the current update stamp for this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUpdateStamp() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFeature
Dim value As System.Integer

value = instance.GetUpdateStamp()
```

C#

```
System.int GetUpdateStamp()
```

C++/CLI

```
System.int GetUpdateStamp();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Current update stamp value for this feature

Visual Basic for Applications (VBA) Syntax

See [Feature::GetUpdateStamp](#).

Remarks

The update stamp is an integer form of the time stamp.

Update stamps are incremented each time the definition of the feature is modified by executing **Edit Definition** or changing the sketch used to generate the feature.

The update stamp of a feature is also incremented when its parent feature changes. Additionally if a feature is dependent on the body, or some other feature for regeneration, then the update stamp of the feature is incremented any time the body changes or the other related feature changes. These types of relationships might not seem typical parent and child relationships.

SOLIDWORKS does not track the affect that all features have on each other. If the topology of a feature is modified by another feature, then its update stamp might not be incremented. For example, if you add a fillet to the to edge of a hole, the update stamp of the hole does not change. This type of tracking is not required by SOLIDWORKS and is time consuming for larger parts.

It is a good idea to consider the entire body (and its topology) invalid when any of the feature time stamps within the model are incremented. For example, if a user creates a simple block containing a thru-hole feature and the user then adds a third feature (filling in a portion of the hole), the resulting solid body now looks very different, for example, to a machining package. The machining package no longer wants to drill the entire thru-hole. However, neither the creation, nor the editing, of the third feature caused the update stamp of the hole feature to be incremented. Therefore, it might be best for the machining package to re-obtain all body topology to avoid machining errors. Depending on what your software is trying to accomplish, you might want to consider the same.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IModelDoc2::GetUpdateStamp Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

HasFrozenUpdatePending Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : HasFrozenUpdatePending Method (IFeature)

Gets whether this feature has pending freeze updates.

.NET Syntax

Visual Basic (Declaration)

```
Function HasFrozenUpdatePending() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature
Dim value As System.Boolean

value = instance.HasFrozenUpdatePending()
```

C#

```
System.bool HasFrozenUpdatePending()
```

C++/CLI

```
System.bool HasFrozenUpdatePending();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the feature needs an update, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::HasFrozenUpdatePending](#).

Example

[Move Freeze Bar \(VBA\)](#)
[Move Freeze Bar \(VB.NET\)](#)
[Move Freeze Bar \(C#\)](#)

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IModelDocExtension::NeedsRebuild2 Property](#)
[IModelDocExtension::UpdateFrozenFeatures Method](#)
[IFeature::IsFrozen Method](#)
[IFeature::MoveFreezeBarTo Method](#)
[IFeatureManager::EditFreeze Method](#)
[IFeatureManager::GetFreezeLocation Method](#)
[IFeature::IsHiddenLock Method](#)
[IModelDocExtension::ShowPartRebuildIndicators Property\(\)](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

HasMaterialPropertyValues Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : HasMaterialPropertyValues Method (IFeature)

Gets whether this feature has an appearance.

.NET Syntax

Visual Basic (Declaration)

```
Function HasMaterialPropertyValues() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Boolean  
  
value = instance.HasMaterialPropertyValues()
```

C#

```
System.bool HasMaterialPropertyValues()
```

C++/CLI

```
System.bool HasMaterialPropertyValues();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this feature has an appearance, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::HasMaterialPropertyValues](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetMaterialPropertyValues2 Method \(\)](#)
[IFeature::SetMaterialPropertyValues2 Method \(\)](#)
[IFeature::RemoveMaterialProperty2 Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetAffectedFaces Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IGetAffectedFaces Method (IFeature)

Gets the faces modified by a feature, such as a draft feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetAffectedFaces( _  
    ByRef NCount As System.Integer _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim NCount As System.Integer  
Dim value As Face2  
  
value = instance.IGetAffectedFaces(NCount)
```

C#

```
Face2 IGetAffectedFaces(  
    ref System.int NCount  
)
```

C++/CLI

```
Face2^ IGetAffectedFaces(  
& System.int% NCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NCount
Number of faces modified by a feature

Return Value

- in-process, unmanaged C++: Pointer to array of [faces](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

Remarks

To determine size the of the array, call [IFeature::GetAffectedFaceCount](#) before calling this method.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetAffectedFaceCount Method](#)
[IFeature::GetAffectedFaces Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetBody Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IGetBody Method (IFeature)

Obsolete. Superseded by [IFeatures::GetFaces](#), [IFeatures::IGetFaces2](#), [IFace2::GetBody](#), and [IFace2::IGetBody](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBody() As Body
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As Body  
  
value = instance.IGetBody()
```

C#

```
Body IGetBody()
```

C++/CLI

```
Body^ IGetBody();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Feature::IGetBody](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetBody2 Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IGetBody2 Method (IFeature)

Obsolete. Superseded by [IFeatures::GetFaces](#), [IFeatures::IGetFaces2](#), [IFace2::GetBody](#), and [IFace2::IGetBody](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBody2() As Body2
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As Body2
```

```
value = instance.IGetBody2()
```

C#

```
Body2 IGetBody2()
```

C++/CLI

```
Body2^ IGetBody2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Feature::IGetBody2](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetBox Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IGetBox Method (IFeature)

Gets the bounding box for this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBox( _  
    ByRef BBox As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim BBox As System.Double  
Dim value As System.Boolean  
  
value = instance.IGetBox(BBox)
```

C#

```
System.bool IGetBox(  
    out System.double BBox  
)
```

C++/CLI

```
System.bool IGetBox(  
& [Out] System.double BBox  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BBox

Array containing the two diagonal points

Return Value

True if the operation was successful, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::IGetBox](#).

Remarks

IMPORTANT: The values returned are approximate and should not be used for comparison or calculation purposes. Furthermore, the bounding box may vary after rebuilding the model.

The resulting box encloses the object, but it might not be the tightest box.

The two X, Y, Z points returned are the lower- and upper-diagonal corners that bound the feature. The box is aligned with the model coordinate system. The box dimensions enclose the feature. However, the box might not be the minimum bounding box for the model.

The return value is an array of 6 doubles as follows:

[XCorner1, YCorner1, ZCorner1, XCorner2, YCorner2, ZCorner2]

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetBox Method](#)
[IAssemblyDoc::GetBox Method](#)
[IAssemblyDoc::IGetBox Method](#)
[IComponent2::GetBox Method](#)
[IComponent2::IGetBox Method](#)
[IBody2::GetBodyBox Method](#)
[IBody2::IGetBodyBox Method](#)
[IFace2::GetBox Method](#)
[IFace2::IGetBox Method](#)
[IModelDocExtension::GetVisibleBox Method](#)
[IModelDocExtension::RemoveVisibleBox Method](#)
[IModelDocExtension::SetVisibleBox Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetChildCount Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IGetChildCount Method (IFeature)

Gets the number of child features that belong to this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetChildCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFeature
Dim value As System.Integer

value = instance.IGetChildCount()
```

C#

```
System.int IGetChildCount()
```

C++/CLI

```
System.int IGetChildCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of direct children belonging to this feature

Visual Basic for Applications (VBA) Syntax

See [Feature::IGetChildCount](#).

Remarks

Call this method before calling [IFeature::IGetChildren](#) to determine the size of the array.

This method gets the number of direct children belonging to this feature, not including children of children.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetChildren Method](#)
[IFeature::IGetParents Method](#)
[IFeature::GetParents Method](#)
[IFeature::IGetParentCount Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetChildren Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IGetChildren Method (IFeature)

Gets the child features belonging to this feature.

.NET Syntax

Visual Basic (Declaration)

Function IGetChildren() As Feature

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As Feature  
  
value = instance.IGetChildren()
```

C#

Feature IGetChildren()

C++/CLI

Feature^ IGetChildren();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of [features](#)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

This method gets the direct children of this feature. It does not get children of children.

To determine the size of the array, call [IFeature::IGetChildCount](#) before calling this method.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetChildren Method](#)
[IFeature::GetParents Method](#)
[IFeature::IGetParents Method](#)
[IFeature::IGetParentCount Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDefinition Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IGetDefinition Method (IFeature)

Gets the feature data object for a feature, such as an extrusion, loft, fillet, chamfer, etc., in order to access the parameters that control the definition of this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDefinition() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFeature
Dim value As System.Object

value = instance.IGetDefinition()
```

C#

```
System.Object IGetDefinition()
```

C++/CLI

```
System.Object^ IGetDefinition();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Unknown interface to the feature data object; use QueryInterface to get the interface to the actual object (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Feature::IGetDefinition](#).

Remarks

You can use this method to query the feature data object, and you can modify the feature data object using [IFeature::IModifyDefinition2](#). Set the feature data object to null when it is no longer needed. Not all feature types are supported, so check to see that the returned object is valid.

To:

- get the type of feature and the name of its associated interface, use [IFeature::GetType](#) or [IFeature::GetType2](#).
- see a complete list of interfaces for feature data objects (e.g., interfaces ending in FeatureData or FeatureData2, such as IExtrudeFeatureData2, ILoftFeatureData, ISimpleFilletFeatureData2, IChamferFeatureData2, etc.), see the **Features Interfaces** section in [Functional Categories](#).
- get the object of a feature that is not a feature data object, use [IFeature::GetSpecificFeature2](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetDefinition Method](#)
[IFeature::IModifyDefinition2 Method](#)
[IFeature::ModifyDefinition Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFaces Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IGetFaces Method (IFeature)

Obsolete. Superseded by [IFeature::IGetFaces2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFaces( _  
    ByRef FaceCount As System.Integer _  
) As Face
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim FaceCount As System.Integer  
Dim value As Face  
  
value = instance.IGetFaces(FaceCount)
```

C#

```
Face IGetFaces(  
    out System.int FaceCount  
)
```

C++/CLI

```
Face^ IGetFaces(  
& [Out] System.int FaceCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceCount

Visual Basic for Applications (VBA) Syntax

See [Feature::IGetFaces](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFaces2 Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IGetFaces2 Method (IFeature)

Gets the faces in this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFaces2( _  
    ByRef FaceCount As System.Integer _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim FaceCount As System.Integer  
Dim value As Face2  
  
value = instance.IGetFaces2(FaceCount)
```

C#

```
Face2 IGetFaces2(  
    out System.int FaceCount  
)
```

```
)
```

C++/CLI

```
Face2^ IGetFaces2(  
& [Out] System.int FaceCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceCount

Number of faces in this feature

Return Value

- in-process, unmanaged C++: Pointer to an array of pointers to the [faces](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

To determine the size of the array, call [IFeature::GetFaceCount](#) before calling this method.

IFeature::IGetFaces2 compares the number of faces in this feature with FaceCount. If the actual number of faces is larger than the specified FaceCount, then this method returns no faces and a status of S_ERROR. If the actual number of faces is smaller than the specified in FaceCount, then this method returns all of the faces in the return array, and changes FaceCount to reflect the correct number of faces.

In SOLIDWORKS, a face:

- is the result of evaluating a feature.
- can be owned by several features.

IFeature::IGetFaces2 returns all of the faces owned by a feature. This is different from the faces highlighted in the user interface when the feature is selected. The user interface filters out multiple feature faces. This filter is only for display purposes.

NOTES:

- This method does not return any faces for draft features because draft features do not create any new faces. Drafting only modifies existing faces.
- The number of faces for rolled hems is 0 because all of the faces belong to the children bends.

To filter out multiple feature faces using the SOLIDWORKS API, you must call [IFace2::IGetFeature](#). Only the oldest feature from the face is returned, that is, the first owning feature in the FeatureManager design tree.

Example

```
HRESULT      hr = S_OK;  
  
long         lNumFaces = 0;  
  
hr = feat->GetFaceCount(&lNumFaces);  
  
LPFACE2*     aFaces = new LPFACE2[lNumFaces];  
  
hr = feat->IGetFaces2(&lNumFaces, aFaces);  
  
...  
  
delete [] aFaces;  
aFaces = 0;
```

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetFaces Method](#)

Availability

IGetFirstSubFeature Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IGetFirstSubFeature Method (IFeature)

Gets the first sub-feature that belongs to this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFirstSubFeature() As Feature
```

Visual Basic (Usage)



```
Dim instance As IFeature
Dim value As Feature

value = instance.IGetFirstSubFeature()
```

C#

```
Feature IGetFirstSubFeature()
```

C++/CLI

```
Feature^ IGetFirstSubFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer the first sub-[feature](#) of this feature

Visual Basic for Applications (VBA) Syntax

See [Feature::IGetFirstSubFeature](#).

Example

[Get Sketches \(C++\)](#)

Remarks

If no sub-features exist for this feature, then this method returns NULL.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetFirstSubFeature Method](#)
[IFeature::GetNextFeature Method](#)
[IFeature::GetNextSubFeature Method](#)
[IFeature::IGetNextFeature Method](#)
[IFeature::IGetNextSubFeature Method](#)
[IFeature::MakeSubFeature Method](#)
[IComponent2::FirstFeature Method](#)
[IModelDoc2::FirstFeature Method](#)
[IModelDoc2::IFirstFeature Method](#)
[IPartDoc::FirstFeature Method](#)
[IPartDoc::IFirstFeature Method](#)

IGetMaterialPropertyValues Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IGetMaterialPropertyValues Method (IFeature)

Obsolete. Superseded by [IFeature::IGetMaterialPropertyValues2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetMaterialPropertyValues() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Double  
  
value = instance.IGetMaterialPropertyValues()
```

C#

```
System.double IGetMaterialPropertyValues()
```

C++/CLI

```
System.double IGetMaterialPropertyValues();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Feature::IGetMaterialPropertyValues](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetMaterialPropertyValues2 Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IGetMaterialPropertyValues2 Method (IFeature)

Gets the material property values for this feature in the specified configurations.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetMaterialPropertyValues2( _  
    ByVal Config\_opt As System.Integer, _  
    ByVal Config\_count As System.Integer, _  
    ByRef Config\_names As System.String _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim Config_opt As System.Integer  
Dim Config_count As System.Integer  
Dim Config_names As System.String  
Dim value As System.Double  
  
value = instance.IGetMaterialPropertyValues2(Config_opt, Config_count, Config_names)
```

C#

```
System.double IGetMaterialPropertyValues2(  
    System.int Config\_opt,  
    System.int Config\_count,  
    ref System.string Config\_names  
)
```

```
System.double IGetMaterialPropertyValues2(
& System.int Config\_opt,
& System.int Config\_count,
& System.String^% Config\_names
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Config_opt

Configuration options as defined by [swInConfigurationOpts_e](#)

Config_count

Number of configurations

Config_names

Array of configuration names of size Config_count

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

The material values returned include the face color (R,G,B values), reflectivity (ambient, diffuse, specular, shininess), transparency, and emission. Valid values are between 0.0 and 1.0, inclusive, for all material properties. If a return value is -1, then that material property was not set for this feature.

If you set Config_opt to swThisConfiguration or swAllConfiguration, then Config_names is ignored.

The format of the returned array:

[*R, G, B, Ambient, Diffuse, Specular, Shininess, Transparency, Emission*] * Config_count

See Also

[IFeature Interface](#)

[IFeature Members](#)

[IFeature::GetMaterialPropertyValues2 Method](#)

[IFeature::IRemoveMaterialProperty2 Method](#)

[IFeature::ISetMaterialPropertyValues2 Method](#)

[IFeature::RemoveMaterialProperty2 Method](#)

[IFeature::SetMaterialPropertyValues2 Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNextFeature Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IGetNextFeature Method (IFeature)

Gets the next feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNextFeature() As Feature
```

Visual Basic (Usage)



```
Dim instance As IFeature
Dim value As Feature
```

```
value = instance.IGetNextFeature()
```

C#

```
Feature IGetNextFeature()
```

```
Feature^ IGetNextFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the next [feature](#)

Visual Basic for Applications (VBA) Syntax

See [Feature::IGetNextFeature](#).

Example

[Access Assembly \(C++\)](#)
[Get Names of Creators of Features \(C++\)](#)

Remarks

This method:

- allows you to access suppressed features.
- returns features in the current order for the model, and this order changes when the model is edited.

Your application should not assume that:

- features retain the same relative or absolute position throughout the model's lifetime. For example, you should not assume that Sketch1 always appears before Sketch2.
- any feature has a specific name. Because features can be renamed, you cannot assume that the first reference plane feature is named Plane1.

When traversing the FeatureManager design tree, your application should use [IFeature::GetTypeName2](#) and [IFeature::GetSpecificFeature2](#) to identify specific features instead of relying solely on [IFeature::Name](#).

This method returns features in the model definition order, which is not the same as the order displayed in the user interface.

See [ITreeControlItem](#) for details.

[IFeature::GetFirstSubFeature](#) and [IFeature::IGetFirstSubFeature](#) provide access to subfeatures.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetNextFeature Method](#)
[IFeature::GetNextSubFeature Method](#)
[IFeature::IGetFirstSubFeature Method](#)
[IFeature::IGetNextSubFeature Method](#)
[IFeature::GetFirstSubFeature Method](#)
[IFeature::IGetFirstSubFeature Method](#)
[IComponent2::FirstFeature Method](#)
[IModelDoc2::FirstFeature Method](#)
[IModelDoc2::IFirstFeature Method](#)
[IPartDoc::FirstFeature Method](#)
[IPartDoc::IFirstFeature Method](#)

IGetNextSubFeature Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IGetNextSubFeature Method (IFeature)

Gets the next sub-feature from the owner of this sub-feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNextSubFeature() As Feature
```

Visual Basic (Usage)

```
Dim instance As IFeature
Dim value As Feature

value = instance.IGetNextSubFeature()
```

C#



```
Feature IGetNextSubFeature()
```

C++/CLI

```
Feature^ IGetNextSubFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer the next sub-[feature](#)

Visual Basic for Applications (VBA) Syntax

See [Feature::IGetNextSubFeature](#).

Example

[Get Sketches \(C++\)](#)

Remarks

If no sub-feature exists, then this method returns NULL.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetFirstSubFeature Method](#)
[IFeature::GetNextFeature Method](#)
[IFeature::GetNextSubFeature Method](#)
[IFeature::IGetFirstSubFeature Method](#)
[IFeature::IGetNextFeature Method](#)
[IFeature::IGetNextSubFeature Method](#)
[IFeature::MakeSubFeature Method](#)
[IComponent2::FirstFeature Method](#)
[IModelDoc2::FirstFeature Method](#)
[IModelDoc2::FirstFeature Method](#)
[IPartDoc::FirstFeature Method](#)
[IPartDoc::FirstFeature Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetParentCount Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IGetParentCount Method (IFeature)

Gets the number of parent features for this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetParentCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Integer  
  
value = instance.IGetParentCount()
```

C#

```
System.int IGetParentCount()
```

C++/CLI

```
System.int IGetParentCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of direct parents for this feature

Visual Basic for Applications (VBA) Syntax

See [Feature::IGetParentCount](#).

Example

[Get Parent Features \(C++\)](#)

Remarks

Call this method before calling [IFeature::IGetParents](#) to determine the size of the array.

This method gets the number of direct parents for this feature, not including parents of parents.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetChildren Method](#)
[IFeature::GetOwnerFeature Method](#)
[IFeature::GetParents Method](#)
[IFeature::IGetChildCount Method](#)
[IFeature::IGetChildren Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetParents Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IGetParents Method (IFeature)

Gets the parent features for this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetParents() As Feature
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As Feature
```

```
value = instance.IGetParents()
```

C#

```
Feature IGetParents()
```

C++/CLI

```
Feature^ IGetParents();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of [features](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Example

[Get Parent Features \(C++\)](#)

Remarks

To determine the size of the array, call [IFeature::IGetParentCount](#) before calling this method.

This method gets only the direct parents of this feature. It does not get parents of parents.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetChildren Method](#)
[IFeature::GetOwnerFeature Method](#)
[IFeature::GetParents Method](#)
[IFeature::IGetChildCount Method](#)
[IFeature::IGetChildren Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSpecificFeature Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IGetSpecificFeature Method (IFeature)

Obsolete. Superseded by [IFeature::GetSpecificFeature2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSpecificFeature() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Object  
  
value = instance.IGetSpecificFeature()
```

C#

```
System.object IGetSpecificFeature()
```

C++/CLI

```
System.Object^ IGetSpecificFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Feature::IGetSpecificFeature](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsSuppressed2 Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IsSuppressed2 Method (IFeature)

Gets whether the feature in the specified configurations is suppressed.

.NET Syntax

Visual Basic (Declaration)

```
Function IIsSuppressed2( _  
    ByVal Config\_opt As System.Integer, _  
    ByVal Config\_count As System.Integer, _  
    ByRef Config\_names As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim Config_opt As System.Integer  
Dim Config_count As System.Integer  
Dim Config_names As System.String  
Dim value As System.Boolean  
  
value = instance.IIsSuppressed2(Config_opt, Config_count, Config_names)
```

C#

```
System.bool IIsSuppressed2(  
    System.int Config\_opt,  
    System.int Config\_count,  
    ref System.string Config\_names  
)
```

C++/CLI

```
System.bool IIsSuppressed2(  
& System.int Config\_opt,  
& System.int Config\_count,  
& System.String^% Config\_names  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Config_opt
Configuration option as defined by [swInConfigurationOpts_e](#)
Config_count
Number of configurations in this feature

Config_names
Array of configuration names

Return Value

Array of the suppression states for the feature in the specified configurations

Visual Basic for Applications (VBA) Syntax

See [Feature::IIsSuppressed2](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::ISetSuppression2 Method](#)
[IFeature::IIsSuppressed2 Method](#)
[IFeature::SetSuppression2 Method](#)
[IFeature::Visible Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0



.NET Syntax

Visual Basic (Declaration)

```
Sub IListExternalFileReferences( _  
    ByVal NumRefs As System.Integer, _  
    ByRef ModelPathName As System.String, _  
    ByRef CompPathName As System.String, _  
    ByRef Feature As System.String, _  
    ByRef DataType As System.String, _  
    ByRef Status As System.Integer, _  
    ByRef RefEntity As System.String, _  
    ByRef FeatComp As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim NumRefs As System.Integer  
Dim ModelPathName As System.String  
Dim CompPathName As System.String  
Dim Feature As System.String  
Dim DataType As System.String  
Dim Status As System.Integer  
Dim RefEntity As System.String  
Dim FeatComp As System.String
```

```
instance.IListExternalFileReferences(NumRefs, ModelPathName, CompPathName, Feature, DataType,  
Status, RefEntity, FeatComp)
```

C#

```
void IListExternalFileReferences(  
    System.int NumRefs,  
    out System.string ModelPathName,  
    out System.string CompPathName,  
    out System.string Feature,  
    out System.string DataType,  
    out System.int Status,  
    out System.string RefEntity,  
    out System.string FeatComp  
)
```

C++/CLI

```
void IListExternalFileReferences(  
    & System.int NumRefs,  
    & [Out] System.String^ ModelPathName,  
    & [Out] System.String^ CompPathName,  
    & [Out] System.String^ Feature,  
    & [Out] System.String^ DataType,  
    & [Out] System.int Status,  
    & [Out] System.String^ RefEntity,  
    & [Out] System.String^ FeatComp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumRefs

ModelPathName

CompPathName

Feature

DataType

Status

RefEntity

FeatComp

Visual Basic for Applications (VBA) Syntax

See [Feature::IListExternalFileReferences](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IListExternalFileReferences2 Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IListExternalFileReferences2 Method (IFeature)

Gets the names and statuses of the external references for this feature in a part or assembly.

.NET Syntax

Visual Basic (Declaration)

```
Sub IListExternalFileReferences2( _  
    ByVal NumRefs As System.Integer, _  
    ByRef ModelPathName As System.String, _  
    ByRef CompPathName As System.String, _  
    ByRef Feature As System.String, _  
    ByRef DataType As System.String, _  
    ByRef Status As System.Integer, _  
    ByRef RefEntity As System.String, _  
    ByRef FeatComp As System.String, _  
    ByRef ConfigOption As System.Integer, _  
    ByRef ConfigName As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim NumRefs As System.Integer  
Dim ModelPathName As System.String  
Dim CompPathName As System.String  
Dim Feature As System.String  
Dim DataType As System.String  
Dim Status As System.Integer  
Dim RefEntity As System.String  
Dim FeatComp As System.String  
Dim ConfigOption As System.Integer  
Dim ConfigName As System.String
```

```
instance.IListExternalFileReferences2(NumRefs, ModelPathName, CompPathName, Feature, DataType,  
Status, RefEntity, FeatComp, ConfigOption, ConfigName)
```

C#

```
void IListExternalFileReferences2(  
    System.int NumRefs,  
    out System.string ModelPathName,  
    out System.string CompPathName,  
    out System.string Feature,  
    out System.string DataType,  
    out System.int Status,  
    out System.string RefEntity,  
    out System.string FeatComp,  
    out System.int ConfigOption,
```

```
    out System.string ConfigName
)
```

C++/CLI

```
void IListExternalFileReferences2(
& System.int NumRefs,
& [Out] System.String^ ModelPathName,
& [Out] System.String^ CompPathName,
& [Out] System.String^ Feature,
& [Out] System.String^ DataType,
& [Out] System.int Status,
& [Out] System.String^ RefEntity,
& [Out] System.String^ FeatComp,
& [Out] System.int ConfigOption,
& [Out] System.String^ ConfigName
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumRefs

Number of external references

ModelPathName

- in-process, unmanaged C++: Pointer to an array of path names of documents of size NumRefs
- VBA, VB.NET, C#, and C++/CLI: Not supported

CompPathName

- in-process, unmanaged C++: Pointer to an array of path names of referenced components of size NumRefs
- VBA, VB.NET, C#, and C++/CLI: Not supported

Feature

- in-process, unmanaged C++: Pointer to an array of in-context items (sketches, features, and so on) of size NumRefs
- VBA, VB.NET, C#, and C++/CLI: Not supported

DataType

- in-process, unmanaged C++: Pointer to an array of data used to create the items (converted edge or face, converted or offset sketch entity, body, and so on) of size NumRefs
- VBA, VB.NET, C#, and C++/CLI: Not supported

Status

- in-process, unmanaged C++: Pointer to an array of the statuses of external references as defined in [swExternalReferenceStatus_e](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

RefEntity

- in-process, unmanaged C++: Pointer to an array of actual items being used and the names of the documents that contain the items of size NumRefs
- VBA, VB.NET, C#, and C++/CLI: Not supported

FeatComp

- in-process, unmanaged C++: Pointer to an array of the names of the components in which the affected features exist of size NumRefs; this information is only displayed when one or more RefEntity is in a different component in an assembly and does not apply to derived parts
- VBA, VB.NET, C#, and C++/CLI: Not supported

ConfigOption

Configuration option as defined by [swExternalFileReferencesConfig_e](#)

ConfigName

Name of the configuration when ConfigOption is swExternalFileReferencesNamedConfig

Remarks

Call [IFeature::ListExternalFileReferencesCount](#) before calling this method to specify NumRefs.

See Also

[IFeature Interface](#)

[IFeature Members](#)

[IFeature::ListExternalFileReferences2 Method](#)

[IFeature::UpdateExternalFileReferences Method](#)

[IComponent2::ListExternalFileReferences2 Method](#)

[IComponent2::ListExternalFileReferencesCount Method](#)

[IComponent2::UpdateExternalFileReferences Method](#)

[IModelDocExtension::ListExternalFileReferences Method](#)

[IModelDocExtension::ListExternalFileReferencesCount Method](#)

[IModelDocExtension::UpdateExternalFileReferences Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IModifyDefinition Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IModifyDefinition Method (IFeature)

Obsolete. Superseded by [IFeature::IModifyDefinition2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IModifyDefinition( _  
    ByVal Data As System.Object, _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim Data As System.Object  
Dim TopDoc As ModelDoc  
Dim Component As Component  
Dim value As System.Boolean  
  
value = instance.IModifyDefinition(Data, TopDoc, Component)
```

C#

```
System.bool IModifyDefinition(  
    System.object Data,  
    ModelDoc TopDoc,  
    Component Component  
)
```

C++/CLI

```
System.bool IModifyDefinition(  
& System.Object^ Data,  
& ModelDoc^ TopDoc,  
& Component^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Data

TopDoc

Component

Visual Basic for Applications (VBA) Syntax

See [Feature::IModifyDefinition](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IModifyDefinition2 Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IModifyDefinition2 Method (IFeature)

Updates the definition of a feature with the new values in an associated feature data object obtained with [IFeature::IGetDefinition](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IModifyDefinition2( _  
    ByVal Data As System.Object, _  
    ByVal TopDoc As ModelDoc2, _
```

```
ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim Data As System.Object  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IModifyDefinition2(Data, TopDoc, Component)
```

C#

```
System.bool IModifyDefinition2(  
    System.object Data,  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IModifyDefinition2(  
    & System.Object^ Data,  
    & ModelDoc2^ TopDoc,  
    & Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Data

IUnknown interface to the feature data object; use QueryInterface to get the interface to the actual object

TopDoc

Top-level document (see **Remarks**)

Component

Component for the feature (see **Remarks**)

Return Value

True if the feature is updated successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::IModifyDefinition2](#).

Remarks

To modify a feature in...	Then TopDoc argument...
A part	Is the IModelDoc2 object for the part and the Component argument should be Nothing or null
An assembly	Should be the assembly IModelDoc2 object and the Component argument should be the IComponent2 object in which the feature is to be modified

When you modify a feature in an assembly, this method leaves the assembly in Editing Part mode. You can switch back to editing the assembly by calling [IAssemblyDoc::EditAssembly](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetDefinition Method](#)
[IFeature::ModifyDefinition Method](#)

Availability

IParameter Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IParameter Method (IFeature)

Gets a pointer to the object for the specified parameter or a pointer to the specified parameter.

.NET Syntax

Visual Basic (Declaration)

```
Function IParameter( _  
    ByVal Name As System.String _  
) As Dimension
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim Name As System.String  
Dim value As Dimension  
  
value = instance.IParameter(Name)
```

C#

```
Dimension IParameter(  
    System.string Name  
)
```

C++/CLI

```
Dimension^ IParameter(  
& System.String^ Name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Name of parameter (for example, "D1")

Return Value

[Dimension](#)

Visual Basic for Applications (VBA) Syntax

See [Feature::IParameter](#).

Remarks

Most parameters are [dimensions](#).

The Name argument for this method does not have to be the "full" dimension name. For example, you only need to pass "D1" not "D1@Base-Revolve". The full dimension name is required if you call [IModelDoc2::IParameter](#).

SOLIDWORKS recognizes some characters as special characters. The use of these characters in part or feature names can cause this method to fail and not return a dimension. These special characters are not recognized in names of parts or features:

- at sign (@)
- period (.)
- backslash (/)

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::Parameter Method](#)

IRemoveMaterialProperty2 Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IRemoveMaterialProperty2 Method (IFeature)

Removes material property values from this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IRemoveMaterialProperty2( _  
    ByVal Config\_opt As System.Integer, _  
    ByVal Config\_count As System.Integer, _  
    ByRef Config\_names As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim Config_opt As System.Integer  
Dim Config_count As System.Integer  
Dim Config_names As System.String  
Dim value As System.Boolean  
  
value = instance.IRemoveMaterialProperty2(Config_opt, Config_count, Config_names)
```

C#

```
System.bool IRemoveMaterialProperty2(  
    System.int Config\_opt,  
    System.int Config\_count,  
    ref System.string Config\_names  
)
```

C++/CLI

```
System.bool IRemoveMaterialProperty2(  
& System.int Config\_opt,  
& System.int Config\_count,  
& System.String^% Config\_names  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Config_opt

Configuration option as defined in [swInConfigurationOpts_e](#)

Config_count

Number of configurations

Config_names

- in-process, unmanaged C++: Pointer to an array of configuration names

• VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

True if material property values are removed, false if not

Remarks

This method is intended to be used on features that have a changed material property value; for example, color.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetMaterialPropertyValues2 Method](#)
[IFeature::!GetMaterialPropertyValues2 Method](#)

[IFeature::IRemoveMaterialProperty2 Method](#)
[IFeature::RemoveMaterialProperty2 Method](#)
[IFeature::SetMaterialPropertyValues2 Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Is3DInterconnectFeature Property (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : Is3DInterconnectFeature Property (IFeature)

Gets whether this is a 3D Interconnect feature.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Is3DInterconnectFeature As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Boolean
```

```
value = instance.Is3DInterconnectFeature
```

C#

```
System.bool Is3DInterconnectFeature {get;}
```

C++/CLI

```
property System.bool Is3DInterconnectFeature {  
    System.bool get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if this is a 3D Interconnect feature, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::Is3DInterconnectFeature](#).

Example

See the [IImport3DInterconnectData](#) examples.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetImportedFeatureParameters Method \(\)](#)
[IFeature::SetImportedFeatureParameters Method \(\)](#)
[IImport3DInterconnectData Interface](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Is3DInterconnectUpdateAvailable Property (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : Is3DInterconnectUpdateAvailable Property (IFeature)

Gets whether an update is available for this 3D Interconnect part or assembly.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Is3DInterconnectUpdateAvailable As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Boolean  
  
value = instance.Is3DInterconnectUpdateAvailable
```

C#

```
System.bool Is3DInterconnectUpdateAvailable {get;}
```

C++/CLI

```
property System.bool Is3DInterconnectUpdateAvailable {  
    System.bool get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if an update is available, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::Is3DInterconnectUpdateAvailable](#).

Example

See the [IImport3DInterconnectData](#) examples.

Remarks

If this property is true, use [IFeature::Update3DInterconnectModel](#) to update the imported feature or component.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IImport3DInterconnectData Interface](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsBase Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IsBase Method (IFeature)

Obsolete. Superseded by [IFeature::IsBase2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IsBase() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Boolean  
  
value = instance.IsBase()
```

C#

```
System.bool IsBase()
```

C++/CLI

```
System.bool IsBase();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Feature::IsBase](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsBase2 Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IsBase2 Method (IFeature)

Gets whether this feature is a base feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IsBase2() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Boolean  
  
value = instance.IsBase2()
```

C#

```
System.bool IsBase2()
```

C++/CLI

```
System.bool IsBase2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this is a base feature, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::IsBase2](#).

Remarks

Any feature that creates a solid body is a base feature. For example:

- An extrude operation creates a solid body; therefore, that feature is a base feature.

- A body imported via an IGES file is a base feature.
- However, a fillet operation does not create a solid body; therefore, that feature is not a base feature.
- In a multibody environment, more than one feature can return true. Thus, a lot of features can be base features in a multibody environment.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::ISetBody3 Method](#)
[IFeature::SetBody2 Method](#)

Availability

SOLIDWORKS 2003 SP3, Revision Number 11.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsDimXpertAnnotation Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IsDimXpertAnnotation Method (IFeature)

Gets whether this feature is a DimXpert annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function IsDimXpertAnnotation() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Boolean  
  
value = instance.IsDimXpertAnnotation()
```

C#

```
System.bool IsDimXpertAnnotation()
```

C++/CLI

```
System.bool IsDimXpertAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if a DimXpert annotation; false otherwise

Visual Basic for Applications (VBA) Syntax

See [Feature::IsDimXpertAnnotation](#).

Example

[Get DimXpertManager Info \(VBA\)](#)
[Get DimXpertManager Info \(VB.NET\)](#)

See Also

[IFeature Interface](#)
[IFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsDimXpertFeature Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IsDimXpertFeature Method (IFeature)

Gets whether this feature is a DimXpert feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IsDimXpertFeature() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Boolean  
  
value = instance.IsDimXpertFeature()
```

C#

```
System.bool IsDimXpertFeature()
```

C++/CLI

```
System.bool IsDimXpertFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if a DimXpert feature; false otherwise

Visual Basic for Applications (VBA) Syntax

See [Feature.IsDimXpertFeature](#).

Example

[Get DimXpertManager Info \(VBA\)](#)
[Get DimXpertManager Info \(VB.NET\)](#)

See Also

[IFeature Interface](#)
[IFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetBody Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : ISetBody Method (IFeature)

Obsolete. Superseded by [IFeature::ISetBody3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ISetBody( _  
    ByVal BodyIn As Body _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim BodyIn As Body  
Dim value As System.Boolean  
  
value = instance.ISetBody(BodyIn)
```

C#

```
System.bool ISetBody(  
    Body BodyIn  
)
```

C++/CLI

```
System.bool ISetBody(  
&    Body^ BodyIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BodyIn

Visual Basic for Applications (VBA) Syntax

See [Feature::ISetBody](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetBody2 Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : ISetBody2 Method (IFeature)

Obsolete. Superseded by [IFeature::ISetBody3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ISetBody2(  
    ByVal BodyIn As Body, _  
    ByVal ApplyUserIds As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim BodyIn As Body  
Dim ApplyUserIds As System.Boolean  
Dim value As System.Boolean  
  
value = instance.ISetBody2(BodyIn, ApplyUserIds)
```

C#

```
System.bool ISetBody2(  
    Body BodyIn,  
    System.bool ApplyUserIds  
)
```

C++/CLI

```
System.bool ISetBody2(  
& Body^ BodyIn,  
& System.bool ApplyUserIds  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BodyIn

ApplyUserIds

Visual Basic for Applications (VBA) Syntax

See [Feature::ISetBody2](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetBody3 Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : ISetBody3 Method (IFeature)

Replaces the body of the base feature.

.NET Syntax

Visual Basic (Declaration)

```
Function ISetBody3( _  
    ByVal BodyIn As Body2, _  
    ByVal ApplyUserIds As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim BodyIn As Body2  
Dim ApplyUserIds As System.Boolean  
Dim value As System.Boolean  
  
value = instance.ISetBody3(BodyIn, ApplyUserIds)
```

C#

```
System.bool ISetBody3(  
    Body2 BodyIn,  
    System.bool ApplyUserIds  
)
```

C++/CLI

```
System.bool ISetBody3(  
& Body2^ BodyIn,  
& System.bool ApplyUserIds  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BodyIn

Pointer to the temporary [body](#) that replaces the base feature body

ApplyUserIds

True applies user-defined face IDs, false does not

Return Value

True if the body was successfully replaced, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::ISetBody3](#).

Remarks

You must create the replacement body as an imported body using [IBody2::CreateBodyFromSurfaces](#) or [IBody2::ICreateTempBodyFromSurfaces](#), as a copy of an imported body generated by these methods, or using translation from IGES in, STEP in, and so on.

If this feature is not the base feature or the body is not an imported body, then the method returns false.

This method replaces the base body or ref-surface body if you created either of these features from imported geometry. If child features exist, then you can use [IFace2::GetFaceId](#) to set the face IDs to both the old body and the replacement body before calling [IFeature::ISetBody3](#). For example, if you are expecting a child feature on a face of the old body to be mapped to a face on the replacement body, you need to set the same ID (integer) to these two faces. This mechanism enables child features to re-attach themselves to the replacement body because [IFeature::ISetBody3](#) cannot do this automatically.

If applyUserIds...	Then Feature::ISetBody3...
True	Tries to match the face IDs on the replacement body with IDs on the child features. This helps when re-attaching the features to the replacement body.
false	Replaces the original body with the replacement body. Face IDs are not be used to match up new faces with child features.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::SetBody2 Method](#)
[IFeature::IsBase2 Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetMaterialPropertyValues Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : [ISetMaterialPropertyValues Method \(IFeature\)](#)

Obsolete. Superseded by [IFeature::ISetMaterialPropertyValues2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ISetMaterialPropertyValues( _  
    ByRef MaterialPropertyValues As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim MaterialPropertyValues As System.Double  
Dim value As System.Boolean  
  
value = instance.ISetMaterialPropertyValues(MaterialPropertyValues)
```

C#

```
System.bool ISetMaterialPropertyValues(  
    ref System.double MaterialPropertyValues  
)
```

C++/CLI

```
System.bool ISetMaterialPropertyValues(  
& System.double% MaterialPropertyValues  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

MaterialPropertyValues

Visual Basic for Applications (VBA) Syntax

See [Feature::ISetMaterialPropertyValues](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetMaterialPropertyValues2 Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : ISetMaterialPropertyValues2 Method (IFeature)

Sets the material property values for this feature in the specified configurations.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetMaterialPropertyValues2( _  
    ByRef Material\_values As System.Double, _  
    ByVal Config\_opt As System.Integer, _  
    ByVal Config\_count As System.Integer, _  
    ByRef Config\_names As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim Material_values As System.Double  
Dim Config_opt As System.Integer  
Dim Config_count As System.Integer  
Dim Config_names As System.String
```

```
instance.ISetMaterialPropertyValues2(Material_values, Config_opt, Config_count, Config_names)
```

C#

```
void ISetMaterialPropertyValues2(  
    ref System.double Material\_values,  
    System.int Config\_opt,  
    System.int Config\_count,  
    ref System.string Config\_names  
)
```

C++/CLI

```
void ISetMaterialPropertyValues2(  
& System.double% Material\_values,  
& System.int Config\_opt,
```

```
& System.int Config\_count,  
& System.String^% Config\_names  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Material_values

- in-process, unmanaged C++: Pointer to an array of material property values (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Config_opt

Configuration option as defined in [swInConfigurationOpts_e](#)

Config_count

Number of configurations (see **Remarks**)

Config_names

- in-process, unmanaged C++: Pointer to an array of configuration names of size *Config_count*
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

The material properties are color (R,G,B values), reflectivity (ambient, diffuse, specular, shininess), transparency, and emission. Valid values are between 0.0 and 1.0, inclusive, for all material properties.

If you set *Config_opt* to *swThisConfiguration* or *swAllConfiguration*, then *Config_names* is ignored. If you set *Config_opt* to *swAllConfiguration*, use [IModelDoc2::GetConfigurationCount](#) to specify *Config_count*.

The format of the *Material_values* array:

[*R*, *G*, *B*, *Ambient*, *Diffuse*, *Specular*, *Shininess*, *Transparency*, *Emission*]

To see a color change, you must:

1. Specify *R*, *G*, and *B*, each with a value between 0.0 and 1.0, inclusive. (These values are internally multiplied by 255.0 to determine the RGB color.)
2. Specify the reflectivity properties (*Diffuse*, *Specular*, *Shininess* (1.0 - Specular spread/Blurriness)), each with a value greater than 0.0 and less than or equal to 1.0.
3. Specify *Ambient*, *Transparency* and *Emission*, each with a value between 0.0 and 1.0, inclusive.
4. Refresh the graphics area after calling this method.

See Also

[IFeature Interface](#)

[IFeature Members](#)

[IFeature::SetMaterialPropertyValues2 Method](#)

[IFeature::GetMaterialPropertyValues2 Method](#)

[IFeature::IGetMaterialPropertyValues2 Method](#)

[IFeature::IRemoveMaterialProperty2 Method](#)

[IFeature::RemoveMaterialProperty2 Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetSuppression2 Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : ISetSuppression2 Method (IFeature)

Sets the suppression state of this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function ISetSuppression2( _  
    ByVal SuppressionState As System.Integer, _  
    ByVal Config\_opt As System.Integer, _  
    ByVal Config\_count As System.Integer, _  
    ByRef Config\_names As System.String _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IFeature  
Dim SuppressionState As System.Integer  
Dim Config_opt As System.Integer
```



```
Dim Config_count As System.Integer
Dim Config_names As System.String
Dim value As System.Boolean
```

```
value = instance.ISetSuppression2(SuppressionState, Config_opt, Config_count, Config_names)
```

C#

```
System.bool ISetSuppression2(
    System.int SuppressionState,
    System.int Config\_opt,
    System.int Config\_count,
    ref System.string Config\_names
)
```

C++/CLI

```
System.bool ISetSuppression2(
    & System.int SuppressionState,
    & System.int Config\_opt,
    & System.int Config\_count,
    & System.String^% Config\_names
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SuppressionState

Suppression state as defined in [swFeatureSuppressionAction_e](#)

Config_opt

Configuration option as defined in [swInConfigurationOpts_e](#)

Config_count

Number of configurations

Config_names

Array of configuration names of size Config_count

Return Value

True if feature is suppressed, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::ISetSuppression2](#).

See Also

[IFeature Interface](#)

[IFeature Members](#)

[IFeature::SetSuppression2 Method](#)

[IFeature::IsSuppressed2 Method](#)

[IFeature::IIsSuppressed2 Method](#)

[IFeature::Visible Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0