

SOLIDWORKS API (.NET VBA C#) — Reference (112/337): IFeature (part 3 of 3)

SOLIDWORKS API Documentation (converted from CHM)

IFeature (part 3 of 3) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsFrozen Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IsFrozen Method (IFeature)

Gets whether this feature is frozen.

.NET Syntax

Visual Basic (Declaration)

```
Function IsFrozen() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature
Dim value As System.Boolean

value = instance.IsFrozen()
```

C#

```
System.bool IsFrozen()
```

C++/CLI

```
System.bool IsFrozen();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the feature is frozen, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Feature::IsFrozen](#).

Example

[Get Whether Feature is Frozen \(VBA\)](#)
[Get Whether Feature is Frozen \(VB.NET\)](#)
[Get Whether Feature is Frozen \(C#\)](#)
[Move Freeze Bar \(C#\)](#)
[Move Freeze Bar \(VB.NET\)](#)
[Move Freeze Bar \(VBA\)](#)

Remarks

When a feature is frozen, you cannot edit the feature and the feature is excluded from rebuilds of the model.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IModelDocExtension::NeedsRebuild2 Property](#)
[IFeature::HasFrozenUpdatePending Method](#)
[IFeature::MoveFreezeBarTo Method](#)
[IFeatureManager::EditFreeze Method](#)
[IFeatureManager::GetFreezeLocation Method](#)
[IModelDocExtension::UpdateFrozenFeatures Method](#)
[IFeature::IsHiddenLock Method](#)
[IFeatureManager::InsertFeatureLock Method \(\)](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsHiddenLock Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IsHiddenLock Method (IFeature)

Gets whether this feature is the freeze bar.

.NET Syntax

Visual Basic (Declaration)

```
Function IsHiddenLock() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Boolean  
  
value = instance.IsHiddenLock()
```

C#

```
System.bool IsHiddenLock()
```

C++/CLI

```
System.bool IsHiddenLock();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the freeze bar, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::IsHiddenLock](#).

Example

[Move Freeze Bar \(VBA\)](#)
[Move Freeze Bar \(VB.NET\)](#)
[Move Freeze Bar \(C#\)](#)

Remarks

Call this property during FeatureManager tree traversal to locate the position of the freeze bar. During a traversal, the freeze bar has been located if:

- [IFeature::Name](#) returns "Freeze****"
- and-
- [IFeature::IsHiddenLock](#) returns true

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::IsFrozen Method](#)
[IFeature::MoveFreezeBarTo Method](#)
[IFeatureManager::EditFreeze Method](#)
[IFeatureManager::GetFreezeLocation Method](#)
[IFeature::HasFrozenUpdatePending Method](#)
[IModelDocExtension::NeedsRebuild2 Property](#)
[IModelDocExtension::UpdateFrozenFeatures Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IsRolledBack Method (IFeature)

Gets whether this feature is rolled back.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IsRolledBack() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature
Dim value As System.Boolean

value = instance.IsRolledBack()
```

C#

```
System.bool IsRolledBack()
```

C++/CLI

```
System.bool IsRolledBack();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the feature is rolled back, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::IsRolledBack](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeatureManager::EditRollback Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsSuppressed Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IsSuppressed Method (IFeature)

Obsolete. Superseded by [IFeature::IsSuppressed2](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IsSuppressed() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature
Dim value As System.Boolean

value = instance.IsSuppressed()
```

C#

```
System.bool IsSuppressed()
```

C++/CLI

```
System.bool IsSuppressed();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Feature.IsSuppressed](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsSuppressed2 Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : IsSuppressed2 Method (IFeature)

Gets whether the feature in the specified configurations is suppressed.

.NET Syntax

Visual Basic (Declaration)

```
Function IsSuppressed2( _  
    ByVal Config\_opt As System.Integer, _  
    ByVal Config\_names As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim Config_opt As System.Integer  
Dim Config_names As System.Object  
Dim value As System.Object  
  
value = instance.IsSuppressed2(Config_opt, Config_names)
```

C#

```
System.object IsSuppressed2(  
    System.int Config\_opt,  
    System.object Config\_names  
)
```

C++/CLI

```
System.Object^ IsSuppressed2(  
& System.int Config\_opt,  
& System.Object^ Config\_names  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Config_opt

Configuration option as defined by [swInConfigurationOpts_e](#)

Config_names

Array of configuration names

Return Value

Array of Booleans indicating the suppression states for the feature in the specified configurations

Visual Basic for Applications (VBA) Syntax

See [Feature::IsSuppressed2](#).

Example

[Is Feature Suppressed in Configuration \(VBA\)](#)
[Get Solid Bodies from Cut-list Folders and Get Custom Properties \(C#\)](#)
[Get Solid Bodies from Cut-list Folders and Get Custom Properties \(VB.NET\)](#)
[Get Solid Bodies from Cut-list Folders and Get Custom Properties \(VBA\)](#)

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::IsSuppressed2 Method](#)
[IFeature::SetSuppression2 Method](#)
[IFeature::SetSuppression2 Method](#)
[IFeature::Visible Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ListExternalFileReferences Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : ListExternalFileReferences Method (IFeature)

Obsolete. Superseded by [IFeature::ListExternalFileReferences2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ListExternalFileReferences( _  
    ByRef ModelPathName As System.Object, _  
    ByRef ComponentPathName As System.Object, _  
    ByRef Feature As System.Object, _  
    ByRef DataType As System.Object, _  
    ByRef Status As System.Object, _  
    ByRef RefEntity As System.Object, _  
    ByRef FeatCom As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim ModelPathName As System.Object  
Dim ComponentPathName As System.Object  
Dim Feature As System.Object  
Dim DataType As System.Object  
Dim Status As System.Object  
Dim RefEntity As System.Object  
Dim FeatCom As System.Object
```

```
instance.ListExternalFileReferences(ModelPathName, ComponentPathName, Feature, DataType, Status,  
RefEntity, FeatCom)
```

C#

```
void ListExternalFileReferences(  
    out System.object ModelPathName,  
    out System.object ComponentPathName,  
    out System.object Feature,  
    out System.object DataType,  
    out System.object Status,  
    out System.object RefEntity,
```

```
    out System.Object FeatCom
)
```

C++/CLI

```
void ListExternalFileReferences(
& [Out] System.Object^ ModelPathName,
& [Out] System.Object^ ComponentPathName,
& [Out] System.Object^ Feature,
& [Out] System.Object^ DataType,
& [Out] System.Object^ Status,
& [Out] System.Object^ RefEntity,
& [Out] System.Object^ FeatCom
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ModelPathName

ComponentPathName

Feature

DataType

Status

RefEntity

FeatCom

Visual Basic for Applications (VBA) Syntax

See [Feature::ListExternalFileReferences](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ListExternalFileReferences2 Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : ListExternalFileReferences2 Method (IFeature)

Gets the names and statuses of the external references on the feature in a part or assembly.

.NET Syntax

Visual Basic (Declaration)

```
Sub ListExternalFileReferences2(
    ByRef ModelPathName As System.Object, _
    ByRef ComponentPathName As System.Object, _
    ByRef Feature As System.Object, _
    ByRef DataType As System.Object, _
    ByRef Status As System.Object, _
    ByRef RefEntity As System.Object, _
    ByRef FeatCom As System.Object, _
    ByRef ConfigOption As System.Integer, _
    ByRef ConfigName As System.String _
)
```

Visual Basic (Usage)

```
Dim instance As IFeature
Dim ModelPathName As System.Object
Dim ComponentPathName As System.Object
Dim Feature As System.Object
Dim DataType As System.Object
```



```

Dim Status As System.Object
Dim RefEntity As System.Object
Dim FeatCom As System.Object
Dim ConfigOption As System.Integer
Dim ConfigName As System.String

```

```

instance.ListExternalFileReferences2(ModelPathName, ComponentPathName, Feature, DataType, Status,
RefEntity, FeatCom, ConfigOption, ConfigName)

```

C#

```

void ListExternalFileReferences2(
    out System.object ModelPathName,
    out System.object ComponentPathName,
    out System.object Feature,
    out System.object DataType,
    out System.object Status,
    out System.object RefEntity,
    out System.object FeatCom,
    out System.int ConfigOption,
    out System.string ConfigName
)

```

C++/CLI

```

void ListExternalFileReferences2(
& [Out] System.Object^ ModelPathName,
& [Out] System.Object^ ComponentPathName,
& [Out] System.Object^ Feature,
& [Out] System.Object^ DataType,
& [Out] System.Object^ Status,
& [Out] System.Object^ RefEntity,
& [Out] System.Object^ FeatCom,
& [Out] System.int ConfigOption,
& [Out] System.String^ ConfigName
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ModelPathName

Array of path names of documents

ComponentPathName

Array of path names of referenced components

Feature

Array of in-context items (sketches, features, and so on)

DataType

Array of data used to create the items (converted edge or face, converted or offset sketch entity, body, and so on)

Status

Array of statuses of external reference as defined in [swExternalReferenceStatus_e](#)

RefEntity

Array of actual items being used and the names of the documents that contain the items

FeatCom

Array of the names of the components in which the affected features exist; this information is only displayed when one or more RefEntity is in a different component in an assembly and does not apply to derived parts

ConfigOption

Configuration option as defined by [swExternalFileReferencesConfig_e](#)

ConfigName

Name of the configuration when ConfigOption is swExternalFileReferencesNamedConfig

Visual Basic for Applications (VBA) Syntax

See [Feature::ListExternalFileReferences2](#).

Example

[Get External References \(VBA\)](#)
[Get External References \(VB.NET\)](#)
[Get External References \(C#\)](#)

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::ListExternalFileReferencesCount Method](#)
[IFeature::UpdateExternalFileReferences Method](#)
[IFeature::IListExternalFileReferences2 Method](#)
[IComponent2::IListExternalFileReferences2 Method](#)
[IComponent2::ListExternalFileReferences2 Method](#)
[IComponent2::ListExternalFileReferencesCount Method](#)
[IComponent2::UpdateExternalFileReferences Method](#)
[IModelDocExtension::IListExternalFileReferences Method](#)
[IModelDocExtension::ListExternalFileReferences Method](#)
[IModelDocExtension::ListExternalFileReferencesCount Method](#)
[IModelDocExtension::UpdateExternalFileReferences Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ListExternalFileReferencesCount Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : ListExternalFileReferencesCount Method (IFeature)

Gets the number of external references on the feature in a part or assembly.

.NET Syntax

Visual Basic (Declaration)

```
Function ListExternalFileReferencesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Integer  
  
value = instance.ListExternalFileReferencesCount()
```

C#

```
System.int ListExternalFileReferencesCount()
```

C++/CLI

```
System.int ListExternalFileReferencesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of external references

Visual Basic for Applications (VBA) Syntax

See [Feature::ListExternalFileReferencesCount](#).

Example

[Get External References \(C#\)](#)
[Get External References \(VB.NET\)](#)
[Get External References \(VBA\)](#)

Remarks

Call this method before calling [IFeature::IListExternalFileReferences2](#) to determine the size of the array.

See Also

[IFeature Interface](#)
[IFeature Members](#)

[IFeature::ListExternalFileReferences2 Method](#)
[IComponent2::ListExternalFileReferences2 Method](#)
[IComponent2::ListExternalFileReferences2 Method](#)
[IComponent2::ListExternalFileReferencesCount Method](#)
[IComponent2::UpdateExternalFileReferences Method](#)
[IModelDocExtension::ListExternalFileReferences Method](#)
[IModelDocExtension::ListExternalFileReferences Method](#)
[IModelDocExtension::ListExternalFileReferencesCount Method](#)
[IModelDocExtension::UpdateExternalFileReferences Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

MakeSubFeature Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : MakeSubFeature Method (IFeature)

Makes a feature become a subfeature of this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function MakeSubFeature( _  
    ByVal SubFeature As Feature _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim SubFeature As Feature  
Dim value As System.Boolean  
  
value = instance.MakeSubFeature(SubFeature)
```

C#

```
System.bool MakeSubFeature(  
    Feature SubFeature  
)
```

C++/CLI

```
System.bool MakeSubFeature(  
& Feature^ SubFeature  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SubFeature
Pointer to the [feature](#) to become a subfeature

Return Value

True if the feature becomes a subfeature, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::MakeSubFeature](#).

Example

[Create Macro Feature Subfeature \(VBA\)](#)

Remarks

- This method is not supported in assembly documents.
- This method can only be used to make subfeatures to a macro feature.

- The feature and subfeature must have a parent-child relationship. If the subfeature is a reference plane, then the feature and subfeatures of the feature are the only parents of the subfeature to be inserted.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetFirstSubFeature Method](#)
[IFeature::GetNextSubFeature Method](#)
[IFeature::!GetFirstSubFeature Method](#)
[IFeature::!GetNextSubFeature Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ModifyDefinition Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : ModifyDefinition Method (IFeature)

Updates the definition of a feature with the new values in an associated feature data object obtained with [IFeature::GetDefinition](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function ModifyDefinition( _  
    ByVal Data As System.Object, _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim Data As System.Object  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.ModifyDefinition(Data, TopDoc, Component)
```

C#

```
System.bool ModifyDefinition(  
    System.object Data,  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool ModifyDefinition(  
& System.Object^ Data,  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Data

Feature data object

TopDoc

Top-level document (see **Remarks**)

Component

Component for the feature (see **Remarks**)

Return Value

True if the feature definition modified successfully, false if not

 Visual Basic for Applications (VBA) Syntax

See [Feature::ModifyDefinition](#).

 Example

[Change Bend Radius of Sheet Metal Part \(VBA\)](#)
[Get and Set Constraint for Dome Feature \(VBA\)](#)
[Modify Plane By Editing its Definition \(VBA\)](#)
[Insert and Change DeleteFace Feature \(C#\)](#)
[Insert and Change DeleteFace Feature \(VB.NET\)](#)
[Insert and Change DeleteFace Feature \(VBA\)](#)

 Remarks

If this method returns:

- False, you may have specified invalid properties in the feature data modifier object. The feature definition was not modified, so the feature may have rolled back to its previous state.
- True, the feature was updated using the feature data modifier object provided. This method will return true even if the feature data modifier object does not include any changed properties or references; some feature data modifier objects reject invalid changes before this method is called. For some feature modifications, this method applies the new properties, returns true, but results in a new rebuild error on the feature.

In either case, this method may leave the feature in an unpredictable state due to errors. After calling this method, call [IFeature::GetErrorCode2](#) to ascertain whether the feature has rebuild errors. If so, try again with valid feature data. To correct rebuild errors, call [IModelDoc2::ForceRebuild3](#). You can also move the rollback bar in the FeatureManager design tree to before and after the feature to correct its state.

You should carefully read specific feature data interface documentation to learn how to correctly specify feature data properties and how this method works with specific features.

To modify a feature in...	Then TopDoc argument...
A part	Is the IModelDoc2 object for the part and the Component argument should be Nothing or null
An assembly	Should be the assembly IModelDoc2 object and the Component argument should be the IComponent2 object in which the feature is to be modified

When you modify a feature in an assembly, this method leaves the assembly in Editing Part mode. You can switch back to editing the assembly by calling [IAssemblyDoc::EditAssembly](#).

 See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::IGetDefinition Method](#)
[IFeature::IModifyDefinition2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

MoveFreezeBarTo Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : MoveFreezeBarTo Method (IFeature)

Obsolete. Superseded by [IFeature::MoveFreezeBarTo2](#).

 .NET Syntax

Visual Basic (Declaration)

```
Function MoveFreezeBarTo( _  
    ByVal Location As System.Integer, _  
    ByVal UpdateAllConfigs As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```

Dim instance As IFeature
Dim Location As System.Integer
Dim UpdateAllConfigs As System.Boolean
Dim value As System.Integer

value = instance.MoveFreezeBarTo(Location, UpdateAllConfigs)

```

C#

```

System.int MoveFreezeBarTo(
    System.int Location,
    System.bool UpdateAllConfigs
)

```

C++/CLI

```

System.int MoveFreezeBarTo(
    & System.int Location,
    & System.bool UpdateAllConfigs
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Location

- [swMoveFreezeBarTo_e](#).swMoveFreezeBarToBeforeFeature
- or-
- [swMoveFreezeBarTo_e](#).swMoveFreezeBarToAfterFeature

UpdateAllConfigs
True to update all configurations, false to not

Return Value

0 indicates that the freeze bar did not move to the specified location in the FeatureManager design tree; a non-0 value indicates that the freeze bar did move to the specified location in the FeatureManager design tree

Visual Basic for Applications (VBA) Syntax

See [Feature::MoveFreezeBarTo](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IModelDocExtension::UpdateFrozenFeatures Method](#)
[IFeature::HasFrozenUpdatePending Method](#)
[IModelDocExtension::NeedsRebuild2 Property](#)
[IFeature::IsFrozen Method](#)
[IFeatureManager::EditFreeze Method](#)
[IFeatureManager::GetFreezeLocation Method](#)
[IFeature::IsHiddenLock Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MoveFreezeBarTo2 Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : MoveFreezeBarTo2 Method (IFeature)

Moves the freeze bar to the specified location in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

```

Function MoveFreezeBarTo2( _
    ByVal Location As System.Integer, _
    ByVal UpdateAllConfigs As System.Boolean, _

```

```
ByVal UnlockConfigs As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim Location As System.Integer  
Dim UpdateAllConfigs As System.Boolean  
Dim UnlockConfigs As System.Boolean  
Dim value As System.Integer  
  
value = instance.MoveFreezeBarTo2(Location, UpdateAllConfigs, UnlockConfigs)
```

C#

```
System.int MoveFreezeBarTo2(  
    System.int Location,  
    System.bool UpdateAllConfigs,  
    System.bool UnlockConfigs  
)
```

C++/CLI

```
System.int MoveFreezeBarTo2(  
    & System.int Location,  
    & System.bool UpdateAllConfigs,  
    & System.bool UnlockConfigs  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Location

- [swMoveFreezeBarTo_e](#).swMoveFreezeBarToBeforeFeature

-or-

- swMoveFreezeBarTo_e.swMoveFreezeBarToAfterFeature

UpdateAllConfigs

True to update all configurations, false to not

UnlockConfigs

True to unlock configurations, false to not

Return Value

1 indicates that the freeze bar did not move to the specified location in the FeatureManager design tree; 0 indicates that the freeze bar did move to the specified location in the FeatureManager design tree

Visual Basic for Applications (VBA) Syntax

See [Feature::MoveFreezeBarTo2](#).

See Also

[IFeature Interface](#)

[IFeature Members](#)

[IFeature::IsFrozen Method \(\)](#)

[IFeature::HasFrozenUpdatePending Method \(\)](#)

[IFeature::IsHiddenLock Method \(\)](#)

[IFeatureManager::EditFreeze2 Method \(\)](#)

[IFeatureManager::GetFreezeLocation Method \(\)](#)

[IModelDocExtension::UpdateFrozenFeatures Method \(\)](#)

[IModelDocExtension::NeedsRebuild2 Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Name Property (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : Name Property (IFeature)

Gets or sets the name of the current feature.

Visual Basic Syntax

Visual Basic (Declaration)

Property Name As System.String

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.String
```

```
instance.Name = value
```

```
value = instance.Name
```

C#

```
System.string Name {get; set;}
```

C++/CLI

```
property System.String^ Name {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the feature

Visual Basic for Applications (VBA) Syntax

See [Feature::Name](#).

Example

[Access Assembly \(C++\)](#)
[Get Parent Features \(C++\)](#)
[Get Selected Feature \(C++\)](#)
[Get Sketches \(C++\)](#)
[Find Total Length of Sketch Segments in Sketch \(VBA\)](#)
[Get Section Properties for Faces from Section Planes \(VBA\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(VB.NET\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(C#\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(VBA\)](#)

Remarks

Feature names can be seen in the FeatureManager design tree of any part or assembly.

Any change to a feature name is not visible to the user until a rebuild has been done. See [IModelDoc2::EditRebuild3](#).

If you are setting the name of a feature, then the new name must be unique in the FeatureManager design tree. If the name is not unique, then the name is not changed. Also, the name cannot contain characters that are reserved by SOLIDWORKS.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetNameForSelection Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Parameter Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : Parameter Method (IFeature)

Gets a pointer to the object for the specified parameter or a pointer to the specified parameter.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function Parameter( _  
    ByVal Name As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim Name As System.String  
Dim value As System.Object  
  
value = instance.Parameter(Name)
```

C#

```
System.Object Parameter(  
    System.string Name  
)
```

C++/CLI

```
System.Object^ Parameter(  
& System.String^ Name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Name of parameter (for example, "D1")

Return Value

Parameter (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Feature::Parameter](#).

Example

[Change Dimension \(VBA\)](#)
[Change Dimension \(VB.NET\)](#)
[Change Dimension \(C#\)](#)

Remarks

Most parameters are [dimensions](#).

The Name argument for this method does not have to be the "full" dimension name. For example, you only need to pass "D1" not "D1@Base-Revolve". The full dimension name is required if you call [IModelDoc2::Parameter](#).

SOLIDWORKS recognizes some characters as special characters. The use of these characters in part or feature names can cause this method to fail and not return a dimension. These special characters are not recognized in names of parts or features:

- at sign (@)
- period (.)
- backslash (/)

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::IParameter Method](#)
[ModelDoc2::IParameter Method](#)
[IDimension::FullName Property](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : RemoveMaterialProperty Method (IFeature)

Obsolete. Superseded by [IFeature::RemoveMaterialProperty2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveMaterialProperty() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Boolean
```

```
value = instance.RemoveMaterialProperty()
```

C#

```
System.bool RemoveMaterialProperty()
```

C++/CLI

```
System.bool RemoveMaterialProperty();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Feature::RemoveMaterialProperty](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveMaterialProperty2 Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : RemoveMaterialProperty2 Method (IFeature)

Removes material property values from this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveMaterialProperty2( _  
    ByVal Config\_opt As System.Integer, _  
    ByVal Config\_names As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim Config_opt As System.Integer  
Dim Config_names As System.Object  
Dim value As System.Boolean
```

```
value = instance.RemoveMaterialProperty2(Config_opt, Config_names)
```

C#

```
System.bool RemoveMaterialProperty2(
    System.int Config\_opt,
    System.object Config\_names
)
```

C++/CLI

```
System.bool RemoveMaterialProperty2(
    & System.int Config\_opt,
    & System.Object^ Config\_names
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Config_opt

Configuration option as defined in [swInConfigurationOpts_e](#)

Config_names

Array of configuration names

Return Value

True if material property values are removed, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::RemoveMaterialProperty2](#).

Remarks

This method is intended to be used on features that have a changed material property value, for example, color.

See Also

[IFeature Interface](#)

[IFeature Members](#)

[IFeature::IRemoveMaterialProperty2 Method](#)

[IFeature::GetMaterialPropertyValues2 Method](#)

[IFeature::IGetMaterialPropertyValues2 Method](#)

[IFeature::ISetMaterialPropertyValues2 Method](#)

[IFeature::SetMaterialPropertyValues2 Method](#)

[IFeature::HasMaterialPropertyValues Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveTexture Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : RemoveTexture Method (IFeature)

Removes texture from this feature in either all of the configurations or only the specified configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveTexture( _
    ByVal BAllConfig As System.Boolean, _
    ByVal Config\_name As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature
Dim BAllConfig As System.Boolean
Dim Config_name As System.String
Dim value As System.Boolean
```

```
value = instance.RemoveTexture(BallConfig, Config_name)
```

C#

```
System.bool RemoveTexture(  
    System.bool BallConfig,  
    System.string Config\_name  
)
```

C++/CLI

```
System.bool RemoveTexture(  
& System.bool BallConfig,  
& System.String^ Config\_name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BallConfig

True to remove texture from this feature in all configurations, false to remove texture from this feature in the configuration specified in Config_name only

Config_name

Name of configuration

Return Value

True if texture is removed, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::RemoveTexture](#).

See Also

[IFeature Interface](#)

[IFeature Members](#)

[IFeature::SetTexture Method](#)

[IFeature::GetTexture Method](#)

[IFeature::RemoveTextureByDisplayState Method](#)

[IFeature::SetTextureByDisplayState Method](#)

[IModelDocExtension::CreateTexture Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

RemoveTextureByDisplayState Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : RemoveTextureByDisplayState Method (IFeature)

Removes texture from this feature in the specified display state.

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveTextureByDisplayState( _  
    ByVal DisplayStateName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim DisplayStateName As System.String  
Dim value As System.Boolean
```

```
value = instance.RemoveTextureByDisplayState(DisplayStateName)
```

C#

```
System.bool RemoveTextureByDisplayState(  
    System.string DisplayStateName  
)
```

C++/CLI

```
System.bool RemoveTextureByDisplayState(  
& System.String^ DisplayStateName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayStateName
Display state name

Return Value

True to remove texture from the feature, false to not

Visual Basic for Applications (VBA) Syntax

See [Feature::RemoveTextureByDisplayState](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::SetTextureByDisplayState Method](#)
[IFeature::SetTexture Method](#)
[IFeature::RemoveTexture Method](#)
[IFeature::GetTexture Method](#)
[IModelDocExtension::CreateTexture Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ResetPropertyExtension Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : ResetPropertyExtension Method (IFeature)

Deletes the property extension for this feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ResetPropertyExtension()
```

Visual Basic (Usage)



```
Dim instance As IFeature  
  
instance.ResetPropertyExtension()
```

C#

```
void ResetPropertyExtension()
```

C++/CLI

```
void ResetPropertyExtension();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Feature::ResetPropertyExtension](#).

 See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::AddPropertyExtension Method](#)
[IFeature::GetPropertyExtension Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Select Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : Select Method (IFeature)

Obsolete. Superseded by [IFeature::Select2](#).

 .NET Syntax

Visual Basic (Declaration)

```
Function Select( _  
    ByVal AppendFlag As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim AppendFlag As System.Boolean  
Dim value As System.Boolean
```

```
value = instance.Select(AppendFlag)
```

C#

```
System.bool Select(  
    System.bool AppendFlag  
)
```

C++/CLI

```
System.bool Select(  
    & System.bool AppendFlag  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AppendFlag

 Visual Basic for Applications (VBA) Syntax

See [Feature::Select](#).

 See Also

[IFeature Interface](#)
[IFeature Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Select2 Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : Select2 Method (IFeature)

Selects and marks this feature.

 .NET Syntax

Visual Basic (Declaration)

```
Function Select2( _  
    ByVal Append As System.Boolean, _  
    ByVal Mark As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim Append As System.Boolean  
Dim Mark As System.Integer  
Dim value As System.Boolean  
  
value = instance.Select2(Append, Mark)
```

C#

```
System.bool Select2(  
    System.bool Append,  
    System.int Mark  
)
```

C++/CLI

```
System.bool Select2(  
& System.bool Append,  
& System.int Mark  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Append

True appends the feature to the current selection list, false replaces the current selection list

Mark

Value you want to use as a mark; this number is used by functions that require ordered selection

Return Value

True if the feature was selected, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::Select2](#).

Example

[Get Plane or Face for Sketch \(VBA\)](#)
[Insert DXF File and Add Dimension \(VBA\)](#)
[Traverse Assembly and Hide All Sketches \(VBA\)](#)
[Suppress Component Feature \(C#\)](#)
[Suppress Component Feature \(VB.NET\)](#)
[Suppress Component Feature \(VBA\)](#)
[Select Plane \(VBA\)](#)
[Select Plane \(VB.NET\)](#)
[Select Plane \(C#\)](#)

Remarks

If an object is already selected with a mark of x and you attempt to select the same object again using this method with Append = true and Mark = y, then that object remains selected with a mark of x. Reselecting a previously selected object does not assign a new mark value.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::Deselect Method](#)
[IFeature::GetSpecificFeature2 Method](#)

Availability

SelectByMark Method (IFeature)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IFeature interface](#) : SelectByMark Method (IFeature)**Obsolete.** Superseded by [IFeature::Select2](#)

.NET Syntax

Visual Basic (Declaration)

```
Function SelectByMark( _
    ByVal AppendFlag As System.Boolean, _
    ByVal Mark As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature
Dim AppendFlag As System.Boolean
Dim Mark As System.Integer
Dim value As System.Boolean
```

```
value = instance.SelectByMark(AppendFlag, Mark)
```

C#

```
System.bool SelectByMark(
    System.bool AppendFlag,
    System.int Mark
)
```

C++/CLI

```
System.bool SelectByMark(
    & System.bool AppendFlag,
    & System.int Mark
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

*AppendFlag**Mark*

Visual Basic for Applications (VBA) Syntax

See [Feature::SelectByMark](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)

SetBodiesToKeep Method (IFeature)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [IFeature interface](#) : SetBodiesToKeep Method (IFeature)

Set the bodies to keep and their configurations for features that create multiple bodies in parts and assemblies.

.NET Syntax

Visual Basic (Declaration)

```

Sub SetBodiesToKeep( _
    ByVal AllBodies As System.Boolean, _
    ByVal BodiesToKeep As System.Object, _
    ByVal ConfigOption As System.Integer, _
    ByVal ConfigNames As System.Object _
)

```

Visual Basic (Usage)



```

Dim instance As IFeature
Dim AllBodies As System.Boolean
Dim BodiesToKeep As System.Object
Dim ConfigOption As System.Integer
Dim ConfigNames As System.Object

instance.SetBodiesToKeep(AllBodies, BodiesToKeep, ConfigOption, ConfigNames)

```

C#

```

void SetBodiesToKeep(
    System.bool AllBodies,
    System.object BodiesToKeep,
    System.int ConfigOption,
    System.object ConfigNames
)

```

C++/CLI

```

void SetBodiesToKeep(
    & System.bool AllBodies,
    & System.Object^ BodiesToKeep,
    & System.int ConfigOption,
    & System.Object^ ConfigNames
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AllBodies

True to keep all bodies, false to not

BodiesToKeep

Array of bodies to keep

ConfigOption

Configuration options as defined in [swInConfigurationOptions](#)

ConfigNames

Array of configuration names

Visual Basic for Applications (VBA) Syntax

See [Feature::SetBodiesToKeep](#).

Example

[Cut Body and Keep All Bodies \(C#\)](#)

[Cut Body and Keep All Bodies \(VB.NET\)](#)

[Cut Body and Keep All Bodies \(VBA\)](#)

See Also

[IFeature Interface](#)

[IFeature Members](#)

[IAssemblyDoc PromptBodiesToKeepNotify Event](#)

[IPartDoc PromptBodiesToKeepNotify Event](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SetBody Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : SetBody Method (IFeature)

Obsolete. Superseded by [IFeature::SetBody2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetBody( _  
    ByVal BodyIn As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim BodyIn As System.Object  
Dim value As System.Boolean  
  
value = instance.SetBody(BodyIn)
```

C#

```
System.bool SetBody(  
    System.object BodyIn  
)
```

C++/CLI

```
System.bool SetBody(  
& System.Object^ BodyIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BodyIn

Visual Basic for Applications (VBA) Syntax

See [Feature::SetBody](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetBody2 Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : SetBody2 Method (IFeature)

Replaces an imported base feature body.

.NET Syntax

Visual Basic (Declaration)

```
Function SetBody2( _  
    ByVal BodyIn As System.Object, _  
    ByVal ApplyUserIds As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```

Dim instance As IFeature
Dim BodyIn As System.Object
Dim ApplyUserIds As System.Boolean
Dim value As System.Boolean

value = instance.SetBody2(BodyIn, ApplyUserIds)

```

C#

```

System.bool SetBody2(
    System.object BodyIn,
    System.bool ApplyUserIds
)

```

C++/CLI

```

System.bool SetBody2(
    & System.Object^ BodyIn,
    & System.bool ApplyUserIds
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BodyIn

Temporary [body](#) that replaces the base feature body

ApplyUserIds

True applies user-defined face IDs, false does not

Return Value

True if the original body was successfully replaced, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::SetBody2](#).

Example

[Change Imported File Associated with an Imported Feature \(VBA\)](#)

Remarks

You must create the replacement body as an imported body using [IBody2::CreateBodyFromSurfaces](#) or [IBody2::CreateTempBodyFromSurfaces](#) as a copy of an imported body generated by these methods, or using translation from IGES in, STEP in, and so on.

If this feature is not the base feature or the body is not an imported body, then the method returns false.

This method replaces the base body or ref-surface body if you created either of these features from imported geometry. If child features exist, then you can use [IFace2::GetFaceId](#) to set the face IDs to both the old body and the replacement body before calling IFeature::SetBody2. For example, if you are expecting a child feature on a face of the old body to be mapped to a face on the replacement body, you need to set the same ID (integer) to these two faces. This mechanism enables child features to re-attach themselves to the replacement body because IFeature::!SetBody3 cannot do this automatically.

If applyUserIds...	Then Feature::SetBodyw...
True	Tries to match the face IDs on the replacement body with IDs on the child features. This helps when re-attaching the features to the replacement body.
false	Replaces the original body with the replacement body. Face IDs are not be used to match up new faces with child features.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::IsBase2 Method](#)
[IFeature::!SetBody3 Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetImportedFeatureParameters Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : SetImportedFeatureParameters Method (IFeature)

Sets the data object for this 3D Interconnect part or assembly.

.NET Syntax

Visual Basic (Declaration)

```
Function SetImportedFeatureParameters( _  
    ByVal DataObj As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim DataObj As System.Object  
Dim value As System.Integer  
  
value = instance.SetImportedFeatureParameters(DataObj)
```

C#

```
System.int SetImportedFeatureParameters(  
    System.object DataObj  
)
```

C++/CLI

```
System.int SetImportedFeatureParameters(  
& System.Object^ DataObj  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DataObj
[IImport3DInterconnectData](#)

Return Value

Error codes as defined in [sw3DInterconnectImportErrors_e](#)

Visual Basic for Applications (VBA) Syntax

See [Feature::SetImportedFeatureParameters](#).

Example

See the [IImport3DInterconnectData](#) examples.

Remarks

Before calling this method, use [IFeature::Is3DInterconnectFeature](#) to ensure that this is a 3D Interconnect feature.

See Also

[IFeature Interface](#)
[IFeature Members](#)

Availability

SetImportedFileName Method (IFeature)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : SetImportedFileName Method (IFeature)

Sets the file name of an imported feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetImportedFileName( _
    ByVal ImpName As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature
Dim ImpName As System.String
Dim value As System.Boolean

value = instance.SetImportedFileName(ImpName)
```

C#

```
System.bool SetImportedFileName(
    System.string ImpName
)
```

C++/CLI

```
System.bool SetImportedFileName(
    & System.String^ ImpName
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ImpName

New filename of the imported feature

Return Value

True if the filename was changed, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::SetImportedFileName](#).

Remarks

This method applies only to imported features. To get the type of this feature, use [IFeature::GetType](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetImportedFileName Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SetMaterialIdName Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : SetMaterialIdName Method (IFeature)

Sets the material name for this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetMaterialIdName( _  
    ByVal Name As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim Name As System.String  
Dim value As System.Boolean  
  
value = instance.SetMaterialIdName(Name)
```

C#

```
System.bool SetMaterialIdName(  
    System.string Name  
)
```

C++/CLI

```
System.bool SetMaterialIdName(  
& System.String^ Name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name
Material name for this feature

Return Value

True if the material name was set successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::SetMaterialIdName](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetMaterialIdName Method](#)
[IFeature::GetMaterialUserName Method](#)
[IFeature::SetMaterialUserName Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetMaterialPropertyValues Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : SetMaterialPropertyValues Method (IFeature)

Obsolete. Superseded by [IFeature::SetMaterialPropertyValues2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetMaterialPropertyValues( _  
    ByVal MaterialPropertyValues As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IFeature  
Dim MaterialPropertyValues As System.Object  
Dim value As System.Boolean  
  
value = instance.SetMaterialPropertyValues(MaterialPropertyValues)
```

C#

```
System.bool SetMaterialPropertyValues(  
    System.object MaterialPropertyValues  
)
```

C++/CLI

```
System.bool SetMaterialPropertyValues(  
    & System.Object^ MaterialPropertyValues  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

MaterialPropertyValues

Visual Basic for Applications (VBA) Syntax

See [Feature::SetMaterialPropertyValues](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetMaterialPropertyValues2 Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : SetMaterialPropertyValues2 Method (IFeature)

Sets the material property values for this feature in the specified configurations.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetMaterialPropertyValues2( _  
    ByVal Material\_values As System.Object, _  
    ByVal Config\_opt As System.Integer, _  
    ByVal Config\_names As System.Object _  
)
```

Visual Basic (Usage)

```
Dim instance As IFeature  
Dim Material_values As System.Object  
Dim Config_opt As System.Integer  
Dim Config_names As System.Object  
  
instance.SetMaterialPropertyValues2(Material_values, Config_opt, Config_names)
```

C#

```
void SetMaterialPropertyValues2(  
    System.object Material\_values,  
    System.int Config\_opt,  
    System.object Config\_names  
)
```

```
void SetMaterialPropertyValues2(
& System.Object^ Material_values,
& System.int Config_opt,
& System.Object^ Config_names
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Material_values

Array of material property values

Config_opt

Configuration option as defined in [swInConfigurationOpts_e](#)

Config_names

Array of configuration names

Visual Basic for Applications (VBA) Syntax

See [Feature::SetMaterialPropertyValues2](#).

Remarks

The material properties are color (R,G,B values), reflectivity (ambient, diffuse, specular, shininess), transparency, and emission. Valid values are between 0.0 and 1.0, inclusive, for all material properties.

If you set Config_opt to swThisConfiguration or swAllConfiguration, then Config_names is ignored.

The format of the Material_values array:

[*R*, *G*, *B*, *Ambient*, *Diffuse*, *Specular*, *Shininess*, *Transparency*, *Emission*]

To see a color change, you must:

1. Specify *R*, *G*, and *B*, each with a value between 0.0 and 1.0, inclusive. (These values are internally multiplied by 255.0 to determine the RGB color.)
2. Specify the reflectivity properties (*Diffuse*, *Specular*, *Shininess* (1.0 - Specular spread/Blurriness)), each with a value greater than 0.0 and less than or equal to 1.0.
3. Specify *Ambient*, *Transparency* and *Emission*, each with a value between 0.0 and 1.0, inclusive.
4. Refresh the graphics area after calling this method.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::SetMaterialPropertyValues2 Method](#)
[IFeature::GetMaterialPropertyValues2 Method](#)
[IFeature::GetMaterialPropertyValues2 Method](#)
[IFeature::IRemoveMaterialProperty2 Method](#)
[IFeature::RemoveMaterialProperty2 Method](#)
[IFeature::HasMaterialPropertyValues Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetMaterialUserName Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : SetMaterialUserName Method (IFeature)

Sets the material user name for this feature, which is visible to the user.

.NET Syntax

Visual Basic (Declaration)

```
Function SetMaterialUserName( _
    ByVal Name As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature
Dim Name As System.String
Dim value As System.Boolean

value = instance.SetMaterialUserName(Name)
```

C#

```
System.bool SetMaterialUserName(
    System.string Name
)
```

C++/CLI

```
System.bool SetMaterialUserName(
    & System.String^ Name
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Material user name property for this feature

Return Value

True if the material user name was set successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::SetMaterialUserName](#).

See Also

[IFeature Interface](#)

[IFeature Members](#)

[IFeature::GetMaterialUserName Method](#)

[IFeature::GetMaterialIdName Method](#)

[IFeature::SetMaterialIdName Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetSuppression Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : SetSuppression Method (IFeature)

Obsolete. Superseded by [IFeature::SetSuppression2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetSuppression( _
    ByVal SuppressState As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature
Dim SuppressState As System.Integer
Dim value As System.Boolean

value = instance.SetSuppression(SuppressState)
```

C#

```
System.bool SetSuppression(
    System.int SuppressState
)
```

C++/CLI

```
System.bool SetSuppression(  
& System.int SupressState  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SupressState

Visual Basic for Applications (VBA) Syntax

See [Feature::SetSuppression](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetSuppression2 Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : SetSuppression2 Method (IFeature)

Sets the suppression state of this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetSuppression2(  
    ByVal SuppressionState As System.Integer, _  
    ByVal Config\_opt As System.Integer, _  
    ByVal Config\_names As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim SuppressionState As System.Integer  
Dim Config_opt As System.Integer  
Dim Config_names As System.Object  
Dim value As System.Boolean
```

```
value = instance.SetSuppression2(SuppressionState, Config_opt, Config_names)
```

C#

```
System.bool SetSuppression2(  
    System.int SuppressionState,  
    System.int Config\_opt,  
    System.object Config\_names  
)
```

C++/CLI

```
System.bool SetSuppression2(  
& System.int SuppressionState,  
& System.int Config\_opt,  
& System.Object^ Config\_names  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SuppressionState

Suppression state as defined in [swFeatureSuppressionAction_e](#)

Config_opt

Configuration option as defined in [swInConfigurationOpts_e](#) (see **Remarks**)
Config_names
Array of configuration names; valid only if Config_opt set to swInConfigurationOpts_e.swSpecifyConfiguration

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::SetSuppression2](#).

Remarks

This method requires that you specify Config_opt.
SOLIDWORKS does not allow suppressing features while a PropertyManager page is open.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::IsSetSuppression2 Method](#)
[IFeature::IsSuppressed2 Method](#)
[IFeature::IsSuppressed2 Method](#)
[IFeature::Visible Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTexture Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : SetTexture Method (IFeature)

Applies texture to this feature in either all configurations or only the specified configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function SetTexture( _  
    ByVal BallConfig As System.Boolean, _  
    ByVal Config\_name As System.String, _  
    ByVal TextureIn As Texture _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IFeature  
Dim BallConfig As System.Boolean  
Dim Config_name As System.String  
Dim TextureIn As Texture  
Dim value As System.Boolean  
  
value = instance.SetTexture(BallConfig, Config_name, TextureIn)
```

C#

```
System.bool SetTexture(  
    System.bool BallConfig,  
    System.string Config\_name,  
    Texture TextureIn  
)
```

C++/CLI

```
System.bool SetTexture(  
& System.bool BallConfig,
```



Copy Code

```
& System.String^ Config\_name,  
& Texture^ TextureIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BAllConfig

True to apply texture to this feature all configurations, false to apply texture to this feature in the configuration specified in config_name only

Config_name

Name of configuration

TextureIn

Pointer to the [ITexture](#) object

Return Value

True if texture is applied, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::SetTexture](#).

See Also

[IFeature Interface](#)

[IFeature Members](#)

[IFeature::GetTexture Method](#)

[IFeature::RemoveTexture Method](#)

[IModelDocExtension::CreateTexture Method](#)

[IFeature::SetTextureByDisplayState Method](#)

[IFeature::RemoveTextureByDisplayState Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTextureByDisplayState Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : SetTextureByDisplayState Method (IFeature)

Applies texture to this feature in the specified display state.

.NET Syntax

Visual Basic (Declaration)

```
Function SetTextureByDisplayState( _  
    ByVal DisplayStateName As System.String, _  
    ByVal TextureIn As Texture _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IFeature  
Dim DisplayStateName As System.String  
Dim TextureIn As Texture  
Dim value As System.Boolean
```

```
value = instance.SetTextureByDisplayState(DisplayStateName, TextureIn)
```

C#

```
System.bool SetTextureByDisplayState(  
    System.string DisplayStateName,  
    Texture TextureIn  
)
```

C++/CLI

```
System.bool SetTextureByDisplayState(  
& System.String^ DisplayStateName,
```

```
& Texture^ TextureIn
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayStateName
Display state name
TextureIn
[Texture](#)

Return Value

True if the texture is applied to the feature, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::SetTextureByDisplayState](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetTexture Method](#)
[IFeature::RemoveTexture Method](#)
[IFeature::RemoveTextureByDisplayState Method](#)
[IFeature::SetTexture Method](#)
[IModelDocExtension::CreateTexture Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetUIState Method (IFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : SetUIState Method (IFeature)

Sets the user-interface state of the current feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetUIState( _
    ByVal StateType As System.Integer, _
    ByVal Flag As System.Boolean _
)
```

Visual Basic (Usage)

```
Dim instance As IFeature
Dim StateType As System.Integer
Dim Flag As System.Boolean

instance.SetUIState(StateType, Flag)
```

C#

```
void SetUIState(
    System.int StateType,
    System.bool Flag
)
```

C++/CLI

```
void SetUIState(
    & System.int StateType,
    & System.bool Flag
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StateType

User interface state type as defined in [swUIStates_e](#)

Flag

True to set the user-interface state, false to not

Visual Basic for Applications (VBA) Syntax

See [Feature::SetUIState](#).

Example

[Display of Item in FeatureManager Design Tree \(C++\)](#)

[Hide Feature in FeatureManager Design Tree \(VBA\)](#)

Remarks

If you pass in StateType of swIsHiddenInFeatureMgr and flag of True, then this method hides the display of the feature in the FeatureManager design tree. To see your changes in the FeatureManager design tree , use [IModelDoc2::EditRebuild3](#).

Features are initialized with all user-interface state type values set to false. However, in the case of attributes, you can use [IAttributeDef::CreateInstance5](#) to set the desired display state of the attribute at the time of creation.

A change in a the state setting of a feature causes all its dependents to inherit the same behavior, without actually setting the state type values c those dependents. Therefore, to get the actual user-interface state value of a feature, you can query its owner.

The user-interface state is not a property.

See Also

[IFeature Interface](#)

[IFeature Members](#)

[IFeature::Visible Property](#)

[IFeature::GetUIState Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Update3DInterconnectModel Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : Update3DInterconnectModel Method (IFeature)

Updates the model for this 3D Interconnect part or assembly.

.NET Syntax

Visual Basic (Declaration)

```
Function Update3DInterconnectModel() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeature
Dim value As System.Boolean
```

```
value = instance.Update3DInterconnectModel()
```

C#

```
System.bool Update3DInterconnectModel()
```

C++/CLI

```
System.bool Update3DInterconnectModel();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if model updated successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [Feature::Update3DInterconnectModel](#).

Example

See the [IImport3DInterconnectData](#) examples.

Remarks

Before calling this method, use [IFeature::Is3DInterconnectUpdateAvailable](#) to determine whether an update is available.

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IImport3DInterconnectData Interface](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UpdateExternalFileReferences Method (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : UpdateExternalFileReferences Method (IFeature)

Updates the external file references on this model.

.NET Syntax

Visual Basic (Declaration)

```
Sub UpdateExternalFileReferences( _  
    ByVal ConfigOption As System.Integer, _  
    ByVal ConfigName As System.String, _  
    ByVal UpdateStatus As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim ConfigOption As System.Integer  
Dim ConfigName As System.String  
Dim UpdateStatus As System.Integer  
  
instance.UpdateExternalFileReferences(ConfigOption, ConfigName, UpdateStatus)
```

C#

```
void UpdateExternalFileReferences(  
    System.int ConfigOption,  
    System.string ConfigName,  
    System.int UpdateStatus  
)
```

C++/CLI

```
void UpdateExternalFileReferences(  
& System.int ConfigOption,  
& System.String^ ConfigName,  
& System.int UpdateStatus  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ConfigOption
Configuration options as defined by [swExternalFileReferencesConfig_e](#)
ConfigName
Name of configuration; required when ConfigOption set to swExternalFileReferencesNamedConfig
UpdateStatus
Update status option as defined by [swExternalFileReferencesUpdate_e](#)

Visual Basic for Applications (VBA) Syntax

See [Feature::UpdateExternalFileReferences](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::IListExternalFileReferences2 Method](#)
[IFeature::ListExternalFileReferences2 Method](#)
[IFeature::ListExternalFileReferencesCount Method](#)
[IComponent2::IListExternalFileReferences2 Method](#)
[IComponent2::ListExternalFileReferences Method](#)
[IComponent2::RemoveMaterialProperty2 Method](#)
[IComponent2::UpdateExternalFileReferences Method](#)
[IModelDocExtension::IListExternalFileReferences Method](#)
[IModelDocExtension::ListExternalFileReferences Method](#)
[IModelDocExtension::ListExternalFileReferencesCount Method](#)
[IModelDocExtension::UpdateExternalFileReferences Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Visible Property (IFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeature Interface](#) : Visible Property (IFeature)

Gets the visibility state of this feature.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Visible As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFeature  
Dim value As System.Integer  
  
value = instance.Visible
```

C#

```
System.int Visible {get;}
```

C++/CLI

```
property System.int Visible {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Visibility state as defined by [swVisibilityState_e](#)

Visual Basic for Applications (VBA) Syntax

See [Feature::Visible](#).

See Also

[IFeature Interface](#)
[IFeature Members](#)
[IFeature::GetUIState Method](#)
[IFeature::IsSuppressed2 Method](#)
[IFeature::SetSuppression2 Method](#)
[IFeature::SetUIState Method](#)

Availability

SOLIDWORKS 2004 SP4, Revision Number 12.4