

SOLIDWORKS API (.NET VBA C#) — Reference (122/337): IFeatureManager (part 9 of 9)

SOLIDWORKS API Documentation (converted from CHM)

IFeatureManager (part 9 of 9) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetFreeformPointData Method (IFeatureManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatureManager Interface](#) : SetFreeformPointData Method (IFeatureManager)

Adds a point to a curve for a Freeform feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetFreeformPointData( _  
    ByVal Direction As System.Short, _  
    ByVal CurveParameter As System.Double, _  
    ByVal ParameterOnCurve As System.Double, _  
    ByVal XOffset As System.Double, _  
    ByVal YOffset As System.Double, _  
    ByVal ZOffset As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IFeatureManager  
Dim Direction As System.Short  
Dim CurveParameter As System.Double  
Dim ParameterOnCurve As System.Double  
Dim XOffset As System.Double  
Dim YOffset As System.Double  
Dim ZOffset As System.Double  
  
instance.SetFreeformPointData(Direction, CurveParameter, ParameterOnCurve, XOffset, YOffset, ZOffset)
```

C#

```
void SetFreeformPointData(  
    System.short Direction,  
    System.double CurveParameter,  
    System.double ParameterOnCurve,  
    System.double XOffset,  
    System.double YOffset,  
    System.double ZOffset  
)
```

C++/CLI

```
void SetFreeformPointData(  
& System.short Direction,  
& System.double CurveParameter,  
& System.double ParameterOnCurve,  
& System.double XOffset,  
& System.double YOffset,  
& System.double ZOffset  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction

Direction of the curve; valid values are either 0 or 1

CurveParameter

Curve where to add the point

ParameterOnCurve

Where on the curve to add the point

XOffset

Value by which to offset x (this value is typically 0, which indicates that the point was not modified)

YOffset

Value by which to offset y (this value is typically 0, which indicates that the point was not modified)

ZOffset
Value by which to offset z (this value is typically 0, which indicates that the point was not modified)

Visual Basic for Applications (VBA) Syntax

See [FeatureManager::SetFreeformPointData](#).

Remarks

The SOLIDWORKS API Freeform-related methods are intended to journal the actions performed by an interactive user while creating the feature. Because user interaction is required to create a Freeform feature, fully automating the creation of it is not possible using the SOLIDWORKS API.

The typical steps performed by an interactive user to create a Freeform feature are:

1. Select the face to form.
2. Add curves on the selected face. Corresponds to [IFeatureManager::SetFreeformCurveData](#).
3. Add points on the curves. Corresponds to [IFeatureManager::SetFreeformPointData](#).
4. Specify boundary continuity. Corresponds to [IFeatureManager::SetFreeformBoundaryContinuity](#).

Interactively pull or push the points to change the shape of the selected face.

5. Insert the Freeform feature. Corresponds to this method, [IFeatureManager::InsertFreeform2](#).

Record a macro while interactively creating a Freeform feature, then examine the macro to see the order in which the Freeform-related methods are recorded.

See Also

[IFeatureManager Interface](#)
[IFeatureManager Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetNetBlendCurveData Method (IFeatureManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatureManager Interface](#) : SetNetBlendCurveData Method (IFeatureManager)

Sets the data for a curve for this boundary feature or boundary surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetNetBlendCurveData( _  
    ByVal Direction As System.Short, _  
    ByVal CurveIndex As System.Short, _  
    ByVal TangentType As System.Short, _  
    ByVal SignedDraftAngle As System.Double, _  
    ByVal SignedTangentLength As System.Double, _  
    ByVal TangentLengthApplyAll As System.Boolean _  
) As Feature
```

Visual Basic (Usage)



```
Dim instance As IFeatureManager  
Dim Direction As System.Short  
Dim CurveIndex As System.Short  
Dim TangentType As System.Short  
Dim SignedDraftAngle As System.Double  
Dim SignedTangentLength As System.Double  
Dim TangentLengthApplyAll As System.Boolean  
Dim value As Feature
```

```
value = instance.SetNetBlendCurveData(Direction, CurveIndex, TangentType, SignedDraftAngle,  
SignedTangentLength, TangentLengthApplyAll)
```

C#

```
Feature SetNetBlendCurveData(  
    System.short Direction,  
    System.short CurveIndex,  
    System.short TangentType,  
    System.double SignedDraftAngle,  
    System.double SignedTangentLength,  
    System.bool TangentLengthApplyAll  
)
```

C++/CLI

```
Feature^ SetNetBlendCurveData(  
& System.short Direction,  
& System.short CurveIndex,  
& System.short TangentType,  
& System.double SignedDraftAngle,  
& System.double SignedTangentLength,  
& System.bool TangentLengthApplyAll  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction

- 0 = Direction 1
- 1 = Direction 2

CurveIndex

Index of curve in the specified direction

TangentType

Type of tangency as defined in [swTangencyType_e](#)

SignedDraftAngle

Draft angle

SignedTangentLength

Tangent length

TangentLengthApplyAll

True if the tangent length applies to all curves, false if not

Return Value

[Feature](#)

Visual Basic for Applications (VBA) Syntax

See [FeatureManager::SetNetBlendCurveData](#).

Example

[Insert Boundary Surface Feature \(VBA\)](#)
[Insert Boundary Feature \(C#\)](#)
[Insert Boundary Feature \(VB.NET\)](#)
[Insert Boundary Feature \(VBA\)](#)

Remarks

You must use this method to set the data for each curve in a boundary feature or boundary surface feature.

See Also

[IFeatureManager Interface](#)
[IFeatureManager Members](#)
[IFeatureManager::InsertNetBlend Method](#)
[IFeatureManager::SetNetBlendDirectionData Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetNetBlendDirectionData Method (IFeatureManager)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatureManager Interface](#) : SetNetBlendDirectionData Method (IFeatureManager)

Sets the curve set data (one for each of the two directions) for this boundary feature or boundary surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetNetBlendDirectionData( _  
    ByVal Direction As System.Short, _  
    ByVal InfluenceType As System.Short, _  
    ByVal TrimCurves As System.Short, _  
    ByVal BlendClosed As System.Boolean, _  
    ByVal SplitSurfaces As System.Boolean _  
) As Feature
```

Visual Basic (Usage)



```
Dim instance As IFeatureManager  
Dim Direction As System.Short  
Dim InfluenceType As System.Short  
Dim TrimCurves As System.Short  
Dim BlendClosed As System.Boolean  
Dim SplitSurfaces As System.Boolean  
Dim value As Feature  
  
value = instance.SetNetBlendDirectionData(Direction, InfluenceType, TrimCurves, BlendClosed, SplitSurfaces)
```

C#

```
Feature SetNetBlendDirectionData(  
    System.short Direction,  
    System.short InfluenceType,  
    System.short TrimCurves,  
    System.bool BlendClosed,  
    System.bool SplitSurfaces  
)
```

C++/CLI

```
Feature^ SetNetBlendDirectionData(  
& System.short Direction,  
& System.short InfluenceType,  
& System.short TrimCurves,  
& System.bool BlendClosed,  
& System.bool SplitSurfaces  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction

- 0 = Direction 1
- 1 = Direction 2

InfluenceType

- 0 = Global
- 1 = To Next Curve
- 2 = To Next Sharp
- 3 = To Next Edge

TrimCurves

- 0 = False to trim curves
- 1 = True to trim curves

BlendClosed

True closes this boundary feature or boundary surface feature, false leaves this boundary feature or boundary surface feature open

SplitSurfaces

Not used

Return Value

[Feature](#)

Visual Basic for Applications (VBA) Syntax

See [FeatureManager::SetNetBlendDirectionData](#).

Example

[Insert Boundary Surface Feature \(VBA\)](#)
[Insert Boundary Feature \(C#\)](#)
[Insert Boundary Feature \(VB.NET\)](#)
[Insert Boundary Feature \(VBA\)](#)

See Also

[IFeatureManager Interface](#)
[IFeatureManager Members](#)
[IFeatureManager::InsertNetBlend Method](#)
[IFeatureManager::SetNetBlendCurveData Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowBodies Method (IFeatureManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatureManager Interface](#) : ShowBodies Method (IFeatureManager)

Shows both hidden solid and surface bodies.

.NET Syntax

Visual Basic (Declaration)

```
Sub ShowBodies()
```

Visual Basic (Usage)



```
Dim instance As IFeatureManager
```

```
instance.ShowBodies()
```

C#

```
void ShowBodies()
```

C++/CLI

```
void ShowBodies();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [FeatureManager::ShowBodies](#).

See Also

[IFeatureManager Interface](#)
[IFeatureManager Members](#)
[IFeatureManager::HideBodies Method](#)
[IBody2::DisableDisplay Property](#)
[IModelDoc2::HideShowBodies Method](#)
[IModelDoc2::HideSolidBody Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowComponentConfigurationDescriptions Property (IFeatureManager)

[See Also](#) [Example](#)



Gets or sets whether to show the active configuration's component configuration descriptions in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

Property ShowComponentConfigurationDescriptions As System.Boolean

Visual Basic (Usage)



```
Dim instance As IFeatureManager
Dim value As System.Boolean

instance.ShowComponentConfigurationDescriptions = value

value = instance.ShowComponentConfigurationDescriptions
```

C#

```
System.bool ShowComponentConfigurationDescriptions {get; set;}
```

C++/CLI

```
property System.bool ShowComponentConfigurationDescriptions {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True shows the active configuration's component configuration descriptions, false does not

Visual Basic for Applications (VBA) Syntax

See [FeatureManager::ShowComponentConfigurationDescriptions](#).

Example

[Show Components and Component Configurations Names and Descriptions \(VBA\)](#)

See Also

[IFeatureManager Interface](#)
[IFeatureManager Members](#)
[IFeatureManager::ShowComponentConfigurationNames Property](#)
[IFeatureManager::ShowComponentDescriptions Property](#)
[IFeatureManager::ShowComponentNames Property](#)
[IFeatureManager::ShowFeatureDescription Property](#)
[IFeatureManager::ShowFeatureName Property](#)
[IFeatureManager::ShowDisplayStateNames Property](#)

Availability

SOLIDWORKS 2007 SP3, Revision Number 15.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowComponentConfigurationNames Property (IFeatureManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatureManager Interface](#) : ShowComponentConfigurationNames Property (IFeatureManager)

Gets or sets whether to show the active configuration's component configuration names in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

Property ShowComponentConfigurationNames As System.Boolean

```
Dim instance As IFeatureManager
Dim value As System.Boolean

instance.ShowComponentConfigurationNames = value

value = instance.ShowComponentConfigurationNames
```

C#

```
System.bool ShowComponentConfigurationNames {get; set;}
```

C++/CLI

```
property System.bool ShowComponentConfigurationNames {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True shows the active configuration's component configuration names, false does not

Visual Basic for Applications (VBA) Syntax

See [FeatureManager::ShowComponentConfigurationNames](#).

Example

[Show Components and Component Configurations Names and Descriptions \(VBA\)](#)

See Also

[IFeatureManager Interface](#)
[IFeatureManager Members](#)
[IFeatureManager::ShowComponentConfigurationDescriptions Property](#)
[IFeatureManager::ShowComponentDescriptions Property](#)
[IFeatureManager::ShowComponentNames Property](#)
[IFeatureManager::ShowFeatureDescription Property](#)
[IFeatureManager::ShowFeatureName Property](#)
[IFeatureManager::ShowDisplayStateNames Property](#)

Availability

SOLIDWORKS 2007 SP3, Revision Number 15.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowComponentDescriptions Property (IFeatureManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatureManager Interface](#) : ShowComponentDescriptions Property (IFeatureManager)

Gets or sets whether to show the component configuration descriptions in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

```
Property ShowComponentDescriptions As System.Boolean
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IFeatureManager
Dim value As System.Boolean

instance.ShowComponentDescriptions = value

value = instance.ShowComponentDescriptions
```

C#

```
System.bool ShowComponentDescriptions {get; set;}
```

C++/CLI

```
property System.bool ShowComponentDescriptions {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True shows the component configuration descriptions, false does not

Visual Basic for Applications (VBA) Syntax

See [FeatureManager::ShowComponentDescriptions](#).

Example

[Show Components and Component Configurations Names and Descriptions \(VBA\)](#)

See Also

[IFeatureManager Interface](#)
[IFeatureManager Members](#)
[IFeatureManager::ShowComponentConfigurationDescriptions Property](#)
[IFeatureManager::ShowComponentConfigurationNames Property](#)
[IFeatureManager::ShowComponentNames Property](#)
[IFeatureManager::ShowFeatureDescription Property](#)
[IFeatureManager::ShowFeatureName Property](#)
[IFeatureManager::ShowDisplayStateNames Property](#)

Availability

SOLIDWORKS 2007 SP3, Revision Number 15.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowComponentNames Property (IFeatureManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatureManager Interface](#) : ShowComponentNames Property (IFeatureManager)

Gets or sets whether to show the component configuration names in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

```
Property ShowComponentNames As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeatureManager  
Dim value As System.Boolean  
  
instance.ShowComponentNames = value  
  
value = instance.ShowComponentNames
```

C#

```
System.bool ShowComponentNames {get; set;}
```

C++/CLI

```
property System.bool ShowComponentNames {  
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True shows the component configuration names, false does not

Visual Basic for Applications (VBA) Syntax

See [FeatureManager::ShowComponentNames](#).

See Also

[IFeatureManager Interface](#)
[IFeatureManager Members](#)
[IFeatureManager::ShowComponentConfigurationDescriptions Property](#)
[IFeatureManager::ShowComponentConfigurationNames Property](#)
[IFeatureManager::ShowComponentDescriptions Property](#)
[IFeatureManager::ShowFeatureDescription Property](#)
[IFeatureManager::ShowFeatureName Property](#)
[IFeatureManager::ShowDisplayStateNames Property](#)

Availability

SOLIDWORKS 2007 SP3, Revision Number 15.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowDisplayStateNames Property (IFeatureManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatureManager Interface](#) : ShowDisplayStateNames Property (IFeatureManager)

Gets or sets whether to show the display state names in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

```
Property ShowDisplayStateNames As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeatureManager  
Dim value As System.Boolean  
  
instance.ShowDisplayStateNames = value  
  
value = instance.ShowDisplayStateNames
```

C#

```
System.bool ShowDisplayStateNames {get; set;}
```

C++/CLI

```
property System.bool ShowDisplayStateNames {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to show display state names, false to not

Visual Basic for Applications (VBA) Syntax

See [FeatureManager::ShowDisplayStateNames](#).

See Also

[IFeatureManager Interface](#)
[IFeatureManager Members](#)
[IFeatureManager::ShowComponentConfigurationDescriptions Property](#)
[IFeatureManager::ShowComponentConfigurationNames Property](#)
[IFeatureManager::ShowComponentDescriptions Property](#)
[IFeatureManager::ShowComponentNames Property](#)
[IFeatureManager::ShowFeatureDescription Property](#)
[IFeatureManager::ShowFeatureDetails Property](#)
[IFeatureManager::ShowFeatureName Property](#)
[IFeatureManager::ShowHierarchyOnly Property](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ShowFeatureDescription Property (IFeatureManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatureManager Interface](#) : ShowFeatureDescription Property (IFeatureManager)

Gets or sets whether to show the description of the feature in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

Property ShowFeatureDescription As System.Boolean

Visual Basic (Usage)



```
Dim instance As IFeatureManager
Dim value As System.Boolean

instance.ShowFeatureDescription = value

value = instance.ShowFeatureDescription
```

C#

```
System.bool ShowFeatureDescription {get; set;}
```

C++/CLI

```
property System.bool ShowFeatureDescription {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True shows the description of the feature, false does not

Visual Basic for Applications (VBA) Syntax

See [FeatureManager::ShowFeatureDescription](#).

See Also

[IFeatureManager Interface](#)
[IFeatureManager Members](#)
[IFeatureManager::ShowFeatureName Property](#)
[IFeatureManager::ShowComponentConfigurationDescriptions Property](#)
[IFeatureManager::ShowComponentConfigurationNames Property](#)
[IFeatureManager::ShowComponentDescriptions Property](#)
[IFeatureManager::ShowComponentNames Property](#)
[IFeature::Description Property](#)
[IFeatureManager::ShowDisplayStateNames Property](#)

Availability

ShowFeatureDetails Property (IFeatureManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatureManager Interface](#) : ShowFeatureDetails Property (IFeatureManager)

Gets or sets whether to show the feature details in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

Property ShowFeatureDetails As System.Boolean

Visual Basic (Usage)



```
Dim instance As IFeatureManager
Dim value As System.Boolean

instance.ShowFeatureDetails = value

value = instance.ShowFeatureDetails
```

C#

```
System.bool ShowFeatureDetails {get; set;}
```

C++/CLI

```
property System.bool ShowFeatureDetails {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to show the feature details in the FeatureManager design tree, false to hide them (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [FeatureManager::ShowFeatureDetails](#).

Example

[Get and Set FeatureManager Design Tree Display \(C#\)](#)
[Get and Set FeatureManager Design Tree Display \(VB.NET\)](#)
[Get and Set FeatureManager Design Tree Display \(VBA\)](#)

Remarks

Setting IFeatureManager::ShowFeatureDetails to true sets [IFeatureManager::ShowHierarchyOnly](#) to false, and vice versa.

This property affects the FeatureManager design tree view of the current configuration of an assembly. It does not affect other configurations.

See Also

[IFeatureManager Interface](#)
[IFeatureManager Members](#)
[IFeatureManager::ViewDependencies Property](#)
[IFeatureManager::ViewFeatures Property](#)
[IFeatureManager::ShowDisplayStateNames Property](#)

Availability

SOLIDWORKS 2010 SP5, Revision Number 18.5

ShowFeatureName Property (IFeatureManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatureManager Interface](#) : ShowFeatureName Property (IFeatureManager)

Gets or sets whether to show the name of the feature in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

Property ShowFeatureName As System.Boolean

Visual Basic (Usage)



```
Dim instance As IFeatureManager
Dim value As System.Boolean
```

```
instance.ShowFeatureName = value
```

```
value = instance.ShowFeatureName
```

C#

```
System.bool ShowFeatureName {get; set;}
```

C++/CLI

```
property System.bool ShowFeatureName {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True shows the name of the feature, false does not

Visual Basic for Applications (VBA) Syntax

See [FeatureManager::ShowFeatureName](#).

See Also

[IFeatureManager Interface](#)
[IFeatureManager Members](#)
[IFeatureManager::ShowFeatureDescription Property](#)
[IFeatureManager::ShowComponentConfigurationDescriptions Property](#)
[IFeatureManager::ShowComponentConfigurationNames Property](#)
[IFeatureManager::ShowComponentDescriptions Property](#)
[IFeatureManager::ShowComponentNames Property](#)
[IFeatureManager::FeatureName Property](#)
[IFeature::Name Property](#)
[IFeatureManager::ShowDisplayStateNames Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowHierarchyOnly Property (IFeatureManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatureManager Interface](#) : ShowHierarchyOnly Property (IFeatureManager)

Gets or sets whether to show only the hierarchy in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

Property ShowHierarchyOnly As System.Boolean

Visual Basic (Usage)



```
Dim instance As IFeatureManager
Dim value As System.Boolean

instance.ShowHierarchyOnly = value

value = instance.ShowHierarchyOnly
```

C#

```
System.bool ShowHierarchyOnly {get; set;}
```

C++/CLI

```
property System.bool ShowHierarchyOnly {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to only show the hierarchy in the FeatureManager design tree, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [FeatureManager::ShowHierarchyOnly](#).

Example

[Get and Set FeatureManager Design Tree Display \(C#\)](#)
[Get and Set FeatureManager Design Tree Display \(VB.NET\)](#)
[Get and Set FeatureManager Design Tree Display \(VBA\)](#)

Remarks

Setting IFeatureManager::ShowHierarchyOnly to true sets [IFeatureManager::ShowFeatureDetails](#) to false, and vice versa.

See Also

[IFeatureManager Interface](#)
[IFeatureManager Members](#)
[IFeatureManager::ViewDependencies Property](#)
[IFeatureManager::ViewFeatures Property](#)
[IFeatureManager::ShowDisplayStateNames Property](#)

Availability

SOLIDWORKS 2010 SP5, Revision Number 18.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

SimpleHole Method (IFeatureManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatureManager Interface](#) : SimpleHole Method (IFeatureManager)

Obsolete. Superseded by [IFeatureManager::SimpleHole2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SimpleHole( _
    ByVal Dia As System.Double, _
    ByVal Sd As System.Boolean, _
```

```

ByVal Flip As System.Boolean, _
ByVal Dir As System.Boolean, _
ByVal T1 As System.Integer, _
ByVal T2 As System.Integer, _
ByVal D1 As System.Double, _
ByVal D2 As System.Double, _
ByVal Dchk1 As System.Boolean, _
ByVal Dchk2 As System.Boolean, _
ByVal Ddir1 As System.Boolean, _
ByVal Ddir2 As System.Boolean, _
ByVal Dang1 As System.Double, _
ByVal Dang2 As System.Double, _
ByVal OffsetReverse1 As System.Boolean, _
ByVal OffsetReverse2 As System.Boolean, _
ByVal TranslateSurface1 As System.Boolean, _
ByVal TranslateSurface2 As System.Boolean, _
ByVal UseFeatScope As System.Boolean, _
ByVal UseAutoSelect As System.Boolean _
) As Feature

```

Visual Basic (Usage)



```

Dim instance As IFeatureManager
Dim Dia As System.Double
Dim Sd As System.Boolean
Dim Flip As System.Boolean
Dim Dir As System.Boolean
Dim T1 As System.Integer
Dim T2 As System.Integer
Dim D1 As System.Double
Dim D2 As System.Double
Dim Dchk1 As System.Boolean
Dim Dchk2 As System.Boolean
Dim Ddir1 As System.Boolean
Dim Ddir2 As System.Boolean
Dim Dang1 As System.Double
Dim Dang2 As System.Double
Dim OffsetReverse1 As System.Boolean
Dim OffsetReverse2 As System.Boolean
Dim TranslateSurface1 As System.Boolean
Dim TranslateSurface2 As System.Boolean
Dim UseFeatScope As System.Boolean
Dim UseAutoSelect As System.Boolean
Dim value As Feature

```

```

value = instance.SimpleHole(Dia, Sd, Flip, Dir, T1, T2, D1, D2, Dchk1, Dchk2, Ddir1, Ddir2, Dang1,
Dang2, OffsetReverse1, OffsetReverse2, TranslateSurface1, TranslateSurface2, UseFeatScope,
UseAutoSelect)

```

C#

```

Feature SimpleHole(
    System.double Dia,
    System.bool Sd,
    System.bool Flip,
    System.bool Dir,
    System.int T1,
    System.int T2,
    System.double D1,
    System.double D2,
    System.bool Dchk1,
    System.bool Dchk2,
    System.bool Ddir1,
    System.bool Ddir2,
    System.double Dang1,
    System.double Dang2,
    System.bool OffsetReverse1,
    System.bool OffsetReverse2,
    System.bool TranslateSurface1,

```

```

System.bool TranslateSurface2,
System.bool UseFeatScope,
System.bool UseAutoSelect
)

```

C++/CLI

```

Feature^ SimpleHole(
& System.double Dia,
& System.bool Sd,
& System.bool Flip,
& System.bool Dir,
& System.int T1,
& System.int T2,
& System.double D1,
& System.double D2,
& System.bool Dchk1,
& System.bool Dchk2,
& System.bool Ddir1,
& System.bool Ddir2,
& System.double Dang1,
& System.double Dang2,
& System.bool OffsetReverse1,
& System.bool OffsetReverse2,
& System.bool TranslateSurface1,
& System.bool TranslateSurface2,
& System.bool UseFeatScope,
& System.bool UseAutoSelect
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Dia

Hole diameter

Sd

True for single-ended, false for double-ended

Flip

True to flip the direction to cut, false to not

Dir

True to flip direction to extrude, false to not

T1

Termination type for first end as defined in [swEndConditions_e](#)

T2

Termination type for second end as defined in [swEndConditions_e](#)

D1

Depth of extrusion for first end in meters

D2

Depth of extrusion for second end in meters

Dchk1

True allows draft angle in first direction, false does not allow drafting

Dchk2

True allows draft angle in second direction, false does not allow drafting

Ddir1

For first draft angle to be inward use true, for draft angle outward use false

Ddir2

For second draft angle to be inward use true, for draft angle outward use false

Dang1

Draft angle for first end

Dang2

Draft angle for second end

OffsetReverse1

If you chose to offset the first end condition from another face or plane, then true specifies offset in direction away from the sketch, false specifies offset from the face or plane in a direction

toward the sketch

OffsetReverse2

If you chose to offset the second end condition from another face or plane, then true specifies offset in direction away from the sketch, false specifies offset from the face or plane in a direction toward the sketch

TranslateSurface1

True to use an offset relative to the surface or the plane selected, false to use a true offset

TranslateSurface2

True to use an offset relative to the surface or the plane selected, false to use a true offset

UseFeatScope

True if the feature only affects selected bodies, false if the feature affects all bodies

UseAutoSelect

True to automatically select all bodies and have the feature affect those bodies, false to select the bodies the feature affects

Return Value

Pointer to the [IFeature](#) object

See [FeatureManager::SimpleHole](#).

See Also

[IFeatureManager Interface](#)
[IFeatureManager Members](#)
[ISimpleHoleFeatureData2 Interface](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SimpleHole2 Method (IFeatureManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatureManager Interface](#) : SimpleHole2 Method (IFeatureManager)

Inserts a simple hole feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SimpleHole2( _  
    ByVal Dia As System.Double, _  
    ByVal Sd As System.Boolean, _  
    ByVal Flip As System.Boolean, _  
    ByVal Dir As System.Boolean, _  
    ByVal T1 As System.Integer, _  
    ByVal T2 As System.Integer, _  
    ByVal D1 As System.Double, _  
    ByVal D2 As System.Double, _  
    ByVal Dchk1 As System.Boolean, _  
    ByVal Dchk2 As System.Boolean, _  
    ByVal Ddir1 As System.Boolean, _  
    ByVal Ddir2 As System.Boolean, _  
    ByVal Dang1 As System.Double, _  
    ByVal Dang2 As System.Double, _  
    ByVal OffsetReverse1 As System.Boolean, _  
    ByVal OffsetReverse2 As System.Boolean, _  
    ByVal TranslateSurface1 As System.Boolean, _  
    ByVal TranslateSurface2 As System.Boolean, _  
    ByVal UseFeatScope As System.Boolean, _  
    ByVal UseAutoSelect As System.Boolean, _  
    ByVal AssemblyFeatureScope As System.Boolean, _  
    ByVal AutoSelectComponents As System.Boolean, _  
    ByVal PropagateFeatureToParts As System.Boolean _  
) As Feature
```

Visual Basic (Usage)



```
Dim instance As IFeatureManager  
Dim Dia As System.Double  
Dim Sd As System.Boolean  
Dim Flip As System.Boolean  
Dim Dir As System.Boolean  
Dim T1 As System.Integer  
Dim T2 As System.Integer  
Dim D1 As System.Double  
Dim D2 As System.Double  
Dim Dchk1 As System.Boolean  
Dim Dchk2 As System.Boolean  
Dim Ddir1 As System.Boolean  
Dim Ddir2 As System.Boolean  
Dim Dang1 As System.Double  
Dim Dang2 As System.Double  
Dim OffsetReverse1 As System.Boolean  
Dim OffsetReverse2 As System.Boolean
```

```

Dim TranslateSurface1 As System.Boolean
Dim TranslateSurface2 As System.Boolean
Dim UseFeatScope As System.Boolean
Dim UseAutoSelect As System.Boolean
Dim AssemblyFeatureScope As System.Boolean
Dim AutoSelectComponents As System.Boolean
Dim PropagateFeatureToParts As System.Boolean
Dim value As Feature

```

```

value = instance.SimpleHole2(Dia, Sd, Flip, Dir, T1, T2, D1, D2, Dchk1, Dchk2, Ddir1, Ddir2,
Dang1, Dang2, OffsetReverse1, OffsetReverse2, TranslateSurface1, TranslateSurface2, UseFeatScope,
UseAutoSelect, AssemblyFeatureScope, AutoSelectComponents, PropagateFeatureToParts)

```

C#

```

Feature SimpleHole2(
    System.double Dia,
    System.bool Sd,
    System.bool Flip,
    System.bool Dir,
    System.int T1,
    System.int T2,
    System.double D1,
    System.double D2,
    System.bool Dchk1,
    System.bool Dchk2,
    System.bool Ddir1,
    System.bool Ddir2,
    System.double Dang1,
    System.double Dang2,
    System.bool OffsetReverse1,
    System.bool OffsetReverse2,
    System.bool TranslateSurface1,
    System.bool TranslateSurface2,
    System.bool UseFeatScope,
    System.bool UseAutoSelect,
    System.bool AssemblyFeatureScope,
    System.bool AutoSelectComponents,
    System.bool PropagateFeatureToParts
)

```

C++/CLI

```

Feature^ SimpleHole2(
& System.double Dia,
& System.bool Sd,
& System.bool Flip,
& System.bool Dir,
& System.int T1,
& System.int T2,
& System.double D1,
& System.double D2,
& System.bool Dchk1,
& System.bool Dchk2,
& System.bool Ddir1,
& System.bool Ddir2,
& System.double Dang1,
& System.double Dang2,
& System.bool OffsetReverse1,
& System.bool OffsetReverse2,
& System.bool TranslateSurface1,
& System.bool TranslateSurface2,
& System.bool UseFeatScope,
& System.bool UseAutoSelect,
& System.bool AssemblyFeatureScope,
& System.bool AutoSelectComponents,
& System.bool PropagateFeatureToParts
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Dia

Hole diameter

Sd

True for single-ended, false for double-ended

Flip

True to flip the direction to cut, false to not

Dir

True to flip direction to extrude, false to not

T1

Termination type for first end as defined in [swEndConditions_e](#)

T2

Termination type for second end as defined in [swEndConditions_e](#)

D1

Depth of extrusion for first end in meters

D2

Depth of extrusion for second end in meters

Dchk1

True allows draft angle in first direction, false does not allow drafting

Dchk2

True allows draft angle in second direction, false does not allow drafting

Ddir1

For first draft angle to be inward use true, for draft angle outward use false

Ddir2

For second draft angle to be inward use true, for draft angle outward use false

Dang1

Draft angle for first end

Dang2

Draft angle for second end

OffsetReverse1

If you chose to offset the first end condition from another face or plane, then true specifies offset in direction away from the sketch, false specifies offset from the face or plane in a direction toward the sketch

OffsetReverse2

If you chose to offset the second end condition from another face or plane, then true specifies offset in direction away from the sketch, false specifies offset from the face or plane in a direction toward the sketch

TranslateSurface1

True to use an offset relative to the surface or the plane selected, false to use a true offset

TranslateSurface2

True to use an offset relative to the surface or the plane selected, false to use a true offset

UseFeatScope

True if the feature only affects selected bodies, false if the feature affects all bodies

UseAutoSelect

True to automatically select all bodies and have the feature affect those bodies, false to select the bodies the feature affects

AssemblyFeatureScope

True if the assembly feature only affects selected components in the assembly, false if the assembly feature affects all components in the assembly

AutoSelectComponents

True to auto-select all affected components, false to not (use the selected components only)

PropagateFeatureToParts

True to propagate the assembly feature to the components in the model that it affects, false to not

Return Value

[Feature](#)

Visual Basic for Applications (VBA) Syntax

See [FeatureManager::SimpleHole2](#).

Example

[Insert Sketch Text and Hole \(VBA\)](#)

[Insert Sketch Text and Hole \(VB.NET\)](#)

[Insert Sketch Text and Hole \(C#\)](#)

See Also

[IFeatureManager Interface](#)

[IFeatureManager Members](#)

[ISimpleHoleFeatureData2 Interface](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SolidForTrim Property (IFeatureManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatureManager Interface](#) : SolidForTrim Property (IFeatureManager)

Gets or sets whether a [surface trim feature](#) is a solid body or a surface body.

.NET Syntax

```
Property SolidForTrim As System.Boolean
```



```
Dim instance As IFeatureManager
Dim value As System.Boolean

instance.SolidForTrim = value

value = instance.SolidForTrim
```

```
System.bool SolidForTrim {get; set;}
```

```
property System.bool SolidForTrim {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if a solid body, false if a surface body (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [FeatureManager::SolidForTrim](#).

Example

[Create Solid Body Surface Trim Feature \(C#\)](#)
[Create Solid Body Surface Trim Feature \(VB.NET\)](#)
[Create Solid Body Surface Trim Feature \(VBA\)](#)

Remarks

This property is only available when creating a surface trim feature. Call this property:

- after calling [IFeatureManager::PreTrimSurface](#)
- before calling [IFeatureManager::PostTrimSurface](#).

See Also

[IFeatureManager Interface](#)
[IFeatureManager Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

UpdateFeatureTree Method (IFeatureManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatureManager Interface](#) : UpdateFeatureTree Method (IFeatureManager)

Updates the FeatureManager design tree.

.NET Syntax

```
Sub UpdateFeatureTree()
```



```
Dim instance As IFeatureManager
```

```
instance.UpdateFeatureTree()
```

C#

```
void UpdateFeatureTree()
```

C++/CLI

```
void UpdateFeatureTree();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [FeatureManager::UpdateFeatureTree](#).

Example

[Turn Lights On \(VBA\)](#)
[Update FeatureManager Design Tree \(VBA\)](#)
[Get Comments in Comments Folder \(C#\)](#)
[Get Comments in Comments Folder \(VB.NET\)](#)
[Get Comments in Comments Folder \(VBA\)](#)

See Also

[IFeatureManager Interface](#)
[IFeatureManager Members](#)
[IFeatureManager::EnableFeatureTree Property](#)
[IFeatureManager::EnableFeatureTreeWindow Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ViewDependencies Property (IFeatureManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatureManager Interface](#) : ViewDependencies Property (IFeatureManager)

Gets or sets whether to view the FeatureManager design tree by its dependencies.

.NET Syntax

Visual Basic (Declaration)

```
Property ViewDependencies As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeatureManager
```

```
Dim value As System.Boolean
```

```
instance.ViewDependencies = value
```

```
value = instance.ViewDependencies
```

C#

```
System.bool ViewDependencies {get; set;}
```

C++/CLI

```
property System.bool ViewDependencies {  
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to view the FeatureManager design tree by its dependencies, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [FeatureManager::ViewDependencies](#).

Example

[Get and Set FeatureManager Design Tree Display \(C#\)](#)
[Get and Set FeatureManager Design Tree Display \(VB.NET\)](#)
[Get and Set FeatureManager Design Tree Display \(VBA\)](#)

Remarks

Setting IFeatureManager::ViewDependencies to true sets [IFeatureManager::ViewFeatures](#) to false, and vice versa.

See Also

[IFeatureManager Interface](#)
[IFeatureManager Members](#)
[IFeatureManager::ShowFeatureDetails Property](#)
[IFeatureManager::ShowHierarchyOnly Property](#)

Availability

SOLIDWORKS 2010 SP5, Revision Number 18.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

ViewFeatures Property (IFeatureManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatureManager Interface](#) : ViewFeatures Property (IFeatureManager)

Gets or sets whether to view the FeatureManager design tree by its features.

.NET Syntax

Visual Basic (Declaration)

Property ViewFeatures As System.Boolean

Visual Basic (Usage)



```
Dim instance As IFeatureManager  
Dim value As System.Boolean
```

```
instance.ViewFeatures = value
```

```
value = instance.ViewFeatures
```

C#

```
System.bool ViewFeatures {get; set;}
```

C++/CLI

```
property System.bool ViewFeatures {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to view the FeatureManager design tree by its features, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [FeatureManager::ViewFeatures](#).

Example

[Get and Set FeatureManager Design Tree Display \(C#\)](#)
[Get and Set FeatureManager Design Tree Display \(VB.NET\)](#)
[Get and Set FeatureManager Design Tree Display \(VBA\)](#)

Remarks

Setting IFeatureManager::ViewFeatures to true sets [IFeatureManager::ViewDependencies](#) to false, and vice versa.

See Also

[IFeatureManager Interface](#)
[IFeatureManager Members](#)
[IFeatureManager::ShowFeatureDetails Property](#)
[IFeatureManager::ShowHierarchyOnly Property](#)

Availability

SOLIDWORKS 2010 SP5, Revision Number 18.5