

SOLIDWORKS API (.NET VBA C#) — Reference

(124/337): IFillSurfaceFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IFillSurfaceFeatureData (Type)

IFillSurfaceFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFillSurfaceFeatureData Interface

Allows access to a fill-surface feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IFillSurfaceFeatureData
```

Visual Basic (Usage)



```
Dim instance As IFillSurfaceFeatureData
```

C#

```
public interface IFillSurfaceFeatureData
```

C++/CLI

```
public interface class IFillSurfaceFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [FillSurfaceFeatureData](#).

Example

[Insert Fill-surface Feature \(C#\)](#)
[Insert Fill-surface Feature \(VB.NET\)](#)
[Insert Fill-surface Feature \(VBA\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[FillSurfaceFeatureData](#)

See Also

[IFillSurfaceFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertFillSurface2 Method](#)

IFillSurfaceFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFillSurfaceFeatureData Interface

For a list of all members of this type, see [IFillSurfaceFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this fill-surface feature.
 GetAlternateFace	Gets an alternate face to use as the boundary face for the curvature control of the patch.

	GetConstraintCurves	Gets the constraint curves for this fill-surface feature.
	GetConstraintCurvesCount	Gets the number of entities used to create the constraint curves for this fill-surface feature.
	GetCurvatureControl	Gets the contact type for the input boundary.
	GetPatchBoundary	Gets the entities used to define the patch boundary for this fill-surface feature.
	GetPatchBoundaryCount	Gets the number of entities used to define the patch boundary for this fill-surface feature.
	IAccessSelections	Gains access to the selections that define this fill-surface feature.
	IGetConstraintCurves	Gets the constraint curves for this fill-surface feature.
	IGetPatchBoundary	Gets the entities used to define the patch boundary for this fill-surface feature.
	ISetConstraintCurves	Sets the entities for the constraint curves.
	ISetPatchBoundary	Sets the patch boundary for this fill-surface feature.
	ReleaseSelectionAccess	Releases access to selections that define this fill-surface feature.
	SetConstraintCurves	Sets the entities for the constraint curves.
	SetCurvatureControl	Sets the contact type for this fill-surface feature.
	SetPatchBoundary	Sets the patch boundary for this fill-surface feature.
	ToggleAlternateFace	Switches the boundary face of the curvature control of the patch.

[Top](#)

See Also

[IFillSurfaceFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertFillSurface2 Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IFillSurfaceFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFillSurfaceFeatureData Interface

The following tables list the members exposed by [IFillSurfaceFeatureData](#).

Public Properties

Name	Description
 Merge	Gets or sets whether or not to merge results.
 OptimizeSurface	Gets or sets whether or not to optimize the patch.
 ResolutionControl	Gets and sets the quality of the resolution of the fill-surface feature.
 ReverseDirection	Gets or sets whether or not to reverse direction while merging results.
 ReverseSurface	Gets or sets direction of the surface patch.
 TryToFormSolid	Gets or sets whether to form a solid.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this fill-surface feature.
 GetAlternateFace	Gets an alternate face to use as the boundary face for the curvature control of the patch.
 GetConstraintCurves	Gets the constraint curves for this fill-surface feature.
 GetConstraintCurvesCount	Gets the number of entities used to create the constraint curves for this fill-surface feature.
 GetCurvatureControl	Gets the contact type for the input boundary.
 GetPatchBoundary	Gets the entities used to define the patch boundary for this fill-surface feature.
 GetPatchBoundaryCount	Gets the number of entities used to define the patch boundary for this fill-surface feature.

		
	IAccessSelections	Gains access to the selections that define this fill-surface feature.
	IGetConstraintCurves	Gets the constraint curves for this fill-surface feature.
	IGetPatchBoundary	Gets the entities used to define the patch boundary for this fill-surface feature.
	ISetConstraintCurves	Sets the entities for the constraint curves.
	ISetPatchBoundary	Sets the patch boundary for this fill-surface feature.
	ReleaseSelectionAccess	Releases access to selections that define this fill-surface feature.
	SetConstraintCurves	Sets the entities for the constraint curves.
	SetCurvatureControl	Sets the contact type for this fill-surface feature.
	SetPatchBoundary	Sets the patch boundary for this fill-surface feature.
	ToggleAlternateFace	Switches the boundary face of the curvature control of the patch.

[Top](#)

See Also

[IFillSurfaceFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertFillSurface2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IFillSurfaceFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IFillSurfaceFeatureData Interface

For a list of all members of this type, see [IFillSurfaceFeatureData members](#).

Public Properties

Name	Description
 Merge	Gets or sets whether or not to merge results.
 OptimizeSurface	Gets or sets whether or not to optimize the patch.
 ResolutionControl	Gets and sets the quality of the resolution of the fill-surface feature.
 ReverseDirection	Gets or sets whether or not to reverse direction while merging results.
 ReverseSurface	Gets or sets direction of the surface patch.
 TryToFormSolid	Gets or sets whether to form a solid.

[Top](#)

See Also

[IFillSurfaceFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertFillSurface2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IFillSurfaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFillSurfaceFeatureData Interface](#) : AccessSelections Method (IFillSurfaceFeatureData)

Gains access to the selections that define this fill-surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFillSurfaceFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document (see **Remarks**)
Component
Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections are successfully accessed, false if not

 Visual Basic for Applications (VBA) Syntax

See [FillSurfaceFeatureData::AccessSelections](#).

 Example

[Insert Fill-surface Feature \(C#\)](#)
[Insert Fill-surface Feature \(VB.NET\)](#)
[Insert Fill-surface Feature \(VBA\)](#)

 Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IFillSurfaceFeatureData::ReleaseSelectionAccess](#) if you did not

 See Also

[IFillSurfaceFeatureData Interface](#)
[IFillSurfaceFeatureData Members](#)
[IFillSurfaceFeatureData::IAccessSelections Method](#)

 Availability

GetAlternateFace Method (IFillSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFillSurfaceFeatureData Interface](#) : GetAlternateFace Method (IFillSurfaceFeatureData)

Gets an alternate face to use as the boundary face for the curvature control of the patch.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAlternateFace() As Face2
```

Visual Basic (Usage)



```
Dim instance As IFillSurfaceFeatureData  
Dim value As Face2
```

```
value = instance.GetAlternateFace()
```

C#

```
Face2 GetAlternateFace()
```

C++/CLI

```
Face2^ GetAlternateFace();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the alternate face, the [IFace2](#) object

Visual Basic for Applications (VBA) Syntax

See [FillSurfaceFeatureData::GetAlternateFace](#).

Remarks

This method is valid only when the contact type is tangent and edges are used to define the patch boundary. If an edge has two faces, then this method returns the face with which the resultant feature geometry is tangent.

Use [IFillSurfaceFeatureData::GetCurvatureControl](#) to determine the contact type.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IFillSurfaceFeatureData Interface](#)
[IFillSurfaceFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

GetConstraintCurves Method (IFillSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFillSurfaceFeatureData Interface](#) : GetConstraintCurves Method (IFillSurfaceFeatureData)

Gets the constraint curves for this fill-surface feature.

.NET Syntax

```
Function GetConstraintCurves( _
    ByRef TypeArr As System.Object _
) As System.Object
```



```
Dim instance As IFillSurfaceFeatureData
Dim TypeArr As System.Object
Dim value As System.Object

value = instance.GetConstraintCurves(TypeArr)
```

```
System.object GetConstraintCurves(
    out System.object TypeArr
)
```

```
System.Object^ GetConstraintCurves(
    & [Out] System.Object^ TypeArr
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TypeArr

Array of types of entities used to constrain the surface as defined by [swSelectType_e](#); valid entities are:

- edges (swSelEDGES)
- sketches (swSelSKETCHES)

Return Value

Array of entities used as constraint curves

Visual Basic for Applications (VBA) Syntax

See [FillSurfaceFeatureData::GetConstraintCurves](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IFillSurfaceFeatureData Interface](#)
[IFillSurfaceFeatureData Members](#)
[IFillSurfaceFeatureData::IGetConstraintCurves Method](#)
[IFillSurfaceFeatureData::GetConstraintCurvesCount Method](#)
[IFillSurfaceFeatureData::SetConstraintCurves Method](#)
[IFillSurfaceFeatureData::ISetConstraintCurves Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

GetConstraintCurvesCount Method (IFillSurfaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFillSurfaceFeatureData Interface](#) : GetConstraintCurvesCount Method (IFillSurfaceFeatureData)

Gets the number of entities used to create the constraint curves for this fill-surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetConstraintCurvesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFillSurfaceFeatureData  
Dim value As System.Integer  
  
value = instance.GetConstraintCurvesCount()
```

C#

```
System.int GetConstraintCurvesCount()
```

C++/CLI

```
System.int GetConstraintCurvesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of entities

Visual Basic for Applications (VBA) Syntax

See [FillSurfaceFeatureData::GetConstraintCurvesCount](#).

Example

[Insert Fill-surface Feature \(C#\)](#)
[Insert Fill-surface Feature \(VB.NET\)](#)
[Insert Fill-surface Feature \(VBA\)](#)

Remarks

Call this method before calling [IFillSurfaceFeatureData::IGetConstraintCurves](#).

See Also

[IFillSurfaceFeatureData Interface](#)
[IFillSurfaceFeatureData Members](#)
[IFillSurfaceFeatureData::GetConstraintCurves Method](#)
[IFillSurfaceFeatureData::ISetConstraintCurves Method](#)
[IFillSurfaceFeatureData::SetConstraintCurves Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCurvatureControl Method (IFillSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFillSurfaceFeatureData Interface](#) : GetCurvatureControl Method (IFillSurfaceFeatureData)

Gets the contact type for the input boundary.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCurvatureControl( _  
    ByVal EntityIn As System.Object _  
) As System.Integer
```

Visual Basic (Usage)




```
Dim instance As IFillSurfaceFeatureData
Dim EntityIn As System.Object
Dim value As System.Integer

value = instance.GetCurvatureControl(EntityIn)
```

C#

```
System.int GetCurvatureControl(
    System.object EntityIn
)
```

C++/CLI

```
System.int GetCurvatureControl(
    & System.Object^ EntityIn
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EntityIn

Edge or sketch boundary returned from [IFillSurfaceFeatureData::GetPatchBoundary](#).

Return Value

Control type as defined in [swContactType_e](#)

Visual Basic for Applications (VBA) Syntax

See [FillSurfaceFeatureData::GetCurvatureControl](#).

Remarks

Sketch boundaries always return a control type of swContact.
See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IFillSurfaceFeatureData Interface](#)
[IFillSurfaceFeatureData Members](#)
[IFillSurfaceFeatureData::GetAlternateFace Method](#)
[IFillSurfaceFeatureData::GetPatchBoundaryCount Method](#)
[IFillSurfaceFeatureData::IGetPatchBoundary Method](#)
[IFillSurfaceFeatureData::ISetPatchBoundary Method](#)
[IFillSurfaceFeatureData::SetCurvatureControl Method](#)
[IFillSurfaceFeatureData::SetPatchBoundary Method](#)
[IFillSurfaceFeatureData::ToggleAlternateFace Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPatchBoundary Method (IFillSurfaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFillSurfaceFeatureData Interface](#) : GetPatchBoundary Method (IFillSurfaceFeatureData)

Gets the entities used to define the patch boundary for this fill-surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPatchBoundary( _
    ByRef EntType As System.Object _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFillSurfaceFeatureData
Dim EntType As System.Object
Dim value As System.Object

value = instance.GetPatchBoundary(EntType)
```

C#

```
System.object GetPatchBoundary(
    out System.object EntType
)
```

C++/CLI

```
System.Object^ GetPatchBoundary(
    & [Out] System.Object^ EntType
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EntType

Array of types of entities used to define the patch boundary as defined by [swSelectType_e](#):

- Edges (swSelEDGES)
- Sketches (swSelSKETCHES)

Return Value

Array of entities used to define the patch boundary

Visual Basic for Applications (VBA) Syntax

See [FillSurfaceFeatureData::GetPatchBoundary](#).

Example

[Insert Fill-surface Feature \(C#\)](#)
[Insert Fill-surface Feature \(VB.NET\)](#)
[Insert Fill-surface Feature \(VBA\)](#)

Remarks

[IFillSurfaceFeatureData::GetCurvatureControl](#) uses the return value as input, so call IFillSurfaceFeatureData::GetPatchBoundary before calling IFillSurfaceFeatureData::GetCurvatureControl.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IFillSurfaceFeatureData Interface](#)
[IFillSurfaceFeatureData Members](#)
[IFillSurfaceFeatureData::GetAlternateFace Method](#)
[IFillSurfaceFeatureData::GetCurvatureControl Method](#)
[IFillSurfaceFeatureData::GetPatchBoundaryCount Method](#)
[IFillSurfaceFeatureData::IGetPatchBoundary Method](#)
[IFillSurfaceFeatureData::ISetPatchBoundary Method](#)
[IFillSurfaceFeatureData::SetCurvatureControl Method](#)
[IFillSurfaceFeatureData::SetPatchBoundary Method](#)
[IFillSurfaceFeatureData::ToggleAlternateFace Method](#)
[IFillSurfaceFeatureData::TryToFormSolid Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPatchBoundaryCount Method (IFillSurfaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFillSurfaceFeatureData Interface](#) : GetPatchBoundaryCount Method (IFillSurfaceFeatureData)

Gets the number of entities used to define the patch boundary for this fill-surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPatchBoundaryCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFillSurfaceFeatureData  
Dim value As System.Integer  
  
value = instance.GetPatchBoundaryCount()
```

C#

```
System.int GetPatchBoundaryCount()
```

C++/CLI

```
System.int GetPatchBoundaryCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of entities used to define the patch boundary

Visual Basic for Applications (VBA) Syntax

See [FillSurfaceFeatureData::GetPatchBoundaryCount](#).

Example

[Insert Fill-surface Feature \(C#\)](#)
[Insert Fill-surface Feature \(VBA\)](#)
[Insert Fill-surface Feature \(VB.NET\)](#)

Remarks

Call this method before calling [IFillSurfaceFeatureData::IGetPatchBoundary](#).

See Also

[IFillSurfaceFeatureData Interface](#)
[IFillSurfaceFeatureData Members](#)
[IFillSurfaceFeatureData::GetAlternateFace Method](#)
[IFillSurfaceFeatureData::GetCurvatureControl Method](#)
[IFillSurfaceFeatureData::GetPatchBoundary Method](#)
[IFillSurfaceFeatureData::ISetPatchBoundary Method](#)
[IFillSurfaceFeatureData::SetCurvatureControl Method](#)
[IFillSurfaceFeatureData::SetPatchBoundary Method](#)
[IFillSurfaceFeatureData::ToggleAlternateFace Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (IFillSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFillSurfaceFeatureData Interface](#) : IAccessSelections Method (IFillSurfaceFeatureData)

Gains access to the selections that define this fill-surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections(  
    ByVal TopDoc As ModelDoc2, _
```

```
ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFillSurfaceFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document (see **Remarks**)
Component
Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [FillSurfaceFeatureData::IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::IModifyDefinition2](#) if you modified the feature
- [IFillSurfaceFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IFillSurfaceFeatureData Interface](#)
[IFillSurfaceFeatureData Members](#)
[IFillSurfaceFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetConstraintCurves Method (IFillSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFillSurfaceFeatureData Interface](#) : IGetConstraintCurves Method (IFillSurfaceFeatureData)

Gets the constraint curves for this fill-surface feature.

Visual Basic (Declaration)

```
Function IGetConstraintCurves( _
    ByVal Count As System.Integer, _
    ByRef TypeArr As System.Integer _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFillSurfaceFeatureData
Dim Count As System.Integer
Dim TypeArr As System.Integer
Dim value As System.Object

value = instance.IGetConstraintCurves(Count, TypeArr)
```

C#

```
System.object IGetConstraintCurves(
    System.int Count,
    out System.int TypeArr
)
```

C++/CLI

```
System.Object^ IGetConstraintCurves(
    & System.int Count,
    & [Out] System.int TypeArr
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of entities used to constrain the surface

TypeArr

- in-process, unmanaged C++: Pointer to an array of types of entities used to constrain the surface as defined by [swSelectType_e](#); valid entities are:
 - edges (swSelEDGES)
 - sketches (swSelSKETCHES)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

- in-process, unmanaged C++: Pointer to an array of entities used as constraint curves
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [IFillSurfaceFeatureData::GetConstraintCurvesCount](#) before calling this method.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IFillSurfaceFeatureData Interface](#)
[IFillSurfaceFeatureData Members](#)
[IFillSurfaceFeatureData::GetConstraintCurves Method](#)
[IFillSurfaceFeatureData::ISetConstraintCurves Method](#)
[IFillSurfaceFeatureData::SetConstraintCurves Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFillSurfaceFeatureData Interface](#) : IGetPatchBoundary Method (IFillSurfaceFeatureData)

Gets the entities used to define the patch boundary for this fill-surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetPatchBoundary( _  
    ByVal Count As System.Integer, _  
    ByRef EntType As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFillSurfaceFeatureData  
Dim Count As System.Integer  
Dim EntType As System.Integer  
Dim value As System.Object  
  
value = instance.IGetPatchBoundary(Count, EntType)
```

C#

```
System.object IGetPatchBoundary(  
    System.int Count,  
    out System.int EntType  
)
```

C++/CLI

```
System.Object^ IGetPatchBoundary(  
& System.int Count,  
& [Out] System.int EntType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of entities used to define the patch boundary

EntType

- in-process, unmanaged C++: Pointer to an array of types of entities used to define the patch boundary as defined by [swSelectType_e](#):
 - edges (swSelEDGES)
 - sketches (swSelSKETCHES)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

- in-process, unmanaged C++: Pointer to an array of entities used to define the patch boundary of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported

Remarks

Call [IFillSurfaceFeatureData::GetPatchBoundaryCount](#) before calling this method.

[IFillSurfaceFeatureData::GetCurvatureControl](#) uses the return value as input, so call IFillSurfaceFeatureData::IGetPatchBoundary before calling IFillSurfaceFeatureData::GetCurvatureControl.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IFillSurfaceFeatureData Interface](#)
[IFillSurfaceFeatureData Members](#)
[IFillSurfaceFeatureData::GetAlternateFace Method](#)
[IFillSurfaceFeatureData::GetPatchBoundary Method](#)
[IFillSurfaceFeatureData::ISetPatchBoundary Method](#)
[IFillSurfaceFeatureData::SetPatchBoundary Method](#)
[IFillSurfaceFeatureData::ToggleAlternateFace Method](#)
[IFillSurfaceFeatureData::TryToFormSolid Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetConstraintCurves Method (IFillSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFillSurfaceFeatureData Interface](#) : ISetConstraintCurves Method (IFillSurfaceFeatureData)

Sets the entities for the constraint curves.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub ISetConstraintCurves( _  
    ByVal Count As System.Integer, _  
    ByRef DispArr As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IFillSurfaceFeatureData  
Dim Count As System.Integer  
Dim DispArr As System.Object  
  
instance.ISetConstraintCurves(Count, DispArr)
```

C#

```
void ISetConstraintCurves(  
    System.int Count,  
    ref System.object DispArr  
)
```

C++/CLI

```
void ISetConstraintCurves(  
& System.int Count,  
& System.Object^% DispArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of entities to use to constrain the surface

DispArr

- in-process, unmanaged C++: Pointer to an array of entities to use to constrain the surface; valid entities are:
 - [edges](#)
 - [sketches](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IFillSurfaceFeatureData Interface](#)

[IFillSurfaceFeatureData Members](#)

[IFillSurfaceFeatureData::GetConstraintCurves Method](#)

[IFillSurfaceFeatureData::GetConstraintCurvesCount Method](#)

[IFillSurfaceFeatureData::SetConstraintCurves Method](#)

Availability

ISetPatchBoundary Method (IFillSurfaceFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IFillSurfaceFeatureData Interface](#) : ISetPatchBoundary Method (IFillSurfaceFeatureData)

Sets the patch boundary for this fill-surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function ISetPatchBoundary( _
    ByVal Count As System.Integer, _
    ByRef DispArr As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFillSurfaceFeatureData
Dim Count As System.Integer
Dim DispArr As System.Object
Dim value As System.Boolean

value = instance.ISetPatchBoundary(Count, DispArr)
```

C#

```
System.bool ISetPatchBoundary(
    System.int Count,
    ref System.object DispArr
)
```

C++/CLI

```
System.bool ISetPatchBoundary(
    & System.int Count,
    & System.Object^% DispArr
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of entities to use for the patch boundary

DispArr

- in-process, unmanaged C++: Pointer to an array of entities to use as the patch boundary of size count; valid entities are:
 - [edges](#)
 - [sketches](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

True if the patch boundary is set, false if not

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IFillSurfaceFeatureData Interface](#)
[IFillSurfaceFeatureData Members](#)
[IFillSurfaceFeatureData::GetAlternateFace Method](#)
[IFillSurfaceFeatureData::GetCurvatureControl Method](#)
[IFillSurfaceFeatureData::GetPatchBoundary Method](#)
[IFillSurfaceFeatureData::GetPatchBoundaryCount Method](#)
[IFillSurfaceFeatureData::IGetPatchBoundary Method](#)
[IFillSurfaceFeatureData::SetCurvatureControl Method](#)
[IFillSurfaceFeatureData::SetPatchBoundary Method](#)

[IFillSurfaceFeatureData::ToggleAlternateFace Method](#)
[IFillSurfaceFeatureData::TryToFormSolid Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Merge Property (IFillSurfaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFillSurfaceFeatureData Interface](#) : Merge Property (IFillSurfaceFeatureData)

Gets or sets whether or not to merge results.

.NET Syntax

Visual Basic (Declaration)

Property Merge As System.Boolean

Visual Basic (Usage)



```
Dim instance As IFillSurfaceFeatureData  
Dim value As System.Boolean
```

```
instance.Merge = value
```

```
value = instance.Merge
```

C#

```
System.bool Merge {get; set;}
```

C++/CLI

```
property System.bool Merge {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True for merged results, false for non-merged results

Visual Basic for Applications (VBA) Syntax

See [FillSurfaceFeatureData::Merge](#).

Example

[Insert Fill-surface Feature \(C#\)](#)
[Insert Fill-surface Feature \(VB.NET\)](#)
[Insert Fill-surface Feature \(VBA\)](#)

Remarks

If the fill surface displays in an unwanted direction while merging results, use [IFillSurfaceFeatureData::ReverseDirection](#) to reverse the direction of the fill surface.

See Also

[IFillSurfaceFeatureData Interface](#)
[IFillSurfaceFeatureData Members](#)
[IFillSurfaceFeatureData::TryToFormSolid Property](#)

Availability

OptimizeSurface Property (IFillSurfaceFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFillSurfaceFeatureData Interface](#) : OptimizeSurface Property (IFillSurfaceFeatureData)

Gets or sets whether or not to optimize the patch.

.NET Syntax

Visual Basic (Declaration)

Property OptimizeSurface As System.Boolean

Visual Basic (Usage)



```
Dim instance As IFillSurfaceFeatureData  
Dim value As System.Boolean
```

```
instance.OptimizeSurface = value
```

```
value = instance.OptimizeSurface
```

C#

```
System.bool OptimizeSurface {get; set;}
```

C++/CLI

```
property System.bool OptimizeSurface {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True for optimized patch, false for non-optimized patch

Visual Basic for Applications (VBA) Syntax

See [FillSurfaceFeatureData::OptimizeSurface](#).

Example

[Insert Fill-surface Feature \(C#\)](#)
[Insert Fill-surface Feature \(VB.NET\)](#)
[Insert Fill-surface Feature \(VBA\)](#)

Remarks

You can only adjust the quality of the resolution of a patch when the patch is not optimized. See [IFillSurfaceFeatureData::ResolutionControl](#) for details.

See Also

[IFillSurfaceFeatureData Interface](#)
[IFillSurfaceFeatureData Members](#)

Availability

ReleaseSelectionAccess Method (IFillSurfaceFeatureData)

[See Also](#)



Releases access to selections that define this fill-surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)

```
Dim instance As IFillSurfaceFeatureData
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [FillSurfaceFeatureData::ReleaseSelectionAccess](#).

Remarks

[IFillSurfaceFeatureData::AccessSelections](#) and [IFillSurfaceFeatureData::!AccessSelections](#) put the model into a rollback state to allow access to the selections that define the fill-surface feature.

Use this method to restore the rollback state if you did not modify the fill-surface feature, or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did modify the fill-surface feature.

See Also

[IFillSurfaceFeatureData Interface](#)
[IFillSurfaceFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ResolutionControl Property (IFillSurfaceFeatureData)

[See Also](#) [Example](#)



SolidWorks.Interop.sldworks Namespace > IFillSurfaceFeatureData Interface : ResolutionControl Property (IFillSurfaceFeatureData)

Gets and sets the quality of the resolution of the fill-surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ResolutionControl As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IFillSurfaceFeatureData
Dim value As System.Integer

instance.ResolutionControl = value
```

```
value = instance.ResolutionControl
```

C#

```
System.int ResolutionControl {get; set;}
```

C++/CLI

```
property System.int ResolutionControl {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Valid values: 1, 2, and 3 (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [FillSurfaceFeatureData::ResolutionControl](#).

Example

[Insert Fill-surface Feature \(C#\)](#)
[Insert Fill-surface Feature \(VB.NET\)](#)
[Insert Fill-surface Feature \(VBA\)](#)

Remarks

Adjusting the quality of the resolution is only available for patches that are not optimized. See [IFillSurfaceFeatureData::OptimizeSurface](#) for details.

Specifying a higher value:

- Increases the number of patches defining the surface
- Improves the quality of the surface profile
- Increases processing time
- Increases the size of the file

See Also

[IFillSurfaceFeatureData Interface](#)
[IFillSurfaceFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (IFillSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFillSurfaceFeatureData Interface](#) : ReverseDirection Property (IFillSurfaceFeatureData)

Gets or sets whether or not to reverse direction while merging results.

.NET Syntax

Visual Basic (Declaration)

```
Property ReverseDirection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFillSurfaceFeatureData  
Dim value As System.Boolean
```

```
instance.ReverseDirection = value
```

```
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse direction while merging results, false to not

Visual Basic for Applications (VBA) Syntax

See [FillSurfaceFeatureData::ReverseDirection](#).

Remarks

When patching a solid with a fill surface, there are often two possible results. Use this method to reverse direction while merging results if the fill surface displays in an unwanted direction. See [IFillSurfaceFeatureData::Merge](#) for details about merging results.

See Also

[IFillSurfaceFeatureData Interface](#)
[IFillSurfaceFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseSurface Property (IFillSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFillSurfaceFeatureData Interface](#) : ReverseSurface Property (IFillSurfaceFeatureData)

Gets or sets direction of the surface patch.

.NET Syntax

Visual Basic (Declaration)

```
Property ReverseSurface As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFillSurfaceFeatureData  
Dim value As System.Boolean
```

```
instance.ReverseSurface = value
```

```
value = instance.ReverseSurface
```

C#

```
System.bool ReverseSurface {get; set;}
```

C++/CLI

```
property System.bool ReverseSurface {  
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True reverses the direction of the surface patch, false does not

Visual Basic for Applications (VBA) Syntax

See [FillSurfaceFeatureData::ReverseSurface](#).

Remarks

This property is dynamic and is only available when:

- All boundary curves are coplanar
- No constraint points exist
- No interior constraints
- Fill surface is nonplanar

See Also

[IFillSurfaceFeatureData Interface](#)
[IFillSurfaceFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetConstraintCurves Method (IFillSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFillSurfaceFeatureData Interface](#) : SetConstraintCurves Method (IFillSurfaceFeatureData)

Sets the entities for the constraint curves.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetConstraintCurves( _  
    ByVal ConstraintVar As System.Object _  
)
```

Visual Basic (Usage)

```
Dim instance As IFillSurfaceFeatureData  
Dim ConstraintVar As System.Object  
  
instance.SetConstraintCurves(ConstraintVar)
```

C#

```
void SetConstraintCurves(  
    System.object ConstraintVar  
)
```

C++/CLI

```
void SetConstraintCurves(  
    & System.Object^ ConstraintVar  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ConstraintVar

Array of entities to use to constrain the surface; valid entities are:

- [Edges](#)
- [Sketches](#)

Visual Basic for Applications (VBA) Syntax

See [IFillSurfaceFeatureData::SetConstraintCurves](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IFillSurfaceFeatureData Interface](#)
[IFillSurfaceFeatureData Members](#)
[IFillSurfaceFeatureData::GetConstraintCurves Method](#)
[IFillSurfaceFeatureData::GetConstraintCurvesCount Method](#)
[IFillSurfaceFeatureData::!GetConstraintCurves Method](#)
[IFillSurfaceFeatureData::!SetConstraintCurves Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetCurvatureControl Method (IFillSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFillSurfaceFeatureData Interface](#) : SetCurvatureControl Method (IFillSurfaceFeatureData)

Sets the contact type for this fill-surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetCurvatureControl( _  
    ByVal EntityIn As System.Object, _  
    ByVal ControlType As System.Integer, _  
    ByVal BALL As System.Boolean _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFillSurfaceFeatureData  
Dim EntityIn As System.Object  
Dim ControlType As System.Integer  
Dim BALL As System.Boolean  
Dim value As System.Boolean  
  
value = instance.SetCurvatureControl(EntityIn, ControlType, BALL)
```

C#

```
System.bool SetCurvatureControl(  
    System.object EntityIn,  
    System.int ControlType,  
    System.bool BALL  
)
```

C++/CLI

```
System.bool SetCurvatureControl(  
& System.Object^ EntityIn,  
& System.int ControlType,
```

```
& System.bool BAII
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EntityIn

Edge or sketch boundary returned by [IFillSurfaceFeatureData::GetPatchBoundary](#) or [IFillSurfaceFeatureData::IGetPatchBoundary](#)

ControlType

Contact type as defined in [swContactType_e](#)

BAII

True to set contact type for all boundary entities, false to not

Return Value

True if contact type is set, false if not

Visual Basic for Applications (VBA) Syntax

See [FillSurfaceFeatureData::SetCurvatureControl](#).

Remarks

Sketch boundaries must be set to swContact.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IFillSurfaceFeatureData Interface](#)

[IFillSurfaceFeatureData Members](#)

[IFillSurfaceFeatureData::GetAlternateFace Method](#)

[IFillSurfaceFeatureData::GetCurvatureControl Method](#)

[IFillSurfaceFeatureData::GetPatchBoundary Method](#)

[IFillSurfaceFeatureData::GetPatchBoundaryCount Method](#)

[IFillSurfaceFeatureData::ISetPatchBoundary Method](#)

[IFillSurfaceFeatureData::SetPatchBoundary Method](#)

[IFillSurfaceFeatureData::ToggleAlternateFace Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetPatchBoundary Method (IFillSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFillSurfaceFeatureData Interface](#) : SetPatchBoundary Method (IFillSurfaceFeatureData)

Sets the patch boundary for this fill-surface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetPatchBoundary( _
    ByVal PatchVar As System.Object _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IFillSurfaceFeatureData
Dim PatchVar As System.Object
Dim value As System.Boolean

value = instance.SetPatchBoundary(PatchVar)
```

C#

```
System.bool SetPatchBoundary(
    System.object PatchVar
)
```



```
System.bool SetPatchBoundary(
& System.Object^ PatchVar
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PatchVar

Array of entities to use as the patch boundary of size count; valid entities are:

- [Edges](#)
- [Sketches](#)

Visual Basic for Applications (VBA) Syntax

See [FillSurfaceFeatureData::SetPatchBoundary](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IFillSurfaceFeatureData Interface](#)
[IFillSurfaceFeatureData Members](#)
[IFillSurfaceFeatureData::GetAlternateFace Method](#)
[IFillSurfaceFeatureData::GetCurvatureControl Method](#)
[IFillSurfaceFeatureData::GetPatchBoundary Method](#)
[IFillSurfaceFeatureData::GetPatchBoundaryCount Method](#)
[IFillSurfaceFeatureData::IPatchBoundary Method](#)
[IFillSurfaceFeatureData::ToggleAlternateFace Method](#)
[IFillSurfaceFeatureData::TryToFormSolid Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ToggleAlternateFace Method (IFillSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFillSurfaceFeatureData Interface](#) : ToggleAlternateFace Method (IFillSurfaceFeatureData)

Switches the boundary face of the curvature control of the patch.

.NET Syntax

Visual Basic (Declaration)

```
Function ToggleAlternateFace() As Face2
```

Visual Basic (Usage)



```
Dim instance As IFillSurfaceFeatureData
Dim value As Face2

value = instance.ToggleAlternateFace()
```

C#

```
Face2 ToggleAlternateFace()
```

C++/CLI

```
Face2^ ToggleAlternateFace();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the new boundary face, [IFace2](#) object

Visual Basic for Applications (VBA) Syntax

See [IFillSurfaceFeatureData::ToggleAlternateFace](#).

Remarks

This method is valid only when the contact type is tangent and edges are used to define the patch boundary. Use [IFillSurfaceFeatureData::GetCurvatureControl](#) to determine the contact type.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IFillSurfaceFeatureData Interface](#)
[IFillSurfaceFeatureData Members](#)
[IFillSurfaceFeatureData::GetAlternateFace Method](#)
[IFillSurfaceFeatureData::GetCurvatureControl Method](#)
[IFillSurfaceFeatureData::GetPatchBoundary Method](#)
[IFillSurfaceFeatureData::GetPatchBoundaryCount Method](#)
[IFillSurfaceFeatureData::IGetPatchBoundary Method](#)
[IFillSurfaceFeatureData::ISetPatchBoundary Method](#)
[IFillSurfaceFeatureData::SetCurvatureControl Method](#)
[IFillSurfaceFeatureData::SetPatchBoundary Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TryToFormSolid Property (IFillSurfaceFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFillSurfaceFeatureData Interface](#) : TryToFormSolid Property (IFillSurfaceFeatureData)

Gets or sets whether to form a solid.

.NET Syntax

Visual Basic (Declaration)

```
Property TryToFormSolid As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFillSurfaceFeatureData  
Dim value As System.Boolean
```

```
instance.TryToFormSolid = value
```

```
value = instance.TryToFormSolid
```

C#

```
System.bool TryToFormSolid {get; set;}
```

C++/CLI

```
property System.bool TryToFormSolid {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if trying to form solid, false if not

Visual Basic for Applications (VBA) Syntax

See [FillSurfaceFeatureData::TryToFormSolid](#).

Remarks

The behavior for this option depends on the boundaries.

- When all the boundaries belong to the same solid body, you can use the surface fill to patch the solid.
- If at least one of the edges is an open sheet edge and you merge results, then the fill knits with the surfaces to which the edges belong. See [IFillSurfaceFeatureData::Merge](#) for details about merging results.
- If all the boundary entities are open edges, then a solid may be created.

See [IFillSurfaceFeatureData::GetPatchBoundary](#) or [IFillSurfaceFeatureData::IGetPatchBoundary](#) and [IFillSurfaceFeatureData::SetPatchBoundary](#) or [IFillSurfaceFeatureData::ISetPatchBoundary](#) for details about boundary entities.

See Also

[IFillSurfaceFeatureData Interface](#)
[IFillSurfaceFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0