

SOLIDWORKS API (.NET VBA C#) — Reference (125/337): IFlatPatternFeatureData-IFlyoutGroup

SOLIDWORKS API Documentation (converted from CHM)

IFlatPatternFeatureData (Type)

IFlatPatternFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFlatPatternFeatureData Interface

Allows access to a Flat-Pattern feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IFlatPatternFeatureData
```

Visual Basic (Usage)



```
Dim instance As IFlatPatternFeatureData
```

C#

```
public interface IFlatPatternFeatureData
```

C++/CLI

```
public interface class IFlatPatternFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFeatureData](#).

Example

[Get Fixed Face of Flat-Pattern Feature \(VBA\)](#)
[Exclude Faces Before Flattening \(VBA\)](#)
[Exclude Faces Before Flattening \(VB.NET\)](#)
[Exclude Faces Before Flattening \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[FlatPatternFeatureData](#)

See Also

[IFlatPatternFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISheetMetalFeatureData Interface](#)
[IFeatureManager::FinishCornerRelief Method \(\)](#)

IFlatPatternFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFlatPatternFeatureData Interface

The following tables list the members exposed by [IFlatPatternFeatureData](#).

Public Properties

Name	Description
 BreakCornerRadius	Gets or sets the radius of the break corner for the Flat-Pattern feature.

 BreakCornerType	Gets or sets the type of break corner for the Flat-Pattern feature.
 CornerTreatment	Gets or sets whether to apply smooth edges in the flat pattern to the Flat-Pattern feature.
 CornerTrimRatioToThickness	Gets or sets the ratio of the relief thickness of the corner trim for the Flat-Pattern feature.
 CornerTrimReliefDistance	Gets or sets the distance of the relief for the corner trim for the Flat-Pattern feature.
 CornerTrimReliefType	Gets or sets the type of relief for the corner trim for the Flat-Pattern feature.
 ExcludedFaces	Gets and sets the faces to exclude from this Flat-Pattern feature.
 FixedFace	Obsolete. Superseded by IFlatPatternFeatureData.FixedFace2
 FixedFace2	Gets or sets the fixed face of this Flat-Pattern feature.
 MergeFace	Gets or sets whether to merge the faces that are planar and coincident in the Flat-Pattern feature.
 ShowSlitInCornerRelief	Get or set whether to show the slit in the corner relief of this Flat-Pattern feature.
 SimplifyBends	Gets or sets whether to simplify bends in this Flat-Pattern feature.
 UseRatioToThickness	Gets or sets whether to use the ratio to thickness setting for the corner trim for the Flat-Pattern feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that describe this Flat-Pattern feature.
 GetAddCornerTrim	Gets whether to add a corner trim to the Flat-Pattern feature.
 GetBreakCorners	Gets whether to add break corners to the Flat-Pattern feature.
 AccessSelections	Obsolete. Superseded by IFlatPatternFeatureData.IAccessSelections2 .
 IAccessSelections2	Gains access to the selections that describe this Flat-Pattern feature.
 IGetExcludedFaces	Gets the faces that are excluded from this Flat-Pattern feature.
 IGetExcludedFacesCount	Gets the number of faces that are excluded from this Flat-Pattern feature.
 ISetExcludedFaces	Sets the faces to exclude from this Flat-Pattern feature.
 ReleaseSelectionAccess	Releases access to selections that describe this Flat-Pattern feature.
 SetAddCornerTrim	Sets whether to add corner trims to the Flat-Pattern feature.
 SetBreakCorners	Sets whether to add break corners to the Flat-Pattern feature.

[Top](#)

See Also

[IFlatPatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISheetMetalFeatureData Interface](#)
[IFeatureManager.FinishCornerRelief Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IFlatPatternFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : [IFlatPatternFeatureData Interface](#)

For a list of all members of this type, see [IFlatPatternFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that describe this Flat-Pattern feature.
 GetAddCornerTrim	Gets whether to add a corner trim to the Flat-Pattern feature.
 GetBreakCorners	Gets whether to add break corners to the Flat-Pattern feature.
 IAccessSelections	Obsolete. Superseded by IFlatPatternFeatureData.IAccessSelections2 .

	IAccessSelections2	Gains access to the selections that describe this Flat-Pattern feature.
	IGetExcludedFaces	Gets the faces that are excluded from this Flat-Pattern feature.
	IGetExcludedFacesCount	Gets the number of faces that are excluded from this Flat-Pattern feature.
	ISetExcludedFaces	Sets the faces to exclude from this Flat-Pattern feature.
	ReleaseSelectionAccess	Releases access to selections that describe this Flat-Pattern feature.
	SetAddCornerTrim	Sets whether to add corner trims to the Flat-Pattern feature.
	SetBreakCorners	Sets whether to add break corners to the Flat-Pattern feature.

[Top](#)

 See Also

[IFlatPatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISheetMetalFeatureData Interface](#)
[IFeatureManager::FinishCornerRelief Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IFlatPatternFeatureData Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : [IFlatPatternFeatureData Interface](#)

For a list of all members of this type, see [IFlatPatternFeatureData members](#).

 Public Properties

Name	Description
 BreakCornerRadius	Gets or sets the radius of the break corner for the Flat-Pattern feature.
 BreakCornerType	Gets or sets the type of break corner for the Flat-Pattern feature.
 CornerTreatment	Gets or sets whether to apply smooth edges in the flat pattern to the Flat-Pattern feature.
 CornerTrimRatioToThickness	Gets or sets the ratio of the relief thickness of the corner trim for the Flat-Pattern feature.
 CornerTrimReliefDistance	Gets or sets the distance of the relief for the corner trim for the Flat-Pattern feature.
 CornerTrimReliefType	Gets or sets the type of relief for the corner trim for the Flat-Pattern feature.
 ExcludedFaces	Gets and sets the faces to exclude from this Flat-Pattern feature.
 FixedFace	Obsolete. Superseded by IFlatPatternFeatureData::FixedFace2
 FixedFace2	Gets or sets the fixed face of this Flat-Pattern feature.
 MergeFace	Gets or sets whether to merge the faces that are planar and coincident in the Flat-Pattern feature.
 ShowSlitInCornerRelief	Get or set whether to show the slit in the corner relief of this Flat-Pattern feature.
 SimplifyBends	Gets or sets whether to simplify bends in this Flat-Pattern feature.
 UseRatioToThickness	Gets or sets whether to use the ratio to thickness setting for the corner trim for the Flat-Pattern feature.

[Top](#)

 See Also

[IFlatPatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISheetMetalFeatureData Interface](#)
[IFeatureManager::FinishCornerRelief Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IFlatPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFeatureData Interface](#) : [AccessSelections Method \(IFlatPatternFeatureData\)](#)

Gains access to the selections that describe this Flat-Pattern feature.

 .NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFlatPatternFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFeatureData::AccessSelections](#).

Example

[Get Fixed Face of Flat-Pattern Feature \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IFlatPatternFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IFlatPatternFeatureData Interface](#)
[IFlatPatternFeatureData Members](#)
[IFlatPatternFeatureData::IAccessSelections2 Method](#)

Availability

BreakCornerRadius Property (IFlatPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFeatureData Interface](#) : BreakCornerRadius Property (IFlatPatternFeatureData)

Gets or sets the radius of the break corner for the Flat-Pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property BreakCornerRadius As System.Double

Visual Basic (Usage)



```
Dim instance As IFlatPatternFeatureData  
Dim value As System.Double
```

```
instance.BreakCornerRadius = value
```

```
value = instance.BreakCornerRadius
```

C#

```
System.double BreakCornerRadius {get; set;}
```

C++/CLI

```
property System.double BreakCornerRadius {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Radius

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFeatureData::BreakCornerRadius](#).

See Also

[IFlatPatternFeatureData Interface](#)
[IFlatPatternFeatureData Members](#)
[IFlatPatternFeatureData::IBreakCornerFeatureData Interface](#)
[IFlatPatternFeatureData::GetBreakCorners Method](#)
[IFlatPatternFeatureData::SetBreakCorners Method](#)
[IFlatPatternFeatureData::BreakCornerType Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

BreakCornerType Property (IFlatPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFeatureData Interface](#) : BreakCornerType Property (IFlatPatternFeatureData)

Gets or sets the type of break corner for the Flat-Pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property BreakCornerType As System.Integer

Visual Basic (Usage)

```
Dim instance As IFlatPatternFeatureData
Dim value As System.Integer

instance.BreakCornerType = value
value = instance.BreakCornerType
```

C#

```
System.int BreakCornerType {get; set;}
```

C++/CLI

```
property System.int BreakCornerType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of break corner as defined in [swBreakCornerTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFeatureData::BreakCornerType](#).

See Also

[IFlatPatternFeatureData Interface](#)
[IFlatPatternFeatureData Members](#)
[IFlatPatternFeatureData::GetBreakCorners Method](#)
[IFlatPatternFeatureData::SetBreakCorners Method](#)
[IFlatPatternFeatureData::BreakCornerRadius Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CornerTreatment Property (IFlatPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFeatureData Interface](#) : CornerTreatment Property (IFlatPatternFeatureData)

Gets or sets whether to apply smooth edges in the flat pattern to the Flat-Pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property CornerTreatment As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IFlatPatternFeatureData
Dim value As System.Boolean

instance.CornerTreatment = value
value = instance.CornerTreatment
```

C#

```
System.bool CornerTreatment {get; set;}
```

C++/CLI

```
property System.bool CornerTreatment {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to apply smooth edges, false to not

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFeatureData::CornerTreatment](#).

See Also

[IFlatPatternFeatureData Interface](#)
[IFlatPatternFeatureData Members](#)
[IFlatPatternFeatureData::ShowSlitInCornerRelief Property\(\)](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CornerTrimRatioToThickness Property (IFlatPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFeatureData Interface](#) : CornerTrimRatioToThickness Property (IFlatPatternFeatureData)

Gets or sets the ratio of the relief thickness of the corner trim for the Flat-Pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property CornerTrimRatioToThickness As System.Double
```

Visual Basic (Usage)



```
Dim instance As IFlatPatternFeatureData
Dim value As System.Double

instance.CornerTrimRatioToThickness = value
value = instance.CornerTrimRatioToThickness
```

C#

```
System.double CornerTrimRatioToThickness {get; set;}
```

C++/CLI

```
property System.double CornerTrimRatioToThickness {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Ratio

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFeatureData::CornerTrimRatioToThickness](#).

See Also

[IFlatPatternFeatureData Interface](#)
[IFlatPatternFeatureData Members](#)
[IFlatPatternFeatureData::GetAddCornerTrim Method](#)
[IFlatPatternFeatureData::SetAddCornerTrim Method](#)
[IFlatPatternFeatureData::CornerTrimReliefDistance Property](#)
[IFlatPatternFeatureData::CornerTrimReliefType Property](#)
[IFlatPatternFeatureData::UseRatioToThickness Property](#)
[IFlatPatternFeatureData::ShowSlitInCornerRelief Property\(\)](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CornerTrimReliefDistance Property (IFlatPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFeatureData Interface](#) : CornerTrimReliefDistance Property (IFlatPatternFeatureData)

Gets or sets the distance of the relief for the corner trim for the Flat-Pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property CornerTrimReliefDistance As System.Double

Visual Basic (Usage)



```
Dim instance As IFlatPatternFeatureData  
Dim value As System.Double  
  
instance.CornerTrimReliefDistance = value  
  
value = instance.CornerTrimReliefDistance
```

C#

```
System.double CornerTrimReliefDistance {get; set;}
```

C++/CLI

```
property System.double CornerTrimReliefDistance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance of the relief for the corner trim

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFeatureData::CornerTrimReliefDistance](#).

See Also

[IFlatPatternFeatureData Interface](#)
[IFlatPatternFeatureData Members](#)
[IFlatPatternFeatureData::GetAddCornerTrim Method](#)
[IFlatPatternFeatureData::SetAddCornerTrim Method](#)
[IFlatPatternFeatureData::CornerTrimRatioToThickness Property](#)
[IFlatPatternFeatureData::CornerTrimReliefType Property](#)
[IFlatPatternFeatureData::UseRatioToThickness Property](#)
[IFlatPatternFeatureData::ShowSlitInCornerRelief Property\(\)](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

CornerTrimReliefType Property (IFlatPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFeatureData Interface](#) : CornerTrimReliefType Property (IFlatPatternFeatureData)

Gets or sets the type of relief for the corner trim for the Flat-Pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property CornerTrimReliefType As System.Integer

Visual Basic (Usage)



```
Dim instance As IFlatPatternFeatureData  
Dim value As System.Integer  
  
instance.CornerTrimReliefType = value  
  
value = instance.CornerTrimReliefType
```

C#

```
System.int CornerTrimReliefType {get; set;}
```

C++/CLI

```
property System.int CornerTrimReliefType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of relief as defined in [swCornerReliefType_e](#)

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFeatureData::CornerTrimReliefType](#).

See Also

[IFlatPatternFeatureData Interface](#)
[IFlatPatternFeatureData Members](#)
[IFlatPatternFeatureData::GetAddCornerTrim Method](#)
[IFlatPatternFeatureData::SetAddCornerTrim Method](#)
[IFlatPatternFeatureData::CornerTrimRatioToThickness Property](#)
[IFlatPatternFeatureData::CornerTrimReliefDistance Property](#)
[IFlatPatternFeatureData::UseRatioToThickness Property](#)
[IFlatPatternFeatureData::ShowSlitInCornerRelief Property\(\)](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

ExcludedFaces Property (IFlatPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFeatureData Interface](#) : ExcludedFaces Property (IFlatPatternFeatureData)

Gets and sets the faces to exclude from this Flat-Pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property ExcludedFaces As System.Object

Visual Basic (Usage)



```
Dim instance As IFlatPatternFeatureData
Dim value As System.Object

instance.ExcludedFaces = value

value = instance.ExcludedFaces
```

C#

```
System.Object ExcludedFaces {get; set;}
```

C++/CLI

```
property System.Object^ ExcludedFaces {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [IFace2s](#)

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFeatureData::ExcludedFaces](#).

Example

[Exclude Faces Before Flattening \(VBA\)](#)
[Exclude Faces Before Flattening \(VB.NET\)](#)
[Exclude Faces Before Flattening \(C#\)](#)

Remarks

To get the size of the array returned by this method, call [IFlatPatternFeatureData::IGetExcludedFacesCount](#).

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IFlatPatternFeatureData Interface](#)
[IFlatPatternFeatureData Members](#)
[IFlatPatternFeatureData::IGetExcludedFaces Method](#)
[IFlatPatternFeatureData::ISetExcludedFaces Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20

SOLIDWORKS API Help

[Send comments](#) on this topic.

FixedFace Property (IFlatPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFeatureData Interface](#) : FixedFace Property (IFlatPatternFeatureData)

Obsolete. Superseded by [IFlatPatternFeatureData::FixedFace2](#).

.NET Syntax

Visual Basic (Declaration)

Property FixedFace As System.Object

Visual Basic (Usage)

```
Dim instance As IFlatPatternFeatureData
Dim value As System.Object

instance.FixedFace = value

value = instance.FixedFace
```

C#

```
System.object FixedFace {get; set;}
```

C++/CLI

```
property System.Object^ FixedFace {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Fixed [face](#)

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFeatureData.FixedFace](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IFlatPatternFeatureData Interface](#)
[IFlatPatternFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

FixedFace2 Property (IFlatPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFeatureData Interface](#) : FixedFace2 Property (IFlatPatternFeatureData)

Gets or sets the fixed face of this Flat-Pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property FixedFace2 As System.Object
```

Visual Basic (Usage)

```
Dim instance As IFlatPatternFeatureData
Dim value As System.Object

instance.FixedFace2 = value

value = instance.FixedFace2
```

C#

```
System.object FixedFace2 {get; set;}
```

C++/CLI

```
property System.Object^ FixedFace2 {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Fixed [face](#) (or [edge](#) for cylindrical sheet metal parts)

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFeatureData::FixedFace2](#).

Example

[Get Fixed Face of Flat-Pattern Feature \(VBA\)](#)
[Get Fixed Face of Flat-Pattern Feature \(VB.NET\)](#)
[Get Fixed Face of Flat-Pattern Feature \(C#\)](#)

Remarks

The difference between this method and the now obsolete `IFlatPatternFeatureData::FixedFace` is that this method successfully returns the fixed face of a Flat-Pattern feature in a sheet metal part created in any version of SOLIDWORKS.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IFlatPatternFeatureData Interface](#)
[IFlatPatternFeatureData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAddCornerTrim Method (IFlatPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFeatureData Interface](#) : GetAddCornerTrim Method (IFlatPatternFeatureData)

Gets whether to add a corner trim to the Flat-Pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAddCornerTrim( _  
    ByRef PFeat As Feature _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFlatPatternFeatureData  
Dim PFeat As Feature  
Dim value As System.Boolean
```

```
value = instance.GetAddCornerTrim(PFeat)
```

C#

```
System.bool GetAddCornerTrim(  
    out Feature PFeat  
)
```

C++/CLI

```
System.bool GetAddCornerTrim(  
& [Out] Feature^ PFeat  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFeat
Flat-Pattern [feature](#) object

Return Value

True to add a corner trim, false to not

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFeatureData::GetAddCornerTrim](#).

See Also

[IFlatPatternFeatureData Interface](#)
[IFlatPatternFeatureData Members](#)
[IFlatPatternFeatureData::CornerTrimRatioToThickness Property](#)
[IFlatPatternFeatureData::CornerTrimReliefDistance Property](#)
[IFlatPatternFeatureData::CornerTrimReliefType Property](#)
[IFlatPatternFeatureData::UseRatioToThickness Property](#)
[IFlatPatternFeatureData::ShowSlitInCornerRelief Property\(\)](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBreakCorners Method (IFlatPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFeatureData Interface](#) : GetBreakCorners Method (IFlatPatternFeatureData)

Gets whether to add break corners to the Flat-Pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBreakCorners( _  
    ByRef PFeat As Feature _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFlatPatternFeatureData  
Dim PFeat As Feature  
Dim value As System.Boolean  
  
value = instance.GetBreakCorners(PFeat)
```

C#

```
System.bool GetBreakCorners(  
    out Feature PFeat  
)
```

C++/CLI

```
System.bool GetBreakCorners(  
& [Out] Feature^ PFeat  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFeat

Flat-Pattern [feature](#) object

Return Value

True to add break corners, false to not

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFeatureData::GetBreakCorners](#).

See Also

[IFlatPatternFeatureData Interface](#)
[IFlatPatternFeatureData Members](#)
[IFlatPatternFeatureData::SetBreakCorners Method](#)
[IFlatPatternFeatureData::BreakCornerRadius Property](#)
[IFlatPatternFeatureData::BreakCornerType Property](#)
[IBreakCornerFeatureData Interface](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections Method (IFlatPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFeatureData Interface](#) : IAccessSelections Method (IFlatPatternFeatureData)

Obsolete. Superseded by [IFlatPatternFeatureData::IAccessSelections2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFlatPatternFeatureData  
Dim TopDoc As ModelDoc  
Dim Component As Component  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc TopDoc,  
    Component Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc^ TopDoc,  
& Component^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Component

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFeatureData::IAccessSelections](#).

See Also

[IFlatPatternFeatureData Interface](#)
[IFlatPatternFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections2 Method (IFlatPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFeatureData Interface](#) : IAccessSelections2 Method (IFlatPatternFeatureData)

Gains access to the selections that describe this Flat-Pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections2( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFlatPatternFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections2(TopDoc, Component)
```

C#

```
System.bool IAccessSelections2(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections2(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFeatureData::IAccessSelections2](#).

Remarks

To modify a feature in a...

Then...

Part

- TopDoc argument is the [IModelDoc2](#) for the part
- Component argument is NULL

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::!ModifyDefinition2](#) if you modified the feature
- [IFlatPatternFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IFlatPatternFeatureData Interface](#)
[IFlatPatternFeatureData Members](#)
[IFlatPatternFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetExcludedFaces Method (IFlatPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFeatureData Interface](#) : IGetExcludedFaces Method (IFlatPatternFeatureData)

Gets the faces that are excluded from this Flat-Pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetExcludedFaces() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFlatPatternFeatureData  
Dim value As System.Object  
  
value = instance.IGetExcludedFaces()
```

C#

```
System.object IGetExcludedFaces()
```

C++/CLI

```
System.Object^ IGetExcludedFaces();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of [IFace2s](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

To get the size of the array returned by this method, call [IFlatPatternFeatureData::!GetExcludedFacesCount](#).

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IFlatPatternFeatureData Interface](#)
[IFlatPatternFeatureData Members](#)
[IFlatPatternFeatureData::ExcludedFaces Property](#)
[IFlatPatternFeatureData::!SetExcludedFaces Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20

IGetExcludedFacesCount Method (IFlatPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFeatureData Interface](#) : IGetExcludedFacesCount Method (IFlatPatternFeatureData)

Gets the number of faces that are excluded from this Flat-Pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetExcludedFacesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFlatPatternFeatureData  
Dim value As System.Integer  
  
value = instance.IGetExcludedFacesCount()
```

C#

```
System.int IGetExcludedFacesCount()
```

C++/CLI

```
System.int IGetExcludedFacesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of excluded faces

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFeatureData::IGetExcludedFacesCount](#).

Remarks

Call this method to get the size of the array returned by [IFlatPatternFeatureData::IGetExcludedFaces](#) and [IFlatPatternFeatureData::ExcludedFaces](#).

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IFlatPatternFeatureData Interface](#)
[IFlatPatternFeatureData Members](#)
[IFlatPatternFeatureData::ISetExcludedFaces Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20

ISetExcludedFaces Method (IFlatPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFeatureData Interface](#) : ISetExcludedFaces Method (IFlatPatternFeatureData)

Sets the faces to exclude from this Flat-Pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetExcludedFaces( _  
    ByVal FaceCount As System.Integer, _  
    ByRef FaceArray As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IFlatPatternFeatureData  
Dim FaceCount As System.Integer  
Dim FaceArray As System.Object  
  
instance.ISetExcludedFaces(FaceCount, FaceArray)
```

C#

```
void ISetExcludedFaces(  
    System.int FaceCount,  
    ref System.object FaceArray  
)
```

C++/CLI

```
void ISetExcludedFaces(  
& System.int FaceCount,  
& System.Object^% FaceArray  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceCount

Number of faces to exclude

FaceArray

- in-process, unmanaged C++: Pointer to an array of [IFace2s](#) to exclude
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IFlatPatternFeatureData Interface](#)

[IFlatPatternFeatureData Members](#)

[IFlatPatternFeatureData::IGetExcludedFaces Method](#)

[IFlatPatternFeatureData::IGetExcludedFacesCount Method](#)

[IFlatPatternFeatureData::ExcludedFaces Property](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20

SOLIDWORKS API Help

[Send comments on this topic.](#)

MergeFace Property (IFlatPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFeatureData Interface](#) : MergeFace Property (IFlatPatternFeatureData)

Gets or sets whether to merge the faces that are planar and coincident in the Flat-Pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property MergeFace As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFlatPatternFeatureData
Dim value As System.Boolean

instance.MergeFace = value

value = instance.MergeFace
```

C#

```
System.bool MergeFace {get; set;}
```

C++/CLI

```
property System.bool MergeFace {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True merges the faces, false does not

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFeatureData.MergeFace](#).

See Also

[IFlatPatternFeatureData Interface](#)
[IFlatPatternFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

[SOLIDWORKS API Help](#)

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IFlatPatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFeatureData Interface](#) : ReleaseSelectionAccess Method (IFlatPatternFeatureData)

Releases access to selections that describe this Flat-Pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IFlatPatternFeatureData

instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFeatureData::ReleaseSelectionAccess](#).

Example

[Get Fixed Face of Flat-Pattern Feature \(VBA\)](#)

Remarks

[IFlatPatternFeatureData::AccessSelections](#) and [IFlatPatternFeatureData::!AccessSelections2](#) put the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefintion2](#) if you did.

See Also

[IFlatPatternFeatureData Interface](#)
[IFlatPatternFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetAddCornerTrim Method (IFlatPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFeatureData Interface](#) : SetAddCornerTrim Method (IFlatPatternFeatureData)

Sets whether to add corner trims to the Flat-Pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetAddCornerTrim( _  
    ByVal BCT As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IFlatPatternFeatureData  
Dim BCT As System.Boolean  
  
instance.SetAddCornerTrim(BCT)
```

C#

```
void SetAddCornerTrim(  
    System.bool BCT  
)
```

C++/CLI

```
void SetAddCornerTrim(  
&    System.bool BCT  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BCT

True to add corner trims, false to not

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFeatureData::SetAddCornerTrim](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IFlatPatternFeatureData Interface](#)
[IFlatPatternFeatureData Members](#)
[IFlatPatternFeatureData::GetAddCornerTrim Method](#)
[IFlatPatternFeatureData::CornerTrimRatioToThickness Property](#)
[IFlatPatternFeatureData::CornerTrimReliefDistance Property](#)
[IFlatPatternFeatureData::CornerTrimReliefType Property](#)
[IFlatPatternFeatureData::UseRatioToThickness Property](#)
[IFlatPatternFeatureData::ShowSlitInCornerRelief Property \(\)](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetBreakCorners Method (IFlatPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFeatureData Interface](#) : SetBreakCorners Method (IFlatPatternFeatureData)

Sets whether to add break corners to the Flat-Pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetBreakCorners( _  
    ByVal BBreakCorner As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IFlatPatternFeatureData  
Dim BBreakCorner As System.Boolean  
  
instance.SetBreakCorners(BBreakCorner)
```

C#

```
void SetBreakCorners(  
    System.bool BBreakCorner  
)
```

C++/CLI

```
void SetBreakCorners(  
& System.bool BBreakCorner  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BBreakCorner

True to add break corners, false to not

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFeatureData::SetBreakCorners](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IFlatPatternFeatureData Interface](#)
[IFlatPatternFeatureData Members](#)
[IFlatPatternFeatureData::GetBreakCorners Method](#)
[IFlatPatternFeatureData::BreakCornerRadius Property](#)
[IFlatPatternFeatureData::BreakCornerType Property](#)
[IBreakCornerFeatureData Interface](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowSlitInCornerRelief Property (IFlatPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFeatureData Interface](#) : ShowSlitInCornerRelief Property (IFlatPatternFeatureData)

Get or set whether to show the slit in the corner relief of this Flat-Pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ShowSlitInCornerRelief As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFlatPatternFeatureData  
Dim value As System.Boolean  
  
instance.ShowSlitInCornerRelief = value  
  
value = instance.ShowSlitInCornerRelief
```

C#

```
System.bool ShowSlitInCornerRelief {get; set;}
```

C++/CLI

```
property System.bool ShowSlitInCornerRelief {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to display the slit in the corner relief of this feature, false to not

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFeatureData::ShowSlitInCornerRelief](#).

Remarks

When you create a rectangular or circular corner relief that is smaller than the bend area, a slit is added so that the part can bend. Setting this property to true makes the slit available in the flat pattern.

This property corresponds to the **Show Slit** option in the Parameters section of the Flat-Pattern PropertyManager.

See Also

[IFlatPatternFeatureData Interface](#)
[IFlatPatternFeatureData Members](#)
[IFlatPatternFeatureData::CornerTrimReliefType Property\(\)](#)
[IFlatPatternFeatureData::GetAddCornerTrim Method\(\)](#)
[IFlatPatternFeatureData::SetAddCornerTrim Method\(\)](#)

[IFlatPatternFeatureData::CornerTreatment Property\(\)](#)
[IFlatPatternFeatureData::CornerTrimRatioToThickness Property\(\)](#)
[IFlatPatternFeatureData::CornerTrimReliefDistance Property\(\)](#)
[IFlatPatternFeatureData::UseRatioToThickness Property\(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SimplifyBends Property (IFlatPatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFeatureData Interface](#) : SimplifyBends Property (IFlatPatternFeatureData)

Gets or sets whether to simplify bends in this Flat-Pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property SimplifyBends As System.Boolean

Visual Basic (Usage)



```
Dim instance As IFlatPatternFeatureData  
Dim value As System.Boolean
```

```
instance.SimplifyBends = value
```

```
value = instance.SimplifyBends
```

C#

```
System.bool SimplifyBends {get; set;}
```

C++/CLI

```
property System.bool SimplifyBends {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to simplify edges to lines, false to leave edges complex

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFeatureData::SimplifyBends](#).

Remarks

This property corresponds to the **Simplify bends** check box on the **Parameters** group box on the **Flat Pattern** PropertyManager, which is displayed when you edit the definition of a flat-pattern feature with complex bends in SOLIDWORKS.

See Also

[IFlatPatternFeatureData Interface](#)
[IFlatPatternFeatureData Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseRatioToThickness Property (IFlatPatternFeatureData)

[See Also](#)



Gets or sets whether to use the ratio to thickness setting for the corner trim for the Flat-Pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property UseRatioToThickness As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFlatPatternFeatureData  
Dim value As System.Boolean
```

```
instance.UseRatioToThickness = value
```

```
value = instance.UseRatioToThickness
```

C#

```
System.bool UseRatioToThickness {get; set;}
```

C++/CLI

```
property System.bool UseRatioToThickness {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the ratio to thickness setting, false to not

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFeatureData::UseRatioToThickness](#).

See Also

[IFlatPatternFeatureData Interface](#)
[IFlatPatternFeatureData Members](#)
[IFlatPatternFeatureData::GetAddCornerTrim Method](#)
[IFlatPatternFeatureData::SetAddCornerTrim Method](#)
[IFlatPatternFeatureData::CornerTrimRatioToThickness Property](#)
[IFlatPatternFeatureData::CornerTrimReliefDistance Property](#)
[IFlatPatternFeatureData::CornerTrimReliefType Property](#)
[IFlatPatternFeatureData::ShowSlitInCornerRelief Property\(\)](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

IFlatPatternFolder (Type)

IFlatPatternFolder Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFlatPatternFolder Interface

Allows access to the flat-pattern folder in the FeatureManager design tree.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IFlatPatternFolder
```

Visual Basic (Usage)

```
Dim instance As IFlatPatternFolder
```

C#

```
public interface IFlatPatternFolder
```

C++/CLI

```
public interface class IFlatPatternFolder
```

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFolder](#).

Example

[Get Flat-Pattern Folder Feature \(VBA\)](#)
[Get Flat-Pattern Folder Feature \(VB.NET\)](#)
[Get Flat-Pattern Folder Feature \(C#\)](#)

Remarks

The FeatureManager design tree of a multi-body sheet metal part created in SOLIDWORKS 2013 and later contains a flat-pattern folder with multiple flat-pattern features. This interface allows access to the flat-pattern folder.

Accessors

[IFeature::GetSpecificFeature2](#)
[IFeatureManager::GetFlatPatternFolder](#)

Access Diagram

[FlatPatternFolder](#)

See Also

[IFlatPatternFolder Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IFlatPatternFolder Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFlatPatternFolder Interface

The following tables list the members exposed by [IFlatPatternFolder](#).

Public Methods

Name	Description
 GetFeature	Gets the feature for this flat-pattern folder.
 GetFlatPatternCount	Gets the number of flat patterns in this folder.
 GetFlatPatterns	Gets the flat-pattern features in this folder.

[Top](#)

See Also

[IFlatPatternFolder Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IFlatPatternFolder Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFlatPatternFolder Interface

For a list of all members of this type, see [IFlatPatternFolder members](#).

Public Methods

Name	Description
 GetFeature	Gets the feature for this flat-pattern folder.
 GetFlatPatternCount	Gets the number of flat patterns in this folder.
 GetFlatPatterns	Gets the flat-pattern features in this folder.

[Top](#)

See Also

[IFlatPatternFolder Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFeature Method (IFlatPatternFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFolder Interface](#) : GetFeature Method (IFlatPatternFolder)

Gets the feature for this flat-pattern folder.

.NET Syntax

Visual Basic (Declaration)

Function GetFeature() As Feature

Visual Basic (Usage)



```
Dim instance As IFlatPatternFolder  
Dim value As Feature  
  
value = instance.GetFeature()
```

C#

Feature GetFeature()

C++/CLI

Feature^ GetFeature();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IFeature](#)

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFolder::GetFeature](#).

Example

See [IFlatPatternFolder](#) examples.

See Also

[IFlatPatternFolder Interface](#)
[IFlatPatternFolder Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFlatPatternCount Method (IFlatPatternFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFolder Interface](#) : GetFlatPatternCount Method (IFlatPatternFolder)

Gets the number of flat patterns in this folder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFlatPatternCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFlatPatternFolder  
Dim value As System.Integer  
  
value = instance.GetFlatPatternCount()
```

C#

```
System.int GetFlatPatternCount()
```

C++/CLI

```
System.int GetFlatPatternCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of flat patterns in this folder

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFolder::GetFlatPatternCount](#).

Example

See [IFlatPatternFolder](#) examples.

See Also

[IFlatPatternFolder Interface](#)
[IFlatPatternFolder Members](#)
[IFlatPatternFolder::GetFlatPatterns Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFlatPatterns Method (IFlatPatternFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlatPatternFolder Interface](#) : GetFlatPatterns Method (IFlatPatternFolder)

Gets the flat-pattern features in this folder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFlatPatterns() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFlatPatternFolder  
Dim value As System.Object  
  
value = instance.GetFlatPatterns()
```

C#

```
System.Object GetFlatPatterns()
```

C++/CLI

```
System.Object^ GetFlatPatterns();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [IFeatures](#)

Visual Basic for Applications (VBA) Syntax

See [FlatPatternFolder::GetFlatPatterns](#).

Example

See [IFlatPatternFolder](#) examples.

See Also

[IFlatPatternFolder Interface](#)
[IFlatPatternFolder Members](#)
[IFlatPatternFolder::GetFlatPatternCount Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

IFlyoutGroup (Type)

IFlyoutGroup Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFlyoutGroup Interface

Allows access to a flyout menu.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IFlyoutGroup
```

Visual Basic (Usage)

```
Dim instance As IFlyoutGroup
```

C#

```
public interface IFlyoutGroup
```

C++/CLI

```
public interface class IFlyoutGroup
```

Visual Basic for Applications (VBA) Syntax

See [FlyoutGroup](#).

Example

[Create Flyouts in the CommandManager \(C#\)](#)
[Create Flyouts in the CommandManager \(VB.NET\)](#)

Remarks

This interface represents a group of flyout commands that appear when a specific entity is selected in a SOLIDWORKS model.

Accessors

[ICommandManager::CreateFlyoutGroup2](#)
[ICommandManager::GetFlyoutGroup](#) and [ICommandManager::GetFlyoutGroups](#)

Access Diagram

[FlyoutGroup](#)

See Also

[IFlyoutGroup Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IFlyoutGroup Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFlyoutGroup Interface

For a list of all members of this type, see [IFlyoutGroup members](#).

Public Methods

Name	Description
 AddCommandItem	Adds an item to a flyout menu.
 AddContextMenuFlyout	Adds this flyout to the context menus of the specified documents and selections.
 RemoveAllCommandItems	Removes all command items from this flyout.
 RemoveCommandItem	Removes a command item at the specified position.
 ReplaceCommandItem	Replaces a command item at the specified position.

[Top](#)

 See Also

[IFlyoutGroup Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

IFlyoutGroup Interface Members

[See Also](#) [Properties](#) [Methods](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IFlyoutGroup Interface

The following tables list the members exposed by [IFlyoutGroup](#).

 Public Properties

Name	Description
 ButtonCount	Gets the number of buttons in this flyout.
 CmdID	Gets the command ID of this flyout.
 FlyoutType	Gets or sets the type of this flyout.
 IconList	Gets or sets the paths for the icons for the toolbar buttons for this flyout.
 LargeIconList	Obsolete. Superseded by IFlyoutGroup::IconList .
 LargeMainIcon	Obsolete. Superseded by IFlyoutGroup::MainIconList .
 MainIconList	Gets or sets the paths for the icons for the buttons for this flyout.
 SmallIconList	Obsolete. Superseded by IFlyoutGroup::IconList .
 SmallMainIcon	Obsolete. Superseded by IFlyoutGroup::MainIconList .

[Top](#)

 Public Methods

Name	Description
 AddCommandItem	Adds an item to a flyout menu.
 AddContextMenuFlyout	Adds this flyout to the context menus of the specified documents and selections.
 RemoveAllCommandItems	Removes all command items from this flyout.
 RemoveCommandItem	Removes a command item at the specified position.
 ReplaceCommandItem	Replaces a command item at the specified position.

[Top](#)

 See Also

[IFlyoutGroup Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

IFlyoutGroup Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IFlyoutGroup Interface

For a list of all members of this type, see [IFlyoutGroup members](#).

Public Properties

Name	Description
 ButtonCount	Gets the number of buttons in this flyout.
 CmdID	Gets the command ID of this flyout.
 FlyoutType	Gets or sets the type of this flyout.
 IconList	Gets or sets the paths for the icons for the toolbar buttons for this flyout.
 LargeIconList	Obsolete. Superseded by IFlyoutGroup::IconList .
 LargeMainIcon	Obsolete. Superseded by IFlyoutGroup::MainIconList .
 MainIconList	Gets or sets the paths for the icons for the buttons for this flyout.
 SmallIconList	Obsolete. Superseded by IFlyoutGroup::IconList .
 SmallMainIcon	Obsolete. Superseded by IFlyoutGroup::MainIconList .

[Top](#)

See Also

[IFlyoutGroup Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddCommandItem Method (IFlyoutGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlyoutGroup Interface](#) : AddCommandItem Method (IFlyoutGroup)

Adds an item to a flyout menu.

.NET Syntax

Visual Basic (Declaration)

```
Function AddCommandItem(  
    ByVal Name As System.String, _  
    ByVal HintString As System.String, _  
    ByVal ImageListIndex As System.Integer, _  
    ByVal CallbackFunction As System.String, _  
    ByVal UpdateCallbackFunction As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFlyoutGroup  
Dim Name As System.String  
Dim HintString As System.String  
Dim ImageListIndex As System.Integer  
Dim CallbackFunction As System.String  
Dim UpdateCallbackFunction As System.String  
Dim value As System.Integer  
  
value = instance.AddCommandItem(Name, HintString, ImageListIndex, CallbackFunction,  
UpdateCallbackFunction)
```

C#

```
System.int AddCommandItem(  
    System.string Name,  
    System.string HintString,  
    System.int ImageListIndex,  
    System.string CallbackFunction,  
    System.string UpdateCallbackFunction  
)
```

C++/CLI

```

System.int AddCommandItem(
& System.String^ Name,
& System.String^ HintString,
& System.int ImageListIndex,
& System.String^ CallbackFunction,
& System.String^ UpdateCallbackFunction
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Name of the item to add to the flyout

HintString

Text displayed in the SOLIDWORKS status bar when the pointer is on the item

ImageListIndex

Index of the image in the icon list (see **Remarks**)

CallbackFunction

Function to call when this item is selected (see **Remarks**)

UpdateCallbackFunction

Optional function that controls the state of the item; if specified, then SOLIDWORKS calls this function before displaying the item

If UpdateCallbackFunction returns...	Then SOLIDWORKS...
0	Deselects and disables the item
1	Deselects and enables the item; this is the default state if no update function is specified
2	Selects and disables the item
3	Selects and enables the item
4	Hides the item

(see **Remarks**)

Return Value

Index of the item within the flyout as assigned by SOLIDWORKS

Visual Basic for Applications (VBA) Syntax

See [FlyoutGroup::AddCommandItem](#).

Example

[Create Flyouts in the CommandManager \(C#\)](#)

[Create Flyouts in the CommandManager \(VB.NET\)](#)

Remarks

See [Add-in Callback and Enable Methods](#) to learn how to specify [CallbackFunction](#) and [UpdateCallbackFunction](#).

Flyouts are created at runtime. Call this method from the callback method defined in [ICommandManager::CreateFlyoutGroup](#).

[ImageListIndex](#) is 0-based. The size of the index is equal to the number of images in the large or small graphic file for that flyout. See [IFlyoutGroup::LargeIconList](#) and [IFlyoutGroup::SmallIconList](#) for details.

See Also

[IFlyoutGroup Interface](#)

[IFlyoutGroup Members](#)

[IFlyoutGroup::RemoveAllCommandItems Method](#)

[IFlyoutGroup::RemoveCommandItem Method](#)

[IFlyoutGroup::ReplaceCommandItem Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlyoutGroup Interface](#) : AddContextMenuFlyout Method (IFlyoutGroup)

Adds this flyout to the context menus of the specified documents and selections.

.NET Syntax

Visual Basic (Declaration)

```
Function AddContextMenuFlyout( _  
    ByVal DocumentType As System.Integer, _  
    ByVal SelectionType As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFlyoutGroup  
Dim DocumentType As System.Integer  
Dim SelectionType As System.Integer  
Dim value As System.Boolean  
  
value = instance.AddContextMenuFlyout(DocumentType, SelectionType)
```

C#

```
System.bool AddContextMenuFlyout(  
    System.int DocumentType,  
    System.int SelectionType  
)
```

C++/CLI

```
System.bool AddContextMenuFlyout(  
& System.int DocumentType,  
& System.int SelectionType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DocumentType

Type of document as defined in [swDocumentTypes_e](#)

SelectionType

Type of object as defined in [swSelectType_e](#)

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [FlyoutGroup::AddContextMenuFlyout](#).

Example

[Create Flyouts in the CommandManager \(C#\)](#)

[Create Flyouts in the CommandManager \(VB.NET\)](#)

Remarks

Call this method once for each set of DocumentType and SelectionType parameters.

Context-sensitive menus support only the standard flyout style ([swCommandFlyoutStyle_e.swCommandFlyoutStyle_Simple](#)), in which there is no immediate action on the main flyout button.

See Also

[IFlyoutGroup Interface](#)

[IFlyoutGroup Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ButtonCount Property (IFlyoutGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlyoutGroup Interface](#) : ButtonCount Property (IFlyoutGroup)

Gets the number of buttons in this flyout.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ButtonCount As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFlyoutGroup
Dim value As System.Integer

value = instance.ButtonCount
```

C#

```
System.int ButtonCount {get;}
```

C++/CLI

```
property System.int ButtonCount {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of buttons in the flyout

Visual Basic for Applications (VBA) Syntax

See [FlyoutGroup::ButtonCount](#).

Example

[Create Flyouts in the CommandManager \(C#\)](#)
[Create Flyouts in the CommandManager \(VB.NET\)](#)

See Also

[IFlyoutGroup Interface](#)
[IFlyoutGroup Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CmdID Property (IFlyoutGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlyoutGroup Interface](#) : CmdID Property (IFlyoutGroup)

Gets the command ID of this flyout.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property CmdID As System.Integer

Visual Basic (Usage)



```
Dim instance As IFlyoutGroup
Dim value As System.Integer
```

```
value = instance.CmdID
```

C#

```
System.int CmdID {get;}
```

C++/CLI

```
property System.int CmdID {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Command ID

Visual Basic for Applications (VBA) Syntax

See [FlyoutGroup::CmdID](#).

Example

[Create Flyouts in the CommandManager \(C#\)](#)
[Create Flyouts in the CommandManager \(VB.NET\)](#)

See Also

[IFlyoutGroup Interface](#)
[IFlyoutGroup Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

FlyoutType Property (IFlyoutGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlyoutGroup Interface](#) : FlyoutType Property (IFlyoutGroup)

Gets or sets the type of this flyout.

.NET Syntax

Visual Basic (Declaration)

```
Property FlyoutType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFlyoutGroup
Dim value As System.Integer
```

```
instance.FlyoutType = value
```

```
value = instance.FlyoutType
```

C#

```
System.int FlyoutType {get; set;}
```

C++/CLI

```
property System.int FlyoutType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Flyout type as defined in [swCommandFlyoutStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [FlyoutGroup::FlyoutType](#).

Example

[Create Flyouts in the CommandManager \(C#\)](#)
[Create Flyouts in the CommandManager \(VB.NET\)](#)

See Also

[IFlyoutGroup Interface](#)
[IFlyoutGroup Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IconList Property (IFlyoutGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlyoutGroup Interface](#) : IconList Property (IFlyoutGroup)

Gets or sets the paths for the icons for the toolbar buttons for this flyout.

.NET Syntax

Visual Basic (Declaration)

```
Property IconList As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFlyoutGroup  
Dim value As System.Object  
  
instance.IconList = value  
  
value = instance.IconList
```

C#

```
System.object IconList {get; set;}
```

C++/CLI

```
property System.Object^ IconList {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of strings of the paths for the icons for the toolbar buttons for this flyout (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [FlyoutGroup::IconList](#).

Example

[Create Flyouts in the CommandManager \(C#\)](#)
[Create Flyouts in the CommandManager \(VB.NET\)](#)

Remarks

This property supports scaling for high resolution screens with high resolution operating system scaling options.

The array of strings for the paths to the image files can contain icons of the following sizes:

- 20 x 20 pixels
- 32 x 32 pixels
- 40 x 40 pixels
- 64 x 64 pixels
- 96 x 96 pixels
- 128 x 128 pixels

Each image file (**.bmp** or **.png**) should contain all of the same-size icons for all of the buttons. For example:



Each icon strip should use a 256-color palette.

The order in which you specify the icons must be the same for this property and [IFlyoutGroup::MainIconList](#). For example, if you specify an array of paths to 20 x 20 pixels, 32 x 32 pixels, and 40 x 40 pixels icons for this property, then you must specify an array of paths to 20 x 20 pixels, 32 pixels, and 40 x 40 pixels icons for [IFlyoutGroup::MainIconList](#).

See Also

[IFlyoutGroup Interface](#)
[IFlyoutGroup Members](#)
[ISldWorks::GetImageSize Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LargeIconList Property (IFlyoutGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlyoutGroup Interface](#) : LargeIconList Property (IFlyoutGroup)

Obsolete. Superseded by [IFlyoutGroup::IconList](#).

.NET Syntax

Visual Basic (Declaration)

Property LargeIconList As System.String

Visual Basic (Usage)



```
Dim instance As IFlyoutGroup
Dim value As System.String

instance.LargeIconList = value
value = instance.LargeIconList
```

C#

```
System.string LargeIconList {get; set;}
```

C++/CLI

```
property System.String^ LargeIconList {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path to the bitmap or PNG containing all of the large button and separator images for this flyout

Visual Basic for Applications (VBA) Syntax

See [FlyoutGroup::LargeIconList](#).

See Also

[IFlyoutGroup Interface](#)
[IFlyoutGroup Members](#)
[IFlyoutGroup::AddCommandItem Method](#)
[IFlyoutGroup::ReplaceCommandItem Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

LargeMainIcon Property (IFlyoutGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlyoutGroup Interface](#) : LargeMainIcon Property (IFlyoutGroup)

Obsolete. Superseded by [IFlyoutGroup::MainIconList](#).

.NET Syntax

Visual Basic (Declaration)

```
Property LargeMainIcon As System.String
```

Visual Basic (Usage)



```
Dim instance As IFlyoutGroup
Dim value As System.String

instance.LargeMainIcon = value
value = instance.LargeMainIcon
```

C#

```
System.string LargeMainIcon {get; set;}
```

C++/CLI

```
property System.String^ LargeMainIcon {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path to the large bitmap or PNG used in this flyout

Visual Basic for Applications (VBA) Syntax

See [FlyoutGroup::LargeMainIcon](#).

See Also

[IFlyoutGroup Interface](#)
[IFlyoutGroup Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MainIconList Property (IFlyoutGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlyoutGroup Interface](#) : MainIconList Property (IFlyoutGroup)

Gets or sets the paths for the icons for the buttons for this flyout.

.NET Syntax

Visual Basic (Declaration)

```
Property MainIconList As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFlyoutGroup
Dim value As System.Object

instance.MainIconList = value
value = instance.MainIconList
```

C#

```
System.Object MainIconList {get; set;}
```

C++/CLI

```
property System.Object^ MainIconList {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of strings of the paths for the icons for the buttons for this flyout (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [FlyoutGroup::MainIconList](#).

Example

[Create Flyouts in the CommandManager \(C#\)](#)
[Create Flyouts in the CommandManager \(VB.NET\)](#)

Remarks

This property supports scaling for high resolution screens with high resolution operating system scaling options.

The array of strings of the paths to the image files can contain icons of the following sizes:

- 20 x 20 pixels
- 32 x 32 pixels
- 40 x 40 pixels
- 64 x 64 pixels
- 96 x 96 pixels
- 128 x128 pixels

Each image file (**.bmp** or **.png**) contains a single icon. Each icon should use a 256-color palette.

The order in which you specify the icons must be the same for this property and [IFlyoutGroup::IconList](#). For example, if you specify an array of paths to 20 x 20 pixels, 32 x 32 pixels, and 40 x 40 pixels icons for this property, then you must specify an array of paths to 20 x 20 pixels, 32 x 32 pixels, and 40 x 40 pixels icons for IFlyoutGroup::IconList.

See Also

[IFlyoutGroup Interface](#)
[IFlyoutGroup Members](#)
[ISldWorks::GetImageSize Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveAllCommandItems Method (IFlyoutGroup)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlyoutGroup Interface](#) : RemoveAllCommandItems Method (IFlyoutGroup)

Removes all command items from this flyout.

.NET Syntax

Visual Basic (Declaration)

```
Sub RemoveAllCommandItems()
```

Visual Basic (Usage)



```
Dim instance As IFlyoutGroup  
instance.RemoveAllCommandItems()
```

C#

```
void RemoveAllCommandItems()
```

C++/CLI

```
void RemoveAllCommandItems();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [FlyoutGroup::RemoveAllCommandItems](#).

Example

[Create Flyouts in the CommandManager \(C#\)](#)
[Create Flyouts in the CommandManager \(VB.NET\)](#)

See Also

[IFlyoutGroup Interface](#)
[IFlyoutGroup Members](#)
[IFlyoutGroup::RemoveCommandItem Method](#)
[IFlyoutGroup::ReplaceCommandItem Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveCommandItem Method (IFlyoutGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlyoutGroup Interface](#) : RemoveCommandItem Method (IFlyoutGroup)

Removes a command item at the specified position.

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveCommandItem( _  
    ByVal Position As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFlyoutGroup  
Dim Position As System.Integer  
Dim value As System.Boolean  
  
value = instance.RemoveCommandItem(Position)
```

C#

```
System.bool RemoveCommandItem(  
    System.int Position  
)
```

C++/CLI

```
System.bool RemoveCommandItem(  
& System.int Position  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Position

0-based index of the item to remove from the flyout

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [FlyoutGroup.RemoveCommandItem](#).

See Also

[IFlyoutGroup Interface](#)
[IFlyoutGroup Members](#)
[IFlyoutGroup.RemoveAllCommandItems Method](#)
[IFlyoutGroup.ReplaceCommandItem Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReplaceCommandItem Method (IFlyoutGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlyoutGroup Interface](#) : ReplaceCommandItem Method (IFlyoutGroup)

Replaces a command item at the specified position.

.NET Syntax

Visual Basic (Declaration)

```
Function ReplaceCommandItem( _  
    ByVal Position As System.Integer, _  
    ByVal Name As System.String, _
```

```

ByVal HintString As System.String, _
ByVal ImageListIndex As System.Integer, _
ByVal CallbackFunction As System.String, _
ByVal UpdateCallbackFunction As System.String _
) As System.Integer

```

Visual Basic (Usage)



```

Dim instance As IFlyoutGroup
Dim Position As System.Integer
Dim Name As System.String
Dim HintString As System.String
Dim ImageListIndex As System.Integer
Dim CallbackFunction As System.String
Dim UpdateCallbackFunction As System.String
Dim value As System.Integer

```

```

value = instance.ReplaceCommandItem(Position, Name, HintString, ImageListIndex, CallbackFunction,
UpdateCallbackFunction)

```

C#

```

System.int ReplaceCommandItem(
    System.int Position,
    System.string Name,
    System.string HintString,
    System.int ImageListIndex,
    System.string CallbackFunction,
    System.string UpdateCallbackFunction
)

```

C++/CLI

```

System.int ReplaceCommandItem(
    & System.int Position,
    & System.String^ Name,
    & System.String^ HintString,
    & System.int ImageListIndex,
    & System.String^ CallbackFunction,
    & System.String^ UpdateCallbackFunction
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Position

0-based index of the item to replace in the flyout

Name

Name of the item to add to the flyout

HintString

Text displayed in the SOLIDWORKS Design status bar when the pointer is on the item

ImageListIndex

Index of the image in the icon list assigned to the parent flyout (see **Remarks**)

CallbackFunction

Function to call when this item is selected

UpdateCallbackFunction

Optional function that controls the state of the item; if specified, then SOLIDWORKS Design calls this function before displaying the item

If your method returns...	Then SOLIDWORKS Design...
0	Deselects and disables the item
1	Deselects and enables the item; this is the default state if no update function is specified
2	Selects and disables the item
3	Selects and enables the item
4	Hides the item

See [FlyoutGroup::ReplaceCommandItem](#).

Remarks

ImageListIndex is 0-based. The size of the index is equal to the number of images in the large or small graphic file for that flyout. See [IFlyoutGroup::LargeIconList](#) and [IFlyoutGroup::SmallIconList](#) for details.

You can use -1 for ImageListIndex to specify that no icon is needed.

See Also

[IFlyoutGroup Interface](#)
[IFlyoutGroup Members](#)
[IFlyoutGroup::RemoveAllCommandItems Method](#)
[IFlyoutGroup::RemoveCommandItem Method](#)
[IFlyoutGroup::AddCommandItem Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SmallIconList Property (IFlyoutGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlyoutGroup Interface](#) : SmallIconList Property (IFlyoutGroup)

Obsolete. Superseded by [IFlyoutGroup::IconList](#).

.NET Syntax

Visual Basic (Declaration)

Property SmallIconList As System.String

Visual Basic (Usage)



```
Dim instance As IFlyoutGroup
Dim value As System.String

instance.SmallIconList = value

value = instance.SmallIconList
```

C#

```
System.string SmallIconList {get; set;}
```

C++/CLI

```
property System.String^ SmallIconList {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path to the bitmap or PNG containing all of the small button and separator images for this flyout

Visual Basic for Applications (VBA) Syntax

See [FlyoutGroup::SmallIconList](#).

See Also

[IFlyoutGroup Interface](#)
[IFlyoutGroup Members](#)
[IFlyoutGroup::AddCommandItem Method](#)
[IFlyoutGroup::ReplaceCommandItem Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SmallMainIcon Property (IFlyoutGroup)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFlyoutGroup Interface](#) : SmallMainIcon Property (IFlyoutGroup)

Obsolete. Superseded by [IFlyoutGroup::MainIconList](#).

.NET Syntax

Visual Basic (Declaration)

Property SmallMainIcon As System.String

Visual Basic (Usage)



```
Dim instance As IFlyoutGroup
Dim value As System.String

instance.SmallMainIcon = value
value = instance.SmallMainIcon
```

C#

```
System.string SmallMainIcon {get; set;}
```

C++/CLI

```
property System.String^ SmallMainIcon {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path to the small bitmap or PNG used in this flyout

Visual Basic for Applications (VBA) Syntax

See [FlyoutGroup::SmallMainIcon](#).

See Also

[IFlyoutGroup Interface](#)
[IFlyoutGroup Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0