

SOLIDWORKS API (.NET VBA C#) — Reference

(131/337): IGtolFrame-IHealEdgesFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IGtolFrame (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGtolFrame Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IGtolFrame Interface

Allows access to indicators and XML strings for symbols in a Gtol feature control frame.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IGtolFrame
```

Visual Basic (Usage)



```
Dim instance As IGtolFrame
```

C#

```
public interface IGtolFrame
```

C++/CLI

```
public interface class IGtolFrame
```

Visual Basic for Applications (VBA) Syntax

See [GtolFrame](#).

Example

```
'VBA
'=====
'Preconditions:
'1. Open a drawing that contains a Gtol created with either SolidWorks 2021 or SolidWorks 2022/2022+.
'2. Open an Immediate window.
'
'Postconditions:
'1. Select a Gtol in the graphics area.
' A Geometric Tolerance PropertyManager opens.
'2. Click on the macro window and press F5.
'3. Gtol format type and schema version print to the Immediate window.
'4. Press F5.
'5. The frame XML schema string prints to the Immediate window.
'6. Press F5.
'7. If the selected Gtol can be converted from 2021, it is attempted.
'8. Inspect the Immediate window.
'9. Press F5.
'10. Gets and sets From and To text and toggles SEPARATE REQUIREMENT.
'11. Inspect the Immediate window.
'12. Press F5.
'13. Gtol frames added and deleted.
'14. Inspect the Immediate window.
'15. Press F5.
'16. Add Indicator tests.
'17. Inspect the Immediate window.
'18. Press F5.
'19. Get Indicator tests.
'20. Inspect the Immediate window.
'21. Press F5.
'22. Delete Indicator tests.
'23. Inspect the Immediate window.
'24. Press F5.
'25. Miscellaneous Indicator tests.
'26. Inspect the Immediate window.
'27. Press F5.
'28. Tolerance type tests.
'29. Inspect the Immediate window.
```

'30. Press F5.

'31. Get and set symbol XML string.

'32. Inspect the Immediate window.

'=====

```
Dim swApp As SldWorks.SldWorks
Dim swModel As SldWorks.ModelDoc2
Dim boolstatus As Boolean
Dim longstatus As Long, longwarnings As Long
Dim swSelMgr As SldWorks.SelectionMgr
Dim swGtol As SldWorks.Gtol
Dim swGtolFrame As SldWorks.GtolFrame
Dim swGtolFrame1 As SldWorks.GtolFrame
Dim FrameCount As Long
Dim sXMLString As String
Dim iIndicator As Long
Dim iFrame As Long
Dim IFormatType As Long
Dim IFormatType1 As Long
Dim ISchemaVersion As Long
Dim sSchemaString As String
Dim swConversionError As SwConst.swGtolFormatConversionError_e
Dim swFromText As String
Dim swToText As String
Dim swFromText1 As String
Dim swToText1 As String
Dim IndicatorCount As Long
Dim sDatum As String
Dim IBorderType As SwConst.swGtolIndicatorBorderType_e
Dim ITolType As SwConst.swGtolGeomCharSymbol_e
Dim swToleranceType As SwConst.swGtolGeomCharSymbol_e
Dim swTolType As Long
Dim pos As Long
```

Option Explicit

Sub main()

```
Set swApp = Application.SldWorks
Set swModel = swApp.ActiveDoc
Set swSelMgr = swModel.SelectionManager
```

Stop 'in the graphics area select Gtol created with either SolidWorks 2021 or SolidWorks 2022/2022+

```
Debug.Print "Select object type as defined by swSelectType_e: " & swSelMgr.GetSelectedObjectType3(1, -1)
Set swGtol = swSelMgr.GetSelectedObject6(1, -1)
```

```
swApp.GetGtolFormatData IFormatType, ISchemaVersion
Debug.Print "Gtol format type as defined by swGtolFormatType_e: " & IFormatType
Debug.Print "Gtol schema version as defined by swGtolFormatSchemaVersion_e: " & ISchemaVersion
```

Stop

```
sSchemaString = swApp.GetGtolFrameXMLSchema
Debug.Print "Gtol frame XML schema: " & sSchemaString
```

Stop

```
boolstatus = swGtol.CanConvertFormat
If Not boolstatus = 0 Then
```

```
    IFormatType1 = swGtol.GetFormat
    If IFormatType1 = SwConst.swGtolFormatType_e.GTOL_SW2021 Then

        boolstatus = swModel.GetSaveFlag
        If boolstatus <> 0 Then
            swModel.Save
        End If
        Debug.Print "SaveFlag BEFORE ConvertFormat is called " & swModel.GetSaveFlag
        swConversionError = swGtol.ConvertFormat
        boolstatus = swModel.GetSaveFlag 'if successful, converted Gtol document should be dirty and return True
        Debug.Print "SaveFlag AFTER ConvertFormat is called " & boolstatus
        IFormatType1 = swGtol.GetFormat 'converted from 2021 to 2022
    End If
End If
```

Stop

```
boolstatus = swGtol.GetFromTo
boolstatus = swGtol.GetFromToText(swFromText, swToText)
```

```
swFromText = "FromMe"
swToText = "ToYou"
```

```

boolstatus = swGtol.SetFromToText(True, swFromText, swToText)
boolstatus = swGtol.GetFromTo

swFromText1 = ""
swToText1 = ""
boolstatus = swGtol.GetFromToText(swFromText1, swToText1) 'should be "FromMe" and "ToMe"

Debug.Print "From text: " & swFromText1
Debug.Print "To text: " & swToText1

boolstatus = swGtol.SeparateRequirement
If Not boolstatus = 0 Then
    swGtol.SeparateRequirement = False
Else
    swGtol.SeparateRequirement = True
End If

Debug.Print "SEPARATE REQUIREMENT ? " & swGtol.SeparateRequirement

Stop

FrameCount = swGtol.GetFrameCount
Debug.Print "Frame count: " & FrameCount
boolstatus = swGtol.AddFrame
FrameCount = swGtol.GetFrameCount 'frame count should increase by one
Debug.Print "Frame added. Frame count now: " & FrameCount
boolstatus = swGtol.DeleteFrame(FrameCount)
FrameCount = swGtol.GetFrameCount 'frame count should decrease by 1, as just added frame was deleted
Debug.Print "Frame deleted. Frame count now: " & FrameCount
boolstatus = swGtol.AddFrame
FrameCount = swGtol.GetFrameCount 'frame count should increase by 1
Debug.Print "Frame added. Frame count now: " & FrameCount

Stop

Set swGtolFrame = swGtol.GetFrame(FrameCount)

IndicatorCount = swGtolFrame.GetIndicatorCount

sDatum = "A"

Debug.Print " "
Debug.Print "Frame " & FrameCount & " IndicatorCount is " & IndicatorCount & ": AddIndicator test"

'supported border types: swGtolIndicatorBorderType_CollectionPlane, swGtolIndicatorBorderType_OrientationPlane
swGtolIndicatorBorderType_IntersectionPlane swGtolIndicatorBorderType_DirectionFeature
'supported tolerance types: swGcsPARALLEL swGcsPERP swGcsANG swGcsCIRCRUNOUT swGcsSYMMETRY

boolstatus = swGtolFrame.AddIndicator(SwConst.swGtolIndicatorBorderType_e.swGtolIndicatorBorderType_IntersectionPlane,
SwConst.swGtolGeomCharSymbol_e.swGcsFLAT, sDatum) 'unsupported TolType
Debug.Print "Unsupported TolType swGcsFLAT. AddIndicator return value is " & boolstatus
boolstatus = swGtolFrame.AddIndicator(SwConst.swGtolGeomCharSymbol_e.swGcsFLAT,
SwConst.swGtolGeomCharSymbol_e.swGcsSYMMETRY, sDatum) 'unsupported BorderType
Debug.Print "Unsupported BorderType swGcsFLAT. AddIndicator return value is " & boolstatus
boolstatus = swGtolFrame.AddIndicator(SwConst.swGtolIndicatorBorderType_e.swGtolIndicatorBorderType_IntersectionPlane,
SwConst.swGtolGeomCharSymbol_e.swGcsSYMMETRY, sDatum) 'supported BorderType and TolType
Debug.Print "Supported BorderType swGtolIndicatorBorderType_IntersectionPlane and TolType swGcsSYMMETRY. AddIndicator return value
is " & boolstatus

IndicatorCount = swGtolFrame.GetIndicatorCount
Debug.Print ""
Debug.Print "Frame " & FrameCount & " IndicatorCount after one successful AddIndicator is " & IndicatorCount 'should increase by 1 from
AddIndicator success
Debug.Print " "

Stop

IndicatorCount = swGtolFrame.GetIndicatorCount
iIndicator = 0
iFrame = 0
FrameCount = swGtol.GetFrameCount
Debug.Print "FrameCount is " & FrameCount & ": GetIndicator test"
For iFrame = 1 To FrameCount
    iBorderType = -1
    iTolType = -1
    sDatum = ""

    Set swGtolFrame1 = swGtol.GetFrame(iFrame)
    For iIndicator = 1 To IndicatorCount
        boolstatus = swGtolFrame1.GetIndicator(iIndicator, iBorderType, iTolType, sDatum)

```

```

        Debug.Print "Frame: " & iFrame & " Indicator index: " & iIndicator & " (BorderType as defined by swGtolIndicatorBorderType_e = " &
        IBorderType & " " & "TolType as defined by swGtolGeomCharSymbol_e = " & ITolType & " " & "Datum = " & sDatum & ")")
    Next
Next

Debug.Print " "

Stop

Debug.Print "Frame " & FrameCount & " DeleteIndicator test"
boolstatus = swGtolFrame.DeleteIndicator(IndicatorCount)
Debug.Print "DeleteIndicator return value is " & boolstatus
IndicatorCount = swGtolFrame.GetIndicatorCount 'should decrease by 1, as indicator deleted
Debug.Print "IndicatorCount is " & IndicatorCount & " after DeleteIndicator"

Stop

Debug.Print " "
Debug.Print "Miscellaneous Indicator test:"
boolstatus = swGtolFrame.AddIndicator(SwConst.swGtolIndicatorBorderType_e.swGtolIndicatorBorderType_OrientationPlane,
SwConst.swGtolGeomCharSymbol_e.swGcsANG, sDatum) 'add indicator for different BorderType and TolType
Debug.Print "Supported swGtolIndicatorBorderType_OrientationPlane BorderType AddIndicator return value is " & boolstatus
IndicatorCount = swGtolFrame.GetIndicatorCount 'should increase by 1
Debug.Print "Frame " & FrameCount & " IndicatorCount after one successful AddIndicator is " & IndicatorCount 'should increase by 1
boolstatus = swGtolFrame.GetIndicator(IndicatorCount, IBorderType, ITolType, sDatum)
Debug.Print "Frame " & FrameCount & " just added GetIndicator: " & " (BorderType = " & IBorderType & " " & "TolType = " & ITolType & " " &
"Datum = " & sDatum & ")")

    If Not sDatum = "B" Then
        sDatum = "B"
    Else
        sDatum = "A"
    End If

    boolstatus = swGtolFrame.SetIndicator(IndicatorCount,
SwConst.swGtolIndicatorBorderType_e.swGtolIndicatorBorderType_IntersectionPlane, SwConst.swGtolGeomCharSymbol_e.swGcsPERP,
sDatum)
    Debug.Print "Indicator " & IndicatorCount & " SetIndicator return value is " & boolstatus
    boolstatus = swGtolFrame.GetIndicator(IndicatorCount,
SwConst.swGtolIndicatorBorderType_e.swGtolIndicatorBorderType_IntersectionPlane, SwConst.swGtolGeomCharSymbol_e.swGcsFLAT,
sDatum)
    Debug.Print "Indicator " & IndicatorCount & " SetIndicator values " & " (BorderType = " & IBorderType & " " & "TolType = " & ITolType & " " &
"Datum = " & sDatum & ")")
    Debug.Print " "

Stop

Set swGtolFrame = swGtol.GetFrame(swGtol.GetFrameCount)
Debug.Print "Frame " & 2 & " ToleranceType test"

boolstatus = swGtolFrame.GetFrameToleranceType(swToleranceType)
Debug.Print "GetFrameToleranceType " & "returned " & boolstatus
Debug.Print "GetFrameToleranceType " & "before set returned tolerance type as defined by swGtolGeomCharSymbol_e: " & swToleranceType
boolstatus = swGtolFrame.SetFrameToleranceType(SwConst.swGtolGeomCharSymbol_e.swGcsROUND)
Debug.Print "SetFrameToleranceType " & "returned " & boolstatus
boolstatus = swGtolFrame.GetFrameToleranceType(swTolType)
Debug.Print "GetFrameToleranceType " & "returned " & boolstatus
Debug.Print "GetFrameToleranceType " & "after set returned tolerance type as defined by swGtolGeomCharSymbol_e: " & swTolType
Debug.Print ""

Stop

sXMLString = swGtolFrame.GetSymbolXml
Debug.Print "Symbol XML string: " & sXMLString

'Set a new symbol XML string of last added frame
pos = -1
pos = InStr(1, sXMLString, ".01") 'Note: converted Gtol has tolerance format of .01, not 0.01
If Not pos = -1 Then
    sXMLString = Replace(sXMLString, ".01", ".02")
Else
    pos = InStr(1, sXMLString, ".02")
    If Not pos = -1 Then
        sXMLString = Replace(sXMLString, ".02", ".01")
    End If
End If

boolstatus = swGtolFrame.SetSymbolXml(sXMLString)
Debug.Print "New symbol XML string: " & sXMLString

End Sub

```

Example

[Get Gtol Frame Information \(VB.NET\)](#)
[Get Gtol Frame Information \(C#\)](#)

Remarks

A geometric tolerance symbol adds geometric tolerances to parts and drawings using feature control frames.

This interface extends [IGtol](#) by supporting the new SOLIDWORKS 2022 Gtol architecture and providing the ability to specify Gtol frames using XML:

- Left of Gtol you can add a single line of text and symbol (first frame only).
- Above Gtol you can add multi-line text and symbol (top frame only).
- Right of Gtol there can be indicator, datum, or text box. Multiple indicators are supported, but any text box must be at the end of the list of indicators. Text box can have only one line and symbol.
- Below Gtol there can be additional frames, text, between instruction, from-to instruction, separate requirement label (bottom frame only).

For more information, see the **SOLIDWORKS Design user-interface help > Detailing and Drawings > Annotations > Symbols > Geometric Tolerance Symbols** topic.

Accessors

[IGtol::GetFrame](#)

Access Diagram

[GtolFrame](#)

See Also

[IGtolFrame Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGtolFrame Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IGtolFrame Interface

For a list of all members of this type, see [IGtolFrame members](#).

Public Methods

Name	Description
AddIndicator	Adds a tolerance indicator to the end of the list of indicators to the right of this Gtol frame.
DeleteIndicator	Deletes the tolerance indicator at the specified Gtol frame indicator index.
GetFrameToleranceType	Gets the tolerance type of this Gtol frame.
GetIndicator	Gets the indicator border type, tolerance type, and datum at the specified indicator index for this Gtol frame.
GetIndicatorCount	Gets the number of indicators in this Gtol frame.
GetSymbolXml	Gets the XML string for this Gtol frame.
SetFrameToleranceType	Sets the tolerance type for this Gtol frame.
SetIndicator	Sets the indicator border type, tolerance type, and datum at the specified indicator index on the right side of this Gtol frame.
SetSymbolXml	Sets the XML string for this Gtol frame.

[Top](#)

See Also

[IGtolFrame Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGtolFrame Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IGtolFrame Interface

The following tables list the members exposed by [IGtolFrame](#).

Public Methods		
Name	Description	
 AddIndicator	Adds a tolerance indicator to the end of the list of indicators to the right of this Gtol frame.	
 DeleteIndicator	Deletes the tolerance indicator at the specified Gtol frame indicator index.	
 GetFrameToleranceType	Gets the tolerance type of this Gtol frame.	
 GetIndicator	Gets the indicator border type, tolerance type, and datum at the specified indicator index for this Gtol frame.	
 GetIndicatorCount	Gets the number of indicators in this Gtol frame.	
 GetSymbolXml	Gets the XML string for this Gtol frame.	
 SetFrameToleranceType	Sets the tolerance type for this Gtol frame.	
 SetIndicator	Sets the indicator border type, tolerance type, and datum at the specified indicator index on the right side of this Gtol frame.	
 SetSymbolXml	Sets the XML string for this Gtol frame.	

[Top](#)

See Also

[IGtolFrame Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddIndicator Method (IGtolFrame)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGtolFrame Interface](#) : AddIndicator Method (IGtolFrame)

Adds a tolerance indicator to the end of the list of indicators to the right of this Gtol frame.

.NET Syntax	
Visual Basic (Declaration)	<pre>Function AddIndicator(_ ByVal BorderType As System.Integer, _ ByVal TolType As System.Integer, _ ByVal Datum As System.String _) As System.Boolean</pre>
Visual Basic (Usage)	<pre>Dim instance As IGtolFrame Dim BorderType As System.Integer Dim TolType As System.Integer Dim Datum As System.String Dim value As System.Boolean</pre> <pre>value = instance.AddIndicator(BorderType, TolType, Datum)</pre> 
C#	<pre>System.bool AddIndicator(System.int BorderType, System.int TolType, System.string Datum)</pre>
C++/CLI	<pre>System.bool AddIndicator(& System.int BorderType, & System.int TolType,</pre>

```
& System.String^ Datum
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BorderType

Type of border as defined by [swGtolIndicatorBorderType_e](#)

TolType

Tolerance type as defined by [swGtolGeomCharSymbol_e](#) (see **Remarks**)

Datum

Datum feature symbol that refers to the BorderType

Return Value

True if tolerance indicator successfully added, false if not

Visual Basic for Applications (VBA) Syntax

See [GtolFrame::AddIndicator](#).

Example

See the [IGtolFrame](#) examples.

Remarks

Tolerance indicators:

- define a tolerance zone within which a Gtol value applies.
- are shown to the right of the main frame, but to the left of any text box for the first frame.

TolType may be one of only swGtolGeomCharSymbol_e.:

- swGcsANG
- swGcsPARALLEL
- swGcsPERP
- swGcsCIRC RUNOUT
- swGcsSYMMETRY

See Also

[IGtolFrame Interface](#)

[IGtolFrame Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments](#) on this topic.

DeleteIndicator Method (IGtolFrame)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGtolFrame Interface](#) : DeleteIndicator Method (IGtolFrame)

Deletes the tolerance indicator at the specified Gtol frame indicator index.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteIndicator( _
    ByVal IndicatorIndex As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IGtolFrame
Dim IndicatorIndex As System.Integer
Dim value As System.Boolean
```

```
value = instance.DeleteIndicator(IndicatorIndex)
```

C#

```
System.bool DeleteIndicator(  
    System.int IndicatorIndex  
)
```

C++/CLI

```
System.bool DeleteIndicator(  
&    System.int IndicatorIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

IndicatorIndex

One-based index of tolerance indicator to delete from the frame

Return Value

True if tolerance indicator successfully deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [GtolFrame::DeleteIndicator](#).

Example

See the [IGtolFrame](#) examples.

Remarks

Before calling this method, use [IGtolFrame.GetIndicatorCount](#) to determine IndicatorIndex.

See Also

[IGtolFrame Interface](#)

[IGtolFrame Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFrameToleranceType Method (IGtolFrame)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGtolFrame Interface](#) : GetFrameToleranceType Method (IGtolFrame)

Gets the tolerance type of this Gtol frame.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFrameToleranceType( _  
    ByRef TolType As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IGtolFrame  
Dim TolType As System.Integer  
Dim value As System.Boolean
```

```
value = instance.GetFrameToleranceType(TolType)
```

C#

```
System.bool GetFrameToleranceType(  
    out System.int TolType  
)
```

C++/CLI

```
System.bool GetFrameToleranceType(  
& [Out] System.int TolType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TolType

Tolerance type as defined by [swGtolGeomCharSymbol_e](#) (see **Remarks**)

Return Value

True if Gtol frame tolerance type successfully retrieved, false if not

Visual Basic for Applications (VBA) Syntax

See [GtolFrame::GetFrameToleranceType](#).

Example

See the [IGtolFrame](#) examples.

Remarks

TolType may be one of only swGtolGeomCharSymbol_e.:

- swGcsANG
- swGcsPARALLEL
- swGcsPERP
- swGcsCIRCRUNOUT
- swGcsSYMMETRY

See Also

[IGtolFrame Interface](#)
[IGtolFrame Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetIndicator Method (IGtolFrame)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGtolFrame Interface](#) : GetIndicator Method (IGtolFrame)

Gets the indicator border type, tolerance type, and datum at the specified indicator index for this Gtol frame.

.NET Syntax

Visual Basic (Declaration)

```
Function GetIndicator( _  
    ByVal IndicatorIndex As System.Integer, _  
    ByRef BorderType As System.Integer, _  
    ByRef TolType As System.Integer, _  
    ByRef Datum As System.String _  
) As System.Boolean
```

Visual Basic (Usage)

 Copy Code

```

Dim instance As IGtolFrame
Dim IndicatorIndex As System.Integer
Dim BorderType As System.Integer
Dim TolType As System.Integer
Dim Datum As System.String
Dim value As System.Boolean

value = instance.GetIndicator(IndicatorIndex, BorderType, TolType, Datum)

```

C#

```

System.bool GetIndicator(
    System.int IndicatorIndex,
    out System.int BorderType,
    out System.int TolType,
    out System.string Datum
)

```

C++/CLI

```

System.bool GetIndicator(
    & System.int IndicatorIndex,
    & [Out] System.int BorderType,
    & [Out] System.int TolType,
    & [Out] System.String^ Datum
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

IndicatorIndex

One-based index of tolerance indicator to retrieve

BorderType

Type of border as defined by [swGtolIndicatorBorderType_e](#)

TolType

Tolerance type as defined by [swGtolGeomCharSymbol_e](#) (see **Remarks**)

Datum

Datum feature symbol that refers to the BorderType

Return Value

True if indicator successfully retrieved, false if not

Visual Basic for Applications (VBA) Syntax

See [GtolFrame::GetIndicator](#).

Example

See the [IGtolFrame](#) examples.

Remarks

Before calling this method, use [IGtolFrame.GetIndicatorCount](#) to determine IndicatorIndex.

TolType may be one of only swGtolGeomCharSymbol_e.:

- swGcsANG
- swGcsPARALLEL
- swGcsPERP
- swGcsCIRCUNOUT
- swGcsSYMMETRY

See Also

[IGtolFrame Interface](#)
[IGtolFrame Members](#)

Availability

GetIndicatorCount Method (IGtolFrame)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGtolFrame Interface](#) : GetIndicatorCount Method (IGtolFrame)

Gets the number of indicators in this Gtol frame.

.NET Syntax

Visual Basic (Declaration)

```
Function GetIndicatorCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IGtolFrame  
Dim value As System.Integer  
  
value = instance.GetIndicatorCount()
```

C#

```
System.int GetIndicatorCount()
```

C++/CLI

```
System.int GetIndicatorCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of indicators in this Gtol frame

Visual Basic for Applications (VBA) Syntax

See [GtolFrame::GetIndicatorCount](#).

Example

See the [IGtolFrame](#) examples.

Remarks

Use this method to determine IndicatorIndex parameters before calling:

- [IGtolFrame::DeleteIndicator](#)
- [IGtolFrame::GetIndicator](#)
- [IGtolFrame::SetIndicator](#)

See Also

[IGtolFrame Interface](#)
[IGtolFrame Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

GetSymbolXml Method (IGtolFrame)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGtolFrame Interface](#) : GetSymbolXml Method (IGtolFrame)

Gets the XML string for this Gtol frame.

.NET Syntax

```
Function GetSymbolXml() As System.String
```



```
Dim instance As IGtolFrame
Dim value As System.String

value = instance.GetSymbolXml()
```

```
System.string GetSymbolXml()
```

```
System.String^ GetSymbolXml();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

XML string for this Gtol frame

Visual Basic for Applications (VBA) Syntax

See [GtolFrame::GetSymbolXml](#).

Example

See the [IGtolFrame](#) examples.

Remarks

This method is valid only for Gtols created in or converted to the SOLIDWORKS 2022 format.

See [Gtol Frame XML Schema](#).

See Also

[IGtolFrame Interface](#)
[IGtolFrame Members](#)
[ISldWorks::GetGtolFrameXMLSchema Method \(\)](#)
[IGtolFrame::SetSymbolXml Method \(\)](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SetFrameToleranceType Method (IGtolFrame)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGtolFrame Interface](#) : SetFrameToleranceType Method (IGtolFrame)

Sets the tolerance type for this Gtol frame.

.NET Syntax

```
Function SetFrameToleranceType( _
    ByVal TolType As System.Integer _
) As System.Boolean
```



```
Dim instance As IGtolFrame
Dim TolType As System.Integer
Dim value As System.Boolean

value = instance.SetFrameToleranceType(TolType)
```

C#

```
System.bool SetFrameToleranceType(
    System.int TolType
)
```

C++/CLI

```
System.bool SetFrameToleranceType(
    & System.int TolType
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TolType
Tolerance type as defined by [swGtolGeomCharSymbol_e](#) (see **Remarks**)

Return Value

True if Gtol frame tolerance type successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [GtolFrame::SetFrameToleranceType](#).

Example

See the [IGtolFrame](#) examples.

Remarks

TolType may be one of only swGtolGeomCharSymbol_e.:

- swGcsANG
- swGcsPARALLEL
- swGcsPERP
- swGcsCIRCUNOUT
- swGcsSYMMETRY

See Also

[IGtolFrame Interface](#)
[IGtolFrame Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetIndicator Method (IGtolFrame)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGtolFrame Interface](#) : SetIndicator Method (IGtolFrame)

Sets the indicator border type, tolerance type, and datum at the specified indicator index on the right side of this Gtol frame.

.NET Syntax

Visual Basic (Declaration)

```
Function SetIndicator( _
    ByVal IndicatorIndex As System.Integer, _
    ByVal BorderType As System.Integer, _
```

```

    ByVal TolType As System.Integer, _
    ByVal Datum As System.String _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As IGtolFrame
Dim IndicatorIndex As System.Integer
Dim BorderType As System.Integer
Dim TolType As System.Integer
Dim Datum As System.String
Dim value As System.Boolean

value = instance.SetIndicator(IndicatorIndex, BorderType, TolType, Datum)

```

C#

```

System.bool SetIndicator(
    System.int IndicatorIndex,
    System.int BorderType,
    System.int TolType,
    System.string Datum
)

```

C++/CLI

```

System.bool SetIndicator(
    & System.int IndicatorIndex,
    & System.int BorderType,
    & System.int TolType,
    & System.String^ Datum
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

IndicatorIndex

One-based index of Gtol frame indicator to set

BorderType

Type of border as defined by [swGtolIndicatorBorderType_e](#)

TolType

Tolerance type as defined by [swGtolGeomCharSymbol_e](#) (see **Remarks**)

Datum

Datum feature symbol that refers to the BorderType

Return Value

True if indicator successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [GtolFrame::SetIndicator](#).

Example

See the [IGtolFrame](#) examples.

Remarks

Before calling this method, use [IGtolFrame::GetIndicatorCount](#) to determine IndicatorIndex.

TolType may be one of only swGtolGeomCharSymbol_e.:

- swGcsANG
- swGcsPARALLEL
- swGcsPERP
- swGcsCIRCRUNOUT
- swGcsSYMMETRY

See Also

[IGtolFrame Interface](#)
[IGtolFrame Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetSymbolXml Method (IGtolFrame)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGtolFrame Interface](#) : SetSymbolXml Method (IGtolFrame)

Sets the XML string for this Gtol frame.

.NET Syntax

Visual Basic (Declaration)

```
Function SetSymbolXml( _  
    ByVal Xmlstring As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IGtolFrame  
Dim Xmlstring As System.String  
Dim value As System.Boolean  
  
value = instance.SetSymbolXml(Xmlstring)
```

C#

```
System.bool SetSymbolXml(  
    System.string Xmlstring  
)
```

C++/CLI

```
System.bool SetSymbolXml(  
& System.String^ Xmlstring  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Xmlstring
XML string

Return Value

True if XML string successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [GtolFrame::SetSymbolXml](#).

Example

See the [IGtolFrame](#) examples.

Remarks

This method is valid only for Gtols created in or converted to the SOLIDWORKS 2022 format.

See [Gtol Frame XML Schema](#).

See Also

[IGtolFrame Interface](#)
[IGtolFrame Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

IGussetFeatureData (Type)

IGussetFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IGussetFeatureData Interface

Allows access to a weldment gusset feature.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IGussetFeatureData
```

Visual Basic (Usage)

```
Dim instance As IGussetFeatureData
```

C#

```
public interface IGussetFeatureData
```

C++/CLI

```
public interface class IGussetFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [GussetFeatureData](#).

Example

[Get Gusset Feature Data \(C#\)](#)
[Get Gusset Feature Data \(VB.NET\)](#)
[Get Gusset Feature Data \(VBA\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[GussetFeatureData](#)

See Also

[IGussetFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertGussetFeature Method](#)
[IFeatureManager::InsertGussetFeature2 Method](#)

IGussetFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IGussetFeatureData Interface

For a list of all members of this type, see [IGussetFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this gusset feature.
GetSupportingFaces	Gets the two, adjacent, supporting faces for this gusset feature.

		
	ReleaseSelectionAccess	Releases access to the selections that define this gusset feature.
	SetSupportingFaces	Sets the two, adjacent, supporting faces for this gusset feature.

[Top](#)

See Also

[IGussetFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertGussetFeature Method](#)
[IFeatureManager::InsertGussetFeature2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGussetFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IGussetFeatureData Interface

The following tables list the members exposed by [IGussetFeatureData](#).

Public Properties

Name	Description
 FlipOffsetDirection	Gets or sets whether the offset direction is flipped for this gusset feature.
 FlipProfileDistanceParameters	Gets or sets whether the Profile Distance 1 and Profile Distance 2 parameters are flipped for this gusset feature.
 OffsetUsed	Gets or sets whether offset is used to locate the profile for this gusset feature.
 ProfileAngle	Gets or sets the profile angle for this gusset feature.
 ProfileDistance1	Gets or sets the distance for the Profile Distance 1 parameter for this gusset feature.
 ProfileDistance2	Gets or sets the distance for the Profile Distance 2 parameter for this gusset feature.
 ProfileDistance3	Gets or sets the distance for the Profile Distance 3 parameter for this gusset feature.
 ProfileDistance4	Gets or sets the distance for the Profile Distance 4 parameter for this gusset feature.
 ProfileLocation	Gets or sets where to locate the profile for this gusset feature.
 ProfileOffsetDistance	Gets or sets the offset distance of the profile for this gusset feature.
 ProfileType	Gets or sets the type of profile for this gusset feature.
 Thickness	Gets or sets the thickness for this gusset feature.
 ThicknessType	Gets or sets the type of thickness for this gusset feature.
 UseAngle	Gets or sets whether an angle is used for specifying the dimensions of the polygonal profile for this gusset feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this gusset feature.
 GetSupportingFaces	Gets the two, adjacent, supporting faces for this gusset feature.
 ReleaseSelectionAccess	Releases access to the selections that define this gusset feature.
 SetSupportingFaces	Sets the two, adjacent, supporting faces for this gusset feature.

[Top](#)

See Also

[IGussetFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertGussetFeature Method](#)
[IFeatureManager::InsertGussetFeature2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGussetFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IGussetFeatureData Interface

For a list of all members of this type, see [IGussetFeatureData members](#).

 Public Properties

Name	Description
 FlipOffsetDirection	Gets or sets whether the offset direction is flipped for this gusset feature.
 FlipProfileDistanceParameters	Gets or sets whether the Profile Distance 1 and Profile Distance 2 parameters are flipped for this gusset feature.
 OffsetUsed	Gets or sets whether offset is used to locate the profile for this gusset feature.
 ProfileAngle	Gets or sets the profile angle for this gusset feature.
 ProfileDistance1	Gets or sets the distance for the Profile Distance 1 parameter for this gusset feature.
 ProfileDistance2	Gets or sets the distance for the Profile Distance 2 parameter for this gusset feature.
 ProfileDistance3	Gets or sets the distance for the Profile Distance 3 parameter for this gusset feature.
 ProfileDistance4	Gets or sets the distance for the Profile Distance 4 parameter for this gusset feature.
 ProfileLocation	Gets or sets where to locate the profile for this gusset feature.
 ProfileOffsetDistance	Gets or sets the offset distance of the profile for this gusset feature.
 ProfileType	Gets or sets the type of profile for this gusset feature.
 Thickness	Gets or sets the thickness for this gusset feature.
 ThicknessType	Gets or sets the type of thickness for this gusset feature.
 UseAngle	Gets or sets whether an angle is used for specifying the dimensions of the polygonal profile for this gusset feature.

[Top](#)

 See Also

[IGussetFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertGussetFeature Method](#)
[IFeatureManager::InsertGussetFeature2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IGussetFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGussetFeatureData Interface](#) : AccessSelections Method (IGussetFeatureData)

Gains access to the selections that define this gusset feature.

 .NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IGussetFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    ModelDoc2 TopDoc,
```



```
        Component2 Component
    )
```

C++/CLI

```
System.bool AccessSelections(
&    ModelDoc2^ TopDoc,
&    Component2^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [GussetFeatureData::AccessSelections](#).

Example

[Get Gusset Feature Data \(C#\)](#)

[Get Gusset Feature Data \(VB.NET\)](#)

[Get Gusset Feature Data \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is Nothing or null
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IGussetFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IGussetFeatureData Interface](#)

[IGussetFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FlipOffsetDirection Property (IGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGussetFeatureData Interface](#) : FlipOffsetDirection Property (IGussetFeatureData)

Gets or sets whether the offset direction is flipped for this gusset feature.

.NET Syntax

Visual Basic (Declaration)

Property FlipOffsetDirection As System.Boolean

Visual Basic (Usage)

```
Dim instance As IGussetFeatureData
Dim value As System.Boolean
```



```
instance.FlipOffsetDirection = value  
value = instance.FlipOffsetDirection
```

C#

```
System.bool FlipOffsetDirection {get; set;}
```

C++/CLI

```
property System.bool FlipOffsetDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flip the offset direction, false to not

Visual Basic for Applications (VBA) Syntax

See [GussetFeatureData::FlipOffsetDirection](#).

See Also

[IGussetFeatureData Interface](#)
[IGussetFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FlipProfileDistanceParameters Property (IGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGussetFeatureData Interface](#) : FlipProfileDistanceParameters Property (IGussetFeatureData)

Gets or sets whether the **Profile Distance 1** and **Profile Distance 2** parameters are flipped for this gusset feature.

.NET Syntax

Visual Basic (Declaration)

```
Property FlipProfileDistanceParameters As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IGussetFeatureData  
Dim value As System.Boolean  
  
instance.FlipProfileDistanceParameters = value  
value = instance.FlipProfileDistanceParameters
```

C#

```
System.bool FlipProfileDistanceParameters {get; set;}
```

C++/CLI

```
property System.bool FlipProfileDistanceParameters {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flip **Profile Distance 1** and **Profile Distance 2** parameters, false to not

Visual Basic for Applications (VBA) Syntax

See [GussetFeatureData::FlipProfileDistanceParameters](#).

See Also

[IGussetFeatureData Interface](#)
[IGussetFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetSupportingFaces Method (IGussetFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGussetFeatureData Interface](#) : GetSupportingFaces Method (IGussetFeatureData)

Gets the two, adjacent, supporting faces for this gusset feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSupportingFaces( _  
    ByRef PFace1 As Face2, _  
    ByRef PFace2 As Face2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IGussetFeatureData  
Dim PFace1 As Face2  
Dim PFace2 As Face2  
Dim value As System.Boolean  
  
value = instance.GetSupportingFaces(PFace1, PFace2)
```

C#

```
System.bool GetSupportingFaces(  
    out Face2 PFace1,  
    out Face2 PFace2  
)
```

C++/CLI

```
System.bool GetSupportingFaces(  
& [Out] Face2^ PFace1,  
& [Out] Face2^ PFace2  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFace1
Pointer to the first [IFace2](#) object
PFace2
Pointer to the second [IFace2](#) object

Return Value

True if both faces are returned, false if not

Visual Basic for Applications (VBA) Syntax

See [IGussetFeatureData::GetSupportingFaces](#).

Example

[Get Gusset Feature Data \(C#\)](#)
[Get Gusset Feature Data \(VB.NET\)](#)
[Get Gusset Feature Data \(VBA\)](#)

See Also

[IGussetFeatureData Interface](#)
[IGussetFeatureData Members](#)
[IGussetFeatureData::SetSupportingFaces Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

OffsetUsed Property (IGussetFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGussetFeatureData Interface](#) : OffsetUsed Property (IGussetFeatureData)

Gets or sets whether offset is used to locate the profile for this gusset feature.

.NET Syntax

Visual Basic (Declaration)

Property OffsetUsed As System.Boolean

Visual Basic (Usage)



```
Dim instance As IGussetFeatureData
Dim value As System.Boolean

instance.OffsetUsed = value
value = instance.OffsetUsed
```

C#

```
System.bool OffsetUsed {get; set;}
```

C++/CLI

```
property System.bool OffsetUsed {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if offset is used, false if not

Visual Basic for Applications (VBA) Syntax

See [GussetFeatureData::OffsetUsed](#).

Example

[Get Gusset Feature Data \(C#\)](#)
[Get Gusset Feature Data \(VB.NET\)](#)
[Get Gusset Feature Data \(VBA\)](#)

See Also

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ProfileAngle Property (IGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGussetFeatureData Interface](#) : ProfileAngle Property (IGussetFeatureData)

Gets or sets the profile angle for this gusset feature.

.NET Syntax

Visual Basic (Declaration)

Property ProfileAngle As System.Double

Visual Basic (Usage)



```
Dim instance As IGussetFeatureData  
Dim value As System.Double
```

```
instance.ProfileAngle = value
```

```
value = instance.ProfileAngle
```

C#

```
System.double ProfileAngle {get; set;}
```

C++/CLI

```
property System.double ProfileAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle

Visual Basic for Applications (VBA) Syntax

See [GussetFeatureData::ProfileAngle](#).

Remarks

[IGussetFeatureData::ProfileType](#) must be set to swGussetProfilePolygon.

See Also

[IGussetFeatureData Interface](#)
[IGussetFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ProfileDistance1 Property (IGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGussetFeatureData Interface](#) : ProfileDistance1 Property (IGussetFeatureData)

Gets or sets the distance for the **Profile Distance 1** parameter for this gusset feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property ProfileDistance1 As System.Double
```

Visual Basic (Usage)



```
Dim instance As IGussetFeatureData
Dim value As System.Double

instance.ProfileDistance1 = value
value = instance.ProfileDistance1
```

C#

```
System.double ProfileDistance1 {get; set;}
```

C++/CLI

```
property System.double ProfileDistance1 {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance

Visual Basic for Applications (VBA) Syntax

See [GussetFeatureData::ProfileDistance1](#).

Remarks

[IGussetFeatureData::ProfileType](#) must be set to swGussetProfilePolygon.

See Also

[IGussetFeatureData Interface](#)
[IGussetFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ProfileDistance2 Property (IGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGussetFeatureData Interface](#) : ProfileDistance2 Property (IGussetFeatureData)

Gets or sets the distance for the **Profile Distance 2** parameter for this gusset feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property ProfileDistance2 As System.Double
```

Visual Basic (Usage)



```
Dim instance As IGussetFeatureData
Dim value As System.Double
```

```
instance.ProfileDistance2 = value  
value = instance.ProfileDistance2
```

C#

```
System.double ProfileDistance2 {get; set;}
```

C++/CLI

```
property System.double ProfileDistance2 {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance

Visual Basic for Applications (VBA) Syntax

See [GussetFeatureData::ProfileDistance2](#).

See Also

[IGussetFeatureData Interface](#)
[IGussetFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProfileDistance3 Property (IGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGussetFeatureData Interface](#) : ProfileDistance3 Property (IGussetFeatureData)

Gets or sets the distance for the **Profile Distance 3** parameter for this gusset feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ProfileDistance3 As System.Double
```

Visual Basic (Usage)



```
Dim instance As IGussetFeatureData  
Dim value As System.Double
```

```
instance.ProfileDistance3 = value  
value = instance.ProfileDistance3
```

C#

```
System.double ProfileDistance3 {get; set;}
```

C++/CLI

```
property System.double ProfileDistance3 {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance

Visual Basic for Applications (VBA) Syntax

See [GussetFeatureData::ProfileDistance3](#).

Remarks

[IGussetFeatureData::ProfileType](#) must be set to swGussetProfilePolygon.

See Also

[IGussetFeatureData Interface](#)
[IGussetFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProfileDistance4 Property (IGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGussetFeatureData Interface](#) : ProfileDistance4 Property (IGussetFeatureData)

Gets or sets the distance for the **Profile Distance 4** parameter for this gusset feature.

.NET Syntax

Visual Basic (Declaration)

Property ProfileDistance4 As System.Double

Visual Basic (Usage)



```
Dim instance As IGussetFeatureData  
Dim value As System.Double
```

```
instance.ProfileDistance4 = value
```

```
value = instance.ProfileDistance4
```

C#

```
System.double ProfileDistance4 {get; set;}
```

C++/CLI

```
property System.double ProfileDistance4 {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance

Visual Basic for Applications (VBA) Syntax

See [GussetFeatureData::ProfileDistance4](#).

Remarks

[IGussetFeatureData::ProfileType](#) must be set to swGussetProfilePolygon.

See Also

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProfileLocation Property (IGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGussetFeatureData Interface](#) : ProfileLocation Property (IGussetFeatureData)

Gets or sets where to locate the profile for this gusset feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ProfileLocation As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IGussetFeatureData  
Dim value As System.Integer
```

```
instance.ProfileLocation = value
```

```
value = instance.ProfileLocation
```

C#

```
System.int ProfileLocation {get; set;}
```

C++/CLI

```
property System.int ProfileLocation {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Location of profile as defined by [swGussetProfileLocationType_e](#)

Visual Basic for Applications (VBA) Syntax

See [GussetFeatureData::ProfileLocation](#).

See Also

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProfileOffsetDistance Property (IGussetFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGussetFeatureData Interface](#) : ProfileOffsetDistance Property (IGussetFeatureData)

Gets or sets the offset distance of the profile for this gusset feature.

.NET Syntax

Visual Basic (Declaration)

Property ProfileOffsetDistance As System.Double

Visual Basic (Usage)



```
Dim instance As IGussetFeatureData
Dim value As System.Double

instance.ProfileOffsetDistance = value
value = instance.ProfileOffsetDistance
```

C#

```
System.double ProfileOffsetDistance {get; set;}
```

C++/CLI

```
property System.double ProfileOffsetDistance {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance

Visual Basic for Applications (VBA) Syntax

See [GussetFeatureData::ProfileOffsetDistance](#).

Example

[Get Gusset Feature Data \(C#\)](#)
[Get Gusset Feature Data \(VB.NET\)](#)
[Get Gusset Feature Data \(VBA\)](#)

Remarks

[IGussetFeatureData::OffsetUsed](#) must be set to True.

See Also

[IGussetFeatureData Interface](#)
[IGussetFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ProfileType Property (IGussetFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGussetFeatureData Interface](#) : ProfileType Property (IGussetFeatureData)

Gets or sets the type of profile for this gusset feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ProfileType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IGussetFeatureData
Dim value As System.Integer

instance.ProfileType = value

value = instance.ProfileType
```

C#

```
System.int ProfileType {get; set;}
```

C++/CLI

```
property System.int ProfileType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of profile as defined in [swGussetProfileType_e](#)

Visual Basic for Applications (VBA) Syntax

See [GussetFeatureData::ProfileType](#).

Example

[Get Gusset Feature Data \(C#\)](#)
[Get Gusset Feature Data \(VB.NET\)](#)
[Get Gusset Feature Data \(VBA\)](#)

See Also

[IGussetFeatureData Interface](#)
[IGussetFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IGussetFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGussetFeatureData Interface](#) : ReleaseSelectionAccess Method (IGussetFeatureData)

Releases access to the selections that define this gusset feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IGussetFeatureData

instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [IGussetFeatureData::ReleaseSelectionAccess](#).

Example

[Get Gusset Feature Data \(C#\)](#)
[Get Gusset Feature Data \(VB.NET\)](#)
[Get Gusset Feature Data \(VBA\)](#)

Remarks

[IGussetFeatureData::AccessSelections](#) puts the model into a rollback state to allow access to the selections that define this gusset feature.

Use this method to restore the rollback state if you did not modify the gusset feature, or use [IFeature::ModifyDefinition](#) if you did modify the gusset feature.

See Also

[IGussetFeatureData Interface](#)
[IGussetFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetSupportingFaces Method (IGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGussetFeatureData Interface](#) : SetSupportingFaces Method (IGussetFeatureData)

Sets the two, adjacent, supporting faces for this gusset feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetSupportingFaces( _  
    ByVal PFace1 As Face2, _  
    ByVal PFace2 As Face2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IGussetFeatureData  
Dim PFace1 As Face2  
Dim PFace2 As Face2  
Dim value As System.Boolean  
  
value = instance.SetSupportingFaces(PFace1, PFace2)
```

C#

```
System.bool SetSupportingFaces(  
    Face2 PFace1,  
    Face2 PFace2  
)
```

C++/CLI

```
System.bool SetSupportingFaces(  
& Face2^ PFace1,
```

& Face2^ [PFace2](#)
)

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFace1

Pointer to the first [IFace2](#) object

PFace2

Pointer to the second [IFace2](#) object

Return Value

True if the supporting faces are set, false if not

Visual Basic for Applications (VBA) Syntax

See [GussetFeatureData::SetSupportingFaces](#).

See Also

[IGussetFeatureData Interface](#)

[IGussetFeatureData Members](#)

[IGussetFeatureData::GetSupportingFaces Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Thickness Property (IGussetFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGussetFeatureData Interface](#) : Thickness Property (IGussetFeatureData)

Gets or sets the thickness for this gusset feature.

.NET Syntax

Visual Basic (Declaration)

Property Thickness As System.Double

Visual Basic (Usage)



```
Dim instance As IGussetFeatureData  
Dim value As System.Double
```

```
instance.Thickness = value
```

```
value = instance.Thickness
```

C#

```
System.double Thickness {get; set;}
```

C++/CLI

```
property System.double Thickness {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Thickness

Visual Basic for Applications (VBA) Syntax

See [GussetFeatureData::Thickness](#).

Example

[Get Gusset Feature Data \(C#\)](#)
[Get Gusset Feature Data \(VB.NET\)](#)
[Get Gusset Feature Data \(VBA\)](#)

See Also

[IGussetFeatureData Interface](#)
[IGussetFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ThicknessType Property (IGussetFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGussetFeatureData Interface](#) : ThicknessType Property (IGussetFeatureData)

Gets or sets the type of thickness for this gusset feature.

.NET Syntax

Visual Basic (Declaration)

Property ThicknessType As System.Integer

Visual Basic (Usage)



```
Dim instance As IGussetFeatureData
Dim value As System.Integer
```

```
instance.ThicknessType = value
```

```
value = instance.ThicknessType
```

C#

```
System.int ThicknessType {get; set;}
```

C++/CLI

```
property System.int ThicknessType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of thickness as defined in [swGussetThicknessType_e](#)

Visual Basic for Applications (VBA) Syntax

See [GussetFeatureData::ThicknessType](#).

Example

[Get Gusset Feature Data \(C#\)](#)
[Get Gusset Feature Data \(VB.NET\)](#)
[Get Gusset Feature Data \(VBA\)](#)

See Also

[IGussetFeatureData Interface](#)
[IGussetFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseAngle Property (IGussetFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IGussetFeatureData Interface](#) : UseAngle Property (IGussetFeatureData)

Gets or sets whether an angle is used for specifying the dimensions of the polygonal profile for this gusset feature.

.NET Syntax

Visual Basic (Declaration)

Property UseAngle As System.Boolean

Visual Basic (Usage)



```
Dim instance As IGussetFeatureData
Dim value As System.Boolean
```

```
instance.UseAngle = value
```

```
value = instance.UseAngle
```

C#

```
System.bool UseAngle {get; set;}
```

C++/CLI

```
property System.bool UseAngle {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if an angle is used, false if not

Visual Basic for Applications (VBA) Syntax

See [GussetFeatureData::UseAngle](#).

Remarks

[IGussetFeatureData::ProfileType](#) must be set to swGussetProfilePolygon.

See Also

[IGussetFeatureData Interface](#)
[IGussetFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

IHealEdgesFeatureData (Type)

IHealEdgesFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHealEdgesFeatureData Interface

Allows access to a heal edges feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IHealEdgesFeatureData

Visual Basic (Usage)



Dim instance As [IHealEdgesFeatureData](#)

C#

public interface IHealEdgesFeatureData

C++/CLI

public interface class IHealEdgesFeatureData

Visual Basic for Applications (VBA) Syntax

See [HealEdgesFeatureData](#).

Example

[Modify Heal Edges Feature \(VBA\)](#)
[Get Heal Edges Feature Data \(C#\)](#)
[Get Heal Edges Feature Data \(VB.NET\)](#)
[Get Heal Edges Feature Data \(VBA\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[HealEdgesFeatureData](#)

See Also

[IHealEdgesFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IHealEdgesFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHealEdgesFeatureData Interface

The following tables list the members exposed by [IHealEdgesFeatureData](#).

Public Properties

Name	Description
 AngularTolerance	Gets or sets the maximum angle between the edges to merge.
 EdgeLengthTolerance	Gets or sets the maximum length of the edges to merge.



Faces

Gets the faces whose edges were healed or sets the faces whose edges you want healed.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that describe this heal edges feature.
 GetEdgeInformation	Gets the number of edges before healing and the number of edges after healing.
 GetFacesCount	Gets the number of faces for this heal edges feature.
 HealEdges	Merges the edges using the specified faces and tolerances.
 IGetFaces	Gets the faces whose edges to heal.
 ISetFaces	Gets the faces whose edges were healed.
 ReleaseSelectionAccess	Releases access to the selections that describe this heal edges feature.

[Top](#)

See Also

[IHealEdgesFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IHealEdgesFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHealEdgesFeatureData Interface

For a list of all members of this type, see [IHealEdgesFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that describe this heal edges feature.
 GetEdgeInformation	Gets the number of edges before healing and the number of edges after healing.
 GetFacesCount	Gets the number of faces for this heal edges feature.
 HealEdges	Merges the edges using the specified faces and tolerances.
 IGetFaces	Gets the faces whose edges to heal.
 ISetFaces	Gets the faces whose edges were healed.
 ReleaseSelectionAccess	Releases access to the selections that describe this heal edges feature.

[Top](#)

See Also

[IHealEdgesFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IHealEdgesFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHealEdgesFeatureData Interface

For a list of all members of this type, see [IHealEdgesFeatureData members](#).

Public Properties

Name	Description
 AngularTolerance	Gets or sets the maximum angle between the edges to merge.
 EdgeLengthTolerance	Gets or sets the maximum length of the edges to merge.



Faces

Gets the faces whose edges were healed or sets the faces whose edges you want healed.

[Top](#)

See Also

[IHealEdgesFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IHealEdgesFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHealEdgesFeatureData Interface](#) : AccessSelections Method (IHealEdgesFeatureData)

Gains access to the selections that describe this heal edges feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections(  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHealEdgesFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections are accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [HealEdgesFeatureData::AccessSelections](#).

Example

[Modify Heal Edges Feature \(VBA\)](#)
[Get Heal Edges Feature Data \(C#\)](#)
[Get Heal Edges Feature Data \(VB.NET\)](#)
[Get Heal Edges Feature Data \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is Nothing or null
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IHealEdgesFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IHealEdgesFeatureData Interface](#)
[IHealEdgesFeatureData Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AngularTolerance Property (IHealEdgesFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHealEdgesFeatureData Interface](#) : AngularTolerance Property (IHealEdgesFeatureData)

Gets or sets the maximum angle between the edges to merge.

.NET Syntax

Visual Basic (Declaration)

Property AngularTolerance As System.Double

Visual Basic (Usage)



```
Dim instance As IHealEdgesFeatureData  
Dim value As System.Double
```

```
instance.AngularTolerance = value
```

```
value = instance.AngularTolerance
```

C#

```
System.double AngularTolerance {get; set;}
```

C++/CLI

```
property System.double AngularTolerance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Maximum angle between the edges to merge

Visual Basic for Applications (VBA) Syntax

See [HealEdgesFeatureData::AngularTolerance](#).

Example

[Get Heal Edges Feature Data \(C#\)](#)
[Get Heal Edges Feature Data \(VB.NET\)](#)
[Get Heal Edges Feature Data \(VBA\)](#)

See Also

[IHealEdgesFeatureData Interface](#)
[IHealEdgesFeatureData Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EdgeLengthTolerance Property (IHealEdgesFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHealEdgesFeatureData Interface](#) : EdgeLengthTolerance Property (IHealEdgesFeatureData)

Gets or sets the maximum length of the edges to merge.

.NET Syntax

Visual Basic (Declaration)

Property EdgeLengthTolerance As System.Double

Visual Basic (Usage)



```
Dim instance As IHealEdgesFeatureData  
Dim value As System.Double
```

```
instance.EdgeLengthTolerance = value
```

```
value = instance.EdgeLengthTolerance
```

C#

```
System.double EdgeLengthTolerance {get; set;}
```

C++/CLI

```
property System.double EdgeLengthTolerance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Maximum length of the edges to merge

Visual Basic for Applications (VBA) Syntax

See [HealEdgesFeatureData::EdgeLengthTolerance](#).

Example

[Get Heal Edges Feature Data \(C#\)](#)
[Get Heal Edges Feature Data \(VB.NET\)](#)
[Get Heal Edges Feature Data \(VBA\)](#)

See Also

[IHealEdgesFeatureData Interface](#)
[IHealEdgesFeatureData Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Faces Property (IHealEdgesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHealEdgesFeatureData Interface](#) : Faces Property (IHealEdgesFeatureData)

Gets the faces whose edges were healed or sets the faces whose edges you want healed.

.NET Syntax

Visual Basic (Declaration)

Property Faces As System.Object

Visual Basic (Usage)



```
Dim instance As IHealEdgesFeatureData  
Dim value As System.Object
```

```
instance.Faces = value
```

```
value = instance.Faces
```

C#

```
System.Object Faces {get; set;}
```

C++/CLI

```
property System.Object^ Faces {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [faces](#)

Visual Basic for Applications (VBA) Syntax

See [HealEdgesFeatureData::Faces](#).

See Also

[IHealEdgesFeatureData Interface](#)
[IHealEdgesFeatureData Members](#)
[IHealEdgesFeatureData::GetFaces Method](#)
[IHealEdgesFeatureData::SetFaces Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEdgeInformation Method (IHealEdgesFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHealEdgesFeatureData Interface](#) : GetEdgeInformation Method (IHealEdgesFeatureData)

Gets the number of edges before healing and the number of edges after healing.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetEdgeInformation( _  
    ByRef EdgeCountBefore As System.Integer, _  
    ByRef EdgeCountAfter As System.Integer _  
)
```

```
Dim instance As IHealEdgesFeatureData
Dim EdgeCountBefore As System.Integer
Dim EdgeCountAfter As System.Integer

instance.GetEdgeInformation(EdgeCountBefore, EdgeCountAfter)
```

C#

```
void GetEdgeInformation(
    out System.int EdgeCountBefore,
    out System.int EdgeCountAfter
)
```

C++/CLI

```
void GetEdgeInformation(
    & [Out] System.int EdgeCountBefore,
    & [Out] System.int EdgeCountAfter
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EdgeCountBefore

Number of edges before healing

EdgeCountAfter

Number of edges after healing

Visual Basic for Applications (VBA) Syntax

See [HealEdgesFeatureData::GetEdgeInformation](#).

Example

[Modify Heal Edges Feature \(VBA\)](#)
[Get Heal Edges Feature Data \(C#\)](#)
[Get Heal Edges Feature Data \(VB.NET\)](#)
[Get Heal Edges Feature Data \(VBA\)](#)

See Also

[IHealEdgesFeatureData Interface](#)
[IHealEdgesFeatureData Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFacesCount Method (IHealEdgesFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHealEdgesFeatureData Interface](#) : GetFacesCount Method (IHealEdgesFeatureData)

Gets the number of faces for this heal edges feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFacesCount() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IHealEdgesFeatureData
Dim value As System.Integer
```

```
value = instance.GetFacesCount()
```

C#

```
System.int GetFacesCount()
```

C++/CLI

```
System.int GetFacesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of faces

 Visual Basic for Applications (VBA) Syntax

See [HealEdgesFeatureData::GetFacesCount](#).

 Example

[Get Heal Edges Feature Data \(C#\)](#)
[Get Heal Edges Feature Data \(VB.NET\)](#)
[Get Heal Edges Feature Data \(VBA\)](#)

 Remarks

Call this method before calling [IHealEdgesFeatureData::IGetFaces](#).

 See Also

[IHealEdgesFeatureData Interface](#)
[IHealEdgesFeatureData Members](#)

 Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

HealEdges Method (IHealEdgesFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHealEdgesFeatureData Interface](#) : HealEdges Method (IHealEdgesFeatureData)

Merges the edges using the specified faces and tolerances.

 .NET Syntax

Visual Basic (Declaration)

```
Sub HealEdges()
```

Visual Basic (Usage)

```
Dim instance As IHealEdgesFeatureData  
instance.HealEdges()
```

C#

```
void HealEdges()
```

C++/CLI

```
void HealEdges();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).



Copy Code

Visual Basic for Applications (VBA) Syntax

See [HealEdgesFeatureData::HealEdges](#).

Example

[Modify Heal Edges Feature \(VBA\)](#)

See Also

[IHealEdgesFeatureData Interface](#)
[IHealEdgesFeatureData Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFaces Method (IHealEdgesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHealEdgesFeatureData Interface](#) : IGetFaces Method (IHealEdgesFeatureData)

Gets the faces whose edges to heal.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFaces( _  
    ByVal Count As System.Integer _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As IHealEdgesFeatureData  
Dim Count As System.Integer  
Dim value As Face2
```

```
value = instance.IGetFaces(Count)
```

C#

```
Face2 IGetFaces(  
    System.int Count  
)
```

C++/CLI

```
Face2^ IGetFaces(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of faces whose edges to heal

Return Value

- in-process, unmanaged C++: Pointer to an array of [faces](#) whose edges to heal
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [IHealEdgesFeatureData::GetFacesCount](#) before using this method.

See Also

[IHealEdgesFeatureData Interface](#)
[IHealEdgesFeatureData Members](#)
[IHealEdgesFeatureData::ISetFaces Method](#)
[IHealEdgesFeatureData::Faces Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetFaces Method (IHealEdgesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHealEdgesFeatureData Interface](#) : ISetFaces Method (IHealEdgesFeatureData)

Gets the faces whose edges were healed.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetFaces( _  
    ByVal Count As System.Integer, _  
    ByRef EntIn As Face2 _  
)
```

Visual Basic (Usage)



```
Dim instance As IHealEdgesFeatureData  
Dim Count As System.Integer  
Dim EntIn As Face2  
  
instance.ISetFaces(Count, EntIn)
```

C#

```
void ISetFaces(  
    System.int Count,  
    ref Face2 EntIn  
)
```

C++/CLI

```
void ISetFaces(  
& System.int Count,  
& Face2^% EntIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of faces whose edges were healed

EntIn

- in-process, unmanaged C++: Pointer to [faces](#) whose edges were healed

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

See Also

[IHealEdgesFeatureData Interface](#)
[IHealEdgesFeatureData Members](#)
[IHealEdgesFeatureData::IGetFaces Method](#)
[IHealEdgesFeatureData::Faces Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

ReleaseSelectionAccess Method (IHealEdgesFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHealEdgesFeatureData Interface](#) : ReleaseSelectionAccess Method (IHealEdgesFeatureData)

Releases access to the selections that describe this heal edges feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IHealEdgesFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [HealEdgesFeatureData::ReleaseSelectionAccess](#).

Example

[Get Heal Edges Feature Data \(C#\)](#)
[Get Heal Edges Feature Data \(VB.NET\)](#)
[Get Heal Edges Feature Data \(VBA\)](#)

Remarks

[IHealEdgesFeatureData::AccessSelections](#) puts the model into a rollback state to allow access to the selections that define the heal edges feature.

Use this method to restore the rollback state if you did not modify the fill-surface feature, or use [IFeature::ModifyDefinition](#) if you did modify the heal edges feature.

See Also

[IHealEdgesFeatureData Interface](#)
[IHealEdgesFeatureData Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0