

SOLIDWORKS API (.NET VBA C#) — Reference

(132/337): IHelixFeatureData- IHingeMateFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IHelixFeatureData (Type)

IHelixFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHelixFeatureData Interface

Allows access to a helix feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IHelixFeatureData
```

Visual Basic (Usage)



```
Dim instance As IHelixFeatureData
```

C#

```
public interface IHelixFeatureData
```

C++/CLI

```
public interface class IHelixFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [HelixFeatureData](#).

Example

[Change Pitch of Helix \(C#\)](#)
[Change Pitch of Helix \(VB.NET\)](#)
[Change Pitch of Helix \(VBA\)](#)
[Create and Modify Variable-pitch Helix \(C#\)](#)
[Create and Modify Variable-pitch Helix \(VB.NET\)](#)
[Create and Modify Variable-pitch Helix \(VBA\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[HelixFeatureData](#)

See Also

[IHelixFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertHelix Method](#)
[IFeatureManager::InsertVariablePitchHelix Method \(\)](#)
[IFeatureManager::AddVariablePitchHelixFirstPitchAndDiameter Method \(\)](#)
[IFeatureManager::AddVariablePitchHelixSegment Method \(\)](#)
[IFeatureManager::EndVariablePitchHelix Method \(\)](#)

IHelixFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHelixFeatureData Interface

For a list of all members of this type, see [IHelixFeatureData members](#).

Public Methods

Name	Description
 AddLastRecord	Adds a region to the end of the Region parameters table of this variable-pitch helix.
 DeleteRecord	Deletes the specified records in the Region parameters table of this variable-pitch helix.
 GetRegionParameterAtIndex	Gets the specified parameter value for the specified region in this variable-pitch helix.
 InsertRecord	Inserts a record before the specified index in the Region parameters table of this variable-pitch helix.
 SetRegionParameterAtIndex	Sets the specified parameter for the specified region in this variable-pitch helix.

[Top](#)

See Also

[IHelixFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertHelix Method](#)
[IFeatureManager::InsertVariablePitchHelix Method \(\)](#)
[IFeatureManager::AddVariablePitchHelixFirstPitchAndDiameter Method \(\)](#)
[IFeatureManager::AddVariablePitchHelixSegment Method \(\)](#)
[IFeatureManager::EndVariablePitchHelix Method \(\)](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IHelixFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHelixFeatureData Interface

The following tables list the members exposed by [IHelixFeatureData](#).

Public Properties

Name	Description
 Clockwise	Gets or sets the direction of the turns of this helix feature.
 DefinedBy	Gets or sets the definition of this helix feature.
 Height	Gets or sets the height of this helix feature.
 Pitch	Gets or sets the pitch of this helix feature.
 PitchCount	Gets the number of regions in this variable-pitch helix.
 ReverseDirection	Gets or sets whether to make this helix feature extend backward from the point of origin.
 Revolution	Gets or sets the number of revolutions for this helix feature.
 StartingAngle	Gets or sets the angle for the first turn of this helix feature.
 Taper	Gets or sets whether this constant-pitch helix feature is tapered.
 TaperAngle	Gets or sets the angle of the taper for this constant-pitch helix feature.
 TaperOutward	Gets or sets the direction of the taper for this constant-pitch helix feature.
 VariablePitch	Gets whether this helix feature has a variable or constant pitch.

[Top](#)

Public Methods

Name	Description
 AddLastRecord	Adds a region to the end of the Region parameters table of this variable-pitch helix.
 DeleteRecord	Deletes the specified records in the Region parameters table of this variable-pitch helix.
 GetRegionParameterAtIndex	Gets the specified parameter value for the specified region in this variable-pitch helix.
 InsertRecord	Inserts a record before the specified index in the Region parameters table of this variable-pitch helix.
 SetRegionParameterAtIndex	Sets the specified parameter for the specified region in this variable-pitch helix.

[Top](#)

See Also

[IHelixFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertHelix Method](#)
[IFeatureManager::InsertVariablePitchHelix Method \(\)](#)
[IFeatureManager::AddVariablePitchHelixFirstPitchAndDiameter Method \(\)](#)
[IFeatureManager::AddVariablePitchHelixSegment Method \(\)](#)
[IFeatureManager::EndVariablePitchHelix Method \(\)](#)

IHelixFeatureData Interface Properties

[See Also](#)

SolidWorks.Interop.sldworks Namespace : IHelixFeatureData Interface

For a list of all members of this type, see [IHelixFeatureData members](#).

Public Properties

Name	Description
Clockwise	Gets or sets the direction of the turns of this helix feature.
DefinedBy	Gets or sets the definition of this helix feature.
Height	Gets or sets the height of this helix feature.
Pitch	Gets or sets the pitch of this helix feature.
PitchCount	Gets the number of regions in this variable-pitch helix.
ReverseDirection	Gets or sets whether to make this helix feature extend backward from the point of origin.
Revolution	Gets or sets the number of revolutions for this helix feature.
StartingAngle	Gets or sets the angle for the first turn of this helix feature.
Taper	Gets or sets whether this constant-pitch helix feature is tapered.
TaperAngle	Gets or sets the angle of the taper for this constant-pitch helix feature.
TaperOutward	Gets or sets the direction of the taper for this constant-pitch helix feature.
VariablePitch	Gets whether this helix feature has a variable or constant pitch.

[Top](#)

See Also

[IHelixFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertHelix Method](#)
[IFeatureManager::InsertVariablePitchHelix Method \(\)](#)
[IFeatureManager::AddVariablePitchHelixFirstPitchAndDiameter Method \(\)](#)
[IFeatureManager::AddVariablePitchHelixSegment Method \(\)](#)
[IFeatureManager::EndVariablePitchHelix Method \(\)](#)

AddLastRecord Method (IHelixFeatureData)

[See Also](#) [Example](#)

SolidWorks.Interop.sldworks Namespace > IHelixFeatureData Interface : AddLastRecord Method (IHelixFeatureData)

Adds a region to the end of the Region parameters table of this variable-pitch helix.

.NET Syntax

Visual Basic (Declaration)

```
Function AddLastRecord( _  
    ByVal HelixPointValue As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHelixFeatureData
Dim HelixPointValue As System.Object
Dim value As System.Boolean

value = instance.AddLastRecord(HelixPointValue)
```

C#

```
System.bool AddLastRecord(
    System.object HelixPointValue
)
```

C++/CLI

```
System.bool AddLastRecord(
    & System.Object^ HelixPointValue
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

HelixPointValue
Array of four doubles for the region to add to the end of the Region parameters table (see **Remarks**)

Return Value

True if the region is added to the end of the Region parameters table, false if not

Visual Basic for Applications (VBA) Syntax

See [HelixFeatureData::AddLastRecord](#).

Example

[Create and Modify Variable-pitch Helix \(C#\)](#)
[Create and Modify Variable-pitch Helix \(VB.NET\)](#)
[Create and Modify Variable-pitch Helix \(VBA\)](#)

Remarks

The values in the array specified for HelixPointValue depends on the type of variable-pitch helix:

Helix type	Array of doubles in this order
Pitch and revolution	Pitch, number of revolutions, 0, diameter
Height and revolution	Height, number of revolutions, 0, diameter
Height and pitch	Height, pitch, 0, diameter

NOTE: You must specify 0 for any element that SOLIDWORKS calculates.

To insert a record at a specific index in the Region parameters table (i.e., between existing records) of this variable-pitch helix, use [IHelixFeatureData::InsertRecord](#).

See Also

[IHelixFeatureData Interface](#)
[IHelixFeatureData Members](#)
[IHelixFeatureData::DeleteRecord Method \(\)](#)
[IHelixFeatureData::GetRegionParameterAtIndex Method \(\)](#)
[IHelixFeatureData::SetRegionParameterAtIndex Method \(\)](#)
[IHelixFeatureData::PitchCount Property \(\)](#)
[IHelixFeatureData::VariablePitch Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Clockwise Property (IHelixFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHelixFeatureData Interface](#) : Clockwise Property (IHelixFeatureData)

Gets or sets the direction of the turns of this helix feature.

 .NET Syntax

Visual Basic (Declaration)

Property Clockwise As System.Boolean

Visual Basic (Usage)

Copy Code

```
Dim instance As IHelixFeatureData
Dim value As System.Boolean

instance.Clockwise = value

value = instance.Clockwise
```

C#

```
System.bool Clockwise {get; set;}
```

C++/CLI

```
property System.bool Clockwise {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE:

See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if direction of turns is clockwise, false if counterclockwise

 Visual Basic for Applications (VBA) Syntax

See [HelixFeatureData.Clockwise](#).

 See Also

[IHelixFeatureData Interface](#)

[IHelixFeatureData Members](#)

 Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DefinedBy Property (IHelixFeatureData)

[See Also](#)

[Example](#)

 

[SolidWorks.Interop.sldworks Namespace](#) > [IHelixFeatureData Interface](#) : DefinedBy Property (IHelixFeatureData)

Gets or sets the definition of this helix feature.

 .NET Syntax

Visual Basic (Declaration)

Property DefinedBy As System.Integer

Visual Basic (Usage)

Copy Code

```
Dim instance As IHelixFeatureData
Dim value As System.Integer

instance.DefinedBy = value

value = instance.DefinedBy
```

C#

```
System.int DefinedBy {get; set;}
```

C++/CLI

```
property System.int DefinedBy {
    System.int get();
    void set ( &    System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of helix as defined by [swHelixDefinedBy_e](#)

Visual Basic for Applications (VBA) Syntax

See [HelixFeatureData::DefinedBy](#).

Example

[Create or Modify Variable-pitch Helix \(C#\)](#)
[Create or Modify Variable-pitch Helix \(VB.NET\)](#)
[Create or Modify Variable-pitch Helix \(VBA\)](#)

See Also

[IHelixFeatureData Interface](#)
[IHelixFeatureData Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DeleteRecord Method (IHelixFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHelixFeatureData Interface](#) : DeleteRecord Method (IHelixFeatureData)

Deletes the specified records in the Region parameters table of this variable-pitch helix.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteRecord( _
    ByVal Indices As System.Object _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IHelixFeatureData
Dim Indices As System.Object
Dim value As System.Boolean

value = instance.DeleteRecord(Indices)
```

C#



```
System.bool DeleteRecord(  
    System.object Indices  
)
```

C++/CLI

```
System.bool DeleteRecord(  
& System.Object^ Indices  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Indices

Array of the indices of the records to delete (see **Remarks**)

Return Value

True if the records are deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [HelixFeatureData.DeleteRecord](#).

Example

[Create and Modify Variable-pitch Helix \(C#\)](#)
[Create and Modify Variable-pitch Helix \(VB.NET\)](#)
[Create and Modify Variable-pitch Helix \(VBA\)](#)

Remarks

You cannot delete the first record in the Regions parameters table.

See Also

[IHelixFeatureData Interface](#)
[IHelixFeatureData Members](#)
[IHelixFeatureData::VariablePitch Property \(\)](#)
[IHelixFeatureData::PitchCount Property \(\)](#)
[IHelixFeatureData::InsertRecord Method \(\)](#)
[IHelixFeatureData::GetRegionParameterAtIndex Method \(\)](#)
[IHelixFeatureData::SetRegionParameterAtIndex Method \(\)](#)
[IHelixFeatureData::AddLastRecord Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetRegionParameterAtIndex Method (IHelixFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHelixFeatureData Interface](#) : GetRegionParameterAtIndex Method (IHelixFeatureData)

Gets the specified parameter value for the specified region in this variable-pitch helix.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRegionParameterAtIndex( _  
    ByVal Index As System.Integer, _  
    ByVal RegionParameter As System.Integer _  
) As System.Double
```

Visual Basic (Usage)

```
Dim instance As IHelixFeatureData  
Dim Index As System.Integer
```



```
Dim RegionParameter As System.Integer
Dim value As System.Double

value = instance.GetRegionParameterAtIndex(Index, RegionParameter)
```

C#

```
System.double GetRegionParameterAtIndex(
    System.int Index,
    System.int RegionParameter
)
```

C++/CLI

```
System.double GetRegionParameterAtIndex(
    & System.int Index,
    & System.int RegionParameter
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the region
RegionParameter
Region parameter as defined in [swVariablePitchHelixRegionParameter](#) e

Return Value

Region parameter value

Visual Basic for Applications (VBA) Syntax

See [HelixFeatureData::GetRegionParameterAtIndex](#).

Example

[Create and Modify Variable-pitch Helix \(C#\)](#)
[Create and Modify Variable-pitch Helix \(VB.NET\)](#)
[Create and Modify Variable-pitch Helix \(VBA\)](#)

See Also

[IHelixFeatureData Interface](#)
[IHelixFeatureData Members](#)
[IHelixFeatureData::VariablePitch Property \(\)](#)
[IHelixFeatureData::PitchCount Property \(\)](#)
[IHelixFeatureData::SetRegionParameterAtIndex Method \(\)](#)
[IHelixFeatureData::InsertRecord Method \(\)](#)
[IHelixFeatureData::DeleteRecord Method \(\)](#)
[IHelixFeatureData::AddLastRecord Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Height Property (IHelixFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHelixFeatureData Interface](#) : Height Property (IHelixFeatureData)

Gets or sets the height of this helix feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Height As System.Double
```

Visual Basic (Usage)



```
Dim instance As IHelixFeatureData  
Dim value As System.Double
```

```
instance.Height = value
```

```
value = instance.Height
```

C#

```
System.double Height {get; set;}
```

C++/CLI

```
property System.double Height {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Height (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [HelixFeatureData.Height](#).

Remarks

If the [helix is defined](#) as swHelixDefinedBy_e.swHelixDefinedByPitchAndRevolution, then you cannot change the height of the helix.

See Also

[IHelixFeatureData Interface](#)
[IHelixFeatureData Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertRecord Method (IHelixFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHelixFeatureData Interface](#) : InsertRecord Method (IHelixFeatureData)

Inserts a record before the specified index in the Region parameters table of this variable-pitch helix.

.NET Syntax

Visual Basic (Declaration)

```
Function InsertRecord(  
    ByVal Index As System.Integer  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHelixFeatureData  
Dim Index As System.Integer  
Dim value As System.Boolean
```

```
value = instance.InsertRecord(Index)
```

C#

```
System.bool InsertRecord(  
    System.int Index  
)
```

C++/CLI

```
System.bool InsertRecord(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index after which to insert a new record

Return Value

True if the record is inserted, false if not

Visual Basic for Applications (VBA) Syntax

See [HelixFeatureData::InsertRecord](#).

Remarks

When inserting a record, the SOLIDWORKS Design software calculates the new region's parameters. You cannot add a record to the beginning of the Region parameters table. To add a record to the end of the Region parameters table, use [IHelixFeatureData::AddLastRecord](#).

See Also

[IHelixFeatureData Interface](#)
[IHelixFeatureData Members](#)
[IHelixFeatureData::VariablePitch Property \(\)](#)
[IHelixFeatureData::PitchCount Property \(\)](#)
[IHelixFeatureData::DeleteRecord Method \(\)](#)
[IHelixFeatureData::SetRegionParameterAtIndex Method \(\)](#)
[IHelixFeatureData::GetRegionParameterAtIndex Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Pitch Property (IHelixFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHelixFeatureData Interface](#) : Pitch Property (IHelixFeatureData)

Gets or sets the pitch of this helix feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Pitch As System.Double
```

Visual Basic (Usage)



```
Dim instance As IHelixFeatureData  
Dim value As System.Double
```

```
instance.Pitch = value
```

```
value = instance.Pitch
```

C#

```
System.double Pitch {get; set;}
```

C++/CLI

```
property System.double Pitch {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pitch (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [HelixFeatureData::Pitch](#).

Example

[Change Pitch of Helix \(C#\)](#)
[Change Pitch of Helix \(VB.NET\)](#)
[Change Pitch of Helix \(VBA\)](#)

Remarks

For...	This property sets...
Helixes	Distance between turns
Spirals	Radial distance between revolutions of the curve

NOTES:

- If the [helix is defined](#) as swHelixDefinedBy_e.swHelixDefinedByHeightAndRevolution, then you cannot change the pitch of the helix.
- If setting a value for pitch for the first region only, then you cannot change diameter, height, or revolution.

See Also

[IHelixFeatureData Interface](#)
[IHelixFeatureData Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PitchCount Property (IHelixFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHelixFeatureData Interface](#) : PitchCount Property (IHelixFeatureData)

Gets the number of regions in this variable-pitch helix.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property PitchCount As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IHelixFeatureData  
Dim value As System.Integer  
  
value = instance.PitchCount
```

C#

```
System.int PitchCount {get;}
```

C++/CLI

```
property System.int PitchCount {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of regions

Visual Basic for Applications (VBA) Syntax

See [HelixFeatureData::PitchCount](#).

Example

[Create and Modify Variable-pitch Helix \(C#\)](#)
[Create and Modify Variable-pitch Helix \(VB.NET\)](#)
[Create and Modify Variable-pitch Helix \(VBA\)](#)

See Also

[IHelixFeatureData Interface](#)
[IHelixFeatureData Members](#)
[IHelixFeatureData::VariablePitch Property \(\)](#)
[IHelixFeatureData::DeleteRecord Method \(\)](#)
[IHelixFeatureData::GetRegionParameterAtIndex Method \(\)](#)
[IHelixFeatureData::InsertRecord Method \(\)](#)
[IHelixFeatureData::SetRegionParameterAtIndex Method \(\)](#)
[IHelixFeatureData::AddLastRecord Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (IHelixFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHelixFeatureData Interface](#) : ReverseDirection Property (IHelixFeatureData)

Gets or sets whether to make this helix feature extend backward from the point of origin.

.NET Syntax

Visual Basic (Declaration)

```
Property ReverseDirection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHelixFeatureData  
Dim value As System.Boolean
```

```
instance.ReverseDirection = value
```

```
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {  
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to extend backward from the point of origin, false to not

Visual Basic for Applications (VBA) Syntax

See [HelixFeatureData.ReverseDirection](#).

Remarks

For...	Reverses direction by...
Helixes	Extending the helix backwards from the point of origin
Spirals	Creating an inward spiral

See Also

[IHelixFeatureData Interface](#)
[IHelixFeatureData Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Revolution Property (IHelixFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHelixFeatureData Interface](#) : Revolution Property (IHelixFeatureData)

Gets or sets the number of revolutions for this helix feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Revolution As System.Double
```

Visual Basic (Usage)



```
Dim instance As IHelixFeatureData  
Dim value As System.Double
```

```
instance.Revolution = value
```

```
value = instance.Revolution
```

C#

```
System.double Revolution {get; set;}
```

C++/CLI

```
property System.double Revolution {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of revolutions (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [HelixFeatureData::Revolution](#).

Remarks

If the [helix is defined](#) as swHelixDefinedBy_e.swHelixDefinedByHeightAndPitch, then you cannot change the number of revolutions in the helix. You must specify a value greater than the previous region's revolution value and less than the next region's revolution value.

See Also

[IHelixFeatureData Interface](#)
[IHelixFeatureData Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetRegionParameterAtIndex Method (IHelixFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHelixFeatureData Interface](#) : SetRegionParameterAtIndex Method (IHelixFeatureData)

Sets the specified parameter for the specified region in this variable-pitch helix.

.NET Syntax

Visual Basic (Declaration)

```
Function SetRegionParameterAtIndex( _  
    ByVal Index As System.Integer, _  
    ByVal Parameter As System.Integer, _  
    ByVal PitchValue As System.Double _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IHelixFeatureData  
Dim Index As System.Integer  
Dim Parameter As System.Integer  
Dim PitchValue As System.Double  
Dim value As System.Integer  
  
value = instance.SetRegionParameterAtIndex(Index, Parameter, PitchValue)
```

C#

```
System.int SetRegionParameterAtIndex(  
    System.int Index,  
    System.int Parameter,  
    System.double PitchValue  
)
```

C++/CLI

```
System.int SetRegionParameterAtIndex(  
& System.int Index,  
& System.int Parameter,  
& System.double PitchValue  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the region

Parameter

Region parameter as defined in [swVariablePitchHelixRegionParameter_e](#) (see [Remarks](#))

PitchValue

Region parameter value

Return Value

Status of setting region parameters as defined in [swSetHelixRegionParameterStatus_e](#)

Visual Basic for Applications (VBA) Syntax

See [HelixFeatureData::SetRegionParameterAtIndex](#).

Example

[Create and Modify Variable-pitch Helix \(C#\)](#)
[Create and Modify Variable-pitch Helix \(VB.NET\)](#)
[Create and Modify Variable-pitch Helix \(VBA\)](#)

Remarks

If the helix is defined as...	Then you cannot change...
swHelixDefinedBy_e_swHelixDefinedByHeightAndPitch	Revolution value
swHelixDefinedBy_e_swHelixDefinedByHeightAndRevolution	Pitch value
swHelixDefinedBy_e_swHelixDefinedByPitchAndRevolution	Height value

If setting a value for...	Then you...
Revolution	Must specify a value greater than the previous region's revolution value and less than the next region's revolution value
Pitch for the first region only	Cannot change diameter, height, or revolution

See Also

[IHelixFeatureData Interface](#)
[IHelixFeatureData Members](#)
[IHelixFeatureData::VariablePitch Property \(\)](#)
[IHelixFeatureData::PitchCount Property \(\)](#)
[IHelixFeatureData::GetRegionParameterAtIndex Method \(\)](#)
[IHelixFeatureData::InsertRecord Method \(\)](#)
[IHelixFeatureData::DeleteRecord Method \(\)](#)
[IHelixFeatureData::AddLastRecord Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

StartingAngle Property (IHelixFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHelixFeatureData Interface](#) : StartingAngle Property (IHelixFeatureData)

Gets or sets the angle for the first turn of this helix feature.

.NET Syntax

Visual Basic (Declaration)

Property StartingAngle As System.Double

Visual Basic (Usage)



```
Dim instance As IHelixFeatureData  
Dim value As System.Double
```

```
instance.StartingAngle = value
```

```
value = instance.StartingAngle
```

C#

```
System.double StartingAngle {get; set;}
```

C++/CLI

```
property System.double StartingAngle {  
    System.double get();
```

```
void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle for the first turn

Visual Basic for Applications (VBA) Syntax

See [HelixFeatureData::StartingAngle](#).

See Also

[IHelixFeatureData Interface](#)
[IHelixFeatureData Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Taper Property (IHelixFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHelixFeatureData Interface](#) : Taper Property (IHelixFeatureData)

Gets or sets whether this constant-pitch helix feature is tapered.

.NET Syntax

Visual Basic (Declaration)

Property Taper As System.Boolean

Visual Basic (Usage)



```
Dim instance As IHelixFeatureData  
Dim value As System.Boolean
```

```
instance.Taper = value
```

```
value = instance.Taper
```

C#

```
System.bool Taper {get; set;}
```

C++/CLI

```
property System.bool Taper {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if helix is tapered, false if not tapered

Visual Basic for Applications (VBA) Syntax

See [HelixFeatureData::Taper](#).

See Also

[IHelixFeatureData Interface](#)
[IHelixFeatureData Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TaperAngle Property (IHelixFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHelixFeatureData Interface](#) : TaperAngle Property (IHelixFeatureData)

Gets or sets the angle of the taper for this constant-pitch helix feature.

.NET Syntax

Visual Basic (Declaration)

Property TaperAngle As System.Double

Visual Basic (Usage)



```
Dim instance As IHelixFeatureData  
Dim value As System.Double
```

```
instance.TaperAngle = value
```

```
value = instance.TaperAngle
```

C#

```
System.double TaperAngle {get; set;}
```

C++/CLI

```
property System.double TaperAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle of taper

Visual Basic for Applications (VBA) Syntax

See [HelixFeatureData.TaperAngle](#).

See Also

[IHelixFeatureData Interface](#)
[IHelixFeatureData Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TaperOutward Property (IHelixFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHelixFeatureData Interface](#) : TaperOutward Property (IHelixFeatureData)

Gets or sets the direction of the taper for this constant-pitch helix feature.

.NET Syntax

Visual Basic (Declaration)

Property TaperOutward As System.Boolean

Visual Basic (Usage)



```
Dim instance As IHelixFeatureData  
Dim value As System.Boolean
```

```
instance.TaperOutward = value
```

```
value = instance.TaperOutward
```

C#

```
System.bool TaperOutward {get; set;}
```

C++/CLI

```
property System.bool TaperOutward {  
    System.bool get();  
    void set ( &    System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if outward, false if inward

Visual Basic for Applications (VBA) Syntax

See [HelixFeatureData.TaperOutward](#).

See Also

[IHelixFeatureData Interface](#)
[IHelixFeatureData Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

VariablePitch Property (IHelixFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHelixFeatureData Interface](#) : VariablePitch Property (IHelixFeatureData)

Gets whether this helix feature has a variable or constant pitch.

.NET Syntax

Visual Basic (Declaration)

```
Property VariablePitch As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHelixFeatureData  
Dim value As System.Boolean
```

```
instance.VariablePitch = value
```

```
value = instance.VariablePitch
```

C#

```
System.bool VariablePitch {get; set;}
```

C++/CLI

```
property System.bool VariablePitch {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if this helix feature has a variable pitch, false if this helix feature has a constant pitch

Visual Basic for Applications (VBA) Syntax

See [HelixFeatureData.VariablePitch](#).

Example

[Create and Modify Variable-pitch Helix \(C#\)](#)
[Create and Modify Variable-pitch Helix \(VB.NET\)](#)
[Create and Modify Variable-pitch Helix \(VBA\)](#)

See Also

[IHelixFeatureData Interface](#)
[IHelixFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

IHemFeatureData (Type)

IHemFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHemFeatureData Interface

Allows access to a hem feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IHemFeatureData

Visual Basic (Usage)

Dim instance As [IHemFeatureData](#)

C#

public interface IHemFeatureData

C++/CLI

public interface class IHemFeatureData

Visual Basic for Applications (VBA) Syntax

See [HemFeatureData](#).

Example

[Insert Sheet Metal Hem \(VBA\)](#)
[Insert Sheet Metal Hem \(VB.NET\)](#)
[Insert Sheet Metal Hem \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[HemFeatureData](#)

See Also

[IHemFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertSheetMetalHem Method](#)

IHemFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHemFeatureData Interface

The following tables list the members exposed by [IHemFeatureData](#).

Public Properties

Name	Description
Angle	Gets or sets the hem size angle.
BendPosition	Gets or sets the bend position.

 Edges	Gets or sets the edges for this hem feature.
 GapDistance	Gets or sets the hem gap distance for open hems only.
 Length	Gets or sets the hem length for closed and open hems only.
 MiterGap	Gets or sets the miter gap for this hem feature.
 Radius	Gets or sets the hem radius for tear drop and rolled hems only.
 ReverseDirection	Gets or sets the reverse direction for this hem feature.
 Type	Gets or sets the hem type.
 UseDefaultBendAllowance	Gets or sets whether to use the default bend allowance state for this hem feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to selections used to define the hem feature.
 GetCustomBendAllowance	Gets the custom bend allowance for the hem feature.
 GetEdgesCount	Gets the number of edges for this hem.
 IAccessSelections	Gains access to selections used to define the hem feature.
 IGetEdges	Gets the edges for this hem.
 ISetEdges	Sets the edges for this hem feature.
 ReleaseSelectionAccess	Releases access to the selections for this hem feature.
 SetCustomBendAllowance	Sets the custom bend allowance for the hem feature.

[Top](#)

See Also

[IHemFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager.InsertSheetMetalHem Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IHemFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHemFeatureData Interface

For a list of all members of this type, see [IHemFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to selections used to define the hem feature.
 GetCustomBendAllowance	Gets the custom bend allowance for the hem feature.
 GetEdgesCount	Gets the number of edges for this hem.
 IAccessSelections	Gains access to selections used to define the hem feature.
 IGetEdges	Gets the edges for this hem.
 ISetEdges	Sets the edges for this hem feature.
 ReleaseSelectionAccess	Releases access to the selections for this hem feature.
 SetCustomBendAllowance	Sets the custom bend allowance for the hem feature.

[Top](#)

See Also

[IHemFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IHemFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IHemFeatureData Interface

For a list of all members of this type, see [IHemFeatureData members](#).

Public Properties

Name	Description
 Angle	Gets or sets the hem size angle.
 BendPosition	Gets or sets the bend position.
 Edges	Gets or sets the edges for this hem feature.
 GapDistance	Gets or sets the hem gap distance for open hems only.
 Length	Gets or sets the hem length for closed and open hems only.
 MiterGap	Gets or sets the miter gap for this hem feature.
 Radius	Gets or sets the hem radius for tear drop and rolled hems only.
 ReverseDirection	Gets or sets the reverse direction for this hem feature.
 Type	Gets or sets the hem type.
 UseDefaultBendAllowance	Gets or sets whether to use the default bend allowance state for this hem feature.

[Top](#)

See Also

- [IHemFeatureData Interface](#)
- [SolidWorks.Interop.sldworks Namespace](#)
- [IFeatureManager::InsertSheetMetalHem Method](#)

AccessSelections Method (IHemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHemFeatureData Interface](#) : AccessSelections Method (IHemFeatureData)

Gains access to selections used to define the hem feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
    ) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IHemFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```



```
System.bool AccessSelections(
& System.Object^ TopDoc,
& System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [HemFeatureData::AccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is Nothing or null
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IHemFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IHemFeatureData Interface](#)

[IHemFeatureData Members](#)

[IHemFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Angle Property (IHemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHemFeatureData Interface](#) : Angle Property (IHemFeatureData)

Gets or sets the hem size angle.

.NET Syntax

Visual Basic (Declaration)

```
Property Angle As System.Double
```

Visual Basic (Usage)



```
Dim instance As IHemFeatureData
Dim value As System.Double
```

```
instance.Angle = value
```

```
value = instance.Angle
```

C#

```
System.double Angle {get; set;}
```

C++/CLI

```
property System.double Angle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle in radians

Visual Basic for Applications (VBA) Syntax

See [HemFeatureData::Angle](#).

See Also

[IHemFeatureData Interface](#)
[IHemFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

BendPosition Property (IHemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHemFeatureData Interface](#) : BendPosition Property (IHemFeatureData)

Gets or sets the bend position.

.NET Syntax

Visual Basic (Declaration)

```
Property BendPosition As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IHemFeatureData  
Dim value As System.Integer  
  
instance.BendPosition = value  
value = instance.BendPosition
```

C#

```
System.int BendPosition {get; set;}
```

C++/CLI

```
property System.int BendPosition {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Position as defined in [swHemPositionTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [HemFeatureData::BendPosition](#).

See Also

[IHemFeatureData Interface](#)
[IHemFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

Edges Property (IHemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHemFeatureData Interface](#) : Edges Property (IHemFeatureData)

Gets or sets the edges for this hem feature.

.NET Syntax

Visual Basic (Declaration)

Property Edges As System.Object

Visual Basic (Usage)



```
Dim instance As IHemFeatureData  
Dim value As System.Object
```

```
instance.Edges = value
```

```
value = instance.Edges
```

C#

```
System.object Edges {get; set;}
```

C++/CLI

```
property System.Object^ Edges {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [edges](#)

Visual Basic for Applications (VBA) Syntax

See [HemFeatureData::Edges](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IHemFeatureData Interface](#)
[IHemFeatureData Members](#)
[IHemFeatureData::IGetEdges Method](#)
[IHemFeatureData::SetEdges Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

GapDistance Property (IHemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHemFeatureData Interface](#) : GapDistance Property (IHemFeatureData)

Gets or sets the hem gap distance for open hems only.

.NET Syntax

Visual Basic (Declaration)

```
Property GapDistance As System.Double
```

Visual Basic (Usage)



```
Dim instance As IHemFeatureData  
Dim value As System.Double
```

```
instance.GapDistance = value
```

```
value = instance.GapDistance
```

C#

```
System.double GapDistance {get; set;}
```

C++/CLI

```
property System.double GapDistance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Gap distance

Visual Basic for Applications (VBA) Syntax

See [HemFeatureData::GapDistance](#).

See Also

[IHemFeatureData Interface](#)
[IHemFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCustomBendAllowance Method (IHemFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHemFeatureData Interface](#) : GetCustomBendAllowance Method (IHemFeatureData)

Gets the custom bend allowance for the hem feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomBendAllowance() As CustomBendAllowance
```

Visual Basic (Usage)



```
Dim instance As IHemFeatureData  
Dim value As CustomBendAllowance
```

```
value = instance.GetCustomBendAllowance()
```

C#

```
CustomBendAllowance GetCustomBendAllowance()
```

C++/CLI

```
CustomBendAllowance^ GetCustomBendAllowance();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Custom bend allowance](#) for the hem feature

Visual Basic for Applications (VBA) Syntax

See [HemFeatureData::GetCustomBendAllowance](#).

Example

[Get All Sheet Metal Feature Data \(VBA\)](#)
[Get All Sheet Metal Feature Data \(VB.NET\)](#)
[Get All Sheet Metal Feature Data \(C#\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IHemFeatureData Interface](#)
[IHemFeatureData Members](#)
[IHemFeatureData::SetCustomBendAllowance Method](#)
[IHemFeatureData::UseDefaultBendAllowance Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEdgesCount Method (IHemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHemFeatureData Interface](#) : GetEdgesCount Method (IHemFeatureData)

Gets the number of edges for this hem.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEdgesCount() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IHemFeatureData  
Dim value As System.Integer
```

```
value = instance.GetEdgesCount()
```

C#



Copy Code

```
System.int GetEdgesCount()
```

C++/CLI

```
System.int GetEdgesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of edges

Visual Basic for Applications (VBA) Syntax

See [HemFeatureData::GetEdgesCount](#).

Remarks

Call this method before calling [IHemFeatureData::IGetEdges](#).

See Also

[IHemFeatureData Interface](#)
[IHemFeatureData Members](#)
[IHemFeatureData::ISetEdges Method](#)
[IHemFeatureData::Edges Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10,1

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections Method (IHemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHemFeatureData Interface](#) : IAccessSelections Method (IHemFeatureData)

Gains access to selections used to define the hem feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHemFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean
```

```
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc2^ TopDoc,
```

& Component2^ [Component](#)
)

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [HemFeatureData::IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::IModifyDefinition2](#) if you modified the feature
- [IHemFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IHemFeatureData Interface](#)

[IHemFeatureData Members](#)

[IHemFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetEdges Method (IHemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHemFeatureData Interface](#) : IGetEdges Method (IHemFeatureData)

Gets the edges for this hem.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetEdges( _  
    ByVal EdgeCount As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IHemFeatureData  
Dim EdgeCount As System.Integer  
Dim value As System.Object
```

```
value = instance.IGetEdges(EdgeCount)
```

C#

```
System.object IGetEdges(  
    System.int EdgeCount  
)
```

C++/CLI

```
System.Object^ IGetEdges(  
& System.int EdgeCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EdgeCount
Number of edges

Return Value

- in-process, unmanaged C++: Pointer to an array of [edges](#) of size EdgeCount
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IHemFeatureData::GetEdgesCount](#) before calling this method.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IHemFeatureData Interface](#)
[IHemFeatureData Members](#)
[IHemFeatureData::ISetEdges Method](#)
[IHemFeatureData::Edges Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetEdges Method (IHemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHemFeatureData Interface](#) : ISetEdges Method (IHemFeatureData)

Sets the edges for this hem feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetEdges( _  
    ByVal EdgeCount As System.Integer, _  
    ByRef EdgeArr As System.Object _  
)
```

Visual Basic (Usage)

```
Dim instance As IHemFeatureData  
Dim EdgeCount As System.Integer  
Dim EdgeArr As System.Object  
  
instance.ISetEdges(EdgeCount, EdgeArr)
```

C#

```
void ISetEdges(  
    System.int EdgeCount,  
    ref System.object EdgeArr  
)
```

C++/CLI

```
void ISetEdges(  
& System.int EdgeCount,
```



Copy Code

```
& System.Object^% EdgeArr
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EdgeCount

Number of edges

EdgeArr

- in-process, unmanaged C++: Pointer to an array of [edges](#) of size EdgeCount
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IHemFeatureData Interface](#)
[IHemFeatureData Members](#)
[IHemFeatureData::IGetEdges Method](#)
[IHemFeatureData::Edges Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Length Property (IHemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHemFeatureData Interface](#) : Length Property (IHemFeatureData)

Gets or sets the hem length for closed and open hems only.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property Length As System.Double
```

Visual Basic (Usage)



```
Dim instance As IHemFeatureData
Dim value As System.Double
```

```
instance.Length = value
```

```
value = instance.Length
```

C#

```
System.double Length {get; set;}
```

C++/CLI

```
property System.double Length {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Hem length

Visual Basic for Applications (VBA) Syntax

See [HemFeatureData::Length](#).

See Also

[IHemFeatureData Interface](#)
[IHemFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

MiterGap Property (IHemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHemFeatureData Interface](#) : MiterGap Property (IHemFeatureData)

Gets or sets the miter gap for this hem feature.

.NET Syntax

Visual Basic (Declaration)

Property MiterGap As System.Double

Visual Basic (Usage)



```
Dim instance As IHemFeatureData  
Dim value As System.Double
```

```
instance.MiterGap = value
```

```
value = instance.MiterGap
```

C#

```
System.double MiterGap {get; set;}
```

C++/CLI

```
property System.double MiterGap {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Miter gap

Visual Basic for Applications (VBA) Syntax

See [HemFeatureData::MiterGap](#).

See Also

[IHemFeatureData Interface](#)
[IHemFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

Radius Property (IHemFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHemFeatureData Interface](#) : Radius Property (IHemFeatureData)

Gets or sets the hem radius for tear drop and rolled hems only.

 **.NET Syntax**

Visual Basic (Declaration)

Property Radius As System.Double

Visual Basic (Usage)

```
Dim instance As IHemFeatureData
Dim value As System.Double

instance.Radius = value

value = instance.Radius
```

C#

```
System.double Radius {get; set;}
```

C++/CLI

```
property System.double Radius {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Hem radius

 **Visual Basic for Applications (VBA) Syntax**

See [HemFeatureData::Radius](#).

 **Example**

[Get All Sheet Metal Feature Data \(VBA\)](#)
[Get All Sheet Metal Feature Data \(VB.NET\)](#)
[Get All Sheet Metal Feature Data \(C#\)](#)

 **See Also**

[IHemFeatureData Interface](#)
[IHemFeatureData Members](#)

 **Availability**

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

ReleaseSelectionAccess Method (IHemFeatureData)

[See Also](#)

 

[SolidWorks.Interop.sldworks Namespace](#) > [IHemFeatureData Interface](#) : ReleaseSelectionAccess Method (IHemFeatureData)

Releases access to the selections for this hem feature.

 **.NET Syntax**

Visual Basic (Declaration)

Sub ReleaseSelectionAccess()

Visual Basic (Usage)

```
Dim instance As IHemFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [HemFeatureData::ReleaseSelectionAccess](#).

Remarks

[IHemFeatureData::AccessSelections](#) and [IHemFeatureData::!AccessSelections](#) put the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefintion2](#) if you did.

See Also

[IHemFeatureData Interface](#)
[IHemFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (IHemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHemFeatureData Interface](#) : ReverseDirection Property (IHemFeatureData)

Gets or sets the reverse direction for this hem feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ReverseDirection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHemFeatureData  
Dim value As System.Boolean  
  
instance.ReverseDirection = value  
  
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {  
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True reverses the direction of the hem, false does not

Visual Basic for Applications (VBA) Syntax

See [HemFeatureData::ReverseDirection](#).

See Also

[IHemFeatureData Interface](#)
[IHemFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetCustomBendAllowance Method (IHemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHemFeatureData Interface](#) : SetCustomBendAllowance Method (IHemFeatureData)

Sets the custom bend allowance for the hem feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetCustomBendAllowance(  
    ByVal PBendData As CustomBendAllowance _  
)
```

Visual Basic (Usage)



```
Dim instance As IHemFeatureData  
Dim PBendData As CustomBendAllowance  
  
instance.SetCustomBendAllowance(PBendData)
```

C#

```
void SetCustomBendAllowance(  
    CustomBendAllowance PBendData  
)
```

C++/CLI

```
void SetCustomBendAllowance(  
& CustomBendAllowance^ PBendData  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PBendData

[Custom bend allowance](#) for the hem feature

Visual Basic for Applications (VBA) Syntax

See [HemFeatureData::SetCustomBendAllowance](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IHemFeatureData Interface](#)
[IHemFeatureData Members](#)
[IHemFeatureData::GetCustomBendAllowance Method](#)
[IHemFeatureData::UseDefaultBendAllowance Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Type Property (IHemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHemFeatureData Interface](#) : Type Property (IHemFeatureData)

Gets or sets the hem type.

.NET Syntax

Visual Basic (Declaration)

Property Type As System.Integer

Visual Basic (Usage)



```
Dim instance As IHemFeatureData  
Dim value As System.Integer
```

```
instance.Type = value
```

```
value = instance.Type
```

C#

```
System.int Type {get; set;}
```

C++/CLI

```
property System.int Type {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Hem type as defined in [swHemTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [HemFeatureData::Type](#).

Example

See [IHemFeatureData](#) examples.

See Also

[IHemFeatureData Interface](#)
[IHemFeatureData Members](#)

Availability

UseDefaultBendAllowance Property (IHemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHemFeatureData Interface](#) : UseDefaultBendAllowance Property (IHemFeatureData)

Gets or sets whether to use the default bend allowance state for this hem feature.

.NET Syntax

Visual Basic (Declaration)

Property UseDefaultBendAllowance As System.Boolean

Visual Basic (Usage)



```
Dim instance As IHemFeatureData  
Dim value As System.Boolean
```

```
instance.UseDefaultBendAllowance = value  
value = instance.UseDefaultBendAllowance
```

C#

```
System.bool UseDefaultBendAllowance {get; set;}
```

C++/CLI

```
property System.bool UseDefaultBendAllowance {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True uses the default bend allowance, false does not

Visual Basic for Applications (VBA) Syntax

See [HemFeatureData::UseDefaultBendAllowance](#).

See Also

[IHemFeatureData Interface](#)
[IHemFeatureData Members](#)
[IHemFeatureData::GetCustomBendAllowance Method](#)
[IHemFeatureData::SetCustomBendAllowance Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

IHingeMateFeatureData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IHingeMateFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHingeMateFeatureData Interface

Allows access to a hinge mate feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IHingeMateFeatureData
```

Visual Basic (Usage)



```
Dim instance As IHingeMateFeatureData
```

C#

```
public interface IHingeMateFeatureData
```

C++/CLI

```
public interface class IHingeMateFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [HingeMateFeatureData](#).

Example

'VBA

' *****

' 1. Open *public_documents\samples\tutorial\api\MechanicalMates\Hinge-Assy.sldasm*.

' 2. Run the macro.

' 3. Inspect the Mates folder in the FeatureManager design tree.

' *****

```
Dim swApp As SldWorks.SldWorks
```

```
Dim Part As SldWorks.ModelDoc2
```

```
Dim boolstatus As Boolean
```

```
Option Explicit
```

```
Sub main()
```

```
    Set swApp = Application.SldWorks
```

```
    Set Part = swApp.ActiveDoc
```

```
    boolstatus = Part.Extension.SelectByRay(3.43240086878041E-02, 9.99999999998522E-02, -5.12270896450673E-03,  
-0.577381545199981, -0.577287712085548, -0.577381545199979, 7.97167289842004E-04, 2, True, 32768, 0)
```

```
    boolstatus = Part.Extension.SelectByRay(8.24118572918451E-02, 0.100000000000008, -4.68924659023173E-02, -0.577381545199981,  
-0.577287712085548, -0.577381545199979, 7.97167289842004E-04, 2, True, 32768, 0)
```

```
    boolstatus = Part.Extension.SelectByRay(1.82257333177063E-02, 4.19666144006783E-02, 0, -0.577381545199981,  
-0.577287712085548, -0.577381545199979, 7.97167289842004E-04, 2, True, 65536, 0)
```

```
    boolstatus = Part.Extension.SelectByRay(7.79243258261317E-02, 4.97185607756023E-02, -3.84484600391488E-02,  
-0.577381545199981, -0.577287712085548, -0.577381545199979, 7.97167289842004E-04, 2, True, 65536, 0)
```

```
    boolstatus = Part.Extension.SelectByRay(5.33819856866558E-02, 9.21914939762019E-02, -1.31731445623018E-03,  
-0.577381545199981, -0.577287712085548, -0.577381545199979, 7.97167289842004E-04, 2, True, 1, 0)
```

```
    boolstatus = Part.Extension.SelectByRay(5.80246157638271E-02, 7.00560308736158E-02, -1.92219802344198E-02,  
-0.577381545199981, -0.577287712085548, -0.577381545199979, 7.97167289842004E-04, 2, True, 1, 0)
```

```
    ' Create HingeMateFeatureData
```

```
    Dim MateData As SldWorks.HingeMateFeatureData
```

```
    Set MateData = Part.CreateMateData(22)
```

```
    ' Set the concentric entities to mate
```

```
    Dim ConcentricEntitiesToMate(1) As Object
```

```
    Set ConcentricEntitiesToMate(0) = Part.SelectionManager.GetSelectedObject6(5, -1)
```

```
    Set ConcentricEntitiesToMate(1) = Part.SelectionManager.GetSelectedObject6(6, -1)
```

```

Dim ConcentricEntitiesToMateVar As Variant
ConcentricEntitiesToMateVar = ConcentricEntitiesToMate
MateData.EntitiesToMate(0) = ConcentricEntitiesToMateVar

' Set the coincident entities to mate
Dim CoincidentEntitiesToMate(1) As Object
Set CoincidentEntitiesToMate(0) = Part.SelectionManager.GetSelectedObject6(1, -1)
Set CoincidentEntitiesToMate(1) = Part.SelectionManager.GetSelectedObject6(2, -1)
Dim CoincidentEntitiesToMateVar As Variant
CoincidentEntitiesToMateVar = CoincidentEntitiesToMate
MateData.EntitiesToMate(1) = CoincidentEntitiesToMateVar

' Set the mate angle selection
MateData.AngleSelection = True

' Set the angle entities to mate
Dim AngleEntitiesToMate(1) As Object
Set AngleEntitiesToMate(0) = Part.SelectionManager.GetSelectedObject6(3, -1)
Set AngleEntitiesToMate(1) = Part.SelectionManager.GetSelectedObject6(4, -1)
Dim AngleEntitiesToMateVar As Variant
AngleEntitiesToMateVar = AngleEntitiesToMate
MateData.EntitiesToMate(2) = AngleEntitiesToMateVar

' Set the mate angle value
MateData.Angle = 0.5235987755983

' Set the mate angle minimum value
MateData.MinVal = 0.5235987755983

' Set the mate angle maximum value
MateData.MaxVal = 0.5235987755983

' Set the mate alignment
MateData.MateAlignment = 0

' Create the mate
Dim MateFeature As SldWorks.Feature
Set MateFeature = Part.CreateMate(MateData)
Part.ClearSelection2 True
Part.EditRebuild3
End Sub

```

Example

[Create Hinge Mate \(C#\)](#)

Remarks

A hinge mate:

- Limits the movement between two components to one rotational degree of freedom.
- Can also limit the angular movement between two components.
- Acts like a concentric mate and a coincident mate.

[IMateFeatureData](#) is the parent of this mate interface.

To create a hinge mate:

1. Follow general instructions in the [AssemblyDoc::CreateMate](#) Remarks.
2. Specify [IHingeMateFeatureData::EntitiesToMate](#) for each EntityType or use [IModelDocExtension::SelectByID2](#) to pre-select the entities using Mark = 1 for the concentric entities, Mark = 32768 for the coincident entities, and Mark = 65536 for the angle entities.
3. Specify other properties of the HingeMateFeatureData object as required.

To edit a hinge mate:

1. Access its feature and call [IFeature::GetDefinition](#) to get the MateFeatureData object.
2. Cast the MateFeatureData object to a HingeMateFeatureData object.
3. Modify the HingeMateFeatureData object.
4. Call [IFeature::ModifyDefinition](#).

To delete a hinge mate, use [IModelDocExtension::DeleteSelection2](#).

Access Diagram

[HingeMateFeatureData](#)

See Also

[IHingeMateFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IHingeMateFeatureData Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHingeMateFeatureData Interface

The following tables list the members exposed by [IHingeMateFeatureData](#).

Public Properties

Name	Description
 Angle	Gets or sets the nominal angle between two selected faces.
 AngleSelection	Gets or sets whether to specify angle limits.
 EntitiesToMate	Gets or sets the entities to mate in this hinge mate.
 MateAlignment	Gets or sets the mate alignment of this hinge mate.
 MaxVal	Gets or sets the maximum angular rotation between the two components.
 MinVal	Gets or sets the minimum angular rotation between the two components.

[Top](#)

See Also

[IHingeMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IHingeMateFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHingeMateFeatureData Interface

For a list of all members of this type, see [IHingeMateFeatureData members](#).

Public Properties

Name	Description
 Angle	Gets or sets the nominal angle between two selected faces.
 AngleSelection	Gets or sets whether to specify angle limits.
 EntitiesToMate	Gets or sets the entities to mate in this hinge mate.
 MateAlignment	Gets or sets the mate alignment of this hinge mate.
 MaxVal	Gets or sets the maximum angular rotation between the two components.
 MinVal	Gets or sets the minimum angular rotation between the two components.

[Top](#)

See Also

[IHingeMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Angle Property (IHingeMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHingeMateFeatureData Interface](#) : Angle Property (IHingeMateFeatureData)

Gets or sets the nominal angle between two selected faces.

.NET Syntax

Visual Basic (Declaration)

Property Angle As System.Double

Visual Basic (Usage)



```
Dim instance As IHingeMateFeatureData
Dim value As System.Double

instance.Angle = value

value = instance.Angle
```

C#

```
System.double Angle {get; set;}
```

C++/CLI

```
property System.double Angle {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle in radians

Visual Basic for Applications (VBA) Syntax

See [HingeMateFeatureData::Angle](#).

Example

See the [IHingeMateFeatureData](#) example.

Remarks

This property is valid only if [IHingeMateFeatureData::AngleSelection](#) is set to true.

See Also

[IHingeMateFeatureData Interface](#)
[IHingeMateFeatureData Members](#)
[IHingeMateFeatureData::MaxVal Property \(\)](#)
[IHingeMateFeatureData::MinVal Property \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AngleSelection Property (IHingeMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHingeMateFeatureData Interface](#) : AngleSelection Property (IHingeMateFeatureData)

Gets or sets whether to specify angle limits.

.NET Syntax

Visual Basic (Declaration)

```
Property AngleSelection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHingeMateFeatureData
Dim value As System.Boolean

instance.AngleSelection = value
```

```
value = instance.AngleSelection
```

C#

```
System.bool AngleSelection {get; set;}
```

C++/CLI

```
property System.bool AngleSelection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to specify angle limits, false to not

Visual Basic for Applications (VBA) Syntax

See [HingeMateFeatureData::AngleSelection](#).

Example

See the [IHingeMateFeatureData](#) example.

Remarks

After setting this property to true, also set:

- [IHingeMateFeatureData::Angle](#)
- [IHingeMateFeatureData::MaxVal](#)
- [IHingeMateFeatureData::MinVal](#)

See Also

[IHingeMateFeatureData Interface](#)
[IHingeMateFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

EntitiesToMate Property (IHingeMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHingeMateFeatureData Interface](#) : EntitiesToMate Property (IHingeMateFeatureData)

Gets or sets the entities to mate in this hinge mate.

.NET Syntax

Visual Basic (Declaration)

```
Property EntitiesToMate( _  
    ByVal EntityType As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IHingeMateFeatureData  
Dim EntityType As System.Integer  
Dim value As System.Object  
  
instance.EntitiesToMate(EntityType) = value  
  
value = instance.EntitiesToMate(EntityType)
```

C#

```
System.Object EntitiesToMate(  
    System.Int EntityType  
) {get; set;}
```

C++/CLI

```
property System.Object^ EntitiesToMate {  
    System.Object^ get(System.Int EntityType);  
    void set (System.Int EntityType, System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EntityType

Type of entity as defined in [swHingeMateEntityType_e](#)

Property Value

Array of mate entities (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [HingeMateFeatureData::EntitiesToMate](#).

Example

See the [IHingeMateFeatureData](#) example.

Remarks

If EntityType is set to swHingeMateEntityType_e.:

- swHingeMateEntityType_Concentric, then select two mate entities as specified in the Remarks of [IConcentricMateFeatureData::EntitiesToMate](#).
- swHingeMateEntityType_Coincident, then select two mate entities:
 - [plane](#) or planar [face](#)
 - another plane or planar face, [edge](#), [sketch point](#), [reference point](#), or [vertex](#)
- swHingeMateEntityType_Angle, then select two faces. This type is valid only if [IHingeMateFeatureData::AngleSelection](#) is set to true.

Instead of specifying this property, you can use [IModelDocExtension::SelectByID2](#) to pre-select the entities to mate using Mark = 1 for concentric entities, Mark = 32768 for coincident entities, and Mark = 65536 for angle faces. You can pre-select mate entities during mate creation, but not during mate editing.

See Also

[IHingeMateFeatureData Interface](#)
[IHingeMateFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MateAlignment Property (IHingeMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHingeMateFeatureData Interface](#) : MateAlignment Property (IHingeMateFeatureData)

Gets or sets the mate alignment of this hinge mate.

.NET Syntax

Visual Basic (Declaration)

```
Property MateAlignment As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IHingeMateFeatureData  
Dim value As System.Integer
```



```
instance.MateAlignment = value  
value = instance.MateAlignment
```

C#

```
System.int MateAlignment {get; set;}
```

C++/CLI

```
property System.int MateAlignment {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Mate alignment as defined in [swMateAlign_e](#)

Visual Basic for Applications (VBA) Syntax

See [HingeMateFeatureData::MateAlignment](#).

Example

See the [IHingeMateFeatureData](#) example.

See Also

[IHingeMateFeatureData Interface](#)
[IHingeMateFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

MaxVal Property (IHingeMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHingeMateFeatureData Interface](#) : MaxVal Property (IHingeMateFeatureData)

Gets or sets the maximum angular rotation between the two components.

.NET Syntax

Visual Basic (Declaration)

```
Property MaxVal As System.Double
```

Visual Basic (Usage)



```
Dim instance As IHingeMateFeatureData  
Dim value As System.Double
```

```
instance.MaxVal = value  
value = instance.MaxVal
```

C#

```
System.double MaxVal {get; set;}
```

C++/CLI

```
property System.double MaxVal {  
    System.double get();
```

```
void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Maximum angular rotation in radians

Visual Basic for Applications (VBA) Syntax

See [HingeMateFeatureData::MaxVal](#).

Example

See the [IHingeMateFeatureData](#) example.

Remarks

This property is valid only if [IHingeMateFeatureData::AngleSelection](#) is set to true.

See Also

[IHingeMateFeatureData Interface](#)
[IHingeMateFeatureData Members](#)
[IHingeMateFeatureData::MinVal Property \(\)](#)
[IHingeMateFeatureData::Angle Property \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

MinVal Property (IHingeMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHingeMateFeatureData Interface](#) : MinVal Property (IHingeMateFeatureData)

Gets or sets the minimum angular rotation between the two components.

.NET Syntax

Visual Basic (Declaration)

Property MinVal As System.Double

Visual Basic (Usage)



```
Dim instance As IHingeMateFeatureData  
Dim value As System.Double
```

```
instance.MinVal = value
```

```
value = instance.MinVal
```

C#

```
System.double MinVal {get; set;}
```

C++/CLI

```
property System.double MinVal {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Minimum angular rotation in radians

Visual Basic for Applications (VBA) Syntax

See [HingeMateFeatureData::MinVal](#).

Example

See the [IHingeMateFeatureData](#) example.

Remarks

This property is valid only if [IHingeMateFeatureData::AngleSelection](#) is set to true.

See Also

[IHingeMateFeatureData Interface](#)
[IHingeMateFeatureData Members](#)
[IHingeMateFeatureData::MaxVal Property \(\)](#)
[IHingeMateFeatureData::Angle Property \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0