

SOLIDWORKS APL(.NET VBA C#) — Reference (133/337): IHoleDataTable-IHoleSeriesFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IHoleDataTable (Type)

IHoleDataTable Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHoleDataTable Interface

Allows access to Hole Wizard fastener tables.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IHoleDataTable
```

Visual Basic (Usage)



```
Dim instance As IHoleDataTable
```

C#

```
public interface IHoleDataTable
```

C++/CLI

```
public interface class IHoleDataTable
```

Visual Basic for Applications (VBA) Syntax

See [HoleDataTable](#).

Example

[Get Hole Standards Data \(VBA\)](#)
[Get Hole Standards Data \(C#\)](#)

Accessors

[IHoleStandardsData::GetFastenerTable](#)

Access Diagram

[HoleDataTable](#)

See Also

[IHoleDataTable Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IHoleDataTable Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHoleDataTable Interface

For a list of all members of this type, see [IHoleDataTable members](#).

Public Methods

Name	Description
 GetCellData	Gets data from the specified table cell of this Hole Wizard fastener table.
 GetColumnNames	Gets the names of all the columns in this Hole Wizard fastener table.

 GetRowCount	Gets the number of rows in this Hole Wizard fastener table.
 GetRowData	Gets data for the specified row of this Hole Wizard fastener table.

[Top](#)

See Also

[IHoleDataTable Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IHoleDataTable Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHoleDataTable Interface

The following tables list the members exposed by [IHoleDataTable](#).

Public Properties

Name	Description
 FastenerID	Gets the ID of the fastener associated with this Hole Wizard fastener table.
 StandardName	Gets the name of the Hole Wizard standard associated with this Hole Wizard fastener table.
 TableTypeID	Gets the fastener table type ID associated with this Hole Wizard fastener table.

[Top](#)

Public Methods

Name	Description
 GetCellData	Gets data from the specified table cell of this Hole Wizard fastener table.
 GetColumnNames	Gets the names of all the columns in this Hole Wizard fastener table.
 GetRowCount	Gets the number of rows in this Hole Wizard fastener table.
 GetRowData	Gets data for the specified row of this Hole Wizard fastener table.

[Top](#)

See Also

[IHoleDataTable Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IHoleDataTable Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHoleDataTable Interface

For a list of all members of this type, see [IHoleDataTable members](#).

Public Properties

Name	Description
 FastenerID	Gets the ID of the fastener associated with this Hole Wizard fastener table.
 StandardName	Gets the name of the Hole Wizard standard associated with this Hole Wizard fastener table.
 TableTypeID	Gets the fastener table type ID associated with this Hole Wizard fastener table.

[Top](#)

See Also

[IHoleDataTable Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

FastenerID Property (IHoleDataTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleDataTable Interface](#) : FastenerID Property (IHoleDataTable)

Gets the ID of the fastener associated with this Hole Wizard fastener table.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property FastenerID As System.Integer

Visual Basic (Usage)



```
Dim instance As IHoleDataTable
Dim value As System.Integer

value = instance.FastenerID
```

C#

```
System.int FastenerID {get;}
```

C++/CLI

```
property System.int FastenerID {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Fastener ID

Visual Basic for Applications (VBA) Syntax

See [HoleDataTable::FastenerID](#).

Example

See the [IHoleDataTable](#) example.

See Also

[IHoleDataTable Interface](#)
[IHoleDataTable Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetCellData Method (IHoleDataTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleDataTable Interface](#) : GetCellData Method (IHoleDataTable)

Gets data from the specified table cell of this Hole Wizard fastener table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCellData( _
    ByVal ColumnName As System.String, _
    ByVal RowIndex As System.Integer, _
```

```
ByRef CellData As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHoleDataTable  
Dim ColumnName As System.String  
Dim RowIndex As System.Integer  
Dim CellData As System.String  
Dim value As System.Boolean  
  
value = instance.GetCellData(ColumnName, RowIndex, CellData)
```

C#

```
System.bool GetCellData(  
    System.string ColumnName,  
    System.int RowIndex,  
    out System.string CellData  
)
```

C++/CLI

```
System.bool GetCellData(  
    & System.String^ ColumnName,  
    & System.int RowIndex,  
    & [Out] System.String^ CellData  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ColumnName
Column name (see **Remarks**)
RowIndex
0-based row index
CellData
Cell data

Return Value

True if cell data successfully retrieved, false if not

Visual Basic for Applications (VBA) Syntax

See [HoleDataTable::GetCellData](#).

Example

See the [IHoleDataTable](#) example.

Remarks

To set:

- ColumnName, use [IHoleDataTable::GetColumnNames](#).
- RowIndex, use [IHoleDataTable::GetRowCount](#).

See Also

[IHoleDataTable Interface](#)
[IHoleDataTable Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleDataTable Interface](#) : GetColumnNames Method (IHoleDataTable)

Gets the names of all the columns in this Hole Wizard fastener table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetColumnNames( _  
    ByRef ColumnNames As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHoleDataTable  
Dim ColumnNames As System.Object  
Dim value As System.Boolean  
  
value = instance.GetColumnNames(ColumnNames)
```

C#

```
System.bool GetColumnNames(  
    out System.object ColumnNames  
)
```

C++/CLI

```
System.bool GetColumnNames(  
    & [Out] System.Object^ ColumnNames  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ColumnNames
Array of column names

Return Value

True if column names successfully retrieved, false if not

Visual Basic for Applications (VBA) Syntax

See [HoleDataTable::GetColumnNames](#).

Example

See the [IHoleDataTable](#) example.

See Also

[IHoleDataTable Interface](#)
[IHoleDataTable Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRowCount Method (IHoleDataTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleDataTable Interface](#) : GetRowCount Method (IHoleDataTable)

Gets the number of rows in this Hole Wizard fastener table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRowCount( _  
    ByRef RowCount As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHoleDataTable  
Dim RowCount As System.Integer  
Dim value As System.Boolean  
  
value = instance.GetRowCount(RowCount)
```

C#

```
System.bool GetRowCount(  
    out System.int RowCount  
)
```

C++/CLI

```
System.bool GetRowCount(  
    & [Out] System.int RowCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RowCount
Number of rows

Return Value

True if number of rows successfully retrieved, false if not

Visual Basic for Applications (VBA) Syntax

See [HoleDataTable::GetRowCount](#).

See Also

[IHoleDataTable Interface](#)
[IHoleDataTable Members](#)
[IHoleDataTable::GetCellData Method \(\)](#)
[IHoleDataTable::GetRowData Method \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRowData Method (IHoleDataTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleDataTable Interface](#) : GetRowData Method (IHoleDataTable)

Gets data for the specified row of this Hole Wizard fastener table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRowData( _  
    ByVal RowIndex As System.Integer, _  
    ByRef RowData As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHoleDataTable
Dim RowIndex As System.Integer
Dim RowData As System.Object
Dim value As System.Boolean

value = instance.GetRowData(RowIndex, RowData)
```

C#

```
System.bool GetRowData(
    System.int RowIndex,
    out System.object RowData
)
```

C++/CLI

```
System.bool GetRowData(
    & System.int RowIndex,
    & [Out] System.Object^ RowData
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RowIndex
0-based index of row
RowData
Row data

Return Value

True if row data successfully retrieved, false if not

Visual Basic for Applications (VBA) Syntax

See [HoleDataTable::GetRowData](#).

Remarks

To set RowIndex, use [IHoleDataTable::GetRowCount](#).

See Also

[IHoleDataTable Interface](#)
[IHoleDataTable Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

StandardName Property (IHoleDataTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleDataTable Interface](#) : StandardName Property (IHoleDataTable)

Gets the name of the Hole Wizard standard associated with this Hole Wizard fastener table.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property StandardName As System.String
```

Visual Basic (Usage)

```
Dim instance As IHoleDataTable
Dim value As System.String
```




```
value = instance.StandardName
```

C#

```
System.string StandardName {get;}
```

C++/CLI

```
property System.String^ StandardName {  
    System.String^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Hole Wizard standard

Visual Basic for Applications (VBA) Syntax

See [HoleDataTable::StandardName](#).

Example

See the [IHoleDataTable](#) example.

See Also

[IHoleDataTable Interface](#)
[IHoleDataTable Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

TableTypeID Property (IHoleDataTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleDataTable Interface](#) : TableTypeID Property (IHoleDataTable)

Gets the fastener table type ID associated with this Hole Wizard fastener table.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property TableTypeID As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IHoleDataTable  
Dim value As System.Integer
```

```
value = instance.TableTypeID
```

C#

```
System.int TableTypeID {get;}
```

C++/CLI

```
property System.int TableTypeID {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Fastener table type ID as defined in [swFastenerTableTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [HoleDataTable::TableTypeID](#).

Example

See the [IHoleDataTable](#) example.

See Also

[IHoleDataTable Interface](#)
[IHoleDataTable Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

IHoleSeriesFeatureData (Type)

IHoleSeriesFeatureData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHoleSeriesFeatureData Interface

Obsolete. Superseded by [IHoleSeriesFeatureData2](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IHoleSeriesFeatureData
```

Visual Basic (Usage)

```
Dim instance As IHoleSeriesFeatureData
```

C#

```
public interface IHoleSeriesFeatureData
```

C++/CLI

```
public interface class IHoleSeriesFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData](#).

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

See Also

[IHoleSeriesFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeature::ModifyDefinition Method](#)
[IFeature::!ModifyDefinition2 Method](#)

IHoleSeriesFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHoleSeriesFeatureData Interface

The following tables list the members exposed by [IHoleSeriesFeatureData](#).

Public Properties

Name	Description
BoltDiameter	Obsolete. Superseded by IHoleSeriesFeatureData2::BoltDiameter .
BoltHeadDiameter	Obsolete. Superseded by IHoleSeriesFeatureData2::BoltHeadDiameter .
EndFace	Obsolete. Superseded by IHoleSeriesFeatureData2::EndFace .
FastenerBottomHoleType	Obsolete. Superseded by IHoleSeriesFeatureData2::FastenerBottomHoleType .
FastenerDefaultUnits	Obsolete. Superseded by IHoleSeriesFeatureData2::FastenerDefaultUnits .
FastenerHoleCount	Obsolete. Superseded by IHoleSeriesFeatureData2::FastenerHoleCount .

 FastenerTopHoleType	Obsolete. Superseded by IHoleSeriesFeatureData2::FastenerTopHoleType .
 Material	Obsolete. Superseded by IHoleSeriesFeatureData2::Material .
 NutDiameter	Obsolete. Superseded by IHoleSeriesFeatureData2::NutDiameter .
 Preload	Obsolete. Superseded by IHoleSeriesFeatureData2::Preload .
 Size	Obsolete. Superseded by IHoleSeriesFeatureData2::Size .
 Standard	Obsolete. Superseded by IHoleSeriesFeatureData2::Standard .
 StartFace	Obsolete. Superseded by IHoleSeriesFeatureData2::StartFace .
 Type	Obsolete. Superseded by IHoleSeriesFeatureData2::Type .

[Top](#)

Public Methods

Name	Description
 AccessSelections	Obsolete. Superseded by IHoleSeriesFeatureData2::AccessSelections .
 GetComponents	Obsolete. Superseded by IHoleSeriesFeatureData2::GetComponents .
 GetComponentsCount	Obsolete. Superseded by IHoleSeriesFeatureData2::GetComponentsCount .
 GetHoleBottomMateEntity	Obsolete. Superseded by IHoleSeriesFeatureData2::GetHoleBottomMateEntity .
 GetHoleTopMateEntity	Obsolete. Superseded by IHoleSeriesFeatureData2::GetHoleTopMateEntity .
 GetSketchPoints	Obsolete. Superseded by IHoleSeriesFeatureData2::GetSketchPoints .
 GetSketchPointsCount	Obsolete. Superseded by IHoleSeriesFeatureData2::GetSketchPointsCount .
 IAccessSelections	Obsolete. Superseded by IHoleSeriesFeatureData2::IAccessSelections .
 IGetComponents	Obsolete. Superseded by IHoleSeriesFeatureData2::IGetComponents .
 IGetHoleBottomMateEntity	Obsolete. Superseded by IHoleSeriesFeatureData2::IGetHoleBottomMateEntity .
 IGetHoleTopMateEntity	Obsolete. Superseded by IHoleSeriesFeatureData2::IGetHoleTopMateEntity .
 IGetSketchPoints	Obsolete. Superseded by IHoleSeriesFeatureData2::IGetSketchPoints .
 ReleaseSelectionAccess	Obsolete. Superseded by IHoleSeriesFeatureData2::ReleaseSelectionAccess .

[Top](#)

See Also

[IHoleSeriesFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeature::ModifyDefinition Method](#)
[IFeature::IModifyDefinition2 Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IHoleSeriesFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHoleSeriesFeatureData Interface

For a list of all members of this type, see [IHoleSeriesFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Obsolete. Superseded by IHoleSeriesFeatureData2::AccessSelections .
 GetComponents	Obsolete. Superseded by IHoleSeriesFeatureData2::GetComponents .
 GetComponentsCount	Obsolete. Superseded by IHoleSeriesFeatureData2::GetComponentsCount .
 GetHoleBottomMateEntity	Obsolete. Superseded by IHoleSeriesFeatureData2::GetHoleBottomMateEntity .
 GetHoleTopMateEntity	Obsolete. Superseded by IHoleSeriesFeatureData2::GetHoleTopMateEntity .
 GetSketchPoints	Obsolete. Superseded by IHoleSeriesFeatureData2::GetSketchPoints .
 GetSketchPointsCount	Obsolete. Superseded by IHoleSeriesFeatureData2::GetSketchPointsCount .
 IAccessSelections	Obsolete. Superseded by IHoleSeriesFeatureData2::IAccessSelections .
 IGetComponents	Obsolete. Superseded by IHoleSeriesFeatureData2::IGetComponents .
 IGetHoleBottomMateEntity	Obsolete. Superseded by IHoleSeriesFeatureData2::IGetHoleBottomMateEntity .
 IGetHoleTopMateEntity	Obsolete. Superseded by IHoleSeriesFeatureData2::IGetHoleTopMateEntity .
 IGetSketchPoints	Obsolete. Superseded by IHoleSeriesFeatureData2::IGetSketchPoints .
 ReleaseSelectionAccess	Obsolete. Superseded by IHoleSeriesFeatureData2::ReleaseSelectionAccess .

[Top](#)

See Also

- [IHoleSeriesFeatureData Interface](#)
- [SolidWorks.Interop.sldworks Namespace](#)
- [IFeature::ModifyDefinition Method](#)
- [IFeature::IModifyDefinition2 Method](#)

IHoleSeriesFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHoleSeriesFeatureData Interface

For a list of all members of this type, see [IHoleSeriesFeatureData members](#).

Public Properties

Name	Description
 BoltDiameter	Obsolete. Superseded by IHoleSeriesFeatureData2::BoltDiameter .
 BoltHeadDiameter	Obsolete. Superseded by IHoleSeriesFeatureData2::BoltHeadDiameter .
 EndFace	Obsolete. Superseded by IHoleSeriesFeatureData2::EndFace .
 FastenerBottomHoleType	Obsolete. Superseded by IHoleSeriesFeatureData2::FastenerBottomHoleType .
 FastenerDefaultUnits	Obsolete. Superseded by IHoleSeriesFeatureData2::FastenerDefaultUnits .
 FastenerHoleCount	Obsolete. Superseded by IHoleSeriesFeatureData2::FastenerHoleCount .

 FastenerTopHoleType	Obsolete. Superseded by IHoleSeriesFeatureData2::FastenerTopHoleType .
 Material	Obsolete. Superseded by IHoleSeriesFeatureData2::Material .
 NutDiameter	Obsolete. Superseded by IHoleSeriesFeatureData2::NutDiameter .
 Preload	Obsolete. Superseded by IHoleSeriesFeatureData2::Preload .
 Size	Obsolete. Superseded by IHoleSeriesFeatureData2::Size .
 Standard	Obsolete. Superseded by IHoleSeriesFeatureData2::Standard .
 StartFace	Obsolete. Superseded by IHoleSeriesFeatureData2::StartFace .
 Type	Obsolete. Superseded by IHoleSeriesFeatureData2::Type .

[Top](#)

See Also

[IHoleSeriesFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeature::ModifyDefinition Method](#)
[IFeature::IModifyDefinition2 Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AccessSelections Method (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : AccessSelections Method (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::AccessSelections](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _
    ByVal TopDoc As System.Object, _
    ByVal Component As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.Object^ TopDoc,
    & System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component in which the feature is to be modified

Return Value

True if the selections are successfully accessed, false if not

 Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData::AccessSelections](#).

 Remarks

To modify a feature in a...	Then...
Part	• TopDoc argument is the IModelDoc2 for the part • Component argument is NULL
Assembly	• TopDoc is the IModelDoc2 object for the assembly • Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IHoleSeriesFeatureData::ReleaseSelectionAccess](#) if you did not

 See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)
[IHoleSeriesFeatureData::IAccessSelections Method](#)

 Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

BoltDiameter Property (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : BoltDiameter Property (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::BoltDiameter](#).

 .NET Syntax

Visual Basic (Declaration)

ReadOnly Property BoltDiameter As System.Double

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData  
Dim value As System.Double  
  
value = instance.BoltDiameter
```

C#

```
System.double BoltDiameter {get;}
```

C++/CLI

```
property System.double BoltDiameter {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Diameter of bolt

Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData::BoltDiameter](#).

See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)
[IHoleSeriesFeatureData::BoltHeadDiameter Property](#)
[IHoleSeriesFeatureData::NutDiameter Property](#)
[IHoleSeriesFeatureData::Material Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

BoltHeadDiameter Property (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : BoltHeadDiameter Property (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::BoltHeadDiameter](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property BoltHeadDiameter As System.Double
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData  
Dim value As System.Double  
  
value = instance.BoltHeadDiameter
```

C#

```
System.double BoltHeadDiameter {get;}
```

C++/CLI

```
property System.double BoltHeadDiameter {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Diameter of head of the bolt

Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData::BoltHeadDiameter](#).

See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)
[IHoleSeriesFeatureData::BoltDiameter Property](#)
[IHoleSeriesFeatureData::NutDiameter Property](#)
[IHoleSeriesFeatureData::Material Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

EndFace Property (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : EndFace Property (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::EndFace](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property EndFace As System.Object
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData  
Dim value As System.Object
```

```
value = instance.EndFace
```

C#

```
System.object EndFace {get;}
```

C++/CLI

```
property System.Object^ EndFace {  
    System.Object^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

End [face](#)

Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData::EndFace](#).

See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

FastenerBottomHoleType Property (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : FastenerBottomHoleType Property (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::FastenerBottomHoleType](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property FastenerBottomHoleType As System.Short
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData  
Dim value As System.Short
```

```
value = instance.FastenerBottomHoleType
```

C#

```
System.short FastenerBottomHoleType {get;}
```

C++/CLI

```
property System.short FastenerBottomHoleType {  
    System.short get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Fastener bottom hole type as defined in [swWzdHoleStandardFastenerTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData::FastenerBottomHoleType](#).

See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)
[IHoleSeriesFeatureData::FastenerDefaultUnits Property](#)
[IHoleSeriesFeatureData::FastenerHoleCount Property](#)
[IHoleSeriesFeatureData::FastenerTopHoleType Property](#)
[IHoleSeriesFeatureData::Size Property](#)
[IHoleSeriesFeatureData::Type Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FastenerDefaultUnits Property (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : FastenerDefaultUnits Property (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::FastenerDefaultUnits](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property FastenerDefaultUnits As System.String
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData  
Dim value As System.String  
  
value = instance.FastenerDefaultUnits
```

C#

```
System.string FastenerDefaultUnits {get;}
```

C++/CLI

```
property System.String^ FastenerDefaultUnits {  
    System.String^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Fastener default units

Visual Basic for Applications (VBA) Syntax

See [IHoleSeriesFeatureData::FastenerDefaultUnits](#).

See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)
[IHoleSeriesFeatureData::FastenerBottomHoleType Property](#)
[IHoleSeriesFeatureData::FastenerHoleCount Property](#)
[IHoleSeriesFeatureData::FastenerTopHoleType Property](#)
[IHoleSeriesFeatureData::Size Property](#)
[IHoleSeriesFeatureData::Type Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FastenerHoleCount Property (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : FastenerHoleCount Property (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::FastenerHoleCount](#).

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property FastenerHoleCount As System.Integer

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData  
Dim value As System.Integer
```

```
value = instance.FastenerHoleCount
```

C#

```
System.int FastenerHoleCount {get;}
```

C++/CLI

```
property System.int FastenerHoleCount {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of fastener holes

Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData::FastenerHoleCount](#).

See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)
[IHoleSeriesFeatureData::FastenerBottomHoleType Property](#)
[IHoleSeriesFeatureData::FastenerDefaultUnits Property](#)
[IHoleSeriesFeatureData::FastenerTopHoleType Property](#)
[IHoleSeriesFeatureData::Size Property](#)
[IHoleSeriesFeatureData::Type Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FastenerTopHoleType Property (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : FastenerTopHoleType Property (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::FastenerTopHoleType](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property FastenerTopHoleType As System.Short
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData  
Dim value As System.Short  
  
value = instance.FastenerTopHoleType
```

C#

```
System.short FastenerTopHoleType {get;}
```

C++/CLI

```
property System.short FastenerTopHoleType {  
    System.short get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Fastener top hole type as defined in [swWzdHoleStandardFastenerTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData::FastenerTopHoleType](#).

See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)
[IHoleSeriesFeatureData::FastenerBottomHoleType Property](#)
[IHoleSeriesFeatureData::FastenerDefaultUnits Property](#)
[IHoleSeriesFeatureData::FastenerHoleCount Property](#)
[IHoleSeriesFeatureData::Size Property](#)
[IHoleSeriesFeatureData::Type Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetComponents Method (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : GetComponents Method (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::GetComponents](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetComponents() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData  
Dim value As System.Object
```

```
value = instance.GetComponents()
```

C#

```
System.Object GetComponents()
```

C++/CLI

```
System.Object^ GetComponents();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [components](#) in this hole series

Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData::GetComponents](#).

See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)
[IHoleSeriesFeatureData::IGetComponents Method](#)
[IHoleSeriesFeatureData::GetComponentsCount Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetComponentsCount Method (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : GetComponentsCount Method (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::GetComponentsCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetComponentsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData  
Dim value As System.Integer
```

```
value = instance.GetComponentsCount()
```

C#

```
System.int GetComponentsCount()
```

C++/CLI

```
System.int GetComponentsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of components in this hole series

Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData::GetComponentsCount](#).

Remarks

Call this method before calling [IHoleSeriesFeatureData::IGetComponents](#) to get the size of the array for that method.

See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)
[IHoleSeriesFeatureData::GetComponents Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetHoleBottomMateEntity Method (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : GetHoleBottomMateEntity Method (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::GetHoleBottomMateEntity](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetHoleBottomMateEntity( _  
    ByVal HoleInstance As System.Integer, _  
    ByVal HoleType As System.Short _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData  
Dim HoleInstance As System.Integer  
Dim HoleType As System.Short  
Dim value As System.Object  
  
value = instance.GetHoleBottomMateEntity(HoleInstance, HoleType)
```

C#

```
System.object GetHoleBottomMateEntity(  
    System.int HoleInstance,  
    System.short HoleType  
)
```

C++/CLI

```
System.Object^ GetHoleBottomMateEntity(  
& System.int HoleInstance,  
& System.short HoleType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

HoleInstance

Index number of the hole whose entity you want

HoleType

Type of hole as defined by [swWzdHoleTypes_e](#)

Return Value

[Entity](#) to which the bottom of the hole is mated

Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData::GetHoleBottomMateEntity](#).

See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)
[IHoleSeriesFeatureData::GetHoleTopMateEntity Method](#)
[IHoleSeriesFeatureData::GetHoleTopMateEntity Method](#)
[IHoleSeriesFeatureData::GetHoleTopMateEntity Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetHoleTopMateEntity Method (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : GetHoleTopMateEntity Method (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::GetHoleTopMateEntity](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetHoleTopMateEntity( _  
    ByVal HoleInstance As System.Integer, _  
    ByVal HoleType As System.Short _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData  
Dim HoleInstance As System.Integer  
Dim HoleType As System.Short  
Dim value As System.Object  
  
value = instance.GetHoleTopMateEntity(HoleInstance, HoleType)
```

C#

```
System.object GetHoleTopMateEntity(  
    System.int HoleInstance,  
    System.short HoleType  
)
```

C++/CLI

```
System.Object^ GetHoleTopMateEntity(  
& System.int HoleInstance,  
& System.short HoleType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

HoleInstance

Index number of the hole whose entity you want

HoleType

Type of hole as defined by [swWzdHoleTypes_e](#)

Return Value

[Entity](#) to which the top of the hole is mated

Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData::GetHoleTopMateEntity](#).

See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)
[IHoleSeriesFeatureData::IGetHoleTopMateEntity Method](#)
[IHoleSeriesFeatureData::GetHoleBottomMateEntity Method](#)
[IHoleSeriesFeatureData::IGetHoleBottomMateEntity Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSketchPoints Method (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : GetSketchPoints Method (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::GetSketchPoints](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetSketchPoints() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData  
Dim value As System.Object  
  
value = instance.GetSketchPoints()
```

C#

```
System.object GetSketchPoints()
```

C++/CLI

```
System.Object^ GetSketchPoints();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Center-hole [sketch points](#)

Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData::GetSketchPoints](#).

See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)
[IHoleSeriesFeatureData::IGetSketchPoints Method](#)
[IHoleSeriesFeatureData::GetSketchPointsCount Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSketchPointsCount Method (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : GetSketchPointsCount Method (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::GetSketchPointsCount](#).

.NET Syntax

Visual Basic (Declaration)

Function GetSketchPointsCount() As System.Integer

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData
Dim value As System.Integer

value = instance.GetSketchPointsCount()
```

C#

```
System.int GetSketchPointsCount()
```

C++/CLI

```
System.int GetSketchPointsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of center-hole sketch points in this hole series

Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData::GetSketchPointsCount](#).

Remarks

Call this method before calling [IHoleSeriesFeatureData::!GetSketchPoints](#) to get the size of the array for that method.

See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)
[IHoleSeriesFeatureData::GetSketchPoints Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections Method (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : IAccessSelections Method (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::IAccessSelections](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _
    ByVal TopDoc As ModelDoc, _
    ByVal Component As Component _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData
Dim TopDoc As ModelDoc
Dim Component As Component
Dim value As System.Boolean

value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(
    ModelDoc TopDoc,
    Component Component
)
```

C++/CLI

```
System.bool IAccessSelections(
    & ModelDoc^ TopDoc,
    & Component^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document

Component

Component in which the feature is to be modified

Return Value

True if the selections are successfully accessed, false if not

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IHoleSeriesFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IHoleSeriesFeatureData Interface](#)

[IHoleSeriesFeatureData Members](#)

[IHoleSeriesFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetComponent Method (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : IGetComponent Method (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::IGetComponent](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetComponent( _
    ByVal NCount As System.Integer _
) As Component2
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData
Dim NCount As System.Integer
Dim value As Component2
```

```
value = instance.IGetComponent(NCount)
```

C#

```
Component2 IGetComponents(  
    System.int NCount  
)
```

C++/CLI

```
Component2^ IGetComponents(  
&    System.int NCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NCount

Number of components in this hole series

Return Value

- in-process, unmanaged C++: Pointer to an array of [components](#) in this hole series
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IHoleSeriesFeatureData::GetComponentsCount](#) to get the value for NCount.

See Also

[IHoleSeriesFeatureData Interface](#)

[IHoleSeriesFeatureData Members](#)

[IHoleSeriesFeatureData::GetComponents Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetHoleBottomMateEntity Method (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : IGetHoleBottomMateEntity Method (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::IGetHoleBottomMateEntity](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetHoleBottomMateEntity( _  
    ByVal HoleInstance As System.Integer, _  
    ByVal HoleType As System.Short _  
) As Entity
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData  
Dim HoleInstance As System.Integer  
Dim HoleType As System.Short  
Dim value As Entity
```

```
value = instance.IGetHoleBottomMateEntity(HoleInstance, HoleType)
```

C#

```
Entity IGetHoleBottomMateEntity(  
    System.int HoleInstance,  
    System.short HoleType  
)
```

C++/CLI

```
Entity^ IGetHoleBottomMateEntity(  
& System.int HoleInstance,  
& System.short HoleType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

HoleInstance

Index number of the hole whose entity you want

HoleType

Type of hole as defined by [swWzdHoleTypes_e](#)

Return Value

[Entity](#) to which the bottom of the hole is mated

See Also

[IHoleSeriesFeatureData Interface](#)

[IHoleSeriesFeatureData Members](#)

[IHoleSeriesFeatureData::GetHoleBottomMateEntity Method](#)

[IHoleSeriesFeatureData::GetHoleTopMateEntity Method](#)

[IHoleSeriesFeatureData::IGetHoleTopMateEntity Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetHoleTopMateEntity Method (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : IGetHoleTopMateEntity Method (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::IGetHoleTopMateEntity](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetHoleTopMateEntity( _  
    ByVal HoleInstance As System.Integer, _  
    ByVal HoleType As System.Short _  
) As Entity
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData  
Dim HoleInstance As System.Integer  
Dim HoleType As System.Short  
Dim value As Entity
```

```
value = instance.IGetHoleTopMateEntity(HoleInstance, HoleType)
```

C#

```
Entity IGetHoleTopMateEntity(  
    System.int HoleInstance,  
    System.short HoleType  
)
```

C++/CLI

```
Entity^ IGetHoleTopMateEntity(  
& System.int HoleInstance,  
& System.short HoleType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

HoleInstance
Index number of the hole whose entity you want
HoleType
Type of hole as defined by [swWzdHoleTypes_e](#)

Return Value

[Entity](#) to which the top of the hole is mated

See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)
[IHoleSeriesFeatureData::GetHoleTopMateEntity Method](#)
[IHoleSeriesFeatureData::GetHoleBottomMateEntity Method](#)
[IHoleSeriesFeatureData::!GetHoleBottomMateEntity Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetSketchPoints Method (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : IGetSketchPoints Method (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::IGetSketchPoints](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSketchPoints( _  
    ByVal NCount As System.Integer _  
) As SketchPoint
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData  
Dim NCount As System.Integer  
Dim value As SketchPoint  
  
value = instance.IGetSketchPoints(NCount)
```

C#

```
SketchPoint IGetSketchPoints(  
    System.int NCount  
)
```

C++/CLI

```
SketchPoint^ IGetSketchPoints(  
    & System.int NCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NCount
Number of center-hole sketch points

Return Value

- in-process, unmanaged C++: Pointer to an array of center-hole [sketch points](#)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IHoleSeriesFeatureData::GetSketchPointsCount](#) to get the value for NCount.

See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)
[IHoleSeriesFeatureData::GetSketchPoints Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Material Property (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : Material Property (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::Material](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Material As System.String
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData  
Dim value As System.String  
  
value = instance.Material
```

C#

```
System.string Material {get;}
```

C++/CLI

```
property System.String^ Material {  
    System.String^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Bolt material name

Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData::Material](#).

Remarks

The material value is not available in the SOLIDWORKS Toolbox database.

See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)
[IHoleSeriesFeatureData::BoltDiameter Property](#)
[IHoleSeriesFeatureData::BoltHeadDiameter Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

NutDiameter Property (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : NutDiameter Property (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::NutDiameter](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property NutDiameter As System.Double
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData  
Dim value As System.Double  
  
value = instance.NutDiameter
```

C#

```
System.double NutDiameter {get;}
```

C++/CLI

```
property System.double NutDiameter {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Diameter of nut

Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData::NutDiameter](#).

See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)
[IHoleSeriesFeatureData::BoltDiameter Property](#)
[IHoleSeriesFeatureData::BoltHeadDiameter Property](#)
[IHoleSeriesFeatureData::Material Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Preload Property (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : Preload Property (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::Preload](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Preload As System.String
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData  
Dim value As System.String  
  
value = instance.Preload
```

C#

```
System.string Preload {get;}
```

C++/CLI

```
property System.String^ Preload {  
    System.String^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Preload information

Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData::Preload](#).

Remarks

The preload value is not available in the SOLIDWORKS Toolbox database.

See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : ReleaseSelectionAccess Method (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::ReleaseSelectionAccess](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData::ReleaseSelectionAccess](#).

Remarks

[IHoleSeriesFeatureData::AccessSelections](#) and [IHoleSeriesFeatureData::!AccessSelections](#) put the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefintion2](#) if you did.

See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Size Property (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : Size Property (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::Size](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Size( _  
    ByVal HoleSeriesWhichPart As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData  
Dim HoleSeriesWhichPart As System.Integer  
Dim value As System.String  
  
value = instance.Size(HoleSeriesWhichPart)
```

C#

```
System.string Size(  
    System.int HoleSeriesWhichPart  
) {get;}
```

C++/CLI

```
property System.String^ Size {  
    System.String^ get(System.int HoleSeriesWhichPart);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

HoleSeriesWhichPart

Which part the hole series passes through as defined by [swHoleSeriesWhichParts_e](#)

Property Value

Fastener size

Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData::Size](#).

See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)
[IHoleSeriesFeatureData::FastenerBottomHoleType Property](#)

[IHoleSeriesFeatureData::FastenerDefaultUnits Property](#)
[IHoleSeriesFeatureData::FastenerHoleCount Property](#)
[IHoleSeriesFeatureData::FastenerTopHoleType Property](#)
[IHoleSeriesFeatureData::Type Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Standard Property (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : Standard Property (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::Standard](#).

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Standard As System.Integer

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData
Dim value As System.Integer

value = instance.Standard
```

C#

```
System.int Standard {get;}
```

C++/CLI

```
property System.int Standard {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Design standard as defined in [swWzdHoleStandards_e](#)

Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData::Standard](#).

See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

StartFace Property (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : StartFace Property (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::StartFace](#).

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property StartFace As System.Object

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData  
Dim value As System.Object
```

```
value = instance.StartFace
```

C#

```
System.object StartFace {get;}
```

C++/CLI

```
property System.Object^ StartFace {  
    System.Object^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Start [face](#)

Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData::StartFace](#).

See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Type Property (IHoleSeriesFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData Interface](#) : Type Property (IHoleSeriesFeatureData)

Obsolete. Superseded by [IHoleSeriesFeatureData2::Type](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Type( _  
    ByVal HoleSeriesWhichPart As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData  
Dim HoleSeriesWhichPart As System.Integer  
Dim value As System.Integer
```

```
value = instance.Type(HoleSeriesWhichPart)
```

C#

```
System.int Type(  
    System.int HoleSeriesWhichPart  
) {get;}
```

C++/CLI

```
property System.int Type {  
    System.int get(System.int HoleSeriesWhichPart);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

HoleSeriesWhichPart

Which part the hole series passes through as defined by [swHoleSeriesWhichParts_e](#)

Property Value

Type of fastener as defined by [swWzdHoleStandardFastenerTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData::Type](#).

See Also

[IHoleSeriesFeatureData Interface](#)
[IHoleSeriesFeatureData Members](#)
[IHoleSeriesFeatureData::FastenerBottomHoleType Property](#)
[IHoleSeriesFeatureData::FastenerDefaultUnits Property](#)
[IHoleSeriesFeatureData::FastenerHoleCount Property](#)
[IHoleSeriesFeatureData::FastenerTopHoleType Property](#)
[IHoleSeriesFeatureData::Size Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0