

# SOLIDWORKS API (.NET VBA C#) — Reference

## (134/337): IHoleSeriesFeatureData2- IHoleStandardsData

SOLIDWORKS API Documentation (converted from CHM)

# IHoleSeriesFeatureData2 (Type)

## IHoleSeriesFeatureData2 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHoleSeriesFeatureData2 Interface

Allows access to the data that defines a hole series feature.  
**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

### .NET Syntax

Visual Basic (Declaration)

```
Public Interface IHoleSeriesFeatureData2
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2
```

C#

```
public interface IHoleSeriesFeatureData2
```

C++/CLI

```
public interface class IHoleSeriesFeatureData2
```

### Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData2](#).

### Example

[Get Hole Series Information \(VBA\)](#)  
[Get Hole Series Information \(VB.NET\)](#)  
[Get Hole Series Information \(C#\)](#)

### Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

### Access Diagram

[HoleSeriesFeatureData2](#)

### See Also

[IHoleSeriesFeatureData2 Members](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IFeature::ModifyDefinition Method \(\)](#)  
[IFeature::IModifyDefinition2 Method \(\)](#)

## IHoleSeriesFeatureData2 Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHoleSeriesFeatureData2 Interface

For a list of all members of this type, see [IHoleSeriesFeatureData2 members](#).

### Public Methods

| Name                                                                                                                 | Description                                                          |
|----------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------|
|  <a href="#">AccessSelections</a> | Gains access to the selections that define this hole series feature. |
| <a href="#">GetComponents</a>                                                                                        | Gets the components in this hole series.                             |

|                                                                                   |                                          |                                                                               |
|-----------------------------------------------------------------------------------|------------------------------------------|-------------------------------------------------------------------------------|
|   |                                          |                                                                               |
|  | <a href="#">GetComponentsCount</a>       | Gets the number of components in this hole series.                            |
|  | <a href="#">GetHoleBottomMateEntity</a>  | Gets the entity to which the bottom of the hole is mated in this hole series. |
|  | <a href="#">GetHoleTopMateEntity</a>     | Gets the entity to which the top of the hole is mated in this hole series.    |
|  | <a href="#">GetSketchPoints</a>          | Gets the center-hole sketch points in this hole series.                       |
|  | <a href="#">GetSketchPointsCount</a>     | Gets the number of center-hole sketch points in this hole series.             |
|  | <a href="#">IAccessSelections</a>        | Gains access to the selections that define this hole series feature.          |
|  | <a href="#">IGetComponents</a>           | Gets the components in this hole series.                                      |
|  | <a href="#">IGetHoleBottomMateEntity</a> | Gets the entity to which the bottom of the hole is mated in this hole series. |
|  | <a href="#">IGetHoleTopMateEntity</a>    | Gets the entity to which the top of the hole is mated in this hole series.    |
|  | <a href="#">IGetSketchPoints</a>         | Gets the center-hole sketch points in this hole series.                       |
|  | <a href="#">ReleaseSelectionAccess</a>   | Releases access to the selections that define this hole series feature.       |

[Top](#)

## See Also

[IHoleSeriesFeatureData2 Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IFeature::ModifyDefinition Method \(\)](#)  
[IFeature::IModifyDefinition2 Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IHoleSeriesFeatureData2 Interface Members

[See Also](#) [Properties](#) [Methods](#)

|                                                                                   |                                                                                                           |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|
|  | <a href="#">SolidWorks.Interop.sldworks Namespace</a> : <a href="#">IHoleSeriesFeatureData2 Interface</a> |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|

The following tables list the members exposed by [IHoleSeriesFeatureData2](#).

## Public Properties

| Name                                                                                                                       | Description                                                          |
|----------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------|
|  <a href="#">BoltDiameter</a>           | Gets the diameter of the bolt in this hole series.                   |
|  <a href="#">BoltHeadDiameter</a>       | Gets the diameter of the head of the bolt in this hole series.       |
|  <a href="#">EndFace</a>                | Gets the end face for this hole series.                              |
|  <a href="#">FastenerBottomHoleType</a> | Gets the fastener bottom hole type in this hole series.              |
|  <a href="#">FastenerDefaultUnits</a>   | Gets the fastener default units for this hole series.                |
|  <a href="#">FastenerHoleCount</a>      | Gets the number of fastener holes in this hole series.               |
|  <a href="#">FastenerTopHoleType</a>    | Gets the fastener top hole type for this hole series.                |
|  <a href="#">Material</a>               | Gets the name of the bolt material in this hole series.              |
|  <a href="#">NutDiameter</a>            | Gets the diameter of the nut in this hole series.                    |
|  <a href="#">Preload</a>                | Gets the preload information for this hole series.                   |
|  <a href="#">Size</a>                   | Gets the fastener size in the specified part in this hole series.    |
|  <a href="#">Standard</a>               | Gets the design standard for this hole series.                       |
|  <a href="#">StartFace</a>              | Gets the start face for this hole series.                            |
|  <a href="#">Type</a>                   | Gets the type of fastener in the specified part in this hole series. |

[Top](#)

## Public Methods

| Name                                                                                                                 | Description                                                          |
|----------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------|
|  <a href="#">AccessSelections</a> | Gains access to the selections that define this hole series feature. |
|  <a href="#">GetComponents</a>    | Gets the components in this hole series.                             |

|                                                                                   |                                          |                                                                               |
|-----------------------------------------------------------------------------------|------------------------------------------|-------------------------------------------------------------------------------|
|   |                                          |                                                                               |
|  | <a href="#">GetComponentsCount</a>       | Gets the number of components in this hole series.                            |
|  | <a href="#">GetHoleBottomMateEntity</a>  | Gets the entity to which the bottom of the hole is mated in this hole series. |
|  | <a href="#">GetHoleTopMateEntity</a>     | Gets the entity to which the top of the hole is mated in this hole series.    |
|  | <a href="#">GetSketchPoints</a>          | Gets the center-hole sketch points in this hole series.                       |
|  | <a href="#">GetSketchPointsCount</a>     | Gets the number of center-hole sketch points in this hole series.             |
|  | <a href="#">IAccessSelections</a>        | Gains access to the selections that define this hole series feature.          |
|  | <a href="#">IGetComponents</a>           | Gets the components in this hole series.                                      |
|  | <a href="#">IGetHoleBottomMateEntity</a> | Gets the entity to which the bottom of the hole is mated in this hole series. |
|  | <a href="#">IGetHoleTopMateEntity</a>    | Gets the entity to which the top of the hole is mated in this hole series.    |
|  | <a href="#">IGetSketchPoints</a>         | Gets the center-hole sketch points in this hole series.                       |
|  | <a href="#">ReleaseSelectionAccess</a>   | Releases access to the selections that define this hole series feature.       |

[Top](#)

## See Also

[IHoleSeriesFeatureData2 Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IFeature::ModifyDefinition Method \(\)](#)  
[IFeature::IModifyDefinition2 Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IHoleSeriesFeatureData2 Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IHoleSeriesFeatureData2 Interface

For a list of all members of this type, see [IHoleSeriesFeatureData2 members](#).

## Public Properties

| Name                                                                                                                       | Description                                                          |
|----------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------|
|  <a href="#">BoltDiameter</a>           | Gets the diameter of the bolt in this hole series.                   |
|  <a href="#">BoltHeadDiameter</a>       | Gets the diameter of the head of the bolt in this hole series.       |
|  <a href="#">EndFace</a>                | Gets the end face for this hole series.                              |
|  <a href="#">FastenerBottomHoleType</a> | Gets the fastener bottom hole type in this hole series.              |
|  <a href="#">FastenerDefaultUnits</a>   | Gets the fastener default units for this hole series.                |
|  <a href="#">FastenerHoleCount</a>      | Gets the number of fastener holes in this hole series.               |
|  <a href="#">FastenerTopHoleType</a>    | Gets the fastener top hole type for this hole series.                |
|  <a href="#">Material</a>               | Gets the name of the bolt material in this hole series.              |
|  <a href="#">NutDiameter</a>            | Gets the diameter of the nut in this hole series.                    |
|  <a href="#">Preload</a>                | Gets the preload information for this hole series.                   |
|  <a href="#">Size</a>                   | Gets the fastener size in the specified part in this hole series.    |
|  <a href="#">Standard</a>               | Gets the design standard for this hole series.                       |
|  <a href="#">StartFace</a>              | Gets the start face for this hole series.                            |
|  <a href="#">Type</a>                   | Gets the type of fastener in the specified part in this hole series. |

[Top](#)

## See Also

[IHoleSeriesFeatureData2 Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IFeature::ModifyDefinition Method \(\)](#)  
[IFeature::IModifyDefinition2 Method \(\)](#)

# AccessSelections Method (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : AccessSelections Method (IHoleSeriesFeatureData2)

Gains access to the selections that define this hole series feature.

## .NET Syntax

### Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

### C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

### C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

*TopDoc*  
Top-level document (see **Remarks**)  
*Component*  
Component in which the feature is to be modified (see **Remarks**)

### Return Value

True if the selections are successfully accessed, false if not

## Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData2::AccessSelections](#).

## Example

See the examples in [IHoleSeriesFeatureData2](#).

## Remarks

| To modify a feature in a... | Then...                                                                                                                                                                                                      |
|-----------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Part                        | <ul style="list-style-type: none"><li>TopDoc argument is the <a href="#">IModelDoc2</a> for the part</li><li>Component argument is NULL</li></ul>                                                            |
| Assembly                    | <ul style="list-style-type: none"><li>TopDoc is the IModelDoc2 object for the assembly</li><li>Component argument is the <a href="#">IComponent2</a> object in which the feature is to be modified</li></ul> |

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IHoleSeriesFeatureData2::ReleaseSelectionAccess](#) if you did not

## See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)  
[IHoleSeriesFeatureData2::IAccessSelections Method\(\)](#)

## Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## BoltDiameter Property (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : BoltDiameter Property (IHoleSeriesFeatureData2)

Gets the diameter of the bolt in this hole series.

## .NET Syntax

### Visual Basic (Declaration)

ReadOnly Property BoltDiameter As System.Double

### Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2  
Dim value As System.Double  
  
value = instance.BoltDiameter
```

### C#

```
System.double BoltDiameter {get;}
```

### C++/CLI

```
property System.double BoltDiameter {  
    System.double get();  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Diameter of bolt

## Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData2::BoltDiameter](#).

## Example

See the examples in [IHoleSeriesFeatureData2](#).

## See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)  
[IHoleSeriesFeatureData2::BoltHeadDiameter Property\(\)](#)  
[IHoleSeriesFeatureData2::Material Property\(\)](#)  
[IHoleSeriesFeatureData2::NutDiameter Property\(\)](#)

## Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## BoltHeadDiameter Property (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : BoltHeadDiameter Property (IHoleSeriesFeatureData2)

Gets the diameter of the head of the bolt in this hole series.

## Visual Basic Syntax

Visual Basic (Declaration)

```
ReadOnly Property BoltHeadDiameter As System.Double
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2  
Dim value As System.Double  
  
value = instance.BoltHeadDiameter
```

C#

```
System.double BoltHeadDiameter {get;}
```

C++/CLI

```
property System.double BoltHeadDiameter {  
    System.double get();  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Diameter of head of the bolt

## Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData2::BoltHeadDiameter](#).

## Example

See the examples in [IHoleSeriesFeatureData2](#).

## See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)  
[IHoleSeriesFeatureData2::BoltDiameter Property \(\)](#)  
[IHoleSeriesFeatureData2::Material Property \(\)](#)  
[IHoleSeriesFeatureData2::NutDiameter Property \(\)](#)

## Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## EndFace Property (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : EndFace Property (IHoleSeriesFeatureData2)

Gets the end face for this hole series.

## Visual Basic Syntax

Visual Basic (Declaration)

```
ReadOnly Property EndFace As System.Object
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2
Dim value As System.Object

value = instance.EndFace
```

C#

```
System.Object EndFace {get;}
```

C++/CLI

```
property System.Object^ EndFace {
    System.Object^ get();
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

End [face](#)

### Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData2::EndFace](#).

### Example

See the examples in [IHoleSeriesFeatureData2](#).

### See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)  
[IHoleSeriesFeatureData2::StartFace Property \(\)](#)

### Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## FastenerBottomHoleType Property (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : FastenerBottomHoleType Property (IHoleSeriesFeatureData2)

Gets the fastener bottom hole type in this hole series.

### .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property FastenerBottomHoleType As System.Short
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2
Dim value As System.Short

value = instance.FastenerBottomHoleType
```

C#

```
System.Short FastenerBottomHoleType {get;}
```

C++/CLI

```
property System.Short FastenerBottomHoleType {
    System.Short get();
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Fastener bottom hole type as defined in [swWzdHoleStandardFastenerTypes\\_e](#)

#### Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData2::FastenerBottomHoleType](#).

#### Example

See the examples in [IHoleSeriesFeatureData2](#).

#### See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)  
[IHoleSeriesFeatureData2::FastenerDefaultUnits Property \(\)](#)  
[IHoleSeriesFeatureData2::FastenerHoleCount Property \(\)](#)  
[IHoleSeriesFeatureData2::FastenerTopHoleType Property \(\)](#)

#### Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## FastenerDefaultUnits Property (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : FastenerDefaultUnits Property (IHoleSeriesFeatureData2)

Gets the fastener default units for this hole series.

#### .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property FastenerDefaultUnits As System.String
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2  
Dim value As System.String  
  
value = instance.FastenerDefaultUnits
```

C#

```
System.string FastenerDefaultUnits {get;}
```

C++/CLI

```
property System.String^ FastenerDefaultUnits {  
    System.String^ get();  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Fastener default units

#### Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData2::FastenerDefaultUnits](#).

#### Example

See the examples in [IHoleSeriesFeatureData2](#).

## See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)  
[IHoleSeriesFeatureData2::FastenerBottomHoleType Property \(\)](#)  
[IHoleSeriesFeatureData2::FastenerHoleCount Property \(\)](#)  
[IHoleSeriesFeatureData2::FastenerTopHoleType Property \(\)](#)

## Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## FastenerHoleCount Property (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : FastenerHoleCount Property (IHoleSeriesFeatureData2)

Gets the number of fastener holes in this hole series.

## .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property FastenerHoleCount As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2  
Dim value As System.Integer
```

```
value = instance.FastenerHoleCount
```

C#

```
System.int FastenerHoleCount {get;}
```

C++/CLI

```
property System.int FastenerHoleCount {  
    System.int get();  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Number of fastener holes

## Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData2::FastenerHoleCount](#).

## Example

See the examples in [IHoleSeriesFeatureData2](#).

## See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)  
[IHoleSeriesFeatureData2::FastenerBottomHoleType Property \(\)](#)  
[IHoleSeriesFeatureData2::FastenerDefaultUnits Property \(\)](#)  
[IHoleSeriesFeatureData2::FastenerTopHoleType Property \(\)](#)

## Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## FastenerTopHoleType Property (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : FastenerTopHoleType Property (IHoleSeriesFeatureData2)

Gets the fastener top hole type for this hole series.

## .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property FastenerTopHoleType As System.Short
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2  
Dim value As System.Short  
  
value = instance.FastenerTopHoleType
```

C#

```
System.short FastenerTopHoleType {get;}
```

C++/CLI

```
property System.short FastenerTopHoleType {  
    System.short get();  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Fastener top hole type as defined in [swWzdHoleStandardFastenerTypes\\_e](#)

## Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData2::FastenerTopHoleType](#).

## Example

See the examples in [IHoleSeriesFeatureData2](#).

## See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)  
[IHoleSeriesFeatureData2::FastenerBottomHoleType Property \(\)](#)  
[IHoleSeriesFeatureData2::FastenerDefaultUnits Property \(\)](#)  
[IHoleSeriesFeatureData2::FastenerHoleCount Property \(\)](#)

## Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetComponents Method (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : GetComponents Method (IHoleSeriesFeatureData2)

Gets the components in this hole series.

## .NET Syntax

Visual Basic (Declaration)

```
Function GetComponents() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2  
Dim value As System.Object  
  
value = instance.GetComponents()
```

C#

```
System.object GetComponents()
```

C++/CLI

```
System.Object^ GetComponents();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Array of [components](#) in this hole series

### Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData2::GetComponents](#).

### Example

See the examples in [IHoleSeriesFeatureData2](#).

### See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)  
[IHoleSeriesFeatureData2::GetComponents Method \(\)](#)  
[IHoleSeriesFeatureData2::GetComponentsCount Method \(\)](#)

### Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetComponentsCount Method (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : GetComponentsCount Method (IHoleSeriesFeatureData2)

Gets the number of components in this hole series.

### .NET Syntax

Visual Basic (Declaration)

```
Function GetComponentsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2  
Dim value As System.Integer  
  
value = instance.GetComponentsCount()
```

C#

```
System.int GetComponentsCount()
```

C++/CLI

```
System.int GetComponentsCount();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Number of components in this hole series

## Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData2::GetComponentsCount](#).

## Example

See the examples in [IHoleSeriesFeatureData2](#).

## Remarks

Call this method before calling [IHoleSeriesFeatureData2::IGetComponents](#) to get the size of the array for that method.

## See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)  
[IHoleSeriesFeatureData2::GetComponents Method \(\)](#)

## Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## GetHoleBottomMateEntity Method (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : GetHoleBottomMateEntity Method (IHoleSeriesFeatureData2)

Gets the entity to which the bottom of the hole is mated in this hole series.

## .NET Syntax

Visual Basic (Declaration)

```
Function GetHoleBottomMateEntity( _  
    ByVal HoleInstance As System.Integer, _  
    ByVal HoleType As System.Short _  
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As IHoleSeriesFeatureData2  
Dim HoleInstance As System.Integer  
Dim HoleType As System.Short  
Dim value As System.Object  
  
value = instance.GetHoleBottomMateEntity(HoleInstance, HoleType)
```

C#

```
System.object GetHoleBottomMateEntity(  
    System.int HoleInstance,  
    System.short HoleType  
)
```

C++/CLI

```
System.Object^ GetHoleBottomMateEntity(  
& System.int HoleInstance,  
& System.short HoleType  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

*HoleInstance*

Index number of the hole whose entity you want

*HoleType*

Type of hole as defined by [swWzdHoleTypes\\_e](#)

#### Return Value

[Entity](#) to which the bottom of the hole is mated

### Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData2::GetHoleBottomMateEntity](#).

### See Also

[IHoleSeriesFeatureData2 Interface](#)

[IHoleSeriesFeatureData2 Members](#)

[IHoleSeriesFeatureData2::IGetHoleBottomMateEntity Method \(\)](#)

[IHoleSeriesFeatureData2::GetHoleTopMateEntity Method \(\)](#)

[IHoleSeriesFeatureData2::IGetHoleTopMateEntity Method \(\)](#)

### Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetHoleTopMateEntity Method (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : GetHoleTopMateEntity Method (IHoleSeriesFeatureData2)

Gets the entity to which the top of the hole is mated in this hole series.

### .NET Syntax

#### Visual Basic (Declaration)

```
Function GetHoleTopMateEntity( _  
    ByVal HoleInstance As System.Integer, _  
    ByVal HoleType As System.Short _  
) As System.Object
```

#### Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2  
Dim HoleInstance As System.Integer  
Dim HoleType As System.Short  
Dim value As System.Object
```

```
value = instance.GetHoleTopMateEntity(HoleInstance, HoleType)
```

#### C#

```
System.Object GetHoleTopMateEntity(  
    System.int HoleInstance,  
    System.short HoleType  
)
```

#### C++/CLI

```
System.Object^ GetHoleTopMateEntity(  
& System.int HoleInstance,  
& System.short HoleType  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*HoleInstance*

Index number of the hole whose entity you want

*HoleType*

Type of hole as defined by [swWzdHoleTypes\\_e](#)

#### Return Value

[Entity](#) to which the top of the hole is mated

## Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData2::GetHoleTopMateEntity](#).

## See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)  
[IHoleSeriesFeatureData2::GetHoleTopMateEntity Method \(\)](#)  
[IHoleSeriesFeatureData2::GetHoleBottomMateEntity Method \(\)](#)  
[IHoleSeriesFeatureData2::GetHoleBottomMateEntity Method \(\)](#)

## Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## GetSketchPoints Method (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : GetSketchPoints Method (IHoleSeriesFeatureData2)

Gets the center-hole sketch points in this hole series.

## .NET Syntax

Visual Basic (Declaration)

```
Function GetSketchPoints() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2  
Dim value As System.Object  
  
value = instance.GetSketchPoints()
```

C#

```
System.object GetSketchPoints()
```

C++/CLI

```
System.Object^ GetSketchPoints();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Return Value

Center-hole [sketch points](#)

## Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData2::GetSketchPoints](#).

## Example

See the examples in [IHoleSeriesFeatureData2](#).

## See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)  
[IHoleSeriesFeatureData2::GetSketchPoints Method \(\)](#)  
[IHoleSeriesFeatureData2::GetSketchPointsCount Method \(\)](#)

## Availability

## GetSketchPointsCount Method (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : GetSketchPointsCount Method (IHoleSeriesFeatureData2)

Gets the number of center-hole sketch points in this hole series.

### .NET Syntax

#### Visual Basic (Declaration)

```
Function GetSketchPointsCount() As System.Integer
```

#### Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2
Dim value As System.Integer

value = instance.GetSketchPointsCount()
```

#### C#

```
System.int GetSketchPointsCount()
```

#### C++/CLI

```
System.int GetSketchPointsCount();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Number of center-hole sketch points in this hole series

### Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData2::GetSketchPointsCount](#).

### Example

See the examples in [IHoleSeriesFeatureData2](#).

### Remarks

Call this method before calling [IHoleSeriesFeatureData2::IGetSketchPoints](#) to get the size of the array for that method.

### See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)  
[IHoleSeriesFeatureData2::GetSketchPoints Method \(\)](#)

### Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

## IAccessSelections Method (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : IAccessSelections Method (IHoleSeriesFeatureData2)

Gains access to the selections that define this hole series feature.

### .NET Syntax

#### Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
) As System.Boolean
```

#### Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2  
Dim TopDoc As ModelDoc  
Dim Component As Component  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

#### C#

```
System.bool IAccessSelections(  
    ModelDoc TopDoc,  
    Component Component  
)
```

#### C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc^ TopDoc,  
& Component^ Component  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*TopDoc*

Top-level document (see **Remarks**)

*Component*

Component in which the feature is to be modified (see **Remarks**)

#### Return Value

True if the selections are successfully accessed, false if not

### Remarks

| To modify a feature in a... | Then...                                                                                                                                                                                                      |
|-----------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Part                        | <ul style="list-style-type: none"><li>TopDoc argument is the <a href="#">IModelDoc2</a> for the part</li><li>Component argument is NULL</li></ul>                                                            |
| Assembly                    | <ul style="list-style-type: none"><li>TopDoc is the IModelDoc2 object for the assembly</li><li>Component argument is the <a href="#">IComponent2</a> object in which the feature is to be modified</li></ul> |

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::IModifyDefinition2](#) if you modified the feature
- [IHoleSeriesFeatureData2::ReleaseSelectionAccess](#) if you did not

### See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)  
[IHoleSeriesFeatureData2::AccessSelections Method \(\)](#)

### Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IGetComponents Method (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : IGetComponents Method (IHoleSeriesFeatureData2)

Gets the components in this hole series.

## .NET Syntax

### Visual Basic (Declaration)

```
Function IGetComponents( _  
    ByVal NCount As System.Integer _  
) As Component2
```

### Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2  
Dim NCount As System.Integer  
Dim value As Component2  
  
value = instance.IGetComponents(NCount)
```

### C#

```
Component2 IGetComponents(  
    System.int NCount  
)
```

### C++/CLI

```
Component2^ IGetComponents(  
& System.int NCount  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*NCount*  
Number of components in this hole series

#### Return Value

- in-process, unmanaged C++: Pointer to an array of [components](#) in this hole series
- VBA, VB.NET, C#, and C++/CLI: Not supported  
See [In-process Methods](#) for details about this type of method.

## Remarks

Before calling this method, call [IHoleSeriesFeatureData2::GetComponentsCount](#) to get the value for NCount.

## See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)  
[IHoleSeriesFeatureData2::GetComponents Method \(\)](#)

## Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IGetHoleBottomMateEntity Method (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : IGetHoleBottomMateEntity Method (IHoleSeriesFeatureData2)

Gets the entity to which the bottom of the hole is mated in this hole series.

## .NET Syntax

### Visual Basic (Declaration)

```
Function IGetHoleBottomMateEntity( _  
    ByVal HoleInstance As System.Integer, _  
    ByVal HoleType As System.Short _  
    ) As Entity
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2  
Dim HoleInstance As System.Integer  
Dim HoleType As System.Short  
Dim value As Entity  
  
value = instance.IGetHoleBottomMateEntity(HoleInstance, HoleType)
```

C#

```
Entity IGetHoleBottomMateEntity(  
    System.int HoleInstance,  
    System.short HoleType  
)
```

C++/CLI

```
Entity^ IGetHoleBottomMateEntity(  
& System.int HoleInstance,  
& System.short HoleType  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*HoleInstance*

Index number of the hole whose entity you want

*HoleType*

Type of hole as defined by [swWzdHoleTypes\\_e](#)

#### Return Value

[Entity](#) to which the bottom of the hole is mated

### See Also

[IHoleSeriesFeatureData2 Interface](#)

[IHoleSeriesFeatureData2 Members](#)

[IHoleSeriesFeatureData2::GetHoleBottomMateEntity Method \(\)](#)

[IHoleSeriesFeatureData2::GetHoleTopMateEntity Method \(\)](#)

[IHoleSeriesFeatureData2::IGetHoleTopMateEntity Method \(\)](#)

### Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## IGetHoleTopMateEntity Method (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : IGetHoleTopMateEntity Method (IHoleSeriesFeatureData2)

Gets the entity to which the top of the hole is mated in this hole series.

### .NET Syntax

Visual Basic (Declaration)

```
Function IGetHoleTopMateEntity( _  
    ByVal HoleInstance As System.Integer, _  
    ByVal HoleType As System.Short _  
    ) As Entity
```

Visual Basic (Usage)



```

Dim instance As IHoleSeriesFeatureData2
Dim HoleInstance As System.Integer
Dim HoleType As System.Short
Dim value As Entity

value = instance.IGetHoleTopMateEntity(HoleInstance, HoleType)

```

C#

```

Entity IGetHoleTopMateEntity(
    System.int HoleInstance,
    System.short HoleType
)

```

C++/CLI

```

Entity^ IGetHoleTopMateEntity(
    & System.int HoleInstance,
    & System.short HoleType
)

```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*HoleInstance*  
Index number of the hole whose entity you want

*HoleType*  
Type of hole as defined by [swWzdHoleTypes\\_e](#)

#### Return Value

[Entity](#) to which the top of the hole is mated

#### See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)  
[IHoleSeriesFeatureData2::GetHoleTopMateEntity Method \(\)](#)  
[IHoleSeriesFeatureData2::GetHoleBottomMateEntity Method \(\)](#)  
[IHoleSeriesFeatureData2::IGetHoleBottomMateEntity Method \(\)](#)

#### Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## IGetSketchPoints Method (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : IGetSketchPoints Method (IHoleSeriesFeatureData2)

Gets the center-hole sketch points in this hole series.

#### .NET Syntax

Visual Basic (Declaration)

```

Function IGetSketchPoints( _
    ByVal NCount As System.Integer _
) As SketchPoint

```

Visual Basic (Usage)

```

Dim instance As IHoleSeriesFeatureData2
Dim NCount As System.Integer
Dim value As SketchPoint

value = instance.IGetSketchPoints(NCount)

```

C#



```
SketchPoint IGetSketchPoints(  
    System.int NCount  
)
```

C++/CLI

```
SketchPoint^ IGetSketchPoints(  
&    System.int NCount  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*NCount*

Number of center-hole sketch points

#### Return Value

- in-process, unmanaged C++: Pointer to an array of center-hole [sketch points](#)
  - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

#### Remarks

Before calling this method, call [IHoleSeriesFeatureData2::GetSketchPointsCount](#) to get the value for NCount.

#### See Also

[IHoleSeriesFeatureData2 Interface](#)

[IHoleSeriesFeatureData2 Members](#)

[IHoleSeriesFeatureData2::GetSketchPoints Method \(\)](#)

#### Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Material Property (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : Material Property (IHoleSeriesFeatureData2)

Gets the name of the bolt material in this hole series.

#### .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Material As System.String
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2  
Dim value As System.String
```

```
value = instance.Material
```

C#

```
System.string Material {get;}
```

C++/CLI

```
property System.String^ Material {  
    System.String^ get();  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Bolt material name

## Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData2::Material](#).

## Example

See the examples in [IHoleSeriesFeatureData2](#).

## Remarks

The material value is not available in the SOLIDWORKS Toolbox database.

## See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)  
[IHoleSeriesFeatureData2::BoltDiameter Property \(\)](#)  
[IHoleSeriesFeatureData2::BoltHeadDiameter Property \(\)](#)  
[IHoleSeriesFeatureData2::NutDiameter Property \(\)](#)

## Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## NutDiameter Property (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : NutDiameter Property (IHoleSeriesFeatureData2)

Gets the diameter of the nut in this hole series.

## .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property NutDiameter As System.Double
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2  
Dim value As System.Double
```

```
value = instance.NutDiameter
```

C#

```
System.double NutDiameter {get;}
```

C++/CLI

```
property System.double NutDiameter {  
    System.double get();  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Diameter of nut

## Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData2::NutDiameter](#).

## Example

See the examples in [IHoleSeriesFeatureData2](#).

## See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)  
[IHoleSeriesFeatureData2::BoltDiameter Property \(\)](#)  
[IHoleSeriesFeatureData2::BoltHeadDiameter Property \(\)](#)  
[IHoleSeriesFeatureData2::Material Property \(\)](#)

## Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## Preload Property (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : Preload Property (IHoleSeriesFeatureData2)

Gets the preload information for this hole series.

## .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Preload As System.String
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2  
Dim value As System.String
```

```
value = instance.Preload
```

C#

```
System.string Preload {get;}
```

C++/CLI

```
property System.String^ Preload {  
    System.String^ get();  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Preload information

## Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData2::Preload](#).

## Example

See the examples in [IHoleSeriesFeatureData2](#).

## Remarks

The preload value is not available in the SOLIDWORKS Toolbox database.

## See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)

## Availability

## ReleaseSelectionAccess Method (IHoleSeriesFeatureData2)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : ReleaseSelectionAccess Method (IHoleSeriesFeatureData2)

Releases access to the selections that define this hole series feature.

## .NET Syntax

## Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

## Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2  
instance.ReleaseSelectionAccess()
```

## C#

```
void ReleaseSelectionAccess()
```

## C++/CLI

```
void ReleaseSelectionAccess();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData2::ReleaseSelectionAccess](#).

## Example

See the examples in [IHoleSeriesFeatureData2](#).

## Remarks

[IHoleSeriesFeatureData2::AccessSelections](#) and [IHoleSeriesFeatureData2::IAccessSelections](#) put the model into a rollback state to allow access to the selections that define this feature.Use this method to restore the rollback state if you did not modify the feature. Use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did.

## See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)

## Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

## Size Property (IHoleSeriesFeatureData2)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : Size Property (IHoleSeriesFeatureData2)

Gets the fastener size in the specified part in this hole series.

## .NET Syntax

## Visual Basic (Declaration)

```
ReadOnly Property Size( _  
    ByVal HoleSeriesWhichPart As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2  
Dim HoleSeriesWhichPart As System.Integer  
Dim value As System.String  
  
value = instance.Size(HoleSeriesWhichPart)
```

C#

```
System.string Size(  
    System.int HoleSeriesWhichPart  
) {get;}
```

C++/CLI

```
property System.String^ Size {  
    System.String^ get(System.int HoleSeriesWhichPart);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*HoleSeriesWhichPart*

Which part the hole series passes through as defined by [swHoleSeriesWhichParts\\_e](#)

#### Property Value

Fastener size

### Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData2::Size](#).

### Example

See the examples in [IHoleSeriesFeatureData2](#).

### See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)

### Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## Standard Property (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : Standard Property (IHoleSeriesFeatureData2)

Gets the design standard for this hole series.

### .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Standard As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2
Dim value As System.Integer

value = instance.Standard
```

C#

```
System.int Standard {get;}
```

C++/CLI

```
property System.int Standard {
    System.int get();
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Design standard as defined in [swWzdHoleStandards\\_e](#)

### Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData2::Standard](#).

### Example

See the examples in [IHoleSeriesFeatureData2](#).

### See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)

### Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## StartFace Property (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : StartFace Property (IHoleSeriesFeatureData2)

Gets the start face for this hole series.

### .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property StartFace As System.Object
```

Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2
Dim value As System.Object

value = instance.StartFace
```

C#

```
System.object StartFace {get;}
```

C++/CLI

```
property System.Object^ StartFace {
    System.Object^ get();
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Property Value

Start [face](#)

## Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData2::StartFace](#).

## See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)  
[IHoleSeriesFeatureData2::EndFace Property\(\)](#)

## Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## Type Property (IHoleSeriesFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleSeriesFeatureData2 Interface](#) : Type Property (IHoleSeriesFeatureData2)

Gets the type of fastener in the specified part in this hole series.

## .NET Syntax

### Visual Basic (Declaration)

```
ReadOnly Property Type( _  
    ByVal HoleSeriesWhichPart As System.Integer _  
) As System.Integer
```

### Visual Basic (Usage)



```
Dim instance As IHoleSeriesFeatureData2  
Dim HoleSeriesWhichPart As System.Integer  
Dim value As System.Integer
```

```
value = instance.Type(HoleSeriesWhichPart)
```

### C#

```
System.int Type(  
    System.int HoleSeriesWhichPart  
) {get;}
```

### C++/CLI

```
property System.int Type {  
    System.int get(System.int HoleSeriesWhichPart);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Parameters

*HoleSeriesWhichPart*

Which part the hole series passes through as defined by [swHoleSeriesWhichParts\\_e](#)

## Property Value

Type of fastener as defined by [swWzdHoleStandardFastenerTypes\\_e](#)

## Visual Basic for Applications (VBA) Syntax

See [HoleSeriesFeatureData2::Type](#).

## Example

See the examples in [IHoleSeriesFeatureData2](#).

## See Also

[IHoleSeriesFeatureData2 Interface](#)  
[IHoleSeriesFeatureData2 Members](#)

## Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

# IHoleStandardsData (Type)

## IHoleStandardsData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHoleStandardsData Interface

Allows access to Hole Wizard standards data.

**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

### .NET Syntax

Visual Basic (Declaration)

Public Interface IHoleStandardsData

Visual Basic (Usage)



Dim instance As [IHoleStandardsData](#)

C#

public interface IHoleStandardsData

C++/CLI

public interface class IHoleStandardsData

### Visual Basic for Applications (VBA) Syntax

See [HoleStandardsData](#).

### Example

[Get Hole Standards Data \(VBA\)](#)  
[Get Hole Standards Data \(C#\)](#)

### Accessors

[ISldWorks::GetHoleStandardsData](#)

### Access Diagram

[HoleStandardsData](#)

### See Also

[IHoleStandardsData Members](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IHoleDataTable Interface](#)

## IHoleStandardsData Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHoleStandardsData Interface

The following tables list the members exposed by [IHoleStandardsData](#).

### Public Methods

| Name                                  | Description                                                                                                          |
|---------------------------------------|----------------------------------------------------------------------------------------------------------------------|
| <a href="#">GetFastenerTable</a>      | Gets the Hole Wizard fastener table for the specified Hole Wizard standard, fastener ID, and fastener table type ID. |
| <a href="#">GetFastenerTableTypes</a> | Gets the array of three fastener table type IDs for the given fastener in the given Hole Wizard standard.            |
| <a href="#">GetFastenerTypes</a>      | Gets the fasteners in the specified Hole Wizard standard.                                                            |



[GetHoleStandards](#)

Gets Hole Wizard standards.

[Top](#)

## See Also

[IHoleStandardsData Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IHoleDataTable Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IHoleStandardsData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHoleStandardsData Interface

For a list of all members of this type, see [IHoleStandardsData members](#).

## Public Methods

| Name                                                                                                                    | Description                                                                                                          |
|-------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------|
|  <a href="#">GetFastenerTable</a>      | Gets the Hole Wizard fastener table for the specified Hole Wizard standard, fastener ID, and fastener table type ID. |
|  <a href="#">GetFastenerTableTypes</a> | Gets the array of three fastener table type IDs for the given fastener in the given Hole Wizard standard.            |
|  <a href="#">GetFastenerTypes</a>      | Gets the fasteners in the specified Hole Wizard standard.                                                            |
|  <a href="#">GetHoleStandards</a>      | Gets Hole Wizard standards.                                                                                          |

[Top](#)

## See Also

[IHoleStandardsData Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IHoleDataTable Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetFastenerTable Method (IHoleStandardsData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleStandardsData Interface](#) : GetFastenerTable Method (IHoleStandardsData)

Gets the Hole Wizard fastener table for the specified Hole Wizard standard, fastener ID, and fastener table type ID.

## .NET Syntax

Visual Basic (Declaration)

```
Function GetFastenerTable( _  
    ByVal StandardName As System.String, _  
    ByVal FastenerID As System.Integer, _  
    ByVal TableID As System.Integer, _  
    ByRef HoleTable As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHoleStandardsData  
Dim StandardName As System.String  
Dim FastenerID As System.Integer  
Dim TableID As System.Integer  
Dim HoleTable As System.Object  
Dim value As System.Boolean  
  
value = instance.GetFastenerTable(StandardName, FastenerID, TableID, HoleTable)
```

C#

```
System.bool GetFastenerTable(  
    System.string StandardName,
```

```
System.int FastenerID,  
System.int TableID,  
out System.object HoleTable  
)
```

C++/CLI

```
System.bool GetFastenerTable(  
& System.String^ StandardName,  
& System.int FastenerID,  
& System.int TableID,  
& [Out] System.Object^ HoleTable  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*StandardName*  
Standard name (see **Remarks**)  
*FastenerID*  
Fastener ID (see **Remarks**)  
*TableID*  
Fastener table type ID (see **Remarks**)  
*HoleTable*  
[IHoleDataTable](#)

#### Return Value

True if fastener data table successfully retrieved, false if not

### Visual Basic for Applications (VBA) Syntax

See [HoleStandardsData::GetFastenerTable](#).

### Example

See the [IHoleStandardsData](#) example.

### Remarks

To set:

- StandardName, use [IHoleStandardsData::GetHoleStandards](#).
- FastenerID, use [IHoleStandardsData::GetFastenerTypes](#).
- TableID, use [IHoleStandardsData::GetFastenerTableTypes](#).

### See Also

[IHoleStandardsData Interface](#)  
[IHoleStandardsData Members](#)

### Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetFastenerTableTypes Method (IHoleStandardsData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleStandardsData Interface](#) : GetFastenerTableTypes Method (IHoleStandardsData)

Gets the array of three fastener table type IDs for the given fastener in the given Hole Wizard standard.

### .NET Syntax

Visual Basic (Declaration)

```
Function GetFastenerTableTypes( _  
    ByVal StandardName As System.String, _  
    ByVal FastenerID As System.Integer, _  
    ByRef FastenerTableTypeIDs As System.Object _  
) As System.Boolean
```

```

Dim instance As IHoleStandardsData
Dim StandardName As System.String
Dim FastenerID As System.Integer
Dim FastenerTableTypeIDs As System.Object
Dim value As System.Boolean

value = instance.GetFastenerTableTypes(StandardName, FastenerID, FastenerTableTypeIDs)

```

C#

```

System.bool GetFastenerTableTypes(
    System.string StandardName,
    System.int FastenerID,
    out System.object FastenerTableTypeIDs
)

```

C++/CLI

```

System.bool GetFastenerTableTypes(
    & System.String^ StandardName,
    & System.int FastenerID,
    & [Out] System.Object^ FastenerTableTypeIDs
)

```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*StandardName*  
Standard name (see **Remarks**)

*FastenerID*  
Fastener ID (see **Remarks**)

*FastenerTableTypeIDs*  
Array of three fastener table type IDs (see **Remarks**)

#### Return Value

True if the fastener table type IDs are successfully retrieved, false if not

### Visual Basic for Applications (VBA) Syntax

See [HoleStandardsData::GetFastenerTableTypes](#).

### Example

See the [IHoleStandardsData](#) example.

### Remarks

Each fastener in a given standard has three tables associated with it: size, thread data, and screw clearances. This method retrieves internal ID: of all three table types as defined in [swFastenerTableTypes\\_e](#) for FastenerID in StandardName.

To set:

- StandardName, use [IHoleStandardsData::GetHoleStandards](#).
- FastenerID, use [IHoleStandardsData::GetFastenerTypes](#).

### See Also

[IHoleStandardsData Interface](#)  
[IHoleStandardsData Members](#)

### Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

Gets the fasteners in the specified Hole Wizard standard.

## .NET Syntax

### Visual Basic (Declaration)

```
Function GetFastenerTypes( _
    ByVal StandardName As System.String, _
    ByRef FastenerIndexes As System.Object, _
    ByRef FastenerNames As System.Object _
) As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As IHoleStandardsData
Dim StandardName As System.String
Dim FastenerIndexes As System.Object
Dim FastenerNames As System.Object
Dim value As System.Boolean

value = instance.GetFastenerTypes(StandardName, FastenerIndexes, FastenerNames)
```

### C#

```
System.bool GetFastenerTypes(
    System.string StandardName,
    out System.object FastenerIndexes,
    out System.object FastenerNames
)
```

### C++/CLI

```
System.bool GetFastenerTypes(
    & System.String^ StandardName,
    & [Out] System.Object^ FastenerIndexes,
    & [Out] System.Object^ FastenerNames
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

*StandardName*  
Standard name (see **Remarks**)

*FastenerIndexes*  
Array of fastener indexes

*FastenerNames*  
Array of fastener names

### Return Value

True if fastener types successfully retrieved, false if not

## Visual Basic for Applications (VBA) Syntax

See [HoleStandardsData::GetFastenerTypes](#).

## Example

See the [IHoleStandardsData](#) example.

## Remarks

To set StandardName, use [IHoleStandardsData::GetHoleStandards](#).

## See Also

[IHoleStandardsData Interface](#)  
[IHoleStandardsData Members](#)

## Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetHoleStandards Method (IHoleStandardsData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleStandardsData Interface](#) : GetHoleStandards Method (IHoleStandardsData)

Gets Hole Wizard standards.

## .NET Syntax

### Visual Basic (Declaration)

```
Function GetHoleStandards( _  
    ByRef Indexes As System.Object, _  
    ByRef Names As System.Object _  
) As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As IHoleStandardsData  
Dim Indexes As System.Object  
Dim Names As System.Object  
Dim value As System.Boolean  
  
value = instance.GetHoleStandards(Indexes, Names)
```

### C#

```
System.bool GetHoleStandards(  
    out System.object Indexes,  
    out System.object Names  
)
```

### C++/CLI

```
System.bool GetHoleStandards(  
& [Out] System.Object^ Indexes,  
& [Out] System.Object^ Names  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

*Indexes*

Array of Hole Wizard standards as defined in [swWzdHoleStandards](#) e

*Names*

Array of names of Hole Wizard standards

### Return Value

True if Hole Wizard standards retrieved successfully, false if not

## Visual Basic for Applications (VBA) Syntax

See [HoleStandardsData::GetHoleStandards](#).

## Example

See the [IHoleStandardsData](#) example.

## See Also

[IHoleStandardsData Interface](#)

[IHoleStandardsData Members](#)

[IHoleStandardsData::GetFastenerTable Method \(\)](#)

[IHoleStandardsData::GetFastenerTableTypes Method \(\)](#)

[IHoleStandardsData::GetFastenerTypes Method \(\)](#)

