

SOLIDWORKS API (.NET VBA C#) — Reference (135/337): IHoleTable-Import3DInterconnectData

SOLIDWORKS API Documentation (converted from CHM)

IHoleTable (Type)

IHoleTable Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHoleTable Interface

Allows access to a hole table feature in a drawing document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IHoleTable
```

Visual Basic (Usage)

```
Dim instance As IHoleTable
```

C#

```
public interface IHoleTable
```

C++/CLI

```
public interface class IHoleTable
```

Visual Basic for Applications (VBA) Syntax

See [HoleTable](#).

Example

[Hide or Show First Column in Hole Table \(C#\)](#)
[Hide or Show First Column in Hole Table \(VB.NET\)](#)
[Hide or Show First Column in Hole Table \(VBA\)](#)
[Get Labels of Datum Origin \(C#\)](#)
[Get Labels of Datum Origin \(VB.NET\)](#)
[Get Labels of Datum Origin \(VBA\)](#)

Accessors

[IDatumOrigin::Table](#)
[IHoleTableAnnotation::HoleTable](#)

Access Diagram

[HoleTable](#)

See Also

[IHoleTable Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IHoleTableAnnotation Interface](#)
[ITableAnnotation Interface](#)

IHoleTable Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHoleTable Interface

The following tables list the members exposed by [IHoleTable](#).

Public Properties

Name	Description
 CombineSameSize	Gets or sets whether to merge cells of the same size in this hole table.
 CombineTags	Gets or sets whether to combine tags for same-size holes.
 DatumOrigin	Gets the datum origin annotation for this hole table.
 EnableUpdate	Gets or sets whether to update hole table and graphics after changing hole tags .
 HoleCentersVisible	Gets or sets whether to show the hole center marks for this hole table.
 HoleTag	Gets or sets the name of the specified tag in a hole table.
 HoleTagsVisible	Gets whether the hole tags are visible for this hole table.
 ShowANSISilnchLetterNumberDrillSizes	Gets or sets whether to display hole sizes in this hole table using ANSI inch letters and drill numbers.
 StartingValue	Gets or sets the starting value for the datum tags of this hole table.
 TagStyle	Gets or sets the tag style for this hole table.

[Top](#)

Public Methods

Name	Description
 AddHole	Adds holes to this hole table.
 AssignTagPrefix	Prefixes the manual datum tags of specified holes with specified text.
 GetFeature	Gets the IFeature object for this hole table.
 GetHoleLocationPrecision	Gets the precision to use for location values for this hole table.
 GetHoleLocationUseDocPrecision	Gets whether to display the location of this hole table using the document's location precision.
 GetTableAnnotationCount	Gets the number of hole table annotations for this hole table.
 GetTableAnnotations	Gets the hole table annotations for this hole table feature.
 IGetTableAnnotations	Gets the hole table annotations for this hole table feature.
 SetHoleLocationPrecision	Sets the precision to use for location values for this hole table.

[Top](#)

See Also

[IHoleTable Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IHoleTableAnnotation Interface](#)
[ITableAnnotation Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IHoleTable Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHoleTable Interface

For a list of all members of this type, see [IHoleTable members](#).

Public Methods

Name	Description
 AddHole	Adds holes to this hole table.
 AssignTagPrefix	Prefixes the manual datum tags of specified holes with specified text.
 GetFeature	Gets the IFeature object for this hole table.
 GetHoleLocationPrecision	Gets the precision to use for location values for this hole table.
 GetHoleLocationUseDocPrecision	Gets whether to display the location of this hole table using the document's location precision.
 GetTableAnnotationCount	Gets the number of hole table annotations for this hole table.
 GetTableAnnotations	Gets the hole table annotations for this hole table feature.

 IGetTableAnnotations	Gets the hole table annotations for this hole table feature.
 SetHoleLocationPrecision	Sets the precision to use for location values for this hole table.

[Top](#)

 See Also

[IHoleTable Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IHoleTableAnnotation Interface](#)
[ITableAnnotation Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IHoleTable Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : [IHoleTable Interface](#)

For a list of all members of this type, see [IHoleTable members](#).

 Public Properties

Name	Description
 CombineSameSize	Gets or sets whether to merge cells of the same size in this hole table.
 CombineTags	Gets or sets whether to combine tags for same-size holes.
 DatumOrigin	Gets the datum origin annotation for this hole table.
 EnableUpdate	Gets or sets whether to update hole table and graphics after changing hole tags .
 HoleCentersVisible	Gets or sets whether to show the hole center marks for this hole table.
 HoleTag	Gets or sets the name of the specified tag in a hole table.
 HoleTagsVisible	Gets whether the hole tags are visible for this hole table.
 ShowANSIInchLetterNumberDrillSizes	Gets or sets whether to display hole sizes in this hole table using ANSI inch letters and drill numbers.
 StartingValue	Gets or sets the starting value for the datum tags of this hole table.
 TagStyle	Gets or sets the tag style for this hole table.

[Top](#)

 See Also

[IHoleTable Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IHoleTableAnnotation Interface](#)
[ITableAnnotation Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddHole Method (IHoleTable)

[See Also](#)

 

[SolidWorks.Interop.sldworks Namespace](#) > [IHoleTable Interface](#) : AddHole Method (IHoleTable)

Adds holes to this hole table.

 .NET Syntax

Visual Basic (Declaration)

Function AddHole() As System.Integer

Visual Basic (Usage)

```
Dim instance As IHoleTable  
Dim value As System.Integer  
  
value = instance.AddHole()
```

C#



```
System.int AddHole()
```

C++/CLI

```
System.int AddHole();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of holes added to this hole table

Visual Basic for Applications (VBA) Syntax

See [HoleTable::AddHole](#).

Remarks

You must either interactively or programmatically select the holes to add to the hole table before running this method.

To add holes...

Interactively

Then...

- Select an edge that defines a hole to add that hole to this hole table.
- Select a face that contains the holes that you want to add to this hole table.

Programmatically

Call [IModelDocExtension::SelectByID2](#).

See Also

[IHoleTable Interface](#)
[IHoleTable Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AssignTagPrefix Method (IHoleTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleTable Interface](#) : AssignTagPrefix Method (IHoleTable)

Prefixes the manual datum tags of specified holes with specified text.

.NET Syntax

Visual Basic (Declaration)

```
Function AssignTagPrefix(_  
    ByVal Index As System.Integer, _  
    ByVal TagPrefix As System.String, _  
    ByVal ApplyTo As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHoleTable  
Dim Index As System.Integer  
Dim TagPrefix As System.String  
Dim ApplyTo As System.Integer  
Dim value As System.Boolean
```

```
value = instance.AssignTagPrefix(Index, TagPrefix, ApplyTo)
```

C#

```
System.bool AssignTagPrefix(
    System.int Index,
    System.string TagPrefix,
    System.int ApplyTo
)
```

C++/CLI

```
System.bool AssignTagPrefix(
    & System.int Index,
    & System.String^ TagPrefix,
    & System.int ApplyTo
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of row to which to apply TagPrefix

TagPrefix

Prefix to apply

ApplyTo

Apply to other holes as defined in [swHoleTableTagPrefixApply_e](#) (see **Remarks**)

Return Value

True if prefix successfully assigned, false if not

Visual Basic for Applications (VBA) Syntax

See [HoleTable::AssignTagPrefix](#).

Remarks

This method:

- is valid only if [IHoleTable::TagStyle](#) is set to [swHoleTableTagStyle_e.swHoleTable_ManualTags](#).
- corresponds to the functionality of the **Assign Tag Prefix** dialog that pops up when you right-click on a hole table row of a manual tag.

If [ApplyTo](#) is specified with [swHoleTableTagPrefixApply_e](#):

- [swHoleTableTagPrefixApply_OnlySpecifiedHole](#), then only the hole as specified by [Index](#) is assigned [TagPrefix](#).
- [swHoleTableTagPrefixApply_AllHolesOfSameSize](#), then all holes that are the same size as the hole specified by [Index](#) are assigned [TagPrefix](#).

When [TagPrefix](#) is assigned to only the hole as specified by [Index](#), the numbering of all holes of the same size changes.

For example, if:

- A model view has six holes of two different sizes, and the hole table manual tags are initially labeled:
AA1, AA2, AA3, AA4, BB1, BB2
- Specify [Index](#) with the row index of AA1.
- Specify [TagPrefix](#) with "AB".
- Specify [ApplyTo](#) with [swHoleTableTagPrefixApply_e.swHoleTableTagPrefixApply_OnlySpecifiedHole](#).

After calling this method:

- The hole table manual tags are re-labeled:
AB1, AA1, AA2, AA3, BB1, BB2

Notice that AA1 is re-labeled to AB1, and AA2 - AA4 are re-numbered to AA1 - AA3. BB1 and BB2 are unchanged.

See Also

[IHoleTable Interface](#)
[IHoleTable Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CombineSameSize Property (IHoleTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleTable Interface](#) : CombineSameSize Property (IHoleTable)

Gets or sets whether to merge cells of the same size in this hole table.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property CombineSameSize As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHoleTable
Dim value As System.Boolean

instance.CombineSameSize = value
value = instance.CombineSameSize
```

C#

```
System.bool CombineSameSize {get; set;}
```

C++/CLI

```
property System.bool CombineSameSize {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to merge cells of the same size, false to not

Visual Basic for Applications (VBA) Syntax

See [HoleTable::CombineSameSize](#).

Remarks

This property appears in the Scheme section of the Hole Table PropertyManager page in SOLIDWORKS.

See Also

[IHoleTable Interface](#)
[IHoleTable Members](#)
[IHoleTable::CombineTags Property\(\)](#)
[IHoleTable::ShowANSIInchLetterNumberDrillSizes Property\(\)](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CombineTags Property (IHoleTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleTable Interface](#) : CombineTags Property (IHoleTable)

Gets or sets whether to combine tags for same-size holes.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property CombineTags As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHoleTable
Dim value As System.Boolean
```

```
instance.CombineTags = value  
value = instance.CombineTags
```

C#

```
System.bool CombineTags {get; set;}
```

C++/CLI

```
property System.bool CombineTags {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to combine tags for same-size holes, false to not

Visual Basic for Applications (VBA) Syntax

See [HoleTable::CombineTags](#).

Remarks

This property appears in the Scheme section of the Hole Table PropertyManager page in SOLIDWORKS.

See Also

[IHoleTable Interface](#)
[IHoleTable Members](#)
[IHoleTable::HoleTag Property](#)
[IHoleTable::HoleTagsVisible Property](#)
[IHoleTable::TagStyle Property](#)
[IHoleTable::CombineSameSize Property](#)
[IHoleTable::ShowANSIInchLetterNumberDrillSizes Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DatumOrigin Property (IHoleTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleTable Interface](#) : DatumOrigin Property (IHoleTable)

Gets the datum origin annotation for this hole table.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property DatumOrigin As DatumOrigin
```

Visual Basic (Usage)



```
Dim instance As IHoleTable  
Dim value As DatumOrigin  
  
value = instance.DatumOrigin
```

C#

```
DatumOrigin DatumOrigin {get;}
```

C++/CLI

```
property DatumOrigin^ DatumOrigin {  
    DatumOrigin^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pointer to the [IDatumOrigin](#) object

Visual Basic for Applications (VBA) Syntax

See [HoleTable::DatumOrigin](#).

Example

[Get Labels of Datum Origin \(C#\)](#)
[Get Labels of Datum Origin \(VB.NET\)](#)
[Get Labels of Datum Origin \(VBA\)](#)

See Also

[IHoleTable Interface](#)
[IHoleTable Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EnableUpdate Property (IHoleTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleTable Interface](#) : EnableUpdate Property (IHoleTable)

Gets or sets whether to update hole table and graphics after [changing hole tags](#).

.NET Syntax

Visual Basic (Declaration)

```
Property EnableUpdate As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHoleTable  
Dim value As System.Boolean  
  
instance.EnableUpdate = value  
value = instance.EnableUpdate
```

C#

```
System.bool EnableUpdate {get; set;}
```

C++/CLI

```
property System.bool EnableUpdate {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True updates the hole table and model view, false does not

Visual Basic for Applications (VBA) Syntax

See [HoleTable::EnableUpdate](#).

Example

[Change Tags in Hole Table \(VB.NET\)](#)
[Change Tags in Hole Table \(VBA\)](#)

Remarks

If you plan on changing many hole tags, then consider setting this property to false to avoid a possible degradation in performance. After changing all of the hole tags, set this property to true to update the hole table and model view.

See Also

[IHoleTable Interface](#)
[IHoleTable Members](#)
[HoleTable::HoleTagsVisible Property](#)
[HoleTable::TagStyle Property](#)
[HoleTable::HoleTag Property](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFeature Method (IHoleTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleTable Interface](#) : GetFeature Method (IHoleTable)

Gets the [IFeature](#) object for this hole table.

.NET Syntax

Visual Basic (Declaration)

Function GetFeature() As Feature

Visual Basic (Usage)



```
Dim instance As IHoleTable  
Dim value As Feature  
  
value = instance.GetFeature()
```

C#

Feature GetFeature()

C++/CLI

Feature^ GetFeature();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [IFeature](#) object

Visual Basic for Applications (VBA) Syntax

See [HoleTable::GetFeature](#).

See Also

[IHoleTable Interface](#)
[IHoleTable Members](#)

Availability

GetHoleLocationPrecision Method (IHoleTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleTable Interface](#) : GetHoleLocationPrecision Method (IHoleTable)

Gets the precision to use for location values for this hole table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetHoleLocationPrecision() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IHoleTable  
Dim value As System.Integer  
  
value = instance.GetHoleLocationPrecision()
```

C#

```
System.int GetHoleLocationPrecision()
```

C++/CLI

```
System.int GetHoleLocationPrecision();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Precision to use for location values

Visual Basic for Applications (VBA) Syntax

See [HoleTable::GetHoleLocationPrecision](#).

See Also

[IHoleTable Interface](#)
[IHoleTable Members](#)
[IHoleTable::GetHoleLocationUseDocPrecision Method](#)
[IHoleTable::SetHoleLocationPrecision Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

GetHoleLocationUseDocPrecision Method (IHoleTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleTable Interface](#) : GetHoleLocationUseDocPrecision Method (IHoleTable)

Gets whether to display the location of this hole table using the document's location precision.

.NET Syntax

Visual Basic (Declaration)

```
Function GetHoleLocationUseDocPrecision() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHoleTable  
Dim value As System.Boolean
```

```
value = instance.GetHoleLocationUseDocPrecision()
```

C#

```
System.bool GetHoleLocationUseDocPrecision()
```

C++/CLI

```
System.bool GetHoleLocationUseDocPrecision();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True to display the location of this hole table using the document's location precision, false to not

Visual Basic for Applications (VBA) Syntax

See [HoleTable::GetHoleLocationUseDocPrecision](#).

See Also

[IHoleTable Interface](#)

[IHoleTable Members](#)

[IHoleTable::GetHoleLocationPrecision Method](#)

[IHoleTable::SetHoleLocationPrecision Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTableAnnotationCount Method (IHoleTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleTable Interface](#) : GetTableAnnotationCount Method (IHoleTable)

Gets the number of hole table annotations for this hole table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTableAnnotationCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IHoleTable
```

```
Dim value As System.Integer
```

```
value = instance.GetTableAnnotationCount()
```

C#

```
System.int GetTableAnnotationCount()
```

C++/CLI

```
System.int GetTableAnnotationCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of hole table annotations for this hole table (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [HoleTable::GetTableAnnotationCount](#).

Remarks

Normally there is one hole table annotation per hole table feature. For example, if you split the table, then there are two separate table annotations.

Call this method before calling [IHoleTable::IGetTableAnnotations](#) if you want to get the total number of table annotations in the hole table, including split table annotations.

See Also

[IHoleTable Interface](#)
[IHoleTable Members](#)
[IHoleTable::GetTableAnnotations Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTableAnnotations Method (IHoleTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleTable Interface](#) : GetTableAnnotations Method (IHoleTable)

Gets the hole table annotations for this hole table feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTableAnnotations() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IHoleTable  
Dim value As System.Object  
  
value = instance.GetTableAnnotations()
```

C#

```
System.object GetTableAnnotations()
```

C++/CLI

```
System.Object^ GetTableAnnotations();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [IHoleTableAnnotation](#) objects for this hole table feature

Visual Basic for Applications (VBA) Syntax

See [HoleTable::GetTableAnnotations](#).

Example

[Hide or Show First Column in Hole Table \(VB.NET\)](#)
[Hide or Show First Column in Hole Table \(VBA\)](#)
[Hide or Show First Column in Hole Table \(C#\)](#)

Remarks

Because many of the [ITableAnnotation](#) APIs apply to all parts of a table annotation that has been split, you might not want all of the table annotations when just one table annotation would be sufficient.

See Also

[IHoleTable Interface](#)
[IHoleTable Members](#)
[IHoleTable::GetTableAnnotationCount Method](#)
[IHoleTable::!GetTableAnnotations Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

HoleCentersVisible Property (IHoleTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleTable Interface](#) : HoleCentersVisible Property (IHoleTable)

Gets or sets whether to show the hole center marks for this hole table.

.NET Syntax

Visual Basic (Declaration)

```
Property HoleCentersVisible As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHoleTable  
Dim value As System.Boolean  
  
instance.HoleCentersVisible = value  
  
value = instance.HoleCentersVisible
```

C#

```
System.bool HoleCentersVisible {get; set;}
```

C++/CLI

```
property System.bool HoleCentersVisible {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the hole center marks are visible, false if not

Visual Basic for Applications (VBA) Syntax

See [HoleTable::HoleCentersVisible](#).

See Also

[IHoleTable Interface](#)
[IHoleTable Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

HoleTag Property (IHoleTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleTable Interface](#) : HoleTag Property (IHoleTable)

Gets or sets the name of the specified tag in a hole table.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property HoleTag( _  
    ByVal Row As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IHoleTable  
Dim Row As System.Integer  
Dim value As System.String  
  
instance.HoleTag(Row) = value  
  
value = instance.HoleTag(Row)
```

C#

```
System.string HoleTag(  
    System.int Row  
) {get; set;}
```

C++/CLI

```
property System.String^ HoleTag {  
    System.String^ get(System.int Row);  
    void set (System.int Row, System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Row

0-based index of the row in which you want to change the name of the tag

Property Value

Tag name

Visual Basic for Applications (VBA) Syntax

See [HoleTable::HoleTag](#).

Example

[Change Tags in Hole Table \(VB.NET\)](#)
[Change Tags in Hole Table \(VBA\)](#)
[Change Tags in Hole Table \(C#\)](#)

Remarks

[IHoleTable::CombineTags](#) must be false for IHoleTable::HoleTag to work.

If you plan on changing many hole tags, then consider setting [IHoleTable::EnableUpdate](#) to false to avoid a possible degradation in performance. After changing all of the hole tags, set IHoleTable::EnableUpdate to true to update the hole table and model view.

See Also

[IHoleTable Interface](#)
[IHoleTable Members](#)
[IHoleTable::HoleTagsVisible Property](#)
[IHoleTable::TagStyle Property](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

HoleTagsVisible Property (IHoleTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleTable Interface](#) : HoleTagsVisible Property (IHoleTable)

Gets whether the hole tags are visible for this hole table.

.NET Syntax

Visual Basic (Declaration)

```
Property HoleTagsVisible As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHoleTable
Dim value As System.Boolean

instance.HoleTagsVisible = value

value = instance.HoleTagsVisible
```

C#

```
System.bool HoleTagsVisible {get; set;}
```

C++/CLI

```
property System.bool HoleTagsVisible {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if hole tags are visible, false if not

Visual Basic for Applications (VBA) Syntax

See [HoleTable::HoleTagsVisible](#).

See Also

[IHoleTable Interface](#)
[IHoleTable Members](#)
[IHoleTable::CombineTags Property](#)
[IHoleTable::HoleTag Property](#)
[IHoleTable::TagStyle Property](#)
[IHoleTable::EnableUpdate Property](#)

Availability

SOLIDWORKS 2004 SP1, Revision 12.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetTableAnnotations Method (IHoleTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleTable Interface](#) : IGetTableAnnotations Method (IHoleTable)

Gets the hole table annotations for this hole table feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTableAnnotations( _
    ByVal Count As System.Integer _
) As HoleTableAnnotation
```

```
Dim instance As IHoleTable
Dim Count As System.Integer
Dim value As HoleTableAnnotation

value = instance.IGetTableAnnotations(Count)
```

C#

```
HoleTableAnnotation IGetTableAnnotations(
    System.int Count
)
```

C++/CLI

```
HoleTableAnnotation^ IGetTableAnnotations(
    & System.int Count
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of hole table annotations for this hole table feature (see **Remarks**)

Return Value

- In-process, unmanaged C++: Pointer to the [IHoleTableAnnotation](#) objects for this hole table feature
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Because many of the [ITableAnnotation](#) APIs apply to all parts of a table annotation that has been split, you might not want all of the table annotations when just one table annotation would be sufficient.

For example, if you change the thickness of the grid line, then changing it on one table annotation affects all splits of that table annotation. Thus, for this method, you might want to specify 1 for Count so that a single value is returned. Or, you can call [IHoleTable::GetTableAnnotationCount](#) if you want the total number of table annotations, including any splits, for this hole table feature.

See Also

[IHoleTable Interface](#)
[IHoleTable Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetHoleLocationPrecision Method (IHoleTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleTable Interface](#) : SetHoleLocationPrecision Method (IHoleTable)

Sets the precision to use for location values for this hole table.

.NET Syntax

Visual Basic (Declaration)

```
Function SetHoleLocationPrecision( _
    ByVal UseDoc As System.Boolean, _
    ByVal Precision As System.Integer _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IHoleTable
Dim UseDoc As System.Boolean
Dim Precision As System.Integer
Dim value As System.Boolean

value = instance.SetHoleLocationPrecision(UseDoc, Precision)
```

C#

```
System.bool SetHoleLocationPrecision(
    System.bool UseDoc,
    System.int Precision
)
```

C++/CLI

```
System.bool SetHoleLocationPrecision(
    & System.bool UseDoc,
    & System.int Precision
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseDoc
True to set the location for this hole table using the document's precision, false to not
Precision
Precision to use for location values if UseDoc set to false

Return Value

True if precision is set, false if not

Visual Basic for Applications (VBA) Syntax

See [HoleTable::SetHoleLocationPrecision](#).

See Also

[IHoleTable Interface](#)
[IHoleTable Members](#)
[IHoleTable::GetHoleLocationPrecision Method](#)
[IHoleTable::GetHoleLocationUseDocPrecision Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowANSIInchLetterNumberDrillSizes Property (IHoleTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleTable Interface](#) : ShowANSIInchLetterNumberDrillSizes Property (IHoleTable)

Gets or sets whether to display hole sizes in this hole table using ANSI inch letters and drill numbers.

.NET Syntax

Visual Basic (Declaration)

```
Property ShowANSIInchLetterNumberDrillSizes As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHoleTable
Dim value As System.Boolean

instance.ShowANSIInchLetterNumberDrillSizes = value
```

```
value = instance.ShowANSIInchLetterNumberDrillSizes
```

C#

```
System.bool ShowANSIInchLetterNumberDrillSizes {get; set;}
```

C++/CLI

```
property System.bool ShowANSIInchLetterNumberDrillSizes {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to display hole sizes using ANSI inch letters and drill numbers, false to not

Visual Basic for Applications (VBA) Syntax

See [HoleTable::ShowANSIInchLetterNumberDrillSizes](#).

Example

[Get Labels of Datum Origin \(VBA\)](#)
[Get Labels of Datum Origin \(VB.NET\)](#)
[Get Labels of Datum Origin \(C#\)](#)

Remarks

This property:

- corresponds to the **Show ANSI inch letter and number drill sizes** option in the Scheme section of the Hole Table PropertyManager page in SOLIDWORKS.
- is valid only for holes created with the Hole Wizard tool.
- specifies whether to display hole sizes as ANSI inch letters or drill numbers, for example, A or #40.

See Also

[IHoleTable Interface](#)
[IHoleTable Members](#)
[IHoleTable::CombineSameSize Property \(\)](#)
[IHoleTable::CombineTags Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

StartingValue Property (IHoleTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleTable Interface](#) : StartingValue Property (IHoleTable)

Gets or sets the starting value for the datum tags of this hole table.

.NET Syntax

Visual Basic (Declaration)

```
Property StartingValue As System.String
```

Visual Basic (Usage)



```
Dim instance As IHoleTable  
Dim value As System.String  
  
instance.StartingValue = value  
  
value = instance.StartingValue
```

C#

```
System.string StartingValue {get; set;}
```

C++/CLI

```
property System.String^ StartingValue {  
    System.String^ get();  
    void set ( &    System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

A letter from A to Z, if the template of this hole table uses letter tags; a positive integer, if it uses number tags (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [HoleTable::StartingValue](#).

Remarks

See [IView::InsertHoleTable2](#) for more information about hole table templates.

See Also

[IHoleTable Interface](#)
[IHoleTable Members](#)
[IHoleTable::HoleTag Property](#)

Availability

SOLIDWORKS 2011 SP02, Revision Number 19.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

TagStyle Property (IHoleTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IHoleTable Interface](#) : TagStyle Property (IHoleTable)

Gets or sets the tag style for this hole table.

.NET Syntax

Visual Basic (Declaration)

```
Property TagStyle As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IHoleTable  
Dim value As System.Integer  
  
instance.TagStyle = value  
  
value = instance.TagStyle
```

C#

```
System.int TagStyle {get; set;}
```

C++/CLI

```
property System.int TagStyle {  
    System.int get();  
    void set ( &    System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Tag style as defined by [swHoleTableTagStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [HoleTable::TagStyle](#).

See Also

[IHoleTable Interface](#)
[IHoleTable Members](#)
[IHoleTable::CombineTags Property](#)
[IHoleTable::HoleTag Property](#)
[IHoleTable::HoleTagsVisible Property](#)
[IHoleTable::EnableUpdate Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

IHoleTableAnnotation (Type)

IHoleTableAnnotation Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHoleTableAnnotation Interface

Accesses the hole table annotation.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IHoleTableAnnotation
```

Visual Basic (Usage)

```
Dim instance As IHoleTableAnnotation
```

C#

```
public interface IHoleTableAnnotation
```

C++/CLI

```
public interface class IHoleTableAnnotation
```

Visual Basic for Applications (VBA) Syntax

See [HoleTableAnnotation](#).

Example

[Hide or Show First Column in Hole Table \(VB.NET\)](#)
[Hide or Show First Column in Hole Table \(VBA\)](#)
[Hide or Show First Column in Hole Table \(C#\)](#)
[Sort Table \(C#\)](#)
[Sort Table \(VB.NET\)](#)
[Sort Table \(VBA\)](#)

Remarks

The IHoleTableAnnotation object is derived from the [TableAnnotation](#) object.

Accessors

[IHoleTable::GetTableAnnotations](#) and [IHoleTable::!GetTableAnnotations](#)
[IView::InsertHoleTable2](#)

Access Diagram

[HoleTableAnnotation](#)

See Also

[IHoleTableAnnotation Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDrawingDoc::InsertTableAnnotation2 Method](#)
[IHoleTable Interface](#)

IHoleTableAnnotation Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHoleTableAnnotation Interface

The following tables list the members exposed by [IHoleTableAnnotation](#).

Public Properties

Name	Description
 Hole Table	Gets the hole table feature for this table annotation.

[Top](#)

Public Methods

Name	Description
 Sort	Sorts this hole table by the specified column in the specified sorting direction.

[Top](#)

See Also

[IHoleTableAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDrawingDoc::InsertTableAnnotation2 Method](#)
[IHoleTable Interface](#)

IHoleTableAnnotation Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHoleTableAnnotation Interface

For a list of all members of this type, see [IHoleTableAnnotation members](#).

Public Methods

Name	Description
 Sort	Sorts this hole table by the specified column in the specified sorting direction.

[Top](#)

See Also

[IHoleTableAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDrawingDoc::InsertTableAnnotation2 Method](#)
[IHoleTable Interface](#)

IHoleTableAnnotation Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IHoleTableAnnotation Interface

For a list of all members of this type, see [IHoleTableAnnotation members](#).

Public Properties

Name	Description
 Hole Table	Gets the hole table feature for this table annotation.

[Top](#)

See Also

[IHoleTableAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDrawingDoc::InsertTableAnnotation2 Method](#)
[IHoleTable Interface](#)

HoleTable Property (IHoleTableAnnotation)

[See Also](#) [Example](#)

 

Gets the hole table feature for this table annotation.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property HoleTable As HoleTable
```

Visual Basic (Usage)



```
Dim instance As IHoleTableAnnotation  
Dim value As HoleTable
```

```
value = instance.HoleTable
```

C#

```
HoleTable HoleTable {get;}
```

C++/CLI

```
property HoleTable^ HoleTable {  
    HoleTable^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pointer to the [IHoleTable](#) object

Visual Basic for Applications (VBA) Syntax

See [HoleTableAnnotation::HoleTable](#).

Example

[Get Labels of Datum Origin \(C#\)](#)
[Get Labels of Datum Origin \(VB.NET\)](#)
[Get Labels of Datum Origin \(VBA\)](#)

See Also

[IHoleTableAnnotation Interface](#)
[IHoleTableAnnotation Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Sort Method (IHoleTableAnnotation)

[See Also](#) [Example](#)



SolidWorks.Interop.sldworks Namespace > [IHoleTableAnnotation Interface](#) : Sort Method (IHoleTableAnnotation)

Sorts this hole table by the specified column in the specified sorting direction.

.NET Syntax

Visual Basic (Declaration)

```
Function Sort( _  
    ByVal ColumnIndex As System.Integer, _  
    ByVal SortAscending As System.Boolean _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IHoleTableAnnotation
Dim ColumnIndex As System.Integer
Dim SortAscending As System.Boolean
Dim value As System.Boolean

value = instance.Sort(ColumnIndex, SortAscending)
```

C#

```
System.bool Sort(
    System.int ColumnIndex,
    System.bool SortAscending
)
```

C++/CLI

```
System.bool Sort(
    & System.int ColumnIndex,
    & System.bool SortAscending
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ColumnIndex
0-based index of column to sort by (see **Remarks**)
SortAscending
True to sort ascending, false to sort descending

Return Value

True if sorted successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [HoleTableAnnotation::Sort](#).

Example

[Sort Table \(C#\)](#)
[Sort Table \(VB.NET\)](#)
[Sort Table \(VBA\)](#)

Remarks

Hole tables must be sorted by the Tag column.

See [Sorting Tables](#) for more information.

See Also

[IHoleTableAnnotation Interface](#)
[IHoleTableAnnotation Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

IImport3DInterconnectData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IImport3DInterconnectData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IImport3DInterconnectData Interface

Allows access to 3D Interconnect feature data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IImport3DInterconnectData
```

Visual Basic (Usage)



```
Dim instance As IImport3DInterconnectData
```

C#

```
public interface IImport3DInterconnectData
```

C++/CLI

```
public interface class IImport3DInterconnectData
```

Visual Basic for Applications (VBA) Syntax

See [IImport3DInterconnectData](#).

Example

[Use 3D Interconnect to Import Third-Party Native CAD Files \(C#\)](#)

Remarks

This interface requires 3D Interconnect. Enable 3D Interconnect by:

- Setting **Tools > Options > System Options > Import > Enable 3D Interconnect**.
- Or -
- Calling [ISldWorks::SetUserPreferenceToggle\(swUserPreferenceToggle_e.swMultiCAD_Enable3DInterconnect, True\)](#).

Access this interface after importing a third-party native CAD file into:

- an existing SOLIDWORKS part using [IPartDoc::InsertImportedFeature](#).
- an existing SOLIDWORKS assembly using [IAssemblyDoc::InsertImportedComponent](#).
- a new SOLIDWORKS part using [ISldWorks::LoadFile4](#).
- a new SOLIDWORKS assembly using [ISldWorks::LoadFile4](#).

Use [IFeature::Is3DInterconnectFeature](#) to determine whether a feature is a 3D Interconnect feature and whether this interface applies.

[ISldWorks::LoadFile4](#) imports into the appropriate native SOLIDWORKS part or assembly as follows:

- For both imported parts and assemblies, you can:
 - Determine whether an update is required ([IFeature::Is3DInterconnectUpdateAvailable](#)) and update the model ([IFeature::Update3DInterconnectModel](#)).
 - Edit the imported data using this interface, its accessor ([IFeature::GetImportedFeatureParameters](#)), or [IFeature::SetImportedFeatureParameters](#).
 - Break the link to the original third-party native CAD file using [IFeature::BreakLink](#). After you break a link, all references to the original CAD file are lost, and you can no longer change the features to transfer from the original file.
- For imported parts only, the native SOLIDWORKS file created is a copy of the original non-native file. The copy retains an external reference to the original third-party native CAD file. If the original CAD file is modified in its original application, the SOLIDWORKS copy can be updated to import those changes. Changes to the SOLIDWORKS copy do not propagate back to the original CAD file.
- For imported assemblies only, after import you must save the new SOLIDWORKS assembly in order for SOLIDWORKS to import and create a copy to edit. Only after saving the new SOLIDWORKS assembly can you edit the imported top-level assembly or break its reference links. Editing lower-level imported components or individually breaking their reference links is not supported.

3D Interconnect supports the following third-party native CAD file formats and versions:

- ACIS: .sat, .sab, .asat, .asab for r1 - 2018 1.0
- Autodesk® Inventor: .ipt for V6-V2018, .iam for V11 - V2018
- CATIA® V5: .CATPart, .CATProduct for V5R8 - V5-6R2017
- IGES: .igs, .iges for up to 5.3
- JT: .jt for JT 8.x, 9.x, and 10.x
- PTC®: .prt, .prt.*, .asm.* for Pro/ENGINEER® 16 - Creo 4.0
- Solid Edge®: .par, .asm, .psm for V18 - ST10
- STEP: .stp, .step for AP203, AP214, AP242
- NX® software: .prt for UG 11 - NX 11

The transfer properties of this interface apply to a subset of supported third-party native CAD files (e.g., Inventor, CATIA V5, Creo, NX, Solid Edge, and a few others). The types of properties that can be imported vary with file format. See the **SOLIDWORKS 3D Interconnect** topics in

the SOLIDWORKS Design user-interface help for specific information.

 Accessors

[IFeature::GetImportedFeatureParameters](#)

 Access Diagram

[Import3DInterconnectData](#)

 See Also

[IImport3DInterconnectData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IImport3DInterconnectData Interface Members

[See Also](#) [Properties](#) [Methods](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IImport3DInterconnectData Interface

The following tables list the members exposed by [IImport3DInterconnectData](#).

 Public Properties

Name	Description
 Axes	Gets or sets whether to import reference axes.
 CustomProperties	Gets or sets whether to import custom properties.
 IgnoreHiddenEntities	Gets or sets whether to ignore hidden entities.
 Material	Gets or sets whether to import material properties.
 Planes	Gets or sets whether to import reference planes.
 SketchesAndCurves	Gets or sets whether to import unconsumed sketches or curve data as 2D or 3D sketches.
 SolidBodies	Gets or sets whether to import solid bodies.
 SurfaceBodies	Gets or sets whether to import the data as surface entities.

[Top](#)

 Public Methods

Name	Description
 GetAuthoringInfo	Gets the name of the authoring application.
 GetReferencedFileName	Gets the full path name of the proprietary, non-native CAD file.
 SetReferencedFileName	Sets the full path name of the proprietary, non-native CAD file.

[Top](#)

 See Also

[IImport3DInterconnectData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IImport3DInterconnectData Interface Methods

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IImport3DInterconnectData Interface

For a list of all members of this type, see [IImport3DInterconnectData members](#).

 Public Methods

Name	Description
------	-------------

 GetAuthoringInfo	Gets the name of the authoring application.
 GetReferencedFileName	Gets the full path name of the proprietary, non-native CAD file.
 SetReferencedFileName	Sets the full path name of the proprietary, non-native CAD file.

[Top](#)

See Also

[IImport3DInterconnectData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IImport3DInterconnectData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IImport3DInterconnectData Interface

For a list of all members of this type, see [IImport3DInterconnectData members](#).

Public Properties

Name	Description
 Axes	Gets or sets whether to import reference axes.
 CustomProperties	Gets or sets whether to import custom properties.
 IgnoreHiddenEntities	Gets or sets whether to ignore hidden entities.
 Material	Gets or sets whether to import material properties.
 Planes	Gets or sets whether to import reference planes.
 SketchesAndCurves	Gets or sets whether to import unconsumed sketches or curve data as 2D or 3D sketches.
 SolidBodies	Gets or sets whether to import solid bodies.
 SurfaceBodies	Gets or sets whether to import the data as surface entities.

[Top](#)

See Also

[IImport3DInterconnectData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Axes Property (IImport3DInterconnectData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImport3DInterconnectData Interface](#) : Axes Property (IImport3DInterconnectData)

Gets or sets whether to import reference axes.

.NET Syntax

Visual Basic (Declaration)

Property Axes As System.Boolean

Visual Basic (Usage)



```
Dim instance As IImport3DInterconnectData  
Dim value As System.Boolean
```

```
instance.Axes = value
```

```
value = instance.Axes
```

C#

```
System.bool Axes {get; set;}
```

C++/CLI

```
property System.bool Axes {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import reference axes, false to not

Visual Basic for Applications (VBA) Syntax

See [Import3DInterconnectData::Axes](#).

Example

See the [IImport3DInterconnectData](#) examples.

Remarks

Reference axes can be imported only from CATIA® V5 files.

See Also

[IImport3DInterconnectData Interface](#)
[IImport3DInterconnectData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CustomProperties Property (IImport3DInterconnectData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImport3DInterconnectData Interface](#) : CustomProperties Property (IImport3DInterconnectData)

Gets or sets whether to import custom properties.

.NET Syntax

Visual Basic (Declaration)

Property CustomProperties As System.Boolean

Visual Basic (Usage)



```
Dim instance As IImport3DInterconnectData  
Dim value As System.Boolean  
  
instance.CustomProperties = value  
  
value = instance.CustomProperties
```

C#

```
System.bool CustomProperties {get; set;}
```

C++/CLI

```
property System.bool CustomProperties {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import custom properties, metadata, or user-defined attributes as SOLIDWORKS custom properties, false to not

Visual Basic for Applications (VBA) Syntax

See [Import3DInterconnectData::CustomProperties](#).

Example

See the [IImport3DInterconnectData](#) examples.

See Also

[IImport3DInterconnectData Interface](#)
[IImport3DInterconnectData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAuthoringInfo Method (IImport3DInterconnectData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImport3DInterconnectData Interface](#) : GetAuthoringInfo Method (IImport3DInterconnectData)

Gets the name of the authoring application.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAuthoringInfo() As System.String
```

Visual Basic (Usage)



```
Dim instance As IImport3DInterconnectData  
Dim value As System.String
```

```
value = instance.GetAuthoringInfo()
```

C#

```
System.string GetAuthoringInfo()
```

C++/CLI

```
System.String^ GetAuthoringInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Authoring application name

Visual Basic for Applications (VBA) Syntax

See [Import3DInterconnectData::GetAuthoringInfo](#).

Example

See the [IImport3DInterconnectData](#) examples.

See Also

[IImport3DInterconnectData Interface](#)
[IImport3DInterconnectData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetReferencedFileName Method (IImport3DInterconnectData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImport3DInterconnectData Interface](#) : GetReferencedFileName Method (IImport3DInterconnectData)

Gets the full path name of the proprietary, non-native CAD file.

.NET Syntax

Visual Basic (Declaration)

```
Function GetReferencedFileName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IImport3DInterconnectData  
Dim value As System.String
```

```
value = instance.GetReferencedFileName()
```

C#

```
System.string GetReferencedFileName()
```

C++/CLI

```
System.String^ GetReferencedFileName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Full path name of the linked non-native CAD file

Visual Basic for Applications (VBA) Syntax

See [Import3DInterconnectData::GetReferencedFileName](#).

Example

See the [IImport3DInterconnectData](#) examples.

See Also

[IImport3DInterconnectData Interface](#)
[IImport3DInterconnectData Members](#)
[IImport3DInterconnectData::SetReferencedFileName Method \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IgnoreHiddenEntities Property (IImport3DInterconnectData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImport3DInterconnectData Interface](#) : IgnoreHiddenEntities Property (IImport3DInterconnectData)

Gets or sets whether to ignore hidden entities.

.NET Syntax

Visual Basic (Declaration)

Property IgnoreHiddenEntities As System.Boolean

Visual Basic (Usage)



```
Dim instance As IImport3DInterconnectData  
Dim value As System.Boolean
```

```
instance.IgnoreHiddenEntities = value
```

```
value = instance.IgnoreHiddenEntities
```

C#

```
System.bool IgnoreHiddenEntities {get; set;}
```

C++/CLI

```
property System.bool IgnoreHiddenEntities {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to ignore hidden entities, false to not

Visual Basic for Applications (VBA) Syntax

See [Import3DInterconnectData::IgnoreHiddenEntities](#).

Example

See the [IImport3DInterconnectData](#) examples.

See Also

[IImport3DInterconnectData Interface](#)
[IImport3DInterconnectData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Material Property (IImport3DInterconnectData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImport3DInterconnectData Interface](#) : Material Property (IImport3DInterconnectData)

Gets or sets whether to import material properties.

.NET Syntax

Visual Basic (Declaration)

Property Material As System.Boolean

Visual Basic (Usage)



```
Dim instance As IImport3DInterconnectData  
Dim value As System.Boolean
```

```
instance.Material = value
```

```
value = instance.Material
```

C#

```
System.bool Material {get; set;}
```

C++/CLI

```
property System.bool Material {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import material name and density attributes, false to not

Visual Basic for Applications (VBA) Syntax

See [Import3DInterconnectData::Material](#).

Example

See the [IImport3DInterconnectData](#) examples.

See Also

[IImport3DInterconnectData Interface](#)
[IImport3DInterconnectData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Planes Property (IImport3DInterconnectData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImport3DInterconnectData Interface](#) : Planes Property (IImport3DInterconnectData)

Gets or sets whether to import reference planes.

.NET Syntax

Visual Basic (Declaration)

```
Property Planes As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IImport3DInterconnectData  
Dim value As System.Boolean
```

```
instance.Planes = value
```

```
value = instance.Planes
```

C#

```
System.bool Planes {get; set;}
```

C++/CLI

```
property System.bool Planes {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import reference planes, false to not

Visual Basic for Applications (VBA) Syntax

See [Import3DInterconnectData::Planes](#).

Example

See the [IImport3DInterconnectData](#) examples.

See Also

[IImport3DInterconnectData Interface](#)
[IImport3DInterconnectData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetReferencedFileName Method (IImport3DInterconnectData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImport3DInterconnectData Interface](#) : SetReferencedFileName Method (IImport3DInterconnectData)

Sets the full path name of the proprietary, non-native CAD file.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetReferencedFileName( _  
    ByVal FileName As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IImport3DInterconnectData  
Dim FileName As System.String  
  
instance.SetReferencedFileName(FileName)
```

C#

```
void SetReferencedFileName(  
    System.string FileName  
)
```

C++/CLI

```
void SetReferencedFileName(  
& System.String^ FileName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName
Full path name of the linked non-native CAD file

Visual Basic for Applications (VBA) Syntax

See [Import3DInterconnectData::SetReferencedFileName](#).

See Also

[IImport3DInterconnectData Interface](#)
[IImport3DInterconnectData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SketchesAndCurves Property (IImport3DInterconnectData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImport3DInterconnectData Interface](#) : SketchesAndCurves Property (IImport3DInterconnectData)

Gets or sets whether to import unconsumed sketches or curve data as 2D or 3D sketches.

.NET Syntax

Visual Basic (Declaration)

Property SketchesAndCurves As System.Boolean

Visual Basic (Usage)



```
Dim instance As IImport3DInterconnectData  
Dim value As System.Boolean
```

```
instance.SketchesAndCurves = value
```

```
value = instance.SketchesAndCurves
```

C#

```
System.bool SketchesAndCurves {get; set;}
```

C++/CLI

```
property System.bool SketchesAndCurves {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import unconsumed sketches or curve data as 2D or 3D sketches, false to not

Visual Basic for Applications (VBA) Syntax

See [IImport3DInterconnectData::SketchesAndCurves](#).

Example

See the [IImport3DInterconnectData](#) examples.

See Also

[IImport3DInterconnectData Interface](#)
[IImport3DInterconnectData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SolidBodies Property (IImport3DInterconnectData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImport3DInterconnectData Interface](#) : SolidBodies Property (IImport3DInterconnectData)

Gets or sets whether to import solid bodies.

.NET Syntax

Visual Basic (Declaration)

Property SolidBodies As System.Boolean

Visual Basic (Usage)



```
Dim instance As IImport3DInterconnectData  
Dim value As System.Boolean  
  
instance.SolidBodies = value  
value = instance.SolidBodies
```

C#

```
System.bool SolidBodies {get; set;}
```

C++/CLI

```
property System.bool SolidBodies {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import solid bodies, false to not

Visual Basic for Applications (VBA) Syntax

See [Import3DInterconnectData::SolidBodies](#).

Example

See the [IImport3DInterconnectData](#) examples.

See Also

[IImport3DInterconnectData Interface](#)
[IImport3DInterconnectData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SurfaceBodies Property (IImport3DInterconnectData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImport3DInterconnectData Interface](#) : SurfaceBodies Property (IImport3DInterconnectData)

Gets or sets whether to import the data as surface entities.

.NET Syntax

Visual Basic (Declaration)

Property SurfaceBodies As System.Boolean

Visual Basic (Usage)



```
Dim instance As IImport3DInterconnectData  
Dim value As System.Boolean
```

```
instance.SurfaceBodies = value  
value = instance.SurfaceBodies
```

C#

```
System.bool SurfaceBodies {get; set;}
```

C++/CLI

```
property System.bool SurfaceBodies {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import the data as surface entities, false to not

Visual Basic for Applications (VBA) Syntax

See [Import3DInterconnectData::SurfaceBodies](#).

Example

See the [IImport3DInterconnectData](#) examples.

See Also

[IImport3DInterconnectData Interface](#)
[IImport3DInterconnectData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0