

SOLIDWORKS API (.NET VBA C#) — Reference (136/337): IImportDxfDwgData-IImportStepData

SOLIDWORKS API Documentation (converted from CHM)

IImportDxfDwgData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IImportDxfDwgData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IImportDxfDwgData Interface

Allows you to specify values when importing or inserting DXF/DWG data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IImportDxfDwgData
```

Visual Basic (Usage)



```
Dim instance As IImportDxfDwgData
```

C#

```
public interface IImportDxfDwgData
```

C++/CLI

```
public interface class IImportDxfDwgData
```

Visual Basic for Applications (VBA) Syntax

See [ImportDxfDwgData](#).

Example

[Import DXF File into Part Sketch \(VBA\)](#)
[Import DXF File into Drawing \(VBA\)](#)
[Insert and Position DXF/DWG File in Drawing \(VBA\)](#)
[Insert and Position DXF/DWG File in Drawing \(VB.NET\)](#)
[Insert and Position DXF/DWG File in Drawing \(C#\)](#)
[Insert DXF/DWG File and Add Dimensions \(VBA\)](#)
[Insert DXF/DWG File and Add Dimensions \(VB.NET\)](#)
[Insert DXF/DWG File and Add Dimensions \(C#\)](#)

Remarks

When importing DXF/DWG data, you can:

- Let SOLIDWORKS determine the default values:
 - Paper size and sheet scale are computed to fit the input data.
 - Length unit is determined from the header of the input DXF/DWG file.
 - Sheet name is the same as the layout name in the input DXF/DWG file.

- or -

- Set your own values by using:
 - [ISldWorks::GetImportFileData](#) to obtain the IImportDxfDwgData interface.
 - Use the following methods with a Sheet argument of "" (an empty string), to set up your defaults before importing or inserting the file:
 - [IImportDxfDwgData::GetPaperSize](#)
 - [IImportDxfDwgData::GetPosition](#)
 - [IImportDxfDwgData::GetSheetScale](#)
 - [IImportDxfDwgData::ImportMethod](#)
 - [IImportDxfDwgData::LengthUnit](#)
 - [IImportDxfDwgData::SetPaperSize](#)

- [IImportDxfDwgData::SetPosition](#)
- [IImportDxfDwgData::SetSheetScale](#)
- [IImportDxfDwgData::SheetName](#)

NOTES:

- Getting the IImportDxfDwgData interface does not get default values from the input file. Any values not set by you are set to the values computed by SOLIDWORKS.
- If the DWG/DXF file has multiple sheets, use these methods with a valid layout name in the Sheet argument to set up sheet specific settings, which override the default settings. If any of the individual items are not specified for a given layout name, the value used is from the defaults (layout name ""). If the default value is not specified, SOLIDWORKS computes and uses a meaningful value for that item.

When inserting DXF/DWG data as a feature into the current model document, first select a plane or planar surface and then call [IFeatureManager::InsertDwgOrDxfFile2](#).

Call [ISldWorks::LoadFile4](#) to import the DXF/DWG file as a new SOLIDWORKS model document.

Accessors

[ISldWorks::GetImportFileData](#)

Access Diagram

[ImportDxfDwgData](#)

See Also

[IImportDxfDwgData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IImportIgesData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IImportDxfDwgData Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IImportDxfDwgData Interface

For a list of all members of this type, see [IImportDxfDwgData members](#).

Public Methods

Name	Description
 GetImportLayerToSheetFormat	Gets whether the specified visible layer is imported to the drawing sheet or sheet format.
 GetImportLayerVisibility	Gets whether the specified layer is imported hidden or visible.
 GetMergeDistance	Gets whether points that are within the specified distance are merged in the part sketch after entities are imported.
 GetMergePoints	Gets whether near-identical points are merged in the part sketch after entities are imported.
 GetPaperSize	Gets the size of the paper for the drawing.
 GetPosition	Gets the position of the entities created in the drawing.
 GetSheetScale	Gets the sheet scale for the drawing.
 SetImportLayerToSheetFormat	Sets whether the specified visible layers are imported to the sheet format or drawing sheet.
 SetImportLayerVisibility	Sets whether the specified layers are imported hidden or visible.
 SetMergePoints	Sets whether near-identical points within the specified distance are merged in the part sketch after entities are imported.
 SetPaperSize	Sets the size of the paper in the drawing.
 SetPosition	Sets the position of the entities created in the drawing.
 SetSheetScale	Sets the sheet scale for the drawing.

[Top](#)

See Also

[IImportDxfDwgData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IImportDxfDwgData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IImportDxfDwgData Interface

The following tables list the members exposed by [IImportDxfDwgData](#).

Public Properties

Name	Description
AddSketchConstraints	Gets or sets whether constraints are added to the geometry in the part sketch after importing the entities.
DocumentTemplate	Gets or sets the filename of the document template.
IgnorePolylineWidth	Gets or sets whether to convert width polylines to solid fill hatches when importing to the part sketch.
ImportDimensions	Gets or sets whether to import dimension into the part sketch.
ImportHatch	Gets or sets whether to import hatch into this part sketch.
ImportMethod	Gets or sets whether to import this sheet (layout).
LengthUnit	Gets or sets the length units for the drawing.
SheetName	Gets or sets the name of the sheet for the drawing.

[Top](#)

Public Methods

Name	Description
GetImportLayerToSheetFormat	Gets whether the specified visible layer is imported to the drawing sheet or sheet format.
GetImportLayerVisibility	Gets whether the specified layer is imported hidden or visible.
GetMergeDistance	Gets whether points that are within the specified distance are merged in the part sketch after entities are imported.
GetMergePoints	Gets whether near-identical points are merged in the part sketch after entities are imported.
GetPaperSize	Gets the size of the paper for the drawing.
GetPosition	Gets the position of the entities created in the drawing.
GetSheetScale	Gets the sheet scale for the drawing.
SetImportLayerToSheetFormat	Sets whether the specified visible layers are imported to the sheet format or drawing sheet.
SetImportLayerVisibility	Sets whether the specified layers are imported hidden or visible.
SetMergePoints	Sets whether near-identical points within the specified distance are merged in the part sketch after entities are imported.
SetPaperSize	Sets the size of the paper in the drawing.
SetPosition	Sets the position of the entities created in the drawing.
SetSheetScale	Sets the sheet scale for the drawing.

[Top](#)

See Also

[IImportDxfDwgData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IImportIgesData Interface](#)

IImportDxfDwgData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IImportDxfDwgData Interface

For a list of all members of this type, see [IImportDxfDwgData members](#).

Public Properties

Name	Description
 AddSketchConstraints	Gets or sets whether constraints are added to the geometry in the part sketch after importing the entities.
 DocumentTemplate	Gets or sets the filename of the document template.
 IgnorePolylineWidth	Gets or sets whether to convert width polylines to solid fill hatches when importing to the part sketch.
 ImportDimensions	Gets or sets whether to import dimension into the part sketch.
 ImportHatch	Gets or sets whether to import hatch into this part sketch.
 ImportMethod	Gets or sets whether to import this sheet (layout).
 LengthUnit	Gets or sets the length units for the drawing.
 SheetName	Gets or sets the name of the sheet for the drawing.

[Top](#)

See Also

[IImportDxfDwgData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IImportIgesData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddSketchConstraints Property (IImportDxfDwgData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportDxfDwgData Interface](#) : AddSketchConstraints Property (IImportDxfDwgData)

Gets or sets whether constraints are added to the geometry in the part sketch after importing the entities.

.NET Syntax

Visual Basic (Declaration)

```
Property AddSketchConstraints( _
    ByVal Sheet As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IImportDxfDwgData
Dim Sheet As System.String
Dim value As System.Boolean

instance.AddSketchConstraints(Sheet) = value

value = instance.AddSketchConstraints(Sheet)
```

C#

```
System.bool AddSketchConstraints(
    System.string Sheet
) {get; set;}
```

C++/CLI

```
property System.bool AddSketchConstraints {
    System.bool get(System.String^ Sheet);
    void set (System.String^ Sheet, System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sheet

Sheet (layout) name of the input file or an empty string for all sheets

Property Value

True to add constraints, false to not

Visual Basic for Applications (VBA) Syntax

See [ImportDxfDwgData::AddSketchConstraints](#).

Example

[Import DXF File into Part Sketch \(VBA\)](#)

Remarks

This property only supports importing to a part sketch; it does not support importing to a drawing.

By default, constraints are not added.

See Also

[IImportDxfDwgData Interface](#)
[IImportDxfDwgData Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DocumentTemplate Property (IImportDxfDwgData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportDxfDwgData Interface](#) : DocumentTemplate Property (IImportDxfDwgData)

Gets or sets the filename of the document template.

.NET Syntax

Visual Basic (Declaration)

Property DocumentTemplate As System.String

Visual Basic (Usage)



```
Dim instance As IImportDxfDwgData
Dim value As System.String

instance.DocumentTemplate = value

value = instance.DocumentTemplate
```

C#

```
System.string DocumentTemplate {get; set;}
```

C++/CLI

```
property System.String^ DocumentTemplate {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Filename of document template

Visual Basic for Applications (VBA) Syntax

See [ImportDxfDwgData::DocumentTemplate](#).

Remarks

This method only supports importing to a drawing; it does not support importing to a part sketch.

See Also

[IImportDxfDwgData Interface](#)
[IImportDxfDwgData Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetImportLayerToSheetFormat Method (IImportDxfDwgData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportDxfDwgData interface](#) : GetImportLayerToSheetFormat Method (IImportDxfDwgData)

Gets whether the specified visible layer is imported to the drawing sheet or sheet format.

.NET Syntax

Visual Basic (Declaration)

```
Function GetImportLayerToSheetFormat( _  
    ByVal Layer As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IImportDxfDwgData  
Dim Layer As System.String  
Dim value As System.Boolean  
  
value = instance.GetImportLayerToSheetFormat(Layer)
```

C#

```
System.bool GetImportLayerToSheetFormat(  
    System.string Layer  
)
```

C++/CLI

```
System.bool GetImportLayerToSheetFormat(  
    & System.String^ Layer  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Layer
Name of the layer

Return Value

True to import the specified visible layer to the sheet format, false to import it to the drawing sheet

Visual Basic for Applications (VBA) Syntax

See [IImportDxfDwgData::GetImportLayerToSheetFormat](#).

Remarks

This method only supports importing to a drawing; it does not support importing to a part sketch.

See Also

[IImportDxfDwgData Interface](#)
[IImportDxfDwgData Members](#)
[IImportDxfDwgData::GetImportLayerVisibility Method](#)
[IImportDxfDwgData::SetImportLayerToSheetFormat Method](#)
[IImportDxfDwgData::SetImportLayerVisibility Method](#)
[IImportDxfDwgData::ImportMethod Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetImportLayerVisibility Method (IImportDxfDwgData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportDxfDwgData Interface](#) : GetImportLayerVisibility Method (IImportDxfDwgData)

Gets whether the specified layer is imported hidden or visible.

.NET Syntax

Visual Basic (Declaration)

```
Function GetImportLayerVisibility( _  
    ByVal Layer As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IImportDxfDwgData  
Dim Layer As System.String  
Dim value As System.Integer  
  
value = instance.GetImportLayerVisibility(Layer)
```

C#

```
System.int GetImportLayerVisibility(  
    System.string Layer  
)
```

C++/CLI

```
System.int GetImportLayerVisibility(  
    & System.String^ Layer  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Layer
Name of the layer

Return Value

Visibility state as defined in [swImportDxfDwg_LayerVisibility_e](#)

Visual Basic for Applications (VBA) Syntax

See [IImportDxfDwgData::GetImportLayerVisibility](#).

Remarks

This method only supports importing to a drawing; it does not support importing to a part sketch.

See Also

[IImportDxfDwgData Interface](#)
[IImportDxfDwgData Members](#)
[IImportDxfDwgData::GetImportLayerToSheetFormat Method](#)
[IImportDxfDwgData::SetImportLayerToSheetFormat Method](#)
[IImportDxfDwgData::SetImportLayerVisibility Method](#)
[IImportDxfDwgData::ImportMethod Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetMergeDistance Method (IImportDxfDwgData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportDxfDwgData Interface](#) : GetMergeDistance Method (IImportDxfDwgData)

Gets whether points that are within the specified distance are merged in the part sketch after entities are imported.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMergeDistance( _  
    ByVal Sheet As System.String _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IImportDxfDwgData  
Dim Sheet As System.String  
Dim value As System.Double  
  
value = instance.GetMergeDistance(Sheet)
```

C#

```
System.double GetMergeDistance(  
    System.string Sheet  
)
```

C++/CLI

```
System.double GetMergeDistance(  
& System.String^ Sheet  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sheet

Sheet (layout) name of the input file or an empty string for all sheets

Return Value

Distance to determine whether two points should be merged

Visual Basic for Applications (VBA) Syntax

See [IImportDxfDwgData::GetMergeDistance](#).

Example

[Import DXF File into Part Sketch \(VBA\)](#)

Remarks

This property only supports importing to a part sketch; it does not support importing to a drawing.

By default, points within 0.001mm are merged.

See Also

[IImportDxfDwgData Interface](#)
[IImportDxfDwgData Members](#)
[IImportDxfDwgData::GetMergePoints Method](#)
[IImportDxfDwgData::SetMergePoints Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetMergePoints Method (IImportDxfDwgData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportDxfDwgData Interface](#) : GetMergePoints Method (IImportDxfDwgData)

Gets whether near-identical points are merged in the part sketch after entities are imported.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMergePoints( _  
    ByVal Sheet As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IImportDxfDwgData  
Dim Sheet As System.String  
Dim value As System.Boolean  
  
value = instance.GetMergePoints(Sheet)
```

C#

```
System.bool GetMergePoints(  
    System.string Sheet  
)
```

C++/CLI

```
System.bool GetMergePoints(  
& System.String^ Sheet  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sheet

Sheet (layout) name of the input file or an empty string for all sheets

Return Value

True to merge near-identical points, false to not

Visual Basic for Applications (VBA) Syntax

See [IImportDxfDwgData::GetMergePoints](#).

Remarks

This property only supports importing to a part sketch; it does not support importing to a drawing.

By default, points within 0.001mm are merged.

See Also

[IImportDxfDwgData Interface](#)
[IImportDxfDwgData Members](#)
[IImportDxfDwgData::GetMergeDistance Method](#)
[IImportDxfDwgData::SetMergePoints Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPaperSize Method (IImportDxfDwgData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportDxfDwgData interface](#) : GetPaperSize Method (IImportDxfDwgData)

Gets the size of the paper for the drawing.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetPaperSize(  
    ByVal Sheet As System.String, _  
    ByRef Size As System.Integer, _  
    ByRef Height As System.Double, _  
    ByRef Width As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IImportDxfDwgData  
Dim Sheet As System.String  
Dim Size As System.Integer  
Dim Height As System.Double  
Dim Width As System.Double  
  
instance.GetPaperSize(Sheet, Size, Height, Width)
```

C#

```
void GetPaperSize(  
    System.string Sheet,  
    out System.int Size,  
    out System.double Height,  
    out System.double Width  
)
```

C++/CLI

```
void GetPaperSize(  
& System.String^ Sheet,  
& [Out] System.int Size,  
& [Out] System.double Height,  
& [Out] System.double Width  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sheet

Sheet (layout) name of the input file or an empty string for all sheets

Size

Size as defined in [swDwgPaperSizes_e](#)

Height

If Size is swDwgPapersUserDefined, then the height of the paper in meters

Width

If Size is swDwgPapersUserDefined, then the width of the paper in meters

Visual Basic for Applications (VBA) Syntax

See [IImportDxfDwgData::GetPaperSize](#).

Remarks

This method only supports importing to a drawing; it does not support importing to a part sketch.

See Also

[IImportDxfDwgData Interface](#)
[IImportDxfDwgData Members](#)
[IImportDxfDwgData::SetPaperSize Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPosition Method (IImportDxfDwgData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportDxfDwgData Interface](#) : GetPosition Method (IImportDxfDwgData)

Gets the position of the entities created in the drawing.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetPosition( _  
    ByVal Sheet As System.String, _  
    ByRef Positioning As System.Integer, _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IImportDxfDwgData  
Dim Sheet As System.String  
Dim Positioning As System.Integer  
Dim X As System.Double  
Dim Y As System.Double  
  
instance.GetPosition(Sheet, Positioning, X, Y)
```

C#

```
void GetPosition(  
    System.string Sheet,  
    out System.int Positioning,  
    out System.double X,  
    out System.double Y  
)
```

C++/CLI

```
void GetPosition(  
& System.String^ Sheet,  
& [Out] System.int Positioning,  
& [Out] System.double X,  
& [Out] System.double Y  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sheet
Sheet (layout) name of the input file or an empty string for all sheets
Positioning
Position as defined in [swDwgImportEntitiesPositioning_e](#)
X
X coordinate of the origin of the imported drawing
Y

Y coordinate of the origin of the imported drawing

Visual Basic for Applications (VBA) Syntax

See [ImportDxfDwgData.GetPosition](#).

Remarks

This method only supports importing to a drawing; it does not support importing to a part sketch.

See Also

[IImportDxfDwgData Interface](#)
[IImportDxfDwgData Members](#)
[IImportDxfDwgData.SetPosition Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSheetScale Method (IImportDxfDwgData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportDxfDwgData Interface](#) : GetSheetScale Method (IImportDxfDwgData)

Gets the sheet scale for the drawing.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetSheetScale(  
    ByVal Sheet As System.String, _  
    ByRef Numerator As System.Double, _  
    ByRef Denominator As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IImportDxfDwgData  
Dim Sheet As System.String  
Dim Numerator As System.Double  
Dim Denominator As System.Double  
  
instance.GetSheetScale(Sheet, Numerator, Denominator)
```

C#

```
void GetSheetScale(  
    System.string Sheet,  
    out System.double Numerator,  
    out System.double Denominator  
)
```

C++/CLI

```
void GetSheetScale(  
& System.String^ Sheet,  
& [Out] System.double Numerator,  
& [Out] System.double Denominator  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sheet
Sheet (layout) name of the input file or an empty string for all sheets
Numerator
Numerator of the scale

Denominator
Denominator of the scale

Visual Basic for Applications (VBA) Syntax

See [ImportDxfDwgData::GetSheetScale](#).

Remarks

This method only supports importing to a drawing; it does not support importing to a part sketch.

See Also

[IImportDxfDwgData Interface](#)
[IImportDxfDwgData Members](#)
[IImportDxfDwgData::SetSheetScale Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IgnorePolylineWidth Property (IImportDxfDwgData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportDxfDwgData Interface](#) : IgnorePolylineWidth Property (IImportDxfDwgData)

Gets or sets whether to convert width polylines to solid fill hatches when importing to the part sketch.

.NET Syntax

Visual Basic (Declaration)

Property IgnorePolylineWidth As System.Boolean

Visual Basic (Usage)



```
Dim instance As IImportDxfDwgData
Dim value As System.Boolean

instance.IgnorePolylineWidth = value

value = instance.IgnorePolylineWidth
```

C#

```
System.bool IgnorePolylineWidth {get; set;}
```

C++/CLI

```
property System.bool IgnorePolylineWidth {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to convert width polylines to solid fill hatches, false to not

Visual Basic for Applications (VBA) Syntax

See [ImportDxfDwgData::IgnorePolylineWidth](#).

See Also

[IImportDxfDwgData Interface](#)
[IImportDxfDwgData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ImportDimensions Property (IImportDxfDwgData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportDxfDwgData Interface](#) : ImportDimensions Property (IImportDxfDwgData)

Gets or sets whether to import dimension into the part sketch.

.NET Syntax

Visual Basic (Declaration)

```
Property ImportDimensions( _  
    ByVal Sheet As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IImportDxfDwgData  
Dim Sheet As System.String  
Dim value As System.Boolean  
  
instance.ImportDimensions(Sheet) = value  
  
value = instance.ImportDimensions(Sheet)
```

C#

```
System.bool ImportDimensions(  
    System.string Sheet  
) {get; set;}
```

C++/CLI

```
property System.bool ImportDimensions {  
    System.bool get(System.String^ Sheet);  
    void set (System.String^ Sheet, System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sheet

Sheet (layout) name of the input file or an empty string for all sheets

Property Value

True to import dimension, false to not

Visual Basic for Applications (VBA) Syntax

See [IImportDxfDwgData::ImportDimensions](#).

Example

[Import DXF File into Part Sketch \(VBA\)](#)

Remarks

This property only supports importing to a part sketch; it does not support importing to a drawing.

By default, dimensions are not imported.

See Also

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ImportHatch Property (IImportDxfDwgData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportDxfDwgData Interface](#) : ImportHatch Property (IImportDxfDwgData)

Gets or sets whether to import hatch into this part sketch.

.NET Syntax

Visual Basic (Declaration)

```
Property ImportHatch( _  
    ByVal Sheet As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IImportDxfDwgData  
Dim Sheet As System.String  
Dim value As System.Boolean  
  
instance.ImportHatch(Sheet) = value  
  
value = instance.ImportHatch(Sheet)
```

C#

```
System.bool ImportHatch(  
    System.string Sheet  
) {get; set;}
```

C++/CLI

```
property System.bool ImportHatch {  
    System.bool get(System.String^ Sheet);  
    void set (System.String^ Sheet, System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sheet

Sheet (layout) name of the input file or an empty string for all sheets

Property Value

True to import hatch, false to not

Visual Basic for Applications (VBA) Syntax

See [IImportDxfDwgData::ImportHatch](#).

Example

[Import DXF File into Part Sketch \(VBA\)](#)

Remarks

This property only supports importing to a part sketch; it does not support importing to a drawing.

By default, hatch will be imported.

See Also

[IImportDxfDwgData Interface](#)
[IImportDxfDwgData Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ImportMethod Property (IImportDxfDwgData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportDxfDwgData Interface](#) : ImportMethod Property (IImportDxfDwgData)

Gets or sets whether to import this sheet (layout).

.NET Syntax

Visual Basic (Declaration)

```
Property ImportMethod( _  
    ByVal Sheet As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IImportDxfDwgData  
Dim Sheet As System.String  
Dim value As System.Integer  
  
instance.ImportMethod(Sheet) = value  
value = instance.ImportMethod(Sheet)
```

C#

```
System.int ImportMethod(  
    System.string Sheet  
) {get; set;}
```

C++/CLI

```
property System.int ImportMethod {  
    System.int get(System.String^ Sheet);  
    void set (System.String^ Sheet, System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sheet

Sheet (layout) name of the input file or an empty string for all sheets (see **Remarks**)

Property Value

Import method as defined in [swIImportDxfDwg.ImportMethod_e](#)

Visual Basic for Applications (VBA) Syntax

See [IImportDxfDwgData::ImportMethod](#).

Example

[Import DXF File into Part Sketch \(VBA\)](#)
[Insert DXF/DWG File and Add Dimensions \(VBA\)](#)
[Insert DXF/DWG File and Add Dimensions \(VB.NET\)](#)
[Insert DXF/DWG File and Add Dimensions \(C#\)](#)
[Insert and Position DXF/DWG File in Drawing \(VBA\)](#)
[Insert and Position DXF/DWG File in Drawing \(VB.NET\)](#)
[Insert and Position DXF/DWG File in Drawing \(C#\)](#)

Remarks

By default, all sheets are imported into a new drawing.

If you want to import...	Then set...
All sheets except for a specific one into a new drawing	<code>ImportDxfDwgData.ImportMethod("<sheet to exclude>") = swImportDxfDwg_DoNotImportSheet</code>
Only a single sheet into a sketch in a new part	<code>ImportDxfDwgData.ImportMethod("") = swImportDxfDwg_DoNotImportSheet</code> to make the default not to import sheets. Then set: <code>ImportDxfDwgData.ImportMethod("<sheet to import>") = swImportDxfDwg_ImportToPartSketch</code> to import only this sheet.

See Also

[IImportDxfDwgData Interface](#)
[IImportDxfDwgData Members](#)
[IImportDxfDwgData::GetImportLayerToSheetFormat Method](#)
[IImportDxfDwgData::GetImportLayerVisibility Method](#)
[IImportDxfDwgData::SetImportLayerToSheetFormat Method](#)
[IImportDxfDwgData::SetImportLayerVisibility Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LengthUnit Property (IImportDxfDwgData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportDxfDwgData Interface](#) : LengthUnit Property (IImportDxfDwgData)

Gets or sets the length units for the drawing.

.NET Syntax

Visual Basic (Declaration)

```
Property LengthUnit( _  
    ByVal Sheet As System.String _  
) As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IImportDxfDwgData  
Dim Sheet As System.String  
Dim value As System.Integer  
  
instance.LengthUnit(Sheet) = value  
  
value = instance.LengthUnit(Sheet)
```

C#

```
System.int LengthUnit(  
    System.string Sheet  
) {get; set;}
```

C++/CLI



```
property System.int LengthUnit {
    System.int get(System.String^ Sheet);
    void set (System.String^ Sheet, System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sheet

Sheet (layout) name of the input file or an empty string for all sheets

Property Value

Length as defined in [swLengthUnit_e](#)

Visual Basic for Applications (VBA) Syntax

See [ImportDxfDwgData::LengthUnit](#).

Example

[Import DXF File into Drawing \(VBA\)](#)
[Insert DXF/DWG File and Add Dimensions \(VBA\)](#)
[Insert DXF/DWG File and Add Dimensions \(VB.NET\)](#)
[Insert DXF/DWG File and Add Dimensions \(C#\)](#)
[Insert and Position DXF/DWG File in Drawing \(C#\)](#)
[Insert and Position DXF/DWG File in Drawing \(VB.NET\)](#)
[Insert and Position DXF/DWG File in Drawing \(VBA\)](#)

Remarks

By default, the length is determined from the header of the input DWG/DXF file.

See Also

[IImportDxfDwgData Interface](#)
[IImportDxfDwgData Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetImportLayerToSheetFormat Method (IImportDxfDwgData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportDxfDwgData Interface](#) : SetImportLayerToSheetFormat Method (IImportDxfDwgData)

Sets whether the specified visible layers are imported to the sheet format or drawing sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function SetImportLayerToSheetFormat( _
    ByVal Layers As System.Object, _
    ByVal SheetFormat As System.Boolean _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IImportDxfDwgData
Dim Layers As System.Object
Dim SheetFormat As System.Boolean
Dim value As System.Boolean
```

```
value = instance.SetImportLayerToSheetFormat(Layers, SheetFormat)
```

C#



```
System.bool SetImportLayerToSheetFormat(  
    System.object Layers,  
    System.bool SheetFormat  
)
```

C++/CLI

```
System.bool SetImportLayerToSheetFormat(  
& System.Object^ Layers,  
& System.bool SheetFormat  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Layers

Array of strings of the names of the layers (see **Remarks**)

SheetFormat

True to import the specified visible layers to the sheet format, false to import them to the drawing sheet

Return Value

True of importing the specified visible layers was successful, false if not

Visual Basic for Applications (VBA) Syntax

See [ImportDxfDwgData::SetImportLayerToSheetFormat](#).

Remarks

This method only supports importing to a drawing; it does not support importing to a part sketch.

The Layers argument can contain either a string or an array of strings, where the strings are the layer names with which to work. You can also specify the argument as empty, which indicates all layers. If this method is not used, the default behavior is to import all layers to the drawing sheet.

The import to sheet or sheet format Boolean is the same for all sheets that are imported; you cannot specify it on a sheet-by-sheet basis.

Visual Basic for Applications (VBA) Example

To import all layers on all sheets to drawings sheets in SOLIDWORKS (this is the default behavior):

```
boolstatus = ImportDxfDwgData.SetImportLayerToSheetFormat (emptyVariant, false)
```

To import layers "A" and "B" to the drawing sheet and the remaining layers to the sheet format:

```
boolstatus = ImportDxfDwgData.SetImportLayerToSheetFormat (emptyVariant, True)  
    layerName(0) = "A"  
    layerName(1) = "B"  
    layerVariant = layerName  
    boolstatus = ImportDxfDwgData.SetImportLayerToSheetFormat ((layerVariant), false)
```

See Also

[IImportDxfDwgData Interface](#)
[IImportDxfDwgData Members](#)
[ImportDxfDwgData::GetImportLayerToSheetFormat Method](#)
[ImportDxfDwgData::GetImportLayerVisibility Method](#)
[ImportDxfDwgData::SetImportLayerVisibility Method](#)
[IImportDxfDwgData::ImportMethod Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SetImportLayerVisibility Method (IImportDxfDwgData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportDxfDwgData Interface](#) : SetImportLayerVisibility Method (IImportDxfDwgData)

Sets whether the specified layers are imported hidden or visible.

.NET Syntax

Visual Basic (Declaration)

```
Function SetImportLayerVisibility( _  
    ByVal Layers As System.Object, _  
    ByVal Visibility As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IImportDxfDwgData  
Dim Layers As System.Object  
Dim Visibility As System.Integer  
Dim value As System.Boolean  
  
value = instance.SetImportLayerVisibility(Layers, Visibility)
```

C#

```
System.bool SetImportLayerVisibility(  
    System.object Layers,  
    System.int Visibility  
)
```

C++/CLI

```
System.bool SetImportLayerVisibility(  
& System.Object^ Layers,  
& System.int Visibility  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Layers

Array of strings of the names of the layers (see **Remarks**)

Visibility

Visibility of the layers as defined in [swImportDxfDwg_LayerVisibility_e](#)

Return Value

True if setting the visibility of these layers is successful, false if not

Visual Basic for Applications (VBA) Syntax

See [ImportDxfDwgData::SetImportLayerVisibility](#).

Remarks

This method only supports importing to a drawing; it does not support importing to a part sketch.

The Layers argument can contain either a string or an array of strings, where the strings are the layer names with which to work. You can also specify the argument as empty, which indicates all layers. If this method is not used, the default behavior is to import all layers with the same visibility as they have in the DXF/DWG file.

The layer visibility is the same for all sheets that are imported; you cannot specify the layer visibility on a sheet-by-sheet basis.

Hidden layers are always imported to the drawing sheet.

You should first specify the behavior that applies to all layers, using an empty VARIANT, because this overrides any information you have previously entered for specific layers. Then, you should use this method with layer names in the VARIANT, to override that default behavior on a layer-by-layer basis.

Visual Basic for Applications (VBA) Example

To import all layers with the same visibility as in the DXF/DWG file (this is the default behavior):

```
boolstatus = ImportDxfDwgData.SetImportLayerVisibility (emptyVariant,  
swImportDxfDwg_LayerMaintain)
```

To import layer "A" hidden and the remaining layers visible:

```
boolstatus = ImportDxfDwgData.SetImportLayerVisibility (emptyVariant,  
swImportDxfDwg_LayerVisible)
```

```
    layerName = "A"
```

```
    layerVariant = layerName
```

```
boolstatus = ImportDxfDwgData.SetImportLayerVisibility ((layerVariant),  
swImportDxfDwg_LayerHidden)
```

See Also

[IImportDxfDwgData Interface](#)
[IImportDxfDwgData Members](#)
[IImportDxfDwgData::GetImportLayerToSheetFormat Method](#)
[IImportDxfDwgData::GetImportLayerVisibility Method](#)
[IImportDxfDwgData::SetImportLayerToSheetFormat Method](#)
[IImportDxfDwgData::ImportMethod Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetMergePoints Method (IImportDxfDwgData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportDxfDwgData Interface](#) : SetMergePoints Method (IImportDxfDwgData)

Sets whether near-identical points within the specified distance are merged in the part sketch after entities are imported.

.NET Syntax

Visual Basic (Declaration)

```
Function SetMergePoints(  
    ByVal Sheet As System.String, _  
    ByVal Merge As System.Boolean, _  
    ByVal Distance As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IImportDxfDwgData  
Dim Sheet As System.String  
Dim Merge As System.Boolean  
Dim Distance As System.Double  
Dim value As System.Boolean  
  
value = instance.SetMergePoints(Sheet, Merge, Distance)
```

C#

```
System.bool SetMergePoints(  
    System.string Sheet,  
    System.bool Merge,  
    System.double Distance  
)
```

C++/CLI

```
System.bool SetMergePoints(  
& System.String^ Sheet,  
& System.bool Merge,  
& System.double Distance  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sheet
Sheet (layout) name of the input file or an empty string for all sheets
Merge
True to merge near-identical points, false to not
Distance
Distance to determine whether two points should be merged

Return Value

True if near-identical points within the specified distance are merged, false if not

Visual Basic for Applications (VBA) Syntax

See [ImportDxfDwgData::SetMergePoints](#).

Example

[Import DXF file into Part Sketch \(VBA\)](#)

Remarks

This property only supports importing to a part sketch; it does not support importing to a drawing.

By default, points within 0.001mm are merged.

See Also

[IImportDxfDwgData Interface](#)
[IImportDxfDwgData Members](#)
[IImportDxfDwgData::GetMergePoints Method](#)
[IImportDxfDwgData::GetMergeDistance Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetPaperSize Method (IImportDxfDwgData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportDxfDwgData Interface](#) : SetPaperSize Method (IImportDxfDwgData)

Sets the size of the paper in the drawing.

.NET Syntax

Visual Basic (Declaration)

```
Function SetPaperSize( _  
    ByVal Sheet As System.String, _  
    ByVal Size As System.Integer, _  
    ByVal Height As System.Double, _  
    ByVal Width As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IImportDxfDwgData  
Dim Sheet As System.String  
Dim Size As System.Integer
```



```
Dim Height As System.Double
Dim Width As System.Double
Dim value As System.Boolean
```

```
value = instance.SetPaperSize(Sheet, Size, Height, Width)
```

C#

```
System.bool SetPaperSize(
    System.string Sheet,
    System.int Size,
    System.double Height,
    System.double Width
)
```

C++/CLI

```
System.bool SetPaperSize(
    & System.String^ Sheet,
    & System.int Size,
    & System.double Height,
    & System.double Width
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sheet

Sheet (layout) name of the input file or an empty string for all sheets

Size

Size as defined in [swDwgPaperSizes_e](#)

Height

If Size is swDwgPapersUserDefined, then the height of the paper in meters

Width

If Size is swDwgPapersUserDefined, then the width of the paper in meters

Return Value

True if paper size is set, false if not

Visual Basic for Applications (VBA) Syntax

See [ImportDxfDwgData::SetPaperSize](#).

Example

[Import DXF File into Drawing \(VBA\)](#)

[Insert and Position DXF/DWG File in Drawing \(VBA\)](#)

[Insert and Position DXF/DWG File in Drawing \(VB.NET\)](#)

[Insert and Position DXF/DWG File in Drawing \(C#\)](#)

Remarks

This method only supports importing to a drawing; it does not support importing to a part sketch.

See Also

[IImportDxfDwgData Interface](#)

[IImportDxfDwgData Members](#)

[IImportDxfDwgData::GetPaperSize Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetPosition Method (IImportDxfDwgData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportDxfDwgData Interface](#) : SetPosition Method (IImportDxfDwgData)

Sets the position of the entities created in the drawing.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function SetPosition( _  
    ByVal Sheet As System.String, _  
    ByVal Positioning As System.Integer, _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IImportDxfDwgData  
Dim Sheet As System.String  
Dim Positioning As System.Integer  
Dim X As System.Double  
Dim Y As System.Double  
Dim value As System.Boolean  
  
value = instance.SetPosition(Sheet, Positioning, X, Y)
```

C#

```
System.bool SetPosition(  
    System.string Sheet,  
    System.int Positioning,  
    System.double X,  
    System.double Y  
)
```

C++/CLI

```
System.bool SetPosition(  
& System.String^ Sheet,  
& System.int Positioning,  
& System.double X,  
& System.double Y  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sheet

Sheet (layout) name of the input file or an empty string for all sheets

Positioning

Position as defined in [swDwgImportEntitiesPositioning_e](#)

X

X coordinate of the origin of the imported drawing

Y

Y coordinate of the origin of the imported drawing

Return Value

True if the position is set, false if not

Visual Basic for Applications (VBA) Syntax

See [ImportDxfDwgData::SetPosition](#).

Example

[Insert and Position DXF/DWG File in Drawing \(C#\)](#)
[Insert and Position DXF/DWG File in Drawing \(VB.NET\)](#)
[Insert and Position DXF/DWG File in Drawing \(VBA\)](#)

Remarks

This method only supports importing to a drawing; it does not support importing to a part sketch.

See Also

[IImportDxfDwgData Interface](#)
[IImportDxfDwgData Members](#)
[IImportDxfDwgData::GetPosition Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetSheetScale Method (IImportDxfDwgData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportDxfDwgData Interface](#) : SetSheetScale Method (IImportDxfDwgData)

Sets the sheet scale for the drawing.

.NET Syntax

Visual Basic (Declaration)

```
Function SetSheetScale( _  
    ByVal Sheet As System.String, _  
    ByVal Numerator As System.Double, _  
    ByVal Denominator As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IImportDxfDwgData  
Dim Sheet As System.String  
Dim Numerator As System.Double  
Dim Denominator As System.Double  
Dim value As System.Boolean
```

```
value = instance.SetSheetScale(Sheet, Numerator, Denominator)
```

C#

```
System.bool SetSheetScale(  
    System.string Sheet,  
    System.double Numerator,  
    System.double Denominator  
)
```

C++/CLI

```
System.bool SetSheetScale(  
& System.String^ Sheet,  
& System.double Numerator,  
& System.double Denominator  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sheet

Sheet (layout) name of the input file or an empty string for all sheets

Numerator

Numerator of the scale

Denominator

Denominator of the scale

Return Value

True if the sheet scale is set, false if not

Visual Basic for Applications (VBA) Syntax

See [IImportDxfDwgData::SetSheetScale](#).

Example

[Import DXF File into Drawing \(VBA\)](#)
[Insert and Position DXF/DWG File in Drawing \(VBA\)](#)
[Insert and Position DXF/DWG File in Drawing \(VB.NET\)](#)
[Insert and Position DXF/DWG File in Drawing \(C#\)](#)

Remarks

This method only supports importing to a drawing; it does not support importing to a part sketch.

See Also

[IImportDxfDwgData Interface](#)
[IImportDxfDwgData Members](#)
[IImportDxfDwgData.GetSheetScale Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SheetName Property (IImportDxfDwgData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportDxfDwgData Interface](#) : SheetName Property (IImportDxfDwgData)

Gets or sets the name of the sheet for the drawing.

.NET Syntax

Visual Basic (Declaration)

```
Property SheetName( _  
    ByVal Sheet As System.String _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IImportDxfDwgData  
Dim Sheet As System.String  
Dim value As System.String  
  
instance.SheetName(Sheet) = value  
  
value = instance.SheetName(Sheet)
```

C#

```
System.string SheetName(  
    System.string Sheet  
) {get; set;}
```

C++/CLI

```
property System.String^ SheetName {  
    System.String^ get(System.String^ Sheet);  
    void set (System.String^ Sheet, System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sheet
Sheet (layout) name of the input file or an empty string for all sheets

Property Value

Name of sheet

Visual Basic for Applications (VBA) Syntax

See [ImportDxfDwgData::SheetName](#).

Example

[Import DXF File into Drawing \(VBA\)](#)

Remarks

This method only supports importing to a drawing; it does not support importing to a part sketch.

See Also

[IImportDxfDwgData Interface](#)
[IImportDxfDwgData Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

IIImportedCurveFeatureData (Type)

IIImportedCurveFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IIImportedCurveFeatureData Interface

Allows access to an imported curve feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IIImportedCurveFeatureData

Visual Basic (Usage)



Dim instance As [IIImportedCurveFeatureData](#)

C#

public interface IIImportedCurveFeatureData

C++/CLI

public interface class IIImportedCurveFeatureData

Visual Basic for Applications (VBA) Syntax

See [ImportedCurveFeatureData](#).

Example

[Get Imported Curve Feature Data \(C#\)](#)
[Get Imported Curve Feature Data \(VB.NET\)](#)
[Get Imported Curve Feature Data \(VBA\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[ImportedCurveFeatureData](#)

See Also

[IIImportedCurveFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IIImportedCurveFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IIImportedCurveFeatureData Interface

For a list of all members of this type, see [IIImportedCurveFeatureData members](#).

Public Methods

Name	Description
 GetCurveCount	Gets the number of curves for this imported curve feature.
 !GetCurves	Gets the curves for this imported curve feature.

 ISetCurves	Sets the curves for this imported curve feature.
 SetBody	Modifies the wire body for this imported curve feature.

[Top](#)

See Also

[IImportedCurveFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IImportedCurveFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)

 SolidWorks.Interop.sldworks Namespace : IImportedCurveFeatureData Interface

The following tables list the members exposed by [IImportedCurveFeatureData](#).

Public Properties

Name	Description
 Curves	Gets or sets the curves for this imported curve feature.

[Top](#)

Public Methods

Name	Description
 GetCurveCount	Gets the number of curves for this imported curve feature.
 IGetCurves	Gets the curves for this imported curve feature.
 ISetCurves	Sets the curves for this imported curve feature.
 SetBody	Modifies the wire body for this imported curve feature.

[Top](#)

See Also

[IImportedCurveFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IImportedCurveFeatureData Interface Properties

[See Also](#)

 SolidWorks.Interop.sldworks Namespace : IImportedCurveFeatureData Interface

For a list of all members of this type, see [IImportedCurveFeatureData members](#).

Public Properties

Name	Description
 Curves	Gets or sets the curves for this imported curve feature.

[Top](#)

See Also

[IImportedCurveFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Curves Property (IImportedCurveFeatureData)

[See Also](#)

 
SolidWorks.Interop.sldworks Namespace > IImportedCurveFeatureData Interface : Curves Property (IImportedCurveFeatureData)

Gets or sets the curves for this imported curve feature.

.NET Syntax

Visual Basic (Declaration)

Property Curves As System.Object

Visual Basic (Usage)



```
Dim instance As IImportedCurveFeatureData
Dim value As System.Object

instance.Curves = value
value = instance.Curves
```

C#

```
System.object Curves {get; set;}
```

C++/CLI

```
property System.Object^ Curves {
    System.Object^ get();
    void set ( &    System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of curves (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ImportedCurveFeatureData::Curves](#).

Remarks

The curve feature is formed in the order of the input curves.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IImportedCurveFeatureData Interface](#)
[IImportedCurveFeatureData Members](#)
[IImportedCurveFeatureData::GetCurveCount Method](#)
[IImportedCurveFeatureData::IGetCurves Method](#)
[IImportedCurveFeatureData::ISetCurves Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetCurveCount Method (IImportedCurveFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportedCurveFeatureData Interface](#) : GetCurveCount Method (IImportedCurveFeatureData)

Gets the number of curves for this imported curve feature.

.NET Syntax

Visual Basic (Declaration)

Function GetCurveCount() As System.Integer

Visual Basic (Usage)



```
Dim instance As IImportedCurveFeatureData  
Dim value As System.Integer  
  
value = instance.GetCurveCount()
```

C#

```
System.int GetCurveCount()
```

C++/CLI

```
System.int GetCurveCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of curves

Visual Basic for Applications (VBA) Syntax

See [ImportedCurveFeatureData::GetCurveCount](#).

Example

[Get Imported Curve Feature Data \(C#\)](#)
[Get Imported Curve Feature Data \(VB.NET\)](#)
[Get Imported Curve Feature Data \(VBA\)](#)

Remarks

Call this method before calling [IImportedCurveFeatureData::IGetCurves](#).

See Also

[IImportedCurveFeatureData Interface](#)
[IImportedCurveFeatureData Members](#)
[IImportedCurveFeatureData::ISetCurves Method](#)
[IImportedCurveFeatureData::Curves Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetCurves Method (IImportedCurveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportedCurveFeatureData Interface](#) : IGetCurves Method (IImportedCurveFeatureData)

Gets the curves for this imported curve feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetCurves( _  
    ByVal Count As System.Integer _  
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As IImportedCurveFeatureData  
Dim Count As System.Integer  
Dim value As System.Object  
  
value = instance.IGetCurves(Count)
```

C#



```
System.object IGetCurves(  
    System.int Count  
)
```

C++/CLI

```
System.Object^ IGetCurves(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of curves

Return Value

- in-process, unmanaged C++: Pointer to an array of curves of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IImportedCurveFeatureData::GetCurveCount](#) before calling this method.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IImportedCurveFeatureData Interface](#)
[IImportedCurveFeatureData Members](#)
[IImportedCurveFeatureData::ISetCurves Method](#)
[IImportedCurveFeatureData::Curves Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetCurves Method (IImportedCurveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportedCurveFeatureData Interface](#) : ISetCurves Method (IImportedCurveFeatureData)

Sets the curves for this imported curve feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetCurves( _  
    ByVal Count As System.Integer, _  
    ByRef DispArr As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IImportedCurveFeatureData  
Dim Count As System.Integer  
Dim DispArr As System.Object
```

```
instance.ISetCurves(Count, DispArr)
```

C#

```
void ISetCurves(  
    System.int Count,
```

```
ref System.object DispArr
)
```

C++/CLI

```
void ISetCurves(
& System.int Count,
& System.Object^% DispArr
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of curves

DispArr

- in-process, unmanaged C++: Pointer to an array of curves of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IImportedCurveFeatureData Interface](#)
[IImportedCurveFeatureData Members](#)
[IImportedCurveFeatureData::GetCurveCount Method](#)
[IImportedCurveFeatureData::IGetCurves Method](#)
[IImportedCurveFeatureData::Curves Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetBody Method (IImportedCurveFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportedCurveFeatureData Interface](#) : SetBody Method (IImportedCurveFeatureData)

Modifies the wire body for this imported curve feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetBody( _
    ByVal DispBody As Body2 _
)
```

Visual Basic (Usage)



```
Dim instance As IImportedCurveFeatureData
Dim DispBody As Body2

instance.SetBody(DispBody)
```

C#

```
void SetBody(
    Body2 DispBody
)
```

C++/CLI

```
void SetBody(  
& Body2^ DispBody  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DispBody
Wire [body](#)

Visual Basic for Applications (VBA) Syntax

See [ImportedCurveFeatureData::SetBody](#).

Remarks

Wire bodies contain wires, loops, coedges, edges, and vertices. Wires typically represent profiles, construction lines, and center lines of swept shapes. Wires can also represent wire frames that, when surfaced, form shells.

The following methods create wire bodies:

- [IEdge::CreateWireBody](#)
- [ICurve::CreateWireBody](#)
- [IModeler::CreateWireBody](#)

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ImportedCurveFeatureData Interface](#)
[ImportedCurveFeatureData Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

IImportIgesData (Type)

IImportIgesData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IImportIgesData Interface

Allows you to specify levels and values when importing IGES data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IImportIgesData
```

Visual Basic (Usage)

```
Dim instance As IImportIgesData
```

C#

```
public interface IImportIgesData
```

C++/CLI

```
public interface class IImportIgesData
```

Visual Basic for Applications (VBA) Syntax

See [ImportIgesData](#).

Example

[Specify IGES Levels and Values, Then Import IGES File \(C#\)](#)
[Specify IGES Levels and Values, Then Import IGES File \(VB.NET\)](#)
[Specify IGES Levels and Values, Then Import IGES File \(VBA\)](#)

Remarks

If user preference swIGESImportShowLevel is...	Then the IGES translator...
True	Displays the IGES-In Surfaces, Curves, and Levels dialog to the user where the user can specify levels and values.
false and you retrieved IImportIgesData	Does not display the IGES-In Surfaces, Curves, and Levels dialog to the user and allows you to specify the levels and values.
false and you did not retrieve IImportIgesData	Does not display the IGES-In Surfaces, Curves, and Levels dialog to the user and uses the default values.

To specify levels and values when importing IGES data:

1. Set the user preference [swIGESImportShowLevel](#) to false.
2. Use [ISldWorks::GetImportFileData](#) to get IImportIgesData.
3. Use the IImportIgesData functions to specify the levels and values.
4. Use [ISldworks::LoadFile4](#) to load the file.

Accessors

[ISldWorks::GetImportFileData](#)

Access Diagram

[ImportIgesData](#)

See Also

[ImportIgesData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ImportDxfDwgData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ImportIgesData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ImportIgesData Interface

The following tables list the members exposed by [ImportIgesData](#).

Public Properties

Name	Description
 CurvesAsSketches	Gets or sets whether the curves are imported as sketches or reference curve features.
 IncludeAllLevels	Gets whether all levels (layers) are imported.
 IncludeCurves	Gets or sets whether or not to import curves.
 IncludeOnlyLevels	Gets the levels (layers) to import.
 IncludeSurfaces	Gets or sets whether to import surfaces.
 ProcessByLevel	Gets or sets whether to process surfaces together.

[Top](#)

Public Methods

Name	Description
 SetLevels	Sets the levels-related information for importing and IGES file.

[Top](#)

See Also

[ImportIgesData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ImportDxfDwgData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ImportIgesData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ImportIgesData Interface

For a list of all members of this type, see [ImportIgesData members](#).

Public Methods

Name	Description
 SetLevels	Sets the levels-related information for importing and IGES file.

[Top](#)

See Also

[ImportIgesData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ImportDxfDwgData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ImportIgesData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IImportIgesData Interface

For a list of all members of this type, see [IImportIgesData members](#).

Public Properties

Name	Description
 CurvesAsSketches	Gets or sets whether the curves are imported as sketches or reference curve features.
 IncludeAllLevels	Gets whether all levels (layers) are imported.
 IncludeCurves	Gets or sets whether or not to import curves.
 IncludeOnlyLevels	Gets the levels (layers) to import.
 IncludeSurfaces	Gets or sets whether to import surfaces.
 ProcessByLevel	Gets or sets whether to process surfaces together.

[Top](#)

See Also

[IImportIgesData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IImportDxfDwgData Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CurvesAsSketches Property (IImportIgesData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportIgesData Interface](#) : CurvesAsSketches Property (IImportIgesData)

Gets or sets whether the curves are imported as sketches or reference curve features.

.NET Syntax

Visual Basic (Declaration)

Property CurvesAsSketches As System.Boolean

Visual Basic (Usage)



```
Dim instance As IImportIgesData
Dim value As System.Boolean

instance.CurvesAsSketches = value

value = instance.CurvesAsSketches
```

C#

```
System.bool CurvesAsSketches {get; set;}
```

C++/CLI

```
property System.bool CurvesAsSketches {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import curves as sketches, false to import curves as reference curve features

Visual Basic for Applications (VBA) Syntax

See [IImportIgesData::CurvesAsSketches](#).

Example

[Specify IGES Levels and Values, Then Import IGES File \(C#\)](#)
[Specify IGES Levels and Values, Then Import IGES File \(VB.NET\)](#)
[Specify IGES Levels and Values, Then Import IGES File \(VBA\)](#)

Remarks

[IImportIgesData::IncludeCurves](#) must be set to true for this property to have an effect.

See Also

[IImportIgesData Interface](#)
[IImportIgesData Members](#)

Availability

SOLIDWORKS 2005 SP3, Revision Number 13.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

IncludeAllLevels Property (IImportIgesData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportIgesData Interface](#) : IncludeAllLevels Property (IImportIgesData)

Gets whether all levels (layers) are imported.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property IncludeAllLevels As System.Boolean

Visual Basic (Usage)



```
Dim instance As IImportIgesData
Dim value As System.Boolean

value = instance.IncludeAllLevels
```

C#

```
System.bool IncludeAllLevels {get;}
```

C++/CLI

```
property System.bool IncludeAllLevels {
    System.bool get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import all levels, false to not

Visual Basic for Applications (VBA) Syntax

See [IImportIgesData::IncludeAllLevels](#).

Remarks

If this property is false, then you can use [IImportIgesData::IncludeOnlyLevels](#) to find out which levels will be processed.

See Also

[IImportIgesData Interface](#)
[IImportIgesData Members](#)
[IImportIgesData::ProcessByLevel Property](#)
[IImportIgesData::SetLevels Method](#)

Availability

SOLIDWORKS 2005 SP3, Revision Number 13.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

IncludeCurves Property (IImportIgesData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportIgesData Interface](#) : IncludeCurves Property (IImportIgesData)

Gets or sets whether or not to import curves.

.NET Syntax

Visual Basic (Declaration)

Property IncludeCurves As System.Boolean

Visual Basic (Usage)



```
Dim instance As IImportIgesData
Dim value As System.Boolean
```

```
instance.IncludeCurves = value
```

```
value = instance.IncludeCurves
```

C#

```
System.bool IncludeCurves {get; set;}
```

C++/CLI

```
property System.bool IncludeCurves {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import curves, false to not

Visual Basic for Applications (VBA) Syntax

See [IImportIgesData::IncludeCurves](#).

Example

[Specify IGES Levels and Values, Then Import IGES File \(C#\)](#)
[Specify IGES Levels and Values, Then Import IGES File \(VB.NET\)](#)
[Specify IGES Levels and Values, Then Import IGES File \(VBA\)](#)

Remarks

If this property is True, then you can use [IImportIgesData::CurvesAsSketches](#) to specify whether to import curves as sketches or as reference curve features.

Use [IImportIgesData::IncludeSurfaces](#) to indicate whether or not to import surfaces.

See Also

[IImportIgesData Interface](#)
[IImportIgesData Members](#)

Availability

SOLIDWORKS 2005 SP3, Revision Number 13.3

IncludeOnlyLevels Property (IImportIgesData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportIgesData Interface](#) : IncludeOnlyLevels Property (IImportIgesData)

Gets the levels (layers) to import.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property IncludeOnlyLevels As System.Object

Visual Basic (Usage)



```
Dim instance As IImportIgesData  
Dim value As System.Object  
  
value = instance.IncludeOnlyLevels
```

C#

```
System.Object IncludeOnlyLevels {get;}
```

C++/CLI

```
property System.Object^ IncludeOnlyLevels {  
    System.Object^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of longs or integers (see [Long vs. Integer](#)) indicating the levels to import

Visual Basic for Applications (VBA) Syntax

See [IImportIgesData::IncludeOnlyLevels](#).

Remarks

[IImportIgesData::IncludeAllLevels](#) must be false to use this property.

See Also

[IImportIgesData Interface](#)
[IImportIgesData Members](#)
[IImportIgesData::ProcessByLevel Property](#)
[IImportIgesData::SetLevels Method](#)

Availability

SOLIDWORKS 2005 SP3, Revision Number 13.3

IncludeSurfaces Property (IImportIgesData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportIgesData Interface](#) : IncludeSurfaces Property (IImportIgesData)

Gets or sets whether to import surfaces.

.NET Syntax

Visual Basic (Declaration)

Property IncludeSurfaces As System.Boolean

Visual Basic (Usage)

```
Dim instance As IImportIgesData  
Dim value As System.Boolean  
  
instance.IncludeSurfaces = value  
  
value = instance.IncludeSurfaces
```

C#

```
System.bool IncludeSurfaces {get; set;}
```

C++/CLI

```
property System.bool IncludeSurfaces {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import surfaces, false to not

Visual Basic for Applications (VBA) Syntax

See [ImportIgesData.IncludeSurfaces](#).

Example

[Specify IGES Levels and Values, Then Import IGES File \(C#\)](#)
[Specify IGES Levels and Values, Then Import IGES File \(VB.NET\)](#)
[Specify IGES Levels and Values, Then Import IGES File \(VBA\)](#)

Remarks

To import curves, use [IImportIgesData.IncludeCurves](#) and [IImportIgesData.CurvesAsSketches](#).

See Also

[IImportIgesData Interface](#)
[IImportIgesData Members](#)
[IImportIgesData.ProcessByLevel Property](#)

Availability

SOLIDWORKS 2005 SP3, Revision Number 13.3

SOLIDWORKS API Help

[Send comments](#) on this topic.

ProcessByLevel Property (IImportIgesData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportIgesData Interface](#) : ProcessByLevel Property (IImportIgesData)

Gets or sets whether to process surfaces together.

.NET Syntax

Visual Basic (Declaration)

```
Property ProcessByLevel As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IImportIgesData  
Dim value As System.Boolean
```

```
instance.ProcessByLevel = value  
value = instance.ProcessByLevel
```

C#

```
System.bool ProcessByLevel {get; set;}
```

C++/CLI

```
property System.bool ProcessByLevel {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to process surfaces on the same IGES level together in their own folder in the FeatureManager design tree, false to process surfaces to level 0 and not put them in their own folder in the FeatureManager design tree

Visual Basic for Applications (VBA) Syntax

See [ImportIgesData::ProcessByLevel](#).

Example

[Specify IGES Levels and Values, Then Import IGES File \(C#\)](#)
[Specify IGES Levels and Values, Then Import IGES File \(VB.NET\)](#)
[Specify IGES Levels and Values, Then Import IGES File \(VBA\)](#)

See Also

[IImportIgesData Interface](#)
[IImportIgesData Members](#)
[IImportIgesData::SetLevels Method](#)
[IImportIgesData::IncludeAllLevels Property](#)
[IImportIgesData::IncludeOnlyLevels Property](#)
[IImportIgesData::IncludeSurfaces Property](#)

Availability

SOLIDWORKS 2005 SP3, Revision Number 13.3

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetLevels Method (IImportIgesData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportIgesData Interface](#) : SetLevels Method (IImportIgesData)

Sets the levels-related information for importing and IGES file.

.NET Syntax

Visual Basic (Declaration)

```
Function SetLevels( _  
    ByVal All As System.Boolean, _  
    ByVal Only As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IImportIgesData  
Dim All As System.Boolean  
Dim Only As System.Object  
Dim value As System.Boolean  
  
value = instance.SetLevels(All, Only)
```

C#

```
System.bool SetLevels(  
    System.bool All,  
    System.object Only  
)
```

C++/CLI

```
System.bool SetLevels(  
& System.bool All,  
& System.Object^ Only  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

All

True to process all IGES levels, false to not

Only

If All is false, then specify either a long or integer, or an array of longs or integers, indicating the levels to process

Return Value

True if the levels-related information is set, false if not

Visual Basic for Applications (VBA) Syntax

See [ImportIgesData::SetLevels](#).

Example

[Specify IGES Levels and Values, Then Import IGES File \(C#\)](#)

[Specify IGES Levels and Values, Then Import IGES File \(VB.NET\)](#)

[Specify IGES Levels and Values, Then Import IGES File \(VBA\)](#)

See Also

[IImportIgesData Interface](#)

[IImportIgesData Members](#)

[IImportIgesData::IncludeAllLevels Property](#)

[IImportIgesData::IncludeOnlyLevels Property](#)

[IImportIgesData::ProcessByLevel Property](#)

Availability

SOLIDWORKS 2005 SP3, Revision Number 13.3

IImportStepData (Type)

IImportStepData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IImportStepData Interface

Allows you to specify values when importing STEP data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IImportStepData
```

Visual Basic (Usage)



```
Dim instance As IImportStepData
```

C#

```
public interface IImportStepData
```

C++/CLI

```
public interface class IImportStepData
```

Visual Basic for Applications (VBA) Syntax

See [ImportStepData](#).

Example

[Import STEP File \(C#\)](#)
[Import STEP File \(VB.NET\)](#)
[Import STEP File \(VBA\)](#)

Remarks

- a. Use [ISldWorks::GetImportFileData](#) to get an IImportStepData interface pointer.
- b. Use [IImportStepData::MapConfigurationData](#) to specify how to map configuration data.
- c. Use [ISldWorks::LoadFile4](#) to load the file.

When IImportStepData is initialized, the current default environment setting, [swImportStepConfigData](#), initializes IImportStepData::MapConfigurationData unless you explicitly set IImportStepData::MapConfigurationData. Then the IImportStepData::MapConfigurationData setting overrides swImportStepConfigData for this import only.

Accessors

[ISldWorks::GetImportFileData](#)

Access Diagram

[ImportStepData](#)

See Also

[IImportStepData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IImportStepData Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IImportStepData Interface

The following tables list the members exposed by [IImportStepData](#).

Public Properties

Name	Description
 MapConfigurationData	Gets or sets whether to import the STEP file configuration data plus geometric data or geometric data only.

[Top](#)

See Also

[IImportStepData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IImportStepData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IImportStepData Interface

For a list of all members of this type, see [IImportStepData members](#).

Public Properties

Name	Description
 MapConfigurationData	Gets or sets whether to import the STEP file configuration data plus geometric data or geometric data only.

[Top](#)

See Also

[IImportStepData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

MapConfigurationData Property (IImportStepData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IImportStepData Interface](#) : MapConfigurationData Property (IImportStepData)

Gets or sets whether to import the STEP file configuration data plus geometric data or geometric data only.

.NET Syntax

Visual Basic (Declaration)

```
Property MapConfigurationData As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IImportStepData  
Dim value As System.Boolean  
  
instance.MapConfigurationData = value  
  
value = instance.MapConfigurationData
```

C#

```
System.bool MapConfigurationData {get; set;}
```

C++/CLI

```
property System.bool MapConfigurationData {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to import the STEP file configuration data plus geometric data, false to import geometric data only

Visual Basic for Applications (VBA) Syntax

See [ImportStepData::MapConfigurationData](#).

Example

[Import STEP File \(C#\)](#)
[Import STEP File \(VB.NET\)](#)
[Import STEP File \(VBA\)](#)

Remarks

If this property is not set, then the current default environment setting, [swImportStepConfigData](#), is used. If this property is set, its setting overrides the swImportStepConfigData setting for this import only.

See Also

[IImportStepData Interface](#)
[IImportStepData Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0