

# SOLIDWORKS API (.NET VBA C#) — Reference

## (138/337): InterferenceDetectionMgr-IntersectFeatureData

SOLIDWORKS API Documentation (converted from CHM)

# IInterferenceDetectionMgr (Type)

## IInterferenceDetectionMgr Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IInterferenceDetectionMgr Interface

Allows you to run interference detection on an assembly to determine whether components interfere with each other.

**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

### .NET Syntax

Visual Basic (Declaration)

```
Public Interface IInterferenceDetectionMgr
```

Visual Basic (Usage)



```
Dim instance As IInterferenceDetectionMgr
```

C#

```
public interface IInterferenceDetectionMgr
```

C++/CLI

```
public interface class IInterferenceDetectionMgr
```

### Visual Basic for Applications (VBA) Syntax

See [InterferenceDetectionMgr](#).

### Example

[Run Interference Detection \(C#\)](#)  
[Run Interference Detection \(VB.NET\)](#)  
[Run Interference Detection \(VBA\)](#)  
[Detect Interferences Using a Transform \(C#\)](#)  
[Detect Interferences Using a Transform \(VB.NET\)](#)  
[Detect Interferences Using a Transform \(VBA\)](#)  
[Set Components and Transforms for Interference Detection \(C#\)](#)  
[Set Components and Transforms for Interference Detection \(VB.NET\)](#)  
[Set Components and Transforms for Interference Detection \(VBA\)](#)

### Remarks

See the SOLIDWORKS Help for details about interference detection.

Use [ICollisionDetectionManager](#) to perform high-efficiency collision detection among groups of components transformed to a variety of positions

### Accessors

[IAssemblyDoc::InterferenceDetectionManager](#)

### Access Diagram

[InterferenceDetectionMgr](#)

### See Also

[IInterferenceDetectionMgr Members](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IInterference Interface](#)  
[IModeler::CheckInterferenceBetweenTwoBodies Method \(\)](#)

## IInterferenceDetectionMgr Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IInterferenceDetectionMgr Interface

For a list of all members of this type, see [IInterferenceDetectionMgr members](#).

## Public Methods

| Name                                                                                                                                      | Description                                                                                               |
|-------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|
|  <a href="#">Done</a>                                    | Stops the interference detection.                                                                         |
|  <a href="#">ExportResults</a>                           | Saves interference detection results to a file.                                                           |
|  <a href="#">GetComponentsAndTransforms</a>              | Gets the interfering components and their transforms.                                                     |
|  <a href="#">GetComponentsTransformInterference</a>      | Calculates and gets the interfering components for the specified components and math transform.           |
|  <a href="#">GetComponentsTransformInterferenceCount</a> | Calculates and gets the number of interfering components for the specified components and math transform. |
|  <a href="#">GetInterferenceComponentCount</a>           | Calculates and gets the number of interfering components.                                                 |
|  <a href="#">GetInterferenceComponents</a>               | Calculates and gets the interfering components.                                                           |
|  <a href="#">GetInterferenceCount</a>                    | Calculates and gets the number of interferences.                                                          |
|  <a href="#">GetInterferences</a>                        | Calculates and gets the interferences.                                                                    |
|  <a href="#">IGetComponentsTransformInterference</a>     | Calculates and gets the interfering components for the specified components and math transform.           |
|  <a href="#">IGetInterferenceComponents</a>              | Calculates and gets the interfering components.                                                           |
|  <a href="#">IGetInterferences</a>                       | Calculates and gets the interferences.                                                                    |
|  <a href="#">SetComponentsAndTransforms</a>              | Sets the interfering components and their transforms.                                                     |

[Top](#)

## See Also

[IInterferenceDetectionMgr Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[Interference Interface](#)  
[IModeler::CheckInterferenceBetweenTwoBodies Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IInterferenceDetectionMgr Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IInterferenceDetectionMgr Interface

The following tables list the members exposed by [IInterferenceDetectionMgr](#).

## Public Properties

| Name                                                                                                                                  | Description                                                                                                                                  |
|---------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
|  <a href="#">CreateFastenersFolder</a>             | Gets or sets whether to create the <b>Fasteners</b> folders to segregate interferences involving fasteners.                                  |
|  <a href="#">IgnoreHiddenBodies</a>                | Gets or sets whether to ignore hidden bodies during interference detection.                                                                  |
|  <a href="#">IncludeMultibodyPartInterferences</a> | Gets or sets whether to report interferences between bodies within multibody parts.                                                          |
|  <a href="#">MakeInterferingPartsTransparent</a>   | Gets or sets whether to display the components of the selected interference in transparent mode.                                             |
|  <a href="#">NonInterferingComponentDisplay</a>    | Gets or sets the mode to display non-interfering components.                                                                                 |
|  <a href="#">ShowIgnoredInterferences</a>          | Gets or sets whether to show ignored interferences.                                                                                          |
|  <a href="#">TreatCoincidenceAsInterference</a>    | Gets or sets whether to treat coincident entities as interference.                                                                           |
|  <a href="#">TreatSubAssembliesAsComponents</a>    | Gets or sets whether to treat subassemblies as single components so that interferences between a sub-assembly's components are not reported. |
|  <a href="#">UseTransform</a>                      | Gets or sets whether to use transforms in interference detection.                                                                            |

[Top](#)

## Public Methods

| Name | Description |
|------|-------------|
|------|-------------|

|                                                                                                                                           |                                                                                                           |
|-------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|
|  <a href="#">Done</a>                                    | Stops the interference detection.                                                                         |
|  <a href="#">ExportResults</a>                           | Saves interference detection results to a file.                                                           |
|  <a href="#">GetComponentsAndTransforms</a>              | Gets the interfering components and their transforms.                                                     |
|  <a href="#">GetComponentsTransformInterference</a>      | Calculates and gets the interfering components for the specified components and math transform.           |
|  <a href="#">GetComponentsTransformInterferenceCount</a> | Calculates and gets the number of interfering components for the specified components and math transform. |
|  <a href="#">GetInterferenceComponentCount</a>           | Calculates and gets the number of interfering components.                                                 |
|  <a href="#">GetInterferenceComponents</a>               | Calculates and gets the interfering components.                                                           |
|  <a href="#">GetInterferenceCount</a>                    | Calculates and gets the number of interferences.                                                          |
|  <a href="#">GetInterferences</a>                        | Calculates and gets the interferences.                                                                    |
|  <a href="#">IGetComponentsTransformInterference</a>     | Calculates and gets the interfering components for the specified components and math transform.           |
|  <a href="#">IGetInterferenceComponents</a>              | Calculates and gets the interfering components.                                                           |
|  <a href="#">IGetInterferences</a>                       | Calculates and gets the interferences.                                                                    |
|  <a href="#">SetComponentsAndTransforms</a>              | Sets the interfering components and their transforms.                                                     |

[Top](#)

## See Also

[InterferenceDetectionMgr Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[Interference Interface](#)  
[IModeler::CheckInterferenceBetweenTwoBodies Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## InterferenceDetectionMgr Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : [InterferenceDetectionMgr Interface](#)

For a list of all members of this type, see [InterferenceDetectionMgr members](#).

## Public Properties

| Name                                                                                                                                  | Description                                                                                                                                  |
|---------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
|  <a href="#">CreateFastenersFolder</a>             | Gets or sets whether to create the <b>Fasteners</b> folders to segregate interferences involving fasteners.                                  |
|  <a href="#">IgnoreHiddenBodies</a>                | Gets or sets whether to ignore hidden bodies during interference detection.                                                                  |
|  <a href="#">IncludeMultibodyPartInterferences</a> | Gets or sets whether to report interferences between bodies within multibody parts.                                                          |
|  <a href="#">MakeInterferingPartsTransparent</a>   | Gets or sets whether to display the components of the selected interference in transparent mode.                                             |
|  <a href="#">NonInterferingComponentDisplay</a>    | Gets or sets the mode to display non-interfering components.                                                                                 |
|  <a href="#">ShowIgnoredInterferences</a>          | Gets or sets whether to show ignored interferences.                                                                                          |
|  <a href="#">TreatCoincidenceAsInterference</a>    | Gets or sets whether to treat coincident entities as interference.                                                                           |
|  <a href="#">TreatSubAssembliesAsComponents</a>    | Gets or sets whether to treat subassemblies as single components so that interferences between a sub-assembly's components are not reported. |
|  <a href="#">UseTransform</a>                      | Gets or sets whether to use transforms in interference detection.                                                                            |

[Top](#)

## See Also

[InterferenceDetectionMgr Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[Interference Interface](#)  
[IModeler::CheckInterferenceBetweenTwoBodies Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## CreateFastenersFolder Property (IInterferenceDetectionMgr)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [InterferenceDetectionMgr Interface](#) : [CreateFastenersFolder Property \(IInterferenceDetectionMgr\)](#)

Gets or sets whether to create the **Fasteners** folders to segregate interferences involving fasteners.

## .NET Syntax

### Visual Basic (Declaration)

Property CreateFastenersFolder As System.Boolean

### Visual Basic (Usage)



```
Dim instance As IInterferenceDetectionMgr  
Dim value As System.Boolean
```

```
instance.CreateFastenersFolder = value
```

```
value = instance.CreateFastenersFolder
```

### C#

```
System.bool CreateFastenersFolder {get; set;}
```

### C++/CLI

```
property System.bool CreateFastenersFolder {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True to create fasteners folder, false to not

## Visual Basic for Applications (VBA) Syntax

See [InterferenceDetectionMgr::CreateFastenersFolder](#).

## Example

[Run Interference Detection \(C#\)](#)  
[Run Interference Detection \(VB.NET\)](#)  
[Run Interference Detection \(VBA\)](#)

## Remarks

Currently, the value set for this property:

- exists only while the InterferenceDetectionMgr object is in scope; i.e., setting this property is temporary.
- does not persist across SOLIDWORKS Design sessions.
- does not persist into the next invocation of interference detection in the user interface.

## See Also

[IInterferenceDetectionMgr Interface](#)  
[InterferenceDetectionMgr Members](#)  
[Interference::IsFastener Property](#)

## Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## Done Method (IInterferenceDetectionMgr)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IInterferenceDetectionMgr Interface](#) : Done Method (IInterferenceDetectionMgr)

Stops the interference detection.

## .NET Syntax

### Visual Basic (Declaration)

```
Sub Done()
```

Visual Basic (Usage)



```
Dim instance As IInterferenceDetectionMgr  
  
instance.Done()
```

C#

```
void Done()
```

C++/CLI

```
void Done();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Visual Basic for Applications (VBA) Syntax

See [InterferenceDetectionMgr::Done](#).

## Example

[Detect Interferences Using a Transform \(C#\)](#)  
[Detect Interferences Using a Transform \(VB.NET\)](#)  
[Detect Interferences Using a Transform \(VBA\)](#)  
[Run Interference Detection \(VBA\)](#)  
[Run Interference Detection \(VB.NET\)](#)  
[Run Interference Detection \(C#\)](#)

## See Also

[IInterferenceDetectionMgr Interface](#)  
[IInterferenceDetectionMgr Members](#)

## Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## ExportResults Method (IInterferenceDetectionMgr)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IInterferenceDetectionMgr Interface](#) : ExportResults Method (IInterferenceDetectionMgr)

Saves interference detection results to a file.

## .NET Syntax

Visual Basic (Declaration)

```
Function ExportResults( _  
    ByVal FileName As System.String, _  
    ByVal IncludeThumbnail As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IInterferenceDetectionMgr  
Dim FileName As System.String  
Dim IncludeThumbnail As System.Boolean  
Dim value As System.Boolean
```

```
value = instance.ExportResults(FileName, IncludeThumbnail)
```

C#

```
System.bool ExportResults(  
    System.string FileName,  
    System.bool IncludeThumbnail  
)
```

C++/CLI

```
System.bool ExportResults(  
& System.String^ FileName,  
& System.bool IncludeThumbnail  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

**Parameters**

*FileName*  
Full path name of the file (\*.xlsx or \*.csv) (see **Remarks**)  
*IncludeThumbnail*  
True to include thumbnail images of interfering components in the Microsoft Excel results, false to not (see **Remarks**)

**Return Value**

True if the export is successful, false if not

 **Visual Basic for Applications (VBA) Syntax**

See [InterferenceDetectionMgr::ExportResults](#).

 **Example**

[Run Interference Detection \(VBA\)](#)  
[Run Interference Detection \(VB.NET\)](#)  
[Run Interference Detection \(C#\)](#)

 **Remarks**

This method corresponds to the **Save Results** button in the Interference Detection PropertyManager.  
Filename is a Microsoft Excel file or a \*.csv file that contains the information presented in the Results list box of the Interference Detection PropertyManager:

| A               | B                    | C                          | D                | E                | F                          | G                          |
|-----------------|----------------------|----------------------------|------------------|------------------|----------------------------|----------------------------|
| Interference ID | Interference Preview | Interference volume (mm^3) | Component 1 name | Component 2 name | Component 1 full reference | Component 2 full reference |
|                 |                      |                            |                  |                  |                            |                            |

IncludeThumbnail is only valid if Filename is a Microsoft Excel file.

If IncludeThumbnail is true, then:

- A thumbnail is created in each row of Column B (Interference Preview).
- Each thumbnail has:
  - 128X128 pixel resolution
  - White background
  - Isometric orientation

 **See Also**

[InterferenceDetectionMgr Interface](#)  
[InterferenceDetectionMgr Members](#)

 **Availability**

SOLIDWORKS 2021 FCS, Revision Number 29

**GetComponentsAndTransforms Method (InterferenceDetectionMgr)**

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [InterferenceDetectionMgr Interface](#) : GetComponentsAndTransforms Method (InterferenceDetectionMgr)

Gets the interfering components and their transforms.

## Visual Basic Syntax

### Visual Basic (Declaration)

```
Function GetComponentAndTransforms( _  
    ByRef ComponentList As System.Object, _  
    ByRef TransformList As System.Object _  
) As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As IInterferenceDetectionMgr  
Dim ComponentList As System.Object  
Dim TransformList As System.Object  
Dim value As System.Boolean  
  
value = instance.GetComponentAndTransforms(ComponentList, TransformList)
```

### C#

```
System.bool GetComponentAndTransforms(  
    out System.object ComponentList,  
    out System.object TransformList  
)
```

### C++/CLI

```
System.bool GetComponentAndTransforms(  
& [Out] System.Object^ ComponentList,  
& [Out] System.Object^ TransformList  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*ComponentList*  
Array of interfering [components](#)  
*TransformList*  
Array of [transforms](#)

#### Return Value

True if successful, false if not

## Visual Basic for Applications (VBA) Syntax

See [InterferenceDetectionMgr::GetComponentAndTransforms](#).

## Example

[Run Interference Detection \(VBA\)](#)  
[Run Interference Detection \(VB.NET\)](#)  
[Run Interference Detection \(C#\)](#)

## See Also

[IInterferenceDetectionMgr Interface](#)  
[IInterferenceDetectionMgr Members](#)  
[IInterferenceDetectionMgr::SetComponentsAndTransforms Method \(\)](#)

## Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetComponentTransformInterference Method (IInterferenceDetectionMgr)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IInterferenceDetectionMgr Interface](#) : GetComponentTransformInterference Method (IInterferenceDetectionMgr)

Calculates and gets the interfering components for the specified components and math transform.

## VB.NET Syntax

### Visual Basic (Declaration)

```
Function GetComponentTransformInterference( _  
    ByVal Component As System.Object, _  
    ByVal Transform As System.Object, _  
    ByRef InterferingComponent As System.Object _  
) As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As IInterferenceDetectionMgr  
Dim Component As System.Object  
Dim Transform As System.Object  
Dim InterferingComponent As System.Object  
Dim value As System.Boolean  
  
value = instance.GetComponentTransformInterference(Component, Transform, InterferingComponent)
```

### C#

```
System.bool GetComponentTransformInterference(  
    System.object Component,  
    System.object Transform,  
    out System.object InterferingComponent  
)
```

### C++/CLI

```
System.bool GetComponentTransformInterference(  
& System.Object^ Component,  
& System.Object^ Transform,  
& [Out] System.Object^ InterferingComponent  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*Component*  
Array of [IComponent2](#)s with which to detect interference  
*Transform*  
[IMathTransform](#)  
*InterferingComponent*  
Array of interfering [IComponent2](#)s

#### Return Value

True if successful, false if not

## Visual Basic for Applications (VBA) Syntax

See [InterferenceDetectionMgr::GetComponentTransformInterference](#).

## Example

[Detect Interferences Using a Transform \(VBA\)](#)  
[Detect Interferences Using a Transform \(VB.NET\)](#)  
[Detect Interferences Using a Transform \(C#\)](#)

## See Also

[IInterferenceDetectionMgr Interface](#)  
[InterferenceDetectionMgr Members](#)  
[InterferenceDetectionMgr::IGetComponentTransformInterference Method](#)  
[InterferenceDetectionMgr::GetInterferenceComponents Method](#)  
[InterferenceDetectionMgr::IGetInterferenceComponents Method](#)  
[InterferenceDetectionMgr::GetInterferences Method](#)  
[InterferenceDetectionMgr::IGetInterferences Method](#)  
[InterferenceDetectionMgr::CreateFastenersFolder Property](#)  
[InterferenceDetectionMgr::IgnoreHiddenBodies Property](#)  
[InterferenceDetectionMgr::IncludeMultibodyPartInterferences Property](#)  
[InterferenceDetectionMgr::MakeInterferingPartsTransparent Property](#)  
[InterferenceDetectionMgr::NonInterferingComponentDisplay Property](#)  
[InterferenceDetectionMgr::ShowIgnoredInterferences Property](#)

[IInterferenceDetectionMgr::TreatCoincidenceAsInterference Property](#)  
[IInterferenceDetectionMgr::TreatSubAssembliesAsComponents Property](#)  
[IInterferenceDetectionMgr::GetComponentsTransformInterferenceCount Method](#)

## Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetComponentsTransformInterferenceCount Method (IInterferenceDetectionMgr)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IInterferenceDetectionMgr Interface](#) : GetComponentsTransformInterferenceCount Method (IInterferenceDetectionMgr)

Calculates and gets the number of interfering components for the specified components and math transform.

## .NET Syntax

### Visual Basic (Declaration)

```
Function GetComponentsTransformInterferenceCount( _  
    ByVal NumOfComponent As System.Integer, _  
    ByRef Component As Component2, _  
    ByRef Transform As MathTransform _  
) As System.Integer
```

### Visual Basic (Usage)



```
Dim instance As IInterferenceDetectionMgr  
Dim NumOfComponent As System.Integer  
Dim Component As Component2  
Dim Transform As MathTransform  
Dim value As System.Integer
```

```
value = instance.GetComponentsTransformInterferenceCount(NumOfComponent, Component, Transform)
```

### C#

```
System.int GetComponentsTransformInterferenceCount(  
    System.int NumOfComponent,  
    ref Component2 Component,  
    ref MathTransform Transform  
)
```

### C++/CLI

```
System.int GetComponentsTransformInterferenceCount(  
& System.int NumOfComponent,  
& Component2^% Component,  
& MathTransform^% Transform  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

*NumOfComponent*  
Number of components in the Component array  
*Component*  
Array of [IComponent2s](#)  
*Transform*  
[IMathTransform](#)

### Return Value

Number of interfering components

## Visual Basic for Applications (VBA) Syntax

See [IInterferenceDetectionMgr::GetComponentsTransformInterferenceCount](#).

## Remarks

Call this method before calling [InterferenceDetectionMgr::GetComponentsTransformInterference](#) to get the size of the array returned by that method.

## See Also

[InterferenceDetectionMgr Interface](#)  
[InterferenceDetectionMgr Members](#)  
[InterferenceDetectionMgr::GetComponentsTransformInterferenceCount Method](#)

## Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## GetInterferenceComponentCount Method (IInterferenceDetectionMgr)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IInterferenceDetectionMgr Interface](#) : GetInterferenceComponentCount Method (IInterferenceDetectionMgr)

Calculates and gets the number of interfering components.

## .NET Syntax

### Visual Basic (Declaration)

```
Function GetInterferenceComponentCount() As System.Integer
```

### Visual Basic (Usage)



```
Dim instance As IInterferenceDetectionMgr  
Dim value As System.Integer  
  
value = instance.GetInterferenceComponentCount()
```

### C#

```
System.int GetInterferenceComponentCount()
```

### C++/CLI

```
System.int GetInterferenceComponentCount();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Return Value

Number of interfering components

## Visual Basic for Applications (VBA) Syntax

See [InterferenceDetectionMgr::GetInterferenceComponentCount](#).

## Remarks

Call this method before calling [InterferenceDetectionMgr::GetInterferenceComponents](#).

## See Also

[InterferenceDetectionMgr Interface](#)  
[InterferenceDetectionMgr Members](#)  
[InterferenceDetectionMgr::GetInterferenceComponents Method](#)  
[InterferenceDetectionMgr::MakeInterferingPartsTransparent Property](#)  
[InterferenceDetectionMgr::NonInterferingComponentDisplay Property](#)  
[InterferenceDetectionMgr::TreatSubAssembliesAsComponents Property](#)  
[Interference::GetComponentCount Method](#)  
[Interference::GetComponents Method](#)  
[Interference::Components Property](#)

## Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

## GetInterferenceComponents Method (IInterferenceDetectionMgr)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IInterferenceDetectionMgr Interface](#) : GetInterferenceComponents Method (IInterferenceDetectionMgr)

Calculates and gets the interfering components.

### .NET Syntax

Visual Basic (Declaration)

```
Function GetInterferenceComponents() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IInterferenceDetectionMgr  
Dim value As System.Object  
  
value = instance.GetInterferenceComponents()
```

C#

```
System.object GetInterferenceComponents()
```

C++/CLI

```
System.Object^ GetInterferenceComponents();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Array of the interfering [components](#)

### Visual Basic for Applications (VBA) Syntax

See [InterferenceDetectionMgr::GetInterferenceComponents](#).

### See Also

[IInterferenceDetectionMgr Interface](#)  
[IInterferenceDetectionMgr Members](#)  
[InterferenceDetectionMgr::GetInterferenceComponentCount Method](#)  
[InterferenceDetectionMgr::IGetInterferenceComponents Method](#)  
[InterferenceDetectionMgr::MakeInterferingPartsTransparent Property](#)  
[InterferenceDetectionMgr::NonInterferingComponentDisplay Property](#)  
[InterferenceDetectionMgr::TreatSubAssembliesAsComponents Property](#)  
[Interference::GetComponentCount Method](#)  
[Interference::IGetComponents Method](#)  
[Interference::Components Property](#)

### Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

## GetInterferenceCount Method (IInterferenceDetectionMgr)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [IInterferenceDetectionMgr Interface](#) : GetInterferenceCount Method (IInterferenceDetectionMgr)

Calculates and gets the number of interferences.

### .NET Syntax

Visual Basic (Declaration)

```
Function GetInterferenceCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IInterferenceDetectionMgr
Dim value As System.Integer

value = instance.GetInterferenceCount()
```

C#

```
System.int GetInterferenceCount()
```

C++/CLI

```
System.int GetInterferenceCount();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Number of interferences

### Visual Basic for Applications (VBA) Syntax

See [InterferenceDetectionMgr::GetInterferenceCount](#).

### Example

[Run Interference Detection \(C#\)](#)  
[Run Interference Detection \(VB.NET\)](#)  
[Run Interference Detection \(VBA\)](#)

### Remarks

Call this method before calling [InterferenceDetectionMgr::GetInterferences](#) to determine the size of the array for the interferences.

### See Also

[InterferenceDetectionMgr Interface](#)  
[InterferenceDetectionMgr Members](#)  
[InterferenceDetectionMgr::GetInterferences Method](#)

### Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## GetInterferences Method (IInterferenceDetectionMgr)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IInterferenceDetectionMgr Interface](#) : GetInterferences Method (IInterferenceDetectionMgr)

Calculates and gets the interferences.

### .NET Syntax

Visual Basic (Declaration)

```
Function GetInterferences() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IInterferenceDetectionMgr
Dim value As System.Object
```

```
value = instance.GetInterferences()
```

C#

```
System.object GetInterferences()
```

C++/CLI

```
System.Object^ GetInterferences();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Array of the [interferences](#)

### Visual Basic for Applications (VBA) Syntax

See [InterferenceDetectionMgr::GetInterferences](#).

### Example

[Run Interference Detection \(C#\)](#)  
[Run Interference Detection \(VB.NET\)](#)  
[Run Interference Detection \(VBA\)](#)

### See Also

[IInterferenceDetectionMgr Interface](#)  
[IInterferenceDetectionMgr Members](#)  
[InterferenceDetectionMgr::GetInterferenceCount Method](#)  
[InterferenceDetectionMgr::IGetInterferences Method](#)

### Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IGetComponentsTransformInterference Method (IInterferenceDetectionMgr)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IInterferenceDetectionMgr Interface](#) : IGetComponentsTransformInterference Method (IInterferenceDetectionMgr)

Calculates and gets the interfering components for the specified components and math transform.

### .NET Syntax

Visual Basic (Declaration)

```
Function IGetComponentsTransformInterference( _  
    ByVal NumOfComponent As System.Integer, _  
    ByRef Component As Component2, _  
    ByRef Transform As MathTransform, _  
    ByVal NumOfIntComponent As System.Integer, _  
    ByRef InterferingComponent As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IInterferenceDetectionMgr  
Dim NumOfComponent As System.Integer  
Dim Component As Component2  
Dim Transform As MathTransform  
Dim NumOfIntComponent As System.Integer  
Dim InterferingComponent As Component2  
Dim value As System.Boolean
```

```
value = instance.IGetComponentsTransformInterference(NumOfComponent, Component, Transform,  
NumOfIntComponent, InterferingComponent)
```

C#

```
System.bool IGetComponentsTransformInterference(  
    System.int NumOfComponent,  
    ref Component2 Component,  
    ref MathTransform Transform,  
    System.int NumOfIntComponent,
```

```
    out Component2 InterferingComponent
)
```

C++/CLI

```
System.bool IGetComponentsTransformInterference(
& System.int NumOfComponent,
& Component2^% Component,
& MathTransform^% Transform,
& System.int NumOfIntComponent,
& [Out] Component2^ InterferingComponent
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*NumOfComponent*

Number of components in array specified by *Component*

*Component*

- in-process, unmanaged C++: Pointer to an array of [components](#)

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

*Transform*

[IMathTransform](#)

*NumOfIntComponent*

Number of interfering components in array returned by this method (see **Remarks**)

*InterferingComponent*

- in-process, unmanaged C++: Pointer to an array of interfering [components](#)

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

#### Return Value

True if successful, false if not

#### Remarks

Before calling this method, call [InterferenceDetectionMgr::GetComponentsTransformInterferenceCount](#) to populate *NumOfIntComponent*.

#### See Also

[InterferenceDetectionMgr Interface](#)

[InterferenceDetectionMgr Members](#)

[InterferenceDetectionMgr::GetComponentsTransformInterference Method](#)

[InterferenceDetectionMgr::CreateFastenersFolder Property](#)

[InterferenceDetectionMgr::IgnoreHiddenBodies Property](#)

[InterferenceDetectionMgr::IncludeMultibodyPartInterferences Property](#)

[InterferenceDetectionMgr::MakeInterferingParts Transparent Property](#)

[InterferenceDetectionMgr::NonInterferingComponentDisplay Property](#)

[InterferenceDetectionMgr::ShowIgnoredInterferences Property](#)

[InterferenceDetectionMgr::TreatCoincidenceAsInterference Property](#)

[InterferenceDetectionMgr::TreatSubAssembliesAsComponents Property](#)

[InterferenceDetectionMgr::IGetInterferenceComponents Method](#)

#### Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IGetInterferenceComponents Method (IInterferenceDetectionMgr)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IInterferenceDetectionMgr Interface](#) : IGetInterferenceComponents Method (IInterferenceDetectionMgr)

Calculates and gets the interfering components.

#### .NET Syntax

Visual Basic (Declaration)

```
Function IGetInterferenceComponents( _
    ByVal InterferenceComponentCount As System.Integer _
) As Component2
```

```
Dim instance As IInterferenceDetectionMgr
Dim InterferenceComponentCount As System.Integer
Dim value As Component2

value = instance.IGetInterferenceComponents(InterferenceComponentCount)
```

C#

```
Component2 IGetInterferenceComponents(
    System.int InterferenceComponentCount
)
```

C++/CLI

```
Component2^ IGetInterferenceComponents(
    & System.int InterferenceComponentCount
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*InterferenceComponentCount*

Number of interfering components

#### Return Value

- in-process, unmanaged C++: Pointer to an array of interfering [components](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

#### Remarks

Before calling this method, call [IInterferenceDetectionMgr::GetInterferenceComponentCount](#) to get the size for the array of interfering components.

#### See Also

[IInterferenceDetectionMgr Interface](#)  
[IInterferenceDetectionMgr Members](#)  
[IInterferenceDetectionMgr::GetInterferenceComponents Method](#)  
[IInterferenceDetectionMgr::MakeInterferingPartsTransparent Property](#)  
[IInterferenceDetectionMgr::NonInterferingComponentDisplay Property](#)  
[IInterferenceDetectionMgr::TreatSubAssembliesAsComponents Property](#)  
[IInterference::GetComponentCount Method](#)  
[IInterference::IGetComponents Method](#)  
[IInterference::Components Property](#)  
[IInterferenceDetectionMgr::IGetComponentsTransformInterference Method](#)

#### Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IGetInterferences Method (IInterferenceDetectionMgr)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IInterferenceDetectionMgr Interface](#) : IGetInterferences Method (IInterferenceDetectionMgr)

Calculates and gets the interferences.

#### .NET Syntax

Visual Basic (Declaration)

```
Function IGetInterferences( _
    ByVal InterferenceCount As System.Integer _
) As Interference
```

Visual Basic (Usage)

```
Dim instance As IInterferenceDetectionMgr
Dim InterferenceCount As System.Integer
Dim value As Interference

value = instance.IGetInterferences(InterferenceCount)
```

C#

```
Interference IGetInterferences(
    System.int InterferenceCount
)
```

C++/CLI

```
Interference^ IGetInterferences(
    & System.int InterferenceCount
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*InterferenceCount*  
Number of interferences

#### Return Value

- in-process, unmanaged C++: Pointer to an array of [interferences](#)
  - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

#### Remarks

Before calling this method, call [IInterferenceDetectionMgr::GetInterferenceCount](#) to get the size of array for the interferences.

#### See Also

[IInterferenceDetectionMgr Interface](#)  
[IInterferenceDetectionMgr Members](#)  
[IInterferenceDetectionMgr::GetInterferences Method](#)

#### Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IgnoreHiddenBodies Property (IInterferenceDetectionMgr)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IInterferenceDetectionMgr Interface](#) : IgnoreHiddenBodies Property (IInterferenceDetectionMgr)

Gets or sets whether to ignore hidden bodies during interference detection.

#### .NET Syntax

Visual Basic (Declaration)

```
Property IgnoreHiddenBodies As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IInterferenceDetectionMgr
Dim value As System.Boolean
```

```
instance.IgnoreHiddenBodies = value
```

```
value = instance.IgnoreHiddenBodies
```

C#

```
System.bool IgnoreHiddenBodies {get; set;}
```

C++/CLI

```
property System.bool IgnoreHiddenBodies {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True to ignore hidden bodies, false to not

### Visual Basic for Applications (VBA) Syntax

See [InterferenceDetectionMgr::IgnoreHiddenBodies](#).

### Example

[Run Interference Detection \(C#\)](#)  
[Run Interference Detection \(VB.NET\)](#)  
[Run Interference Detection \(VBA\)](#)

### Remarks

Currently, the value set for this property:

- exists only while the InterferenceDetectionMgr object is in scope; i.e., setting this property is temporary.
- does not persist across SOLIDWORKS Design sessions.
- does not persist into the next invocation of interference detection in the user interface.

### See Also

[InterferenceDetectionMgr Interface](#)  
[InterferenceDetectionMgr Members](#)

### Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IncludeMultibodyPartInterferences Property (InterferenceDetectionMgr)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [InterferenceDetectionMgr Interface](#) : IncludeMultibodyPartInterferences Property (InterferenceDetectionMgr)

Gets or sets whether to report interferences between bodies within multibody parts.

### .NET Syntax

Visual Basic (Declaration)

```
Property IncludeMultibodyPartInterferences As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IInterferenceDetectionMgr  
Dim value As System.Boolean  
  
instance.IncludeMultibodyPartInterferences = value  
value = instance.IncludeMultibodyPartInterferences
```

C#

```
System.bool IncludeMultibodyPartInterferences {get; set;}
```

C++/CLI

```
property System.bool IncludeMultibodyPartInterferences {
    System.bool get();
    void set ( & System.bool value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True to report interferences between bodies within multibody parts, false to not

### Visual Basic for Applications (VBA) Syntax

See [InterferenceDetectionMgr::IncludeMultibodyPartInterferences](#).

### Example

[Run Interference Detection \(C#\)](#)  
[Run Interference Detection \(VB.NET\)](#)  
[Run Interference Detection \(VBA\)](#)

### Remarks

Currently, the value set for this property:

- exists only while the InterferenceDetectionMgr object is in scope; i.e., setting this property is temporary.
- does not persist across SOLIDWORKS Design sessions.
- does not persist into the next invocation of interference detection in the user interface.

### See Also

[InterferenceDetectionMgr Interface](#)  
[InterferenceDetectionMgr Members](#)

### Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## MakeInterferingPartsTransparent Property (IInterferenceDetectionMgr)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IInterferenceDetectionMgr Interface](#) : MakeInterferingPartsTransparent Property (IInterferenceDetectionMgr)

Gets or sets whether to display the components of the selected interference in transparent mode.

### .NET Syntax

Visual Basic (Declaration)

```
Property MakeInterferingPartsTransparent As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IInterferenceDetectionMgr
Dim value As System.Boolean
```

```
instance.MakeInterferingPartsTransparent = value
```

```
value = instance.MakeInterferingPartsTransparent
```

C#

```
System.bool MakeInterferingPartsTransparent {get; set;}
```

C++/CLI

```
property System.bool MakeInterferingPartsTransparent {
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True to make interfering parts transparent, false to not

### Visual Basic for Applications (VBA) Syntax

See [InterferenceDetectionMgr::MakeInterferingPartsTransparent](#).

### Example

[Run Interference Detection \(C#\)](#)  
[Run Interference Detection \(VB.NET\)](#)  
[Run Interference Detection \(VBA\)](#)

### Remarks

Currently, the value set for this property:

- exists only while the InterferenceDetectionMgr object is in scope; i.e., setting this property is temporary.
- does not persist across SOLIDWORKS Design sessions.
- does not persist into the next invocation of interference detection in the user interface.

### See Also

[IInterferenceDetectionMgr Interface](#)  
[IInterferenceDetectionMgr Members](#)  
[InterferenceDetectionMgr::GetInterferenceComponentCount Method](#)  
[InterferenceDetectionMgr::GetInterferenceComponents Method](#)  
[InterferenceDetectionMgr::IGetInterferenceComponents Method](#)  
[InterferenceDetectionMgr::NonInterferingComponentDisplay Property](#)  
[InterferenceDetectionMgr::TreatSubAssembliesAsComponents Property](#)  
[Interference::GetComponentCount Method](#)  
[Interference::IGetComponents Method](#)  
[Interference::Components Property](#)

### Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## NonInterferingComponentDisplay Property (IInterferenceDetectionMgr)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IInterferenceDetectionMgr Interface](#) : NonInterferingComponentDisplay Property (IInterferenceDetectionMgr)

Gets or sets the mode to display non-interfering components.

### .NET Syntax

Visual Basic (Declaration)

Property NonInterferingComponentDisplay As System.Integer

Visual Basic (Usage)



```
Dim instance As IInterferenceDetectionMgr  
Dim value As System.Integer
```

```
instance.NonInterferingComponentDisplay = value
```

```
value = instance.NonInterferingComponentDisplay
```

C#

```
System.int NonInterferingComponentDisplay {get; set;}
```

C++/CLI

```
property System.int NonInterferingComponentDisplay {
    System.int get();
    void set ( & System.int value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Mode to display non-interfering components as defined in [swNonInterferingComponentDisplay\\_e](#)

### Visual Basic for Applications (VBA) Syntax

See [InterferenceDetectionMgr::NonInterferingComponentDisplay](#).

### Example

[Run Interference Detection \(C#\)](#)  
[Run Interference Detection \(VB.NET\)](#)  
[Run Interference Detection \(VBA\)](#)

### See Also

[IInterferenceDetectionMgr Interface](#)  
[IInterferenceDetectionMgr Members](#)  
[IInterferenceDetectionMgr::GetInterferenceComponentCount Method](#)  
[IInterferenceDetectionMgr::GetInterferenceComponents Method](#)  
[IInterferenceDetectionMgr::IGetInterferenceComponents Method](#)  
[IInterferenceDetectionMgr::MakeInterferingParts Transparent Property](#)  
[IInterferenceDetectionMgr::TreatSubAssembliesAsComponents Property](#)  
[IInterference::GetComponentCount Method](#)  
[IInterference::IGetComponents Method](#)  
[IInterference::Components Property](#)

### Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## SetComponentsAndTransforms Method (IInterferenceDetectionMgr)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IInterferenceDetectionMgr Interface](#) : SetComponentsAndTransforms Method (IInterferenceDetectionMgr)

Sets the interfering components and their transforms.

### .NET Syntax

#### Visual Basic (Declaration)

```
Function SetComponentsAndTransforms( _
    ByVal ComponentList As System.Object, _
    ByVal TransformList As System.Object _
) As System.Integer
```

#### Visual Basic (Usage)



```
Dim instance As IInterferenceDetectionMgr
Dim ComponentList As System.Object
Dim TransformList As System.Object
Dim value As System.Integer
```

```
value = instance.SetComponentsAndTransforms(ComponentList, TransformList)
```

#### C#

```
System.int SetComponentsAndTransforms(
    System.object ComponentList,
    System.object TransformList
)
```

#### C++/CLI

```
System.int SetComponentsAndTransforms(  
& System.Object^ ComponentList,  
& System.Object^ TransformList  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*ComponentList*  
Array of interfering [components](#)  
*TransformList*  
Array of [transforms](#)

#### Return Value

Status as defined by [swSetComponentsAndTransformsStatus\\_e](#)

### Visual Basic for Applications (VBA) Syntax

See [InterferenceDetectionMgr::SetComponentsAndTransforms](#).

### Example

[Set Components and Transforms for Interference Detection \(C#\)](#)  
[Set Components and Transforms for Interference Detection \(VB.NET\)](#)  
[Set Components and Transforms for Interference Detection \(VBA\)](#)

### Remarks

You must pass in absolute transforms to this method.

If you want to transform a component incrementally before interference detection, then you must multiply that incremental transform by the component's existing transform before passing in the resultant transform.

To produce the effect of identity transforms on components (i.e., the components do not move while participating in interference detection), the transforms for those components passed in can be null or Nothing. However, passing in null or Nothing for all of the transforms is interpreted as invalid input.

**NOTE:** A null or Nothing is interpreted as the component's existing transform (i.e., an identity incremental transform).

### See Also

[IInterferenceDetectionMgr Interface](#)  
[IInterferenceDetectionMgr Members](#)  
[IInterferenceDetectionMgr::GetComponentsAndTransforms Method \(\)](#)

### Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## ShowIgnoredInterferences Property (IInterferenceDetectionMgr)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IInterferenceDetectionMgr Interface](#) : ShowIgnoredInterferences Property (IInterferenceDetectionMgr)

Gets or sets whether to show ignored interferences.

### .NET Syntax

Visual Basic (Declaration)

Property ShowIgnoredInterferences As System.Boolean

Visual Basic (Usage)



```
Dim instance As IInterferenceDetectionMgr  
Dim value As System.Boolean
```

```
instance.ShowIgnoredInterferences = value
```

```
value = instance.ShowIgnoredInterferences
```

C#

```
System.bool ShowIgnoredInterferences {get; set;}
```

C++/CLI

```
property System.bool ShowIgnoredInterferences {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True to show ignored interferences, false to not

### Visual Basic for Applications (VBA) Syntax

See [InterferenceDetectionMgr::ShowIgnoredInterferences](#).

### Example

[Run Interference Detection \(C#\)](#)  
[Run Interference Detection \(VB.NET\)](#)  
[Run Interference Detection \(VBA\)](#)

### Remarks

Currently, the value set for this property:

- exists only while the InterferenceDetectionMgr object is in scope; i.e., setting this property is temporary.
- does not persist across SOLIDWORKS Design sessions.
- does not persist into the next invocation of interference detection in the user interface.

### See Also

[InterferenceDetectionMgr Interface](#)  
[InterferenceDetectionMgr Members](#)

### Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## TreatCoincidenceAsInterference Property (IInterferenceDetectionMgr)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IInterferenceDetectionMgr Interface](#) : TreatCoincidenceAsInterference Property (IInterferenceDetectionMgr)

Gets or sets whether to treat coincident entities as interference.

### .NET Syntax

Visual Basic (Declaration)

```
Property TreatCoincidenceAsInterference As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IInterferenceDetectionMgr  
Dim value As System.Boolean  
  
instance.TreatCoincidenceAsInterference = value  
value = instance.TreatCoincidenceAsInterference
```

C#

```
System.bool TreatCoincidenceAsInterference {get; set;}
```

C++/CLI

```
property System.bool TreatCoincidenceAsInterference {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True to treat coincident entities as interference, false to not

### Visual Basic for Applications (VBA) Syntax

See [InterferenceDetectionMgr::TreatCoincidenceAsInterference](#).

### Example

[Run Interference Detection \(C#\)](#)  
[Run Interference Detection \(VB.NET\)](#)  
[Run Interference Detection \(VBA\)](#)  
[Get Interferences Using a Transform \(C#\)](#)  
[Get Interferences Using a Transform \(VB.NET\)](#)  
[Get Interferences Using a Transform \(VBA\)](#)

### Remarks

Currently, the value set for this property:

- exists only while the InterferenceDetectionMgr object is in scope; i.e., setting this property is temporary.
- does not persist across SOLIDWORKS Design sessions.
- does not persist into the next invocation of interference detection in the user interface.

### See Also

[IInterferenceDetectionMgr Interface](#)  
[IInterferenceDetectionMgr Members](#)

### Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## TreatSubAssembliesAsComponents Property (IInterferenceDetectionMgr)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IInterferenceDetectionMgr Interface](#) : TreatSubAssembliesAsComponents Property (IInterferenceDetectionMgr)

Gets or sets whether to treat subassemblies as single components so that interferences between a sub-assembly's components are not reported.

### .NET Syntax

Visual Basic (Declaration)

```
Property TreatSubAssembliesAsComponents As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IInterferenceDetectionMgr  
Dim value As System.Boolean  
  
instance.TreatSubAssembliesAsComponents = value  
  
value = instance.TreatSubAssembliesAsComponents
```

C#

```
System.bool TreatSubAssembliesAsComponents {get; set;}
```

C++/CLI

```
property System.bool TreatSubAssembliesAsComponents {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True to treat a sub-assembly's components as single, false to not

### Visual Basic for Applications (VBA) Syntax

See [InterferenceDetectionMgr::TreatSubAssembliesAsComponents](#).

### Example

[Run Interference Detection \(C#\)](#)  
[Run Interference Detection \(VB.NET\)](#)  
[Run Interference Detection \(VBA\)](#)

### Remarks

Currently, the value set for this property:

- exists only while the InterferenceDetectionMgr object is in scope; i.e., setting this property is temporary.
- does not persist across SOLIDWORKS Design sessions.
- does not persist into the next invocation of interference detection in the user interface.

### See Also

[InterferenceDetectionMgr Interface](#)  
[InterferenceDetectionMgr Members](#)  
[InterferenceDetectionMgr::NonInterferingComponentDisplay Property](#)  
[InterferenceDetectionMgr::MakeInterferingParts Transparent Property](#)  
[InterferenceDetectionMgr::IGetInterferenceComponents Method](#)  
[InterferenceDetectionMgr::GetInterferenceComponents Method](#)  
[InterferenceDetectionMgr::GetInterferenceComponentCount Method](#)  
[Interference::GetComponentCount Method](#)  
[Interference::IGetComponents Method](#)  
[Interference::Components Property](#)

### Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## UseTransform Property (IInterferenceDetectionMgr)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IInterferenceDetectionMgr Interface](#) : UseTransform Property (IInterferenceDetectionMgr)

Gets or sets whether to use transforms in interference detection.

### .NET Syntax

Visual Basic (Declaration)

Property UseTransform As System.Boolean

Visual Basic (Usage)



```
Dim instance As IInterferenceDetectionMgr  
Dim value As System.Boolean
```

```
instance.UseTransform = value
```

```
value = instance.UseTransform
```

C#

```
System.bool UseTransform {get; set;}
```

C++/CLI

```
property System.bool UseTransform {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True to use transforms, false to not

### Visual Basic for Applications (VBA) Syntax

See [InterferenceDetectionMgr::UseTransform](#).

### Example

[Run Interference Detection \(VBA\)](#)  
[Run Interference Detection \(VB.NET\)](#)  
[Run Interference Detection \(C#\)](#)

### See Also

[IInterferenceDetectionMgr Interface](#)  
[IInterferenceDetectionMgr Members](#)

### Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

# IIIntersectFeatureData (Type)

## IIIntersectFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IIIntersectFeatureData Interface

Allows access to an intersect feature.

**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

### .NET Syntax

Visual Basic (Declaration)

```
Public Interface IIIntersectFeatureData
```

Visual Basic (Usage)

```
Dim instance As IIIntersectFeatureData
```

C#

```
public interface IIIntersectFeatureData
```

C++/CLI

```
public interface class IIIntersectFeatureData
```

### Visual Basic for Applications (VBA) Syntax

See [IntersectFeatureData](#).

### Example

[Get Intersect Feature Data \(VBA\)](#)  
[Get Intersect Feature Data \(VB.NET\)](#)  
[Get Intersect Feature Data \(C#\)](#)

### Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

### Access Diagram

[IntersectFeatureData](#)

### See Also

[IIIntersectFeatureData Members](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IFeatureManager::PostIntersect Method \(\)](#)  
[IFeatureManager::PreIntersect Method \(\)](#)

## IIIntersectFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IIIntersectFeatureData Interface

For a list of all members of this type, see [IIIntersectFeatureData members](#).

### Public Methods

| Name                                                                                                                 | Description                                                        |
|----------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------|
|  <a href="#">AccessSelections</a> | Gains access to the selections that define this intersect feature. |
| <a href="#">GetIntersections</a>                                                                                     | Gets the intersect regions in this intersect feature.              |

|                                                                                   |                                            |                                                                                        |
|-----------------------------------------------------------------------------------|--------------------------------------------|----------------------------------------------------------------------------------------|
|   |                                            |                                                                                        |
|  | <a href="#">GetIntersectionsCount</a>      | Gets the number of intersect regions in this intersect feature.                        |
|  | <a href="#">GetIntersectionsTools</a>      | Gets the intersecting solids, surfaces, and planes in this intersect feature.          |
|  | <a href="#">GetIntersectionsToolsCount</a> | Gets the number of solids, surfaces, and planes used to create this intersect feature. |
|  | <a href="#">ReleaseSelectionAccess</a>     | Releases access to the selections for this intersect feature.                          |
|  | <a href="#">SetIntersections</a>           | Specifies which of the intersect regions to exclude from this intersect feature.       |
|  | <a href="#">SetIntersectionsTools</a>      | Specifies the intersecting solids, surfaces, and planes for this intersect feature.    |

[Top](#)

## See Also

[IIntersectFeatureData Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IFeatureManager::PostIntersect Method \(\)](#)  
[IFeatureManager::PreIntersect Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IntersectFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)

|                                                                                   |                                                                                         |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------|
|  | <a href="#">SolidWorks.Interop.sldworks Namespace</a> : IIntersectFeatureData Interface |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------|

The following tables list the members exposed by [IIntersectFeatureData](#).

## Public Properties

| Name                                                                                                        | Description                                                                        |
|-------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------|
|  <a href="#">CapPlanar</a> | Gets or sets whether to close the flat openings of surfaces.                       |
|  <a href="#">Consume</a>  | Gets or sets whether to remove input surfaces from the FeatureManager design tree. |
|  <a href="#">Merge</a>   | Gets or sets whether to merge included regions into one body.                      |

[Top](#)

## Public Methods

| Name                                                                                                                           | Description                                                                            |
|--------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------|
|  <a href="#">AccessSelections</a>           | Gains access to the selections that define this intersect feature.                     |
|  <a href="#">GetIntersections</a>           | Gets the intersect regions in this intersect feature.                                  |
|  <a href="#">GetIntersectionsCount</a>      | Gets the number of intersect regions in this intersect feature.                        |
|  <a href="#">GetIntersectionsTools</a>      | Gets the intersecting solids, surfaces, and planes in this intersect feature.          |
|  <a href="#">GetIntersectionsToolsCount</a> | Gets the number of solids, surfaces, and planes used to create this intersect feature. |
|  <a href="#">ReleaseSelectionAccess</a>     | Releases access to the selections for this intersect feature.                          |
|  <a href="#">SetIntersections</a>           | Specifies which of the intersect regions to exclude from this intersect feature.       |
|  <a href="#">SetIntersectionsTools</a>      | Specifies the intersecting solids, surfaces, and planes for this intersect feature.    |

[Top](#)

## See Also

[IIntersectFeatureData Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IFeatureManager::PostIntersect Method \(\)](#)  
[IFeatureManager::PreIntersect Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IntersectFeatureData Interface Properties

[See Also](#)

|                                                                                     |                                                                                         |
|-------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------|
|  | <a href="#">SolidWorks.Interop.sldworks Namespace</a> : IIntersectFeatureData Interface |
|-------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------|

For a list of all members of this type, see [IIntersectFeatureData members](#).

## Public Properties

| Name                                                                                                        | Description                                                                        |
|-------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------|
|  <a href="#">CapPlanar</a> | Gets or sets whether to close the flat openings of surfaces.                       |
|  <a href="#">Consume</a>   | Gets or sets whether to remove input surfaces from the FeatureManager design tree. |
|  <a href="#">Merge</a>     | Gets or sets whether to merge included regions into one body.                      |

[Top](#)

## See Also

[IIntersectFeatureData Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IFeatureManager::PostIntersect Method \(\)](#)  
[IFeatureManager::PreIntersect Method \(\)](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

## AccessSelections Method (IIntersectFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IIntersectFeatureData Interface](#) : AccessSelections Method (IIntersectFeatureData)

Gains access to the selections that define this intersect feature.

## .NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IIntersectFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

*TopDoc*  
Top-level document (see **Remarks**)  
*Component*  
Component in which the feature is to be modified (see **Remarks**)

### Return Value

True if the selections were successfully accessed, false if not

## Visual Basic for Applications (VBA) Syntax

See [IntersectFeatureData::AccessSelections](#).

## Remarks

| To modify a feature in a... | Then...                                                                                                                                                                                                      |
|-----------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Part                        | <ul style="list-style-type: none"><li>TopDoc argument is the <a href="#">IModelDoc2</a> for the part</li><li>Component argument is NULL</li></ul>                                                            |
| Assembly                    | <ul style="list-style-type: none"><li>TopDoc is the IModelDoc2 object for the assembly</li><li>Component argument is the <a href="#">IComponent2</a> object in which the feature is to be modified</li></ul> |

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IntersectFeatureData::ReleaseSelectionAccess](#) if you did not

## See Also

[IIntersectFeatureData Interface](#)  
[IntersectFeatureData Members](#)

## Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## CapPlanar Property (IIntersectFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IIntersectFeatureData Interface](#) : CapPlanar Property (IIntersectFeatureData)

Gets or sets whether to close the flat openings of surfaces.

## .NET Syntax

Visual Basic (Declaration)

Property CapPlanar As System.Boolean

Visual Basic (Usage)



```
Dim instance As IIntersectFeatureData
Dim value As System.Boolean

instance.CapPlanar = value
value = instance.CapPlanar
```

C#

```
System.bool CapPlanar {get; set;}
```

C++/CLI

```
property System.bool CapPlanar {
    System.bool get();
    void set ( & System.bool value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

True to close the flat openings, false to not

## Visual Basic for Applications (VBA) Syntax

See [IntersectFeatureData::CapPlanar](#).

## Example

See the [IIntersectFeatureData](#) examples.

## See Also

[IIntersectFeatureData Interface](#)  
[IIntersectFeatureData Members](#)

## Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Consume Property (IIntersectFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IIntersectFeatureData Interface](#) : Consume Property (IIntersectFeatureData)

Gets or sets whether to remove input surfaces from the FeatureManager design tree.

## .NET Syntax

### Visual Basic (Declaration)

Property Consume As System.Boolean

### Visual Basic (Usage)



```
Dim instance As IIntersectFeatureData  
Dim value As System.Boolean
```

```
instance.Consume = value
```

```
value = instance.Consume
```

### C#

```
System.bool Consume {get; set;}
```

### C++/CLI

```
property System.bool Consume {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

True to remove input surfaces, false to not

## Visual Basic for Applications (VBA) Syntax

See [IntersectFeatureData::Consume](#).

## Example

See the [IIntersectFeatureData](#) examples.

## See Also

[IIntersectFeatureData Interface](#)  
[IIntersectFeatureData Members](#)

## Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetIntersections Method (IIntersectFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IIntersectFeatureData Interface](#) : GetIntersections Method (IIntersectFeatureData)

Gets the intersect regions in this intersect feature.

## Visual Basic Syntax

### Visual Basic (Declaration)

```
Function GetIntersections( _  
    ByRef Excluded As System.Object _  
) As System.Object
```

### Visual Basic (Usage)



```
Dim instance As IIntersectFeatureData  
Dim Excluded As System.Object  
Dim value As System.Object  
  
value = instance.GetIntersections(Excluded)
```

### C#

```
System.object GetIntersections(  
    out System.object Excluded  
)
```

### C++/CLI

```
System.Object^ GetIntersections(  
    & [Out] System.Object^ Excluded  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Parameters

#### *Excluded*

Array of booleans; true indicates that the corresponding intersect region in the array of returned intersect regions is excluded from this intersect feature

### Return Value

Array of [intersect regions](#)

## Visual Basic for Applications (VBA) Syntax

See [IntersectFeatureData::GetIntersections](#).

## See Also

[IIntersectFeatureData Interface](#)  
[IIntersectFeatureData Members](#)  
[IIntersectFeatureData::SetIntersections Method \(\)](#)  
[IIntersectFeatureData::GetIntersectionsCount Method \(\)](#)

## Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetIntersectionsCount Method (IIntersectFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IIntersectFeatureData Interface](#) : GetIntersectionsCount Method (IIntersectFeatureData)

Gets the number of intersect regions in this intersect feature.

## Visual Basic Syntax

### Visual Basic (Declaration)

```
Function GetIntersectionsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IIntersectFeatureData  
Dim value As System.Integer  
  
value = instance.GetIntersectionsCount()
```

C#

```
System.int GetIntersectionsCount()
```

C++/CLI

```
System.int GetIntersectionsCount();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Number of intersect regions

### Visual Basic for Applications (VBA) Syntax

See [IntersectFeatureData::GetIntersectionsCount](#).

### Example

See the [IIntersectFeatureData](#) examples.

### See Also

[IIntersectFeatureData Interface](#)  
[IIntersectFeatureData Members](#)  
[IntersectFeatureData::GetIntersections Method \(\)](#)

### Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## GetIntersectionsTools Method (IIntersectFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IIntersectFeatureData Interface](#) : GetIntersectionsTools Method (IIntersectFeatureData)

Gets the intersecting solids, surfaces, and planes in this intersect feature.

### .NET Syntax

Visual Basic (Declaration)

```
Function GetIntersectionsTools() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IIntersectFeatureData  
Dim value As System.Object  
  
value = instance.GetIntersectionsTools()
```

C#

```
System.object GetIntersectionsTools()
```

C++/CLI

```
System.Object^ GetIntersectionsTools();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Array of intersecting [solids](#), [surfaces](#), and [planes](#) in this intersect feature

#### Visual Basic for Applications (VBA) Syntax

See [IntersectFeatureData::GetIntersectionsTools](#).

#### See Also

[IIntersectFeatureData Interface](#)  
[IIntersectFeatureData Members](#)  
[IntersectFeatureData::GetIntersectionsToolsCount Method \(\)](#)  
[IntersectFeatureData::SetIntersectionsTools Method \(\)](#)

#### Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## GetIntersectionsToolsCount Method (IIntersectFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IIntersectFeatureData Interface](#) : GetIntersectionsToolsCount Method (IIntersectFeatureData)

Gets the number of solids, surfaces, and planes used to create this intersect feature.

#### .NET Syntax

Visual Basic (Declaration)

```
Function GetIntersectionsToolsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IIntersectFeatureData  
Dim value As System.Integer  
  
value = instance.GetIntersectionsToolsCount()
```

C#

```
System.int GetIntersectionsToolsCount()
```

C++/CLI

```
System.int GetIntersectionsToolsCount();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Number of solids, surfaces, and planes used to create this intersect feature

#### Visual Basic for Applications (VBA) Syntax

See [IntersectFeatureData::GetIntersectionsToolsCount](#).

#### Example

See the [IIntersectFeatureData](#) examples.

#### See Also

[IIntersectFeatureData Interface](#)  
[IIntersectFeatureData Members](#)  
[IIntersectFeatureData::GetIntersectionsTools Method\(\)](#)

## Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Merge Property (IIntersectFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IIntersectFeatureData Interface](#) : Merge Property (IIntersectFeatureData)

Gets or sets whether to merge included regions into one body.

## .NET Syntax

Visual Basic (Declaration)

Property Merge As System.Boolean

Visual Basic (Usage)



```
Dim instance As IIntersectFeatureData  
Dim value As System.Boolean
```

```
instance.Merge = value
```

```
value = instance.Merge
```

C#

```
System.bool Merge {get; set;}
```

C++/CLI

```
property System.bool Merge {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

True to merge included regions into one body, false to create a separate body for each included region

## Visual Basic for Applications (VBA) Syntax

See [IntersectFeatureData::Merge](#).

## Example

See the [IIntersectFeatureData](#) examples.

## See Also

[IIntersectFeatureData Interface](#)  
[IIntersectFeatureData Members](#)

## Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## ReleaseSelectionAccess Method (IIntersectFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IIntersectFeatureData Interface](#) : ReleaseSelectionAccess Method (IIntersectFeatureData)

Releases access to the selections for this intersect feature.

## .NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IIntersectFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

## Visual Basic for Applications (VBA) Syntax

See [IntersectFeatureData::ReleaseSelectionAccess](#).

## Remarks

[IntersectFeatureData::AccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature. Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) if you did.

## See Also

[IIntersectFeatureData Interface](#)  
[IIntersectFeatureData Members](#)

## Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## SetIntersections Method (IIntersectFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IIntersectFeatureData Interface](#) : SetIntersections Method (IIntersectFeatureData)

Specifies which of the intersect regions to exclude from this intersect feature.

## .NET Syntax

Visual Basic (Declaration)

```
Sub SetIntersections( _  
    ByVal Intersections As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IIntersectFeatureData  
Dim Intersections As System.Object  
  
instance.SetIntersections(Intersections)
```

C#

```
void SetIntersections(  
    System.object Intersections  
)
```

C++/CLI

```
void SetIntersections(  
& System.Object^ Intersections  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*Intersections*

Array of booleans; true indicates to exclude the corresponding intersect region in the array of intersect regions returned by [IntersectFeatureData::GetIntersections](#)

### Visual Basic for Applications (VBA) Syntax

See [IntersectFeatureData::SetIntersections](#).

### See Also

[IIntersectFeatureData Interface](#)  
[IntersectFeatureData Members](#)

### Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## SetIntersectionsTools Method (IIntersectFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IIntersectFeatureData Interface](#) : SetIntersectionsTools Method (IIntersectFeatureData)

Specifies the intersecting solids, surfaces, and planes for this intersect feature.

### .NET Syntax

Visual Basic (Declaration)

```
Sub SetIntersectionsTools(  
    ByVal Tools As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IIntersectFeatureData  
Dim Tools As System.Object  
  
instance.SetIntersectionsTools(Tools)
```

C#

```
void SetIntersectionsTools(  
    System.object Tools  
)
```

C++/CLI

```
void SetIntersectionsTools(  
& System.Object^ Tools  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*Tools*

Array of intersecting [solids](#), [surfaces](#), and [planes](#) for this intersect feature

## Visual Basic for Applications (VBA) Syntax

See [IntersectFeatureData::SetIntersectionsTools](#).

## See Also

[IIntersectFeatureData Interface](#)

[IIntersectFeatureData Members](#)

[IIntersectFeatureData::GetIntersectionsTools Method \(\)](#)

## Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0