

SOLIDWORKS API (.NET VBA C#) — Reference

(139/337): IJogFeatureData-ILayer

SOLIDWORKS API Documentation (converted from CHM)

IJogFeatureData (Type)

IJogFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IJogFeatureData Interface

Allows access to a jog feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IJogFeatureData
```

Visual Basic (Usage)

```
Dim instance As IJogFeatureData
```

C#

```
public interface IJogFeatureData
```

C++/CLI

```
public interface class IJogFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [JogFeatureData](#).

Example

[Get All Sheet Metal Feature Data \(VBA\)](#)
[Get All Sheet Metal Feature Data \(VB.NET\)](#)
[Get All Sheet Metal Feature Data \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[JogFeatureData](#)

See Also

[IJogFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertSheetMetalJog Method](#)

IJogFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IJogFeatureData Interface

The following tables list the members exposed by [IJogFeatureData](#).

Public Properties

Name	Description
BendRadius	Gets or sets the bend radius for this jog feature.
DimensionPositionType	Gets or sets the dimension position type for this jog feature.

 FixedFace	Gets or sets the fixed face for this jog feature.
 FixedPoint	Gets or sets the fixed point x, y, z coordinates for this jog feature.
 FixProjectedLength	Gets or sets whether to fix the projected length for this jog feature.
 JogAngle	Gets or sets the jog angle for this jog feature.
 JogPositionType	Gets or sets the jog position type for this jog feature.
 OffsetDistance	Gets or sets the offset distance for this jog feature.
 OffsetReference	Gets or sets the offset reference for this jog feature.
 OffsetType	Gets or sets the offset type for this jog feature.
 ReverseDirection	Gets or sets whether to reverse the direction of this jog feature.
 ReverseOffset	Gets or sets whether to reverse the offset of this jog feature.
 UseDefaultBendAllowance	Gets or sets whether to use the default bend allowance for this jog feature.
 UseDefaultBendRadius	Gets or sets whether to use the default bend radius for this jog feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this jog feature.
 GetCustomBendAllowance	Gets the custom bend allowance for this jog feature.
 GetOffsetReferenceType	Gets the offset reference geometry type for this jog feature.
 IAccessSelections	Gains access to the selections that define this jog feature.
 IGetFixedPoint	Gets the fixed-point x, y, z coordinates for this jog feature.
 ISetFixedPoint	Sets the fixed-point x, y, z coordinates for this jog feature.
 ReleaseSelectionAccess	Releases access to the selections for this jog feature.
 SetCustomBendAllowance	Sets the custom bend allowance for this jog feature.

[Top](#)

See Also

[IJogFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertSheetMetalJog_Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IJogFeatureData Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IJogFeatureData Interface

For a list of all members of this type, see [IJogFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this jog feature.
 GetCustomBendAllowance	Gets the custom bend allowance for this jog feature.
 GetOffsetReferenceType	Gets the offset reference geometry type for this jog feature.
 IAccessSelections	Gains access to the selections that define this jog feature.
 IGetFixedPoint	Gets the fixed-point x, y, z coordinates for this jog feature.
 ISetFixedPoint	Sets the fixed-point x, y, z coordinates for this jog feature.
 ReleaseSelectionAccess	Releases access to the selections for this jog feature.
 SetCustomBendAllowance	Sets the custom bend allowance for this jog feature.



[Top](#)

See Also

[IJogFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertSheetMetalJog Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IJogFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IJogFeatureData Interface

For a list of all members of this type, see [IJogFeatureData members](#).

Public Properties

Name	Description
 BendRadius	Gets or sets the bend radius for this jog feature.
 DimensionPositionType	Gets or sets the dimension position type for this jog feature.
 FixedFace	Gets or sets the fixed face for this jog feature.
 FixedPoint	Gets or sets the fixed point x, y, z coordinates for this jog feature.
 FixProjectedLength	Gets or sets whether to fix the projected length for this jog feature.
 JogAngle	Gets or sets the jog angle for this jog feature.
 JogPositionType	Gets or sets the jog position type for this jog feature.
 OffsetDistance	Gets or sets the offset distance for this jog feature.
 OffsetReference	Gets or sets the offset reference for this jog feature.
 OffsetType	Gets or sets the offset type for this jog feature.
 ReverseDirection	Gets or sets whether to reverse the direction of this jog feature.
 ReverseOffset	Gets or sets whether to reverse the offset of this jog feature.
 UseDefaultBendAllowance	Gets or sets whether to use the default bend allowance for this jog feature.
 UseDefaultBendRadius	Gets or sets whether to use the default bend radius for this jog feature.

[Top](#)

See Also

[IJogFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertSheetMetalJog Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IJogFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJogFeatureData Interface](#) : AccessSelections Method (IJogFeatureData)

Gains access to the selections that define this jog feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```

Dim instance As IJogFeatureData
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)

```

C#

```

System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)

```

C++/CLI

```

System.bool AccessSelections(
    & System.Object^ TopDoc,
    & System.Object^ Component
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document (see **Remarks**)

Component
Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [JogFeatureData::AccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IJogFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IJogFeatureData Interface](#)
[IJogFeatureData Members](#)
[IJogFeatureData::IAccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

BendRadius Property (IJogFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJogFeatureData Interface](#) : BendRadius Property (IJogFeatureData)

Gets or sets the bend radius for this jog feature.

.NET Syntax

Visual Basic (Declaration)

Property BendRadius As System.Double

Visual Basic (Usage)



```
Dim instance As IJogFeatureData  
Dim value As System.Double  
  
instance.BendRadius = value  
value = instance.BendRadius
```

C#

```
System.double BendRadius {get; set;}
```

C++/CLI

```
property System.double BendRadius {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [JogFeatureData::BendRadius](#).

Example

See [IJogFeatureData](#) examples.

See Also

[IJogFeatureData Interface](#)
[IJogFeatureData Members](#)
[IJogFeatureData::UseDefaultBendRadius Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DimensionPositionType Property (IJogFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJogFeatureData Interface](#) : DimensionPositionType Property (IJogFeatureData)

Gets or sets the dimension position type for this jog feature.

.NET Syntax

Visual Basic (Declaration)

```
Property DimensionPositionType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IJogFeatureData  
Dim value As System.Integer  
  
instance.DimensionPositionType = value  
value = instance.DimensionPositionType
```

C#

```
System.int DimensionPositionType {get; set;}
```

C++/CLI

```
property System.int DimensionPositionType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Dimension position type as defined in [swJogDimensionPositionType_e](#)

Visual Basic for Applications (VBA) Syntax

See [JogFeatureData::DimensionPositionType](#).

See Also

[IJogFeatureData Interface](#)
[IJogFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

FixedFace Property (IJogFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJogFeatureData Interface](#) : FixedFace Property (IJogFeatureData)

Gets or sets the fixed face for this jog feature.

.NET Syntax

Visual Basic (Declaration)

Property FixedFace As System.Object

Visual Basic (Usage)



```
Dim instance As IJogFeatureData  
Dim value As System.Object
```

```
instance.FixedFace = value
```

```
value = instance.FixedFace
```

C#

```
System.object FixedFace {get; set;}
```

C++/CLI

```
property System.Object^ FixedFace {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Fixed [face](#)

Visual Basic for Applications (VBA) Syntax

See [JogFeatureData::FixedFace](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IJogFeatureData Interface](#)
[IJogFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

FixedPoint Property (IJogFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJogFeatureData Interface](#) : FixedPoint Property (IJogFeatureData)

Gets or sets the fixed point x, y, z coordinates for this jog feature.

.NET Syntax

Visual Basic (Declaration)

```
Property FixedPoint As System.Object
```

Visual Basic (Usage)



```
Dim instance As IJogFeatureData  
Dim value As System.Object
```

```
instance.FixedPoint = value
```

```
value = instance.FixedPoint
```

C#

```
System.object FixedPoint {get; set;}
```

C++/CLI

```
property System.Object^ FixedPoint {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of fixed point coordinates

Visual Basic for Applications (VBA) Syntax

See [JogFeatureData::FixedPoint](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IJogFeatureData Interface](#)
[IJogFeatureData Members](#)
[IJogFeatureData::IGetFixedPoint Method](#)
[IJogFeatureData::ISetFixedPoint Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

FixProjectedLength Property (IJogFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJogFeatureData Interface](#) : FixProjectedLength Property (IJogFeatureData)

Gets or sets whether to fix the projected length for this jog feature.

.NET Syntax

Visual Basic (Declaration)

Property FixProjectedLength As System.Boolean

Visual Basic (Usage)



```
Dim instance As IJogFeatureData
Dim value As System.Boolean

instance.FixProjectedLength = value
value = instance.FixProjectedLength
```

C#

```
System.bool FixProjectedLength {get; set;}
```

C++/CLI

```
property System.bool FixProjectedLength {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True fixes the projected length, false does not

Visual Basic for Applications (VBA) Syntax

See [JogFeatureData::FixProjectedLength](#).

See Also

[IJogFeatureData Interface](#)
[IJogFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCustomBendAllowance Method (IJogFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJogFeatureData Interface](#) : GetCustomBendAllowance Method (IJogFeatureData)

Gets the custom bend allowance for this jog feature.

.NET Syntax

Visual Basic (Declaration)

Function GetCustomBendAllowance() As CustomBendAllowance

Visual Basic (Usage)



```
Dim instance As IJogFeatureData  
Dim value As CustomBendAllowance
```

```
value = instance.GetCustomBendAllowance()
```

C#

```
CustomBendAllowance GetCustomBendAllowance()
```

C++/CLI

```
CustomBendAllowance^ GetCustomBendAllowance();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [custom bend allowance](#)

Visual Basic for Applications (VBA) Syntax

See [JogFeatureData::GetCustomBendAllowance](#).

Example

See [IJogFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IJogFeatureData Interface](#)
[IJogFeatureData Members](#)
[IJogFeatureData::SetCustomBendAllowance Method](#)
[IJogFeatureData::UseDefaultBendAllowance Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetOffsetReferenceType Method (IJogFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJogFeatureData Interface](#) : GetOffsetReferenceType Method (IJogFeatureData)

Gets the offset reference geometry type for this jog feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetOffsetReferenceType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IJogFeatureData  
Dim value As System.Integer
```

```
value = instance.GetOffsetReferenceType()
```

C#

```
System.int GetOffsetReferenceType()
```

C++/CLI

```
System.int GetOffsetReferenceType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Offset reference geometry type as defined in [swJogOffsetTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [JogFeatureData::GetOffsetReferenceType](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IJogFeatureData Interface](#)
[IJogFeatureData Members](#)
[IJogFeatureData::OffsetDistance Property](#)
[IJogFeatureData::OffsetReference Property](#)
[IJogFeatureData::OffsetType Property](#)
[IJogFeatureData::ReverseOffset Property](#)

Availability

SOLIDWORKS 2001Plus SP3, Revision Number 10.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (IJogFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJogFeatureData Interface](#) : IAccessSelections Method (IJogFeatureData)

Gains access to the selections that define this jog feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IJogFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [JogFeatureData::IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::IModifyDefintion2](#) if you modified the feature
- [IJogFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IJogFeatureData Interface](#)

[IJogFeatureData Members](#)

[IJogFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFixedPoint Method (IJogFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJogFeatureData Interface](#) : IGetFixedPoint Method (IJogFeatureData)

Gets the fixed-point x, y, z coordinates for this jog feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFixedPoint() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IJogFeatureData
```

```
Dim value As System.Double
```

```
value = instance.IGetFixedPoint()
```

C#

```
System.double IGetFixedPoint()
```

C++/CLI

```
System.double IGetFixedPoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of fixed-point coordinates
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IJogFeatureData Interface](#)
[IJogFeatureData Members](#)
[IJogFeatureData::ISetFixedPoint Method](#)
[IJogFeatureData::FixedPoint Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetFixedPoint Method (IJogFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJogFeatureData Interface](#) : ISetFixedPoint Method (IJogFeatureData)

Sets the fixed-point x, y, z coordinates for this jog feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetFixedPoint( _  
    ByRef Point As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IJogFeatureData  
Dim Point As System.Double  
  
instance.ISetFixedPoint(Point)
```

C#

```
void ISetFixedPoint(  
    ref System.double Point  
)
```

C++/CLI

```
void ISetFixedPoint(  
& System.double% Point  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Point

- in-process, unmanaged C++: Pointer to an array of fixed-point coordinates
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IJogFeatureData Interface](#)
[IJogFeatureData Members](#)
[IJogFeatureData::IGetFixedPoint Method](#)
[IJogFeatureData::FixedPoint Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

JogAngle Property (IJogFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJogFeatureData Interface](#) : JogAngle Property (IJogFeatureData)

Gets or sets the jog angle for this jog feature.

.NET Syntax

Visual Basic (Declaration)

Property JogAngle As System.Double

Visual Basic (Usage)



```
Dim instance As IJogFeatureData  
Dim value As System.Double
```

```
instance.JogAngle = value
```

```
value = instance.JogAngle
```

C#

```
System.double JogAngle {get; set;}
```

C++/CLI

```
property System.double JogAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Jog angle

Visual Basic for Applications (VBA) Syntax

See [JogFeatureData::JogAngle](#).

See Also

[IJogFeatureData Interface](#)
[IJogFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

JogPositionType Property (IJogFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJogFeatureData Interface](#) : JogPositionType Property (IJogFeatureData)

Gets or sets the jog position type for this jog feature.

.NET Syntax

Visual Basic (Declaration)

```
Property JogPositionType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IJogFeatureData  
Dim value As System.Integer
```

```
instance.JogPositionType = value
```

```
value = instance.JogPositionType
```

C#

```
System.int JogPositionType {get; set;}
```

C++/CLI

```
property System.int JogPositionType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Position type as defined in [swJogPositionType_e](#)

Visual Basic for Applications (VBA) Syntax

See [JogFeatureData::JogPositionType](#).

See Also

[IJogFeatureData Interface](#)
[IJogFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

OffsetDistance Property (IJogFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJogFeatureData Interface](#) : OffsetDistance Property (IJogFeatureData)

Gets or sets the offset distance for this jog feature.

.NET Syntax

Visual Basic (Declaration)

```
Property OffsetDistance As System.Double
```

Visual Basic (Usage)



```
Dim instance As IJogFeatureData  
Dim value As System.Double
```

```
instance.OffsetDistance = value
```

```
value = instance.OffsetDistance
```

C#

```
System.double OffsetDistance {get; set;}
```

C++/CLI

```
property System.double OffsetDistance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Offset distance

Visual Basic for Applications (VBA) Syntax

See [JogFeatureData::OffsetDistance](#).

See Also

[IJogFeatureData Interface](#)
[IJogFeatureData Members](#)
[IJogFeatureData::GetOffsetReferenceType Method](#)
[IJogFeatureData::OffsetReference Property](#)
[IJogFeatureData::OffsetType Property](#)
[IJogFeatureData::ReverseOffset Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

OffsetReference Property (IJogFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJogFeatureData Interface](#) : OffsetReference Property (IJogFeatureData)

Gets or sets the offset reference for this jog feature.

.NET Syntax

Visual Basic (Declaration)

```
Property OffsetReference As System.Object
```

Visual Basic (Usage)



```
Dim instance As IJogFeatureData  
Dim value As System.Object
```

```
instance.OffsetReference = value
```

```
value = instance.OffsetReference
```

C#

```
System.object OffsetReference {get; set;}
```

C++/CLI

```
property System.Object^ OffsetReference {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Offset reference

Visual Basic for Applications (VBA) Syntax

See [JogFeatureData::OffsetReference](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IJogFeatureData Interface](#)
[IJogFeatureData Members](#)
[IJogFeatureData::GetOffsetReferenceType Method](#)
[IJogFeatureData::OffsetDistance Property](#)
[IJogFeatureData::OffsetType Property](#)
[IJogFeatureData::ReverseOffset Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

OffsetType Property (IJogFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJogFeatureData Interface](#) : OffsetType Property (IJogFeatureData)

Gets or sets the offset type for this jog feature.

.NET Syntax

Visual Basic (Declaration)

```
Property OffsetType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IJogFeatureData  
Dim value As System.Integer
```

```
instance.OffsetType = value
```

```
value = instance.OffsetType
```

C#

```
System.int OffsetType {get; set;}
```

C++/CLI

```
property System.int OffsetType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Offset type as defined in [swJogOffsetTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [JogFeatureData::OffsetType](#).

See Also

[IJogFeatureData Interface](#)
[IJogFeatureData Members](#)
[IJogFeatureData::GetOffsetReferenceType Method](#)
[IJogFeatureData::OffsetDistance Property](#)
[IJogFeatureData::OffsetReference Property](#)
[IJogFeatureData::ReverseOffset Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IJogFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJogFeatureData Interface](#) : ReleaseSelectionAccess Method (IJogFeatureData)

Releases access to the selections for this jog feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IJogFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [JogFeatureData::ReleaseSelectionAccess](#).

Remarks

[IJogFeatureData::AccessSelections](#) and [IJogFeatureData::IAccessSelections](#) put the model into a rollback state to allow access to the selection that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefintion2](#) if you did.

See Also

[IJogFeatureData Interface](#)
[IJogFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (IJogFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJogFeatureData Interface](#) : ReverseDirection Property (IJogFeatureData)

Gets or sets whether to reverse the direction of this jog feature.

.NET Syntax

Visual Basic (Declaration)

Property ReverseDirection As System.Boolean

Visual Basic (Usage)



```
Dim instance As IJogFeatureData
Dim value As System.Boolean

instance.ReverseDirection = value
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True reverses the direction, false does not

Visual Basic for Applications (VBA) Syntax

See [JogFeatureData::ReverseDirection](#).

See Also

[IJogFeatureData Interface](#)
[IJogFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseOffset Property (IJogFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJogFeatureData Interface](#) : ReverseOffset Property (IJogFeatureData)

Gets or sets whether to reverse the offset of this jog feature.

.NET Syntax

Visual Basic (Declaration)

Property ReverseOffset As System.Boolean

Visual Basic (Usage)



```
Dim instance As IJogFeatureData
Dim value As System.Boolean

instance.ReverseOffset = value
value = instance.ReverseOffset
```

C#

```
System.bool ReverseOffset {get; set;}
```

C++/CLI

```
property System.bool ReverseOffset {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True enables the reverse offset, false disables it

Visual Basic for Applications (VBA) Syntax

See [JogFeatureData::ReverseOffset](#).

See Also

[IJogFeatureData Interface](#)
[IJogFeatureData Members](#)
[IJogFeatureData::GetOffsetReferenceType Method](#)
[IJogFeatureData::OffsetDistance Property](#)
[IJogFeatureData::OffsetReference Property](#)
[IJogFeatureData::OffsetType Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetCustomBendAllowance Method (IJogFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJogFeatureData Interface](#) : SetCustomBendAllowance Method (IJogFeatureData)

Sets the custom bend allowance for this jog feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetCustomBendAllowance( _  
    ByVal PBendData As CustomBendAllowance _  
)
```

Visual Basic (Usage)



```
Dim instance As IJogFeatureData  
Dim PBendData As CustomBendAllowance  
  
instance.SetCustomBendAllowance(PBendData)
```

C#

```
void SetCustomBendAllowance(  
    CustomBendAllowance PBendData  
)
```

C++/CLI

```
void SetCustomBendAllowance(  
& CustomBendAllowance^ PBendData  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PBendData

Pointer to the [custom bend allowance](#)

Visual Basic for Applications (VBA) Syntax

See [JogFeatureData::SetCustomBendAllowance](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IJogFeatureData Interface](#)
[IJogFeatureData Members](#)
[IJogFeatureData::GetCustomBendAllowance Method](#)
[IJogFeatureData::UseDefaultBendAllowance Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseDefaultBendAllowance Property (IJogFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJogFeatureData Interface](#) : UseDefaultBendAllowance Property (IJogFeatureData)

Gets or sets whether to use the default bend allowance for this jog feature.

.NET Syntax

Visual Basic (Declaration)

Property UseDefaultBendAllowance As System.Boolean

Visual Basic (Usage)



```
Dim instance As IJogFeatureData
Dim value As System.Boolean

instance.UseDefaultBendAllowance = value
value = instance.UseDefaultBendAllowance
```

C#

```
System.bool UseDefaultBendAllowance {get; set;}
```

C++/CLI

```
property System.bool UseDefaultBendAllowance {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True uses the default bend allowance, false does not

Visual Basic for Applications (VBA) Syntax

See [JogFeatureData::UseDefaultBendAllowance](#).

Example

See [IJogFeatureData](#) examples.

See Also

[IJogFeatureData Interface](#)
[IJogFeatureData Members](#)
[IJogFeatureData::GetCustomBendAllowance Method](#)
[IJogFeatureData::SetCustomBendAllowance Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseDefaultBendRadius Property (IJogFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJogFeatureData Interface](#) : UseDefaultBendRadius Property (IJogFeatureData)

Gets or sets whether to use the default bend radius for this jog feature.

.NET Syntax

Visual Basic (Declaration)

```
Property UseDefaultBendRadius As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IJogFeatureData  
Dim value As System.Boolean  
  
instance.UseDefaultBendRadius = value  
  
value = instance.UseDefaultBendRadius
```

C#

```
System.bool UseDefaultBendRadius {get; set;}
```

C++/CLI

```
property System.bool UseDefaultBendRadius {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True uses the default bend radius, false does not

Visual Basic for Applications (VBA) Syntax

See [JogFeatureData::UseDefaultBendRadius](#).

Example

[Get All Sheet Metal Feature Data \(VBA\)](#)

See Also

[IJogFeatureData Interface](#)
[IJogFeatureData Members](#)
[IJogFeatureData::BendRadius Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

IJoinFeatureData (Type)

IJoinFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IJoinFeatureData Interface

Allows access to a join feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IJoinFeatureData
```

Visual Basic (Usage)

```
Dim instance As IJoinFeatureData
```

C#

```
public interface IJoinFeatureData
```

C++/CLI

```
public interface class IJoinFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [JoinFeatureData](#).

Example

[Insert Join Feature \(C#\)](#)
[Insert Join Feature \(VB.NET\)](#)
[Insert Join Feature \(VBA\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[JoinFeatureData](#)

See Also

[IJoinFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAssemblyDoc::InsertJoin2 Method](#)

IJoinFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IJoinFeatureData Interface

The following tables list the members exposed by [IJoinFeatureData](#).

Public Properties

Name	Description
ForceSurfaceContact	Gets or sets whether to join any coincident faces and any intruding volumes.
HideParts	Gets or sets whether the original components are hidden after joined.



[JoinedParts](#)

Gets and sets the parts to join.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this join feature.
 GetJoinedPartsCount	Gets the number of joined parts.
 IGetJoinedParts	Gets the joined parts.
 ISetJoinedParts	Sets the parts to join.
 ReleaseSelectionAccess	Releases access to the selections that define this join feature.

[Top](#)

See Also

[IJoinFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAssemblyDoc::InsertJoin2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IJoinFeatureData Interface Methods

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IJoinFeatureData Interface

For a list of all members of this type, see [IJoinFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this join feature.
 GetJoinedPartsCount	Gets the number of joined parts.
 IGetJoinedParts	Gets the joined parts.
 ISetJoinedParts	Sets the parts to join.
 ReleaseSelectionAccess	Releases access to the selections that define this join feature.

[Top](#)

See Also

[IJoinFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAssemblyDoc::InsertJoin2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IJoinFeatureData Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IJoinFeatureData Interface

For a list of all members of this type, see [IJoinFeatureData members](#).

Public Properties

Name	Description
 ForceSurfaceContact	Gets or sets whether to join any coincident faces and any intruding volumes.
 HideParts	Gets or sets whether the original components are hidden after joined.
 JoinedParts	Gets and sets the parts to join.

[Top](#)

See Also

AccessSelections Method (IJoinFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJoinFeatureData Interface](#) : AccessSelections Method (IJoinFeatureData)

Gains access to the selections that define this join feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IJoinFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document (see **Remarks**)
Component
Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [JoinFeatureData::AccessSelections](#).

Example

[Insert Join Feature \(C#\)](#)
[Insert Join Feature \(VB.NET\)](#)
[Insert Join Feature \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IJoinFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IJoinFeatureData Interface](#)
[IJoinFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ForceSurfaceContact Property (IJoinFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJoinFeatureData Interface](#) : ForceSurfaceContact Property (IJoinFeatureData)

Gets or sets whether to join any coincident faces and any intruding volumes.

.NET Syntax

Visual Basic (Declaration)

Property ForceSurfaceContact As System.Boolean

Visual Basic (Usage)



```
Dim instance As IJoinFeatureData  
Dim value As System.Boolean  
  
instance.ForceSurfaceContact = value  
  
value = instance.ForceSurfaceContact
```

C#

```
System.bool ForceSurfaceContact {get; set;}
```

C++/CLI

```
property System.bool ForceSurfaceContact {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to join any coincident faces and any intruding volumes, false to not

Visual Basic for Applications (VBA) Syntax

See [JoinFeatureData::ForceSurfaceContact](#).

See Also

[IJoinFeatureData Interface](#)
[IJoinFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetJoinedPartsCount Method (IJoinFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJoinFeatureData Interface](#) : GetJoinedPartsCount Method (IJoinFeatureData)

Gets the number of joined parts.

.NET Syntax

Visual Basic (Declaration)

```
Function GetJoinedPartsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IJoinFeatureData  
Dim value As System.Integer  
  
value = instance.GetJoinedPartsCount()
```

C#

```
System.int GetJoinedPartsCount()
```

C++/CLI

```
System.int GetJoinedPartsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of joined parts

Visual Basic for Applications (VBA) Syntax

See [JoinFeatureData::GetJoinedPartsCount](#).

Example

[Insert Join Feature \(C#\)](#)
[Insert Join Feature \(VB.NET\)](#)
[Insert Join Feature \(VBA\)](#)

Remarks

Call this method before calling [IJoinFeatureData::IGetJoinedParts](#) to determine the size of the array.

See Also

[IJoinFeatureData Interface](#)
[IJoinFeatureData Members](#)
[IJoinFeatureData::ISetJoinedParts Method](#)
[IJoinFeatureData::JoinedParts Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

HideParts Property (IJoinFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJoinFeatureData Interface](#) : HideParts Property (IJoinFeatureData)

Gets or sets whether the original components are hidden after joined.

.NET Syntax

Visual Basic (Declaration)

Property HideParts As System.Boolean

Visual Basic (Usage)



```
Dim instance As IJoinFeatureData  
Dim value As System.Boolean
```

```
instance.HideParts = value
```

```
value = instance.HideParts
```

C#

```
System.bool HideParts {get; set;}
```

C++/CLI

```
property System.bool HideParts {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the original components are hidden after joined, false to not

Visual Basic for Applications (VBA) Syntax

See [JoinFeatureData::HideParts](#).

See Also

[IJoinFeatureData Interface](#)
[IJoinFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetJoinedParts Method (IJoinFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJoinFeatureData Interface](#) : IGetJoinedParts Method (IJoinFeatureData)

Gets the joined parts.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetJoinedParts( _  
    ByVal Count As System.Integer _  
) As Component2
```

Visual Basic (Usage)



```
Dim instance As IJoinFeatureData  
Dim Count As System.Integer  
Dim value As Component2
```

```
value = instance.IGetJoinedParts(Count)
```

C#

```
Component2 IGetJoinedParts(  
    System.int Count
```

)

C++/CLI

```
Component2^ IGetJoinedParts(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of joined parts

Return Value

- in-process, unmanaged C++: Pointer to an array of joined parts, the [IComponent2](#) objects
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IJoinFeatureData::GetJoinedPartsCount](#) before calling this method to determine Count.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IJoinFeatureData Interface](#)
[IJoinFeatureData Members](#)
[IJoinFeatureData::ISetJoinedParts Method](#)
[IJoinFeatureData::JoinedParts Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetJoinedParts Method (IJoinFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJoinFeatureData Interface](#) : ISetJoinedParts Method (IJoinFeatureData)

Sets the parts to join.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetJoinedParts( _  
    ByVal Count As System.Integer, _  
    ByRef Parts As Component2 _  
)
```

Visual Basic (Usage)



```
Dim instance As IJoinFeatureData  
Dim Count As System.Integer  
Dim Parts As Component2
```

```
instance.ISetJoinedParts(Count, Parts)
```

C#

```
void ISetJoinedParts(  
    System.int Count,  
    ref Component2 Parts  
)
```

C++/CLI

```
void ISetJoinedParts(
& System.int Count,
& Component2^% Parts
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of parts to join

Parts

- in-process, unmanaged C++: Pointer to an array of joined parts, the [IComponent2](#) objects
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IJoinFeatureData Interface](#)

[IJoinFeatureData Members](#)

[IJoinFeatureData::GetJoinedPartsCount Method](#)

[IJoinFeatureData::IGetJoinedParts Method](#)

[IJoinFeatureData::JoinedParts Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

JoinedParts Property (IJoinFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJoinFeatureData Interface](#) : JoinedParts Property (IJoinFeatureData)

Gets and sets the parts to join.

.NET Syntax

Visual Basic (Declaration)

```
Property JoinedParts As System.Object
```

Visual Basic (Usage)



```
Dim instance As IJoinFeatureData
```

```
Dim value As System.Object
```

```
instance.JoinedParts = value
```

```
value = instance.JoinedParts
```

C#

```
System.object JoinedParts {get; set;}
```

C++/CLI

```
property System.Object^ JoinedParts {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of joined parts, the [IComponent2](#) objects

Visual Basic for Applications (VBA) Syntax

See [JoinFeatureData::JoinedParts](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IJoinFeatureData Interface](#)
[IJoinFeatureData Members](#)
[IJoinFeatureData::GetJoinedPartsCount Method](#)
[IJoinFeatureData::IGetJoinedParts Method](#)
[IJoinFeatureData::ISetJoinedParts Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReleaseSelectionAccess Method (IJoinFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IJoinFeatureData Interface](#) : ReleaseSelectionAccess Method (IJoinFeatureData)

Releases access to the selections that define this join feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IJoinFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [JoinFeatureData::ReleaseSelectionAccess](#).

Example

[Insert Join Feature \(C#\)](#)
[Insert Join Feature \(VB.NET\)](#)
[Insert Join Feature \(VBA\)](#)

Remarks

[IJoinFeatureData::AccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefintion2](#) if you did.

See Also

[IJoinFeatureData Interface](#)
[IJoinFeatureData Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

ILayer (Type)

ILayer Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILayer Interface

Allows access to the properties and items on a layer, including the color, width, name, etc., used to define the layer.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ILayer
```

Visual Basic (Usage)



```
Dim instance As ILayer
```

C#

```
public interface ILayer
```

C++/CLI

```
public interface class ILayer
```

Visual Basic for Applications (VBA) Syntax

See [Layer](#).

Example

[Get Layers \(C#\)](#)
[Get Layers \(VB.NET\)](#)
[Get Layers \(VBA\)](#)

Remarks

The ILayer interface is managed and accessible from the [ILayerMgr](#) interface. Layers are only supported in SOLIDWORKS drawing documents.

Accessors

[ILayerMgr::GetLayerById](#) and [ILayerMgr::!GetLayerById](#)
[ILayerMgr::GetLayer](#) and [ILayerMgr::!GetLayer](#)

Access Diagram

[Layer](#)

See Also

[ILayer Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ILayerMgr Interface](#)
[IDrawingDoc Interface](#)

ILayer Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILayer Interface

The following tables list the members exposed by [ILayer](#).

Public Properties

Name	Description
 Color	Gets and sets the line color for this layer.
 Description	Gets and sets this layer description.
 Name	Gets and sets the name of this layer.
 Printable	Gets and sets whether this layer is printed when the drawing document is printed.
 Style	Gets and sets the line style for this layer.
 Visible	Gets or sets the visibility of this layer.
 Width	Gets and sets the line width for this layer.

[Top](#)

Public Methods

Name	Description
 GetID	Gets the layer ID for this layer.
 GetItems	Gets the items on this layer.

[Top](#)

See Also

[ILayer Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ILayerMgr Interface](#)
[IDrawingDoc Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ILayer Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILayer Interface

For a list of all members of this type, see [ILayer members](#).

Public Methods

Name	Description
 GetID	Gets the layer ID for this layer.
 GetItems	Gets the items on this layer.

[Top](#)

See Also

[ILayer Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ILayerMgr Interface](#)
[IDrawingDoc Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ILayer Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILayer Interface

For a list of all members of this type, see [ILayer members](#).

Public Properties

Name	Description
 Color	Gets and sets the line color for this layer.
 Description	Gets and sets this layer description.

 Name	Gets and sets the name of this layer.
 Printable	Gets and sets whether this layer is printed when the drawing document is printed.
 Style	Gets and sets the line style for this layer.
 Visible	Gets or sets the visibility of this layer.
 Width	Gets and sets the line width for this layer.

[Top](#)

See Also

[ILayer Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ILayerMgr Interface](#)
[IDrawingDoc Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Color Property (ILayer)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILayer Interface](#) : Color Property (ILayer)

Gets and sets the line color for this layer.

.NET Syntax

Visual Basic (Declaration)

Property Color As System.Integer

Visual Basic (Usage)



```
Dim instance As ILayer
Dim value As System.Integer

instance.Color = value

value = instance.Color
```

C#

```
System.int Color {get; set;}
```

C++/CLI

```
property System.int Color {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

COLORREF value for the color

Visual Basic for Applications (VBA) Syntax

See [Layer::Color](#).

Example

[Get Layers \(C#\)](#)
[Get Layers \(VB.NET\)](#)
[Get Layers \(VBA\)](#)

See Also

[ILayer Interface](#)
[ILayer Members](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

Description Property (ILayer)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILayer Interface](#) : Description Property (ILayer)

Gets and sets this layer description.

.NET Syntax

Visual Basic (Declaration)

Property Description As System.String

Visual Basic (Usage)



```
Dim instance As ILayer
Dim value As System.String

instance.Description = value
value = instance.Description
```

C#

```
System.string Description {get; set;}
```

C++/CLI

```
property System.String^ Description {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Layer description

Visual Basic for Applications (VBA) Syntax

See [Layer::Description](#).

Example

[Get Layers \(C#\)](#)
[Get Layers \(VB.NET\)](#)
[Get Layers \(VBA\)](#)

See Also

[ILayer Interface](#)
[ILayer Members](#)

Availability

SOLIDWORKS 99 SP6, datecode 1999355

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetID Method (ILayer)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILayer Interface](#) : GetID Method (ILayer)

Gets the layer ID for this layer.

Visual Basic (Declaration)

```
Function GetID() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILayer
Dim value As System.Integer

value = instance.GetID()
```

C#

```
System.int GetID()
```

C++/CLI

```
System.int GetID();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Layer ID for this layer

Visual Basic for Applications (VBA) Syntax

See [Layer::GetID](#).

Example

[Get Layers \(C#\)](#)
[Get Layers \(VB.NET\)](#)
[Get Layers \(VBA\)](#)

Remarks

A layer ID:

- is unique within the drawing.
- is persistent across SOLIDWORKS Design sessions and never changes, even if you [change the name of the layer](#).
- can be used to identify a specific layer when multiple layers exist in a drawing.
- cannot be assigned by applications or users.
- is not the same as a [persistent reference ID](#). You can get a layer using its persistent reference ID, but you cannot get a layer using this method.

See Also

[ILayer Interface](#)
[ILayer Members](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetItems Method (ILayer)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILayer Interface](#) : GetItems Method (ILayer)

Gets the items on this layer.

Visual Basic (Declaration)

```
Function GetItems( _  
    ByVal ItemType As System.Integer _
```

```
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILayer  
Dim ItemType As System.Integer  
Dim value As System.Object  
  
value = instance.GetItems(ItemType)
```

C#

```
System.object GetItems(  
    System.int ItemType  
)
```

C++/CLI

```
System.Object^ GetItems(  
&    System.int ItemType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ItemType

Items to get as defined in [swLayerItemsOption e](#)

Return Value

Array of layer items

Visual Basic for Applications (VBA) Syntax

See [Layer::GetItems](#).

See Also

[ILayer Interface](#)
[ILayer Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Name Property (ILayer)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILayer Interface](#) : Name Property (ILayer)

Gets and sets the name of this layer.

.NET Syntax

Visual Basic (Declaration)

```
Property Name As System.String
```

Visual Basic (Usage)



```
Dim instance As ILayer  
Dim value As System.String  
  
instance.Name = value  
  
value = instance.Name
```

C#

```
System.string Name {get; set;}
```

C++/CLI

```
property System.String^ Name {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Layer name

Visual Basic for Applications (VBA) Syntax

See [Layer::Name](#).

See Also

[ILayer Interface](#)
[ILayer Members](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments](#) on this topic.

Printable Property (ILayer)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILayer Interface](#) : Printable Property (ILayer)

Gets and sets whether this layer is printed when the drawing document is printed.

.NET Syntax

Visual Basic (Declaration)

```
Property Printable As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILayer  
Dim value As System.Boolean  
  
instance.Printable = value  
value = instance.Printable
```

C#

```
System.bool Printable {get; set;}
```

C++/CLI

```
property System.bool Printable {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the layer is printable, false if the layer is not visible (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ILayer::Printable](#).

Example

See the [ILayer](#) examples.

Remarks

Always call this property after setting [ILayer::Visible](#) to the opposite state, because setting [ILayer::Visible](#) might change the state of [ILayer::Printable](#). It is not possible to make a layer printable if it is not visible.

To ensure that [ILayer::Visible](#) and [ILayer::Printable](#) are set to the desired states, perform the following steps in this order:

1. Set [ILayer::Visible](#).
2. Get the state of [ILayer::Printable](#).
3. Set [ILayer::Printable](#) if necessary.

See Also

[ILayer Interface](#)
[ILayer Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Style Property (ILayer)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILayer Interface](#) : Style Property (ILayer)

Gets and sets the line style for this layer.

.NET Syntax

Visual Basic (Declaration)

Property Style As System.Integer

Visual Basic (Usage)



```
Dim instance As ILayer
Dim value As System.Integer

instance.Style = value

value = instance.Style
```

C#

```
System.int Style {get; set;}
```

C++/CLI

```
property System.int Style {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Line style as defined in [swLineStyles_e](#)

Visual Basic for Applications (VBA) Syntax

See [Layer::Style](#).

Example

[Get Layers \(C#\)](#)
[Get Layers \(VB.NET\)](#)
[Get Layers \(VBA\)](#)

See Also

[ILayer Interface](#)
[ILayer Members](#)
[ILayer.Width Property](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments](#) on this topic.

Visible Property (ILayer)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILayer Interface](#) : Visible Property (ILayer)

Gets or sets the visibility of this layer.

.NET Syntax

Visual Basic (Declaration)

Property Visible As System.Boolean

Visual Basic (Usage)



```
Dim instance As ILayer
Dim value As System.Boolean

instance.Visible = value
value = instance.Visible
```

C#

```
System.bool Visible {get; set;}
```

C++/CLI

```
property System.bool Visible {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the layer is visible, false if the layer is not visible (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Layer.Visible](#).

Example

[Determine if Layer is Visible \(VBA\)](#)
[Get Layers \(C#\)](#)
[Get Layers \(VB.NET\)](#)
[Get Layers \(VBA\)](#)

Remarks

After setting this property to the opposite state, call [ILayer::Printable](#) to check its state, because setting ILayer::Visible might change the state of ILayer::Printable.

To ensure that ILayer::Visible and ILayer::Printable are set to the desired states, perform the following steps in this order:

1. Set ILayer::Visible.
2. Get the state of ILayer::Printable.
3. Set ILayer::Printable if necessary.

See Also

[ILayer Interface](#)
[ILayer Members](#)

Availability

SOLIDWORKS 99 SP6, datecode 1999355

SOLIDWORKS API Help

[Send comments on this topic.](#)

Width Property (ILayer)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILayer Interface](#) : Width Property (ILayer)

Gets and sets the line width for this layer.

.NET Syntax

Visual Basic (Declaration)

Property Width As System.Integer

Visual Basic (Usage)



```
Dim instance As ILayer
Dim value As System.Integer

instance.Width = value
value = instance.Width
```

C#

```
System.int Width {get; set;}
```

C++/CLI

```
property System.int Width {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Line width as defined in [swLineWeights_e](#)

Visual Basic for Applications (VBA) Syntax

See [Layer::Width](#).

Example

[Get Layers \(C#\)](#)
[Get Layers \(VB.NET\)](#)
[Get Layers \(VBA\)](#)

See Also

[ILayer Interface](#)
[ILayer Members](#)

Availability

SOLIDWORKS 99, datecode 1999207