

SOLIDWORKS API (.NET VBA C#) — Reference

(140/337): ILayerMgr-ILibraryFeatureData

SOLIDWORKS API Documentation (converted from CHM)

ILayerMgr (Type)

ILayerMgr Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILayerMgr Interface

Allows you to manage a drawing document's layers.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ILayerMgr
```

Visual Basic (Usage)

```
Dim instance As ILayerMgr
```

C#

```
public interface ILayerMgr
```

C++/CLI

```
public interface class ILayerMgr
```

Visual Basic for Applications (VBA) Syntax

See [LayerMgr](#).

Example

[Get Layers \(C#\)](#)
[Get Layers \(VB.NET\)](#)
[Get Layers \(VBA\)](#)

Remarks

Each drawing document has its own ILayerMgr object and its own [ILayer](#) objects. The ILayerMgr interface provides functions that allow you to manipulate and work with individual layers. This includes adding layers, setting the current layer, obtaining specific layers, etc.

Layers are only supported in SOLIDWORKS drawing documents.

Accessors

[IModelDoc2::GetLayerManager](#) and [IModelDoc2::IGetLayerManager](#)

Access Diagram

[LayerMgr](#)

See Also

[ILayerMgr Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDrawingDoc Interface](#)

ILayerMgr Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILayerMgr Interface

For a list of all members of this type, see [ILayerMgr members](#).

Public Methods

Name	Description
 AddLayer	Adds a layer to this drawing document.
 DeleteLayer	Deletes the specified layer in this drawing document.
 GetCount	Gets the number of layers in this drawing document.
 GetCurrentLayer	Gets the name of the current (active) layer in this drawing document.
 GetLayer	Gets the specified layer in this drawing document.
 GetLayerById	Gets the layer using the specified layer ID in this drawing document.
 GetLayerList	Gets a list of layers in this drawing document.
 IGetLayer	Gets the specified layer in this drawing document.
 IGetLayerById	Gets the layer using the specified layer ID in this drawing document.
 IGetLayerList	Gets a list of layers in this drawing document.
 SetCurrentLayer	Sets the current (or active) layer in this drawing document.

[Top](#)

See Also

[ILayerMgr Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDrawingDoc Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ILayerMgr Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILayerMgr Interface

The following tables list the members exposed by [ILayerMgr](#).

Public Methods

Name	Description
 AddLayer	Adds a layer to this drawing document.
 DeleteLayer	Deletes the specified layer in this drawing document.
 GetCount	Gets the number of layers in this drawing document.
 GetCurrentLayer	Gets the name of the current (active) layer in this drawing document.
 GetLayer	Gets the specified layer in this drawing document.
 GetLayerById	Gets the layer using the specified layer ID in this drawing document.
 GetLayerList	Gets a list of layers in this drawing document.
 IGetLayer	Gets the specified layer in this drawing document.
 IGetLayerById	Gets the layer using the specified layer ID in this drawing document.
 IGetLayerList	Gets a list of layers in this drawing document.
 SetCurrentLayer	Sets the current (or active) layer in this drawing document.

[Top](#)

See Also

[ILayerMgr Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDrawingDoc Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddLayer Method (ILayerMgr)

[See Also](#)



Adds a layer to this drawing document.

.NET Syntax

Visual Basic (Declaration)

```
Function AddLayer( _  
    ByVal NameIn As System.String, _  
    ByVal DescIn As System.String, _  
    ByVal ColorIn As System.Integer, _  
    ByVal StyleIn As System.Integer, _  
    ByVal WidthIn As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILayerMgr  
Dim NameIn As System.String  
Dim DescIn As System.String  
Dim ColorIn As System.Integer  
Dim StyleIn As System.Integer  
Dim WidthIn As System.Integer  
Dim value As System.Integer  
  
value = instance.AddLayer(NameIn, DescIn, ColorIn, StyleIn, WidthIn)
```

C#

```
System.int AddLayer(  
    System.string NameIn,  
    System.string DescIn,  
    System.int ColorIn,  
    System.int StyleIn,  
    System.int WidthIn  
)
```

C++/CLI

```
System.int AddLayer(  
& System.String^ NameIn,  
& System.String^ DescIn,  
& System.int ColorIn,  
& System.int StyleIn,  
& System.int WidthIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NameIn

Layer name

DescIn

Description for the new layer

ColorIn

COLORREF value specifying the desired color of items within this layer

StyleIn

Line style as defined in [swLineStyles_e](#)

WidthIn

Line width as defined in [swLineWeights_e](#)

Return Value

1 if the layer was created successfully

Visual Basic for Applications (VBA) Syntax

See [LayerMgr.AddLayer](#).

See Also

[ILayerMgr Interface](#)
[ILayerMgr Members](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments](#) on this topic.

DeleteLayer Method (ILayerMgr)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILayerMgr Interface](#) : DeleteLayer Method (ILayerMgr)

Deletes the specified layer in this drawing document.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteLayer( _  
    ByVal Name As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILayerMgr  
Dim Name As System.String  
Dim value As System.Boolean  
  
value = instance.DeleteLayer(Name)
```

C#

```
System.bool DeleteLayer(  
    System.string Name  
)
```

C++/CLI

```
System.bool DeleteLayer(  
& System.String^ Name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Name of the layer to delete

Return Value

True if the layer was successfully deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [LayerMgr::DeleteLayer](#).

See Also

[ILayerMgr Interface](#)
[ILayerMgr Members](#)
[ILayerMgr::GetCurrentLayer Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

GetCount Method (ILayerMgr)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILayerMgr Interface](#) : GetCount Method (ILayerMgr)

Gets the number of layers in this drawing document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILayerMgr  
Dim value As System.Integer  
  
value = instance.GetCount()
```

C#

```
System.int GetCount()
```

C++/CLI

```
System.int GetCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of layers

Visual Basic for Applications (VBA) Syntax

See [LayerMgr::GetCount](#).

Remarks

Call this method before calling [ILayerMgr::GetLayerList](#) to determine the size of the array.

See Also

[ILayerMgr Interface](#)
[ILayerMgr Members](#)

Availability

SOLIDWORKS 99, datecode 1999207

GetCurrentLayer Method (ILayerMgr)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILayerMgr Interface](#) : GetCurrentLayer Method (ILayerMgr)

Gets the name of the current (active) layer in this drawing document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCurrentLayer() As System.String
```

Visual Basic (Usage)



```
Dim instance As ILayerMgr
Dim value As System.String

value = instance.GetCurrentLayer()
```

C#

```
System.string GetCurrentLayer()
```

C++/CLI

```
System.String^ GetCurrentLayer();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Name of the active layer

Visual Basic for Applications (VBA) Syntax

See [LayerMgr::GetCurrentLayer](#).

Example

[Get Layers \(VBA\)](#)

Remarks

If an empty string is returned, then there is no active layer and **-None-** is displayed in the Layer toolbar.

To access information about a layer, get the [ILayer](#) object by passing the layer name to [ILayerMgr::GetLayer](#).

To change the currently active layer, use [ILayerMgr::SetCurrentLayer](#).

See Also

[ILayerMgr Interface](#)
[ILayerMgr Members](#)
[ILayerMgr::SetCurrentLayer Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLayer Method (ILayerMgr)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILayerMgr Interface](#) : GetLayer Method (ILayerMgr)

Gets the specified layer in this drawing document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLayer( _  
    ByVal NameIn As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILayerMgr
Dim NameIn As System.String
Dim value As System.Object

value = instance.GetLayer(NameIn)
```

C#

```
System.Object GetLayer(
    System.string NameIn
)
```

C++/CLI

```
System.Object^ GetLayer(
    & System.String^ NameIn
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NameIn
Layer name

Return Value

Layer

Visual Basic for Applications (VBA) Syntax

See [LayerMgr::GetLayer](#).

Example

[Determine If Layer Is Visible \(VBA\)](#)
[Get Layers \(C#\)](#)
[Get Layers \(VB.NET\)](#)
[Get Layers \(VBA\)](#)

Remarks

You can get the layer name by calling [ILayerMgr::GetCurrentLayer](#), create a new layer calling [ILayerMgr::AddLayer](#), or obtain a list of layer names by calling [ILayerMgr::GetLayerList](#).

See Also

[ILayerMgr Interface](#)
[ILayerMgr Members](#)
[ILayerMgr::IGetLayer Method](#)

Availability

SOLIDWORKS 99, Revision Number 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLayerById Method (ILayerMgr)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILayerMgr Interface](#) : GetLayerById Method (ILayerMgr)

Gets the layer using the specified layer ID in this drawing document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLayerById( _
    ByVal LayerId As System.Short _
```

```
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILayerMgr  
Dim LayerId As System.Short  
Dim value As System.Object  
  
value = instance.GetLayerById(LayerId)
```

C#

```
System.object GetLayerById(  
    System.short LayerId  
)
```

C++/CLI

```
System.Object^ GetLayerById(  
&    System.short LayerId  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

LayerId
Layer ID

Return Value

Layer

Visual Basic for Applications (VBA) Syntax

See [LayerMgr::GetLayerById](#).

Remarks

You can get the layer ID from several places. [IView::GetUserPoints2](#) and [IView::GetLines4](#) (and similar functions) return the LayerId as part of the array of return information. [IAnnotation::GetVisualProperties](#) also returns the LayerId as part of the array of return information.

See Also

[ILayerMgr Interface](#)
[ILayerMgr Members](#)
[ILayerMgr::IGetLayerById Method](#)

Availability

SOLIDWORKS 99 SP7, datecode 2000004

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLayerList Method (ILayerMgr)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILayerMgr Interface](#) : GetLayerList Method (ILayerMgr)

Gets a list of layers in this drawing document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLayerList() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILayerMgr
Dim value As System.Object

value = instance.GetLayerList()
```

C#

```
System.Object GetLayerList()
```

C++/CLI

```
System.Object^ GetLayerList();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of strings containing the name of each [ILayer](#) object in this [ILayerMgr](#) object

Visual Basic for Applications (VBA) Syntax

See [LayerMgr::GetLayerList](#).

Example

[Get Layers \(C#\)](#)
[Get Layers \(VB.NET\)](#)
[Get Layers \(VBA\)](#)

Remarks

This is a 0-based array (first element is at position 0).

See Also

[ILayerMgr Interface](#)
[ILayerMgr Members](#)
[ILayerMgr::IGetLayerList Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetLayer Method (ILayerMgr)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILayerMgr Interface](#) : IGetLayer Method (ILayerMgr)

Gets the specified layer in this drawing document.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetLayer( _
    ByVal NameIn As System.String _
) As Layer
```

Visual Basic (Usage)



```
Dim instance As ILayerMgr
Dim NameIn As System.String
Dim value As Layer

value = instance.IGetLayer(NameIn)
```

C#

```
Layer IGetLayer(  
    System.string NameIn  
)
```

C++/CLI

```
Layer^ IGetLayer(  
& System.String^ NameIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NameIn
Layer name

Return Value

[ILayer](#) object

Visual Basic for Applications (VBA) Syntax

See [LayerMgr::IGetLayer](#).

Remarks

You can get the layer name by calling [ILayerMgr::GetCurrentLayer](#), create a new layer calling [ILayerMgr::AddLayer](#), or obtain a list of layer names by calling [ILayerMgr::IGetLayerList](#).

See Also

[ILayerMgr Interface](#)
[ILayerMgr Members](#)
[ILayerMgr::GetLayer Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetLayerById Method (ILayerMgr)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILayerMgr Interface](#) : IGetLayerById Method (ILayerMgr)

Gets the layer using the specified layer ID in this drawing document.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetLayerById( _  
    ByVal LayerId As System.Short _  
) As Layer
```

Visual Basic (Usage)



```
Dim instance As ILayerMgr  
Dim LayerId As System.Short  
Dim value As Layer
```

```
value = instance.IGetLayerById(LayerId)
```

C#

```
Layer IGetLayerById(  
    System.short LayerId  
)
```

C++/CLI

```
Layer^ IGetLayerById(  
& System.short LayerId  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

LayerId
Layer ID

Return Value

[ILayer](#) object

Visual Basic for Applications (VBA) Syntax

See [LayerMgr::IGetLayerById](#).

Remarks

You can get the layer ID from several places. [IView::IGetUserPoints2](#) and [IView::IGetLines4](#) (and similar functions) return the LayerId as part of the array of return information. [IAnnotation::IGetVisualProperties](#) also returns the LayerId as part of the array of return information.

See Also

[ILayerMgr Interface](#)
[ILayerMgr Members](#)
[ILayerMgr::GetLayerById Method](#)

Availability

SOLIDWORKS 99 SP7, datecode 2000004

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetLayerList Method (ILayerMgr)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILayerMgr Interface](#) : IGetLayerList Method (ILayerMgr)

Gets a list of layers in this drawing document.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetLayerList() As System.String
```

Visual Basic (Usage)



```
Dim instance As ILayerMgr  
Dim value As System.String  
  
value = instance.IGetLayerList()
```

C#

```
System.string IGetLayerList()
```

C++/CLI

```
System.String^ IGetLayerList();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of strings containing the name of each [ILayer](#) object in this [ILayerMgr](#) object
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

This is a 0-based array (first element is at position 0).

Call [ILayerMgr::GetCount](#) to determine the size of the array.

See Also

[ILayerMgr Interface](#)
[ILayerMgr Members](#)
[ILayerMgr::GetLayerList Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetCurrentLayer Method (ILayerMgr)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILayerMgr Interface](#) : SetCurrentLayer Method (ILayerMgr)

Sets the current (or active) layer in this drawing document.

.NET Syntax

Visual Basic (Declaration)

```
Function SetCurrentLayer(  
    ByVal NameIn As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILayerMgr  
Dim NameIn As System.String  
Dim value As System.Integer  
  
value = instance.SetCurrentLayer(NameIn)
```

C#

```
System.int SetCurrentLayer(  
    System.string NameIn  
)
```

C++/CLI

```
System.int SetCurrentLayer(  
    & System.String^ NameIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NameIn

Name of the layer to become the active layer

Return Value

1 if the active layer was changed to the specified layer, 0 if not

Visual Basic for Applications (VBA) Syntax

See [LayerMgr::SetCurrentLayer](#).

See Also

[ILayerMgr Interface](#)
[ILayerMgr Members](#)
[ILayerMgr::GetCurrentLayer Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

ILibraryFeatureData (Type)

ILibraryFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILibraryFeatureData Interface

Allows access to library feature data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ILibraryFeatureData
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData
```

C#

```
public interface ILibraryFeatureData
```

C++/CLI

```
public interface class ILibraryFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [LibraryFeatureData](#).

Example

[Get Library Feature Data \(VBA\)](#)
[Get Library Feature Data \(VB.NET\)](#)
[Get Library Feature Data \(C#\)](#)

Remarks

See [Library Features and LibraryFeatureData Objects](#).

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

[IFeatureManager::CreateDefinition](#)

Access Diagram

[LibraryFeatureData](#)

See Also

[ILibraryFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ILibraryFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILibraryFeatureData Interface

The following tables list the members exposed by [ILibraryFeatureData](#).

Public Properties

Name	Description
 ConfigurationName	Gets or sets the name of the active library feature configuration.
 LibraryPart	Gets the path and filename of the library feature.
 LinkToLibraryPart	Gets or sets whether to link the library feature to its parent library feature document.
 OverrideDimension	Gets or sets whether to override the existing size dimension values of the library feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to selections that define this library feature.
 GetAllConfigurationNames	Gets the names of the library feature configurations.
 GetConfigurationCount	Gets the number of library feature configurations.
 GetDimensions	Gets the names and values of the specified type of dimension for this library feature.
 GetDimensionsCount	Gets the number of dimensions of the specified type for this library feature.
 GetPlacementPlane	Obsolete. Superseded by ILibraryFeatureData.GetPlacementPlane2 .
 GetPlacementPlane2	Gets the face or plane on which the library feature was placed.
 GetReferences	Obsolete. Superseded by ILibraryFeatureData.GetReferences2 .
 GetReferences2	Obsolete. Superseded by ILibraryFeatureData.GetReferences3 .
 GetReferences3	Gets the references with respect to the specified scope.
 GetReferencesCount	Gets the number of references for the library feature.
 IGetAllConfigurationNames	Gets the names of the library feature configurations.
 IGetDimensions	Gets the names and values of the specified type of dimension for this library feature.
 IGetReferences	Obsolete. Superseded by ILibraryFeatureData.IGetReferences2 .
 IGetReferences2	Obsolete. Superseded by ILibraryFeatureData.IGetReferences3 .
 IGetReferences3	Gets the references with respect to the specified scope.
 Initialize	Initializes a newly created library feature using the specified library part.
 ISetReferences	Sets the references for the library feature.
 ReleaseSelectionAccess	Releases access to the selections that created this library feature.
 SetDimension	Sets a dimension's type, name, and value for the library feature.
 SetPlacementPlane	Sets the face or plane on which to place the library feature.
 SetReferences	Sets the references for the library feature.

[Top](#)

See Also

[ILibraryFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ILibraryFeatureData Interface Methods

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : [ILibraryFeatureData Interface](#)

For a list of all members of this type, see [ILibraryFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to selections that define this library feature.
 GetAllConfigurationNames	Gets the names of the library feature configurations.
 GetConfigurationCount	Gets the number of library feature configurations.
 GetDimensions	Gets the names and values of the specified type of dimension for this library feature.
 GetDimensionsCount	Gets the number of dimensions of the specified type for this library feature.
 GetPlacementPlane	Obsolete. Superseded by ILibraryFeatureData.GetPlacementPlane2 .
 GetPlacementPlane2	Gets the face or plane on which the library feature was placed.
 GetReferences	Obsolete. Superseded by ILibraryFeatureData.GetReferences2 .
 GetReferences2	Obsolete. Superseded by ILibraryFeatureData.GetReferences3 .
 GetReferences3	Gets the references with respect to the specified scope.
 GetReferencesCount	Gets the number of references for the library feature.
 IGetAllConfigurationNames	Gets the names of the library feature configurations.
 IGetDimensions	Gets the names and values of the specified type of dimension for this library feature.
 IGetReferences	Obsolete. Superseded by ILibraryFeatureData.IGetReferences2 .
 IGetReferences2	Obsolete. Superseded by ILibraryFeatureData.IGetReferences3 .
 IGetReferences3	Gets the references with respect to the specified scope.
 Initialize	Initializes a newly created library feature using the specified library part.
 ISetReferences	Sets the references for the library feature.
 ReleaseSelectionAccess	Releases access to the selections that created this library feature.
 SetDimension	Sets a dimension's type, name, and value for the library feature.
 SetPlacementPlane	Sets the face or plane on which to place the library feature.
 SetReferences	Sets the references for the library feature.

[Top](#)

See Also

[ILibraryFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ILibraryFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : [ILibraryFeatureData Interface](#)

For a list of all members of this type, see [ILibraryFeatureData members](#).

Public Properties

Name	Description
 ConfigurationName	Gets or sets the name of the active library feature configuration.
 LibraryPart	Gets the path and filename of the library feature.
 LinkToLibraryPart	Gets or sets whether to link the library feature to its parent library feature document.
 OverrideDimension	Gets or sets whether to override the existing size dimension values of the library feature.

[Top](#)

See Also

[ILibraryFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (ILibraryFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : AccessSelections Method (ILibraryFeatureData)

Gains access to selections that define this library feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal PTopDoc As ModelDoc2, _  
    ByVal PComponent As Component2 _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData  
Dim PTopDoc As ModelDoc2  
Dim PComponent As Component2  
Dim value As System.Boolean  
  
value = instance.AccessSelections(PTopDoc, PComponent)
```

C#

```
System.bool AccessSelections(  
    ModelDoc2 PTopDoc,  
    Component2 PComponent  
)
```

C++/CLI

```
System.bool AccessSelections(  
& ModelDoc2^ PTopDoc,  
& Component2^ PComponent  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PTopDoc
Top-level document (see **Remarks**)
PComponent
Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [LibraryFeatureData::AccessSelections](#).

Example

[Get Library Feature Data \(VBA\)](#)
[Get Library Feature Data \(VB.NET\)](#)
[Get Library Feature Data \(C#\)](#)

Remarks

To modify a feature in a...	Then...
Part	- PTopDoc argument is the IModelDoc2 for the part - PComponent argument is NULL
Assembly	- PTopDoc is the IModelDoc2 object for the assembly - PComponent argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ILibraryFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ILibraryFeatureData Interface](#)
[ILibraryFeatureData Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ConfigurationName Property (ILibraryFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : ConfigurationName Property (ILibraryFeatureData)

Gets or sets the name of the active library feature configuration.

.NET Syntax

Visual Basic (Declaration)

```
Property ConfigurationName As System.String
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData  
Dim value As System.String
```

```
instance.ConfigurationName = value
```

```
value = instance.ConfigurationName
```

C#

```
System.string ConfigurationName {get; set;}
```

C++/CLI

```
property System.String^ ConfigurationName {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of active library feature configuration

Visual Basic for Applications (VBA) Syntax

See [LibraryFeatureData::ConfigurationName](#).

Example

[Get Library Feature Data \(VBA\)](#)
[Get Library Feature Data \(VB.NET\)](#)
[Get Library Feature Data \(C#\)](#)

Remarks

If the size dimensions are overridden, then the get version of this property returns an empty string.

See Also

[ILibraryFeatureData Interface](#)
[ILibraryFeatureData Members](#)
[ILibraryFeatureData::GetAllConfigurationNames Method](#)

[ILibraryFeatureData::GetConfigurationCount Method](#)
[ILibraryFeatureData::IGetAllConfigurationNames Method](#)
[ILibraryFeatureData::OverrideDimension Property](#)
[ILibraryFeatureData::GetDimensions Method](#)
[ILibraryFeatureData::GetDimensionsCount Method](#)
[ILibraryFeatureData::IGetDimensions Method](#)
[ILibraryFeatureData::SetDimension Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAllConfigurationNames Method (ILibraryFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : GetAllConfigurationNames Method (ILibraryFeatureData)

Gets the names of the library feature configurations.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAllConfigurationNames() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData  
Dim value As System.Object  
  
value = instance.GetAllConfigurationNames()
```

C#

```
System.object GetAllConfigurationNames()
```

C++/CLI

```
System.Object^ GetAllConfigurationNames();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Names of the library feature configurations

Visual Basic for Applications (VBA) Syntax

See [LibraryFeatureData::GetAllConfigurationNames](#).

Example

[Get Library Feature Data \(VBA\)](#)
[Get Library Feature Data \(VB.NET\)](#)
[Get Library Feature Data \(C#\)](#)

Remarks

If the library feature part document is not open or the library feature is not linked to the library feature part, then only the name of the active library feature configuration is returned.

See Also

[ILibraryFeatureData Interface](#)
[ILibraryFeatureData Members](#)
[ILibraryFeatureData::IGetAllConfigurationNames Method](#)
[ILibraryFeatureData::GetConfigurationCount Method](#)
[ILibraryFeatureData::ConfigurationName Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

GetConfigurationCount Method (ILibraryFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : GetConfigurationCount Method (ILibraryFeatureData)

Gets the number of library feature configurations.

.NET Syntax

Visual Basic (Declaration)

```
Function GetConfigurationCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData  
Dim value As System.Integer  
  
value = instance.GetConfigurationCount()
```

C#

```
System.int GetConfigurationCount()
```

C++/CLI

```
System.int GetConfigurationCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of library feature configurations

Visual Basic for Applications (VBA) Syntax

See [LibraryFeatureData::GetConfigurationCount](#).

Remarks

Call this method before calling [ILibraryFeatureData::IGetAllConfigurationNames](#).

See Also

[ILibraryFeatureData Interface](#)
[ILibraryFeatureData Members](#)
[ILibraryFeatureData::GetAllConfigurationNames Method](#)
[ILibraryFeatureData::IGetAllConfigurationNames Method](#)
[ILibraryFeatureData::ConfigurationName Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

GetDimensions Method (ILibraryFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : GetDimensions Method (ILibraryFeatureData)

Gets the names and values of the specified type of dimension for this library feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensions(  
    ByVal Type As System.Integer, _
```

```
ByRef DimName As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData  
Dim Type As System.Integer  
Dim DimName As System.Object  
Dim value As System.Object  
  
value = instance.GetDimensions(Type, DimName)
```

C#

```
System.object GetDimensions(  
    System.int Type,  
    out System.object DimName  
)
```

C++/CLI

```
System.Object^ GetDimensions(  
& System.int Type,  
& [Out] System.Object^ DimName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Type

Type of dimension as defined in [swLibFeatDimensionType](#) e

DimName

Array of the dimension names

Return Value

Array of the values of the dimensions

Visual Basic for Applications (VBA) Syntax

See [LibraryFeatureData::GetDimensions](#).

Example

[Get Library Feature Data \(VBA\)](#)
[Get Library Feature Data \(VB.NET\)](#)
[Get Library Feature Data \(C#\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILibraryFeatureData Interface](#)
[ILibraryFeatureData Members](#)
[ILibraryFeatureData::IGetDimensions Method](#)
[ILibraryFeatureData::GetDimensionsCount Method](#)
[ILibraryFeatureData::OverrideDimension Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDimensionsCount Method (ILibraryFeatureData)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : GetDimensionsCount Method (ILibraryFeatureData)

Gets the number of dimensions of the specified type for this library feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetDimensionsCount( _  
    ByVal Type As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData  
Dim Type As System.Integer  
Dim value As System.Integer  
  
value = instance.GetDimensionsCount(Type)
```

C#

```
System.int GetDimensionsCount(  
    System.int Type  
)
```

C++/CLI

```
System.int GetDimensionsCount(  
& System.int Type  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Type

Type of dimension as defined in [swLibraryFeatDimensionType_e](#)

Return Value

Number of dimensions

Visual Basic for Applications (VBA) Syntax

See [LibraryFeatureData::GetDimensionsCount](#).

Example

[Get Library Feature Data \(VBA\)](#)
[Get Library Feature Data \(VB.NET\)](#)
[Get Library Feature Data \(C#\)](#)

Remarks

Call this method before calling [ILibraryFeatureData::GetDimensions](#) to determine the size of the array.

See Also

[ILibraryFeatureData Interface](#)
[ILibraryFeatureData Members](#)
[ILibraryFeatureData::GetDimensions Method](#)
[ILibraryFeatureData::OverrideDimension Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetPlacementPlane Method (ILibraryFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : GetPlacementPlane Method (ILibraryFeatureData)

Obsolete. Superseded by [ILibraryFeatureData::GetPlacementPlane2](#).

■ .NET Syntax

Visual Basic (Declaration)

```
Function GetPlacementPlane( _  
    ByRef Type As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData  
Dim Type As System.Integer  
Dim value As System.Object  
  
value = instance.GetPlacementPlane(Type)
```

C#

```
System.object GetPlacementPlane(  
    out System.int Type  
)
```

C++/CLI

```
System.Object^ GetPlacementPlane(  
& [Out] System.int Type  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Type

Placement type as defined in [swSelectType_e](#)

Return Value

[Face](#) or [plane](#)

■ Visual Basic for Applications (VBA) Syntax

See [LibraryFeatureData::GetPlacementPlane](#).

■ Example

[Get Library Feature Data \(VBA\)](#)

■ Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

■ See Also

[ILibraryFeatureData Interface](#)

[ILibraryFeatureData Members](#)

[ILibraryFeatureData::SetPlacementPlane Method](#)

■ Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPlacementPlane2 Method (ILibraryFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : GetPlacementPlane2 Method (ILibraryFeatureData)

Gets the face or plane on which the library feature was placed.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPlacementPlane2( _  
    ByVal Scope As System.Integer, _  
    ByRef Type As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData  
Dim Scope As System.Integer  
Dim Type As System.Integer  
Dim value As System.Object  
  
value = instance.GetPlacementPlane2(Scope, Type)
```

C#

```
System.Object GetPlacementPlane2(  
    System.int Scope,  
    out System.int Type  
)
```

C++/CLI

```
System.Object^ GetPlacementPlane2(  
& System.int Scope,  
& [Out] System.int Type  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Scope

Placement scope as defined in [swLibFeatureData_e](#)

Type

Placement type as defined in [swSelectType_e](#)

Return Value

[Face](#) or [plane](#)

Visual Basic for Applications (VBA) Syntax

See [LibraryFeatureData::GetPlacementPlane2](#).

Example

[Get Library Feature Data \(VBA\)](#)
[Get Library Feature Data \(VB.NET\)](#)
[Get Library Feature Data \(C#\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILibraryFeatureData Interface](#)
[ILibraryFeatureData Members](#)
[ILibraryFeatureData::SetPlacementPlane Method](#)

Availability

SOLIDWORKS 2010 SP1, Revision Number 18.1

GetReferences Method (ILibraryFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : GetReferences Method (ILibraryFeatureData)

Obsolete. Superseded by [ILibraryFeatureData::GetReferences2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetReferences( _  
    ByRef RefType As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData  
Dim RefType As System.Object  
Dim value As System.Object  
  
value = instance.GetReferences(RefType)
```

C#

```
System.object GetReferences(  
    out System.object RefType  
)
```

C++/CLI

```
System.Object^ GetReferences(  
& [Out] System.Object^ RefType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RefType

Array of reference types as defined by [swSelectType_e](#)

Return Value

Array of references

Visual Basic for Applications (VBA) Syntax

See [LibraryFeatureData::GetReferences](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILibraryFeatureData Interface](#)
[ILibraryFeatureData Members](#)
[ILibraryFeatureData::GetReferencesCount Method](#)
[ILibraryFeatureData::!GetReferences Method](#)
[ILibraryFeatureData::SetReferences Method](#)
[ILibraryFeatureData::!SetReferences Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : GetReferences2 Method (ILibraryFeatureData)

Obsolete. Superseded by [ILibraryFeatureData::GetReferences3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetReferences2(  
    ByVal Scope As System.Integer, _  
    ByRef RefType As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData  
Dim Scope As System.Integer  
Dim RefType As System.Object  
Dim value As System.Object  
  
value = instance.GetReferences2(Scope, RefType)
```

C#

```
System.object GetReferences2(  
    System.int Scope,  
    out System.object RefType  
)
```

C++/CLI

```
System.Object^ GetReferences2(  
& System.int Scope,  
& [Out] System.Object^ RefType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Scope

Reference scope as defined in [swLibFeatureData_e](#)

RefType

Array of reference types as defined by [swSelectType_e](#)

Return Value

Array of references

Visual Basic for Applications (VBA) Syntax

See [LibraryFeatureData::GetReferences2](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILibraryFeatureData Interface](#)

[ILibraryFeatureData Members](#)

[ILibraryFeatureData::IGetReferences2 Method](#)

[ILibraryFeatureData::SetReferences Method](#)

[ILibraryFeatureData::ISetReferences Method](#)

Availability

SOLIDWORKS 2010 SP1, Revision Number 18.1

GetReferences3 Method (ILibraryFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : GetReferences3 Method (ILibraryFeatureData)

Gets the references with respect to the specified scope.

.NET Syntax

Visual Basic (Declaration)

```

Function GetReferences3( _
    ByVal Scope As System.Integer, _
    ByRef RefType As System.Object, _
    ByRef RefName As System.Object _
) As System.Object

```

Visual Basic (Usage)



```

Dim instance As ILibraryFeatureData
Dim Scope As System.Integer
Dim RefType As System.Object
Dim RefName As System.Object
Dim value As System.Object

value = instance.GetReferences3(Scope, RefType, RefName)

```

C#

```

System.object GetReferences3(
    System.int Scope,
    out System.object RefType,
    out System.object RefName
)

```

C++/CLI

```

System.Object^ GetReferences3(
    & System.int Scope,
    & [Out] System.Object^ RefType,
    & [Out] System.Object^ RefName
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Scope

Reference scope as defined in [swLibFeatureData_e](#)

RefType

Array of reference types as defined by [swSelectType_e](#)

RefName

Array of reference names

Return Value

Array of references

Visual Basic for Applications (VBA) Syntax

See [LibraryFeatureData::GetReferences3](#).

Example

[Get Library Feature Data \(VBA\)](#)
[Get Library Feature Data \(VB.NET\)](#)
[Get Library Feature Data \(C#\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILibraryFeatureData Interface](#)
[ILibraryFeatureData Members](#)
[ILibraryFeatureData::SetReferences Method \(\)](#)
[ILibraryFeatureData::!SetReferences Method \(\)](#)
[ILibraryFeatureData::!GetReferences3 Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetReferencesCount Method (ILibraryFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : GetReferencesCount Method (ILibraryFeatureData)

Gets the number of references for the library feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetReferencesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData  
Dim value As System.Integer  
  
value = instance.GetReferencesCount()
```

C#

```
System.int GetReferencesCount()
```

C++/CLI

```
System.int GetReferencesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of references

Visual Basic for Applications (VBA) Syntax

See [LibraryFeatureData::GetReferencesCount](#).

Example

[Get Library Feature Data \(VBA\)](#)
[Get Library Feature Data \(VB.NET\)](#)
[Get Library Feature Data \(C#\)](#)

Remarks

Call this method before calling [ILibraryFeatureData::!GetReferences](#).

See Also

[ILibraryFeatureData Interface](#)
[ILibraryFeatureData Members](#)
[ILibraryFeatureData::GetReferences Method](#)
[ILibraryFeatureData::!SetReferences Method](#)
[ILibraryFeatureData::SetReferences Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetAllConfigurationNames Method (ILibraryFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : IGetAllConfigurationNames Method (ILibraryFeatureData)

Gets the names of the library feature configurations.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetAllConfigurationNames( _  
    ByVal Count As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData  
Dim Count As System.Integer  
Dim value As System.String  
  
value = instance.IGetAllConfigurationNames(Count)
```

C#

```
System.string IGetAllConfigurationNames(  
    System.int Count  
)
```

C++/CLI

```
System.String^ IGetAllConfigurationNames(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of library configurations

Return Value

- in-process, unmanaged C++: Pointer to an array of strings of the names of the library feature configurations
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [ILibraryFeatureData::GetConfigurationCount](#) to determine the size of the array.

If the library feature part document is not open or the library feature is not linked to the library feature part, then only the name of the active library feature configuration is returned.

See Also

[ILibraryFeatureData Interface](#)
[ILibraryFeatureData Members](#)
[ILibraryFeatureData::GetAllConfigurationNames Method](#)
[ILibraryFeatureData::ConfigurationName Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

IGetDimensions Method (ILibraryFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : IGetDimensions Method (ILibraryFeatureData)

Gets the names and values of the specified type of dimension for this library feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDimensions( _
    ByVal Type As System.Integer, _
    ByVal Count As System.Integer, _
    ByRef DimName As System.String _
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData
Dim Type As System.Integer
Dim Count As System.Integer
Dim DimName As System.String
Dim value As System.Double

value = instance.IGetDimensions(Type, Count, DimName)
```

C#

```
System.double IGetDimensions(
    System.int Type,
    System.int Count,
    out System.string DimName
)
```

C++/CLI

```
System.double IGetDimensions(
    & System.int Type,
    & System.int Count,
    & [Out] System.String^ DimName
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Type

Type of dimension as defined in [swLibraryFeatDimensionType_e](#)

Count

Number of dimensions

DimName

- in-process, unmanaged C++: Pointer to an array of dimension names

- VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Return Value

- in-process, unmanaged C++: Pointer to an array of dimension values

- VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [ILibraryFeatureData::GetDimensionsCount](#) to determine the size of the array.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILibraryFeatureData Interface](#)
[ILibraryFeatureData Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetReferences Method (ILibraryFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : IGetReferences Method (ILibraryFeatureData)

Obsolete. Superseded by [ILibraryFeatureData::IGetReferences2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetReferences( _  
    ByVal Count As System.Integer, _  
    ByRef RefType As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData  
Dim Count As System.Integer  
Dim RefType As System.Integer  
Dim value As System.Object  
  
value = instance.IGetReferences(Count, RefType)
```

C#

```
System.object IGetReferences(  
    System.int Count,  
    out System.int RefType  
)
```

C++/CLI

```
System.Object^ IGetReferences(  
    & System.int Count,  
    & [Out] System.int RefType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of references

RefType

- in-process, unmanaged C++: Pointer to an array of type long of reference types as defined by [swSelectType_e](#)

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

- in-process, unmanaged C++: Pointer to an array of references

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [ILibraryFeatureData::GetReferencesCount](#) to determine the size of the array.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILibraryFeatureData Interface](#)
[ILibraryFeatureData Members](#)
[ILibraryFeatureData::GetReferences Method](#)
[ILibraryFeatureData::SetReferences Method](#)
[ILibraryFeatureData::ISetReferences Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetReferences2 Method (ILibraryFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : IGetReferences2 Method (ILibraryFeatureData)

Obsolete. Superseded by [ILibraryFeatureData::IGetReferences3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetReferences2( _  
    ByVal Scope As System.Integer, _  
    ByVal Count As System.Integer, _  
    ByRef RefType As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData  
Dim Scope As System.Integer  
Dim Count As System.Integer  
Dim RefType As System.Integer  
Dim value As System.Object  
  
value = instance.IGetReferences2(Scope, Count, RefType)
```

C#

```
System.object IGetReferences2(  
    System.int Scope,  
    System.int Count,  
    out System.int RefType  
)
```

C++/CLI

```
System.Object^ IGetReferences2(  
& System.int Scope,  
& System.int Count,  
& [Out] System.int RefType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Scope

Reference scope as defined in [swLibFeatureData_e](#)

Count

Number of references

RefType

- in-process, unmanaged C++: Pointer to an array of type long of reference types as defined by [swSelectType_e](#)

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

- in-process, unmanaged C++: Pointer to an array of references

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [ILibraryFeatureData::GetReferencesCount](#) to determine the size of the array.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILibraryFeatureData Interface](#)
[ILibraryFeatureData Members](#)
[ILibraryFeatureData::GetReferences2 Method](#)
[ILibraryFeatureData::SetReferences Method](#)
[ILibraryFeatureData::ISetReferences Method](#)

Availability

SOLIDWORKS 2010 SP1, Revision Number 18.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetReferences3 Method (ILibraryFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : IGetReferences3 Method (ILibraryFeatureData)

Gets the references with respect to the specified scope.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetReferences3( _  
    ByVal Scope As System.Integer, _  
    ByVal Count As System.Integer, _  
    ByRef RefType As System.Integer, _  
    ByRef RefName As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData  
Dim Scope As System.Integer  
Dim Count As System.Integer  
Dim RefType As System.Integer  
Dim RefName As System.String  
Dim value As System.Object  
  
value = instance.IGetReferences3(Scope, Count, RefType, RefName)
```

C#

```
System.object IGetReferences3(  
    System.int Scope,  
    System.int Count,  
    out System.int RefType,  
    out System.string RefName  
)
```

C++/CLI

```
System.Object^ IGetReferences3(  
& System.int Scope,  
& System.int Count,  
& [Out] System.int RefType,  
& [Out] System.String^ RefName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Scope
Reference scope as defined in [swLibFeatureData_e](#)
Count
Number of references

RefType

- In-process, unmanaged C++: Pointer to an array of type long of reference types as defined by [swSelectType_e](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

RefName

- In-process, unmanaged C++: Pointer to an array of reference names
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

- In-process, unmanaged C++: Pointer to an array of references
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [ILibraryFeatureData::GetReferencesCount](#) to determine the size of the array.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILibraryFeatureData Interface](#)
[ILibraryFeatureData Members](#)
[ILibraryFeatureData::GetReferences3 Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Initialize Method (ILibraryFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : Initialize Method (ILibraryFeatureData)

Initializes a newly created library feature using the specified library part.

.NET Syntax

Visual Basic (Declaration)

```
Function Initialize(  
    ByVal FileNameIn As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData  
Dim FileNameIn As System.String  
Dim value As System.Boolean  
  
value = instance.Initialize(FileNameIn)
```

C#

```
System.bool Initialize(  
    System.string FileNameIn  
)
```

C++/CLI

```
System.bool Initialize(  
& System.String^ FileNameIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileNameIn

Path and filename of the library part

Return Value

True if the library feature is initialized, false if not

Visual Basic for Applications (VBA) Syntax

See [LibraryFeatureData::Initialize](#).

Example

[Create Library Feature With References \(C#\)](#)
[Create Library Feature With References \(VB.NET\)](#)
[Create Library Feature With References \(VBA\)](#)

See Also

[ILibraryFeatureData Interface](#)
[ILibraryFeatureData Members](#)
[ILibraryFeatureData::LibraryPart Property](#)
[ILibraryFeatureData::LinkToLibraryPart Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetReferences Method (ILibraryFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : ISetReferences Method (ILibraryFeatureData)

Sets the references for the library feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetReferences( _  
    ByVal Count As System.Integer, _  
    ByRef RefVar As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData  
Dim Count As System.Integer  
Dim RefVar As System.Object  
  
instance.ISetReferences(Count, RefVar)
```

C#

```
void ISetReferences(  
    System.int Count,  
    ref System.object RefVar  
)
```

C++/CLI

```
void ISetReferences(  
& System.int Count,  
& System.Object^% RefVar  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of references

RefVar

- in-process, unmanaged C++: Pointer to an array of references

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILibraryFeatureData Interface](#)

[ILibraryFeatureData Members](#)

[ILibraryFeatureData::GetReferences Method](#)

[ILibraryFeatureData::GetReferencesCount Method](#)

[ILibraryFeatureData::IGetReferences Method](#)

[ILibraryFeatureData::SetReferences Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LibraryPart Property (ILibraryFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : LibraryPart Property (ILibraryFeatureData)

Gets the path and filename of the library feature.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property LibraryPart As System.String
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData
```

```
Dim value As System.String
```

```
value = instance.LibraryPart
```

C#

```
System.string LibraryPart {get;}
```

C++/CLI

```
property System.String^ LibraryPart {  
    System.String^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path and filename of the library feature

Visual Basic for Applications (VBA) Syntax

See [LibraryFeatureData::LibraryPart](#).

See Also

[ILibraryFeatureData Interface](#)

[ILibraryFeatureData Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

LinkToLibraryPart Property (ILibraryFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : LinkToLibraryPart Property (ILibraryFeatureData)

Gets or sets whether to link the library feature to its parent library feature document.

.NET Syntax

Visual Basic (Declaration)

Property LinkToLibraryPart As System.Boolean

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData  
Dim value As System.Boolean
```

```
instance.LinkToLibraryPart = value
```

```
value = instance.LinkToLibraryPart
```

C#

```
System.bool LinkToLibraryPart {get; set;}
```

C++/CLI

```
property System.bool LinkToLibraryPart {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to link the library feature to its parent library feature document, false to not

Visual Basic for Applications (VBA) Syntax

See [LibraryFeatureData::LinkToLibraryPart](#).

Example

[Get Library Feature Data \(VBA\)](#)
[Get Library Feature Data \(VB.NET\)](#)
[Get Library Feature Data \(C#\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILibraryFeatureData Interface](#)
[ILibraryFeatureData Members](#)
[ILibraryFeatureData::LibraryPart Property](#)
[ILibraryFeatureData::Initialize Method](#)

Availability

OverrideDimension Property (ILibraryFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : OverrideDimension Property (ILibraryFeatureData)

Gets or sets whether to override the existing size dimension values of the library feature.

.NET Syntax

Visual Basic (Declaration)

Property OverrideDimension As System.Boolean

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData
Dim value As System.Boolean
```

```
instance.OverrideDimension = value
```

```
value = instance.OverrideDimension
```

C#

```
System.bool OverrideDimension {get; set;}
```

C++/CLI

```
property System.bool OverrideDimension {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override the existing size dimensions values of the library feature, false to not

Visual Basic for Applications (VBA) Syntax

See [LibraryFeatureData::OverrideDimension](#).

Example

[Get Library Feature Data \(VBA\)](#)
[Get Library Feature Data \(VB.NET\)](#)
[Get Library Feature Data \(C#\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILibraryFeatureData Interface](#)
[ILibraryFeatureData Members](#)
[ILibraryFeatureData::GetDimensions Method](#)
[ILibraryFeatureData::GetDimensionsCount Method](#)
[ILibraryFeatureData::IGetDimensions Method](#)
[ILibraryFeatureData::SetDimension Method](#)
[ILibraryFeatureData::ConfigurationName Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

ReleaseSelectionAccess Method (ILibraryFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : ReleaseSelectionAccess Method (ILibraryFeatureData)

Releases access to the selections that created this library feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [LibraryFeatureData::ReleaseSelectionAccess](#).

Example

[Get Library Feature Data \(VBA\)](#)
[Get Library Feature Data \(VB.NET\)](#)
[Get Library Feature Data \(C#\)](#)

Remarks

[ILibraryFeatureData::AccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did.

See Also

[ILibraryFeatureData Interface](#)
[ILibraryFeatureData Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetDimension Method (ILibraryFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : SetDimension Method (ILibraryFeatureData)

Sets a dimension's type, name, and value for the library feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetDimension( _
    ByVal Type As System.Integer, _
    ByVal DimName As System.String, _
    ByVal DimVal As System.Double _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData
Dim Type As System.Integer
Dim DimName As System.String
Dim DimVal As System.Double
Dim value As System.Boolean

value = instance.SetDimension(Type, DimName, DimVal)
```

C#

```
System.bool SetDimension(
    System.int Type,
    System.string DimName,
    System.double DimVal
)
```

C++/CLI

```
System.bool SetDimension(
    & System.int Type,
    & System.String^ DimName,
    & System.double DimVal
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Type
Type of dimension as defined in [swLibFeatDimensionType_e](#)
DimName
Name of dimension
DimVal
Name of dimension

Return Value

True is the dimension is set, false if not

Visual Basic for Applications (VBA) Syntax

See [LibraryFeatureData::SetDimension](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILibraryFeatureData Interface](#)
[ILibraryFeatureData Members](#)
[ILibraryFeatureData::GetDimensions Method](#)
[ILibraryFeatureData::GetDimensionsCount Method](#)
[ILibraryFeatureData::IGetDimensions Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : SetPlacementPlane Method (ILibraryFeatureData)

Sets the face or plane on which to place the library feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetPlacementPlane( _  
    ByVal PDispIn As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData  
Dim PDispIn As System.Object  
  
instance.SetPlacementPlane(PDispIn)
```

C#

```
void SetPlacementPlane(  
    System.object PDispIn  
)
```

C++/CLI

```
void SetPlacementPlane(  
    & System.Object^ PDispIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PDispIn

[Face](#) or [plane](#) on which to place the library feature

Visual Basic for Applications (VBA) Syntax

See [LibraryFeatureData::SetPlacementPlane](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILibraryFeatureData Interface](#)
[ILibraryFeatureData Members](#)
[ILibraryFeatureData::GetPlacementPlane Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetReferences Method (ILibraryFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFeatureData Interface](#) : SetReferences Method (ILibraryFeatureData)

Sets the references for the library feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetReferences( _  
    ByVal RefVar As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ILibraryFeatureData  
Dim RefVar As System.Object  
  
instance.SetReferences(RefVar)
```

C#

```
void SetReferences(  
    System.Object RefVar  
)
```

C++/CLI

```
void SetReferences(  
& System.Object^ RefVar  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RefVar
Array of references

Visual Basic for Applications (VBA) Syntax

See [LibraryFeatureData::SetReferences](#).

Example

[Create Library Feature With References \(C#\)](#)
[Create Library Feature With References \(VB.NET\)](#)
[Create Library Feature With References \(VBA\)](#)

Remarks

Some SolidWorks properties and methods, such as this method, have an input object that must be marshaled to an IDispatch object array because System.Object has replaced VARIANT in the .NET framework. When marshaling System.Object to an IDispatch object array, you must explicitly control the marshaling behavior by using the **System.Runtime.InteropServices.DispatchWrapper** class. See the VB.NET and C# examples in this Help topic and [IDispatch Object Arrays as Input in .NET](#) for more information.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILibraryFeatureData Interface](#)
[ILibraryFeatureData Members](#)
[ILibraryFeatureData::GetReferences Method](#)
[ILibraryFeatureData::GetReferencesCount Method](#)
[ILibraryFeatureData::IGetReferences Method](#)
[ILibraryFeatureData::ISetReferences Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0