

SOLIDWORKS API (.NET VBA C#) — Reference

(141/337): ILibraryFormToolFeatureData- ILinearCouplerMateFeatureData

SOLIDWORKS API Documentation (converted from CHM)

ILibraryFormToolFeatureData (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ILibraryFormToolFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILibraryFormToolFeatureData Interface

Allows access to library forming tool feature data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ILibraryFormToolFeatureData
```

Visual Basic (Usage)



```
Dim instance As ILibraryFormToolFeatureData
```

C#

```
public interface ILibraryFormToolFeatureData
```

C++/CLI

```
public interface class ILibraryFormToolFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [LibraryFormToolFeatureData](#).

Example

'VBA

'This example demonstrates how to insert a design library forming tool into a sheet metal part and reposition and replace it with another forming tool.

'-----

' Preconditions:

' 1. Open *public_documents\samples\tutorial\sheetmetal\formtools\cover.sldprt*.

' 2. Ensure that the two specified formtoolpath locations exist.

' 3. Ensure that the Sheet Metal tab is visible on the CommandManager toolbar.

' 4. Run macro.

' 5. At the pause, inspect the FeatureManager design tree and the graphics area for the drafted rectangular emboss forming tool.

' Then select a flat face where to re-position (and replace) the forming tool.

' 6. Press F5 finish.

'

' Postconditions:

' 1. A dimple emboss replaces the drafted rectangular emboss.

' 2. Inspect the FeatureManager design tree, graphics area, and the Immediate window.

'

' NOTE: Do not save the part as it may be used elsewhere.

'-----

```
Dim swApp As SldWorks.SldWorks
```

```

Dim swModel As ModelDoc2
Dim featMgr As FeatureManager
Dim boolstatus As Boolean
Option Explicit
Sub main()
    Set swApp = Application.SldWorks
    Set swModel = swApp.ActiveDoc

    'Select a flat face where to insert an emboss forming tool
    boolstatus = swModel.Extension.SelectByRay(5.53557395141979E-02,
3.03381093343091E-02, 2.66948404126879E-02, -0.707061513640545, -0.415946801562901,
-0.57188484347632, 5.32844353755021E-04, 2, False, 0, 0)

    Set featMgr = swModel.FeatureManager

    Dim LibFormToolFeatureData As LibraryFormToolFeatureData
    Set LibFormToolFeatureData = featMgr.CreateDefinition(swFmFormToolInstance)

    LibFormToolFeatureData.LinkToFormTool = True
    LibFormToolFeatureData.FormToolPath = "install_dir\data\Design Library\forming
tools\embosses\drafted rectangular emboss.sldftp"
    Call LibFormToolFeatureData.OverrideDocumentSettings(True, True, True, True)
    LibFormToolFeatureData.RotationAngle = 0.5

    Dim swFeat As Feature
    Set swFeat = featMgr.CreateFeature(LibFormToolFeatureData)

    Stop ' Inspect the graphics area and FeatureManager design tree; select a flat
face where to re-position (and replace) the forming tool

    Dim selMgr As SelectionMgr
    Set selMgr = swModel.SelectionManager

    Dim face2 As face2
    Set face2 = selMgr.GetSelectedObject6(1, -1)

    Dim pickPt As Variant
    pickPt = selMgr.GetSelectionPoint2(1, -1)

    Dim MU As MathUtility
    Set MU = swApp.GetMathUtility()

    Dim mathPt As MathPoint
    Set mathPt = MU.CreatePoint(pickPt)

```

```

swModel.ClearSelection2 (True)

Dim swLibFormFeatData1 As LibraryFormToolFeatureData
Set swLibFormFeatData1 = swFeat.GetDefinition()

Debug.Print swLibFormFeatData1.GetPunchID()
Debug.Print swLibFormFeatData1.FormToolConfiguration
Debug.Print swLibFormFeatData1.FormToolPath
Debug.Print swLibFormFeatData1.LinkToFormTool
Debug.Print swLibFormFeatData1.RotationAngle

Debug.Print swLibFormFeatData1.AccessSelections(swModel, Nothing)

Dim face As face2
Set face = swLibFormFeatData1.PlacementFace

swLibFormFeatData1.RotationAngle = 0.7833
Call swLibFormFeatData1.OverrideDocumentSettings(True, True, True, True)
swLibFormFeatData1.FormToolConfiguration = "Default"
swLibFormFeatData1.FormToolPath = "install_dir\data\Design Library\forming
tools\embosses\dimple.SLDFTP"
swLibFormFeatData1.LinkToFormTool = True
Dim ent As Entity
Set ent = face
Call ent.Select4(True, Nothing)
Call swLibFormFeatData1.SetPlacementFace(face2, mathPt)

Debug.Print swFeat.ModifyDefinition(swLibFormFeatData1, swModel, Nothing)

Dim face1 As face2
Set face1 = swLibFormFeatData1.PlacementFace
End Sub

```

Example

[Create Forming Tool Feature \(VB.NET\)](#)
[Create Forming Tool Feature \(C#\)](#)

Remarks

To create a library forming tool feature:

1. Ensure that the Sheet Metal tab is visible on the CommandManager toolbar.
2. Call [IModelDocExtension::SelectByRay](#) to select a flat face (with Mark = 0) on which to use a forming tool.
3. Call [IFeatureManager::CreateDefinition](#)(swFmFormToolInstance) to create this feature data object.
4. Call [ILibraryFormToolFeatureData::OverrideDocumentSettings](#) to specify flat pattern visibility options.
5. Specify the forming tool and its rotation angle for placement using [ILibraryFormToolFeatureData::FormToolConfiguration](#), [FormToolPath](#), [LinkToFormTool](#), and [RotationAngle](#).
6. Call [IFeatureManager::CreateFeature](#) to create the feature.

To modify a library form tool feature:

1. Select a new location by clicking on a flat face in the graphics area where to re-position and/or replace the forming tool.
2. Call [IFeature::GetDefinition](#) to obtain this feature data object.
3. Call [ILibraryFormToolFeatureData::AccessSelections](#).
4. Specify [ILibraryFormToolFeatureData::SetPlacementFace](#) to re-position the forming tool.

5. Call `ILibraryFormToolFeatureData::OverrideDocumentSettings` to change the flat pattern visibility options.
6. Modify `ILibraryFormToolFeatureData::FormToolConfiguration`, `FormToolPath` (a change to `FormToolPath` changes the feature name), `LinkToFormTool`, and `RotationAngle`.
7. Call `IFeature::ModifyDefinition` to finalize any changes or `ILibraryFormToolFeatureData::ReleaseSelectionAccess` if no changes were made.

Forming tools are dies that dent, bend, stretch, or otherwise form sheet metal. For more information about forming tools, see the **SOLIDWORKS Design user-interface online help > Sheet Metal > Using Forming Tools with Sheet Metal** topics.

Accessors

`IFeature::GetDefinition`

`IFeatureManager::CreateDefinition`

Access Diagram

[LibraryFormToolFeatureData](#)

See Also

[ILibraryFormToolFeatureData Members](#)
[SolidWorks.Interop.sldworks.Namespace](#)
[IFeatureManager::CreateFormTool2 Method \(\)](#)
[IView::InsertPunchTable Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ILibraryFormToolFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks.Namespace](#) : `ILibraryFormToolFeatureData` Interface

The following tables list the members exposed by [ILibraryFormToolFeatureData](#).

Public Properties

Name	Description
 FormToolConfiguration	Gets or sets the configuration of this forming tool's part to insert.
 FormToolPath	Gets or sets the pathname of this forming tool's part in the Design Library.
 LinkToFormTool	Gets or sets whether to link this forming tool to its part in the Design Library.
 OverrideSettings	Gets whether the document settings are overridden when displaying this forming tool in its flat pattern.
 PickPoint	Gets the pickpoint where this forming tool is inserted.
 PlacementFace	Gets the placement face where this forming tool is inserted.
 RotationAngle	Gets or sets the rotation angle of this forming tool.
 ShowCenter	Gets whether to display the center mark where this forming tool is located in the flat pattern.
 ShowProfile	Gets whether to display the placement sketch of this forming tool when the part is flattened.
 ShowPunch	Gets whether to display the cut of this forming tool when the part is flattened.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to selections that define this library forming tool feature.
 GetPunchID	Gets the punch ID assigned to the Design Library forming tool.
 OverrideDocumentSettings	Specifies the flat pattern visibility options for this forming tool feature.
 ReleaseSelectionAccess	Releases access to the selections that created this library forming tool feature.
 SetPlacementFace	Specifies the face and pickpoint where the forming tool is inserted.

[Top](#)

See Also

[ILibraryFormToolFeatureData Interface](#)
[SolidWorks.Interop.sldworks.Namespace](#)

ILibraryFormToolFeatureData Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ILibraryFormToolFeatureData Interface

For a list of all members of this type, see [ILibraryFormToolFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to selections that define this library forming tool feature.
 GetPunchID	Gets the punch ID assigned to the Design Library forming tool.
 OverrideDocumentSettings	Specifies the flat pattern visibility options for this forming tool feature.
 ReleaseSelectionAccess	Releases access to the selections that created this library forming tool feature.
 SetPlacementFace	Specifies the face and pickpoint where the forming tool is inserted.

[Top](#)

See Also

[ILibraryFormToolFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::CreateFormTool2 Method \(\)](#)
[IView::InsertPunchTable Method \(\)](#)

ILibraryFormToolFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ILibraryFormToolFeatureData Interface

For a list of all members of this type, see [ILibraryFormToolFeatureData members](#).

Public Properties

Name	Description
 FormToolConfiguration	Gets or sets the configuration of this forming tool's part to insert.
 FormToolPath	Gets or sets the pathname of this forming tool's part in the Design Library.
 LinkToFormTool	Gets or sets whether to link this forming tool to its part in the Design Library.
 OverrideSettings	Gets whether the document settings are overridden when displaying this forming tool in its flat pattern.
 PickPoint	Gets the pickpoint where this forming tool is inserted.
 PlacementFace	Gets the placement face where this forming tool is inserted.
 RotationAngle	Gets or sets the rotation angle of this forming tool.
 ShowCenter	Gets whether to display the center mark where this forming tool is located in the flat pattern.
 ShowProfile	Gets whether to display the placement sketch of this forming tool when the part is flattened.
 ShowPunch	Gets whether to display the cut of this forming tool when the part is flattened.

[Top](#)

See Also

[ILibraryFormToolFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::CreateFormTool2 Method \(\)](#)
[IView::InsertPunchTable Method \(\)](#)

AccessSelections Method (ILibraryFormToolFeatureData)

[See Also](#)



.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILibraryFormToolFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document (see **Remarks**)
Component
Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [LibraryFormToolFeatureData::AccessSelections](#).

Example

See the [ILibraryFormToolFeatureData](#) examples.

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [ILibraryFormToolFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

FormToolConfiguration Property (ILibraryFormToolFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFormToolFeatureData Interface](#) : FormToolConfiguration Property (ILibraryFormToolFeatureData)

Gets or sets the configuration of this forming tool's part to insert.

.NET Syntax

Visual Basic (Declaration)

Property FormToolConfiguration As System.String

Visual Basic (Usage)



```
Dim instance As ILibraryFormToolFeatureData  
Dim value As System.String
```

```
instance.FormToolConfiguration = value  
value = instance.FormToolConfiguration
```

C#

```
System.string FormToolConfiguration {get; set;}
```

C++/CLI

```
property System.String^ FormToolConfiguration {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Forming tool configuration name

Visual Basic for Applications (VBA) Syntax

See [LibraryFormToolFeatureData::FormToolConfiguration](#).

Example

See the [ILibraryFormToolFeatureData](#) examples.

See Also

[ILibraryFormToolFeatureData Interface](#)
[ILibraryFormToolFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

FormToolPath Property (ILibraryFormToolFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFormToolFeatureData Interface](#) : FormToolPath Property (ILibraryFormToolFeatureData)

Gets or sets the pathname of this forming tool's part in the Design Library.

.NET Syntax

Visual Basic (Declaration)

```
Property FormToolPath As System.String
```

Visual Basic (Usage)



```
Dim instance As ILibraryFormToolFeatureData  
Dim value As System.String  
  
instance.FormToolPath = value  
value = instance.FormToolPath
```

C#

```
System.string FormToolPath {get; set;}
```

C++/CLI

```
property System.String^ FormToolPath {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Design library forming tool part pathname

Visual Basic for Applications (VBA) Syntax

See [LibraryFormToolFeatureData::FormToolPath](#).

Example

See the [ILibraryFormToolFeatureData](#) examples.

Remarks

When LibraryFormToolFeatureData is modified and this property changes to another forming tool, then the forming tool feature name changes to reflect the new forming tool name.

See Also

[ILibraryFormToolFeatureData Interface](#)
[ILibraryFormToolFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPunchID Method (ILibraryFormToolFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFormToolFeatureData Interface](#) : GetPunchID Method (ILibraryFormToolFeatureData)

Gets the punch ID assigned to the Design Library forming tool.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPunchID() As System.String
```

Visual Basic (Usage)



```
Dim instance As ILibraryFormToolFeatureData
Dim value As System.String

value = instance.GetPunchID()
```

C#

```
System.string GetPunchID()
```

C++/CLI

```
System.String^ GetPunchID();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Punch ID

Visual Basic for Applications (VBA) Syntax

See [LibraryFormToolFeatureData::GetPunchID](#).

Example

See the [ILibraryFormToolFeatureData](#) examples.

Remarks

Punch IDs are displayed in flat pattern punch tables. See [IView::InsertPunchTable](#).

See Also

[ILibraryFormToolFeatureData Interface](#)
[ILibraryFormToolFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

LinkToFormTool Property (ILibraryFormToolFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFormToolFeatureData Interface](#) : LinkToFormTool Property (ILibraryFormToolFeatureData)

Gets or sets whether to link this forming tool to its part in the Design Library.

.NET Syntax

Visual Basic (Declaration)

```
Property LinkToFormTool As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILibraryFormToolFeatureData
Dim value As System.Boolean

instance.LinkToFormTool = value

value = instance.LinkToFormTool
```

C#

```
System.bool LinkToFormTool {get; set;}
```

C++/CLI

```
property System.bool LinkToFormTool {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to link this forming tool to its part in the Design Library, false to not

Visual Basic for Applications (VBA) Syntax

See [LibraryFormToolFeatureData::LinkToFormTool](#).

Example

See the [ILibraryFormToolFeatureData](#) examples.

See Also

[ILibraryFormToolFeatureData Interface](#)
[ILibraryFormToolFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

OverrideDocumentSettings Method (ILibraryFormToolFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFormToolFeatureData Interface](#) : OverrideDocumentSettings Method (ILibraryFormToolFeatureData)

Specifies the flat pattern visibility options for this forming tool feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub OverrideDocumentSettings( _
    ByVal OverrideSettings As System.Boolean, _
    ByVal ShowPunch As System.Boolean, _
    ByVal ShowProfile As System.Boolean, _
    ByVal ShowCenter As System.Boolean _
)
```

Visual Basic (Usage)



```
Dim instance As ILibraryFormToolFeatureData
Dim OverrideSettings As System.Boolean
Dim ShowPunch As System.Boolean
Dim ShowProfile As System.Boolean
Dim ShowCenter As System.Boolean

instance.OverrideDocumentSettings(OverrideSettings, ShowPunch, ShowProfile, ShowCenter)
```

C#

```
void OverrideDocumentSettings(
    System.bool OverrideSettings,
    System.bool ShowPunch,
    System.bool ShowProfile,
    System.bool ShowCenter
)
```

C++/CLI

```
void OverrideDocumentSettings(  
& System.bool OverrideSettings,  
& System.bool ShowPunch,  
& System.bool ShowProfile,  
& System.bool ShowCenter  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OverrideSettings

True to override the options set in **Tools > Options > Document Properties > Sheet Metal**, false to not (see **Remarks**)

ShowPunch

True to display the cut of this forming tool when the part is flattened, false to not (see **Remarks**)

ShowProfile

True to display the placement sketch of this forming tool when the part is flattened, false to not (see **Remarks**)

ShowCenter

True to display the center mark where this forming tool is located in the flat pattern, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [LibraryFormToolFeatureData::OverrideDocumentSettings](#).

Example

See the [ILibraryFormToolFeatureData](#) examples.

Remarks

ShowPunch, ShowProfile, and ShowCenter are valid only if OverrideSettings is set to true.

See Also

[ILibraryFormToolFeatureData Interface](#)
[ILibraryFormToolFeatureData Members](#)
[ILibraryFormToolFeatureData::OverrideSettings Property \(\)](#)
[ILibraryFormToolFeatureData::ShowCenter Property \(\)](#)
[ILibraryFormToolFeatureData::ShowProfile Property \(\)](#)
[ILibraryFormToolFeatureData::ShowPunch Property \(\)](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

OverrideSettings Property (ILibraryFormToolFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFormToolFeatureData Interface](#) : OverrideSettings Property (ILibraryFormToolFeatureData)

Gets whether the document settings are overridden when displaying this forming tool in its flat pattern.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property OverrideSettings As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILibraryFormToolFeatureData  
Dim value As System.Boolean
```

```
value = instance.OverrideSettings
```

C#

```
System.bool OverrideSettings {get;}
```

C++/CLI

```
property System.bool OverrideSettings {
    System.bool get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override document settings, false to not

Visual Basic for Applications (VBA) Syntax

See [LibraryFormToolFeatureData::OverrideSettings](#).

See Also

[ILibraryFormToolFeatureData Interface](#)
[ILibraryFormToolFeatureData Members](#)
[ILibraryFormToolFeatureData::OverrideDocumentSettings Method \(\)](#)
[ILibraryFormToolFeatureData::ShowCenter Property \(\)](#)
[ILibraryFormToolFeatureData::ShowProfile Property \(\)](#)
[ILibraryFormToolFeatureData::ShowPunch Property \(\)](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

PickPoint Property (ILibraryFormToolFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFormToolFeatureData Interface](#) : PickPoint Property (ILibraryFormToolFeatureData)

Gets the pickpoint where this forming tool is inserted.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property PickPoint As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILibraryFormToolFeatureData
Dim value As System.Object

value = instance.PickPoint
```

C#

```
System.Object PickPoint {get;}
```

C++/CLI

```
property System.Object^ PickPoint {
    System.Object^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IMathPoint](#)

Visual Basic for Applications (VBA) Syntax

See [LibraryFormToolFeatureData::PickPoint](#).

See Also

[ILibraryFormToolFeatureData Interface](#)
[ILibraryFormToolFeatureData Members](#)
[ILibraryFormToolFeatureData::SetPlacementFace Method\(\)](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

PlacementFace Property (ILibraryFormToolFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFormToolFeatureData Interface](#) : PlacementFace Property (ILibraryFormToolFeatureData)

Gets the placement face where this forming tool is inserted.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property PlacementFace As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILibraryFormToolFeatureData  
Dim value As System.Object
```

```
value = instance.PlacementFace
```

C#

```
System.Object PlacementFace {get;}
```

C++/CLI

```
property System.Object^ PlacementFace {  
    System.Object^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IFace2](#)

Visual Basic for Applications (VBA) Syntax

See [LibraryFormToolFeatureData::PlacementFace](#).

Example

See the [ILibraryFormToolFeatureData](#) examples.

See Also

[ILibraryFormToolFeatureData Interface](#)
[ILibraryFormToolFeatureData Members](#)
[ILibraryFormToolFeatureData::SetPlacementFace Method\(\)](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (ILibraryFormToolFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFormToolFeatureData Interface](#) : ReleaseSelectionAccess Method (ILibraryFormToolFeatureData)

Releases access to the selections that created this library forming tool feature.

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)

```
Dim instance As ILibraryFormToolFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [LibraryFormToolFeatureData::ReleaseSelectionAccess](#).

Remarks

[ILibraryFormToolFeatureData::AccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature. Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) if you did.

See Also

[ILibraryFormToolFeatureData Interface](#)
[ILibraryFormToolFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

RotationAngle Property (ILibraryFormToolFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFormToolFeatureData Interface](#) : RotationAngle Property (ILibraryFormToolFeatureData)

Gets or sets the rotation angle of this forming tool.

Visual Basic (Declaration)

```
Property RotationAngle As System.Double
```

Visual Basic (Usage)

```
Dim instance As ILibraryFormToolFeatureData  
Dim value As System.Double  
  
instance.RotationAngle = value  
  
value = instance.RotationAngle
```

C#

```
System.double RotationAngle {get; set;}
```

C++/CLI

```
property System.double RotationAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Rotation angle

Visual Basic for Applications (VBA) Syntax

See [LibraryFormToolFeatureData::RotationAngle](#).

Example

See the [ILibraryFormToolFeatureData](#) examples.

See Also

[ILibraryFormToolFeatureData Interface](#)
[ILibraryFormToolFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetPlacementFace Method (ILibraryFormToolFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFormToolFeatureData Interface](#) : SetPlacementFace Method (ILibraryFormToolFeatureData)

Specifies the face and pickpoint where the forming tool is inserted.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetPlacementFace( _  
    ByVal Face As System.Object, _  
    ByVal PickPoint As System.Object _  
)
```

Visual Basic (Usage)

```
Dim instance As ILibraryFormToolFeatureData  
Dim Face As System.Object  
Dim PickPoint As System.Object  
  
instance.SetPlacementFace(Face, PickPoint)
```

C#

```
void SetPlacementFace(  
    System.object Face,  
    System.object PickPoint  
)
```

C++/CLI

```
void SetPlacementFace(  
& System.Object^ Face,
```



Copy Code

```
& System.Object^ PickPoint
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Face
[IFace2](#)
PickPoint
[IMathPoint](#)

Visual Basic for Applications (VBA) Syntax

See [LibraryFormToolFeatureData::SetPlacementFace](#).

Example

See the [ILibraryFormToolFeatureData](#) examples.

See Also

[ILibraryFormToolFeatureData Interface](#)
[ILibraryFormToolFeatureData Members](#)
[ILibraryFormToolFeatureData::PlacementFace Property \(\)](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowCenter Property (ILibraryFormToolFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFormToolFeatureData Interface](#) : ShowCenter Property (ILibraryFormToolFeatureData)

Gets whether to display the center mark where this forming tool is located in the flat pattern.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ShowCenter As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILibraryFormToolFeatureData
Dim value As System.Boolean
```

```
value = instance.ShowCenter
```

C#

```
System.bool ShowCenter {get;}
```

C++/CLI

```
property System.bool ShowCenter {
    System.bool get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to display the center mark where this forming tool is located in the flat pattern, false to not

Visual Basic for Applications (VBA) Syntax

See [LibraryFormToolFeatureData::ShowCenter](#).

See Also

[ILibraryFormToolFeatureData Interface](#)
[ILibraryFormToolFeatureData Members](#)
[ILibraryFormToolFeatureData::OverrideDocumentSettings Method \(\)](#)
[ILibraryFormToolFeatureData::OverrideSettings Property \(\)](#)
[ILibraryFormToolFeatureData::ShowProfile Property \(\)](#)
[ILibraryFormToolFeatureData::ShowPunch Property \(\)](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowProfile Property (ILibraryFormToolFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFormToolFeatureData Interface](#) : ShowProfile Property (ILibraryFormToolFeatureData)

Gets whether to display the placement sketch of this forming tool when the part is flattened.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ShowProfile As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILibraryFormToolFeatureData  
Dim value As System.Boolean  
  
value = instance.ShowProfile
```

C#

```
System.bool ShowProfile {get;}
```

C++/CLI

```
property System.bool ShowProfile {  
    System.bool get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to display the placement sketch of this forming tool when the part is flattened, false to not

Visual Basic for Applications (VBA) Syntax

See [LibraryFormToolFeatureData::ShowProfile](#).

See Also

[ILibraryFormToolFeatureData Interface](#)
[ILibraryFormToolFeatureData Members](#)
[ILibraryFormToolFeatureData::OverrideDocumentSettings Method \(\)](#)
[ILibraryFormToolFeatureData::OverrideSettings Property \(\)](#)
[ILibraryFormToolFeatureData::ShowCenter Property \(\)](#)
[ILibraryFormToolFeatureData::ShowPunch Property \(\)](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowPunch Property (ILibraryFormToolFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILibraryFormToolFeatureData Interface](#) : ShowPunch Property (ILibraryFormToolFeatureData)

Gets whether to display the cut of this forming tool when the part is flattened.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ShowPunch As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILibraryFormToolFeatureData  
Dim value As System.Boolean
```

```
value = instance.ShowPunch
```

C#

```
System.bool ShowPunch {get;}
```

C++/CLI

```
property System.bool ShowPunch {  
    System.bool get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to display the cut of this forming tool when the part is flattened, false to not

Visual Basic for Applications (VBA) Syntax

See [LibraryFormToolFeatureData::ShowPunch](#).

See Also

[ILibraryFormToolFeatureData Interface](#)
[ILibraryFormToolFeatureData Members](#)
[ILibraryFormToolFeatureData::OverrideDocumentSettings Method \(\)](#)
[ILibraryFormToolFeatureData::OverrideSettings Property \(\)](#)
[ILibraryFormToolFeatureData::ShowCenter Property \(\)](#)
[ILibraryFormToolFeatureData::ShowProfile Property \(\)](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

ILight (Type)

ILight Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILight Interface

Allows access to the light feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ILight

Visual Basic (Usage)

Dim instance As [ILight](#)

C#

public interface ILight

C++/CLI

public interface class ILight

Visual Basic for Applications (VBA) Syntax

See [Light](#).

Example

[Redirect Spotlight \(VBA\)](#)
[Add Spotlight and Get Light Feature \(C#\)](#)
[Add Spotlight and Get Light Feature \(VB.NET\)](#)
[Add Spotlight and Get Light Feature \(VBA\)](#)

Accessors

[IFeature::GetSpecificFeature2](#)

Access Diagram

[Light](#)

See Also

[ILight Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ILight Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILight Interface

The following tables list the members exposed by [ILight](#).

Public Methods

Name	Description
GetID	Gets the light ID for this light feature.

[Top](#)

See Also

[ILight Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ILight Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILight Interface

For a list of all members of this type, see [ILight members](#).

Public Methods

Name	Description
 GetID	Gets the light ID for this light feature.

[Top](#)

See Also

[ILight Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetID Method (ILight)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILight Interface](#) : GetID Method (ILight)

Gets the light ID for this light feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetID() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILight  
Dim value As System.Integer  
  
value = instance.GetID()
```

C#

```
System.int GetID()
```

C++/CLI

```
System.int GetID();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Light ID for this light feature

Visual Basic for Applications (VBA) Syntax

See [Light::GetID](#).

Example

[Redirect Spotlight \(VBA\)](#)
[Add Spotlight and Get Light Feature \(C#\)](#)
[Add Spotlight and Get Light Feature \(VB.NET\)](#)
[Add Spotlight and Get Light Feature \(VBA\)](#)

Remarks

A light ID:

- is unique within the document.
- is persistent across SOLIDWORKS Design sessions and never changes, even if you change the name of the light.
- can be used to identify a specific light in a document.
- cannot be assigned by applications or users.
- is not the same as a [persistent reference ID](#). You can get a light using its persistent reference ID, but you cannot get a light using this method.

See Also

[ILight Interface](#)
[ILight Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

ILightDialog (Type)

ILightDialog Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILightDialog Interface

Obtained from a LightingDialogCreateNotify event.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ILightDialog
```

Visual Basic (Usage)



```
Dim instance As ILightDialog
```

C#

```
public interface ILightDialog
```

C++/CLI

```
public interface class ILightDialog
```

Visual Basic for Applications (VBA) Syntax

See [LightDialog](#).

Remarks

Use this interface to add your own dialog information to the SOLIDWORKS lighting dialog.

Accessors

[DAssemblyDocEvents_LightingDialogCreateNotifyEventHandler](#)

[DPartDocEvents_LightingDialogCreateNotifyEventHandler](#)

Access Diagram

[LightDialog](#)

See Also

[ILightDialog Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ILightDialog Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILightDialog Interface

For a list of all members of this type, see [ILightDialog members](#).

Public Methods

Name	Description
 AddSubDialog	Adds a sub-dialog to the lighting dialog.
 GetLightId	Gets the ID of the edited light in the light dialog.

[Top](#)

See Also

[ILightDialog Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ILightDialog Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : [ILightDialog Interface](#)

The following tables list the members exposed by [ILightDialog](#).

Public Methods

Name	Description
 AddSubDialog	Adds a sub-dialog to the lighting dialog.
 GetLightId	Gets the ID of the edited light in the light dialog.

[Top](#)

See Also

[ILightDialog Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddSubDialog Method (ILightDialog)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILightDialog Interface](#) : AddSubDialog Method (ILightDialog)

Adds a sub-dialog to the lighting dialog.

.NET Syntax

Visual Basic (Declaration)

```
Function AddSubDialog( _  
    ByVal Page As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILightDialog  
Dim Page As System.Integer  
Dim value As System.Boolean  
  
value = instance.AddSubDialog(Page)
```

C#

```
System.bool AddSubDialog(  
    System.int Page  
)
```

C++/CLI

```
System.bool AddSubDialog(  
& System.int Page  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Page

Pointer to a CDialog object cast to a long

Return Value

True if the dialog was successfully added, false if not

Visual Basic for Applications (VBA) Syntax

See [LightDialog::AddSubDialog](#).

Remarks

Currently only one sub-dialog can be added to each dialog.

See Also

[ILightDialog Interface](#)
[ILightDialog Members](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLightId Method (ILightDialog)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILightDialog Interface](#) : GetLightId Method (ILightDialog)

Gets the ID of the edited light in the light dialog.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLightId() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILightDialog  
Dim value As System.Integer
```

```
value = instance.GetLightId()
```

C#

```
System.int GetLightId()
```

C++/CLI

```
System.int GetLightId();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

ID of the light currently being modified by the dialog; -1 if the light cannot be found

Visual Basic for Applications (VBA) Syntax

See [LightDialog::GetLightId](#).

See Also

[ILightDialog Interface](#)
[ILightDialog Members](#)

Availability

SOLIDWORKS 99, Revision Number 1999207

ILinearCouplerMateFeatureData (Type)

ILinearCouplerMateFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILinearCouplerMateFeatureData Interface

Allows access to linear/linear coupler mate feature data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

Visual Basic Syntax

Visual Basic (Declaration)

```
Public Interface ILinearCouplerMateFeatureData
```

Visual Basic (Usage)



```
Dim instance As ILinearCouplerMateFeatureData
```

C#

```
public interface ILinearCouplerMateFeatureData
```

C++/CLI

```
public interface class ILinearCouplerMateFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [LinearCouplerMateFeatureData](#).

Example

[Create and Edit Linear-Linear Coupler Mate \(VBA\)](#)
[Create and Edit Linear-Linear Coupler Mate \(C#\)](#)

Remarks

A linear/linear coupler mate establishes a relationship between the translation of one component and the translation of another component.

[IMateFeatureData](#) is the parent of this advanced mate interface.

To create a linear/linear coupler mate:

1. Follow general instructions in the [IAssemblyDoc::CreateMate](#) Remarks.
2. Specify [ILinearCouplerMateFeatureData::MateEntity1](#) and [ILinearCouplerMateFeatureData::MateEntity2](#).
3. Specify other properties of the LinearCouplerMateFeatureData object as required.

To edit a linear/linear coupler mate:

1. Access its feature and call [IFeature::GetDefinition](#) to get the MateFeatureData object.
2. Cast the MateFeatureData object to a LinearCouplerMateFeatureData object.
3. Modify the LinearCouplerMateFeatureData object.
4. Call [IFeature::ModifyDefinition](#).

To delete a linear/linear coupler mate, use [IModelDocExtension::DeleteSelection2](#).

Access Diagram

[LinearCouplerMateFeatureData](#)

See Also

[ILinearCouplerMateFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ILinearCouplerMateFeatureData Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILinearCouplerMateFeatureData Interface

The following tables list the members exposed by [ILinearCouplerMateFeatureData](#).

Public Properties

Name	Description
 CouplerRatioDenominator	Gets or sets the displacement of the second mated component along its direction of motion in this linear/linear coupler mate.
 CouplerRatioNumerator	Gets or sets the displacement of the first mated component along its direction of motion in this linear/linear coupler mate.
 MateEntity1	Gets or sets the entity of the first mated component of this linear/linear coupler mate.
 MateEntity2	Gets or sets the entity of the second mated component of this linear/linear coupler mate.
 ReferenceComponent1	Gets or sets the reference component of the first mate entity of this linear coupler mate.
 ReferenceComponent2	Gets or sets the reference component of the second mate entity of this linear/linear coupler mate.
 Reverse	Gets or sets whether to reverse the direction of motion of the second mated component relative to the direction of motion of the first mated component of this linear/linear coupler mate.

[Top](#)

See Also

[ILinearCouplerMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

ILinearCouplerMateFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILinearCouplerMateFeatureData Interface

For a list of all members of this type, see [ILinearCouplerMateFeatureData members](#).

Public Properties

Name	Description
 CouplerRatioDenominator	Gets or sets the displacement of the second mated component along its direction of motion in this linear/linear coupler mate.
 CouplerRatioNumerator	Gets or sets the displacement of the first mated component along its direction of motion in this linear/linear coupler mate.
 MateEntity1	Gets or sets the entity of the first mated component of this linear/linear coupler mate.
 MateEntity2	Gets or sets the entity of the second mated component of this linear/linear coupler mate.
 ReferenceComponent1	Gets or sets the reference component of the first mate entity of this linear coupler mate.
 ReferenceComponent2	Gets or sets the reference component of the second mate entity of this linear/linear coupler mate.
 Reverse	Gets or sets whether to reverse the direction of motion of the second mated component relative to the direction of motion of the first mated component of this linear/linear coupler mate.

[Top](#)

See Also

[ILinearCouplerMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

CouplerRatioDenominator Property (ILinearCouplerMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILinearCouplerMateFeatureData Interface](#) : CouplerRatioDenominator Property (ILinearCouplerMateFeatureData)

Gets or sets the displacement of the second mated component along its direction of motion in this linear/linear coupler mate.

.NET Syntax

Visual Basic (Declaration)

Property `CouplerRatioDenominator` As `System.Double`

Visual Basic (Usage)

 Copy Code

```
Dim instance As ILinearCouplerMateFeatureData  
Dim value As System.Double
```

```
instance.CouplerRatioDenominator = value
```

```
value = instance.CouplerRatioDenominator
```

C#

```
System.double CouplerRatioDenominator {get; set;}
```

C++/CLI

```
property System.double CouplerRatioDenominator {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Coupler ratio denominator

Visual Basic for Applications (VBA) Syntax

See [LinearCouplerMateFeatureData::CouplerRatioDenominator](#).

Example

See the [ILinearCouplerMateFeatureData](#) examples.

Remarks

ILinearCouplerMateFeatureData::CouplerRatioNumerator / ILinearCouplerMateFeatureData::CouplerRatioDenominator describes the ratio of displacement between the first and second mated components.

See Also

[ILinearCouplerMateFeatureData Interface](#)
[ILinearCouplerMateFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CouplerRatioNumerator Property (ILinearCouplerMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILinearCouplerMateFeatureData Interface](#) : CouplerRatioNumerator Property (ILinearCouplerMateFeatureData)

Gets or sets the displacement of the first mated component along its direction of motion in this linear/linear coupler mate.

.NET Syntax

Visual Basic (Declaration)

```
Property CouplerRatioNumerator As System.Double
```

Visual Basic (Usage)



```
Dim instance As ILinearCouplerMateFeatureData
Dim value As System.Double

instance.CouplerRatioNumerator = value

value = instance.CouplerRatioNumerator
```

C#

```
System.double CouplerRatioNumerator {get; set;}
```

C++/CLI

```
property System.double CouplerRatioNumerator {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Coupler ratio numerator

Visual Basic for Applications (VBA) Syntax

See [LinearCouplerMateFeatureData::CouplerRatioNumerator](#).

Example

See the [ILinearCouplerMateFeatureData](#) examples.

See Also

[ILinearCouplerMateFeatureData Interface](#)
[ILinearCouplerMateFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MateEntity1 Property (ILinearCouplerMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILinearCouplerMateFeatureData Interface](#) : MateEntity1 Property (ILinearCouplerMateFeatureData)

Gets or sets the entity of the first mated component of this linear/linear coupler mate.

.NET Syntax

Visual Basic (Declaration)

```
Property MateEntity1 As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILinearCouplerMateFeatureData
Dim value As System.Object

instance.MateEntity1 = value

value = instance.MateEntity1
```

C#

```
System.object MateEntity1 {get; set;}
```

C++/CLI

```
property System.Object^ MateEntity1 {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

First mated component entity ([face](#) or [edge](#))

Visual Basic for Applications (VBA) Syntax

See [LinearCouplerMateFeatureData::MateEntity1](#).

Example

See the [ILinearCouplerMateFeatureData](#) examples.

See Also

[ILinearCouplerMateFeatureData Interface](#)
[ILinearCouplerMateFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MateEntity2 Property (ILinearCouplerMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILinearCouplerMateFeatureData Interface](#) : MateEntity2 Property (ILinearCouplerMateFeatureData)

Gets or sets the entity of the second mated component of this linear/linear coupler mate.

.NET Syntax

Visual Basic (Declaration)

```
Property MateEntity2 As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILinearCouplerMateFeatureData
Dim value As System.Object
```

```
instance.MateEntity2 = value
```

```
value = instance.MateEntity2
```

C#

```
System.object MateEntity2 {get; set;}
```

C++/CLI

```
property System.Object^ MateEntity2 {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Second mated component entity

Visual Basic for Applications (VBA) Syntax

See [LinearCouplerMateFeatureData::MateEntity2](#).

Example

See the [ILinearCouplerMateFeatureData](#) examples.

See Also

[ILinearCouplerMateFeatureData Interface](#)
[ILinearCouplerMateFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReferenceComponent1 Property (ILinearCouplerMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILinearCouplerMateFeatureData Interface](#) : ReferenceComponent1 Property (ILinearCouplerMateFeatureData)

Gets or sets the reference component of the first mate entity of this linear coupler mate.

.NET Syntax

Visual Basic (Declaration)

```
Property ReferenceComponent1 As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILinearCouplerMateFeatureData  
Dim value As System.Object  
  
instance.ReferenceComponent1 = value  
  
value = instance.ReferenceComponent1
```

C#

```
System.Object ReferenceComponent1 {get; set;}
```

C++/CLI

```
property System.Object^ ReferenceComponent1 {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Reference component 1

Visual Basic for Applications (VBA) Syntax

See [LinearCouplerMateFeatureData::ReferenceComponent1](#).

Remarks

Use this property to set up the motion of the first mated component with respect to a reference component. If you do not set this property, motion is with respect to the assembly origin.

See Also

[ILinearCouplerMateFeatureData Interface](#)
[ILinearCouplerMateFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReferenceComponent2 Property (ILinearCouplerMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILinearCouplerMateFeatureData Interface](#) : ReferenceComponent2 Property (ILinearCouplerMateFeatureData)

Gets or sets the reference component of the second mate entity of this linear/linear coupler mate.

Visual Basic Syntax

Visual Basic (Declaration)

Property ReferenceComponent2 As System.Object

Visual Basic (Usage)



```
Dim instance As ILinearCouplerMateFeatureData
Dim value As System.Object
```

```
instance.ReferenceComponent2 = value
```

```
value = instance.ReferenceComponent2
```

C#

```
System.Object ReferenceComponent2 {get; set;}
```

C++/CLI

```
property System.Object^ ReferenceComponent2 {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Reference component 2

Visual Basic for Applications (VBA) Syntax

See [LinearCouplerMateFeatureData::ReferenceComponent12](#).

Remarks

Use this property to set up the motion of the second mated component with respect to a reference component. If you do not set this property, motion is with respect to the assembly origin.

See Also

[ILinearCouplerMateFeatureData Interface](#)
[ILinearCouplerMateFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Reverse Property (ILinearCouplerMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILinearCouplerMateFeatureData Interface](#) : Reverse Property (ILinearCouplerMateFeatureData)

Gets or sets whether to reverse the direction of motion of the second mated component relative to the direction of motion of the first mated component of this linear/linear coupler mate.

.NET Syntax

Visual Basic (Declaration)

Property Reverse As System.Boolean

Visual Basic (Usage)



```
Dim instance As ILinearCouplerMateFeatureData  
Dim value As System.Boolean
```

```
instance.Reverse = value
```

```
value = instance.Reverse
```

C#

```
System.bool Reverse {get; set;}
```

C++/CLI

```
property System.bool Reverse {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the direction of motion, false to not

Visual Basic for Applications (VBA) Syntax

See [LinearCouplerMateFeatureData::Reverse](#).

Example

See the [ILinearCouplerMateFeatureData](#) examples.

See Also

[ILinearCouplerMateFeatureData Interface](#)
[ILinearCouplerMateFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0