

SOLIDWORKS API (.NET, VBA, C#) — Reference

(144/337): ILocalCurvePatternFeatureData

SOLIDWORKS API Documentation (converted from CHM)

ILocalCurvePatternFeatureData (Type)

ILocalCurvePatternFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILocalCurvePatternFeatureData Interface

Allows access to a curve-driven component pattern feature in an assembly.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ILocalCurvePatternFeatureData

Visual Basic (Usage)



Dim instance As [ILocalCurvePatternFeatureData](#)

C#

public interface ILocalCurvePatternFeatureData

C++/CLI

public interface class ILocalCurvePatternFeatureData

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData](#).

Example

[Create Local Curve-driven Pattern \(C#\)](#)
[Create Local Curve-driven Pattern \(VB.NET\)](#)
[Create Local Curve-driven Pattern \(VBA\)](#)

Remarks

Read [Pattern Features and their Feature Data Objects](#).

Before calling [IFeatureManager::CreateDefinition](#), you must pre-select the entities needed to create the curve-driven component pattern feature.

	Use Mark=...
To select...	
Components to pattern	1
Curve, edge, sketch, or sketch entity for Direction 1	2
Curve, edge, sketch, or sketch entity for Direction 2	4
Reference point (only needed if ILocalCurvePatternFeatureData::D1ReferencePoint is set to swLocalCurvePatternReferencePoint_e.swLocalCurvePatternSelectedPoint)	32
Face normal (face on which a 3D curve lies)	64

After calling [IFeatureManager::CreateDefinition](#), you can explicitly set other properties on the feature data object.

You must call [IFeatureManager::CreateFeature](#) after initializing this feature data object in order to successfully create the curve-driven component pattern feature.

For more information, see the **Assemblies > Basic Component Operations > Component Patterns > Curve Driven Component Pattern** topic in the SOLIDWORKS Design user-interface help.

Accessors

[IFeature::GetDefinition](#)

[IFeatureManager::CreateDefinition](#)

Access Diagram

[LocalCurvePatternFeatureData](#)

See Also

[ILocalCurvePatternFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICurveDrivenPatternFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ILocalCurvePatternFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILocalCurvePatternFeatureData Interface

The following tables list the members exposed by [ILocalCurvePatternFeatureData](#).

Public Properties

Name	Description
 D1AlignmentMethod	Gets or sets how to align the instances in this curve-driven component pattern feature.
 D1CurveMethod	Gets or sets how to use the curve , edge , sketch , or sketch entity selected for the pattern direction.
 D1Direction	Gets or sets Direction 1 using the selected curve, edge, sketch, or sketch entity for this curve-driven component pattern feature.
 D1FaceNormal	Gets or sets the face on which the 3D curve lies for this curve-driven component pattern feature.
 D1InstanceCount	Gets or sets the number of instances of the seed component in Direction 1 in this curve-driven component pattern feature.
 D1IsEqualSpaced	Gets or sets whether to use equal spacing between instances of the pattern in Direction 1 for this curve-driven component pattern feature.
 D1ReferencePoint	Gets or sets the reference point for Direction 1 for this curve-driven component pattern feature.
 D1ReverseDirection	Gets or sets whether to reverse the direction of Direction 1 in this curve-driven component pattern feature.
 D1Spacing	Gets or sets the distance between pattern instances in Direction 1 in this curve-driven component pattern feature.
 D2Direction	Gets or sets Direction 2 using the selected curve, edge, sketch, or sketch entity for this bidirectional curve-driven component pattern feature.
 D2InstanceCount	Gets or sets the number of instances of the seed component in Direction 2 in this bidirectional curve-driven component pattern feature.
 D2IsEqualSpaced	Gets or sets whether to use equal spacing between instances of the pattern in Direction 2 for this bidirectional curve-driven component pattern feature.
 D2PatternSeedOnly	Gets or sets whether to only pattern the seed component in Direction 2 in this bidirectional curve-driven component pattern feature.
 D2ReverseDirection	Gets or sets whether to reverse the direction of Direction 2 in this bidirectional curve-driven component pattern feature.
 D2Spacing	Gets or sets the distance between pattern instances in Direction 2 in this bidirectional curve-driven component pattern feature.
 Dir2Specified	Gets or sets whether to create a bidirectional pattern for this curve-driven component pattern feature.
 ForceUseSeedConfiguration	Gets or sets whether to synchronize the configuration of pattern components with the configuration of the seed component in this local curve pattern feature.
 PatternComponentArray	Gets or sets the components in this curve-driven component pattern feature.
 SelectedPoint	Gets or sets the reference point for this curve-driven component pattern feature.
 SkippedItemArray	Gets or sets the array of skipped components in this curve-driven component pattern feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this curve-driven component pattern feature.
 GetPatternComponentCount	Gets the number of components in this curve-driven component pattern feature.
 GetSkippedItemCount	Gets the number of components skipped in this curve-driven component pattern feature.
 GetTransform	Gets the transform for the specified instance in this curve-driven component pattern feature.

 ReleaseSelectionAccess	Releases access to the selections for this curve-driven component pattern feature.
---	--

[Top](#)

See Also

[ILocalCurvePatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICurveDrivenPatternFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ILocalCurvePatternFeatureData Interface Methods

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ILocalCurvePatternFeatureData Interface

For a list of all members of this type, see [ILocalCurvePatternFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this curve-driven component pattern feature.
 GetPatternComponentCount	Gets the number of components in this curve-driven component pattern feature.
 GetSkippedItemCount	Gets the number of components skipped in this curve-driven component pattern feature.
 GetTransform	Gets the transform for the specified instance in this curve-driven component pattern feature.
 ReleaseSelectionAccess	Releases access to the selections for this curve-driven component pattern feature.

[Top](#)

See Also

[ILocalCurvePatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICurveDrivenPatternFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ILocalCurvePatternFeatureData Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ILocalCurvePatternFeatureData Interface

For a list of all members of this type, see [ILocalCurvePatternFeatureData members](#).

Public Properties

Name	Description
 D1AlignmentMethod	Gets or sets how to align the instances in this curve-driven component pattern feature.
 D1CurveMethod	Gets or sets how to use the curve , edge , sketch , or sketch entity selected for the pattern direction.
 D1Direction	Gets or sets Direction 1 using the selected curve, edge, sketch, or sketch entity for this curve-driven component pattern feature.
 D1FaceNormal	Gets or sets the face on which the 3D curve lies for this curve-driven component pattern feature.
 D1InstanceCount	Gets or sets the number of instances of the seed component in Direction 1 in this curve-driven component pattern feature.
 D1IsEqualSpaced	Gets or sets whether to use equal spacing between instances of the pattern in Direction 1 for this curve-driven component pattern feature.
 D1ReferencePoint	Gets or sets the reference point for Direction 1 for this curve-driven component pattern feature.
 D1ReverseDirection	Gets or sets whether to reverse the direction of Direction 1 in this curve-driven component pattern feature.
 D1Spacing	Gets or sets the distance between pattern instances in Direction 1 in this curve-driven component pattern feature.
 D2Direction	Gets or sets Direction 2 using the selected curve, edge, sketch, or sketch entity for this bidirectional curve-driven component pattern feature.
 D2InstanceCount	Gets or sets the number of instances of the seed component in Direction 2 in this bidirectional curve-driven component pattern feature.
 D2IsEqualSpaced	Gets or sets whether to use equal spacing between instances of the pattern in Direction 2 for this bidirectional curve-driven component pattern feature.
 D2PatternSeedOnly	Gets or sets whether to only pattern the seed component in Direction 2 in this bidirectional curve-driven component pattern feature.
 D2ReverseDirection	Gets or sets whether to reverse the direction of Direction 2 in this bidirectional curve-driven component pattern feature.

	D2Spacing	Gets or sets the distance between pattern instances in Direction 2 in this bidirectional curve-driven component pattern feature.
	Dir2Specified	Gets or sets whether to create a bidirectional pattern for this curve-driven component pattern feature.
	ForceUseSeedConfiguration	Gets or sets whether to synchronize the configuration of pattern components with the configuration of the seed component in this local curve pattern feature.
	PatternComponentArray	Gets or sets the components in this curve-driven component pattern feature.
	SelectedPoint	Gets or sets the reference point for this curve-driven component pattern feature.
	SkippedItemArray	Gets or sets the array of skipped components in this curve-driven component pattern feature.

[Top](#)

See Also

[ILocalCurvePatternFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICurveDrivenPatternFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (ILocalCurvePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : AccessSelections Method (ILocalCurvePatternFeatureData)

Gains access to the selections that define this curve-driven component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _
    ByVal TopDoc As System.Object, _
    ByVal Component As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.Object^ TopDoc,
    & System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document (see **Remarks**)

Component
Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::AccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is <code>NULL</code>
Assembly	- TopDoc is the <code>IModelDoc2</code> object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [ILocalCurvePatternFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D1AlignmentMethod Property (ILocalCurvePatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : D1AlignmentMethod Property (ILocalCurvePatternFeatureData)

Gets or sets how to align the instances in this curve-driven component pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property D1AlignmentMethod As System.Integer

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData  
Dim value As System.Integer
```

```
instance.D1AlignmentMethod = value
```

```
value = instance.D1AlignmentMethod
```

C#

```
System.int D1AlignmentMethod {get; set;}
```

C++/CLI

```
property System.int D1AlignmentMethod {  
    System.int get();  
    void set ( &    System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Alignment as defined in [swLocalCurvePatternAlignment_e](#)

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::D1AlignmentMethod](#).

Example

[Create Local Curve-driven Pattern \(C#\)](#)
[Create Local Curve-driven Pattern \(VB.NET\)](#)
[Create Local Curve-driven Pattern \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

For more information, see the **Curve Driven Component Pattern** topic in the SOLIDWORKS Design user-interface help.

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)
[ILocalCurvePatternFeatureData::D1CurveMethod Property\(\)](#)
[ILocalCurvePatternFeatureData::D1Direction Property\(\)](#)
[ILocalCurvePatternFeatureData::D1InstanceCount Property\(\)](#)
[ILocalCurvePatternFeatureData::D1IsEqualSpaced Property\(\)](#)
[ILocalCurvePatternFeatureData::D1ReferencePoint Property\(\)](#)
[ILocalCurvePatternFeatureData::D1ReverseDirection Property\(\)](#)
[ILocalCurvePatternFeatureData::D1Spacing Property\(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D1CurveMethod Property (ILocalCurvePatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : D1CurveMethod Property (ILocalCurvePatternFeatureData)

Gets or sets how to use the [curve](#), [edge](#), [sketch](#), or sketch entity selected for the pattern direction.

.NET Syntax

Visual Basic (Declaration)

Property D1CurveMethod As System.Integer

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData  
Dim value As System.Integer
```

```
instance.D1CurveMethod = value
```

```
value = instance.D1CurveMethod
```

C#

```
System.int D1CurveMethod {get; set;}
```

C++/CLI

```
property System.int D1CurveMethod {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Curve method as defined in [swLocalCurvePatternCurveMethod](#) e

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::D1CurveMethod](#).

Example

[Create Local Curve-driven Pattern \(C#\)](#)
[Create Local Curve-driven Pattern \(VB.NET\)](#)
[Create Local Curve-driven Pattern \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

For more information, see the **Curve Driven Component Pattern** topic in the SOLIDWORKS Design user-interface help.

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)
[ILocalCurvePatternFeatureData::D1AlignmentMethod Property\(\)](#)
[ILocalCurvePatternFeatureData::D1InstanceCount Property\(\)](#)
[ILocalCurvePatternFeatureData::D1IsEqualSpaced Property\(\)](#)
[ILocalCurvePatternFeatureData::D1ReferencePoint Property\(\)](#)
[ILocalCurvePatternFeatureData::D1ReverseDirection Property\(\)](#)
[ILocalCurvePatternFeatureData::D1Spacing Property\(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D1Direction Property (ILocalCurvePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : D1Direction Property (ILocalCurvePatternFeatureData)

Gets or sets Direction 1 using the selected curve, edge, sketch, or sketch entity for this curve-driven component pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property D1Direction As System.Object

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData  
Dim value As System.Object
```

```
instance.D1Direction = value
```

```
value = instance.D1Direction
```

C#

```
System.Object D1Direction {get; set;}
```

C++/CLI

```
property System.Object^ D1Direction {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Curve](#), [edge](#), [sketch](#), or sketch entity for Direction 1

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::D1Direction](#).

Remarks

You must pre-select the direction entity using selection Mark = 1 before creating the feature definition. If you are using a 3D curve for Direction 1 then you must also pre-select the face normal entity using selection Mark = 64.

Use this property only when editing the pattern feature.

If you specify this property using a 3D curve, you should also specify [ILocalCurvePatternFeatureData::D1FaceNormal](#).

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)
[ILocalCurvePatternFeatureData::D1AlignmentMethod Property \(\)](#)
[ILocalCurvePatternFeatureData::D1CurveMethod Property \(\)](#)
[ILocalCurvePatternFeatureData::D1InstanceCount Property \(\)](#)
[ILocalCurvePatternFeatureData::D1IsEqualSpaced Property \(\)](#)
[ILocalCurvePatternFeatureData::D1ReferencePoint Property \(\)](#)
[ILocalCurvePatternFeatureData::D1ReverseDirection Property \(\)](#)
[ILocalCurvePatternFeatureData::D1Spacing Property \(\)](#)
[ILocalCurvePatternFeatureData::D2Direction Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D1FaceNormal Property (ILocalCurvePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : D1FaceNormal Property (ILocalCurvePatternFeatureData)

Gets or sets the face on which the 3D curve lies for this curve-driven component pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property D1FaceNormal As System.Object

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData  
Dim value As System.Object
```

```
instance.D1FaceNormal = value
```

```
value = instance.D1FaceNormal
```

C#

```
System.Object D1FaceNormal {get; set;}
```

C++/CLI

```
property System.Object^ D1FaceNormal {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IFace2](#)

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::D1FaceNormal](#).

Remarks

If you pre-select a 3D curve for Direction 1, then before creating the feature definition, you must also pre-select the face normal entity using selection Mark = 64.

Use this property only when editing the pattern feature.

This property is valid only when specifying [ILocalCurvePatternFeatureData::D1Direction](#) using a 3D curve.

If you try to change this property to null or Nothing, [IFeature::ModifyDefinition](#) returns true but the property does not change.

For more information, see the **Curve Driven Component Pattern** topic in the SOLIDWORKS Design user-interface help.

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D1InstanceCount Property (ILocalCurvePatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : D1InstanceCount Property (ILocalCurvePatternFeatureData)

Gets or sets the number of instances of the seed component in Direction 1 in this curve-driven component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property D1InstanceCount As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData  
Dim value As System.Integer
```

```
instance.D1InstanceCount = value
```

```
value = instance.D1InstanceCount
```

C#

```
System.int D1InstanceCount {get; set;}
```

C++/CLI

```
property System.int D1InstanceCount {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of instances of the seed component in Direction 1

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::D1InstanceCount](#).

Example

[Create Local Curve-driven Pattern \(C#\)](#)
[Create Local Curve-driven Pattern \(VB.NET\)](#)
[Create Local Curve-Driven Pattern \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)
[ILocalCurvePatternFeatureData::D1AlignmentMethod Property \(\)](#)
[ILocalCurvePatternFeatureData::D1CurveMethod Property \(\)](#)
[ILocalCurvePatternFeatureData::D1Direction Property \(\)](#)
[ILocalCurvePatternFeatureData::D1IsEqualSpaced Property \(\)](#)
[ILocalCurvePatternFeatureData::D1ReferencePoint Property \(\)](#)
[ILocalCurvePatternFeatureData::D1ReverseDirection Property \(\)](#)
[ILocalCurvePatternFeatureData::D1Spacing Property \(\)](#)
[ILocalCurvePatternFeatureData::D2InstanceCount Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D1IsEqualSpaced Property (ILocalCurvePatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : D1IsEqualSpaced Property (ILocalCurvePatternFeatureData)

Gets or sets whether to use equal spacing between instances of the pattern in Direction 1 for this curve-driven component pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property D1IsEqualSpaced As System.Boolean

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData  
Dim value As System.Boolean
```

```
instance.D1IsEqualSpaced = value
```

```
value = instance.D1IsEqualSpaced
```

C#

```
System.bool D1IsEqualSpaced {get; set;}
```

C++/CLI

```
property System.bool D1IsEqualSpaced {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use equal spacing in Direction 1, false to use the value set by [ILocalCurvePatternFeatureData::D1Spacing](#).

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::D1Spacing](#).

Example

[Create Local Curve-driven Pattern \(C#\)](#)
[Create Local Curve-driven Pattern \(VB.NET\)](#)
[Create Local Curve-Driven Pattern \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)
[ILocalCurvePatternFeatureData::D1AlignmentMethod Property \(\)](#)
[ILocalCurvePatternFeatureData::D1CurveMethod Property \(\)](#)
[ILocalCurvePatternFeatureData::D1InstanceCount Property \(\)](#)
[ILocalCurvePatternFeatureData::D1ReferencePoint Property \(\)](#)
[ILocalCurvePatternFeatureData::D1ReverseDirection Property \(\)](#)
[ILocalCurvePatternFeatureData::D2IsEqualSpaced Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D1ReferencePoint Property (ILocalCurvePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : D1ReferencePoint Property (ILocalCurvePatternFeatureData)

Gets or sets the reference point for Direction 1 for this curve-driven component pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property D1ReferencePoint As System.Integer

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData  
Dim value As System.Integer
```

```
instance.D1ReferencePoint = value
```

```
value = instance.D1ReferencePoint
```

C#

```
System.int D1ReferencePoint {get; set;}
```

C++/CLI

```
property System.int D1ReferencePoint {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Reference point in Direction 1 as defined in [swLocalCurvePatternReferencePoint_e](#)

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::D1ReferencePoint](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

For more information, see the **Curve Driven Component Pattern** topic in the SOLIDWORKS Design user-interface help.

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)
[ILocalCurvePatternFeatureData::D1AlignmentMethod Property \(\)](#)
[ILocalCurvePatternFeatureData::D1CurveMethod Property \(\)](#)
[ILocalCurvePatternFeatureData::D1Direction Property \(\)](#)
[ILocalCurvePatternFeatureData::D1InstanceCount Property \(\)](#)
[ILocalCurvePatternFeatureData::D1IsEqualSpaced Property \(\)](#)

[ILocalCurvePatternFeatureData::D1ReverseDirection Property \(\)](#)
[ILocalCurvePatternFeatureData::D1Spacing Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D1ReverseDirection Property (ILocalCurvePatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : D1ReverseDirection Property (ILocalCurvePatternFeatureData)

Gets or sets whether to reverse the [direction](#) of Direction 1 in this curve-driven component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property D1ReverseDirection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData  
Dim value As System.Boolean
```

```
instance.D1ReverseDirection = value
```

```
value = instance.D1ReverseDirection
```

C#

```
System.bool D1ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool D1ReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the direction of Direction 1, false to not

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::D1ReverseDirection](#).

Example

[Create Local Curve-driven Pattern \(C#\)](#)
[Create Local Curve-driven Pattern \(VB.NET\)](#)
[Create Local Curve-Driven Pattern \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)
[ILocalCurvePatternFeatureData::D1AlignmentMethod Property \(\)](#)
[ILocalCurvePatternFeatureData::D1CurveMethod Property \(\)](#)
[ILocalCurvePatternFeatureData::D1InstanceCount Property \(\)](#)
[ILocalCurvePatternFeatureData::D1IsEqualSpaced Property \(\)](#)
[ILocalCurvePatternFeatureData::D1ReferencePoint Property \(\)](#)
[ILocalCurvePatternFeatureData::D1Spacing Property \(\)](#)
[ILocalCurvePatternFeatureData::D2ReverseDirection Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D1Spacing Property (ILocalCurvePatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : D1Spacing Property (ILocalCurvePatternFeatureData)

Gets or sets the distance between pattern instances in Direction 1 in this curve-driven component pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property D1Spacing As System.Double

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData  
Dim value As System.Double
```

```
instance.D1Spacing = value
```

```
value = instance.D1Spacing
```

C#

```
System.double D1Spacing {get; set;}
```

C++/CLI

```
property System.double D1Spacing {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance between pattern instances in Direction 1 (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::D1Spacing](#).

Example

[Create Local Curve-driven Pattern \(C#\)](#)
[Create Local Curve-driven Pattern \(VB.NET\)](#)
[Create Local Curve-Driven Pattern \(VBA\)](#)

Remarks

To set the spacing between pattern instances, set [ILocalCurvePatternFeatureData::Dir1IsEqualSpaced](#) to false.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)
[ILocalCurvePatternFeatureData::D1AlignmentMethod Property \(\)](#)
[ILocalCurvePatternFeatureData::D1CurveMethod Property \(\)](#)
[ILocalCurvePatternFeatureData::D1Direction Property \(\)](#)
[ILocalCurvePatternFeatureData::D1InstanceCount Property \(\)](#)
[ILocalCurvePatternFeatureData::D1ReferencePoint Property \(\)](#)
[ILocalCurvePatternFeatureData::D1ReverseDirection Property \(\)](#)
[ILocalCurvePatternFeatureData::D2Spacing Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D2Direction Property (ILocalCurvePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : D2Direction Property (ILocalCurvePatternFeatureData)

Gets or sets Direction 2 using the selected curve, edge, sketch, or sketch entity for this bidirectional curve-driven component pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property D2Direction As System.Object

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData  
Dim value As System.Object
```

```
instance.D2Direction = value
```

```
value = instance.D2Direction
```

C#

```
System.object D2Direction {get; set;}
```

C++/CLI

```
property System.Object^ D2Direction {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Curve](#), [edge](#), [sketch](#), or sketch entity for Direction 2

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::D2Direction](#).

Remarks

You must pre-select the direction entity using selection Mark = 1 before creating the feature definition. Use this property only when editing the pattern feature.

[ILocalCurvePatternFeatureData::Dir2Specified](#) must be set to true for this property have an effect.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)
[ILocalCurvePatternFeatureData::D2InstanceCount Property \(\)](#)
[ILocalCurvePatternFeatureData::D2IsEqualSpaced Property \(\)](#)
[ILocalCurvePatternFeatureData::D2PatternSeedOnly Property \(\)](#)
[ILocalCurvePatternFeatureData::D2ReverseDirection Property \(\)](#)
[ILocalCurvePatternFeatureData::D2Spacing Property \(\)](#)
[ILocalCurvePatternFeatureData::D1Direction Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

D2InstanceCount Property (ILocalCurvePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : D2InstanceCount Property (ILocalCurvePatternFeatureData)

Gets or sets the number of instances of the seed component in Direction 2 in this bidirectional curve-driven component pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property D2InstanceCount As System.Integer

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData
Dim value As System.Integer
```

```
instance.D2InstanceCount = value
```

```
value = instance.D2InstanceCount
```

C#

```
System.int D2InstanceCount {get; set;}
```

C++/CLI

```
property System.int D2InstanceCount {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of instances of the seed component in Direction 2

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::D2InstanceCount](#).

Remarks

[ILocalCurvePatternFeatureData::Dir2Specified](#) must be set to true for this property have an effect.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)
[ILocalCurvePatternFeatureData::D2Direction Property \(\)](#)
[ILocalCurvePatternFeatureData::D2IsEqualSpaced Property \(\)](#)
[ILocalCurvePatternFeatureData::D2PatternSeedOnly Property \(\)](#)
[ILocalCurvePatternFeatureData::D2ReverseDirection Property \(\)](#)
[ILocalCurvePatternFeatureData::D2Spacing Property \(\)](#)
[ILocalCurvePatternFeatureData::D1InstanceCount Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

D2IsEqualSpaced Property (ILocalCurvePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : D2IsEqualSpaced Property (ILocalCurvePatternFeatureData)

Gets or sets whether to use equal spacing between instances of the pattern in Direction 2 for this bidirectional curve-driven component pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property D2IsEqualSpaced As System.Boolean

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData
Dim value As System.Boolean

instance.D2IsEqualSpaced = value

value = instance.D2IsEqualSpaced
```

C#

```
System.bool D2IsEqualSpaced {get; set;}
```

C++/CLI

```
property System.bool D2IsEqualSpaced {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use equal spacing in Direction 2, false to use the value set by [ILocalCurvePatternFeatureData::D2Spacing](#)

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::D2Spacing](#).

Remarks

[ILocalCurvePatternFeatureData::Dir2Specified](#) must be set to true for this property have an effect.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)
[ILocalCurvePatternFeatureData::D2Direction Property\(\)](#)
[ILocalCurvePatternFeatureData::D2InstanceCount Property\(\)](#)
[ILocalCurvePatternFeatureData::D2PatternSeedOnly Property\(\)](#)
[ILocalCurvePatternFeatureData::D2ReverseDirection Property\(\)](#)
[ILocalCurvePatternFeatureData::D1IsEqualSpaced Property\(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D2PatternSeedOnly Property (ILocalCurvePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : D2PatternSeedOnly Property (ILocalCurvePatternFeatureData)

Gets or sets whether to only pattern the seed component in Direction 2 in this bidirectional curve-driven component pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property D2PatternSeedOnly As System.Boolean

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData
Dim value As System.Boolean

instance.D2PatternSeedOnly = value

value = instance.D2PatternSeedOnly
```

C#

```
System.bool D2PatternSeedOnly {get; set;}
```

C++/CLI

```
property System.bool D2PatternSeedOnly {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to pattern only the seed component in Direction 2, false to pattern the seed component and all of the pattern instances generated in Direction 1 in Direction 2

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::D2PatternSeedOnly](#).

Remarks

[ILocalCurvePatternFeatureData::Dir2Specified](#) must be set to true for this property have an effect.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)
[ILocalCurvePatternFeatureData::D2Direction Property \(\)](#)
[ILocalCurvePatternFeatureData::D2InstanceCount Property \(\)](#)
[ILocalCurvePatternFeatureData::D2IsEqualSpaced Property \(\)](#)
[ILocalCurvePatternFeatureData::D2ReverseDirection Property \(\)](#)
[ILocalCurvePatternFeatureData::D2Spacing Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D2ReverseDirection Property (ILocalCurvePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : D2ReverseDirection Property (ILocalCurvePatternFeatureData)

Gets or sets whether to reverse the [direction](#) of Direction 2 in this bidirectional curve-driven component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property D2ReverseDirection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData
Dim value As System.Boolean

instance.D2ReverseDirection = value

value = instance.D2ReverseDirection
```

C#

```
System.bool D2ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool D2ReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the direction of Direction 2, false to not

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::D2ReverseDirection](#).

Remarks

[ILocalCurvePatternFeatureData::Dir2Specified](#) must be set to true for this property have an effect.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)
[ILocalCurvePatternFeatureData::D2Direction Property \(\)](#)
[ILocalCurvePatternFeatureData::D2InstanceCount Property \(\)](#)
[ILocalCurvePatternFeatureData::D2IsEqualSpaced Property \(\)](#)
[ILocalCurvePatternFeatureData::D2PatternSeedOnly Property \(\)](#)
[ILocalCurvePatternFeatureData::D2Spacing Property \(\)](#)
[ILocalCurvePatternFeatureData::D1ReverseDirection Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D2Spacing Property (ILocalCurvePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : D2Spacing Property (ILocalCurvePatternFeatureData)

Gets or sets the distance between pattern instances in Direction 2 in this bidirectional curve-driven component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property D2Spacing As System.Double
```

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData  
Dim value As System.Double  
  
instance.D2Spacing = value  
  
value = instance.D2Spacing
```

C#

```
System.double D2Spacing {get; set;}
```

C++/CLI

```
property System.double D2Spacing {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance between pattern instances in Direction 2 (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::D2Spacing](#).

Remarks

[ILocalCurvePatternFeatureData::Dir2Specified](#) must be set to true for this property have an effect. To set the spacing between pattern instances set [ILocalCurvePatternFeatureData::D2IsEqualSpaced](#) to false.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)
[ILocalCurvePatternFeatureData::D2Direction Property \(\)](#)
[ILocalCurvePatternFeatureData::D2InstanceCount Property \(\)](#)
[ILocalCurvePatternFeatureData::D2PatternSeedOnly Property \(\)](#)
[ILocalCurvePatternFeatureData::D2ReverseDirection Property \(\)](#)
[ILocalCurvePatternFeatureData::D1Spacing Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Dir2Specified Property (ILocalCurvePatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : Dir2Specified Property (ILocalCurvePatternFeatureData)

Gets or sets whether to create a bidirectional pattern for this curve-driven component pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property Dir2Specified As System.Boolean

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData
Dim value As System.Boolean
```

```
instance.Dir2Specified = value
```

```
value = instance.Dir2Specified
```

C#

```
System.bool Dir2Specified {get; set;}
```

C++/CLI

```
property System.bool Dir2Specified {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to create a bidirectional pattern, false to create the pattern in Direction 1 only

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::Dir2Specified](#).

Example

[Create Local Curve-driven Pattern \(C#\)](#)
[Create Local Curve-driven Pattern \(VB.NET\)](#)
[Create Local Curve-Driven Pattern \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)
[ILocalCurvePatternFeatureData::D2Direction Property \(\)](#)
[ILocalCurvePatternFeatureData::D2InstanceCount Property \(\)](#)
[ILocalCurvePatternFeatureData::D2IsEqualSpaced Property \(\)](#)
[ILocalCurvePatternFeatureData::D2PatternSeedOnly Property \(\)](#)
[ILocalCurvePatternFeatureData::D2ReverseDirection Property \(\)](#)
[ILocalCurvePatternFeatureData::D2Spacing Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ForceUseSeedConfiguration Property (ILocalCurvePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : ForceUseSeedConfiguration Property (ILocalCurvePatternFeatureData)

Gets or sets whether to synchronize the configuration of pattern components with the configuration of the seed component in this local curve pattern feature.

.NET Syntax

Visual Basic (Declaration)

Property ForceUseSeedConfiguration As System.Boolean

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData  
Dim value As System.Boolean
```

```
instance.ForceUseSeedConfiguration = value
```

```
value = instance.ForceUseSeedConfiguration
```

C#

```
System.bool ForceUseSeedConfiguration {get; set;}
```

C++/CLI

```
property System.bool ForceUseSeedConfiguration {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the seed component configuration for all pattern components, false to not

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::ForceUseSeedConfiguration](#).

Remarks

If this property is set to true, the **Referenced configuration** section of the Component Properties dialog is disabled, and you cannot use [IComponent2::ReferencedConfiguration](#) to change the pattern instance configuration.

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)

Availability

SOLIDWORKS 2021 FCS, Revision Number 29

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPatternComponentCount Method (ILocalCurvePatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : GetPatternComponentCount Method (ILocalCurvePatternFeatureData)

Gets the number of components in this curve-driven component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPatternComponentCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData  
Dim value As System.Integer  
  
value = instance.GetPatternComponentCount()
```

C#

```
System.int GetPatternComponentCount()
```

C++/CLI

```
System.int GetPatternComponentCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of components

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::GetPatternComponentCount](#).

Example

[Create Local Curve-driven Pattern \(C#\)](#)
[Create Local Curve-driven Pattern \(VB.NET\)](#)
[Create Local Curve-driven Pattern \(VBA\)](#)

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)
[ILocalCurvePatternFeatureData::PatternComponentArray Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSkippedItemCount Method (ILocalCurvePatternFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : GetSkippedItemCount Method (ILocalCurvePatternFeatureData)

Gets the number of components skipped in this curve-driven component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSkippedItemCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData
Dim value As System.Integer

value = instance.GetSkippedItemCount()
```

C#

```
System.int GetSkippedItemCount()
```

C++/CLI

```
System.int GetSkippedItemCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of components skipped

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::GetSkippedItemCount](#).

Example

[Create Local Curve-driven Pattern \(C#\)](#)
[Create Local Curve-driven Pattern \(VB.NET\)](#)
[Create Local Curve-driven Pattern \(VBA\)](#)

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)
[ILocalCurveDrivenPatternFeature::SkippedItemArray Property\(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTransform Method (ILocalCurvePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : GetTransform Method (ILocalCurvePatternFeatureData)

Gets the transform for the specified instance in this curve-driven component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTransform( _  
    ByVal Instance As System.Integer _  
) As MathTransform
```

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData  
Dim Instance As System.Integer  
Dim value As MathTransform  
  
value = instance.GetTransform(Instance)
```

C#

```
MathTransform GetTransform(  
    System.int Instance  
)
```

C++/CLI

```
MathTransform^ GetTransform(  
&    System.int Instance  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Instance
Index of one repeating element in this sketch-driven component pattern feature (see **Remarks**)

Return Value

[Transform](#)

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::GetTransform](#).

Remarks

Valid values for Instance are 1 <= Instance <= [ILocalCurvePatternFeatureData::GetPatternComponentCount](#).

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PatternComponentArray Property (ILocalCurvePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : PatternComponentArray Property (ILocalCurvePatternFeatureData)

Gets or sets the components in this curve-driven component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property PatternComponentArray As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData
Dim value As System.Object

instance.PatternComponentArray = value
value = instance.PatternComponentArray
```

C#

```
System.Object PatternComponentArray {get; set;}
```

C++/CLI

```
property System.Object^ PatternComponentArray {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [components](#) in this local curve-driven pattern feature

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::PatternComponentArray](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)
[ILocalCurvePatternFeatureData::GetPatternComponentCount Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReleaseSelectionAccess Method (ILocalCurvePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : ReleaseSelectionAccess Method (ILocalCurvePatternFeatureData)

Releases access to the selections for this curve-driven component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData

instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::ReleaseSelectionAccess](#).

Remarks

[ILocalCurvePatternFeatureData::AccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature. Use this method to restore the rollback state if you did not modify the feature, or use [IFeature::ModifyDefinition](#) if you did.

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SelectedPoint Property (ILocalCurvePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : SelectedPoint Property (ILocalCurvePatternFeatureData)

Gets or sets the reference point for this curve-driven component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property SelectedPoint As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData  
Dim value As System.Object
```

```
instance.SelectedPoint = value
```

```
value = instance.SelectedPoint
```

C#

```
System.object SelectedPoint {get; set;}
```

C++/CLI

```
property System.Object^ SelectedPoint {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Reference point (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::SelectedPoint](#).

Remarks

You can pre-select the reference point using Mark = 32 before creating the feature definition.

This property is valid only if [ILocalCurvePatternFeatureData::D1ReferencePoint](#) is set to [swLocalCurvePatternReferencePoint_e.swLocalCurvePatternSelectedPoint](#).

See [Accessing Selections that Define Features](#) for additional details on using this property.

For more information, see the **Curve Driven Component Pattern** topic in the SOLIDWORKS Design user-interface help.

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SkippedItemArray Property (ILocalCurvePatternFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILocalCurvePatternFeatureData Interface](#) : SkippedItemArray Property (ILocalCurvePatternFeatureData)

Gets or sets the array of skipped components in this curve-driven component pattern feature.

.NET Syntax

Visual Basic (Declaration)

```
Property SkippedItemArray As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILocalCurvePatternFeatureData  
Dim value As System.Object
```

```
instance.SkippedItemArray = value
```

```
value = instance.SkippedItemArray
```

C#

```
System.object SkippedItemArray {get; set;}
```

C++/CLI

```
property System.Object^ SkippedItemArray {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of integers representing the skipped components

Visual Basic for Applications (VBA) Syntax

See [LocalCurvePatternFeatureData::SkippedItemArray](#).

Remarks

This array is 0-based. If you skip the third and fifth components, then the array looks like ArrayOut[0]=3 and ArrayOut[1]=5.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILocalCurvePatternFeatureData Interface](#)
[ILocalCurvePatternFeatureData Members](#)
[ILocalCurvePatternFeatureData::GetSkippedItemCount Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0