

SOLIDWORKS API (.NET VBA C#) — Reference (147/337): ILoftFeatureData

SOLIDWORKS API Documentation (converted from CHM)

I LoftFeatureData (Type)

I LoftFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : I LoftFeatureData Interface

Allows access to a loft feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ILoftFeatureData
```

Visual Basic (Usage)

```
Dim instance As ILoftFeatureData
```

C#

```
public interface ILoftFeatureData
```

C++/CLI

```
public interface class ILoftFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData](#).

Example

[Get Guide Curves in Loft Feature \(C#\)](#)
[Get Guide Curves in Loft Feature \(VB.NET\)](#)
[Get Guide Curves in Loft Feature \(VBA\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[LoftFeatureData](#)

See Also

[ILoftFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertCutBlend Method](#)
[IFeatureManager::InsertProtrusionBlend Method](#)

I LoftFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : I LoftFeatureData Interface

The following tables list the members exposed by [ILoiftFeatureData](#).

Public Properties

Name	Description
AdvancedSmoothing	Gets or sets whether to enable advanced smoothing for this loft feature.
AutoSelect	Gets or sets whether to automatically select all or only specific bodies for the loft feature to affect in a multibody part.

		
	Centerline	Gets and sets the centerline for this loft feature.
	Close	Gets or sets whether to close this loft feature.
	EndConstraintApplyToAll	Gets whether an end constraint was applied to this loft feature. NOTE: This property is a get-only property. Set is not implemented.
	EndConstraintDraftAngle	Gets or sets the draft angle for the end constraint for the loft feature.
	EndConstraintDraftAngleDirection	Gets or sets the direction of the angle of the draft for the end constraint for the loft feature.
	EndDirectionVector	Gets or sets the direction vector in which to end this loft feature.
	EndTangencyType	Gets or sets the end tangency type for this loft feature.
	EndTangentLength	Gets or sets the end tangent length for this loft feature.
	FeatureScope	Gets or sets whether to use scope for the loft feature in a multibody part.
	FeatureScopeBodies	Gets or sets the solid bodies that the loft feature affects in a multibody part.
	GuideCurveInfluence	Gets or sets the type of guide curve influence for this loft feature.
	GuideCurves	Gets and sets the guide curves for this loft feature.
	MaintainTangency	Gets or sets whether to maintain tangency for this loft feature.
	Merge	Gets or sets whether to merge the results of this loft feature in a multibody part.
	NumberOfSections	Gets and sets the number of sections in this loft feature.
	PickPoints	Gets or sets the pick points of a loft feature.
	Profiles	Gets and sets the profiles for this loft feature.
	ReverseEndTangentDirection	Reverses the tangent direction for the end point of this loft feature.
	ReverseStartTangentDirection	Reverses the tangent direction for the start point of this loft feature.
	StartConstraintApplyToAll	Gets whether a start constraint was applied to this loft feature. NOTE: This property is a get-only property. Set is not implemented.
	StartConstraintDraftAngle	Gets or sets the angle of the draft for the start constraint of the loft feature.
	StartConstraintDraftAngleDirection	Gets or sets the direction of the angle of the draft for the start constraint for the loft feature.
	StartDirectionVector	Gets or sets the direction vector in which to start this loft feature.
	StartTangencyType	Gets or sets the start tangency type for this loft feature.
	StartTangentLength	Gets or sets the start tangent length for this loft feature.
	ThinWallType	Gets or sets the thin wall type for this loft feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Accesses the selections used to define the loft feature.
 GetFeatureScopeBodiesCount	Gets the number of solid bodies affected by the loft feature in a multibody part.
 GetGuideCurvesCount	Gets the number of guide curves for this loft feature.
 GetGuideCurvesType	Gets the guide curve types for this loft feature.
 GetGuideTangencyType	Gets the tangency type of the guide curve (i.e., controls the tangency where the loft meets the guide curves) for this loft feature.
 GetProfileCount	Gets the number of profiles associated with this loft feature.
 GetWallThickness	Gets the wall thickness in the specified direction for this loft feature.
 IAccessSelections	Accesses the selections used to define the loft feature.
 IGetFeatureScopeBodies	Gets the solid bodies that the loft feature affects in a multibody part.
 IGetGuideCurves	Gets the guide curves for this loft feature.

	IGetGuideCurvesType	Gets the guide curve types for this loft feature.
	IGetProfiles	Gets the profiles associated with this loft feature.
	IsBossFeature	Gets whether the loft feature is a boss feature.
	ISetFeatureScopeBodies	Sets the solid bodies that the loft feature affects in a multibody part.
	ISetGuideCurves	Sets the guide curves for this loft feature.
	ISetProfiles	Sets the profiles for this loft feature.
	IsThinFeature	Gets whether this loft feature is a thin feature.
	ReleaseSelectionAccess	Releases access to the selections for this loft feature.
	SetGuideTangencyType	Sets the tangency type of the guide curve (i.e., controls the tangency where the loft meets the guide curves) for this loft feature.
	SetWallThickness	Sets the wall thickness for this loft feature in the forward or reverse direction.

[Top](#)

 See Also

[ILoftFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertCutBlend Method](#)
[IFeatureManager::InsertProtrusionBlend Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ILoftFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ILoftFeatureData Interface

For a list of all members of this type, see [ILoftFeatureData members](#).

 Public Methods

Name	Description
 AccessSelections	Accesses the selections used to define the loft feature.
 GetFeatureScopeBodiesCount	Gets the number of solid bodies affected by the loft feature in a multibody part.
 GetGuideCurvesCount	Gets the number of guide curves for this loft feature.
 GetGuideCurvesType	Gets the guide curve types for this loft feature.
 GetGuideTangencyType	Gets the tangency type of the guide curve (i.e., controls the tangency where the loft meets the guide curves) for this loft feature.
 GetProfileCount	Gets the number of profiles associated with this loft feature.
 GetWallThickness	Gets the wall thickness in the specified direction for this loft feature.
 IAccessSelections	Accesses the selections used to define the loft feature.
 IGetFeatureScopeBodies	Gets the solid bodies that the loft feature affects in a multibody part.
 IGetGuideCurves	Gets the guide curves for this loft feature.
 IGetGuideCurvesType	Gets the guide curve types for this loft feature.
 IGetProfiles	Gets the profiles associated with this loft feature.
 IsBossFeature	Gets whether the loft feature is a boss feature.
 ISetFeatureScopeBodies	Sets the solid bodies that the loft feature affects in a multibody part.
 ISetGuideCurves	Sets the guide curves for this loft feature.
 ISetProfiles	Sets the profiles for this loft feature.
 IsThinFeature	Gets whether this loft feature is a thin feature.
 ReleaseSelectionAccess	Releases access to the selections for this loft feature.
 SetGuideTangencyType	Sets the tangency type of the guide curve (i.e., controls the tangency where the loft meets the guide curves) for this loft feature.
 SetWallThickness	Sets the wall thickness for this loft feature in the forward or reverse direction.

See Also

[ILoftFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertCutBlend Method](#)
[IFeatureManager::InsertProtrusionBlend Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ILoftFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ILoftFeatureData Interface

For a list of all members of this type, see [ILoftFeatureData members](#).

Public Properties

Name	Description
 AdvancedSmoothing	Gets or sets whether to enable advanced smoothing for this loft feature.
 AutoSelect	Gets or sets whether to automatically select all or only specific bodies for the loft feature to affect in a multibody part.
 Centerline	Gets and sets the centerline for this loft feature.
 Close	Gets or sets whether to close this loft feature.
 EndConstraintApplyToAll	Gets whether an end constraint was applied to this loft feature. NOTE: This property is a get-only property. Set is not implemented.
 EndConstraintDraftAngle	Gets or sets the draft angle for the end constraint for the loft feature.
 EndConstraintDraftAngleDirection	Gets or sets the direction of the angle of the draft for the end constraint for the loft feature.
 EndDirectionVector	Gets or sets the direction vector in which to end this loft feature.
 EndTangencyType	Gets or sets the end tangency type for this loft feature.
 EndTangentLength	Gets or sets the end tangent length for this loft feature.
 FeatureScope	Gets or sets whether to use scope for the loft feature in a multibody part.
 FeatureScopeBodies	Gets or sets the solid bodies that the loft feature affects in a multibody part.
 GuideCurveInfluence	Gets or sets the type of guide curve influence for this loft feature.
 GuideCurves	Gets and sets the guide curves for this loft feature.
 MaintainTangency	Gets or sets whether to maintain tangency for this loft feature.
 Merge	Gets or sets whether to merge the results of this loft feature in a multibody part.
 NumberOfSections	Gets and sets the number of sections in this loft feature.
 PickPoints	Gets or sets the pick points of a loft feature.
 Profiles	Gets and sets the profiles for this loft feature.
 ReverseEndTangentDirection	Reverses the tangent direction for the end point of this loft feature.
 ReverseStartTangentDirection	Reverses the tangent direction for the start point of this loft feature.
 StartConstraintApplyToAll	Gets whether a start constraint was applied to this loft feature. NOTE: This property is a get-only property. Set is not implemented.
 StartConstraintDraftAngle	Gets or sets the angle of the draft for the start constraint of the loft feature.
 StartConstraintDraftAngleDirection	Gets or sets the direction of the angle of the draft for the start constraint for the loft feature.
 StartDirectionVector	Gets or sets the direction vector in which to start this loft feature.
 StartTangencyType	Gets or sets the start tangency type for this loft feature.
 StartTangentLength	Gets or sets the start tangent length for this loft feature.
 ThinWallType	Gets or sets the thin wall type for this loft feature.

[Top](#)

See Also

[ILoftFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertCutBlend Method](#)
[IFeatureManager::InsertProtrusionBlend Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (ILoftFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : AccessSelections Method (ILoftFeatureData)

Accesses the selections used to define the loft feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document (see **Remarks**)
Component
Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were accessed successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::AccessSelections](#).

Example

[Get Guide Curves in Loft Feature \(C#\)](#)
[Get Guide Curves in Loft Feature \(VB.NET\)](#)
[Get Guide Curves in Loft Feature \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [ILoftFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::IAccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

AdvancedSmoothing Property (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : AdvancedSmoothing Property (ILoftFeatureData)

Gets or sets whether to enable advanced smoothing for this loft feature.

.NET Syntax

Visual Basic (Declaration)

Property AdvancedSmoothing As System.Boolean

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData
Dim value As System.Boolean

instance.AdvancedSmoothing = value

value = instance.AdvancedSmoothing
```

C#

```
System.bool AdvancedSmoothing {get; set;}
```

C++/CLI

```
property System.bool AdvancedSmoothing {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True enables advanced smoothing, false disables it

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::AdvancedSmoothing](#).

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)

Availability

AutoSelect Property (ILoftFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : AutoSelect Property (ILoftFeatureData)

Gets or sets whether to automatically select all or only specific bodies for the loft feature to affect in a multibody part.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property AutoSelect As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim value As System.Boolean
```

```
instance.AutoSelect = value
```

```
value = instance.AutoSelect
```

C#

```
System.bool AutoSelect {get; set;}
```

C++/CLI

```
property System.bool AutoSelect {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to automatically select all bodies, false to select specific bodies for [ILoftFeatureData::FeatureScopeBodies](#) or [ILoftFeatureData::ISetFeatureScopeBodies](#)

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::AutoSelect](#).

Remarks

This property is only available when the [ILoftFeatureData::FeatureScope](#) property is true. The loft feature is expanded along the plane on which the feature is created and selects all or only the specified bodies it intersects.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::GetFeatureScopeBodiesCount Method](#)
[ILoftFeatureData::ISetFeatureScopeBodies Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

Centerline Property (ILoftFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : Centerline Property (ILoftFeatureData)

Gets and sets the centerline for this loft feature.

.NET Syntax

Visual Basic (Declaration)

Property Centerline As System.Object

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim value As System.Object  
  
instance.Centerline = value  
value = instance.Centerline
```

C#

```
System.object Centerline {get; set;}
```

C++/CLI

```
property System.Object^ Centerline {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[ICenterLine](#)

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::CenterLine](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Close Property (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : Close Property (ILoftFeatureData)

Gets or sets whether to close this loft feature.

.NET Syntax

Visual Basic (Declaration)

Property Close As System.Boolean

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim value As System.Boolean
```

```
instance.Close = value  
value = instance.Close
```

C#

```
System.bool Close {get; set;}
```

C++/CLI

```
property System.bool Close {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True for closed loft features, false for open

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::Close](#).

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EndConstraintApplyToAll Property (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : EndConstraintApplyToAll Property (ILoftFeatureData)

Gets whether an end constraint was applied to this loft feature.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property EndConstraintApplyToAll As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim value As System.Boolean  
  
instance.EndConstraintApplyToAll = value  
value = instance.EndConstraintApplyToAll
```

C#

```
System.bool EndConstraintApplyToAll {get; set;}
```

C++/CLI

```
property System.bool EndConstraintApplyToAll {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if an end constraint was specified, false if not

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::EndConstraintApplyToAll](#).

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::EndConstraintDraftAngle Property](#)
[ILoftFeatureData::EndConstraintDraftAngleDirection Property](#)
[ILoftFeatureData::StartConstraintApplyToAll Property](#)
[ILoftFeatureData::StartConstraintDraftAngle Property](#)
[ILoftFeatureData::StartConstraintDraftAngleDirection Property](#)
[ILoftFeatureData::GetGuideTangencyType Method](#)
[ILoftFeatureData::SetGuideTangencyType Method](#)
[ILoftFeatureData::EndTangencyType Property](#)
[ILoftFeatureData::EndTangentLength Property](#)
[ILoftFeatureData::MaintainTangency Property](#)
[ILoftFeatureData::ReverseEndTangentDirection Property](#)
[ILoftFeatureData::ReverseStartTangentDirection Property](#)
[ILoftFeatureData::StartTangencyType Property](#)
[ILoftFeatureData::StartTangentLength Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

EndConstraintDraftAngle Property (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : EndConstraintDraftAngle Property (ILoftFeatureData)

Gets or sets the draft angle for the end constraint for the loft feature.

.NET Syntax

Visual Basic (Declaration)

Property EndConstraintDraftAngle As System.Double

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData
Dim value As System.Double

instance.EndConstraintDraftAngle = value

value = instance.EndConstraintDraftAngle
```

C#

```
System.double EndConstraintDraftAngle {get; set;}
```

C++/CLI

```
property System.double EndConstraintDraftAngle {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Draft angle

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::EndConstraintDraftAngle](#).

Remarks

This property is only valid if [ILoftFeatureData::StartConstraintApplyToAll](#) and [ILoftFeatureData::EndConstraintApplyToAll](#) are True.

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::EndConstraintDraftAngleDirection Property](#)
[ILoftFeatureData::StartConstraintDraftAngle Property](#)
[ILoftFeatureData::StartConstraintDraftAngleDirection Property](#)
[ILoftFeatureData::StartTangentLength Property](#)
[ILoftFeatureData::StartTangencyType Property](#)
[ILoftFeatureData::ReverseStartTangentDirection Property](#)
[ILoftFeatureData::ReverseEndTangentDirection Property](#)
[ILoftFeatureData::MaintainTangency Property](#)
[ILoftFeatureData::EndTangentLength Property](#)
[ILoftFeatureData::EndTangencyType Property](#)
[ILoftFeatureData::SetGuideTangencyType Method](#)
[ILoftFeatureData::GetGuideTangencyType Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EndConstraintDraftAngleDirection Property (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : EndConstraintDraftAngleDirection Property (ILoftFeatureData)

Gets or sets the direction of the angle of the draft for the end constraint for the loft feature.

.NET Syntax

Visual Basic (Declaration)

Property EndConstraintDraftAngleDirection As System.Boolean

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim value As System.Boolean
```

```
instance.EndConstraintDraftAngleDirection = value
```

```
value = instance.EndConstraintDraftAngleDirection
```

C#

```
System.bool EndConstraintDraftAngleDirection {get; set;}
```

C++/CLI

```
property System.bool EndConstraintDraftAngleDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the direction of the draft angle is reversed, false if not

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::EndConstraintDraftAngleDirection](#).

Remarks

This property is only valid if [ILoftFeatureData::StartConstraintApplyToAll](#) and [ILoftFeatureData::EndConstraintApplyToAll](#) are True.

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::EndConstraintDraftAngle Property](#)
[ILoftFeatureData::StartConstraintDraftAngle Property](#)
[ILoftFeatureData::StartConstraintDraftAngleDirection Property](#)
[ILoftFeatureData::GetGuideTangencyType Method](#)
[ILoftFeatureData::SetGuideTangencyType Method](#)
[ILoftFeatureData::EndTangencyType Property](#)
[ILoftFeatureData::EndTangentLength Property](#)
[ILoftFeatureData::MaintainTangency Property](#)
[ILoftFeatureData::ReverseEndTangentDirection Property](#)
[ILoftFeatureData::ReverseStartTangentDirection Property](#)
[ILoftFeatureData::StartTangencyType Property](#)
[ILoftFeatureData::StartTangentLength Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EndDirectionVector Property (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : EndDirectionVector Property (ILoftFeatureData)

Gets or sets the direction vector in which to end this loft feature.

.NET Syntax

Visual Basic (Declaration)

Property EndDirectionVector As System.Object

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim value As System.Object
```

```
instance.EndDirectionVector = value
```

```
value = instance.EndDirectionVector
```

C#

```
System.object EndDirectionVector {get; set;}
```

C++/CLI

```
property System.Object^ EndDirectionVector {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

End direction vector

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::EndDirectionVector](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::StartDirectionVector Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EndTangencyType Property (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : EndTangencyType Property (ILoftFeatureData)

Gets or sets the end tangency type for this loft feature.

Visual Basic Syntax

Visual Basic (Declaration)

Property EndTangencyType As System.Short

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim value As System.Short
```

```
instance.EndTangencyType = value
```

```
value = instance.EndTangencyType
```

C#

```
System.short EndTangencyType {get; set;}
```

C++/CLI

```
property System.short EndTangencyType {  
    System.short get();  
    void set ( & System.short value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

End tangency type as defined in [swTangencyType_e](#)

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::EndTangencyType](#).

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::EndTangentLength Property](#)
[ILoftFeatureData::StartTangencyType Property](#)
[ILoftFeatureData::StartTangentLength Property](#)
[ILoftFeatureData::StartConstraintDraftAngleDirection Property](#)
[ILoftFeatureData::StartConstraintDraftAngle Property](#)
[ILoftFeatureData::StartConstraintApplyToAll Property](#)
[ILoftFeatureData::ReverseStartTangentDirection Property](#)
[ILoftFeatureData::ReverseEndTangentDirection Property](#)
[ILoftFeatureData::MaintainTangency Property](#)
[ILoftFeatureData::EndConstraintDraftAngleDirection Property](#)
[ILoftFeatureData::EndConstraintDraftAngle Property](#)
[ILoftFeatureData::EndConstraintApplyToAll Property](#)
[ILoftFeatureData::SetGuideTangencyType Method](#)
[ILoftFeatureData::GetGuideTangencyType Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EndTangentLength Property (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : EndTangentLength Property (ILoftFeatureData)

Gets or sets the end tangent length for this loft feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property EndTangentLength As System.Double
```

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim value As System.Double
```

```
instance.EndTangentLength = value
```

```
value = instance.EndTangentLength
```

C#

```
System.double EndTangentLength {get; set;}
```

C++/CLI

```
property System.double EndTangentLength {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

End tangent length

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::EndTangentLength](#).

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::EndTangencyType Property](#)
[ILoftFeatureData::StartTangencyType Property](#)
[ILoftFeatureData::StartTangentLength Property](#)
[ILoftFeatureData::GetGuideTangencyType Method](#)
[ILoftFeatureData::SetGuideTangencyType Method](#)
[ILoftFeatureData::EndConstraintApplyToAll Property](#)
[ILoftFeatureData::EndConstraintDraftAngle Property](#)
[ILoftFeatureData::EndConstraintDraftAngleDirection Property](#)
[ILoftFeatureData::MaintainTangency Property](#)
[ILoftFeatureData::ReverseEndTangentDirection Property](#)
[ILoftFeatureData::ReverseStartTangentDirection Property](#)
[ILoftFeatureData::StartConstraintApplyToAll Property](#)
[ILoftFeatureData::StartConstraintDraftAngle Property](#)
[ILoftFeatureData::StartConstraintDraftAngleDirection Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

FeatureScope Property (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : FeatureScope Property (ILoftFeatureData)

Gets or sets whether to use scope for the loft feature in a multibody part.

Visual Basic Syntax

Visual Basic (Declaration)

Property FeatureScope As System.Boolean

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim value As System.Boolean
```

```
instance.FeatureScope = value
```

```
value = instance.FeatureScope
```

C#

```
System.bool FeatureScope {get; set;}
```

C++/CLI

```
property System.bool FeatureScope {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

When:

- true, only the specified bodies in the multibody part are affected by the loft feature
- false, all of the bodies in the multibody part are affected by the loft feature

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::FeatureScope](#).

Remarks

The loft feature is expanded along the plane on which the feature is created and affects all or only the specified bodies it intersects.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::GetFeatureScopeBodiesCount Method](#)
[ILoftFeatureData::IGetFeatureScopeBodies Method](#)
[ILoftFeatureData::ISetFeatureScopeBodies Method](#)
[ILoftFeatureData::AutoSelect Property](#)
[ILoftFeatureData::FeatureScopeBodies Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

FeatureScopeBodies Property (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : FeatureScopeBodies Property (ILoftFeatureData)

Gets or sets the solid bodies that the loft feature affects in a multibody part.

.NET Syntax

Visual Basic (Declaration)

Property FeatureScopeBodies As System.Object

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData
Dim value As System.Object

instance.FeatureScopeBodies = value

value = instance.FeatureScopeBodies
```

C#

```
System.Object FeatureScopeBodies {get; set;}
```

C++/CLI

```
property System.Object^ FeatureScopeBodies {
    System.Object^ get();
    void set ( &    System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of solid [bodies](#) that the feature affects

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::FeatureScopeBodies](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData.GetFeatureScopeBodiesCount Method](#)
[ILoftFeatureData.IGetFeatureScopeBodies Method](#)
[ILoftFeatureData.ISetFeatureScopeBodies Method](#)
[ILoftFeatureData.AutoSelect Property](#)
[ILoftFeatureData.FeatureScope Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFeatureScopeBodiesCount Method (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : GetFeatureScopeBodiesCount Method (ILoftFeatureData)

Gets the number of solid bodies affected by the loft feature in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeatureScopeBodiesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData
Dim value As System.Integer
```

```
value = instance.GetFeatureScopeBodiesCount()
```

C#

```
System.int GetFeatureScopeBodiesCount()
```

C++/CLI

```
System.int GetFeatureScopeBodiesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of solid bodies affected by the loft feature in a multibody part

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::GetFeatureScopeBodiesCount](#).

Remarks

Call this method before calling [ILoftFeatureData::IGetFeatureScopeBodies](#) to determine the size of the array for that method.

If [ILoftFeatureData::FeatureScope](#) is false, then the return value will be 0.

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::ISetFeatureScopeBodies Method](#)
[ILoftFeatureData::FeatureScopeBodies Property](#)
[ILoftFeatureData::AutoSelect Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetGuideCurvesCount Method (ILoftFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : GetGuideCurvesCount Method (ILoftFeatureData)

Gets the number of guide curves for this loft feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetGuideCurvesCount() As System.Short
```

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim value As System.Short
```

```
value = instance.GetGuideCurvesCount()
```

C#

```
System.short GetGuideCurvesCount()
```

C++/CLI

```
System.short GetGuideCurvesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of guide curves

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::GetGuideCurvesCount](#).

Example

[Get Guide Curves in Loft Feature \(C#\)](#)
[Get Guide Curves in Loft Feature \(VB.NET\)](#)
[Get Guide Curves in Loft Feature \(VBA\)](#)

Remarks

Call this method before calling [ILoftFeatureData::IGetGuideCurves](#) to determine the size of the array for that method.

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::GetGuideCurvesType Method](#)
[ILoftFeatureData::IGetGuideCurvesType Method](#)
[ILoftFeatureData::ISetGuideCurves Method](#)
[ILoftFeatureData::GuideCurveInfluence Property](#)
[ILoftFeatureData::GuideCurves Property](#)
[ILoftFeatureData::GetGuideTangencyType Method](#)
[ILoftFeatureData::SetGuideTangencyType Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetGuideCurvesType Method (ILoftFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : GetGuideCurvesType Method (ILoftFeatureData)

Gets the guide curve types for this loft feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetGuideCurvesType() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData
Dim value As System.Object

value = instance.GetGuideCurvesType()
```

C#

```
System.object GetGuideCurvesType()
```

C++/CLI

```
System.Object^ GetGuideCurvesType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of types of guide curves as defined in [swSelectType_e](#)

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::GetGuideCurvesType](#).

Example

[Get Guide Curves in Loft Feature \(C#\)](#)
[Get Guide Curves in Loft Feature \(VB.NET\)](#)
[Get Guide Curves in Loft Feature \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::IGetGuideCurvesType Method](#)
[ILoftFeatureData::ISetGuideCurves Method](#)
[ILoftFeatureData::GuideCurveInfluence Property](#)
[ILoftFeatureData::GuideCurves Property](#)
[ILoftFeatureData::GetGuideTangencyType Method](#)
[ILoftFeatureData::SetGuideTangencyType Method](#)
[ILoftFeatureData::GetGuideCurvesCount Method](#)
[ILoftFeatureData::IGetGuideCurves Method](#)

Availability

SOLIDWORKS 2001Plus SP3, Revision Number 10.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetGuideTangencyType Method (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : GetGuideTangencyType Method (ILoftFeatureData)

Gets the tangency type of the guide curve (i.e., controls the tangency where the loft meets the guide curves) for this loft feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetGuideTangencyType( _  
    ByVal GuideIndex As System.Short _  
) As System.Short
```

Visual Basic (Usage)

```
Dim instance As ILoftFeatureData  
Dim GuideIndex As System.Short  
Dim value As System.Short
```

```
value = instance.GetGuideTangencyType(GuideIndex)
```

C#

```
System.short GetGuideTangencyType(  
    System.short GuideIndex  
)
```

C++/CLI

```
System.short GetGuideTangencyType(  
&    System.short GuideIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

GuideIndex

Index of the guide tangency type

Return Value

Tangency type of the guide curve as defined in [swTangencyType_e](#)

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::GetGuideTangencyType](#).

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::SetGuideTangencyType Method](#)
[ILoftFeatureData::GetGuideCurvesCount Method](#)
[ILoftFeatureData::GetGuideCurvesType Method](#)
[ILoftFeatureData::IGetGuideCurves Method](#)
[ILoftFeatureData::IGetGuideCurvesType Method](#)
[ILoftFeatureData::ISetGuideCurves Method](#)
[ILoftFeatureData::GuideCurves Property](#)
[ILoftFeatureData::GuideCurveInfluence Property](#)
[ILoftFeatureData::EndConstraintApplyToAll Property](#)
[ILoftFeatureData::EndConstraintDraftAngle Property](#)
[ILoftFeatureData::EndConstraintDraftAngleDirection Property](#)
[ILoftFeatureData::EndTangencyType Property](#)
[ILoftFeatureData::EndTangentLength Property](#)
[ILoftFeatureData::MaintainTangency Property](#)
[ILoftFeatureData::StartConstraintApplyToAll Property](#)
[ILoftFeatureData::StartConstraintDraftAngle Property](#)
[ILoftFeatureData::StartConstraintDraftAngleDirection Property](#)
[ILoftFeatureData::StartTangencyType Property](#)
[ILoftFeatureData::StartTangentLength Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetProfileCount Method (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : GetProfileCount Method (ILoftFeatureData)

Gets the number of profiles associated with this loft feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetProfileCount() As System.Short
```

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim value As System.Short  
  
value = instance.GetProfileCount()
```

C#

```
System.short GetProfileCount()
```

C++/CLI

```
System.short GetProfileCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of profiles

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::GetProfileCount](#).

Remarks

Call this method before calling [ILoftFeatureData::IGetProfiles](#) to determine the size of the array for that method.

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::ISetProfiles Method](#)
[ILoftFeatureData::Profiles Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetWallThickness Method (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : GetWallThickness Method (ILoftFeatureData)

Gets the wall thickness in the specified direction for this loft feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetWallThickness( _  
    ByVal Forward As System.Boolean _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim Forward As System.Boolean  
Dim value As System.Double  
  
value = instance.GetWallThickness(Forward)
```

C#

```
System.double GetWallThickness(  
    System.bool Forward  
)
```

C++/CLI

```
System.double GetWallThickness(  
    & System.bool Forward  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward
True for forward direction, false for reverse

Return Value

Wall thickness

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::GetWallThickness](#).

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::IsThinFeature Method](#)
[ILoftFeatureData::SetWallThickness Method](#)
[ILoftFeatureData::ThinWallType Property](#)

Availability

GuideCurveInfluence Property (ILoftFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : GuideCurveInfluence Property (ILoftFeatureData)

Gets or sets the type of guide curve influence for this loft feature.

.NET Syntax

Visual Basic (Declaration)

Property GuideCurveInfluence As System.Integer

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData
Dim value As System.Integer

instance.GuideCurveInfluence = value

value = instance.GuideCurveInfluence
```

C#

```
System.int GuideCurveInfluence {get; set;}
```

C++/CLI

```
property System.int GuideCurveInfluence {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of guide curve influence as defined in [swGuideCurveInfluence_e](#)

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::GuideCurveInfluence](#).

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::GetGuideCurvesCount Method](#)
[ILoftFeatureData::GetGuideCurvesType Method](#)
[ILoftFeatureData::GetGuideTangencyType Method](#)
[ILoftFeatureData::IGetGuideCurves Method](#)
[ILoftFeatureData::IGetGuideCurvesType Method](#)
[ILoftFeatureData::ISetGuideCurves Method](#)
[ILoftFeatureData::SetGuideTangencyType Method](#)
[ILoftFeatureData::GuideCurves Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

GuideCurves Property (ILoftFeatureData)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : GuideCurves Property (ILoftFeatureData)

Gets and sets the guide curves for this loft feature.

.NET Syntax

Visual Basic (Declaration)

Property GuideCurves As System.Object

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData
Dim value As System.Object

instance.GuideCurves = value

value = instance.GuideCurves
```

C#

```
System.object GuideCurves {get; set;}
```

C++/CLI

```
property System.Object^ GuideCurves {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [features](#) of guide curves

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::GuideCurves](#).

Example

[Get Guide Curves in Loft Feature \(C#\)](#)
[Get Guide Curves in Loft Feature \(VB.NET\)](#)
[Get Guide Curves in Loft Feature \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::GetGuideCurvesCount Method](#)
[ILoftFeatureData::GetGuideCurvesType Method](#)
[ILoftFeatureData::GetGuideTangencyType Method](#)
[ILoftFeatureData::IGetGuideCurves Method](#)
[ILoftFeatureData::IGetGuideCurvesType Method](#)
[ILoftFeatureData::ISetGuideCurves Method](#)
[ILoftFeatureData::SetGuideTangencyType Method](#)
[ILoftFeatureData::GuideCurveInfluence Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : IAccessSelections Method (ILoftFeatureData)

Accesses the selections used to define the loft feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _
    ByVal TopDoc As ModelDoc2, _
    ByVal Component As Component2 _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData
Dim TopDoc As ModelDoc2
Dim Component As Component2
Dim value As System.Boolean

value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(
    ModelDoc2 TopDoc,
    Component2 Component
)
```

C++/CLI

```
System.bool IAccessSelections(
    & ModelDoc2^ TopDoc,
    & Component2^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were accessed successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::IModifyDefinition2](#) if you modified the feature
- [ILoftFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ILoftFeatureData Interface](#)

[ILoftFeatureData Members](#)

[ILoftFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0



Gets the solid bodies that the loft feature affects in a multibody part.

VB.NET Syntax

Visual Basic (Declaration)

```
Function IGetFeatureScopeBodies( _  
    ByVal Count As System.Integer _  
) As Body2
```

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim Count As System.Integer  
Dim value As Body2  
  
value = instance.IGetFeatureScopeBodies(Count)
```

C#

```
Body2 IGetFeatureScopeBodies(  
    System.int Count  
)
```

C++/CLI

```
Body2^ IGetFeatureScopeBodies(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of solid bodies to affect

Return Value

- in-process, unmanaged C++: Pointer to an array of solid [bodies](#) of size count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [ILoftFeatureData::GetFeatureScopeBodiesCount](#) to get the size of Count.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::ISetFeatureScopeBodies Method](#)
[ILoftFeatureData::FeatureScope Property](#)
[ILoftFeatureData::FeatureScopeBodies Property](#)
[ILoftFeatureData::AutoSelect Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0



Gets the guide curves for this loft feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetGuideCurves( _  
    ByVal Count As System.Short _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim Count As System.Short  
Dim value As System.Object  
  
value = instance.IGetGuideCurves(Count)
```

C#

```
System.object IGetGuideCurves(  
    System.short Count  
)
```

C++/CLI

```
System.Object^ IGetGuideCurves(  
& System.short Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of guide curves

Return Value

- in-process, unmanaged C++: Pointer to an array of [features](#) of guide curves of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [ILoftFeatureData::GetGuideCurvesCount](#) to get the size of Count.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::GetGuideCurvesType Method](#)
[ILoftFeatureData::GetGuideTangencyType Method](#)
[ILoftFeatureData::IGetGuideCurvesType Method](#)
[ILoftFeatureData::ISetGuideCurves Method](#)
[ILoftFeatureData::SetGuideTangencyType Method](#)
[ILoftFeatureData::GuideCurveInfluence Property](#)
[ILoftFeatureData::GuideCurves Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetGuideCurvesType Method (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : IGetGuideCurvesType Method (ILoftFeatureData)

Gets the guide curve types for this loft feature.

.NET Syntax

```
Function IGetGuideCurvesType( _
    ByVal Count As System.Integer _
) As System.Integer
```



```
Dim instance As ILoftFeatureData
Dim Count As System.Integer
Dim value As System.Integer

value = instance.IGetGuideCurvesType(Count)
```

```
System.int IGetGuideCurvesType(
    System.int Count
)
```

```
System.int IGetGuideCurvesType(
    & System.int Count
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of guide curves

Return Value

- in-process, unmanaged C++: Pointer to an array of the types of guide curves as defined by [swSelectType_e](#) of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::GetGuideCurvesCount Method](#)
[ILoftFeatureData::GetGuideCurvesType Method](#)
[ILoftFeatureData::GetGuideTangencyType Method](#)
[ILoftFeatureData::IGetGuideCurves Method](#)
[ILoftFeatureData::ISetGuideCurves Method](#)
[ILoftFeatureData::SetGuideTangencyType Method](#)
[ILoftFeatureData::GuideCurveInfluence Property](#)
[ILoftFeatureData::GuideCurves Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetProfiles Method (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : IGetProfiles Method (ILoftFeatureData)

Gets the profiles associated with this loft feature.

.NET Syntax

```
Function IGetProfiles( _  
    ByVal Count As System.Short _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim Count As System.Short  
Dim value As System.Object  
  
value = instance.IGetProfiles(Count)
```

C#

```
System.object IGetProfiles(  
    System.short Count  
)
```

C++/CLI

```
System.Object^ IGetProfiles(  
& System.short Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of profiles

Return Value

- in-process, unmanaged C++: Pointer to an array of profiles of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [ILoftFeatureData::GetProfileCount](#) to get the size of Count.

Each profile returned is a [IFeature](#) object. A [ISketch](#) object can be extracted from this IFeature object by using [IFeature::GetSpecificFeature2](#).

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::Profiles Property](#)
[ILoftFeatureData::ISetProfiles Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsBossFeature Method (ILoftFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : IsBossFeature Method (ILoftFeatureData)

Gets whether the loft feature is a boss feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IsBossFeature() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim value As System.Boolean  
  
value = instance.IsBossFeature()
```

C#

```
System.bool IsBossFeature()
```

C++/CLI

```
System.bool IsBossFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if it is a boss feature, false if not

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::IsBossFeature](#).

Example

[Get Guide Curves in Loft Feature \(C#\)](#)
[Get Guide Curves in Loft Feature \(VB.NET\)](#)
[Get Guide Curves in Loft Feature \(VBA\)](#)

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::IsThinFeature Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetFeatureScopeBodies Method (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : ISetFeatureScopeBodies Method (ILoftFeatureData)

Sets the solid bodies that the loft feature affects in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetFeatureScopeBodies( _  
    ByVal Count As System.Integer, _  
    ByRef BodyArr As Body2 _  
)
```

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim Count As System.Integer  
Dim BodyArr As Body2
```

```
instance.ISetFeatureScopeBodies(Count, BodyArr)
```

C#

```
void ISetFeatureScopeBodies(  
    System.int Count,
```

```
    ref Body2 BodyArr
)
```

C++/CLI

```
void ISetFeatureScopeBodies(
&    System.int Count,
&    Body2^% BodyArr
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of solid bodies to affect

BodyArr

- in-process, unmanaged C++: Pointer to an array of [bodies](#) of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILoftFeatureData Interface](#)

[ILoftFeatureData Members](#)

[ILoftFeatureData::IGetFeatureScopeBodies Method](#)

[ILoftFeatureData::FeatureScope Property](#)

[ILoftFeatureData::FeatureScopeBodies Property](#)

[ILoftFeatureData::GetFeatureScopeBodiesCount Method](#)

[ILoftFeatureData::AutoSelect Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetGuideCurves Method (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : ISetGuideCurves Method (ILoftFeatureData)

Sets the guide curves for this loft feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetGuideCurves( _
    ByVal Count As System.Short, _
    ByRef PDisp As System.Object _
)
```

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData
Dim Count As System.Short
Dim PDisp As System.Object
```

```
instance.ISetGuideCurves(Count, PDisp)
```

C#

```
void ISetGuideCurves(
    System.short Count,
    ref System.object PDisp
)
```

C++/CLI

```

void ISetGuideCurves(
& System.short Count,
& System.Object^% PDisp
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of guide curves

PDisp

- in-process, unmanaged C++: Pointer to an array of [features](#) of guide curves of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::GetGuideCurvesCount Method](#)
[ILoftFeatureData::GetGuideCurvesType Method](#)
[ILoftFeatureData::GetGuideTangencyType Method](#)
[ILoftFeatureData::IGetGuideCurves Method](#)
[ILoftFeatureData::IGetGuideCurvesType Method](#)
[ILoftFeatureData::SetGuideTangencyType Method](#)
[ILoftFeatureData::GuideCurveInfluence Property](#)
[ILoftFeatureData::GuideCurves Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetProfiles Method (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : ISetProfiles Method (ILoftFeatureData)

Sets the profiles for this loft feature.

.NET Syntax

Visual Basic (Declaration)

```

Sub ISetProfiles( _
    ByVal Count As System.Short, _
    ByRef PDisp As System.Object _
)

```

Visual Basic (Usage)

```

Dim instance As ILoftFeatureData
Dim Count As System.Short
Dim PDisp As System.Object

instance.ISetProfiles(Count, PDisp)

```

C#

```

void ISetProfiles(
    System.short Count,
    ref System.object PDisp
)

```

C++/CLI



```

void ISetProfiles(
& System.short Count,
& System.Object^% PDisp
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of profiles

PDisp

- in-process, unmanaged C++: Pointer to an array of profiles of size Count

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Each profile is an [IFeature](#) object that contains a [sketch](#).

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[ILoftFeatureData Interface](#)

[ILoftFeatureData Members](#)

[ILoftFeatureData::GetProfileCount Method](#)

[ILoftFeatureData::IGetProfiles Method](#)

[ILoftFeatureData::Profiles Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsThinFeature Method (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : IsThinFeature Method (ILoftFeatureData)

Gets whether this loft feature is a thin feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IsThinFeature() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData
```

```
Dim value As System.Boolean
```

```
value = instance.IsThinFeature()
```

C#

```
System.bool IsThinFeature()
```

C++/CLI

```
System.bool IsThinFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if it is a thin feature, false if not

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::IsThinFeature](#).

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::GetWallThickness Method](#)
[ILoftFeatureData::SetWallThickness Method](#)
[ILoftFeatureData::IsBossFeature Method](#)
[ILoftFeatureData::ThinWallType Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

MaintainTangency Property (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : MaintainTangency Property (ILoftFeatureData)

Gets or sets whether to maintain tangency for this loft feature.

.NET Syntax

Visual Basic (Declaration)

Property MaintainTangency As System.Boolean

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim value As System.Boolean
```

```
instance.MaintainTangency = value
```

```
value = instance.MaintainTangency
```

C#

```
System.bool MaintainTangency {get; set;}
```

C++/CLI

```
property System.bool MaintainTangency {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True maintains tangency, false does not

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::MaintainTangency](#).

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::GetGuideTangencyType Method](#)
[ILoftFeatureData::SetGuideTangencyType Method](#)
[ILoftFeatureData::EndConstraintApplyToAll Property](#)
[ILoftFeatureData::EndConstraintDraftAngle Property](#)
[ILoftFeatureData::EndConstraintDraftAngleDirection Property](#)
[ILoftFeatureData::EndTangencyType Property](#)
[ILoftFeatureData::EndTangentLength Property](#)
[ILoftFeatureData::ReverseEndTangentDirection Property](#)
[ILoftFeatureData::ReverseStartTangentDirection Property](#)
[ILoftFeatureData::StartConstraintApplyToAll Property](#)
[ILoftFeatureData::StartConstraintDraftAngle Property](#)
[ILoftFeatureData::StartConstraintDraftAngleDirection Property](#)

[ILoftFeatureData::StartTangencyType Property](#)
[ILoftFeatureData::StartTangentLength Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Merge Property (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : Merge Property (ILoftFeatureData)

Gets or sets whether to merge the results of this loft feature in a multibody part.

.NET Syntax

Visual Basic (Declaration)

Property Merge As System.Boolean

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim value As System.Boolean
```

```
instance.Merge = value
```

```
value = instance.Merge
```

C#

```
System.bool Merge {get; set;}
```

C++/CLI

```
property System.bool Merge {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True merges the results of this loft feature in a multibody part, false does not

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::Merge](#).

Remarks

The merge results option tells the SOLIDWORKS Design software whether to merge the new body or bodies with existing bodies in the multibody part. This property is set to True by default.

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

NumberOfSections Property (ILoftFeatureData)

[See Also](#)



Gets and sets the number of sections in this loft feature.

.NET Syntax

Visual Basic (Declaration)

Property NumberOfSections As System.Double

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData
Dim value As System.Double

instance.NumberOfSections = value

value = instance.NumberOfSections
```

C#

```
System.double NumberOfSections {get; set;}
```

C++/CLI

```
property System.double NumberOfSections {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of sections

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::NumberOfSections](#).

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

PickPoints Property (ILoftFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : PickPoints Property (ILoftFeatureData)

Gets or sets the pick points of a loft feature.

.NET Syntax

Visual Basic (Declaration)

Property PickPoints As System.Object

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData
Dim value As System.Object

instance.PickPoints = value
```

```
value = instance.PickPoints
```

C#

```
System.object PickPoints {get; set;}
```

C++/CLI

```
property System.Object^ PickPoints {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of the pick points that contain arrays of coordinates of the pick points of this loft feature

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::PickPoints](#).

Example

[Get and Set Loft's Pick Points \(VB.NET\)](#)
[Get and Set Loft's Pick Points \(C#\)](#)

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Profiles Property (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : Profiles Property (ILoftFeatureData)

Gets and sets the profiles for this loft feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Profiles As System.Object
```

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim value As System.Object
```

```
instance.Profiles = value
```

```
value = instance.Profiles
```

C#

```
System.object Profiles {get; set;}
```

C++/CLI

```
property System.Object^ Profiles {  
    System.Object^ get();
```

```
void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Profiles for this loft

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::Profiles](#).

Remarks

Each profile returned is a [IFeature](#) object. A [ISketch](#) object can be extracted from this Feature object by using [IFeature::GetSpecificFeature2](#).

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::GetProfileCount Method](#)
[ILoftFeatureData::IGetProfiles Method](#)
[ILoftFeatureData::ISetProfiles Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (ILoftFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : ReleaseSelectionAccess Method (ILoftFeatureData)

Releases access to the selections for this loft feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::ReleaseSelectionAccess](#).

Example

[Get Guide Curves in Loft Feature \(C#\)](#)
[Get Guide Curves in Loft Feature \(VB.NET\)](#)
[Get Guide Curves in Loft Feature \(VBA\)](#)

Remarks

[ILoftFeatureData::AccessSelections](#) and [ILoftFeatureData::IAccessSelections](#) put the model into a rollback state to allow access to the selection that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefintion2](#) if you did.

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseEndTangentDirection Property (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : ReverseEndTangentDirection Property (ILoftFeatureData)

Reverses the tangent direction for the end point of this loft feature.

.NET Syntax

Visual Basic (Declaration)

Property ReverseEndTangentDirection As System.Boolean

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData
Dim value As System.Boolean

instance.ReverseEndTangentDirection = value

value = instance.ReverseEndTangentDirection
```

C#

```
System.bool ReverseEndTangentDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseEndTangentDirection {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True reverses the end tangent direction, false does not

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::ReverseEndTangentDirection](#).

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData.GetGuideTangencyType Method](#)
[ILoftFeatureData.SetGuideTangencyType Method](#)
[ILoftFeatureData.EndConstraintApplyToAll Property](#)
[ILoftFeatureData.EndConstraintDraftAngle Property](#)
[ILoftFeatureData.EndConstraintDraftAngleDirection Property](#)
[ILoftFeatureData.EndTangencyType Property](#)

[ILoftFeatureData.EndTangentLength Property](#)
[ILoftFeatureData.MaintainTangency Property](#)
[ILoftFeatureData.ReverseStartTangentDirection Property](#)
[ILoftFeatureData.StartConstraintApplyToAll Property](#)
[ILoftFeatureData.StartConstraintDraftAngle Property](#)
[ILoftFeatureData.StartConstraintDraftAngleDirection Property](#)
[ILoftFeatureData.StartTangencyType Property](#)
[ILoftFeatureData.StartTangentLength Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseStartTangentDirection Property (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : ReverseStartTangentDirection Property (ILoftFeatureData)

Reverses the tangent direction for the start point of this loft feature.

.NET Syntax

Visual Basic (Declaration)

Property ReverseStartTangentDirection As System.Boolean

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim value As System.Boolean  
  
instance.ReverseStartTangentDirection = value  
value = instance.ReverseStartTangentDirection
```

C#

```
System.bool ReverseStartTangentDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseStartTangentDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True reverses the tangent direction for the start point, false does not

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::ReverseStartTangentDirection](#).

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::GetGuideTangencyType Method](#)
[ILoftFeatureData::SetGuideTangencyType Method](#)
[ILoftFeatureData::EndConstraintApplyToAll Property](#)
[ILoftFeatureData::EndConstraintDraftAngle Property](#)
[ILoftFeatureData::EndConstraintDraftAngleDirection Property](#)
[ILoftFeatureData::EndTangencyType Property](#)
[ILoftFeatureData::EndTangentLength Property](#)
[ILoftFeatureData::MaintainTangency Property](#)
[ILoftFeatureData::ReverseEndTangentDirection Property](#)
[ILoftFeatureData::StartConstraintApplyToAll Property](#)
[ILoftFeatureData::StartConstraintDraftAngle Property](#)
[ILoftFeatureData::StartConstraintDraftAngleDirection Property](#)
[ILoftFeatureData::StartTangencyType Property](#)
[ILoftFeatureData::StartTangentLength Property](#)

Availability

SetGuideTangencyType Method (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : SetGuideTangencyType Method (ILoftFeatureData)

Sets the tangency type of the guide curve (i.e., controls the tangency where the loft meets the guide curves) for this loft feature.

.NET Syntax

Visual Basic (Declaration)

```

Sub SetGuideTangencyType( _
    ByVal GuideIndex As System.Short, _
    ByVal TangType As System.Short _
)

```

Visual Basic (Usage)



```

Dim instance As ILoftFeatureData
Dim GuideIndex As System.Short
Dim TangType As System.Short

instance.SetGuideTangencyType(GuideIndex, TangType)

```

C#

```

void SetGuideTangencyType(
    System.short GuideIndex,
    System.short TangType
)

```

C++/CLI

```

void SetGuideTangencyType(
    & System.short GuideIndex,
    & System.short TangType
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

GuideIndex

Index of guide curve

TangType

Tangency type of guide curve as defined in [swTangencyType_e](#)

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::SetGuideTangencyType](#).

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::GetGuideCurvesCount Method](#)
[ILoftFeatureData::GetGuideCurvesType Method](#)
[ILoftFeatureData::GetGuideTangencyType Method](#)
[ILoftFeatureData::IGetGuideCurves Method](#)
[ILoftFeatureData::IGetGuideCurvesType Method](#)
[ILoftFeatureData::ISetGuideCurves Method](#)
[ILoftFeatureData::GuideCurveInfluence Property](#)
[ILoftFeatureData::GuideCurves Property](#)
[ILoftFeatureData::EndConstraintApplyToAll Property](#)
[ILoftFeatureData::EndConstraintDraftAngle Property](#)
[ILoftFeatureData::EndConstraintDraftAngleDirection Property](#)
[ILoftFeatureData::EndTangencyType Property](#)
[ILoftFeatureData::EndTangentLength Property](#)
[ILoftFeatureData::MaintainTangency Property](#)
[ILoftFeatureData::ReverseEndTangentDirection Property](#)
[ILoftFeatureData::ReverseStartTangentDirection Property](#)
[ILoftFeatureData::StartConstraintApplyToAll Property](#)
[ILoftFeatureData::StartConstraintDraftAngle Property](#)
[ILoftFeatureData::StartConstraintDraftAngleDirection Property](#)

[ILoftFeatureData::StartTangencyType Property](#)
[ILoftFeatureData::StartTangentLength Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetWallThickness Method (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : SetWallThickness Method (ILoftFeatureData)

Sets the wall thickness for this loft feature in the forward or reverse direction.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetWallThickness( _  
    ByVal Forward As System.Boolean, _  
    ByVal WallThickness As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim Forward As System.Boolean  
Dim WallThickness As System.Double  
  
instance.SetWallThickness(Forward, WallThickness)
```

C#

```
void SetWallThickness(  
    System.bool Forward,  
    System.double WallThickness  
)
```

C++/CLI

```
void SetWallThickness(  
&    System.bool Forward,  
&    System.double WallThickness  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Forward

True for forward feature direction, false for reverse

WallThickness

Wall thickness

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::SetWallThickness](#).

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::GetWallThickness Method](#)
[ILoftFeatureData::IsThinFeature Method](#)
[ILoftFeatureData::ThinWallType Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

StartConstraintApplyToAll Property (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : StartConstraintApplyToAll Property (ILoftFeatureData)

Gets whether a start constraint was applied to this loft feature.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property StartConstraintApplyToAll As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim value As System.Boolean  
  
instance.StartConstraintApplyToAll = value  
  
value = instance.StartConstraintApplyToAll
```

C#

```
System.bool StartConstraintApplyToAll {get; set;}
```

C++/CLI

```
property System.bool StartConstraintApplyToAll {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if a start constraint was specified, false if not

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::StartConstraintApplyToAll](#).

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::GetGuideTangencyType Method](#)
[ILoftFeatureData::SetGuideTangencyType Method](#)
[ILoftFeatureData::EndConstraintApplyToAll Property](#)
[ILoftFeatureData::EndConstraintDraftAngle Property](#)
[ILoftFeatureData::EndConstraintDraftAngleDirection Property](#)
[ILoftFeatureData::EndTangencyType Property](#)
[ILoftFeatureData::EndTangentLength Property](#)
[ILoftFeatureData::MaintainTangency Property](#)
[ILoftFeatureData::ReverseEndTangentDirection Property](#)
[ILoftFeatureData::ReverseStartTangentDirection Property](#)
[ILoftFeatureData::StartConstraintDraftAngle Property](#)
[ILoftFeatureData::StartConstraintDraftAngleDirection Property](#)
[ILoftFeatureData::StartTangencyType Property](#)
[ILoftFeatureData::StartTangentLength Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

StartConstraintDraftAngle Property (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : StartConstraintDraftAngle Property (ILoftFeatureData)

Gets or sets the angle of the draft for the start constraint of the loft feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property StartConstraintDraftAngle As System.Double
```

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim value As System.Double  
  
instance.StartConstraintDraftAngle = value  
value = instance.StartConstraintDraftAngle
```

C#

```
System.double StartConstraintDraftAngle {get; set;}
```

C++/CLI

```
property System.double StartConstraintDraftAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Draft angle

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::StartConstraintDraftAngle](#).

Remarks

This property is only valid if [ILoftFeatureData::StartConstraintApplyToAll](#) and [ILoftFeatureData::EndConstraintApplyToAll](#) are True.

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::GetGuideTangencyType Method](#)
[ILoftFeatureData::SetGuideTangencyType Method](#)
[ILoftFeatureData::EndConstraintApplyToAll Property](#)
[ILoftFeatureData::EndConstraintDraftAngle Property](#)
[ILoftFeatureData::EndConstraintDraftAngleDirection Property](#)
[ILoftFeatureData::EndTangencyType Property](#)
[ILoftFeatureData::EndTangentLength Property](#)
[ILoftFeatureData::ReverseEndTangentDirection Property](#)
[ILoftFeatureData::ReverseStartTangentDirection Property](#)
[ILoftFeatureData::StartConstraintApplyToAll Property](#)
[ILoftFeatureData::StartConstraintDraftAngleDirection Property](#)
[ILoftFeatureData::StartTangencyType Property](#)
[ILoftFeatureData::StartTangentLength Property](#)
[ILoftFeatureData::MaintainTangency Property](#)
[ILoftFeatureData::MaintainTangency Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

StartConstraintDraftAngleDirection Property (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : StartConstraintDraftAngleDirection Property (ILoftFeatureData)

Gets or sets the direction of the angle of the draft for the start constraint for the loft feature.

Visual Basic Syntax

```
Property StartConstraintDraftAngleDirection As System.Boolean
```



```
Dim instance As ILoftFeatureData
Dim value As System.Boolean

instance.StartConstraintDraftAngleDirection = value

value = instance.StartConstraintDraftAngleDirection
```

```
System.bool StartConstraintDraftAngleDirection {get; set;}
```

```
property System.bool StartConstraintDraftAngleDirection {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the direction of the draft angle is reversed, false if not

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::StartConstraintDraftAngleDirection](#).

Remarks

This property is only valid if [ILoftFeatureData::StartConstraintApplyToAll](#) and [ILoftFeatureData::EndConstraintApplyToAll](#) are True.

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::GetGuideTangencyType Method](#)
[ILoftFeatureData::SetGuideTangencyType Method](#)
[ILoftFeatureData::EndConstraintApplyToAll Property](#)
[ILoftFeatureData::EndConstraintDraftAngle Property](#)
[ILoftFeatureData::EndConstraintDraftAngleDirection Property](#)
[ILoftFeatureData::EndTangencyType Property](#)
[ILoftFeatureData::EndTangentLength Property](#)
[ILoftFeatureData::MaintainTangency Property](#)
[ILoftFeatureData::ReverseEndTangentDirection Property](#)
[ILoftFeatureData::ReverseStartTangentDirection Property](#)
[ILoftFeatureData::StartConstraintApplyToAll Property](#)
[ILoftFeatureData::StartConstraintDraftAngle Property](#)
[ILoftFeatureData::StartTangencyType Property](#)
[ILoftFeatureData::StartTangentLength Property](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

StartDirectionVector Property (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : StartDirectionVector Property (ILoftFeatureData)

Gets or sets the direction vector in which to start this loft feature.

.NET Syntax

```
Property StartDirectionVector As System.Object
```

```
Dim instance As ILoftFeatureData
Dim value As System.Object

instance.StartDirectionVector = value
value = instance.StartDirectionVector
```

C#

```
System.Object StartDirectionVector {get; set;}
```

C++/CLI

```
property System.Object^ StartDirectionVector {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Start direction vector

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::StartDirectionVector](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::EndDirectionVector Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

StartTangencyType Property (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : StartTangencyType Property (ILoftFeatureData)

Gets or sets the start tangency type for this loft feature.

.NET Syntax

Visual Basic (Declaration)

```
Property StartTangencyType As System.Short
```

Visual Basic (Usage)

```
Dim instance As ILoftFeatureData
Dim value As System.Short

instance.StartTangencyType = value
value = instance.StartTangencyType
```

C#

```
System.short StartTangencyType {get; set;}
```

C++/CLI

```
property System.short StartTangencyType {  
    System.short get();  
    void set ( &    System.short value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Start tangency type as defined in [swTangencyType_e](#)

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::StartTangencyType](#).

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::GetGuideTangencyType Method](#)
[ILoftFeatureData::SetGuideTangencyType Method](#)
[ILoftFeatureData::EndConstraintApplyToAll Property](#)
[ILoftFeatureData::EndConstraintDraftAngle Property](#)
[ILoftFeatureData::EndConstraintDraftAngleDirection Property](#)
[ILoftFeatureData::EndTangencyType Property](#)
[ILoftFeatureData::EndTangentLength Property](#)
[ILoftFeatureData::MaintainTangency Property](#)
[ILoftFeatureData::ReverseEndTangentDirection Property](#)
[ILoftFeatureData::ReverseStartTangentDirection Property](#)
[ILoftFeatureData::StartConstraintApplyToAll Property](#)
[ILoftFeatureData::StartConstraintDraftAngle Property](#)
[ILoftFeatureData::StartConstraintDraftAngleDirection Property](#)
[ILoftFeatureData::StartTangentLength Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

StartTangentLength Property (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : StartTangentLength Property (ILoftFeatureData)

Gets or sets the start tangent length for this loft feature.

.NET Syntax

Visual Basic (Declaration)

```
Property StartTangentLength As System.Double
```

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim value As System.Double  
  
instance.StartTangentLength = value  
  
value = instance.StartTangentLength
```

C#

```
System.double StartTangentLength {get; set;}
```

C++/CLI

```
property System.double StartTangentLength {  
    System.double get();
```

```
void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Start tangent length

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::StartTangentLength](#).

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::GetGuideTangencyType Method](#)
[ILoftFeatureData::SetGuideTangencyType Method](#)
[ILoftFeatureData::EndConstraintApplyToAll Property](#)
[ILoftFeatureData::EndConstraintDraftAngle Property](#)
[ILoftFeatureData::EndConstraintDraftAngleDirection Property](#)
[ILoftFeatureData::EndTangencyType Property](#)
[ILoftFeatureData::EndTangentLength Property](#)
[ILoftFeatureData::MaintainTangency Property](#)
[ILoftFeatureData::ReverseEndTangentDirection Property](#)
[ILoftFeatureData::ReverseStartTangentDirection Property](#)
[ILoftFeatureData::StartConstraintApplyToAll Property](#)
[ILoftFeatureData::StartConstraintDraftAngle Property](#)
[ILoftFeatureData::StartConstraintDraftAngleDirection Property](#)
[ILoftFeatureData::StartTangencyType Property](#)
[ILoftFeatureData::StartTangentLength Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ThinWallType Property (ILoftFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ILoftFeatureData Interface](#) : ThinWallType Property (ILoftFeatureData)

Gets or sets the thin wall type for this loft feature.

.NET Syntax

Visual Basic (Declaration)

Property ThinWallType As System.Short

Visual Basic (Usage)



```
Dim instance As ILoftFeatureData  
Dim value As System.Short
```

```
instance.ThinWallType = value
```

```
value = instance.ThinWallType
```

C#

```
System.short ThinWallType {get; set;}
```

C++/CLI

```
property System.short ThinWallType {  
    System.short get();  
    void set ( & System.short value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Thin feature type:

- 0 = One direction
- 1 = One direction reverse
- 2 = Midplane
- 3 = Two direction

Visual Basic for Applications (VBA) Syntax

See [LoftFeatureData::ThinWallType](#).

See Also

[ILoftFeatureData Interface](#)
[ILoftFeatureData Members](#)
[ILoftFeatureData::IsThinFeature Method](#)
[ILoftFeatureData::GetWallThickness Method](#)
[ILoftFeatureData::SetWallThickness Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0