

SOLIDWORKS API (.NET VBA C#) — Reference

(151/337): IMagneticLine-IManipulator

SOLIDWORKS API Documentation (converted from CHM)

IMagneticLine (Type)

IMagneticLine Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMagneticLine Interface

Allows access to a magnetic line.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IMagneticLine

Visual Basic (Usage)

Dim instance As [IMagneticLine](#)

C#

public interface IMagneticLine

C++/CLI

public interface class IMagneticLine

Visual Basic for Applications (VBA) Syntax

See [MagneticLine](#).

Example

[Insert Magnetic Line \(VBA\)](#)
[Insert Magnetic Line \(VB.NET\)](#)
[Insert Magnetic Line \(C#\)](#)

Accessors

[ISheet.InsertMagneticLine](#)

Access Diagram

[MagneticLine](#)

See Also

[IMagneticLine Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IMagneticLine Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMagneticLine Interface

The following tables list the members exposed by [IMagneticLine](#).

Public Properties

Name	Description
Angle	Gets and sets the angle of this magnetic line with respect to the horizontal axis.
EndPoint	Gets and sets the end point of this magnetic line.
EqualSpacing	Gets and sets whether to equally space the notes on this magnetic line.

[Length](#)

Gets and sets the length of this magnetic line.

[StartPoint](#)

Gets and sets the start point of this magnetic line.

[Top](#)

Public Methods

Name	Description
 AddNote	Attaches to this magnetic line the specified note at the specified position.
 GetNotes	Gets the notes attached to this magnetic line.
 GetNotesCount	Gets the number of notes attached to this magnetic line.
 IGetNotes	Gets the notes attached to this magnetic line.
 RemoveNote	Detaches the specified note from this magnetic line and moves it to the specified location.

[Top](#)

See Also

[IMagneticLine Interface](#)[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMagneticLine Interface Methods

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) : IMagneticLine InterfaceFor a list of all members of this type, see [IMagneticLine members](#).

Public Methods

Name	Description
 AddNote	Attaches to this magnetic line the specified note at the specified position.
 GetNotes	Gets the notes attached to this magnetic line.
 GetNotesCount	Gets the number of notes attached to this magnetic line.
 IGetNotes	Gets the notes attached to this magnetic line.
 RemoveNote	Detaches the specified note from this magnetic line and moves it to the specified location.

[Top](#)

See Also

[IMagneticLine Interface](#)[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMagneticLine Interface Properties

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) : IMagneticLine InterfaceFor a list of all members of this type, see [IMagneticLine members](#).

Public Properties

Name	Description
 Angle	Gets and sets the angle of this magnetic line with respect to the horizontal axis.
 EndPoint	Gets and sets the end point of this magnetic line.
 EqualSpacing	Gets and sets whether to equally space the notes on this magnetic line.
 Length	Gets and sets the length of this magnetic line.



[StartPoint](#)

Gets and sets the start point of this magnetic line.

[Top](#)

See Also

[IMagneticLine Interface](#)

[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddNote Method (IMagneticLine)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMagneticLine Interface](#) : AddNote Method (IMagneticLine)

Attaches to this magnetic line the specified note at the specified position.

.NET Syntax

Visual Basic (Declaration)

```
Function AddNote( _  
    ByVal Note As Note, _  
    ByVal Position As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMagneticLine  
Dim Note As Note  
Dim Position As System.Double  
Dim value As System.Boolean  
  
value = instance.AddNote(Note, Position)
```

C#

```
System.bool AddNote(  
    Note Note,  
    System.double Position  
)
```

C++/CLI

```
System.bool AddNote(  
& Note^ Note,  
& System.double Position  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Note

[INote](#) to attach to this magnetic line

Position

0.0 <= Attachment position on magnetic line <= 1.0; valid only if [IMagneticLine::EqualSpacing](#) is false

Return Value

True if successful, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [MagneticLine::AddNote](#).

Example

[Insert Magnetic Line \(C#\)](#)

[Insert Magnetic Line \(VB.NET\)](#)

[Insert Magnetic Line \(VBA\)](#)

Remarks

All notes attached to a magnetic line must be from the same view.

See Also

[IMagneticLine Interface](#)
[IMagneticLine Members](#)
[IMagneticLine::RemoveNote Method](#)
[IMagneticLine::GetNotes Method](#)
[IMagneticLine::IGetNotes Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Angle Property (IMagneticLine)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMagneticLine Interface](#) : Angle Property (IMagneticLine)

Gets and sets the angle of this magnetic line with respect to the horizontal axis.

.NET Syntax

Visual Basic (Declaration)

Property Angle As System.Double

Visual Basic (Usage)



```
Dim instance As IMagneticLine  
Dim value As System.Double
```

```
instance.Angle = value
```

```
value = instance.Angle
```

C#

```
System.double Angle {get; set;}
```

C++/CLI

```
property System.double Angle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle in radians of the magnetic line with respect to the horizontal axis

Visual Basic for Applications (VBA) Syntax

See [MagneticLine::Angle](#).

Example

[Insert Magnetic Line \(C#\)](#)
[Insert Magnetic Line \(VB.NET\)](#)
[Insert Magnetic Line \(VBA\)](#)

See Also

[IMagneticLine Interface](#)
[IMagneticLine Members](#)

[IMagneticLine::EndPoint Property](#)
[IMagneticLine::StartPoint Property](#)
[IMagneticLine::EqualSpacing Property](#)
[IMagneticLine::Length Property](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EndPoint Property (IMagneticLine)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMagneticLine Interface](#) : EndPoint Property (IMagneticLine)

Gets and sets the end point of this magnetic line.

.NET Syntax

Visual Basic (Declaration)

Property EndPoint As MathPoint

Visual Basic (Usage)



```
Dim instance As IMagneticLine  
Dim value As MathPoint
```

```
instance.EndPoint = value
```

```
value = instance.EndPoint
```

C#

```
MathPoint EndPoint {get; set;}
```

C++/CLI

```
property MathPoint^ EndPoint {  
    MathPoint^ get();  
    void set ( & MathPoint^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IMathPoint](#)

Visual Basic for Applications (VBA) Syntax

See [MagneticLine::EndPoint](#).

See Also

[IMagneticLine Interface](#)
[IMagneticLine Members](#)
[IMagneticLine::StartPoint Property](#)
[IMagneticLine::Angle Property](#)
[IMagneticLine::EqualSpacing Property](#)
[IMagneticLine::Length Property](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EqualSpacing Property (IMagneticLine)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMagneticLine Interface](#) : EqualSpacing Property (IMagneticLine)

Gets and sets whether to equally space the notes on this magnetic line.

Visual Basic Syntax

Visual Basic (Declaration)

Property EqualSpacing As System.Boolean

Visual Basic (Usage)



```
Dim instance As IMagneticLine  
Dim value As System.Boolean
```

```
instance.EqualSpacing = value
```

```
value = instance.EqualSpacing
```

C#

```
System.bool EqualSpacing {get; set;}
```

C++/CLI

```
property System.bool EqualSpacing {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to equally space the notes, false to drag the notes to any location on the magnetic line (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [MagneticLine::EqualSpacing](#).

Example

[Insert Magnetic Line \(VBA\)](#)
[Insert Magnetic Line \(VB.NET\)](#)
[Insert Magnetic Line \(C#\)](#)

Remarks

If this property is set to true, then [IMagneticLine::AddNote](#) ignores any Position parameter value.

See Also

[IMagneticLine Interface](#)
[IMagneticLine Members](#)
[IMagneticLine::Angle Property](#)
[IMagneticLine::EndPoint Property](#)
[IMagneticLine::StartPoint Property](#)
[IMagneticLine::Length Property](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNotes Method (IMagneticLine)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMagneticLine Interface](#) : GetNotes Method (IMagneticLine)

Gets the notes attached to this magnetic line.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetNotes() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMagneticLine  
Dim value As System.Object
```

```
value = instance.GetNotes()
```

C#

```
System.Object GetNotes()
```

C++/CLI

```
System.Object^ GetNotes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of attached [INotes](#)

Visual Basic for Applications (VBA) Syntax

See [MagneticLine::GetNotes](#).

See Also

[IMagneticLine Interface](#)
[IMagneticLine Members](#)
[IMagneticLine::GetNotesCount Method](#)
[IMagneticLine::IGetNotes Method](#)
[IMagneticLine::AddNote Method](#)
[IMagneticLine::RemoveNote Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetNotesCount Method (IMagneticLine)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMagneticLine Interface](#) : GetNotesCount Method (IMagneticLine)

Gets the number of notes attached to this magnetic line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNotesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMagneticLine  
Dim value As System.Integer
```

```
value = instance.GetNotesCount()
```

C#

```
System.int GetNotesCount()
```

C++/CLI

```
System.int GetNotesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of attached notes

Visual Basic for Applications (VBA) Syntax

See [MagneticLine::GetNotesCount](#).

Example

[Insert Magnetic Line \(VBA\)](#)
[Insert Magnetic Line \(VB.NET\)](#)
[Insert Magnetic Line \(C#\)](#)

See Also

[IMagneticLine Interface](#)
[IMagneticLine Members](#)
[IMagnetLine::GetNotes Method](#)
[IMagnetLine::IGetNotes Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNotes Method (IMagneticLine)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMagneticLine Interface](#) : IGetNotes Method (IMagneticLine)

Gets the notes attached to this magnetic line.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNotes( _  
    ByVal Count As System.Integer _  
) As Note
```

Visual Basic (Usage)



```
Dim instance As IMagneticLine  
Dim Count As System.Integer  
Dim value As Note
```

```
value = instance.IGetNotes(Count)
```

C#

```
Note IGetNotes(  
    System.int Count  
)
```

C++/CLI

```
Note^ IGetNotes(  
&    System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of notes returned by this method (see **Remarks**)

Return Value

- In-process, unmanaged C++: Pointer to an array of [INotes](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [IMagneticLine::GetNotesCount](#) to get the value of Count.

See Also

[IMagneticLine Interface](#)
[IMagneticLine Members](#)
[IMagneticLine::GetNotes Method](#)
[IMagneticLine::AddNote Method](#)
[IMagneticLine::RemoveNote Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Length Property (IMagneticLine)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMagneticLine Interface](#) : Length Property (IMagneticLine)

Gets and sets the length of this magnetic line.

.NET Syntax

Visual Basic (Declaration)

Property Length As System.Double

Visual Basic (Usage)



```
Dim instance As IMagneticLine  
Dim value As System.Double
```

```
instance.Length = value
```

```
value = instance.Length
```

C#

```
System.double Length {get; set;}
```

C++/CLI

```
property System.double Length {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Length in meters of this magnetic line

Visual Basic for Applications (VBA) Syntax

See [MagneticLine::Length](#).

Example

[Insert Magnetic Line \(C#\)](#)
[Insert Magnetic Line \(VB.NET\)](#)
[Insert Magnetic Line \(VBA\)](#)

See Also

[IMagneticLine Interface](#)
[IMagneticLine Members](#)

[IMagneticLine::Angle Property](#)
[IMagneticLine::EndPoint Property](#)
[IMagneticLine::StartPoint Property](#)
[IMagneticLine::EqualSpacing Property](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveNote Method (IMagneticLine)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMagneticLine Interface](#) : RemoveNote Method (IMagneticLine)

Detaches the specified note from this magnetic line and moves it to the specified location.

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveNote( _  
    ByVal Note As Note, _  
    ByVal Location As MathPoint _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMagneticLine  
Dim Note As Note  
Dim Location As MathPoint  
Dim value As System.Boolean  
  
value = instance.RemoveNote(Note, Location)
```

C#

```
System.bool RemoveNote(  
    Note Note,  
    MathPoint Location  
)
```

C++/CLI

```
System.bool RemoveNote(  
& Note^ Note,  
& MathPoint^ Location  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Note
[INote](#) to detach from this magnetic line
Location
[IMathPoint](#) where to move the note specified by Note

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [MagneticLine::RemoveNote](#).

Example

[Insert Magnetic Line \(C#\)](#)
[Insert Magnetic Line \(VB.NET\)](#)
[Insert Magnetic Line \(VBA\)](#)

See Also

[IMagneticLine Interface](#)
[IMagneticLine Members](#)
[IMagneticLine::AddNote Method](#)
[IMagneticLine::GetNotes Method](#)
[IMagneticLine::IGetNotes Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

StartPoint Property (IMagneticLine)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMagneticLine Interface](#) : StartPoint Property (IMagneticLine)

Gets and sets the start point of this magnetic line.

.NET Syntax

Visual Basic (Declaration)

Property StartPoint As MathPoint

Visual Basic (Usage)



```
Dim instance As IMagneticLine  
Dim value As MathPoint
```

```
instance.StartPoint = value  
value = instance.StartPoint
```

C#

```
MathPoint StartPoint {get; set;}
```

C++/CLI

```
property MathPoint^ StartPoint {  
    MathPoint^ get();  
    void set ( & MathPoint^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IMathPoint](#)

Visual Basic for Applications (VBA) Syntax

See [MagneticLine::StartPoint](#).

See Also

[IMagneticLine Interface](#)
[IMagneticLine Members](#)
[IMagneticLine::EndPoint Property](#)
[IMagneticLine::Angle Property](#)
[IMagneticLine::EqualSpacing Property](#)
[IMagneticLine::Length Property](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

IManipulator (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IManipulator Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IManipulator Interface

Allows access to a manipulator, which is similar to the triad or the drag arrow (also called a handle), in a SOLIDWORKS part or assembly document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IManipulator
```

Visual Basic (Usage)



```
Dim instance As IManipulator
```

C#

```
public interface IManipulator
```

C++/CLI

```
public interface class IManipulator
```

Visual Basic for Applications (VBA) Syntax

See [Manipulator](#).

Example

[Insert and Use Plane with Manipulator \(C#\)](#)
[Insert and Use Plane with Manipulator \(VB.NET\)](#)
[Insert and Use Plane with Manipulator \(VBA\)](#)

Remarks

An add-in application must create the handler for the manipulator. See [ISwManipulatorHandler2](#) and [Manipulators](#) for details.

Accessors

[IModelViewManager::CreateManipulator](#)

Access Diagram

[Manipulator](#)

See Also

[IManipulator Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDragArrowManipulator Interface](#)
[ITriadManipulator Interface](#)
[IPlaneManipulator Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IManipulator Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IManipulator Interface

For a list of all members of this type, see [Manipulator members](#).

Public Methods

Name	Description
 GetSpecificManipulator	Gets the manipulator for this SOLIDWORKS part or assembly document.
 Remove	Removes the manipulator from this SOLIDWORKS part or assembly document.
 Select	Select a manipulator.
 Show	Shows the manipulator in this SOLIDWORKS part or assembly document.

[Top](#)

See Also

[IManipulator Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDragArrowManipulator Interface](#)
[ITriadManipulator Interface](#)
[IPlaneManipulator Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IManipulator Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IManipulator Interface

The following tables list the members exposed by [IManipulator](#).

Public Properties

Name	Description
 Name	Gets and sets the name of a manipulator.
 Options	Gets or sets whether the manipulator is deleted when a component in an assembly is modified or deleted.
 Selectable	Gets or sets whether the manipulator can be selected in a PropertyManager page's selection box.
 Visible	Gets or sets whether the manipulator is visible in this SOLIDWORKS part or assembly document.

[Top](#)

Public Methods

Name	Description
 GetSpecificManipulator	Gets the manipulator for this SOLIDWORKS part or assembly document.
 Remove	Removes the manipulator from this SOLIDWORKS part or assembly document.
 Select	Select a manipulator.
 Show	Shows the manipulator in this SOLIDWORKS part or assembly document.

[Top](#)

See Also

[IManipulator Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDragArrowManipulator Interface](#)
[ITriadManipulator Interface](#)
[IPlaneManipulator Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IManipulator Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IManipulator Interface

For a list of all members of this type, see [IManipulator members](#).

Public Properties

Name	Description
Name	Gets and sets the name of a manipulator.



[Options](#)

Gets or sets whether the manipulator is deleted when a component in an assembly is modified or deleted.



[Selectable](#)

Gets or sets whether the manipulator can be selected in a PropertyManager page's selection box.



[Visible](#)

Gets or sets whether the manipulator is visible in this SOLIDWORKS part or assembly document.

[Top](#)

See Also

[IManipulator Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDragArrowManipulator Interface](#)
[ITriadManipulator Interface](#)
[IPlaneManipulator Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSpecificManipulator Method (IManipulator)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IManipulator Interface](#) : GetSpecificManipulator Method (IManipulator)

Gets the manipulator for this SOLIDWORKS part or assembly document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSpecificManipulator() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IManipulator  
Dim value As System.Object
```

```
value = instance.GetSpecificManipulator()
```

C#

```
System.object GetSpecificManipulator()
```

C++/CLI

```
System.Object^ GetSpecificManipulator();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- [ITriadManipulator](#)
- [IDragArrowManipulator](#)
- [IPlaneManipulator](#)

Visual Basic for Applications (VBA) Syntax

See [Manipulator::GetSpecificManipulator](#).

Example

[Insert and Use Plane with Manipulator \(VBA\)](#)
[Create Triad Manipulator \(VBA\)](#)
[Create Triad Manipulator \(VB.NET\)](#)
[Create Triad Manipulator \(C#\)](#)

See Also

[IManipulator Interface](#)
[IManipulator Members](#)

Availability

Name Property (IManipulator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IManipulator Interface](#) : Name Property (IManipulator)

Gets and sets the name of a manipulator.

.NET Syntax

Visual Basic (Declaration)

```
Property Name As System.String
```

Visual Basic (Usage)



```
Dim instance As IManipulator  
Dim value As System.String
```

```
instance.Name = value
```

```
value = instance.Name
```

C#

```
System.string Name {get; set;}
```

C++/CLI

```
property System.String^ Name {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the manipulator

Visual Basic for Applications (VBA) Syntax

See [Manipulator::Name](#).

See Also

[IManipulator Interface](#)
[IManipulator Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

Options Property (IManipulator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IManipulator Interface](#) : Options Property (IManipulator)

Gets or sets whether the manipulator is deleted when a component in an assembly is modified or deleted.

.NET Syntax

Visual Basic (Declaration)

```
Property Options As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IManipulator  
Dim value As System.Integer
```

```
instance.Options = value
```

```
value = instance.Options
```

C#

```
System.int Options {get; set;}
```

C++/CLI

```
property System.int Options {  
    System.int get();  
    void set ( &    System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Option as defined in [swManipulatorOptions_e](#) (see [Remarks](#))

Visual Basic for Applications (VBA) Syntax

See [Manipulator::Options](#).

Remarks

SOLIDWORKS recommends setting this property to swManipulatorOpts_KeepAfterComponentModify when working in an assembly.

See Also

[IManipulator Interface](#)
[IManipulator Members](#)

Availability

SOLIDWORKS 2009 SP2, Revision Number 17.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

Remove Method (IManipulator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IManipulator Interface](#) : Remove Method (IManipulator)

Removes the manipulator from this SOLIDWORKS part or assembly document.

.NET Syntax

Visual Basic (Declaration)

```
Sub Remove()
```

Visual Basic (Usage)



```
Dim instance As IManipulator
```

```
instance.Remove()
```

C#

```
void Remove()
```

C++/CLI

```
void Remove();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Manipulator::Remove](#).

See Also

[IManipulator Interface](#)
[IManipulator Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Select Method (IManipulator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IManipulator Interface](#) : Select Method (IManipulator)

Select a manipulator.

.NET Syntax

Visual Basic (Declaration)

```
Function Select( _  
    ByVal Append As System.Boolean, _  
    ByVal Data As SelectData _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IManipulator  
Dim Append As System.Boolean  
Dim Data As SelectData  
Dim value As System.Boolean  
  
value = instance.Select(Append, Data)
```

C#

```
System.bool Select(  
    System.bool Append,  
    SelectData Data  
)
```

C++/CLI

```
System.bool Select(  
& System.bool Append,  
& SelectData^ Data  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Append
True appends the manipulator tot he selection list, false replaces the selection list with this manipulator
Data
[ISelectData](#) object

Return Value

True if the manipulator is selected, false if not

Visual Basic for Applications (VBA) Syntax

See [Manipulator::Select](#).

See Also

[IManipulator Interface](#)
[IManipulator Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Selectable Property (IManipulator)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IManipulator Interface](#) : Selectable Property (IManipulator)

Gets or sets whether the manipulator can be selected in a PropertyManager page's selection box.

.NET Syntax

Visual Basic (Declaration)

Property Selectable As System.Boolean

Visual Basic (Usage)



```
Dim instance As IManipulator  
Dim value As System.Boolean
```

```
instance.Selectable = value
```

```
value = instance.Selectable
```

C#

```
System.bool Selectable {get; set;}
```

C++/CLI

```
property System.bool Selectable {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the manipulator can be selected, false if not

Visual Basic for Applications (VBA) Syntax

See [Manipulator::Selectable](#).

Example

[Create PropertyManager Page and Selectable Triad Manipulator \(VBA\)](#)

See Also

[IManipulator Interface](#)
[IManipulator Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Show Method (IManipulator)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IManipulator Interface](#) : Show Method (IManipulator)

Shows the manipulator in this SOLIDWORKS part or assembly document.

.NET Syntax

Visual Basic (Declaration)

```
Sub Show( _  
    ByVal PModelDoc As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IManipulator  
Dim PModelDoc As System.Object  
  
instance.Show(PModelDoc)
```

C#

```
void Show(  
    System.object PModelDoc  
)
```

C++/CLI

```
void Show(  
& System.Object^ PModelDoc  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PModelDoc
[Model document](#)

Visual Basic for Applications (VBA) Syntax

See [Manipulator::Show](#).

Example

[Create Triad Manipulator \(VBA\)](#)
[Create Triad Manipulator \(VB.NET\)](#)
[Create Triad Manipulator \(C#\)](#)

See Also

[IManipulator Interface](#)
[IManipulator Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Visible Property (IManipulator)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IManipulator Interface](#) : Visible Property (IManipulator)

Gets or sets whether the manipulator is visible in this SOLIDWORKS part or assembly document.

.NET Syntax

Visual Basic (Declaration)

Property Visible As System.Boolean

Visual Basic (Usage)



```
Dim instance As IManipulator  
Dim value As System.Boolean
```

```
instance.Visible = value
```

```
value = instance.Visible
```

C#

```
System.bool Visible {get; set;}
```

C++/CLI

```
property System.bool Visible {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the manipulator is visible, false if not

Visual Basic for Applications (VBA) Syntax

See [Manipulator::Visible](#).

See Also

[IManipulator Interface](#)
[IManipulator Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0