

SOLIDWORKS API (.NET, VBA, C#) — Reference (155/337): IMateEntity-IMateReference

SOLIDWORKS API Documentation (converted from CHM)

IMateEntity (Type)

IMateEntity Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMateEntity Interface

Obsolete. Superseded by [IMateEntity2](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IMateEntity
```

Visual Basic (Usage)



```
Dim instance As IMateEntity
```

C#

```
public interface IMateEntity
```

C++/CLI

```
public interface class IMateEntity
```

Visual Basic for Applications (VBA) Syntax

See [MateEntity](#).

See Also

[IMateEntity Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IMateEntity Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMateEntity Interface

The following tables list the members exposed by [IMateEntity](#).

Public Methods

Name	Description
GetComponent	Obsolete. Superseded by IMateEntity2::ReferenceComponent .
GetComponentName	Obsolete. Superseded by IMateEntity2::ReferenceComponent .
GetEntityParams	Obsolete. Superseded by IMateEntity2::EntityParams .
GetEntityType	Obsolete. Superseded by IMateEntity2::ReferenceType2 .
GetMember	Obsolete. Superseded by IMateEntity2::ReferenceComponent .
IGetComponent	Obsolete. Superseded by IMateEntity2::ReferenceComponent .
IGetComponent2	Obsolete. Superseded by IMateEntity2::ReferenceComponent .
IGetEntityParams	Obsolete. Superseded by IMateEntity2::EntityParams .
IGetMember	Obsolete. Superseded by IMateEntity2::ReferenceComponent .

[Top](#)

See Also

IMateEntity Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IMateEntity Interface

For a list of all members of this type, see [IMateEntity members](#).

Public Methods

Name	Description
 GetComponent	Obsolete. Superseded by IMateEntity2::ReferenceComponent .
 GetComponentName	Obsolete. Superseded by IMateEntity2::ReferenceComponent .
 GetEntityParams	Obsolete. Superseded by IMateEntity2::EntityParams .
 GetEntityType	Obsolete. Superseded by IMateEntity2::ReferenceType2 .
 GetMember	Obsolete. Superseded by IMateEntity2::ReferenceComponent .
 IGetComponent	Obsolete. Superseded by IMateEntity2::ReferenceComponent .
 IGetComponent2	Obsolete. Superseded by IMateEntity2::ReferenceComponent .
 IGetEntityParams	Obsolete. Superseded by IMateEntity2::EntityParams .
 IGetMember	Obsolete. Superseded by IMateEntity2::ReferenceComponent .

[Top](#)

See Also

[IMateEntity Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

GetComponent Method (IMateEntity)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateEntity Interface](#) : GetComponent Method (IMateEntity)

Obsolete. Superseded by [IMateEntity2::ReferenceComponent](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetComponent() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMateEntity  
Dim value As System.Object  
  
value = instance.GetComponent()
```

C#

```
System.object GetComponent()
```

C++/CLI

```
System.Object^ GetComponent();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MateEntity::GetComponent](#).

See Also

[IMateEntity Interface](#)
[IMateEntity Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetComponentName Method (IMateEntity)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateEntity Interface](#) : GetComponentName Method (IMateEntity)

Obsolete. Superseded by [IMateEntity2::ReferenceComponent](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetComponentName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IMateEntity  
Dim value As System.String  
  
value = instance.GetComponentName()
```

C#

```
System.string GetComponentName()
```

C++/CLI

```
System.String^ GetComponentName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MateEntity::GetComponentName](#).

See Also

[IMateEntity Interface](#)
[IMateEntity Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetEntityParams Method (IMateEntity)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateEntity Interface](#) : GetEntityParams Method (IMateEntity)

Obsolete. Superseded by [IMateEntity2::EntityParams](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetEntityParams() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMateEntity  
Dim value As System.Object  
  
value = instance.GetEntityParams()
```

C#

```
System.object GetEntityParams()
```

C++/CLI

```
System.Object^ GetEntityParams();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MateEntity::GetEntityParams](#).

See Also

[IMateEntity Interface](#)
[IMateEntity Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetEntityType Method (IMateEntity)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateEntity Interface](#) : GetEntityType Method (IMateEntity)

Obsolete. Superseded by [IMateEntity2::ReferenceType2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetEntityType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMateEntity  
Dim value As System.Integer  
  
value = instance.GetEntityType()
```

C#

```
System.int GetEntityType()
```

C++/CLI

```
System.int GetEntityType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MateEntity::GetEntityType](#).

See Also

[IMateEntity Interface](#)
[IMateEntity Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetMember Method (IMateEntity)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateEntity Interface](#) : GetMember Method (IMateEntity)

Obsolete. Superseded by [IMateEntity2::ReferenceComponent](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetMember() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMateEntity  
Dim value As System.Object  
  
value = instance.GetMember()
```

C#

```
System.object GetMember()
```

C++/CLI

```
System.Object^ GetMember();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MateEntity.GetMember](#).

See Also

[IMateEntity Interface](#)
[IMateEntity Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetComponent Method (IMateEntity)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateEntity Interface](#) : IGetComponent Method (IMateEntity)

Obsolete. Superseded by [IMateEntity2.ReferenceComponent](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetComponent() As Component
```

Visual Basic (Usage)



```
Dim instance As IMateEntity  
Dim value As Component  
  
value = instance.IGetComponent()
```

C#

```
Component IGetComponent()
```

C++/CLI

```
Component^ IGetComponent();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MateEntity.IGetComponent](#).

See Also

IGetComponent2 Method (IMateEntity)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateEntity Interface](#) : IGetComponent2 Method (IMateEntity)

Obsolete. Superseded by [IMateEntity2::ReferenceComponent](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetComponent2() As Component2
```

Visual Basic (Usage)



```
Dim instance As IMateEntity  
Dim value As Component2
```

```
value = instance.IGetComponent2()
```

C#

```
Component2 IGetComponent2()
```

C++/CLI

```
Component2^ IGetComponent2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MateEntity.IGetComponent2](#).

See Also

[IMateEntity Interface](#)
[IMateEntity Members](#)

IGetEntityParams Method (IMateEntity)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateEntity Interface](#) : IGetEntityParams Method (IMateEntity)

Obsolete. Superseded by [IMateEntity2::EntityParams](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetEntityParams() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IMateEntity  
Dim value As System.Double
```

```
value = instance.IGetEntityParams()
```

C#

```
System.double IGetEntityParams()
```

C++/CLI

```
System.double IGetEntityParams();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MateEntity::IGetEntityParams](#).

See Also

[IMateEntity Interface](#)
[IMateEntity Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetMember Method (IMateEntity)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateEntity Interface](#) : IGetMember Method (IMateEntity)

Obsolete. Superseded by [IMateEntity2::ReferenceComponent](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetMember() As Member
```

Visual Basic (Usage)



```
Dim instance As IMateEntity  
Dim value As Member  
  
value = instance.IGetMember()
```

C#

```
Member IGetMember()
```

C++/CLI

```
Member^ IGetMember();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MateEntity::IGetMember](#).

See Also

[IMateEntity Interface](#)
[IMateEntity Members](#)

IMateEntity2 (Type)

IMateEntity2 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMateEntity2 Interface

Allows access to mated entities and the assembly mate definition.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IMateEntity2
```

Visual Basic (Usage)

```
Dim instance As IMateEntity2
```

C#

```
public interface IMateEntity2
```

C++/CLI

```
public interface class IMateEntity2
```

Visual Basic for Applications (VBA) Syntax

See [MateEntity2](#).

Example

[Edit Mate \(VBA\)](#)
[Get Mates and Mate Entities \(C#\)](#)
[Get Mates and Mate Entities \(VB.NET\)](#)
[Get Mates and Mate Entities \(VBA\)](#)

Accessors

[IMate::MateEntity](#)

Access Diagram

[MateEntity2](#)

See Also

[IMateEntity2 Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IMate2 Interface](#)

IMateEntity2 Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMateEntity2 Interface

The following tables list the members exposed by [IMateEntity2](#).

Public Properties

Name	Description
EntityParams	Gets the parameters for this mate entity.
Reference	Gets the mate reference for this mate entity.



[ReferenceComponent](#)

Gets the reference component for this mate entity.

[ReferenceType](#)

Obsolete. Superseded by [IMate2Entity.Reference2](#)

[ReferenceType2](#)

Gets the mate entity reference type for this mate entity.

[Top](#)

Public Methods

Name	Description
 GetEntityParamsSize	Gets the number of parameters for this mate entity.
 IGetEntityParams	Gets the parameters of this mate entity.

[Top](#)

See Also

[IMateEntity2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IMate2 Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMateEntity2 Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMateEntity2 Interface

For a list of all members of this type, see [IMateEntity2 members](#).

Public Methods

Name	Description
 GetEntityParamsSize	Gets the number of parameters for this mate entity.
 IGetEntityParams	Gets the parameters of this mate entity.

[Top](#)

See Also

[IMateEntity2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IMate2 Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMateEntity2 Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMateEntity2 Interface

For a list of all members of this type, see [IMateEntity2 members](#).

Public Properties

Name	Description
 EntityParams	Gets the parameters for this mate entity.
 Reference	Gets the mate reference for this mate entity.
 ReferenceComponent	Gets the reference component for this mate entity.
 ReferenceType	Obsolete. Superseded by IMate2Entity.Reference2
 ReferenceType2	Gets the mate entity reference type for this mate entity.

[Top](#)

See Also

[IMateEntity2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

EntityParams Property (IMateEntity2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateEntity2 Interface](#) : EntityParams Property (IMateEntity2)

Gets the parameters for this mate entity.

Visual Basic Syntax

Visual Basic (Declaration)

```
ReadOnly Property EntityParams As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMateEntity2
Dim value As System.Object

value = instance.EntityParams
```

C#

```
System.Object EntityParams {get;}
```

C++/CLI

```
property System.Object^ EntityParams {
    System.Object^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of doubles representing the mate entity parameters (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [MateEntity2::EntityParams](#).

Example

[Edit Mate \(VBA\)](#)
[Get Mate Definition \(VBA\)](#)
[Get Mates and Mate Entities \(C#\)](#)
[Get Mates and Mate Entities \(VB.NET\)](#)
[Get Mates and Mate Entities \(VBA\)](#)

Remarks

The return value is the following array of doubles:

$[\textit{pointX}, \textit{pointY}, \textit{pointZ}, \textit{vectorI}, \textit{vectorJ}, \textit{vectorK}, \textit{radius1}, \textit{radius2}]$

where

- *pointX* is the X location of this mate entity in the assembly model space
- *pointY* is the Y location of this mate entity in the assembly model space
- *pointZ* is the Z location of this mate entity in the assembly model space
- *vectorI* is the i component of the assembly mate vector
- *vectorJ* is the j component of the assembly mate vector
- *vectorK* is the k component of the assembly mate vector
- *radius1* is the value for the first radius
- *radius2* is the value for the second radius

To define the mate entity, the following information is returned based on the mate type. All coordinate information is given in terms of the assembly coordinate system where the mate resides.

Mate Type	Returned
swMatePoint	<i>pointX, pointY, pointZ</i>
swMateLine	<i>pointX, pointY, pointZ, vectorI, vectorJ, vectorK</i> where the point is a point on the line and the vector represents the line direction.
swMatePlane	<i>pointX, pointY, pointZ, vectorI, vectorJ, vectorK</i> where the point is a point on the plane and the vector represents the plane normal.
swMateCylinder	<i>pointX, pointY, pointZ, vectorI, vectorJ, vectorK, radius1</i> where the point is a point on the cylinder axis and the vector represents the cylinder axis.
swMateCone	<i>pointX, pointY, pointZ, vectorI, vectorJ, vectorK, radius1, radius2</i> where the point is a point on the cone axis and the vector represents the cone axis.

To get the [IMateEntity2](#) interface, use [IMate2::MateEntity](#).

 See Also

[IMateEntity2 Interface](#)
[IMateEntity2 Members](#)
[IMateEntity2::GetEntityParamsSize Method](#)
[IMateEntity2::IGetEntityParams Method](#)

 Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEntityParamsSize Method (IMateEntity2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateEntity2 Interface](#) : GetEntityParamsSize Method (IMateEntity2)

Gets the number of parameters for this mate entity.

 .NET Syntax

Visual Basic (Declaration)

Function GetEntityParamsSize() As System.Integer

Visual Basic (Usage)



```
Dim instance As IMateEntity2
Dim value As System.Integer

value = instance.GetEntityParamsSize()
```

C#

System.int GetEntityParamsSize()

C++/CLI

System.int GetEntityParamsSize();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of parameters for this mate entity

 Visual Basic for Applications (VBA) Syntax

See [MateEntity2::GetEntityParamsSize](#).

 Remarks

Call this method before calling [IMateEntity2::IGetEntityParams](#) to determine the size of the array for that method.

See Also

[IMateEntity2 Interface](#)
[IMateEntity2 Members](#)
[IMateEntity2::EntityParams Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetEntityParams Method (IMateEntity2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateEntity2 Interface](#) : IGetEntityParams Method (IMateEntity2)

Gets the parameters of this mate entity.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetEntityParams( _  
    ByVal NParamsSize As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IMateEntity2  
Dim NParamsSize As System.Integer  
Dim value As System.Double  
  
value = instance.IGetEntityParams(NParamsSize)
```

C#

```
System.double IGetEntityParams(  
    System.int NParamsSize  
)
```

C++/CLI

```
System.double IGetEntityParams(  
& System.int NParamsSize  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NParamsSize
Number of parameters for this mate entity

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles representing the parameters for this mate entity (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IMateEntity2::GetEntityParamsSize](#) to get the value for the size of the array.

The return value is the following array of doubles:

[*pointX*, *pointY*, *pointZ*, *vectorI*, *vectorJ*, *vectorK*, *radius1*, *radius2*]

where

- *pointX* is the X location of this mate entity in the assembly model space
- *pointY* is the Y location of this mate entity in the assembly model space

- *pointZ* is the Z location of this mate entity in the assembly model space
- *vectorI* is the i component of the assembly mate vector
- *vectorJ* is the j component of the assembly mate vector
- *vectorK* is the k component of the assembly mate vector
- *radius1* is the value for the first radius
- *radius2* is the value for the second radius

To define the mate entity, the following information is returned based on the mate type. All coordinate information is given in terms of the assembly coordinate system where the mate resides.

Mate Type	Returned
swMatePoint	<i>pointX</i> , <i>pointY</i> , <i>pointZ</i>
swMateLine	<i>pointX</i> , <i>pointY</i> , <i>pointZ</i> , <i>vectorI</i> , <i>vectorJ</i> , <i>vectorK</i> where the point is a point on the line and the vector represents the line direction.
swMatePlane	<i>pointX</i> , <i>pointY</i> , <i>pointZ</i> , <i>vectorI</i> , <i>vectorJ</i> , <i>vectorK</i> where the point is a point on the plane and the vector represents the plane normal.
swMateCylinder	<i>pointX</i> , <i>pointY</i> , <i>pointZ</i> , <i>vectorI</i> , <i>vectorJ</i> , <i>vectorK</i> , <i>radius1</i> where the point is a point on the cylinder axis and the vector represents the cylinder axis.
swMateCone	<i>pointX</i> , <i>pointY</i> , <i>pointZ</i> , <i>vectorI</i> , <i>vectorJ</i> , <i>vectorK</i> , <i>radius1</i> , <i>radius2</i> where the point is a point on the cone axis and the vector represents the cone axis.

To get the [IMateEntity2](#) interface, use [IMate2::MateEntity](#).

See Also

[IMateEntity2 Interface](#)
[IMateEntity2 Members](#)
[IMateEntity2::EntityParams Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number

SOLIDWORKS API Help

[Send comments on this topic.](#)

Reference Property (IMateEntity2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateEntity2 Interface](#) : Reference Property (IMateEntity2)

Gets the mate reference for this mate entity.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Reference As System.Object

Visual Basic (Usage)

```
Dim instance As IMateEntity2
Dim value As System.Object

value = instance.Reference
```

C#

```
System.Object Reference {get;}
```

C++/CLI

```
property System.Object^ Reference {
    System.Object^ get();
}
```



NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Mate reference](#)

Visual Basic for Applications (VBA) Syntax

See [MateEntity2::Reference](#).

Example

[Edit Mate \(VBA\)](#)

Remarks

Mate references can be one or more entities of a component used for automatic mating.

See Also

[IMateEntity2 Interface](#)
[IMateEntity2 Members](#)
[IMateEntity2::ReferenceComponent Property](#)
[IMateEntity2::ReferenceType2 Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReferenceComponent Property (IMateEntity2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateEntity2 Interface](#) : ReferenceComponent Property (IMateEntity2)

Gets the reference component for this mate entity.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ReferenceComponent As Component2
```

Visual Basic (Usage)



```
Dim instance As IMateEntity2  
Dim value As Component2  
  
value = instance.ReferenceComponent
```

C#

```
Component2 ReferenceComponent {get;}
```

C++/CLI

```
property Component2^ ReferenceComponent {  
    Component2^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Component](#)

Visual Basic for Applications (VBA) Syntax

See [MateEntity2::ReferenceComponent](#).

Example

[Edit Mate \(VBA\)](#)
[Get Mate Definition \(VBA\)](#)
[Get Mates and Mate Entities \(C#\)](#)
[Get Mates and Mate Entities \(VB.NET\)](#)
[Get Mates and Mate Entities \(VBA\)](#)

Remarks

The component instance tree of a subassembly is not loaded because a subassembly does not have a view of its own. Thus, this property returns Nothing or null if the **Inplace** mate is in a subassembly.

See Also

[IMateEntity2 Interface](#)
[IMateEntity2 Members](#)
[IMateEntity2::Reference Property](#)
[IMateEntity2::ReferenceType2 Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReferenceType Property (IMateEntity2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateEntity2 Interface](#) : ReferenceType Property (IMateEntity2)

Obsolete. Superseded by [IMate2Entity::Reference2](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ReferenceType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMateEntity2  
Dim value As System.Integer  
  
value = instance.ReferenceType
```

C#

```
System.int ReferenceType {get;}
```

C++/CLI

```
property System.int ReferenceType {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MateEntity2::ReferenceType](#).

See Also

[IMateEntity2 Interface](#)
[IMateEntity2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReferenceType2 Property (IMateEntity2)

[See Also](#)



Gets the mate entity reference type for this mate entity.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ReferenceType2 As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMateEntity2  
Dim value As System.Integer
```

```
value = instance.ReferenceType2
```

C#

```
System.int ReferenceType2 {get;}
```

C++/CLI

```
property System.int ReferenceType2 {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of mate reference as defined in [swSelectType_e](#)

Visual Basic for Applications (VBA) Syntax

See [MateEntity2::ReferenceType2](#).

See Also

[IMateEntity2 Interface](#)
[IMateEntity2 Members](#)
[IMateEntity2::Reference Property](#)
[IMateEntity2::ReferenceComponent Property](#)

Availability

SOLIDWORKS 2006 SP4, Revision Number 14.4

IMateFeatureData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IMateFeatureData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMateFeatureData Interface

Allows access to mate feature data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IMateFeatureData

Visual Basic (Usage)

Dim instance As [IMateFeatureData](#)

C#

public interface IMateFeatureData

C++/CLI

public interface class IMateFeatureData

Visual Basic for Applications (VBA) Syntax

See [MateFeatureData](#).

Example

See the interfaces listed in Remarks for mate-specific examples.

Remarks

This interface is the base interface for the following mate-specific interfaces:

- [IAngleMateFeatureData](#)
- [ICamFollowerMateFeatureData](#)
- [ICoincidentMateFeatureData](#)
- [IConcentricMateFeatureData](#)
- [IDistanceMateFeatureData](#)
- [IGearMateFeatureData](#)
- [IHingeMateFeatureData](#)
- [ILinearCouplerMateFeatureData](#)
- [ILockMateFeatureData](#)
- [IParallelMateFeatureData](#)
- [IPerpendicularMateFeatureData](#)
- [IProfileCenterMateFeatureData](#)
- [IRackPinionMateFeatureData](#)
- [IScrewMateFeatureData](#)
- [ISlotMateFeatureData](#)
- [ISymmetricMateFeatureData](#)
- [ITangentMateFeatureData](#)
- [IUniversalJointMateFeatureData](#)
- [IWidthMateFeatureData](#)

To create a mate, see the [IAssemblyDoc::CreateMate](#) remarks.

Accessors

[IAssemblyDoc::CreateMateData](#)

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[MateFeatureData](#)

 See Also

[IMateFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IMateFeatureData Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMateFeatureData Interface

The following tables list the members exposed by [IMateFeatureData](#).

 Public Properties

Name	Description
 ErrorStatus	Gets the status of adding or editing this mate.
 TypeName	Gets or sets the type of this mate.

[Top](#)

 See Also

[IMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IMateFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMateFeatureData Interface

For a list of all members of this type, see [IMateFeatureData members](#).

 Public Properties

Name	Description
 ErrorStatus	Gets the status of adding or editing this mate.
 TypeName	Gets or sets the type of this mate.

[Top](#)

 See Also

[IMateFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ErrorStatus Property (IMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateFeatureData Interface](#) : ErrorStatus Property (IMateFeatureData)

Gets the status of adding or editing this mate.

 .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ErrorStatus As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMateFeatureData  
Dim value As System.Integer  
  
value = instance.ErrorStatus
```

C#

```
System.int ErrorStatus {get;}
```

C++/CLI

```
property System.int ErrorStatus {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Status of adding or editing this mate as defined in [swAddMateError_e](#)

Visual Basic for Applications (VBA) Syntax

See [MateFeatureData::ErrorStatus](#).

See Also

[IMateFeatureData Interface](#)
[IMateFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

TypeName Property (IMateFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateFeatureData Interface](#) : TypeName Property (IMateFeatureData)

Gets or sets the type of this mate.

.NET Syntax

Visual Basic (Declaration)

```
Property TypeName As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMateFeatureData  
Dim value As System.Integer
```

```
instance.TypeName = value
```

```
value = instance.TypeName
```

C#

```
System.int TypeName {get; set;}
```

C++/CLI

```
property System.int TypeName {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Mate type as defined in [swMateType_e](#)

Visual Basic for Applications (VBA) Syntax

See [MateFeatureData::TypeName](#).

Example

See the [IMateFeatureData](#) examples.

See Also

[IMateFeatureData Interface](#)
[IMateFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

IMateInPlace (Type)

IMateInPlace Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMateInPlace Interface

Allows access to an **Inplace** (coincident) mate, which is created when you insert a component in the context of an assembly.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IMateInPlace
```

Visual Basic (Usage)

```
Dim instance As IMateInPlace
```

C#

```
public interface IMateInPlace
```

C++/CLI

```
public interface class IMateInPlace
```

Visual Basic for Applications (VBA) Syntax

See [MateInPlace](#).

Example

[Get Component Names and Types for Inplace Mate \(VBA\)](#)
[Insert Join Feature \(C#\)](#)
[Insert Join Feature \(VB.NET\)](#)
[Insert Join Feature \(VBA\)](#)

Accessors

[IComponent2::GetMates](#)

[IFeature::GetSpecificFeature2](#)

Access Diagram

[MateInPlace](#)

See Also

[IMateInPlace Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IMate2 Interface](#)

IMateInPlace Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMateInPlace Interface

The following tables list the members exposed by [IMateInPlace](#).

Public Properties

Name	Description
Component	Gets the component for this Inplace mate.

[MateComponentName](#)Gets the name of the specified component for this **Inplace** mate.[MateEntity](#)Gets the name of the mated entity associated with the specified index for this **Inplace** mate.[MateEntityType](#)Gets the type of entity in this **Inplace** mate.[Top](#)

Public Methods

**Name****Description**[GetMateEntityCount](#)Gets the number of **Inplace** mated entities in this assembly.[Top](#)

See Also

[IMateInPlace Interface](#)[SolidWorks.Interop.sldworks Namespace](#)[IMate2 Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMateInPlace Interface Methods

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) : IMateInPlace InterfaceFor a list of all members of this type, see [IMateInPlace members](#).

Public Methods

**Name****Description**[GetMateEntityCount](#)Gets the number of **Inplace** mated entities in this assembly.[Top](#)

See Also

[IMateInPlace Interface](#)[SolidWorks.Interop.sldworks Namespace](#)[IMate2 Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMateInPlace Interface Properties

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) : IMateInPlace InterfaceFor a list of all members of this type, see [IMateInPlace members](#).

Public Properties

**Name****Description**[Component](#)Gets the component for this **Inplace** mate.[MateComponentName](#)Gets the name of the specified component for this **Inplace** mate.[MateEntity](#)Gets the name of the mated entity associated with the specified index for this **Inplace** mate.[MateEntityType](#)Gets the type of entity in this **Inplace** mate.[Top](#)

See Also

[IMateInPlace Interface](#)[SolidWorks.Interop.sldworks Namespace](#)[IMate2 Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Component Property (IMateInPlace)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateInPlace Interface](#) : Component Property (IMateInPlace)

Gets the component for this **Inplace** mate.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Component As Component2
```

Visual Basic (Usage)



```
Dim instance As IMateInPlace  
Dim value As Component2
```

```
value = instance.Component
```

C#

```
Component2 Component {get;}
```

C++/CLI

```
property Component2^ Component {  
    Component2^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Component](#)

Visual Basic for Applications (VBA) Syntax

See [MateInPlace::Component](#).

Example

[Get Component Names and Types for Inplace Mate \(VBA\)](#)

Remarks

The component instance tree of a subassembly is not loaded because a subassembly does not have a view of its own. Thus, this property returns NULL if the **Inplace** mate is in a subassembly.

See Also

[IMateInPlace Interface](#)
[IMateInPlace Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetMateEntityCount Method (IMateInPlace)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateInPlace Interface](#) : GetMateEntityCount Method (IMateInPlace)

Gets the number of **Inplace** mated entities in this assembly.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMateEntityCount() As System.Integer
```

```
Dim instance As IMateInPlace
Dim value As System.Integer

value = instance.GetMateEntityCount()
```

C#

```
System.int GetMateEntityCount()
```

C++/CLI

```
System.int GetMateEntityCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of **Inplace** mated entities

Visual Basic for Applications (VBA) Syntax

See [MateInPlace::GetMateEntityCount](#).

Example

[Get Component Names and Types for Inplace Mate \(VBA\)](#)

[Get Mates \(C#\)](#)

[Get Mates \(VB.NET\)](#)

[Get Mates \(VBA\)](#)

See Also

[IMateInPlace Interface](#)

[IMateInPlace Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MateComponentName Property (IMateInPlace)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateInPlace Interface](#) : MateComponentName Property (IMateInPlace)

Gets the name of the specified component for this **Inplace** mate.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property MateComponentName( _
    ByVal NIndex As System.Integer _
) As System.String
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IMateInPlace
Dim NIndex As System.Integer
Dim value As System.String

value = instance.MateComponentName(NIndex)
```

C#

```
System.string MateComponentName(
    System.int NIndex
```

```
) {get;}
```

C++/CLI

```
property System.String^ MateComponentName {  
    System.String^ get(System.int NIndex);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NIndex

0-based index associated with the specified component

Property Value

Name of the specified component

Visual Basic for Applications (VBA) Syntax

See [MateInPlace::MateComponentName](#).

Example

[Get Component Names and Types for Inplace MAte \(VBA\)](#)
[Get Mates \(C#\)](#)
[Get Mates \(VB.NET\)](#)
[Get Mates \(VBA\)](#)

See Also

[IMateInPlace Interface](#)
[IMateInPlace Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

MateEntity Property (IMateInPlace)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateInPlace Interface](#) : MateEntity Property (IMateInPlace)

Gets the name of the mated entity associated with the specified index for this **Inplace** mate.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property MateEntity( _  
    ByVal NIndex As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMateInPlace  
Dim NIndex As System.Integer  
Dim value As System.Object
```

```
value = instance.MateEntity(NIndex)
```

C#

```
System.object MateEntity(  
    System.int NIndex  
) {get;}
```

C++/CLI

```
property System.Object^ MateEntity {  
    System.Object^ get(System.int NIndex);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NIndex

0-based index associated with this entity

Property Value

[Face](#) or [reference plane](#)

Visual Basic for Applications (VBA) Syntax

See [MateInPlace::MateEntity](#).

Remarks

To get the type of entity returned by this method, call [IMateInPlace::MateEntityType](#) .

See Also

[IMateInPlace Interface](#)
[IMateInPlace Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

MateEntityType Property (IMateInPlace)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateInPlace Interface](#) : MateEntityType Property (IMateInPlace)

Gets the type of entity in this **Inplace** mate.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property MateEntityType( _  
    ByVal NIndex As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMateInPlace  
Dim NIndex As System.Integer  
Dim value As System.Integer  
  
value = instance.MateEntityType(NIndex)
```

C#

```
System.int MateEntityType(  
    System.int NIndex  
) {get;}
```

C++/CLI

```
property System.int MateEntityType {  
    System.int get(System.int NIndex);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NIndex

0-based index associated with this entity

Property Value

Type of entity as defined by [swSelectType_e](#)

Visual Basic for Applications (VBA) Syntax

See [IMateInPlace::MateEntityType](#).

Example

[Get Component Names and Types for Inplace Mate \(VBA\)](#)
[Get Mates \(C#\)](#)
[Get Mates \(VB.NET\)](#)
[Get Mates \(VBA\)](#)

Remarks

To get the name of the entity, call [IMateInPlace::MateEntity](#).

See Also

[IMateInPlace Interface](#)
[IMateInPlace Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

IMateLoadReference (Type)

IMateLoadReference Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMateLoadReference Interface

Allows access to mate load references.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IMateLoadReference
```

Visual Basic (Usage)



```
Dim instance As IMateLoadReference
```

C#

```
public interface IMateLoadReference
```

C++/CLI

```
public interface class IMateLoadReference
```

Visual Basic for Applications (VBA) Syntax

See [MateLoadReference](#).

Example

[Insert Mate Load Reference \(C#\)](#)
[Insert Mate Load Reference \(VB.NET\)](#)
[Insert Mate Load Reference \(VBA\)](#)

Accessors

[IAssemblyDoc::InsertLoadReference](#)
[IMate2::MateLoadReference](#)

Access Diagram

[MateLoadReference](#)

See Also

[IMateLoadReference Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IMate2 Interface](#)

IMateLoadReference Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMateLoadReference Interface

The following tables list the members exposed by [IMateLoadReference](#).

Public Properties

Name	Description
 Component	Gets the specified component associated with the mate that owns this load reference.

 Mate	Gets the mate that owns this mate load reference.
 Name	Gets the name of this mate load reference.

[Top](#)

Public Methods

Name	Description
 Delete	Deletes this mate load reference.
 GetFaces	Gets the supplemental faces of the mate associated with the specified component.
 GetFacesCount	Gets the number of supplemental faces of the mate associated with the specified component.
 IGetFaces	Gets the supplemental faces of the mate associated with the specified component.

[Top](#)

See Also

[IMateLoadReference Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IMate2 Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMateLoadReference Interface Methods

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IMateLoadReference Interface

For a list of all members of this type, see [IMateLoadReference members](#).

Public Methods

Name	Description
 Delete	Deletes this mate load reference.
 GetFaces	Gets the supplemental faces of the mate associated with the specified component.
 GetFacesCount	Gets the number of supplemental faces of the mate associated with the specified component.
 IGetFaces	Gets the supplemental faces of the mate associated with the specified component.

[Top](#)

See Also

[IMateLoadReference Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IMate2 Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMateLoadReference Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IMateLoadReference Interface

For a list of all members of this type, see [IMateLoadReference members](#).

Public Properties

Name	Description
 Component	Gets the specified component associated with the mate that owns this load reference.
 Mate	Gets the mate that owns this mate load reference.
 Name	Gets the name of this mate load reference.

[Top](#)

See Also

Component Property (IMateLoadReference)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateLoadReference Interface](#) : Component Property (IMateLoadReference)

Gets the specified component associated with the mate that owns this load reference.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Component( _  
    ByVal WhichOne As System.Integer _  
) As Component2
```

Visual Basic (Usage)



```
Dim instance As IMateLoadReference  
Dim WhichOne As System.Integer  
Dim value As Component2  
  
value = instance.Component(WhichOne)
```

C#

```
Component2 Component(  
    System.int WhichOne  
) {get;}
```

C++/CLI

```
property Component2^ Component {  
    Component2^ get(System.int WhichOne);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichOne

- 0 = Component1
- 1 = Component2

Property Value

[Component](#) associated with the mate that owns this load reference

Visual Basic for Applications (VBA) Syntax

See [MateLoadReference::Component](#).

Example

[Insert Mate Load Reference \(C#\)](#)
[Insert Mate Load Reference \(VB.NET\)](#)
[Insert Mate Load Reference \(VBA\)](#)

See Also

[IMateLoadReference Interface](#)
[IMateLoadReference Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateLoadReference Interface](#) : Delete Method (IMateLoadReference)

Deletes this mate load reference.

.NET Syntax

Visual Basic (Declaration)

```
Function Delete() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMateLoadReference  
Dim value As System.Boolean  
  
value = instance.Delete()
```

C#

```
System.bool Delete()
```

C++/CLI

```
System.bool Delete();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the mate load reference is deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [MateLoadReference::Delete](#).

Remarks

This method rebuilds the FeatureManager design tree, which can be a time-consuming operation if it is large. If using this method to delete many load references at once, use [IFeatureManager::EnableFeatureTree](#) before and after using IAssemblyDoc::InsertLoadReference to disable and then re-enable rebuilding the FeatureManager design tree.

See Also

[IMateLoadReference Interface](#)
[IMateLoadReference Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFaces Method (IMateLoadReference)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateLoadReference Interface](#) : GetFaces Method (IMateLoadReference)

Gets the supplemental faces of the mate associated with the specified component.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFaces( _  
    ByVal WhichOne As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMateLoadReference
Dim WhichOne As System.Integer
Dim value As System.Object

value = instance.GetFaces(WhichOne)
```

C#

```
System.Object GetFaces(
    System.int WhichOne
)
```

C++/CLI

```
System.Object^ GetFaces(
    & System.int WhichOne
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichOne

- 0 = Component1

- 1 = Component2

Return Value

Array of supplemental [faces](#)

Visual Basic for Applications (VBA) Syntax

See [MateLoadReference::GetFaces](#).

Remarks

The supplemental faces can belong to one of two components. Specify the component that owns the supplemental faces that you want to access.

See Also

[IMateLoadReference Interface](#)
[IMateLoadReference Members](#)
[IMateLoadReference::GetFacesCount Method](#)
[IMateLoadReference::IGetFaces Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFacesCount Method (IMateLoadReference)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateLoadReference Interface](#) : GetFacesCount Method (IMateLoadReference)

Gets the number of supplemental faces of the mate associated with the specified component.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFacesCount( _
    ByVal WhichOne As System.Integer _
) As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IMateLoadReference
Dim WhichOne As System.Integer
```



```
Dim value As System.Integer

value = instance.GetFacesCount(WhichOne)
```

C#

```
System.int GetFacesCount(
    System.int WhichOne
)
```

C++/CLI

```
System.int GetFacesCount(
    & System.int WhichOne
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichOne

- 0 = Component1
- 1 = Component2

Return Value

Number of supplemental faces of the mate associated with the specified component

Visual Basic for Applications (VBA) Syntax

See [MateLoadReference::GetFacesCount](#).

Example

[Insert Mate Load Reference \(C#\)](#)
[Insert Mate Load Reference \(VB.NET\)](#)
[Insert Mate Load Reference \(VBA\)](#)

Remarks

The supplemental faces can belong to one of two components. Specify the component that owns the supplemental faces that you want to access.

Call this method before calling [IMateLoadReference::IGetFaces](#) to determine the size of the array.

See Also

[IMateLoadReference Interface](#)
[IMateLoadReference Members](#)
[IMateLoadReference::GetFaces Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFaces Method (IMateLoadReference)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateLoadReference Interface](#) : IGetFaces Method (IMateLoadReference)

Gets the supplemental faces of the mate associated with the specified component.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFaces( _
    ByVal WhichOne As System.Integer, _
    ByVal FaceCount As System.Integer _
) As Face2
```

```
Dim instance As IMateLoadReference
Dim WhichOne As System.Integer
Dim FaceCount As System.Integer
Dim value As Face2

value = instance.IGetFaces(WhichOne, FaceCount)
```

C#

```
Face2 IGetFaces(
    System.int WhichOne,
    System.int FaceCount
)
```

C++/CLI

```
Face2^ IGetFaces(
    & System.int WhichOne,
    & System.int FaceCount
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichOne

- 0 = Component1
- 1 = Component2

FaceCount

Number of supplemental faces

Return Value

- in-process, unmanaged C++: Pointer to an array of supplemental [faces](#)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

The supplemental faces can belong to one of two components. Specify the component that owns the supplemental faces that you want to access.

Before calling this method, call [IMateLoadReference::GetFacesCount](#) to determine the size of the array for that method.

See Also

[IMateLoadReference Interface](#)

[IMateLoadReference Members](#)

[IMateLoadReference::GetFaces Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Mate Property (IMateLoadReference)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateLoadReference Interface](#) : Mate Property (IMateLoadReference)

Gets the mate that owns this mate load reference.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Mate As Mate2
```

Visual Basic (Usage)

```
Dim instance As IMateLoadReference  
Dim value As Mate2
```

```
value = instance.Mate
```

C#

```
Mate2 Mate {get;}
```

C++/CLI

```
property Mate2^ Mate {  
    Mate2^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Mate](#) that owns this mate load reference

Visual Basic for Applications (VBA) Syntax

See [MateLoadReference.Mate](#).

See Also

[IMateLoadReference Interface](#)
[IMateLoadReference Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Name Property (IMateLoadReference)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateLoadReference Interface](#) : Name Property (IMateLoadReference)

Gets the name of this mate load reference.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Name As System.String
```

Visual Basic (Usage)



```
Dim instance As IMateLoadReference  
Dim value As System.String  
  
value = instance.Name
```

C#

```
System.string Name {get;}
```

C++/CLI

```
property System.String^ Name {  
    System.String^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of mate load reference

Visual Basic for Applications (VBA) Syntax

See [MateLoadReference::Name](#).

Example

[Insert Mate Load Reference \(C#\)](#)
[Insert Mate Load Reference \(VB.NET\)](#)
[Insert Mate Load Reference \(VBA\)](#)

See Also

[IMateLoadReference Interface](#)
[IMateLoadReference Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

IMateReference (Type)

IMateReference Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMateReference Interface

Allows access to a mate reference, which specifies one or more entities of a component to use for automatic mating.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IMateReference
```

Visual Basic (Usage)



```
Dim instance As IMateReference
```

C#

```
public interface IMateReference
```

C++/CLI

```
public interface class IMateReference
```

Visual Basic for Applications (VBA) Syntax

See [MateReference](#).

Example

[Get Mate Reference Properties \(VBA\)](#)
[Get Mate Reference Properties \(VB.NET\)](#)
[Get Mate Reference Properties \(C#\)](#)
[Edit Mate Reference \(C#\)](#)
[Edit Mate Reference \(VB.NET\)](#)
[Edit Mate Reference \(VBA\)](#)

Accessors

[IFeature::GetSpecificFeature2](#)

Access Diagram

[MateReference](#)

See Also

[IMateReference Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertMateReference2 Method](#)
[IMate2 Interface](#)

IMateReference Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMateReference Interface

For a list of all members of this type, see [IMateReference members](#).

Public Methods

Name	Description
Edit	Lets you edit the selected mate reference.



[Top](#)

See Also

[IMateReference Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertMateReference2 Method](#)
[IMate2 Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMateReference Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMateReference Interface

The following tables list the members exposed by [IMateReference](#).

Public Properties

Name	Description
 Name	Gets the name of the selected mate reference.
 ReferenceAlignment	Gets the mate reference alignment for the specified mate reference entity in the selected mate reference.
 ReferenceEntity	Obsolete. Superseded by IMateReference.ReferenceEntity2.
 ReferenceEntity2	Gets the specified mate entity in this mate reference.
 ReferenceEntityCount	Gets the number of mate reference entities for the selected mate reference.
 ReferenceEntityType	Gets the exact entity type returned by IMateReference.ReferenceEntity2 .
 ReferenceType	Gets the mate type for the specified entity in this mate reference.

[Top](#)

Public Methods

Name	Description
 Edit	Lets you edit the selected mate reference.

[Top](#)

See Also

[IMateReference Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertMateReference2 Method](#)
[IMate2 Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMateReference Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMateReference Interface

For a list of all members of this type, see [IMateReference members](#).

Public Properties

Name	Description
 Name	Gets the name of the selected mate reference.
 ReferenceAlignment	Gets the mate reference alignment for the specified mate reference entity in the selected mate reference.
 ReferenceEntity	Obsolete. Superseded by IMateReference.ReferenceEntity2.
 ReferenceEntity2	Gets the specified mate entity in this mate reference.
 ReferenceEntityCount	Gets the number of mate reference entities for the selected mate reference.
 ReferenceEntityType	Gets the exact entity type returned by IMateReference.ReferenceEntity2 .



ReferenceType

Gets the mate type for the specified entity in this mate reference.

[Top](#)

See Also

[IMateReference Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager.InsertMateReference2 Method](#)
[IMate2 Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Edit Method (IMateReference)

[See Also](#)
[Example](#)


[SolidWorks.Interop.sldworks Namespace](#) > [IMateReference Interface](#) : Edit Method (IMateReference)

Lets you edit the selected mate reference.

.NET Syntax

Visual Basic (Declaration)

```

Function Edit( _
    ByVal BstrMateReferenceName As System.String, _
    ByVal PrimaryReferenceEntity As Entity, _
    ByVal PrimaryReferenceType As System.Integer, _
    ByVal PrimaryReferenceAlignment As System.Integer, _
    ByVal SecondaryReferenceEntity As Entity, _
    ByVal SecondaryReferenceType As System.Integer, _
    ByVal SecondaryReferenceAlignment As System.Integer, _
    ByVal TertiaryReferenceEntity As Entity, _
    ByVal TertiaryReferenceType As System.Integer, _
    ByVal TertiaryReferenceAlignment As System.Integer _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As IMateReference
Dim BstrMateReferenceName As System.String
Dim PrimaryReferenceEntity As Entity
Dim PrimaryReferenceType As System.Integer
Dim PrimaryReferenceAlignment As System.Integer
Dim SecondaryReferenceEntity As Entity
Dim SecondaryReferenceType As System.Integer
Dim SecondaryReferenceAlignment As System.Integer
Dim TertiaryReferenceEntity As Entity
Dim TertiaryReferenceType As System.Integer
Dim TertiaryReferenceAlignment As System.Integer
Dim value As System.Boolean

value = instance.Edit(BstrMateReferenceName, PrimaryReferenceEntity, PrimaryReferenceType,
PrimaryReferenceAlignment, SecondaryReferenceEntity, SecondaryReferenceType,
SecondaryReferenceAlignment, TertiaryReferenceEntity, TertiaryReferenceType,
TertiaryReferenceAlignment)

```

C#

```

System.bool Edit(
    System.string BstrMateReferenceName,
    Entity PrimaryReferenceEntity,
    System.int PrimaryReferenceType,
    System.int PrimaryReferenceAlignment,
    Entity SecondaryReferenceEntity,
    System.int SecondaryReferenceType,
    System.int SecondaryReferenceAlignment,
    Entity TertiaryReferenceEntity,
    System.int TertiaryReferenceType,
    System.int TertiaryReferenceAlignment
)

```

```

System.bool Edit(
& System.String^ BstrMateReferenceName,
& Entity^ PrimaryReferenceEntity,
& System.int PrimaryReferenceType,
& System.int PrimaryReferenceAlignment,
& Entity^ SecondaryReferenceEntity,
& System.int SecondaryReferenceType,
& System.int SecondaryReferenceAlignment,
& Entity^ TertiaryReferenceEntity,
& System.int TertiaryReferenceType,
& System.int TertiaryReferenceAlignment
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BstrMateReferenceName

Name of the new mate reference, which replaces the selected mate reference

PrimaryReferenceEntity

Primary mate reference entity, a pointer to an [IEntity](#) object

PrimaryReferenceType

Type of mate as defined by [swMateReferenceType_e](#) for PrimaryReferenceEntity

PrimaryReferenceAlignment

Type of alignment as defined by [swMateReferenceAlignment_e](#) for PrimaryReferenceEntity

SecondaryReferenceEntity

Secondary mate reference entity, a pointer to an [IEntity](#) object

SecondaryReferenceType

Type of mate as defined by [swMateReferenceType_e](#) for SecondaryReferenceEntity

SecondaryReferenceAlignment

Type of alignment as defined by [swMateReferenceAlignment_e](#) for SecondaryReferenceEntity

TertiaryReferenceEntity

Tertiary mate reference entity, a pointer to an [IEntity](#) object

TertiaryReferenceType

Type of mate as defined by [swMateReferenceType_e](#) for TertiaryReferenceEntity

TertiaryReferenceAlignment

Type of alignment as defined by [swMateReferenceAlignment_e](#) for TertiaryReferenceEntity

Return Value

Always True

Visual Basic for Applications (VBA) Syntax

See [MateReference::Edit](#).

Example

[Edit Mate Reference \(C#\)](#)

[Edit Mate Reference \(VB.NET\)](#)

[Edit Mate Reference \(VBA\)](#)

Remarks

To clear the previous references, you can pass Nothing or null for the primary, secondary, or tertiary reference entities.

This method applies the parameters to the actual features. After calling this method, call [IModelDoc2::EditRebuild](#) to rebuild the model, and then call [IModelDocExtension::NeedsRebuild](#) to determine if the rebuild was successful.

See Also

[IMateReference Interface](#)

[IMateReference Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

Name Property (IMateReference)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateReference Interface](#) : Name Property (IMateReference)

Gets the name of the selected mate reference.

Visual Basic Syntax

Visual Basic (Declaration)

```
ReadOnly Property Name As System.String
```

Visual Basic (Usage)



```
Dim instance As IMateReference  
Dim value As System.String  
  
value = instance.Name
```

C#

```
System.string Name {get;}
```

C++/CLI

```
property System.String^ Name {  
    System.String^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the selected mate reference

Visual Basic for Applications (VBA) Syntax

See [MateReference::Name](#).

Example

[Get Mate Reference Properties \(VBA\)](#)
[Get Mate Reference Properties \(VB.NET\)](#)
[Get Mate Reference Properties \(C#\)](#)

See Also

[IMateReference Interface](#)
[IMateReference Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReferenceAlignment Property (IMateReference)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateReference Interface](#) : ReferenceAlignment Property (IMateReference)

Gets the mate reference alignment for the specified mate reference entity in the selected mate reference.

Visual Basic Syntax

Visual Basic (Declaration)

```
ReadOnly Property ReferenceAlignment( _  
    ByVal Index As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMateReference  
Dim Index As System.Integer  
Dim value As System.Integer
```

```
value = instance.ReferenceAlignment(Index)
```

C#

```
System.int ReferenceAlignment(  
    System.int Index  
) {get;}
```

C++/CLI

```
property System.int ReferenceAlignment {  
    System.int get(System.int Index);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Mate reference entity as defined by [swMateReferenceIndex_e](#)

Property Value

Type of alignment as defined by [swMateReferenceAlignment_e](#)

Visual Basic for Applications (VBA) Syntax

See [MateReference::ReferenceAlignment](#).

Example

[Get Mate Reference Properties \(VBA\)](#)
[Get Mate Reference Properties \(VB.NET\)](#)
[Get Mate Reference Properties \(C#\)](#)

Remarks

Before calling this property, call [IMateReference::ReferenceEntityCount](#) to determine the number of mate reference entities for the mate reference.

This method returns -1 if there is no reference entity. See [IMateReference::ReferenceEntity](#) for details.

See Also

[IMateReference Interface](#)
[IMateReference Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReferenceEntity Property (IMateReference)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateReference Interface](#) : ReferenceEntity Property (IMateReference)

Obsolete. Superseded by [IMateReference::ReferenceEntity2](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ReferenceEntity( _  
    ByVal Index As System.Integer _  
) As Entity
```

Visual Basic (Usage)



```
Dim instance As IMateReference
Dim Index As System.Integer
Dim value As Entity

value = instance.ReferenceEntity(Index)
```

C#

```
Entity ReferenceEntity(
    System.int Index
) {get;}
```

C++/CLI

```
property Entity^ ReferenceEntity {
    Entity^ get(System.int Index);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Mate reference entity as define by [swMateReferenceIndex_e](#)

Property Value

[Entity](#)

Visual Basic for Applications (VBA) Syntax

See [MateReference::ReferenceEntity](#).

Example

[Get Mate Reference Properties \(VBA\)](#)

Remarks

Before calling this property, call [IMateReference::ReferenceEntityCount](#) to determine the number of mate reference entities for the mate reference.

See Also

[IMateReference Interface](#)

[IMateReference Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReferenceEntity2 Property (IMateReference)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateReference Interface](#) : ReferenceEntity2 Property (IMateReference)

Gets the specified mate entity in this mate reference.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ReferenceEntity2( _
    ByVal Index As System.Integer _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMateReference
Dim Index As System.Integer
Dim value As System.Object

value = instance.ReferenceEntity2(Index)
```

C#

```
System.Object ReferenceEntity2(
    System.Int Index
) {get;}
```

C++/CLI

```
property System.Object^ ReferenceEntity2 {
    System.Object^ get(System.Int Index);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Mate reference entity as defined in [swMateReferenceIndex_e](#)

Property Value

[IEntity](#) or [ISketchPoint](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [MateReference::ReferenceEntity2](#).

Example

[Get Mate Reference Properties \(VBA\)](#)
[Get Mate Reference Properties \(VB.NET\)](#)
[Get Mate Reference Properties \(C#\)](#)

Remarks

Before calling this property, call [IMateReference::ReferenceEntityCount](#) to determine the range of values for Index.

After calling this property, call [IMateReference::ReferenceEntityType](#) to determine which type this property returns and then cast the returned object into the appropriate type.

See Also

[IMateReference Interface](#)
[IMateReference Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReferenceEntityCount Property (IMateReference)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateReference Interface](#) : ReferenceEntityCount Property (IMateReference)

Gets the number of mate reference entities for the selected mate reference.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ReferenceEntityCount As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMateReference
Dim value As System.Integer

value = instance.ReferenceEntityCount
```

C#

```
System.int ReferenceEntityCount {get;}
```

C++/CLI

```
property System.int ReferenceEntityCount {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of mate reference entities

Visual Basic for Applications (VBA) Syntax

See [MateReference::ReferenceEntityCount](#).

Example

[Get Mate Reference Properties \(VBA\)](#)
[Get Mate Reference Properties \(VB.NET\)](#)
[Get Mate Reference Properties \(C#\)](#)

Remarks

This method returns a value 3 (primary, secondary, and tertiary).

Call this property before calling [IMateReference::ReferenceAlignment](#), [IMateReference::ReferenceEntity](#), or [IMateReference::ReferenceType](#).

See Also

[IMateReference Interface](#)
[IMateReference Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReferenceEntityType Property (IMateReference)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateReference Interface](#) : ReferenceEntityType Property (IMateReference)

Gets the exact entity type returned by [IMateReference::ReferenceEntity2](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ReferenceEntityType( _
    ByVal Index As System.Integer _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMateReference
Dim Index As System.Integer
Dim value As System.Integer
```

```
value = instance.ReferenceEntityType(Index)
```

C#

```
System.int ReferenceEntityType(  
    System.int Index  
) {get;}
```

C++/CLI

```
property System.int ReferenceEntityType {  
    System.int get(System.int Index);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Mate reference entity as defined in [swMateReferenceIndex_e](#)

Property Value

Value as defined in [swSelectType_e](#)

Visual Basic for Applications (VBA) Syntax

See [MateReference::ReferenceEntityType](#).

Example

[Get Mate Reference Properties \(VBA\)](#)
[Get Mate Reference Properties \(VB.NET\)](#)
[Get Mate Reference Properties \(C#\)](#)

Remarks

Call this property to determine the type returned by [IMateReference::ReferenceEntity2](#). Then cast the object returned by IMateReference::ReferenceEntity2 into the appropriate type.

See Also

[IMateReference Interface](#)
[IMateReference Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReferenceType Property (IMateReference)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMateReference Interface](#) : ReferenceType Property (IMateReference)

Gets the mate type for the specified entity in this mate reference.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ReferenceType( _  
    ByVal Index As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IMateReference  
Dim Index As System.Integer  
Dim value As System.Integer
```



```
value = instance.ReferenceType(Index)
```

C#

```
System.int ReferenceType(  
    System.int Index  
) {get;}
```

C++/CLI

```
property System.int ReferenceType {  
    System.int get(System.int Index);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Mate reference entity as defined by [swMateReferenceIndex_e](#)

Property Value

Mate reference type as defined by [swMateReferenceType_e](#)

Visual Basic for Applications (VBA) Syntax

See [MateReference::ReferenceType](#).

Example

[Get Mate Reference Properties \(VBA\)](#)
[Get Mate Reference Properties \(VB.NET\)](#)
[Get Mate Reference Properties \(C#\)](#)

Remarks

Before calling this property, call [IMateReference::ReferenceEntityCount](#) to determine the number of mate reference entities for the mate reference.

This method returns -1 if there is no reference entity. See [IMateReference::ReferenceEntity](#) for details.

See Also

[IMateReference Interface](#)
[IMateReference Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0