

SOLIDWORKS API (.NET VBA C#) — Reference

(158/337): IMBD3DPdfData-IMBDSTEP242Data

SOLIDWORKS API Documentation (converted from CHM)

IMBD3DPdfData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IMBD3DPdfData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMBD3DPdfData Interface

Gains access to the details for publishing a SOLIDWORKS MBD 3D PDF.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IMBD3DPdfData

Visual Basic (Usage)



Dim instance As [IMBD3DPdfData](#)

C#

public interface IMBD3DPdfData

C++/CLI

public interface class IMBD3DPdfData

Visual Basic for Applications (VBA) Syntax

See [MBD3DPdfData](#).

Example

[Publish Text and Custom Properties from Theme to MBD 3D PDF \(C#\)](#)
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VB.NET\)](#)
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VBA\)](#)
[Export BOM's Second Column to BOM Table Area \(C#\)](#)
[Export BOM's Second Column to BOM Table Area \(VB.NET\)](#)
[Export BOM's Second Column to BOM Table Area \(VBA\)](#)
[Fire Notification When Publishing Part to MBD 3D PDF \(VB.NET\)](#)
[Fire Notification When Publishing Part to MBD 3D PDF \(C#\)](#)
[Fire Notification When Publishing Part to MBD 3D PDF \(VBA\)](#)

Remarks

SOLIDWORKS Model Based Definition (MBD) is an integrated drawingless manufacturing solution for SOLIDWORKS.

This interface and its methods and properties require that the SOLIDWORKS MBD add-in be loaded. ([ISldWorks::LoadAddIn](#))

The MBD3DPdfData object corresponds to the SOLIDWORKS MBD **Publish to 3D PDF** PropertyManager page.

Typical steps for generating a SOLIDWORKS MBD 3D PDF using the SOLIDWORKS API are:

1. Get the MBD3DPdfData object using [IModelDocExtension::GetMBD3DPdfData](#).
2. Set the path and file name of the SOLIDWORKS MBD 3D PDF theme using [IMBD3DPdfData::ThemeName](#).
3. Get standard and custom views using [IMBD3DPdfData::GetStandardViews](#) and [IMBD3DPdfData::GetMoreViews](#).
4. Set standard and custom views using [IMBD3DPdfData::SetStandardViews](#) and [IMBD3DPdfData::SetMoreViews](#).
5. Get and set text and custom properties in the theme using [IMBD3DPdfData::GetTextCustomProperties](#) and [ITextAndCustomProperty](#).
6. Set the path for the SOLIDWORKS MBD 3D PDF using [IMBD3DPdfData::FilePath](#).
7. Generate the SOLIDWORKS MBD 3D PDF using [IModelDocExtension::PublishTo3DPDF](#).

See the SOLIDWORKS Help for details about MBD.

Accessors

[IModelDocExtension::GetMBD3DPdfData](#)

Access Diagram

[MBD3DPdfData](#)

See Also

[IMBD3DPdfData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::PublishTo3DPDF Method](#)
[IView3D Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMBD3DPdfData Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IMBD3DPdfData Interface

For a list of all members of this type, see [IMBD3DPdfData members](#).

Public Methods

Name	Description
 GetAttachments	Gets the fully qualified paths of the files to include as attachments when publishing to SOLIDWORKS MBD 3D PDF.
 GetBomAreaCount	Gets the number of BOM Table Areas defined in the theme for this SOLIDWORKS MBD 3D PDF.
 GetImportedNotes	Gets the imported note names from the theme of this MBD3DPdfData.
 GetMoreViews	Gets the names of the custom views (i.e., named views and 3D views) in the model for this SOLIDWORKS MBD 3D PDF.
 GetStandardViews	Gets the types of standard views in the model for this SOLIDWORKS MBD 3D PDF.
 GetTextAndCustomProperties	Gets the text and custom properties in the theme for this SOLIDWORKS MBD 3D PDF.
 SetAttachments	Sets the fully qualified paths of the files to include as attachments when publishing to SOLIDWORKS MBD 3D PDF.
 SetBomTable	Maps a BOM Table Area in the theme with a BOM table in the model and sets the columns in the BOM table to export to the BOM Table Area in a SOLIDWORKS MBD 3D PDF.
 SetImportedNote	Sets the specified imported note.
 SetIndependentViewPort	Sets the specified view for an independent viewport for the SOLIDWORKS MBD 3D PDF.
 SetMoreViews	Sets the names of the custom views (i.e., named views and 3D views) in the model for this SOLIDWORKS MBD 3D PDF.
 SetStandardViews	Sets the types of standard views in the model for this SOLIDWORKS MBD 3D PDF.

[Top](#)

See Also

[IMBD3DPdfData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::PublishTo3DPDF Method](#)
[IView3D Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMBD3DPdfData Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : IMBD3DPdfData Interface

The following tables list the members exposed by [IMBD3DPdfData](#).

Public Properties

Name	Description
 Accuracy	Gets or sets the level of accuracy for lossy compression when publishing to SOLIDWORKS MBD 3D PDF.
 CompressLossyTessellation	Gets or sets whether to apply lossy compression to polygons in the model when publishing to SOLIDWORKS MBD 3D PDF.
 CreateAttachSTEP242	Gets or sets whether to export SOLIDWORKS parts and assemblies to STEP 242 format and attach the STEP 242 file to the SOLIDWORKS MBD 3D PDF.
 ExcludeFromAnnotationView	Gets or sets whether to exclude BOM tables from annotation views for this SOLIDWORKS MBD 3D PDF.
 FilePath	Gets or sets the path and file name to which to save this SOLIDWORKS MBD 3D PDF.
 STEP242Edition	Gets or sets the STEP 242 edition to use.
 ThemeName	Gets or sets the path and file name of the theme for this SOLIDWORKS MBD 3D PDF.
 ViewPdfAfterSaving	Gets or sets whether to display this SOLIDWORKS MBD 3D PDF after publishing it .

[Top](#)

Public Methods

Name	Description
 GetAttachments	Gets the fully qualified paths of the files to include as attachments when publishing to SOLIDWORKS MBD 3D PDF.
 GetBomAreaCount	Gets the number of BOM Table Areas defined in the theme for this SOLIDWORKS MBD 3D PDF.
 GetImportedNotes	Gets the imported note names from the theme of this MBD3DPdfData.
 GetMoreViews	Gets the names of the custom views (i.e., named views and 3D views) in the model for this SOLIDWORKS MBD 3D PDF.
 GetStandardViews	Gets the types of standard views in the model for this SOLIDWORKS MBD 3D PDF.
 GetTextAndCustomProperties	Gets the text and custom properties in the theme for this SOLIDWORKS MBD 3D PDF.
 SetAttachments	Sets the fully qualified paths of the files to include as attachments when publishing to SOLIDWORKS MBD 3D PDF.
 SetBomTable	Maps a BOM Table Area in the theme with a BOM table in the model and sets the columns in the BOM table to export to the BOM Table Area in a SOLIDWORKS MBD 3D PDF.
 SetImportedNote	Sets the specified imported note.
 SetIndependentViewPort	Sets the specified view for an independent viewport for the SOLIDWORKS MBD 3D PDF.
 SetMoreViews	Sets the names of the custom views (i.e., named views and 3D views) in the model for this SOLIDWORKS MBD 3D PDF.
 SetStandardViews	Sets the types of standard views in the model for this SOLIDWORKS MBD 3D PDF.

[Top](#)

See Also

[IMBD3DPdfData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::PublishTo3DPDF Method](#)
[IView3D Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMBD3DPdfData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMBD3DPdfData Interface

For a list of all members of this type, see [IMBD3DPdfData members](#).

Public Properties

Name	Description
 Accuracy	Gets or sets the level of accuracy for lossy compression when publishing to SOLIDWORKS MBD 3D PDF.
 CompressLossyTessellation	Gets or sets whether to apply lossy compression to polygons in the model when publishing to SOLIDWORKS MBD 3D PDF.
 CreateAttachSTEP242	Gets or sets whether to export SOLIDWORKS parts and assemblies to STEP 242 format and attach the STEP 242 file to the SOLIDWORKS MBD 3D PDF.
 ExcludeFromAnnotationView	Gets or sets whether to exclude BOM tables from annotation views for this SOLIDWORKS MBD 3D PDF.
 FilePath	Gets or sets the path and file name to which to save this SOLIDWORKS MBD 3D PDF.
 STEP242Edition	Gets or sets the STEP 242 edition to use.
 ThemeName	Gets or sets the path and file name of the theme for this SOLIDWORKS MBD 3D PDF.
 ViewPdfAfterSaving	Gets or sets whether to display this SOLIDWORKS MBD 3D PDF after publishing it .

[Top](#)

See Also

[IMBD3DPdfData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::PublishTo3DPDF Method](#)
[IView3D Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Accuracy Property (IMBD3DPdfData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBD3DPdfData Interface](#) : Accuracy Property (IMBD3DPdfData)

Gets or sets the level of accuracy for lossy compression when publishing to SOLIDWORKS MBD 3D PDF.

.NET Syntax

Visual Basic (Declaration)

```
Property Accuracy As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMBD3DPdfData  
Dim value As System.Integer
```

```
instance.Accuracy = value
```

```
value = instance.Accuracy
```

C#

```
System.int Accuracy {get; set;}
```

C++/CLI

```
property System.int Accuracy {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Level of accuracy for lossy compression as defined in [sw3DPDFAccuracy_e](#)

Visual Basic for Applications (VBA) Syntax

See [MBD3DPdfData::Accuracy](#).

Example

[Attach Files to MBD 3D PDF \(C#\)](#)
[Attach Files to MBD 3D PDF \(VB.NET\)](#)
[Attach Files to MBD 3D PDF \(VBA\)](#)

See Also

[IMBD3DPdfData Interface](#)
[IMBD3DPdfData Members](#)
[IMBD3DPdfData::CompressLossyTessellation Property\(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CompressLossyTessellation Property (IMBD3DPdfData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBD3DPdfData Interface](#) : CompressLossyTessellation Property (IMBD3DPdfData)

Gets or sets whether to apply lossy compression to polygons in the model when publishing to SOLIDWORKS MBD 3D PDF.

.NET Syntax

Visual Basic (Declaration)

```
Property CompressLossyTessellation As System.Boolean
```

```
Dim instance As IMBD3DPdfData
Dim value As System.Boolean

instance.CompressLossyTessellation = value

value = instance.CompressLossyTessellation
```

C#

```
System.bool CompressLossyTessellation {get; set;}
```

C++/CLI

```
property System.bool CompressLossyTessellation {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to apply lossy compression to polygons in the model, false to not

Visual Basic for Applications (VBA) Syntax

See [MBD3DPdfData::CompressLossyTessellation](#).

Example

[Attach Files to MBD 3D PDF \(C#\)](#)
[Attach Files to MBD 3D PDF \(VB.NET\)](#)
[Attach Files to MBD 3D PDF \(VBA\)](#)

See Also

[IMBD3DPdfData Interface](#)
[IMBD3DPdfData Members](#)
[IMBD3DPdfData::Accuracy Property \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateAttachSTEP242 Property (IMBD3DPdfData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBD3DPdfData Interface](#) : CreateAttachSTEP242 Property (IMBD3DPdfData)

Gets or sets whether to export SOLIDWORKS parts and assemblies to STEP 242 format and attach the STEP 242 file to the SOLIDWORKS MBD 3D PDF.

.NET Syntax

Visual Basic (Declaration)

```
Property CreateAttachSTEP242 As System.Boolean
```

Visual Basic (Usage)

 Copy Code

```
Dim instance As IMBD3DPdfData
Dim value As System.Boolean

instance.CreateAttachSTEP242 = value

value = instance.CreateAttachSTEP242
```

C#

```
System.bool CreateAttachSTEP242 {get; set;}
```

C++/CLI

```
property System.bool CreateAttachSTEP242 {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to export SOLIDWORKS parts and assemblies to STEP 242 format and attach the STEP 242 file to SOLIDWORKS MBD 3D PDF, false to not

Visual Basic for Applications (VBA) Syntax

See [IMBD3DPdfData::CreateAttachSTEP242](#).

Example

[Attach Files to MBD 3D PDF \(C#\)](#)
[Attach Files to MBD 3D PDF \(VB.NET\)](#)
[Attach Files to MBD 3D PDF \(VBA\)](#)

See Also

[IMBD3DPdfData Interface](#)
[IMBD3DPdfData Members](#)
[IModelDocExtension::PublishSTEP242File Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ExcludeFromAnnotationView Property (IMBD3DPdfData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBD3DPdfData Interface](#) : ExcludeFromAnnotationView Property (IMBD3DPdfData)

Gets or sets whether to exclude BOM tables from annotation views for this SOLIDWORKS MBD 3D PDF.

.NET Syntax

Visual Basic (Declaration)

```
Property ExcludeFromAnnotationView As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMBD3DPdfData  
Dim value As System.Boolean
```

```
instance.ExcludeFromAnnotationView = value
```

```
value = instance.ExcludeFromAnnotationView
```

C#

```
System.bool ExcludeFromAnnotationView {get; set;}
```

C++/CLI

```
property System.bool ExcludeFromAnnotationView {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to exclude BOM tables from annotation views, false to not

Visual Basic for Applications (VBA) Syntax

See [IMBD3DPdfData::ExcludeFromAnnotationView](#).

See Also

[IMBD3DPdfData Interface](#)
[IMBD3DPdfData Members](#)
[IMBD3DPdfData::GetBomAreaCount Method \(\)](#)
[IMBD3DPdfData::SetBomTable Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FilePath Property (IMBD3DPdfData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBD3DPdfData Interface](#) : FilePath Property (IMBD3DPdfData)

Gets or sets the path and file name to which to save this SOLIDWORKS MBD 3D PDF.

.NET Syntax

Visual Basic (Declaration)

```
Property FilePath As System.String
```

Visual Basic (Usage)



```
Dim instance As IMBD3DPdfData  
Dim value As System.String
```

```
instance.FilePath = value
```

```
value = instance.FilePath
```

C#

```
System.string FilePath {get; set;}
```

C++/CLI

```
property System.String^ FilePath {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path and file name

Visual Basic for Applications (VBA) Syntax

See [IMBD3DPdfData::FilePath](#).

Example

[Publish Text and Custom Properties from Theme to MBD 3D PDF \(C#\)](#)
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VB.NET\)](#)
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VBA\)](#)

See Also

[IMBD3DPdfData Interface](#)
[IMBD3DPdfData Members](#)
[IMBD3DPdfData::ViewPdfAfterSaving_Property\(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAttachments Method (IMBD3DPdfData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBD3DPdfData Interface](#) : GetAttachments Method (IMBD3DPdfData)

Gets the fully qualified paths of the files to include as attachments when publishing to SOLIDWORKS MBD 3D PDF.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAttachments() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMBD3DPdfData  
Dim value As System.Object
```

```
value = instance.GetAttachments()
```

C#

```
System.object GetAttachments()
```

C++/CLI

```
System.Object^ GetAttachments();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of strings of the fully qualified paths of the files to include as attachments

Visual Basic for Applications (VBA) Syntax

See [MBD3DPdfData::GetAttachments](#).

See Also

[IMBD3DPdfData Interface](#)
[IMBD3DPdfData Members](#)
[IMBD3DPdfData::SetAttachments Method\(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBomAreaCount Method (IMBD3DPdfData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBD3DPdfData Interface](#) : GetBomAreaCount Method (IMBD3DPdfData)

Gets the number of BOM Table Areas defined in the [theme](#) for this SOLIDWORKS MBD 3D PDF.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBomAreaCount() As System.Integer
```

```
Dim instance As IMBD3DPdfData
Dim value As System.Integer

value = instance.GetBomAreaCount()
```

C#

```
System.int GetBomAreaCount()
```

C++/CLI

```
System.int GetBomAreaCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of BOM Table Areas defined in the theme

Visual Basic for Applications (VBA) Syntax

See [MBD3DPdfData::GetBomAreaCount](#).

Example

[Export BOM's Second Column to BOM Table Area \(C#\)](#)
[Export BOM's Second Column to BOM Table Area \(VB.NET\)](#)
[Export BOM's Second Column to BOM Table Area \(VBA\)](#)

See Also

[IMBD3DPdfData Interface](#)
[IMBD3DPdfData Members](#)
[IMBD3DPdfData::SetBomTable Method \(\)](#)
[IMBD3DPdfData::ExcludeFromAnnotationView Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetImportedNotes Method (IMBD3DPdfData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBD3DPdfData Interface](#) : GetImportedNotes Method (IMBD3DPdfData)

Gets the imported note names from the theme of this MBD3DPdfData.

.NET Syntax

Visual Basic (Declaration)

```
Function GetImportedNotes() As System.Object
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IMBD3DPdfData
Dim value As System.Object

value = instance.GetImportedNotes()
```

C#

```
System.object GetImportedNotes()
```

C++/CLI

```
System.Object^ GetImportedNotes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of imported note names

Visual Basic for Applications (VBA) Syntax

See [IMBD3DPdfData::GetImportedNotes](#).

Example

See the [IMBD3DPdfData::SetImportedNote](#) example.

Remarks

Before calling this method, you need to use [IMBD3DPdfData::ThemeName](#) to set the theme of this MBD3DPdfData.

See Also

[IMBD3DPdfData Interface](#)
[IMBD3DPdfData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetMoreViews Method (IMBD3DPdfData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBD3DPdfData Interface](#) : GetMoreViews Method (IMBD3DPdfData)

Gets the names of the custom views (i.e., [named views](#) and [3D views](#)) in the model for this SOLIDWORKS MBD 3D PDF.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMoreViews() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMBD3DPdfData  
Dim value As System.Object  
  
value = instance.GetMoreViews()
```

C#

```
System.object GetMoreViews()
```

C++/CLI

```
System.Object^ GetMoreViews();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of strings of the names of the custom views

Visual Basic for Applications (VBA) Syntax

See [MBD3DPdfData::GetMoreViews](#).

See Also

[IMBD3DPdfData Interface](#)
[IMBD3DPdfData Members](#)
[IMBD3DPdfData::GetStandardViews Method \(\)](#)
[IMBD3DPdfData::SetMoreViews Method \(\)](#)
[IMBD3DPdfData::SetStandardViews Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetStandardViews Method (IMBD3DPdfData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBD3DPdfData Interface](#) : GetStandardViews Method (IMBD3DPdfData)

Gets the types of standard views in the model for this SOLIDWORKS MBD 3D PDF.

.NET Syntax

Visual Basic (Declaration)

```
Function GetStandardViews() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMBD3DPdfData  
Dim value As System.Object  
  
value = instance.GetStandardViews()
```

C#

```
System.object GetStandardViews()
```

C++/CLI

```
System.Object^ GetStandardViews();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of the types of standard views as defined in [swStandardViews_e](#)

Visual Basic for Applications (VBA) Syntax

See [IMBD3DPdfData::GetStandardViews](#).

See Also

[IMBD3DPdfData Interface](#)
[IMBD3DPdfData Members](#)
[IMBD3DPdfData::GetMoreViews Method \(\)](#)
[IMBD3DPdfData::SetMoreViews Method \(\)](#)
[IMBD3DPdfData::SetStandardViews Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextAndCustomProperties Method (IMBD3DPdfData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBD3DPdfData Interface](#) : GetTextAndCustomProperties Method (IMBD3DPdfData)

Gets the text and custom properties in the [theme](#) for this SOLIDWORKS MBD 3D PDF.

.NET Syntax

Visual Basic (Declaration)

Function GetTextAndCustomProperties() As System.Object

Visual Basic (Usage)



```
Dim instance As IMBD3DPdfData  
Dim value As System.Object
```

```
value = instance.GetTextAndCustomProperties()
```

C#

```
System.object GetTextAndCustomProperties()
```

C++/CLI

```
System.Object^ GetTextAndCustomProperties();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [text and custom properties](#) in the theme for this SOLIDWORKS MBD 3D PDF

Visual Basic for Applications (VBA) Syntax

See [MBD3DPdfData::GetTextAndCustomProperties](#).

Example

[Publish Text and Custom Properties from Theme to MBD 3D PDF \(C#\)](#)
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VB.NET\)](#)
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VBA\)](#)

Remarks

SOLIDWORKS Model Based Definition (MBD) is an integrated drawingless manufacturing solution for SOLIDWORKS.

Typical steps for generating a SOLIDWORKS MBD 3D PDF using the SOLIDWORKS API are:

1. Get the [MBD3DPdfData object](#) using [IModelDocExtension::GetMBD3DPdfData](#).
2. Set the path and file name of the SOLIDWORKS MBD 3D PDF theme using [IMBD3DPdfData::ThemeName](#).
3. Get standard and custom views using [IMBD3DPdfData::GetStandardViews](#) and [IMBD3DPdfData::GetMoreViews](#).
4. Set standard and custom views using [IMBD3DPdfData::SetStandardViews](#) and [IMBD3DPdfData::SetMoreViews](#).
5. Get and set text and custom properties in the theme using the array of objects returned by this method.
6. Set the path for the SOLIDWORKS MBD 3D PDF using [IMBD3DPdfData::FilePath](#).
7. Generate the SOLIDWORKS MBD 3D PDF using [IModelDocExtension::PublishTo3DPDF](#).

See the SOLIDWORKS Help for details about MBD.

See Also

[IMBD3DPdfData Interface](#)
[IMBD3DPdfData Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetAttachments Method (IMBD3DPdfData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBD3DPdfData Interface](#) : SetAttachments Method (IMBD3DPdfData)

Sets the fully qualified paths of the files to include as attachments when publishing to SOLIDWORKS MBD 3D PDF.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetAttachments( _  
    ByVal values As System.Object _
```

)

Visual Basic (Usage)



```
Dim instance As IMBD3DPdfData  
Dim Values As System.Object  
  
instance.SetAttachments(Values)
```

C#

```
void SetAttachments(  
    System.Object Values  
)
```

C++/CLI

```
void SetAttachments(  
& System.Object^ Values  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Values

Array of strings of the fully qualified paths of the files to include as attachments

Visual Basic for Applications (VBA) Syntax

See [MBD3DPdfData::SetAttachments](#).

Example

[Attach Files to MBD 3D PDF \(C#\)](#)
[Attach Files to MBD 3D PDF \(VB.NET\)](#)
[Attach Files to MBD 3D PDF \(VBA\)](#)

See Also

[IMBD3DPdfData Interface](#)
[IMBD3DPdfData Members](#)
[IMBD3DPdfData::GetAttachments Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetBomTable Method (IMBD3DPdfData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBD3DPdfData Interface](#) : SetBomTable Method (IMBD3DPdfData)

Maps a BOM Table Area in the [theme](#) with a BOM table in the model and sets the columns in the BOM table to export to the BOM Table Area in a SOLIDWORKS MBD 3D PDF.

.NET Syntax

Visual Basic (Declaration)

```
Function SetBomTable( _  
    ByVal Index As System.Integer, _  
    ByVal BomTableName As System.String, _  
    ByVal Columns As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMBD3DPdfData  
Dim Index As System.Integer
```

```
Dim BomTableName As System.String
Dim Columns As System.Object
Dim value As System.Integer

value = instance.SetBomTable(Index, BomTableName, Columns)
```

C#

```
System.int SetBomTable(
    System.int Index,
    System.string BomTableName,
    System.object Columns
)
```

C++/CLI

```
System.int SetBomTable(
    & System.int Index,
    & System.String^ BomTableName,
    & System.Object^ Columns
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

0-based index of the BOM Table Area in the theme (see **Remarks**)

BomTableName

Name of the BOM table to map to the BOM Table Area specified by Index (see **Remarks**)

Columns

Array of strings of the names of the columns to export from the BOM table specified in BomTableName (see **Remarks**)

Return Value

0 = success; BOM table mapped

1 = failure; specified BomTableName not found in model

Visual Basic for Applications (VBA) Syntax

See [IMBD3DPdfData::SetBomTable](#).

Example

[Export BOM's Second Column to BOM Table Area \(C#\)](#)
[Export BOM's Second Column to BOM Table Area \(VB.NET\)](#)
[Export BOM's Second Column to BOM Table Area \(VBA\)](#)

Remarks

To get...	Call...
Index	IMBD3DPdfData::GetBomAreaCount to find out the number of BOM Table Areas in the theme
BomTableName	IBomFeature::Name
Columns	ITableAnnotation::ColumnCount to get the number of columns in the BOM table TableAnnotation::GetColumnName for each column you want to export after getting the table annotation for the BOM table annotation

See Also

[IMBD3DPdfData Interface](#)
[IMBD3DPdfData Members](#)
[IMBD3DPdfData::ExcludeFromAnnotationView Property\(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SetImportedNote Method (IMBD3DPdfData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBD3DPdfData Interface](#) : SetImportedNote Method (IMBD3DPdfData)

Sets the specified imported note.

.NET Syntax

Visual Basic (Declaration)

```
Function SetImportedNote( _  
    ByVal Name As System.String, _  
    ByVal Note As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMBD3DPdfData  
Dim Name As System.String  
Dim Note As System.Object  
Dim value As System.Boolean  
  
value = instance.SetImportedNote(Name, Note)
```

C#

```
System.bool SetImportedNote(  
    System.string Name,  
    System.object Note  
)
```

C++/CLI

```
System.bool SetImportedNote(  
& System.String^ Name,  
& System.Object^ Note  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Name of the imported note to set (see **Remarks**)

Note

[INote](#)

Return Value

True if note set successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [MBD3DPdfData::SetImportedNote](#).

Example

'VBA

'Open a model with two notes.

'Ensure that the specified theme.xml exists or set IMBD3DPdfData::ThemeName to a standard SOLIDWORKS theme.

'See IMBD3DPdfData::ThemeName for details.

'Run the following macro to create MBDPart1.PDF.

```
Option Explicit  
Dim swApp As SldWorks.SldWorks  
Dim swModel As SldWorks.ModelDoc2  
Dim swModelDocExt As SldWorks.ModelDocExtension  
Dim swMBDPdfData As SldWorks.MBD3DPdfData  
Dim fileName As String  
Dim standardViews As Variant  
Dim viewIDs(2) As Long
```

```

Dim viewNames(1) As String
Dim status As Long
Dim Vtitle As Variant
Dim swnote1 As SldWorks.Note
Dim swnote2 As SldWorks.Note
Dim boolstatus As Boolean
Sub main()

    Set swApp = Application.SldWorks
    Set swModel = swApp.ActiveDoc
    Set swModelDocExt = swModel.Extension

    'Get MBD3DPdfData object
    Set swMBDPdfData = swModelDocExt.GetMBD3DPdfData

    'Set path and file name for SOLIDWORKS MBD 3D PDF
    swMBDPdfData.FilePath = swApp.GetCurrentMacroPathFolder + "\MBDPart1.PDF"

    'Display SOLIDWORKS MBD 3D PDF after saving
    swMBDPdfData.ViewPdfAfterSaving = True

    'Set SOLIDWORKS MBD 3D PDF theme
    swMBDPdfData.ThemeName = swApp.GetCurrentMacroPathFolder + "\multipage assembly 1 (a4 landscape)\theme.xml"

    viewIDs(0) = swStandardViews_e.swIsometricView
    standardViews = viewIDs
    swMBDPdfData.SetStandardViews (standardViews)

    Vtitle = swMBDPdfData.GetImportedNotes()

    Debug.Print "Number of imported notes: " & UBound(Vtitle)
    Debug.Print "Names of imported notes in theme.xml: " & Vtitle(0) & "," & Vtitle(1)

    swModel.ClearSelection2 True

    boolstatus = swModel.Extension.SelectByID2("DetailItem1@Annotations", "NOTE", 4.4204917724824E-03, 3.51478241987688E-02, -1.41024939463153E-02, True, 0, Nothing, 0)
    boolstatus = swModel.Extension.SelectByID2("DetailItem2@Annotations", "NOTE", 0.0235101574792542.73959875410024E-02, -1.89093669451609E-02, True, 0, Nothing, 0)

    Set swnote1 = swModel.SelectionManager.GetSelectedObject6(1, -1)
    Set swnote2 = swModel.SelectionManager.GetSelectedObject6(2, -1)

    boolstatus = swMBDPdfData.SetImportedNote(Vtitle(0), swnote1)
    boolstatus = swMBDPdfData.SetImportedNote(Vtitle(1), swnote2)

    'Create SOLIDWORKS MBD 3D PDF
    status = swModelDocExt.PublishTo3DPDF(swMBDPdfData)
    Debug.Print ("Status of publishing part to SOLIDWORKS MBD 3D PDF (0 = success): " & status)

End Sub

```

Remarks

Use [IMBD3DPdfData::GetImportedNotes](#) to get the names of available imported note names you can use to set notes in this PDF.

See Also

[IMBD3DPdfData Interface](#)
[IMBD3DPdfData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBD3DPdfData Interface](#) : SetIndependentViewPort Method (IMBD3DPdfData)

Sets the specified view for an independent viewport for the SOLIDWORKS MBD 3D PDF.

.NET Syntax

Visual Basic (Declaration)

```
Function SetIndependentViewPort( _  
    ByVal ViewName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMBD3DPdfData  
Dim ViewName As System.String  
Dim value As System.Boolean
```

```
value = instance.SetIndependentViewPort(ViewName)
```

C#

```
System.bool SetIndependentViewPort(  
    System.string ViewName  
)
```

C++/CLI

```
System.bool SetIndependentViewPort(  
& System.String^ ViewName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ViewName

Name of the view (e.g., "Top View" or "*Top")

Return Value

True if the specified view is set for an independent viewport for the SOLIDWORKS MBD 3D PDF, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [MBD3DPdfData::SetIndependentViewPort](#).

Example

[Set Independent Viewport for MBD 3D PDF \(C#\)](#)
[Set Independent Viewport for MBD 3D PDF \(VB.NET\)](#)
[Set Independent Viewport for MBD 3D PDF \(VBA\)](#)

Remarks

The [theme](#) for the SOLIDWORKS MBD 3D PDF must contain an independent viewport. See the examples for instructions on how to add an independent viewport to a theme and how to set a view for that independent viewport.

See Also

[IMBD3DPdfData Interface](#)
[IMBD3DPdfData Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBD3DPdfData Interface](#) : SetMoreViews Method (IMBD3DPdfData)

Sets the names of the custom views (i.e., [named views](#) and [3D views](#)) in the model for this SOLIDWORKS MBD 3D PDF.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetMoreViews(  
    ByVal Values As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IMBD3DPdfData  
Dim Values As System.Object  
  
instance.SetMoreViews(Values)
```

C#

```
void SetMoreViews(  
    System.Object Values  
)
```

C++/CLI

```
void SetMoreViews(  
& System.Object^ Values  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Values
Array of strings of the names of the custom views

Visual Basic for Applications (VBA) Syntax

See [MBD3DPdfData::SetMoreViews](#).

Example

[Publish Text and Custom Properties from Theme to MBD 3D PDF \(C#\)](#)
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VB.NET\)](#)
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VBA\)](#)

See Also

[IMBD3DPdfData Interface](#)
[IMBD3DPdfData Members](#)
[IMBD3DPdfData::GetMoreViews Method \(\)](#)
[IMBD3DPdfData::SetStandardViews Method \(\)](#)
[IMBD3DPdfData::GetStandardViews Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetStandardViews Method (IMBD3DPdfData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBD3DPdfData Interface](#) : SetStandardViews Method (IMBD3DPdfData)

Sets the types of standard views in the model for this SOLIDWORKS MBD 3D PDF.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetStandardViews( _  
    ByVal Values As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IMBD3DPdfData  
Dim Values As System.Object  
  
instance.SetStandardViews(Values)
```

C#

```
void SetStandardViews(  
    System.object Values  
)
```

C++/CLI

```
void SetStandardViews(  
& System.Object^ Values  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Values

Array of the types of standard views as defined in [swStandardViews_e](#)

Visual Basic for Applications (VBA) Syntax

See [MBD3DPdfData::SetStandardViews](#).

Example

[Publish Text and Custom Properties from Theme to MBD 3D PDF \(C#\)](#)
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VB.NET\)](#)
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VBA\)](#)

See Also

[IMBD3DPdfData Interface](#)
[IMBD3DPdfData Members](#)
[IMBD3DPdfData::GetStandardViews Method \(\)](#)
[IMBD3DPdfData::GetMoreViews Method \(\)](#)
[IMBD3DPdfData::SetMoreViews Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

STEP242Edition Property (IMBD3DPdfData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBD3DPdfData Interface](#) : STEP242Edition Property (IMBD3DPdfData)

Gets or sets the STEP 242 edition to use.

.NET Syntax

Visual Basic (Declaration)

```
Property STEP242Edition As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMBD3DPdfData  
Dim value As System.Integer
```

```
instance.STEP242Edition = value
```

```
value = instance.STEP242Edition
```

C#

```
System.int STEP242Edition {get; set;}
```

C++/CLI

```
property System.int STEP242Edition {  
    System.int get();  
    void set ( &    System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

STEP 242 edition as defined by [swMBDSTEP242PublishEdition_e](#)

Visual Basic for Applications (VBA) Syntax

See [MBD3DPdfData::STEP242Edition](#).

Remarks

See the [IMBDSTEP242Data](#) examples.

See Also

[IMBD3DPdfData Interface](#)
[IMBD3DPdfData Members](#)

Availability

SOLIDWORKS 2025 SP03, Revision Number 33.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

ThemeName Property (IMBD3DPdfData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBD3DPdfData Interface](#) : ThemeName Property (IMBD3DPdfData)

Gets or sets the path and file name of the theme for this SOLIDWORKS MBD 3D PDF.

.NET Syntax

Visual Basic (Declaration)

```
Property ThemeName As System.String
```

Visual Basic (Usage)



```
Dim instance As IMBD3DPdfData  
Dim value As System.String
```

```
instance.ThemeName = value
```

```
value = instance.ThemeName
```

C#

```
System.string ThemeName {get; set;}
```

C++/CLI

```
property System.String^ ThemeName {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path and file name of the theme

Visual Basic for Applications (VBA) Syntax

See [IMBD3DPdfData::ThemeName](#).

Example

[Publish Text and Custom Properties from Theme to MBD 3D PDF \(C#\)](#)
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VB.NET\)](#)
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VBA\)](#)

Remarks

You can also get or set the SOLIDWORKS MBD 3D PDF path for a theme using:

- SOLIDWORKS API. Call:
 - [ISldWorks::GetUserPreferenceStringValue](#)(swUserPreferenceStringValue_e.swFileLocationsThemeFolder) or
 - [ISldWorks::SetUserPreferenceStringValue](#)(swUserPreferenceStringValue_e.swFileLocationsThemeFolder, <Value>)
- SOLIDWORKS Design user interface. Click **Tools > System Options > File Locations > 3D PDF Themes** in **Show folders for**.

See Also

[IMBD3DPdfData Interface](#)
[IMBD3DPdfData Members](#)
[IMBD3DPdfData::SetIndependentViewPort Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ViewPdfAfterSaving Property (IMBD3DPdfData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBD3DPdfData Interface](#) : ViewPdfAfterSaving Property (IMBD3DPdfData)

Gets or sets whether to display this SOLIDWORKS MBD 3D PDF after [publishing it](#).

.NET Syntax

Visual Basic (Declaration)

```
Property ViewPdfAfterSaving As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMBD3DPdfData
Dim value As System.Boolean
```

```
instance.ViewPdfAfterSaving = value
```

```
value = instance.ViewPdfAfterSaving
```

C#

```
System.bool ViewPdfAfterSaving {get; set;}
```

C++/CLI

```
property System.bool ViewPdfAfterSaving {
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to display the SOLIDWORKS MBD 3D PDF after publishing it, false to not

Visual Basic for Applications (VBA) Syntax

See [MBD3DPdfData::ViewPdfAfterSaving](#).

Example

[Publish Text and Custom Properties from Theme to MBD 3D PDF \(C#\)](#)
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VB.NET\)](#)
[Publish Text and Custom Properties from Theme to MBD 3D PDF \(VBA\)](#)

See Also

[IMBD3DPdfData Interface](#)
[IMBD3DPdfData Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

IMBDSTEP242Data (Type)

IMBDSTEP242Data Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMBDSTEP242Data Interface

Allows access to the details for publishing a SOLIDWORKS MBD 3D STEP242 file.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IMBDSTEP242Data

Visual Basic (Usage)

Dim instance As [IMBDSTEP242Data](#)

C#

public interface IMBDSTEP242Data

C++/CLI

public interface class IMBDSTEP242Data

Visual Basic for Applications (VBA) Syntax

See [MBDSTEP242Data](#).

Example

[Export SOLIDWORKS MBD to STEP 242 \(VBA\)](#)
[Export SOLIDWORKS MBD to STEP 242 \(VB.NET\)](#)
[Export SOLIDWORKS MBD to STEP 242 \(C#\)](#)

Remarks

SOLIDWORKS Model Based Definition (MBD) is an integrated drawingless manufacturing solution for SOLIDWORKS.

This interface and its methods and properties require that the SOLDWORKS MBD add-in be loaded. ([ISldWorks::LoadAddIn](#))

The MBDSTEP242Data object corresponds to the SOLIDWORKS MBD **Publish to STEP242** PropertyManager page.

See the SOLIDWORKS Help for details about MBD.

Accessors

[IModelDocExtension::GetIMBDSTEP242Data](#)

Access Diagram

[MBDSTEP242Data](#)

See Also

[IMBDSTEP242Data Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IMBDSTEP242Data Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMBDSTEP242Data Interface

The following tables list the members exposed by [IMBDSTEP242Data](#).

Public Properties	
Name	Description
 CustomPropertiesToPublish	Gets or sets the model's custom properties to export to the STEP 242 format.
 ExportFaceEdgeProperties	Gets or sets whether to export face and edge properties to the STEP 242 format.
 PublishFileName	Gets or sets the path and file name to which to export this SOLIDWORKS MBD STEP 242 data.
 PublishWithAllCustomProperties	Gets or sets whether to publish all custom properties to the STEP 242 format.
 SplitPeriodicFaces	Gets or sets whether to split periodic faces into two.
 STEP242Edition	Gets or sets the STEP 242 edition to use.
Top	

See Also

[IMBDSTEP242Data Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

IMBDSTEP242Data Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IMBDSTEP242Data Interface

For a list of all members of this type, see [IMBDSTEP242Data members](#).

Public Properties	
Name	Description
 CustomPropertiesToPublish	Gets or sets the model's custom properties to export to the STEP 242 format.
 ExportFaceEdgeProperties	Gets or sets whether to export face and edge properties to the STEP 242 format.
 PublishFileName	Gets or sets the path and file name to which to export this SOLIDWORKS MBD STEP 242 data.
 PublishWithAllCustomProperties	Gets or sets whether to publish all custom properties to the STEP 242 format.
 SplitPeriodicFaces	Gets or sets whether to split periodic faces into two.
 STEP242Edition	Gets or sets the STEP 242 edition to use.
Top	

See Also

[IMBDSTEP242Data Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

CustomPropertiesToPublish Property (IMBDSTEP242Data)

[See Also](#)

  [SolidWorks.Interop.sldworks Namespace](#) > [IMBDSTEP242Data Interface](#) : CustomPropertiesToPublish Property (IMBDSTEP242Data)

Gets or sets the model's custom properties to export to the STEP 242 format.

.NET Syntax	
Visual Basic (Declaration)	
Property CustomPropertiesToPublish As System.Object	
Visual Basic (Usage)	
Dim instance As IMBDSTEP242Data Dim value As System.Object	

```
instance.CustomPropertiesToPublish = value  
value = instance.CustomPropertiesToPublish
```

C#

```
System.Object CustomPropertiesToPublish {get; set;}
```

C++/CLI

```
property System.Object^ CustomPropertiesToPublish {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of custom properties

Visual Basic for Applications (VBA) Syntax

See [IMBDSTEP242Data::CustomPropertiesToPublish](#).

Example

See the [IMBDSTEP242Data](#) examples.

Remarks

This property is valid only if [IMBDSTEP242Data::PublishWithAllCustomProperties](#) is set to false.

See Also

[IMBDSTEP242Data Interface](#)
[IMBDSTEP242Data Members](#)

Availability

SOLIDWORKS 2025 SP03, Revision Number 33.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

ExportFaceEdgeProperties Property (IMBDSTEP242Data)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBDSTEP242Data Interface](#) : ExportFaceEdgeProperties Property (IMBDSTEP242Data)

Gets or sets whether to export face and edge properties to the STEP 242 format.

.NET Syntax

Visual Basic (Declaration)

```
Property ExportFaceEdgeProperties As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMBDSTEP242Data  
Dim value As System.Boolean
```

```
instance.ExportFaceEdgeProperties = value  
value = instance.ExportFaceEdgeProperties
```

C#

```
System.bool ExportFaceEdgeProperties {get; set;}
```

C++/CLI

```
property System.bool ExportFaceEdgeProperties {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to export face and edge properties, false to not

Visual Basic for Applications (VBA) Syntax

See [IMBDSTEP242Data::ExportFaceEdgeProperties](#).

Example

See the [IMBDSTEP242Data](#) examples.

See Also

[IMBDSTEP242Data Interface](#)
[IMBDSTEP242Data Members](#)

Availability

SOLIDWORKS 2025 SP03, Revision Number 33.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

PublishFileName Property (IMBDSTEP242Data)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBDSTEP242Data Interface](#) : PublishFileName Property (IMBDSTEP242Data)

Gets or sets the path and file name to which to export this SOLIDWORKS MBD STEP 242 data.

.NET Syntax

Visual Basic (Declaration)

```
Property PublishFileName As System.String
```

Visual Basic (Usage)



```
Dim instance As IMBDSTEP242Data
Dim value As System.String
```

```
instance.PublishFileName = value
```

```
value = instance.PublishFileName
```

C#

```
System.string PublishFileName {get; set;}
```

C++/CLI

```
property System.String^ PublishFileName {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pathname of STEP 242 file (*.stp)

Visual Basic for Applications (VBA) Syntax

See [MBDSTEP242Data::PublishFileName](#).

Example

See the [IMBDSTEP242Data](#) examples.

See Also

[IMBDSTEP242Data Interface](#)
[IMBDSTEP242Data Members](#)

Availability

SOLIDWORKS 2025 SP03, Revision Number 33.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

PublishWithAllCustomProperties Property (IMBDSTEP242Data)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBDSTEP242Data Interface](#) : PublishWithAllCustomProperties Property (IMBDSTEP242Data)

Gets or sets whether to publish all custom properties to the STEP 242 format.

.NET Syntax

Visual Basic (Declaration)

```
Property PublishWithAllCustomProperties As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IMBDSTEP242Data  
Dim value As System.Boolean
```

```
instance.PublishWithAllCustomProperties = value
```

```
value = instance.PublishWithAllCustomProperties
```

C#

```
System.bool PublishWithAllCustomProperties {get; set;}
```

C++/CLI

```
property System.bool PublishWithAllCustomProperties {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to publish all custom properties, false to not

Visual Basic for Applications (VBA) Syntax

See [MBDSTEP242Data::PublishWithAllCustomProperties](#).

Example

See the [IMBDSTEP242Data](#) examples.

See Also

[IMBDSTEP242Data Interface](#)
[IMBDSTEP242Data Members](#)

Availability

SOLIDWORKS 2025 SP03, Revision Number 33.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

SplitPeriodicFaces Property (IMBDSTEP242Data)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBDSTEP242Data Interface](#) : SplitPeriodicFaces Property (IMBDSTEP242Data)

Gets or sets whether to split periodic faces into two.

.NET Syntax

Visual Basic (Declaration)

Property SplitPeriodicFaces As System.Boolean

Visual Basic (Usage)



```
Dim instance As IMBDSTEP242Data
Dim value As System.Boolean

instance.SplitPeriodicFaces = value
value = instance.SplitPeriodicFaces
```

C#

```
System.bool SplitPeriodicFaces {get; set;}
```

C++/CLI

```
property System.bool SplitPeriodicFaces {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to split periodic faces, false to not

Visual Basic for Applications (VBA) Syntax

See [IMBDSTEP242Data::SplitPeriodicFaces](#).

Example

See the [IMBDSTEP242Data](#) examples.

See Also

[IMBDSTEP242Data Interface](#)
[IMBDSTEP242Data Members](#)

Availability

SOLIDWORKS 2025 SP03, Revision Number 33.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

STEP242Edition Property (IMBDSTEP242Data)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMBDSTEP242Data Interface](#) : STEP242Edition Property (IMBDSTEP242Data)

Gets or sets the STEP 242 edition to use.

.NET Syntax

Visual Basic (Declaration)

Property STEP242Edition As System.Integer

Visual Basic (Usage)



```
Dim instance As IMBDSTEP242Data  
Dim value As System.Integer
```

```
instance.STEP242Edition = value
```

```
value = instance.STEP242Edition
```

C#

```
System.int STEP242Edition {get; set;}
```

C++/CLI

```
property System.int STEP242Edition {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

STEP 242 edition as defined by [swMBDSTEP242PublishEdition_e](#)

Visual Basic for Applications (VBA) Syntax

See [MBDSTEP242Data::STEP242Edition](#).

Example

See the [IMBDSTEP242Data](#) examples.

See Also

[IMBDSTEP242Data Interface](#)
[IMBDSTEP242Data Members](#)

Availability

SOLIDWORKS 2025 SP03, Revision Number 33.3