

SOLIDWORKS API (.NET VBA C#) — Reference

(160/337): IMidSurface-IMidSurface2

SOLIDWORKS API Documentation (converted from CHM)

IMidSurface (Type)

IMidSurface Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMidSurface Interface

Obsolete. Superseded by [IMidSurface3](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IMidSurface
```

Visual Basic (Usage)



```
Dim instance As IMidSurface
```

C#

```
public interface IMidSurface
```

C++/CLI

```
public interface class IMidSurface
```

Visual Basic for Applications (VBA) Syntax

See [MidSurface](#).

See Also

[IMidSurface Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IMidSurface Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMidSurface Interface

The following tables list the members exposed by [IMidSurface](#).

Public Methods

Name	Description
 EdgeGetFace	Obsolete. Superseded by IMidSurface2:EdgeGetFace .
 GetFaceCount	Obsolete. Superseded by IMidSurface2:GetFaceCount .
 GetFacePairCount	Obsolete. Superseded by IMidSurface2:GetFacePairCount .
 GetFirstFace	Obsolete. Superseded by IMidSurface2:GetFirstFace .
 GetFirstFaceArray	Obsolete. Superseded by IMidSurface2:GetFirstFaceArray .
 GetFirstFacePair	Obsolete. Superseded by IMidSurface2:GetFirstFacePair .
 GetFirstNeutralSheet	Obsolete. Superseded by IMidSurface2:GetFirstNeutralSheet .
 GetNeutralSheetCount	Obsolete. Superseded by IMidSurface2:GetNeutralSheetCount .
 GetNextFace	Obsolete. Superseded by IMidSurface2:GetNextFace .
 GetNextFaceArray	Obsolete. Superseded by IMidSurface2:GetNextFaceArray .
 GetNextFacePair	Obsolete. Superseded by IMidSurface2:GetNextFacePair .
 GetNextNeutralSheet	Obsolete. Superseded by IMidSurface2:GetNextNeutralSheet .

		
	IEdgeGetFace	Obsolete. Superseded by IMidSurface2:IEdgeGetFace .
	IGetFirstFace	Obsolete. Superseded by IMidSurface2:IGetFirstFace .
	IGetFirstFaceArray	Obsolete. Superseded by IMidSurface2:IGetFirstFaceArray .
	IGetFirstFacePair	Obsolete. Superseded by IMidSurface2:IGetFirstFacePair .
	IGetFirstNeutralSheet	Obsolete. Superseded by IMidSurface2:IGetFirstNeutralSheet .
	IGetNextFace	Obsolete. Superseded by IMidSurface2:IGetNextFace .
	IGetNextFaceArray	Obsolete. Superseded by IMidSurface2:IGetNextFaceArray .
	IGetNextFacePair	Obsolete. Superseded by IMidSurface2:IGetNextFacePair .
	IGetNextNeutralSheet	Obsolete. Superseded by IMidSurface2:IGetNextNeutralSheet .

[Top](#)

 See Also

[IMidSurface Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMidSurface Interface Methods

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IMidSurface Interface

For a list of all members of this type, see [IMidSurface members](#).

 Public Methods

Name	Description
	EdgeGetFace Obsolete. Superseded by IMidSurface2:EdgeGetFace .
	GetFaceCount Obsolete. Superseded by IMidSurface2:GetFaceCount .
	GetFacePairCount Obsolete. Superseded by IMidSurface2:GetFacePairCount .
	GetFirstFace Obsolete. Superseded by IMidSurface2:GetFirstFace .
	GetFirstFaceArray Obsolete. Superseded by IMidSurface2:GetFirstFaceArray .
	GetFirstFacePair Obsolete. Superseded by IMidSurface2:GetFirstFacePair .
	GetFirstNeutralSheet Obsolete. Superseded by IMidSurface2:GetFirstNeutralSheet .
	GetNeutralSheetCount Obsolete. Superseded by IMidSurface2:GetNeutralSheetCount .
	GetNextFace Obsolete. Superseded by IMidSurface2:GetNextFace .
	GetNextFaceArray Obsolete. Superseded by IMidSurface2:GetNextFaceArray .
	GetNextFacePair Obsolete. Superseded by IMidSurface2:GetNextFacePair .
	GetNextNeutralSheet Obsolete. Superseded by IMidSurface2:GetNextNeutralSheet .
	IEdgeGetFace Obsolete. Superseded by IMidSurface2:IEdgeGetFace .
	IGetFirstFace Obsolete. Superseded by IMidSurface2:IGetFirstFace .
	IGetFirstFaceArray Obsolete. Superseded by IMidSurface2:IGetFirstFaceArray .
	IGetFirstFacePair Obsolete. Superseded by IMidSurface2:IGetFirstFacePair .
	IGetFirstNeutralSheet Obsolete. Superseded by IMidSurface2:IGetFirstNeutralSheet .
	IGetNextFace Obsolete. Superseded by IMidSurface2:IGetNextFace .
	IGetNextFaceArray Obsolete. Superseded by IMidSurface2:IGetNextFaceArray .
	IGetNextFacePair Obsolete. Superseded by IMidSurface2:IGetNextFacePair .
	IGetNextNeutralSheet Obsolete. Superseded by IMidSurface2:IGetNextNeutralSheet .

[Top](#)

See Also

[IMidSurface Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

EdgeGetFace Method (IMidSurface)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface Interface](#) : EdgeGetFace Method (IMidSurface)

Obsolete. Superseded by [IMidSurface2::EdgeGetFace](#).

.NET Syntax

Visual Basic (Declaration)

```
Function EdgeGetFace( _  
    ByVal EdgeInDisp As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface  
Dim EdgeInDisp As System.Object  
Dim value As System.Object  
  
value = instance.EdgeGetFace(EdgeInDisp)
```

C#

```
System.object EdgeGetFace(  
    System.object EdgeInDisp  
)
```

C++/CLI

```
System.Object^ EdgeGetFace(  
& System.Object^ EdgeInDisp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EdgeInDisp

Visual Basic for Applications (VBA) Syntax

See [MidSurface::EdgeGetFace](#).

See Also

[IMidSurface Interface](#)
[IMidSurface Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFaceCount Method (IMidSurface)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface Interface](#) : GetFaceCount Method (IMidSurface)

Obsolete. Superseded by [IMidSurface2::GetFaceCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFaceCount() As System.Integer
```

```
Dim instance As IMidSurface
Dim value As System.Integer

value = instance.GetFaceCount()
```

C#

```
System.int GetFaceCount()
```

C++/CLI

```
System.int GetFaceCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MidSurface::GetFaceCount](#).

See Also

[IMidSurface Interface](#)
[IMidSurface Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFacePairCount Method (IMidSurface)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface Interface](#) : GetFacePairCount Method (IMidSurface)

Obsolete. Superseded by [IMidSurface2::GetFacePairCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFacePairCount() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IMidSurface
Dim value As System.Integer

value = instance.GetFacePairCount()
```

C#

```
System.int GetFacePairCount()
```

C++/CLI

```
System.int GetFacePairCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MidSurface::GetFacePairCount](#).

See Also

[IMidSurface Interface](#)
[IMidSurface Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstFace Method (IMidSurface)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface Interface](#) : GetFirstFace Method (IMidSurface)

Obsolete. Superseded by [IMidSurface2::GetFirstFace](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstFace( _  
    ByRef FromFace1Disp As System.Object, _  
    ByRef FromFace2Disp As System.Object, _  
    ByRef Thickness As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface  
Dim FromFace1Disp As System.Object  
Dim FromFace2Disp As System.Object  
Dim Thickness As System.Double  
Dim value As System.Object  
  
value = instance.GetFirstFace(FromFace1Disp, FromFace2Disp, Thickness)
```

C#

```
System.object GetFirstFace(  
    out System.object FromFace1Disp,  
    out System.object FromFace2Disp,  
    out System.double Thickness  
)
```

C++/CLI

```
System.Object^ GetFirstFace(  
& [Out] System.Object^ FromFace1Disp,  
& [Out] System.Object^ FromFace2Disp,  
& [Out] System.double Thickness  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FromFace1Disp

FromFace2Disp

Thickness

Visual Basic for Applications (VBA) Syntax

See [MidSurface::GetFirstFace](#).

See Also

[IMidSurface Interface](#)
[IMidSurface Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFirstFaceArray Method (IMidSurface)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface Interface](#) : GetFirstFaceArray Method (IMidSurface)

Obsolete. Superseded by [IMidSurface2::GetFirstFaceArray](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstFaceArray( _  
    ByRef Thickness As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface  
Dim Thickness As System.Double  
Dim value As System.Object  
  
value = instance.GetFirstFaceArray(Thickness)
```

C#

```
System.object GetFirstFaceArray(  
    out System.double Thickness  
)
```

C++/CLI

```
System.Object^ GetFirstFaceArray(  
& [Out] System.double Thickness  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Thickness

Visual Basic for Applications (VBA) Syntax

See [MidSurface::GetFirstFaceArray](#).

See Also

[IMidSurface Interface](#)
[IMidSurface Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFirstFacePair Method (IMidSurface)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface Interface](#) : GetFirstFacePair Method (IMidSurface)

Obsolete. Superseded by [IMidSurface2::GetFirstFacePair](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstFacePair( _  
    ByRef Thickness As System.Double, _  
    ByRef PartnerFaceDisp As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface  
Dim Thickness As System.Double  
Dim PartnerFaceDisp As System.Object  
Dim value As System.Object  
  
value = instance.GetFirstFacePair(Thickness, PartnerFaceDisp)
```

C#

```
System.object GetFirstFacePair(  
    out System.double Thickness,  
    out System.object PartnerFaceDisp  
)
```

C++/CLI

```
System.Object^ GetFirstFacePair(  
& [Out] System.double Thickness,  
& [Out] System.Object^ PartnerFaceDisp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Thickness

PartnerFaceDisp

Visual Basic for Applications (VBA) Syntax

See [MidSurface::GetFirstFacePair](#).

See Also

[IMidSurface Interface](#)
[IMidSurface Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstNeutralSheet Method (IMidSurface)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface Interface](#) : GetFirstNeutralSheet Method (IMidSurface)

Obsolete. Superseded by [IMidSurface2::GetFirstNeutralSheet](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstNeutralSheet() As System.Object
```

Visual Basic (Usage)

```
Dim instance As IMidSurface  
Dim value As System.Object  
  
value = instance.GetFirstNeutralSheet()
```

C#

```
System.object GetFirstNeutralSheet()
```

C++/CLI

```
System.Object^ GetFirstNeutralSheet();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MidSurface::GetFirstNeutralSheet](#).

See Also

[IMidSurface Interface](#)
[IMidSurface Members](#)

GetNeutralSheetCount Method (IMidSurface)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface Interface](#) : GetNeutralSheetCount Method (IMidSurface)

Obsolete. Superseded by [IMidSurface2::GetNeutralSheetCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNeutralSheetCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMidSurface  
Dim value As System.Integer  
  
value = instance.GetNeutralSheetCount()
```

C#

```
System.int GetNeutralSheetCount()
```

C++/CLI

```
System.int GetNeutralSheetCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MidSurface::GetNeutralSheetCount](#).

See Also

[IMidSurface Interface](#)
[IMidSurface Members](#)

GetNextFace Method (IMidSurface)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface Interface](#) : GetNextFace Method (IMidSurface)

Obsolete. Superseded by [IMidSurface2::GetNextFace](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNextFace( _  
    ByRef FromFace1Disp As System.Object, _  
    ByRef FromFace2Disp As System.Object, _  
    ByRef Thickness As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface  
Dim FromFace1Disp As System.Object  
Dim FromFace2Disp As System.Object  
Dim Thickness As System.Double  
Dim value As System.Object  
  
value = instance.GetNextFace(FromFace1Disp, FromFace2Disp, Thickness)
```

C#

```
System.Object GetNextFace(
    out System.Object FromFace1Disp,
    out System.Object FromFace2Disp,
    out System.Double Thickness
)
```

C++/CLI

```
System.Object^ GetNextFace(
    & [Out] System.Object^ FromFace1Disp,
    & [Out] System.Object^ FromFace2Disp,
    & [Out] System.Double Thickness
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FromFace1Disp

FromFace2Disp

Thickness

Visual Basic for Applications (VBA) Syntax

See [IMidSurface::GetNextFace](#).

See Also

[IMidSurface Interface](#)
[IMidSurface Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetNextFaceArray Method (IMidSurface)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface Interface](#) : GetNextFaceArray Method (IMidSurface)

Obsolete. Superseded by [IMidSurface2::GetNextFaceArray](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNextFaceArray( _
    ByRef Thickness As System.Double _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface
Dim Thickness As System.Double
Dim value As System.Object
```

```
value = instance.GetNextFaceArray(Thickness)
```

C#

```
System.Object GetNextFaceArray(
    out System.Double Thickness
)
```

C++/CLI

```
System.Object^ GetNextFaceArray(
    & [Out] System.Double Thickness
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Thickness

Visual Basic for Applications (VBA) Syntax

See [MidSurface::GetNextFaceArray](#).

See Also

[IMidSurface Interface](#)
[IMidSurface Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNextFacePair Method (IMidSurface)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface Interface](#) : GetNextFacePair Method (IMidSurface)

Obsolete. Superseded by [IMidSurface2::GetNextFacePair](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNextFacePair( _  
    ByRef Thickness As System.Double, _  
    ByRef PartnerFaceDisp As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface  
Dim Thickness As System.Double  
Dim PartnerFaceDisp As System.Object  
Dim value As System.Object  
  
value = instance.GetNextFacePair(Thickness, PartnerFaceDisp)
```

C#

```
System.object GetNextFacePair(  
    out System.double Thickness,  
    out System.object PartnerFaceDisp  
)
```

C++/CLI

```
System.Object^ GetNextFacePair(  
& [Out] System.double Thickness,  
& [Out] System.Object^ PartnerFaceDisp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Thickness

PartnerFaceDisp

Visual Basic for Applications (VBA) Syntax

See [MidSurface::GetNextFacePair](#).

See Also

[IMidSurface Interface](#)
[IMidSurface Members](#)

GetNextNeutralSheet Method (IMidSurface)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface Interface](#) : GetNextNeutralSheet Method (IMidSurface)

Obsolete. Superseded by [IMidSurface2::GetNextNeutralSheet](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNextNeutralSheet() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface  
Dim value As System.Object  
  
value = instance.GetNextNeutralSheet()
```

C#

```
System.object GetNextNeutralSheet()
```

C++/CLI

```
System.Object^ GetNextNeutralSheet();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MidSurface::GetNextNeutralSheet](#).

See Also

[IMidSurface Interface](#)
[IMidSurface Members](#)

IEdgeGetFace Method (IMidSurface)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface Interface](#) : IEdgeGetFace Method (IMidSurface)

Obsolete. Superseded by [IMidSurface2::IEdgeGetFace](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IEdgeGetFace(  
    ByVal EdgeInDisp As Edge _  
) As Face
```

Visual Basic (Usage)



```
Dim instance As IMidSurface  
Dim EdgeInDisp As Edge  
Dim value As Face  
  
value = instance.IEdgeGetFace(EdgeInDisp)
```

C#

```
Face IEdgeGetFace(  
    Edge EdgeInDisp  
)
```

C++/CLI

```
Face^ IEdgeGetFace(  
&    Edge^ EdgeInDisp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EdgeInDisp

Visual Basic for Applications (VBA) Syntax

See [MidSurface::IEdgeGetFace](#).

See Also

[IMidSurface Interface](#)
[IMidSurface Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFirstFace Method (IMidSurface)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface Interface](#) : IGetFirstFace Method (IMidSurface)

Obsolete. Superseded by [IMidSurface2::IGetFirstFace](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFirstFace( _  
    ByRef FromFace1Disp As Face, _  
    ByRef FromFace2Disp As Face, _  
    ByRef Thickness As System.Double _  
) As Face
```

Visual Basic (Usage)



```
Dim instance As IMidSurface  
Dim FromFace1Disp As Face  
Dim FromFace2Disp As Face  
Dim Thickness As System.Double  
Dim value As Face
```

```
value = instance.IGetFirstFace(FromFace1Disp, FromFace2Disp, Thickness)
```

C#

```
Face IGetFirstFace(  
    out Face FromFace1Disp,  
    out Face FromFace2Disp,  
    out System.double Thickness  
)
```

C++/CLI

```
Face^ IGetFirstFace(  
&    [Out] Face^ FromFace1Disp,  
&    [Out] Face^ FromFace2Disp,  
&    [Out] System.double Thickness  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FromFace1Disp

FromFace2Disp

Thickness

Visual Basic for Applications (VBA) Syntax

See [MidSurface::IGetFirstFace](#).

See Also

[IMidSurface Interface](#)

[IMidSurface Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFirstFaceArray Method (IMidSurface)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface Interface](#) : IGetFirstFaceArray Method (IMidSurface)

Obsolete. Superseded by [IMidSurface2::IGetFirstFaceArray](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFirstFaceArray( _  
    ByVal FromFrontFaceListDisp As System.IntPtr, _  
    ByRef SizeOfFrontFaceList As System.Integer, _  
    ByVal FromFaceBackListDisp As System.IntPtr, _  
    ByRef SizeOfBackFaceList As System.Integer, _  
    ByRef Thickness As System.Double _  
    ) As Face
```

Visual Basic (Usage)



```
Dim instance As IMidSurface  
Dim FromFrontFaceListDisp As System.IntPtr  
Dim SizeOfFrontFaceList As System.Integer  
Dim FromFaceBackListDisp As System.IntPtr  
Dim SizeOfBackFaceList As System.Integer  
Dim Thickness As System.Double  
Dim value As Face  
  
value = instance.IGetFirstFaceArray(FromFrontFaceListDisp, SizeOfFrontFaceList,  
FromFaceBackListDisp, SizeOfBackFaceList, Thickness)
```

C#

```
Face IGetFirstFaceArray(  
    out System.IntPtr FromFrontFaceListDisp,  
    out System.int SizeOfFrontFaceList,  
    out System.IntPtr FromFaceBackListDisp,  
    out System.int SizeOfBackFaceList,  
    out System.double Thickness  
)
```

C++/CLI

```

Face^ IGetFirstFaceArray(
& [Out] System.IntPtr FromFrontFaceListDisp,
& [Out] System.int SizeOfFrontFaceList,
& [Out] System.IntPtr FromFaceBackListDisp,
& [Out] System.int SizeOfBackFaceList,
& [Out] System.double Thickness
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FromFrontFaceListDisp

SizeOfFrontFaceList

FromFaceBackListDisp

SizeOfBackFaceList

Thickness

Visual Basic for Applications (VBA) Syntax

See [IMidSurface::IGetFirstFaceArray](#).

See Also

[IMidSurface Interface](#)
[IMidSurface Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFirstFacePair Method (IMidSurface)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface Interface](#) : IGetFirstFacePair Method (IMidSurface)

Obsolete. Superseded by [IMidSurface2::IGetFirstFacePair](#).

.NET Syntax

Visual Basic (Declaration)

```

Function IGetFirstFacePair( _
    ByRef Thickness As System.Double, _
    ByRef PartnerFaceDisp As Face _
) As Face

```

Visual Basic (Usage)



```

Dim instance As IMidSurface
Dim Thickness As System.Double
Dim PartnerFaceDisp As Face
Dim value As Face

```

```
value = instance.IGetFirstFacePair(Thickness, PartnerFaceDisp)
```

C#

```

Face IGetFirstFacePair(
    out System.double Thickness,
    out Face PartnerFaceDisp
)

```

C++/CLI

```

Face^ IGetFirstFacePair(
& [Out] System.double Thickness,
& [Out] Face^ PartnerFaceDisp
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Thickness

PartnerFaceDisp

Visual Basic for Applications (VBA) Syntax

See [MidSurface::IGetFirstFacePair](#).

See Also

[IMidSurface Interface](#)
[IMidSurface Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFirstNeutralSheet Method (IMidSurface)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface Interface](#) : IGetFirstNeutralSheet Method (IMidSurface)

Obsolete. Superseded by [IMidSurface2::IGetFirstNeutralSheet](#).

.NET Syntax

Visual Basic (Declaration)

Function IGetFirstNeutralSheet() As Body

Visual Basic (Usage)



```
Dim instance As IMidSurface  
Dim value As Body  
  
value = instance.IGetFirstNeutralSheet()
```

C#

Body IGetFirstNeutralSheet()

C++/CLI

Body^ IGetFirstNeutralSheet();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [MidSurface::IGetFirstNeutralSheet](#).

See Also

[IMidSurface Interface](#)
[IMidSurface Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNextFace Method (IMidSurface)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface Interface](#) : IGetNextFace Method (IMidSurface)

Obsolete. Superseded by [IMidSurface2::IGetNextFace](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNextFace( _  
    ByRef FromFace1Disp As Face, _
```

```

        ByRef FromFace2Disp As Face, _
        ByRef Thickness As System.Double _
    ) As Face

```

Visual Basic (Usage)



```

Dim instance As IMidSurface
Dim FromFace1Disp As Face
Dim FromFace2Disp As Face
Dim Thickness As System.Double
Dim value As Face

value = instance.IGetNextFace(FromFace1Disp, FromFace2Disp, Thickness)

```

C#

```

Face IGetNextFace(
    out Face FromFace1Disp,
    out Face FromFace2Disp,
    out System.double Thickness
)

```

C++/CLI

```

Face^ IGetNextFace(
    & [Out] Face^ FromFace1Disp,
    & [Out] Face^ FromFace2Disp,
    & [Out] System.double Thickness
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FromFace1Disp

FromFace2Disp

Thickness

Visual Basic for Applications (VBA) Syntax

See [MidSurface::IGetNextFace](#).

See Also

[IMidSurface Interface](#)
[IMidSurface Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNextFaceArray Method (IMidSurface)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface Interface](#) : IGetNextFaceArray Method (IMidSurface)

Obsolete. Superseded by [IMidSurface2::IGetNextFaceArray](#).

.NET Syntax

Visual Basic (Declaration)

```

Function IGetNextFaceArray( _
    ByVal FromFrontFaceListDisp As System.IntPtr, _
    ByRef SizeOfFrontFaceList As System.Integer, _
    ByVal FromFaceBackListDisp As System.IntPtr, _
    ByRef SizeOfBackFaceList As System.Integer, _
    ByRef Thickness As System.Double _
) As Face

```

Visual Basic (Usage)



```

Dim instance As IMidSurface
Dim FromFrontFaceListDisp As System.IntPtr
Dim SizeOfFrontFaceList As System.Integer
Dim FromFaceBackListDisp As System.IntPtr
Dim SizeOfBackFaceList As System.Integer
Dim Thickness As System.Double
Dim value As Face

value = instance.IGetNextFaceArray(FromFrontFaceListDisp, SizeOfFrontFaceList,
FromFaceBackListDisp, SizeOfBackFaceList, Thickness)

```

C#

```

Face IGetNextFaceArray(
    out System.IntPtr FromFrontFaceListDisp,
    out System.int SizeOfFrontFaceList,
    out System.IntPtr FromFaceBackListDisp,
    out System.int SizeOfBackFaceList,
    out System.double Thickness
)

```

C++/CLI

```

Face^ IGetNextFaceArray(
    & [Out] System.IntPtr FromFrontFaceListDisp,
    & [Out] System.int SizeOfFrontFaceList,
    & [Out] System.IntPtr FromFaceBackListDisp,
    & [Out] System.int SizeOfBackFaceList,
    & [Out] System.double Thickness
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FromFrontFaceListDisp

SizeOfFrontFaceList

FromFaceBackListDisp

SizeOfBackFaceList

Thickness

Visual Basic for Applications (VBA) Syntax

See [MidSurface::IGetNextFaceArray](#).

See Also

[IMidSurface Interface](#)
[IMidSurface Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNextFacePair Method (IMidSurface)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface Interface](#) : IGetNextFacePair Method (IMidSurface)

Obsolete. Superseded by [IMidSurface2::IGetNextFacePair](#).

.NET Syntax

Visual Basic (Declaration)

```

Function IGetNextFacePair( _
    ByRef Thickness As System.Double, _
    ByRef PartnerFaceDisp As Face _
) As Face

```

Visual Basic (Usage)

```
Dim instance As IMidSurface
Dim Thickness As System.Double
Dim PartnerFaceDisp As Face
Dim value As Face

value = instance.IGetNextFacePair(Thickness, PartnerFaceDisp)
```

C#

```
Face IGetNextFacePair(
    out System.double Thickness,
    out Face PartnerFaceDisp
)
```

C++/CLI

```
Face^ IGetNextFacePair(
& [Out] System.double Thickness,
& [Out] Face^ PartnerFaceDisp
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Thickness

PartnerFaceDisp

Visual Basic for Applications (VBA) Syntax

See [MidSurface::IGetNextFacePair](#).

See Also

[IMidSurface Interface](#)
[IMidSurface Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetNextNeutralSheet Method (IMidSurface)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface Interface](#) : IGetNextNeutralSheet Method (IMidSurface)

Obsolete. Superseded by [IMidSurface2::IGetNextNeutralSheet](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNextNeutralSheet() As Body
```

Visual Basic (Usage)

```
Dim instance As IMidSurface
Dim value As Body

value = instance.IGetNextNeutralSheet()
```

C#

```
Body IGetNextNeutralSheet()
```

C++/CLI

```
Body^ IGetNextNeutralSheet();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [IMidSurface::IGetNextNeutralSheet](#).

See Also

[IMidSurface Interface](#)
[IMidSurface Members](#)

IMidSurface2 (Type)

IMidSurface2 Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMidSurface2 Interface

Obsolete. Superseded by [IMidSurface3](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IMidSurface2
```

Visual Basic (Usage)

```
Dim instance As IMidSurface2
```

C#

```
public interface IMidSurface2
```

C++/CLI

```
public interface class IMidSurface2
```

Visual Basic for Applications (VBA) Syntax

See [MidSurface2](#).

Accessors

- [IFeature::GetSpecificFeature2](#)
- [IModelDoc2::InsertMidSurfaceExt](#) and [IModelDoc2::InsertMidSurfaceExt](#)

See Also

- [IMidSurface2 Members](#)
- [SolidWorks.Interop.sldworks Namespace](#)

IMidSurface2 Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMidSurface2 Interface

For a list of all members of this type, see [IMidSurface2 members](#).

Public Methods

Name	Description
EdgeGetFace	Obsolete. Superseded by IMidSurface3:EdgeGetFace .
GetFaceCount	Obsolete. Superseded by IMidSurface3:GetFaceCount .
GetFacePairCount	Obsolete. Superseded by IMidSurface3:GetFacePairCount .
GetFirstFace	Obsolete. Superseded by IMidSurface3:GetFirstFace .
GetFirstFaceArray	Obsolete. Superseded by IMidSurface3:GetFirstFaceArray .
GetFirstFacePair	Obsolete. Superseded by IMidSurface3:GetFirstFacePair .
GetFirstNeutralSheet	Obsolete. Superseded by IMidSurface3:GetFirstNeutralSheet .

 GetNeutralSheetCount	Obsolete. Superseded by IMidSurface3: GetNeutralSheetCount .
 GetNextFace	Obsolete. Superseded by IMidSurface3: GetNextFace .
 GetNextFaceArray	Obsolete. Superseded by IMidSurface3: GetNextFaceArray .
 GetNextFacePair	Obsolete. Superseded by IMidSurface3: GetNextFacePair .
 GetNextNeutralSheet	Obsolete. Superseded by IMidSurface3: GetNextNeutralSheet .
 IEdgeGetFace	Obsolete. Superseded by IMidSurface3: IEdgeGetFace .
 IGetFirstFace	Obsolete. Superseded by IMidSurface3: IGetFirstFace .
 IGetFirstFaceArray	Obsolete. Superseded by IMidSurface3: IGetFirstFaceArray .
 IGetFirstFacePair	Obsolete. Superseded by IMidSurface3: IGetFirstFacePair .
 IGetFirstNeutralSheet	Obsolete. Superseded by IMidSurface3: IGetFirstNeutralSheet .
 IGetNextFace	Obsolete. Superseded by IMidSurface3: IGetNextFace .
 IGetNextFaceArray	Obsolete. Superseded by IMidSurface3: IGetNextFaceArray .
 IGetNextFacePair	Obsolete. Superseded by IMidSurface3: IGetNextFacePair .
 IGetNextNeutralSheet	Obsolete. Superseded by IMidSurface3: IGetNextNeutralSheet .

[Top](#)

See Also

[IMidSurface2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IMidSurface2 Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMidSurface2 Interface

The following tables list the members exposed by [IMidSurface2](#).

Public Methods

Name	Description
 EdgeGetFace	Obsolete. Superseded by IMidSurface3: EdgeGetFace .
 GetFaceCount	Obsolete. Superseded by IMidSurface3: GetFaceCount .
 GetFacePairCount	Obsolete. Superseded by IMidSurface3: GetFacePairCount .
 GetFirstFace	Obsolete. Superseded by IMidSurface3: GetFirstFace .
 GetFirstFaceArray	Obsolete. Superseded by IMidSurface3: GetFirstFaceArray .
 GetFirstFacePair	Obsolete. Superseded by IMidSurface3: GetFirstFacePair .
 GetFirstNeutralSheet	Obsolete. Superseded by IMidSurface3: GetFirstNeutralSheet .
 GetNeutralSheetCount	Obsolete. Superseded by IMidSurface3: GetNeutralSheetCount .
 GetNextFace	Obsolete. Superseded by IMidSurface3: GetNextFace .
 GetNextFaceArray	Obsolete. Superseded by IMidSurface3: GetNextFaceArray .
 GetNextFacePair	Obsolete. Superseded by IMidSurface3: GetNextFacePair .
 GetNextNeutralSheet	Obsolete. Superseded by IMidSurface3: GetNextNeutralSheet .
 IEdgeGetFace	Obsolete. Superseded by IMidSurface3: IEdgeGetFace .
 IGetFirstFace	Obsolete. Superseded by IMidSurface3: IGetFirstFace .
 IGetFirstFaceArray	Obsolete. Superseded by IMidSurface3: IGetFirstFaceArray .
 IGetFirstFacePair	Obsolete. Superseded by IMidSurface3: IGetFirstFacePair .
 IGetFirstNeutralSheet	Obsolete. Superseded by IMidSurface3: IGetFirstNeutralSheet .
 IGetNextFace	Obsolete. Superseded by IMidSurface3: IGetNextFace .

		
	IGetNextFaceArray	Obsolete. Superseded by IMidSurface3:IGetNextFaceArray .
	IGetNextFacePair	Obsolete. Superseded by IMidSurface3:IGetNextFacePair .
	IGetNextNeutralSheet	Obsolete. Superseded by IMidSurface3:IGetNextNeutralSheet .

[Top](#)

See Also

[IMidSurface2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

EdgeGetFace Method (IMidSurface2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface2 Interface](#) : EdgeGetFace Method (IMidSurface2)

Obsolete. Superseded by [IMidSurface3:EdgeGetFace](#).

.NET Syntax

Visual Basic (Declaration)

```
Function EdgeGetFace( _
    ByVal EdgeInDisp As System.Object _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface2
Dim EdgeInDisp As System.Object
Dim value As System.Object

value = instance.EdgeGetFace(EdgeInDisp)
```

C#

```
System.object EdgeGetFace(
    System.object EdgeInDisp
)
```

C++/CLI

```
System.Object^ EdgeGetFace(
    & System.Object^ EdgeInDisp
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EdgeInDisp
Midsurface [edge](#)

Return Value

[Face](#) on the original solid body

Visual Basic for Applications (VBA) Syntax

See [MidSurface2::EdgeGetFace](#).

Remarks

This condition occurs when a reference surface extends to meet one of the faces on the original part body. If the edge specified does not lie on one of the original part body faces, then a NULL is returned.

This edge is not topologically related to the face returned.

See Also

[IMidSurface2 Interface](#)
[IMidSurface2 Members](#)
[IMidSurface2::IEdgeGetFace Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFaceCount Method (IMidSurface2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface2 Interface](#) : GetFaceCount Method (IMidSurface2)

Obsolete. Superseded by [IMidSurface3::GetFaceCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFaceCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMidSurface2  
Dim value As System.Integer  
  
value = instance.GetFaceCount()
```

C#

```
System.int GetFaceCount()
```

C++/CLI

```
System.int GetFaceCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of faces in this midsurface feature

Visual Basic for Applications (VBA) Syntax

See [MidSurface2::GetFaceCount](#).

Remarks

If more than one reference surface exists in the midsurface feature, then those faces are included in the total count returned.

See Also

[IMidSurface2 Interface](#)
[IMidSurface2 Members](#)
[IMidSurface2::GetFirstFace Method](#)
[IMidSurface2::IGetFirstFace Method](#)
[IMidSurface2::GetNextFace Method](#)
[IMidSurface2::IGetNextFace Method](#)
[IMidSurface2::GetFirstFaceArray Method](#)
[IMidSurface2::GetNextFaceArray Method](#)
[IMidSurface2::IGetFirstFaceArray Method](#)
[IMidSurface2::IGetNextFaceArray Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFacePairCount Method (IMidSurface2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface2 Interface](#) : GetFacePairCount Method (IMidSurface2)

Obsolete. Superseded by [IMidSurface3::GetFacePairCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFacePairCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMidSurface2  
Dim value As System.Integer  
  
value = instance.GetFacePairCount()
```

C#

```
System.int GetFacePairCount()
```

C++/CLI

```
System.int GetFacePairCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of parallel face pairs from the original part body

Visual Basic for Applications (VBA) Syntax

See [MidSurface2::GetFacePairCount](#).

See Also

[IMidSurface2 Interface](#)
[IMidSurface2 Members](#)
[IMidSurface2::GetFirstFacePair Method](#)
[IMidSurface2::GetNextFacePair Method](#)
[IMidSurface2::IGetFirstFacePair Method](#)
[IMidSurface2::IGetNextFacePair Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstFace Method (IMidSurface2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface2 Interface](#) : GetFirstFace Method (IMidSurface2)

Obsolete. Superseded by [IMidSurface3::GetFirstFace](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstFace( _  
    ByRef FromFace1Disp As System.Object, _  
    ByRef FromFace2Disp As System.Object, _  
    ByRef Thickness As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```

Dim instance As IMidSurface2
Dim FromFace1Disp As System.Object
Dim FromFace2Disp As System.Object
Dim Thickness As System.Double
Dim value As System.Object

value = instance.GetFirstFace(FromFace1Disp, FromFace2Disp, Thickness)

```

C#

```

System.object GetFirstFace(
    out System.object FromFace1Disp,
    out System.object FromFace2Disp,
    out System.double Thickness
)

```

C++/CLI

```

System.Object^ GetFirstFace(
    & [Out] System.Object^ FromFace1Disp,
    & [Out] System.Object^ FromFace2Disp,
    & [Out] System.double Thickness
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FromFace1Disp
[Face](#) on the original part body used in generating the neutral face
FromFace2Disp
 Parallel [face](#) to FromFace1Disp on the original part body used in generating the neutral face
Thickness
 Distance between the two parallel faces, FromFace1Disp and FromFace2Disp

Return Value

First [face](#) in this midsurface feature

Visual Basic for Applications (VBA) Syntax

See [MidSurface2::GetFirstFace](#).

Remarks

- The first two return values are the two faces from the original part body that were used to generate this midsurface face.
- The next return value is the thickness (in meters) between the two parallel faces from the original part body.
- The last return value is the first face in this midsurface feature.

Use [IMidSurface2::GetNextFace](#) to get the next neutral face in this midsurface feature.

See Also

[IMidSurface2 Interface](#)
[IMidSurface2 Members](#)
[IMidSurface2::IGetFirstFace Method](#)
[IMidSurface2::GetFaceCount Method](#)
[IMidSurface2::IGetNextFace Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstFaceArray Method (IMidSurface2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface2 Interface](#) : GetFirstFaceArray Method (IMidSurface2)

Obsolete. Superseded by [IMidSurface3::GetFirstFaceArray](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetFirstFaceArray( _  
    ByRef Thickness As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface2  
Dim Thickness As System.Double  
Dim value As System.Object  
  
value = instance.GetFirstFaceArray(Thickness)
```

C#

```
System.Object GetFirstFaceArray(  
    out System.double Thickness  
)
```

C++/CLI

```
System.Object^ GetFirstFaceArray(  
& [Out] System.double Thickness  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Thickness

Thickness between the faces

Return Value

First [face](#)

Visual Basic for Applications (VBA) Syntax

See [MidSurface2::GetFirstFaceArray](#).

Remarks

A separator is needed between the front faces and back faces. Thus, a NULL always exists between the front faces and the back faces.

For example, if there are five faces in the model, then the mid-surface has five faces. To get the five faces:

- Call [IMidSurface2::GetFirstFaceArray](#) once.
- Call [IMidSurface2::GetNextFaceArray](#) four times.

At each call, the data is arranged as follows if there is one front face in the array:

[*Neutral face*], [*front face*], NULL, [*back face*]

If there are more than one front face in the array, then the data is arranged as follows:

[*Neutral face*], [*front face1*, *front face2*], NULL, [*back face1*, *back face2*]

To get the next face from the original paired faces, call [IMidSurface2::GetNextFaceArray](#).

See Also

[IMidSurface2 Interface](#)
[IMidSurface2 Members](#)
[IMidSurface2::GetFirstFaceArray Method](#)
[IMidSurface2::GetFaceCount Method](#)
[IMidSurface2::GetNextFaceArray Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

GetFirstFacePair Method (IMidSurface2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface2 Interface](#) : GetFirstFacePair Method (IMidSurface2)

Obsolete. Superseded by [IMidSurface3::GetFirstFacePair](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstFacePair( _  
    ByRef Thickness As System.Double, _  
    ByRef PartnerFaceDisp As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface2  
Dim Thickness As System.Double  
Dim PartnerFaceDisp As System.Object  
Dim value As System.Object  
  
value = instance.GetFirstFacePair(Thickness, PartnerFaceDisp)
```

C#

```
System.object GetFirstFacePair(  
    out System.double Thickness,  
    out System.object PartnerFaceDisp  
)
```

C++/CLI

```
System.Object^ GetFirstFacePair(  
& [Out] System.double Thickness,  
& [Out] System.Object^ PartnerFaceDisp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Thickness

Distance between these two parallel faces

PartnerFaceDisp

[Face](#) on the original part body used in generating the neutral face

Return Value

[Face](#) on the original part body used in generating the neutral face

Visual Basic for Applications (VBA) Syntax

See [MidSurface2::GetFirstFacePair](#).

Remarks

The two faces returned by this method are the two parallel faces from the original part body that were used to generate the first neutral face in this midsurface feature.

This method is similar to [IMidSurface2::GetFirstFace](#), except this method does not return the neutral face.

Call [IMidSurface2::GetNextFacePair](#) to get the next pair of faces in this midsurface feature.

See Also

[IMidSurface2 Interface](#)
[IMidSurface2 Members](#)
[IMidSurface2::GetFirstFacePair Method](#)
[IMidSurface2::GetFacePairCount Method](#)
[IMidSurface2::GetNextFacePair Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstNeutralSheet Method (IMidSurface2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface2 Interface](#) : GetFirstNeutralSheet Method (IMidSurface2)

Obsolete. Superseded by [IMidSurface3::GetFirstNeutralSheet](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstNeutralSheet() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface2  
Dim value As System.Object  
  
value = instance.GetFirstNeutralSheet()
```

C#

```
System.Object GetFirstNeutralSheet()
```

C++/CLI

```
System.Object^ GetFirstNeutralSheet();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First reference surface sheet [body](#) in this midsurface feature

Visual Basic for Applications (VBA) Syntax

See [MidSurface2::GetFirstNeutralSheet](#).

Remarks

Each reference surface in the midsurface feature is considered to be a sheet body. If the reference surfaces are sewn together during the creation of the midsurface feature ([IModelDoc2::InsertMidSurfaceExt](#)), then the midsurface feature contains only one reference surface sheet body.

The sheet body returned from this method has the normal topology that you would expect to find on a body (for example, faces, edges, and so on). See the [IBody2](#) object for methods that provide access to this topology.

Call [IMidSurface2::GetNextNeutralSheet](#) to get the next reference surface in this midsurface feature.

See Also

[IMidSurface2 Interface](#)
[IMidSurface2 Members](#)
[IMidSurface2::IGetFirstNeutralSheet Method](#)
[IMidSurface2::GetNeutralSheetCount Method](#)
[IMidSurface2::IGetNextNeutralSheet Method](#)

Availability

SOLIDWORKS 2001Pus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNeutralSheetCount Method (IMidSurface2)

[See Also](#)



Obsolete. Superseded by [IMidSurface3::GetNeutralSheetCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNeutralSheetCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMidSurface2
Dim value As System.Integer

value = instance.GetNeutralSheetCount()
```

C#

```
System.int GetNeutralSheetCount()
```

C++/CLI

```
System.int GetNeutralSheetCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of reference surface sheet bodies found in this midsurface feature

Visual Basic for Applications (VBA) Syntax

See [MidSurface2::GetNeutralSheetCount](#).

Remarks

Each reference surface in the midsurface feature is considered to be a sheet body. If the reference surfaces are sewn together during the creation of our midsurface feature ([IModelDoc2::InsertMidSurfaceExt](#) or [IModelDoc2::InsertMidSurfaceExt](#)), then the midsurface feature contains only one reference surface sheet body.

See Also

[IMidSurface2 Interface](#)
[IMidSurface2 Members](#)
[IMidSurface2::GetFirstNeutralSheet Method](#)
[IMidSurface2::GetFirstNeutralSheet Method](#)
[IMidSurface2::GetNextNeutralSheet Method](#)
[IMidSurface2::GetNextNeutralSheet Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetNextFace Method (IMidSurface2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface2 Interface](#) : GetNextFace Method (IMidSurface2)

Obsolete. Superseded by [IMidSurface3::GetNextFace](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNextFace( _
    ByRef FromFace1Disp As System.Object, _
    ByRef FromFace2Disp As System.Object, _
    ByRef Thickness As System.Double _
) As System.Object
```

```

Dim instance As IMidSurface2
Dim FromFace1Disp As System.Object
Dim FromFace2Disp As System.Object
Dim Thickness As System.Double
Dim value As System.Object

value = instance.GetNextFace(FromFace1Disp, FromFace2Disp, Thickness)

```

C#

```

System.object GetNextFace(
    out System.object FromFace1Disp,
    out System.object FromFace2Disp,
    out System.double Thickness
)

```

C++/CLI

```

System.Object^ GetNextFace(
    & [Out] System.Object^ FromFace1Disp,
    & [Out] System.Object^ FromFace2Disp,
    & [Out] System.double Thickness
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FromFace1Disp

[Face](#) on the original part body used in generating the neutral face

FromFace2Disp

[Face](#) on the original part body used in generating the neutral face

Thickness

Distance between the two parallel faces, FromFace1Disp and FromFace2Disp

Return Value

[Face](#) in this midsurface feature

Visual Basic for Applications (VBA) Syntax

See [MidSurface2::GetNextFace](#).

Remarks

Call [IMidSurface2::GetFirstFace](#) before calling this method to get the first neutral face.

This method returns the next neutral face in this midsurface feature along with three other items.

- The first two return values are the two faces from the original part body that were used to generate this neutral midsurface face.
- The next return value is the thickness (in meters) between the two parallel faces from the original part body.
- The last return value is the neutral face in this midsurface feature.

See Also

[IMidSurface2 Interface](#)

[IMidSurface2 Members](#)

[IMidSurface2::IGetNextFace Method](#)

[IMidSurface2::GetFaceCount Method](#)

[IMidSurface2::IGetFirstFace Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

Obsolete. Superseded by [IMidSurface3::GetNextFaceArray](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNextFaceArray( _  
    ByRef Thickness As System.Double _  
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As IMidSurface2  
Dim Thickness As System.Double  
Dim value As System.Object  
  
value = instance.GetNextFaceArray(Thickness)
```

C#

```
System.object GetNextFaceArray(  
    out System.double Thickness  
)
```

C++/CLI

```
System.Object^ GetNextFaceArray(  
& [Out] System.double Thickness  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Thickness
Thickness between the faces

Return Value

Next [face](#)

Visual Basic for Applications (VBA) Syntax

See [MidSurface2::GetNextFaceArray](#).

Remarks

A separator is needed between the front faces and back faces. Thus, a NULL always exists between the front faces and the back faces.

For example, if there are five faces in the model, then the mid-surface has five faces. To get the five faces:

- Call [IMidSurface2::GetFirstFaceArray](#) once.
- Call [IMidSurface2::GetNextFaceArray](#) four times.

At each call, the data is arranged as follows if there is one front face in the array:

[*Neutral face*], [*front face*], NULL, [*back face*]

If there are more than one front face in the array, then the data is arranged as follows:

[*Neutral face*], [*front face1*, *front face2*], NULL, [*back face1*, *back face2*]

Call [IMidSurface2::GetFirstFaceArray](#) to get the first face from the original paired faces.

See Also

[IMidSurface2 Interface](#)
[IMidSurface2 Members](#)
[IMidSurface2::GetFaceCount Method](#)
[IMidSurface2::IGetFirstFaceArray Method](#)
[IMidSurface2::IGetNextFaceArray Method](#)

Availability

GetNextFacePair Method (IMidSurface2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface2 Interface](#) : GetNextFacePair Method (IMidSurface2)

Obsolete. Superseded by [IMidSurface3::GetNextFacePair](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNextFacePair( _  
    ByRef Thickness As System.Double, _  
    ByRef PartnerFaceDisp As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface2  
Dim Thickness As System.Double  
Dim PartnerFaceDisp As System.Object  
Dim value As System.Object  
  
value = instance.GetNextFacePair(Thickness, PartnerFaceDisp)
```

C#

```
System.object GetNextFacePair(  
    out System.double Thickness,  
    out System.object PartnerFaceDisp  
)
```

C++/CLI

```
System.Object^ GetNextFacePair(  
& [Out] System.double Thickness,  
& [Out] System.Object^ PartnerFaceDisp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Thickness

Distance between these two parallel faces

PartnerFaceDisp

[Face](#) on the original part body used in generating the neutral face

Return Value

[Face](#) on the original part body used in generating the neutral face

Visual Basic for Applications (VBA) Syntax

See [MidSurface2::GetNextFacePair](#).

Remarks

The two faces returned are the two parallel faces from the original part body that were used to generate the neutral face in this midsurface feature.

Call [IMidSurface2::GetFirstFacePair](#) to get the first pair of faces used in this midsurface feature.

This method is similar to [IMidSurface2::GetNextFace](#), except this method does not return the neutral face.

See Also

[IMidSurface2 Interface](#)

[IMidSurface2 Members](#)

[IMidSurface2::IGetNextFacePair Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNextNeutralSheet Method (IMidSurface2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface2 Interface](#) : GetNextNeutralSheet Method (IMidSurface2)

Obsolete. Superseded by [IMidSurface3::GetNextNeutralSheet](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNextNeutralSheet() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface2  
Dim value As System.Object  
  
value = instance.GetNextNeutralSheet()
```

C#

```
System.object GetNextNeutralSheet()
```

C++/CLI

```
System.Object^ GetNextNeutralSheet();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next reference surface sheet [body](#) in this midsurface feature

Visual Basic for Applications (VBA) Syntax

See [MidSurface2::GetNextNeutralSheet](#).

Remarks

Each reference surface in the midsurface feature is considered a sheet body. If the reference surfaces are sewn together during the creation of the midsurface feature ([IModelDoc2::InsertMidSurfaceExt](#)), then the midsurface feature contains only one reference surface sheet body. If this is the case, then this method returns NULL. Use [IMidSurface2::GetFirstNeutralSheet](#) to get the first and only reference surface sheet body.

The sheet body returned from this method has the normal topology that you would expect to find on a body (for example, faces, edges, and so on). See the [IBody2](#) object for methods that provide access to this topology.

See Also

[IMidSurface2 Interface](#)
[IMidSurface2 Members](#)
[IMidSurface2::IGetNextNeutralSheet Method](#)
[IMidSurface2::IGetFirstNeutralSheet Method](#)
[IMidSurface2::GetNeutralSheetCount Method](#)

Availability

SolidWork s2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IEdgeGetFace Method (IMidSurface2)

[See Also](#)



Obsolete. Superseded by [IMidSurface3::IEdgeGetFace](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IEdgeGetFace(  
    ByVal EdgeInDisp As Edge _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As IMidSurface2  
Dim EdgeInDisp As Edge  
Dim value As Face2  
  
value = instance.IEdgeGetFace(EdgeInDisp)
```

C#

```
Face2 IEdgeGetFace(  
    Edge EdgeInDisp  
)
```

C++/CLI

```
Face2^ IEdgeGetFace(  
& Edge^ EdgeInDisp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EdgeInDisp
Midsurface [edge](#)

Return Value

[Face](#) on the original solid body

Visual Basic for Applications (VBA) Syntax

See [MidSurface2::IEdgeGetFace](#).

Remarks

This condition occurs when a reference surface extends to meet one of the faces on the original part body. If the edge specified does not lie on one of the original part body faces, then a NULL is returned.

This edge is not topologically related to the face returned.

See Also

[IMidSurface2 Interface](#)
[IMidSurface2 Members](#)
[IMidSurface2::EdgeGetFace Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0



Obsolete. Superseded by [IMidSurface3::IGetFirstFace](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFirstFace( _  
    ByRef FromFace1Disp As Face2, _  
    ByRef FromFace2Disp As Face2, _  
    ByRef Thickness As System.Double _  
    ) As Face2
```

Visual Basic (Usage)



```
Dim instance As IMidSurface2  
Dim FromFace1Disp As Face2  
Dim FromFace2Disp As Face2  
Dim Thickness As System.Double  
Dim value As Face2  
  
value = instance.IGetFirstFace(FromFace1Disp, FromFace2Disp, Thickness)
```

C#

```
Face2 IGetFirstFace(  
    out Face2 FromFace1Disp,  
    out Face2 FromFace2Disp,  
    out System.double Thickness  
)
```

C++/CLI

```
Face2^ IGetFirstFace(  
& [Out] Face2^ FromFace1Disp,  
& [Out] Face2^ FromFace2Disp,  
& [Out] System.double Thickness  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[FromFace1Disp](#)
[Face](#) on the original part body used in generating the neutral face
[FromFace2Disp](#)
Parallel [face](#) to [FromFace1Disp](#) on the original part body used in generating the neutral face
[Thickness](#)
Distance between the two parallel faces, [FromFace1Disp](#) and [FromFace2Disp](#)

Return Value

First [face](#) in this midsurface feature

Visual Basic for Applications (VBA) Syntax

See [MidSurface2::IGetFirstFace](#).

Remarks

- The first two return values are the two faces from the original part body that were used to generate this midsurface face.
- The next return value is the thickness (in meters) between the two parallel faces from the original part body.
- The last return value is the first face in this midsurface feature.

Use [IMidSurface2::IGetNextFace](#) to get the next neutral face in this midsurface feature.

See Also

[IMidSurface2 Interface](#)
[IMidSurface2 Members](#)
[IMidSurface2::GetFirstFace Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFirstFaceArray Method (IMidSurface2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface2 Interface](#) : IGetFirstFaceArray Method (IMidSurface2)

Obsolete. Superseded by [IMidSurface3::IGetFirstFaceArray](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFirstFaceArray( _  
    ByRef FromFrontFaceListDisp As Face2, _  
    ByRef SizeOfFrontFaceList As System.Integer, _  
    ByRef FromFaceBackListDisp As Face2, _  
    ByRef SizeOfBackFaceList As System.Integer, _  
    ByRef Thickness As System.Double _  
    ) As Face2
```

Visual Basic (Usage)



```
Dim instance As IMidSurface2  
Dim FromFrontFaceListDisp As Face2  
Dim SizeOfFrontFaceList As System.Integer  
Dim FromFaceBackListDisp As Face2  
Dim SizeOfBackFaceList As System.Integer  
Dim Thickness As System.Double  
Dim value As Face2  
  
value = instance.IGetFirstFaceArray(FromFrontFaceListDisp, SizeOfFrontFaceList,  
    FromFaceBackListDisp, SizeOfBackFaceList, Thickness)
```

C#

```
Face2 IGetFirstFaceArray(  
    out Face2 FromFrontFaceListDisp,  
    out System.int SizeOfFrontFaceList,  
    out Face2 FromFaceBackListDisp,  
    out System.int SizeOfBackFaceList,  
    out System.double Thickness  
)
```

C++/CLI

```
Face2^ IGetFirstFaceArray(  
& [Out] Face2^ FromFrontFaceListDisp,  
& [Out] System.int SizeOfFrontFaceList,  
& [Out] Face2^ FromFaceBackListDisp,  
& [Out] System.int SizeOfBackFaceList,  
& [Out] System.double Thickness  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FromFrontFaceListDisp
List of front [faces](#)
SizeOfFrontFaceList
Number of front faces
FromFaceBackListDisp
List of back [faces](#)
SizeOfBackFaceList
Number of back faces
Thickness
Thickness between the faces

Return Value

First [face](#)

Visual Basic for Applications (VBA) Syntax

See [IMidSurface2::IGetFirstFaceArray](#).

Remarks

A separator is needed between the front faces and back faces. Thus, a NULL always exists between the front faces and the back faces.

For example, if there are five faces in the model, then the mid-surface has five faces. To get the five faces:

- Call [IMidSurface2::IGetFirstFaceArray](#) once.
- Call [IMidSurface2::IGetNextFaceArray](#) four times.

At each call, the data is arranged as follows if there is one front face in the array:

[*Neutral face*], [*front face*], NULL, [*back face*]

If there are more than one front face in the array, then the data is arranged as follows:

[*Neutral face*], [*front face1*, *front face2*], NULL, [*back face1*, *back face2*]

To get the next face from the original paired faces, call [IMidSurface2::IGetNextFaceArray](#).

See Also

[IMidSurface2 Interface](#)
[IMidSurface2 Members](#)
[IMidSurface2::GetFaceCount Method](#)
[IMidSurface2::GetFirstFaceArray Method](#)
[IMidSurface2::GetNextFaceArray Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFirstFacePair Method (IMidSurface2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface2 Interface](#) : [IGetFirstFacePair Method \(IMidSurface2\)](#)

Obsolete. Superseded by [IMidSurface3::IGetFirstFacePair](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFirstFacePair( _  
    ByRef Thickness As System.Double, _  
    ByRef PartnerFaceDisp As Face2 _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As IMidSurface2  
Dim Thickness As System.Double  
Dim PartnerFaceDisp As Face2  
Dim value As Face2
```

```
value = instance.IGetFirstFacePair(Thickness, PartnerFaceDisp)
```

C#

```
Face2 IGetFirstFacePair(  
    out System.double Thickness,  
    out Face2 PartnerFaceDisp  
)
```

C++/CLI

```
Face2^ IGetFirstFacePair(  
& [Out] System.double Thickness,  
& [Out] Face2^ PartnerFaceDisp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Thickness

Distance between these two parallel faces

PartnerFaceDisp

[Face](#) on the original part body used in generating the neutral face

Return Value

[Face](#) on the original part body used in generating the neutral face

Visual Basic for Applications (VBA) Syntax

See [MidSurface2::IGetFirstFacePair](#).

Remarks

The two faces returned by this method are the two parallel faces from the original part body that were used to generate the first neutral face in this midsurface feature.

This method is similar to [IMidSurface2::IGetFirstFace](#), except this method does not return the neutral face.

Call [IMidSurface2::IGetNextFacePair](#) to get the next pair of faces in this midsurface feature.

See Also

[IMidSurface2 Interface](#)

[IMidSurface2 Members](#)

[IMidSurface2::GetFacePairCount Method](#)

[IMidSurface2::GetFirstFacePair Method](#)

[IMidSurface2::GetNextFacePair Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFirstNeutralSheet Method (IMidSurface2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface2 Interface](#) : IGetFirstNeutralSheet Method (IMidSurface2)

Obsolete. Superseded by [IMidSurface3::IGetFirstNeutralSheet](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFirstNeutralSheet() As Body2
```

Visual Basic (Usage)



```
Dim instance As IMidSurface2
```

```
Dim value As Body2
```

```
value = instance.IGetFirstNeutralSheet()
```

C#

```
Body2 IGetFirstNeutralSheet()
```

C++/CLI

```
Body2^ IGetFirstNeutralSheet();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First reference surface sheet [body](#) in this midsurface feature

Visual Basic for Applications (VBA) Syntax

See [MidSurface2::IGetFirstNeutralSheet](#).

Remarks

Each reference surface in the midsurface feature is considered to be a sheet body. If the reference surfaces are sewn together during the creation of the midsurface feature ([IModelDoc2::InsertMidSurfaceExt](#)), then the midsurface feature contains only one reference surface sheet body.

The sheet body returned from this method has the normal topology that you would expect to find on a body (for example, faces, edges, and so on). See the [IBody2](#) object for methods that provide access to this topology.

Call [IMidSurface2::IGetNextNeutralSheet](#) to get the next reference surface in this midsurface feature.

See Also

[IMidSurface2 Interface](#)
[IMidSurface2 Members](#)
[IMidSurface2::GetFirstNeutralSheet Method](#)
[IMidSurface2::GetNextNeutralSheet Method](#)
[IMidSurface2::GetNeutralSheetCount Method](#)

Availability

SOLIDWORKS 2001Pus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNextFace Method (IMidSurface2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface2 Interface](#) : IGetNextFace Method (IMidSurface2)

Obsolete. Superseded by [IMidSurface3::IGetNextFace](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNextFace( _  
    ByRef FromFace1Disp As Face2, _  
    ByRef FromFace2Disp As Face2, _  
    ByRef Thickness As System.Double _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As IMidSurface2  
Dim FromFace1Disp As Face2  
Dim FromFace2Disp As Face2  
Dim Thickness As System.Double  
Dim value As Face2
```

```
value = instance.IGetNextFace(FromFace1Disp, FromFace2Disp, Thickness)
```

C#

```

Face2 IGetNextFace(
    out Face2 FromFace1Disp,
    out Face2 FromFace2Disp,
    out System.double Thickness
)

```

C++/CLI

```

Face2^ IGetNextFace(
    & [Out] Face2^ FromFace1Disp,
    & [Out] Face2^ FromFace2Disp,
    & [Out] System.double Thickness
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FromFace1Disp

[Face](#) on the original part body used in generating the neutral face

FromFace2Disp

[Face](#) on the original part body used in generating the neutral face

Thickness

Distance between the two parallel faces, FromFace1Disp and FromFace2Disp

Return Value

[Face](#) in this midsurface feature

Visual Basic for Applications (VBA) Syntax

See [MidSurface2::IGetNextFace](#).

Remarks

Call [IMidSurface2::IGetFirstFace](#) before calling this method to get the first neutral face.

This method returns the next neutral face in this midsurface feature along with three other items.

- The first two return values are the two faces from the original part body that were used to generate this neutral midsurface face.
- The next return value is the thickness (in meters) between the two parallel faces from the original part body.
- The last return value is the neutral face in this midsurface feature.

See Also

[IMidSurface2 Interface](#)

[IMidSurface2 Members](#)

[IMidSurface2::IGetFirstFace Method](#)

[IMidSurface2::IGetFaceCount Method](#)

[IMidSurface2::IGetNextFace Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNextFaceArray Method (IMidSurface2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface2 Interface](#) : IGetNextFaceArray Method (IMidSurface2)

Obsolete. Superseded by [IMidSurface3::IGetNextFaceArray](#).

.NET Syntax

Visual Basic (Declaration)

```

Function IGetNextFaceArray( _
    ByRef FromFrontFaceListDisp As Face2, _
    ByRef SizeOfFrontFaceList As System.Integer, _
    ByRef FromFaceBackListDisp As Face2, _

```

```

ByRef SizeOfBackFaceList As System.Integer, _
ByRef Thickness As System.Double _
) As Face2

```

Visual Basic (Usage)



```

Dim instance As IMidSurface2
Dim FromFrontFaceListDisp As Face2
Dim SizeOfFrontFaceList As System.Integer
Dim FromFaceBackListDisp As Face2
Dim SizeOfBackFaceList As System.Integer
Dim Thickness As System.Double
Dim value As Face2

value = instance.IGetNextFaceArray(FromFrontFaceListDisp, SizeOfFrontFaceList,
FromFaceBackListDisp, SizeOfBackFaceList, Thickness)

```

C#

```

Face2 IGetNextFaceArray(
    out Face2 FromFrontFaceListDisp,
    out System.int SizeOfFrontFaceList,
    out Face2 FromFaceBackListDisp,
    out System.int SizeOfBackFaceList,
    out System.double Thickness
)

```

C++/CLI

```

Face2^ IGetNextFaceArray(
    & [Out] Face2^ FromFrontFaceListDisp,
    & [Out] System.int SizeOfFrontFaceList,
    & [Out] Face2^ FromFaceBackListDisp,
    & [Out] System.int SizeOfBackFaceList,
    & [Out] System.double Thickness
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FromFrontFaceListDisp

List of front [faces](#)

SizeOfFrontFaceList

Number of front faces

FromFaceBackListDisp

List of back [faces](#)

SizeOfBackFaceList

Number of back faces

Thickness

Thickness between the faces

Return Value

Next [face](#)

Visual Basic for Applications (VBA) Syntax

See [MidSurface2::IGetNextFaceArray](#).

Remarks

A separator is needed between the front faces and back faces. Thus, a NULL always exists between the front faces and the back faces.

For example, if there are five faces in the model, then the mid-surface has five faces. To get the five faces:

- Call [IMidSurface2::IGetGetFirstFaceArray](#) once.
- Call [IMidSurface2::IGetNextFaceArray](#) four times.

At each call, the data is arranged as follows if there is one front face in the array:

[*Neutral face*], [*front face*], NULL, [*back face*]

If there are more than one front face in the array, then the data is arranged as follows:

[*Neutral face*], [*front face1*, *front face2*], NULL, [*back face1*, *back face2*]

Call [IMidSurface2::IGetFirstFaceArray](#) to get the first face from the original paired faces.

See Also

[IMidSurface2 Interface](#)
[IMidSurface2 Members](#)
[IMidSurface2::GetFirstFaceArray Method](#)
[IMidSurface2::GetNextFaceArray Method](#)
[IMidSurface2::GetFaceCount Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNextFacePair Method (IMidSurface2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface2 Interface](#) : IGetNextFacePair Method (IMidSurface2)

Obsolete. Superseded by [IMidSurface3::IGetNextFacePair](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNextFacePair( _  
    ByRef Thickness As System.Double, _  
    ByRef PartnerFaceDisp As Face2 _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As IMidSurface2  
Dim Thickness As System.Double  
Dim PartnerFaceDisp As Face2  
Dim value As Face2  
  
value = instance.IGetNextFacePair(Thickness, PartnerFaceDisp)
```

C#

```
Face2 IGetNextFacePair(  
    out System.double Thickness,  
    out Face2 PartnerFaceDisp  
)
```

C++/CLI

```
Face2^ IGetNextFacePair(  
& [Out] System.double Thickness,  
& [Out] Face2^ PartnerFaceDisp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Thickness

Distance between these two parallel faces

PartnerFaceDisp

[Face](#) on the original part body used in generating the neutral face

Return Value

[Face](#) on the original part body used in generating the neutral face

Visual Basic for Applications (VBA) Syntax

See [MidSurface2::IGetNextFacePair](#).

Remarks

The two faces returned are the two parallel faces from the original part body that were used to generate the neutral face in this midsurface feature.

Call [IMidSurface2::IGetFirstFacePair](#) to get the first pair of faces used in this midsurface feature.

This method is similar to [IMidSurface2::IGetNextFace](#), except this method does not return the neutral face.

See Also

[IMidSurface2 Interface](#)
[IMidSurface2 Members](#)
[IMidSurface2::IGetFirstFacePair Method](#)
[IMidSurface2::IGetNextFacePair Method](#)
[IMidSurface2::IGetFacePairCount Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNextNeutralSheet Method (IMidSurface2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface2 Interface](#) : IGetNextNeutralSheet Method (IMidSurface2)

Obsolete. Superseded by [IMidSurface3::IGetNextNeutralSheet](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNextNeutralSheet() As Body2
```

Visual Basic (Usage)



```
Dim instance As IMidSurface2  
Dim value As Body2
```

```
value = instance.IGetNextNeutralSheet()
```

C#

```
Body2 IGetNextNeutralSheet()
```

C++/CLI

```
Body2^ IGetNextNeutralSheet();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next reference surface sheet [body](#) in this midsurface feature

Visual Basic for Applications (VBA) Syntax

See [MidSurface2::IGetNextNeutralSheet](#).

Remarks

Each reference surface in the midsurface feature is considered a sheet body. If the reference surfaces are sewn together during the creation of the midsurface feature ([IModelDoc2::InsertMidSurfaceExt](#)), then the midsurface feature contains only one reference surface sheet body. If this is the case, then this method returns NULL. Use [IMidSurface2::IGetFirstNeutralSheet](#) to get the first and only reference surface sheet body.

The sheet body returned from this method has the normal topology that you would expect to find on a body (for example, faces, edges, and so on). See the [IBody2](#) object for methods that provide access to this topology.

See Also

[IMidSurface2 Interface](#)
[IMidSurface2 Members](#)
[IMidSurface2::GetNeutralSheetCount Method](#)
[IMidSurface2::GetFirstNeutralSheet Method](#)
[IMidSurface2::GetNextNeutralSheet Method](#)

Availability

SolidWorks s2001Plus FCS, Revision Number 10.0