

SOLIDWORKS API (.NET, VBA, C#) — Reference

(161/337): IMidSurface3

SOLIDWORKS API Documentation (converted from CHM)

IMidSurface3 (Type)

IMidSurface3 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMidSurface3 Interface

Allows access to a midsurface feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IMidSurface3
```

Visual Basic (Usage)

```
Dim instance As IMidSurface3
```

C#

```
public interface IMidSurface3
```

C++/CLI

```
public interface class IMidSurface3
```

Visual Basic for Applications (VBA) Syntax

See [MidSurface3](#).

Example

- [Insert MidSurface in Component \(C#\)](#)
- [Insert MidSurface in Component \(VB.NET\)](#)
- [Insert MidSurface in Component \(VBA\)](#)
- [Get Areas of MidSurface Faces \(C#\)](#)
- [Get Areas of MidSurface Faces \(VB.NET\)](#)
- [Get Areas of MidSurface Faces \(VBA\)](#)

Accessors

- [IFeatureManager::InsertMidSurface](#)
- [IFeature::GetSpecificFeature2](#)

Access Diagram

[MidSurface3](#)

See Also

- [IMidSurface3 Members](#)
- [SolidWorks.Interop.sldworks Namespace](#)

IMidSurface3 Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMidSurface3 Interface

The following tables list the members exposed by [IMidSurface3](#).

Public Methods

Name	Description
------	-------------

	EdgeGetFace	Gets the body face on which the specified midsurface edge lies.
	GetFaceCount	Gets the number of faces in the midsurface feature.
	GetFacePairCount	Gets the number of parallel pairs of faces found in the original part body that were used to calculate the midsurface feature.
	GetFaces	Gets the faces in this midsurface feature.
	GetFirstFace	Gets the first face in this midsurface feature and three other items.
	GetFirstFaceArray	Gets the first face and the thickness between the faces.
	GetFirstFacePair	Gets the first pair of parallel faces in this midsurface feature and the thickness (in meters) between the two faces.
	GetFirstNeutralSheet	Gets the first reference surface in this midsurface feature.
	GetNeutralSheetCount	Gets the total number of reference surfaces found in this midsurface feature.
	GetNextFace	Gets the next neutral face in this midsurface feature.
	GetNextFaceArray	Gets the next face from the original paired faces and the thickness between the faces.
	GetNextFacePair	Gets the next pair of parallel faces in this midsurface feature and the thickness (in meters) between the two faces.
	GetNextNeutralSheet	Gets the next reference surface in this midsurface feature.
	IEdgeGetFace	Gets the body face on which the specified midsurface edge lies.
	IGetFaces	Gets the faces in this midsurface feature.
	IGetFirstFace	Gets the next neutral face in this midsurface feature.
	IGetFirstFaceArray	Gets the first face and the thickness between the faces.
	IGetFirstFacePair	Gets the first pair of parallel faces in this midsurface feature and the thickness (in meters) between the two faces.
	IGetFirstNeutralSheet	Gets the first reference surface in this midsurface feature.
	IGetNextFace	Gets the next neutral face in this midsurface feature.
	IGetNextFaceArray	Gets the next face from the original paired faces and the thickness between the faces.
	IGetNextFacePair	Gets the next pair of parallel faces in this midsurface feature and the thickness (in meters) between the two faces.
	IGetNextNeutralSheet	Gets the next reference surface in this midsurface feature.

[Top](#)

 See Also

[IMidSurface3 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IMidSurface3 Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IMidSurface3 Interface

For a list of all members of this type, see [IMidSurface3 members](#).

 Public Methods

Name	Description
	EdgeGetFace Gets the body face on which the specified midsurface edge lies.
	GetFaceCount Gets the number of faces in the midsurface feature.
	GetFacePairCount Gets the number of parallel pairs of faces found in the original part body that were used to calculate the midsurface feature.
	GetFaces Gets the faces in this midsurface feature.
	GetFirstFace Gets the first face in this midsurface feature and three other items.
	GetFirstFaceArray Gets the first face and the thickness between the faces.
	GetFirstFacePair Gets the first pair of parallel faces in this midsurface feature and the thickness (in meters) between the two faces.
	GetFirstNeutralSheet Gets the first reference surface in this midsurface feature.
	GetNeutralSheetCount Gets the total number of reference surfaces found in this midsurface feature.

	GetNextFace	Gets the next neutral face in this midsurface feature.
	GetNextFaceArray	Gets the next face from the original paired faces and the thickness between the faces.
	GetNextFacePair	Gets the next pair of parallel faces in this midsurface feature and the thickness (in meters) between the two faces.
	GetNextNeutralSheet	Gets the next reference surface in this midsurface feature.
	IEdgeGetFace	Gets the body face on which the specified midsurface edge lies.
	IGetFaces	Gets the faces in this midsurface feature.
	IGetFirstFace	Gets the next neutral face in this midsurface feature.
	IGetFirstFaceArray	Gets the first face and the thickness between the faces.
	IGetFirstFacePair	Gets the first pair of parallel faces in this midsurface feature and the thickness (in meters) between the two faces.
	IGetFirstNeutralSheet	Gets the first reference surface in this midsurface feature.
	IGetNextFace	Gets the next neutral face in this midsurface feature.
	IGetNextFaceArray	Gets the next face from the original paired faces and the thickness between the faces.
	IGetNextFacePair	Gets the next pair of parallel faces in this midsurface feature and the thickness (in meters) between the two faces.
	IGetNextNeutralSheet	Gets the next reference surface in this midsurface feature.

[Top](#)

See Also

[IMidSurface3 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

EdgeGetFace Method (IMidSurface3)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface3 Interface](#) : EdgeGetFace Method (IMidSurface3)

Gets the body face on which the specified midsurface edge lies.

.NET Syntax

Visual Basic (Declaration)

```
Function EdgeGetFace( _
    ByVal EdgeInDisp As System.Object _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface3
Dim EdgeInDisp As System.Object
Dim value As System.Object

value = instance.EdgeGetFace(EdgeInDisp)
```

C#

```
System.object EdgeGetFace(
    System.object EdgeInDisp
)
```

C++/CLI

```
System.Object^ EdgeGetFace(
    & System.Object^ EdgeInDisp
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EdgeInDisp
Midsurface [edge](#)

Return Value

[Face](#) on the original solid body

Visual Basic for Applications (VBA) Syntax

See [MidSurface3::EdgeGetFace](#).

Remarks

This condition occurs when a reference surface extends to meet one of the faces on the original part body. If the edge specified does not lie on one of the original part body faces, then a null is returned.

This edge is not topologically related to the face returned.

See Also

[IMidSurface3 Interface](#)
[IMidSurface3 Members](#)
[IMidSurface3::!EdgeGetFace Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFaceCount Method (IMidSurface3)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface3 Interface](#) : GetFaceCount Method (IMidSurface3)

Gets the number of faces in the midsurface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFaceCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMidSurface3  
Dim value As System.Integer  
  
value = instance.GetFaceCount()
```

C#

```
System.int GetFaceCount()
```

C++/CLI

```
System.int GetFaceCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of faces in this midsurface feature, including a null face (separator) between the front and back face, which counts as one face

Visual Basic for Applications (VBA) Syntax

See [MidSurface3::GetFaceCount](#).

Example

[Insert MidSurface in Component \(C#\)](#)
[Insert MidSurface in Component \(VB.NET\)](#)
[Insert MidSurface in Component \(VBA\)](#)

Remarks

If more than one reference surface exists in the midsurface feature, then those faces are included in the total.

See Also

[IMidSurface3 Interface](#)
[IMidSurface3 Members](#)
[IMidSurface3::GetFirstFace Method](#)
[IMidSurface3::GetFirstFaceArray Method](#)
[IMidSurface3::GetNextFace Method](#)
[IMidSurface3::GetNextFaceArray Method](#)
[IMidSurface3::IGetFirstFace Method](#)
[IMidSurface3::IGetFirstFaceArray Method](#)
[IMidSurface3::IGetNextFace Method](#)
[IMidSurface3::IGetNextFaceArray Method](#)
[IMidSurface3::GetFaces Method](#)
[IMidSurface3::IGetFaces Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFacePairCount Method (IMidSurface3)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface3 Interface](#) : GetFacePairCount Method (IMidSurface3)

Gets the number of parallel pairs of faces found in the original part body that were used to calculate the midsurface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFacePairCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMidSurface3
Dim value As System.Integer

value = instance.GetFacePairCount()
```

C#

```
System.int GetFacePairCount()
```

C++/CLI

```
System.int GetFacePairCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of parallel face pairs from the original part body

Visual Basic for Applications (VBA) Syntax

See [MidSurface3::GetFacePairCount](#).

See Also

[IMidSurface3 Interface](#)
[IMidSurface3 Members](#)
[IMidSurface3::GetFirstFacePair Method](#)
[IMidSurface3::GetNextFacePair Method](#)
[IMidSurface3::IGetFirstFacePair Method](#)
[IMidSurface3::IGetNextFacePair Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFaces Method (IMidSurface3)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface3 Interface](#) : GetFaces Method (IMidSurface3)

Gets the faces in this midsurface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFaces() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface3  
Dim value As System.Object  
  
value = instance.GetFaces()
```

C#

```
System.Object GetFaces()
```

C++/CLI

```
System.Object^ GetFaces();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [faces](#)

Visual Basic for Applications (VBA) Syntax

See [MidSurface3::GetFaces](#).

Example

[Get Areas of MidSurface Faces \(C#\)](#)
[Get Areas of MidSurface Faces \(VB.NET\)](#)
[Get Areas of MidSurface Faces \(VBA\)](#)

See Also

[IMidSurface3 Interface](#)
[IMidSurface3 Members](#)
[IMidSurface3::IGetFaces Method](#)
[IMidSurface3::GetFaceCount Method](#)
[IMidSurface3::GetFirstFace Method](#)
[IMidSurface3::GetNextFace Method](#)
[IMidSurface3::IGetFirstFace Method](#)
[IMidSurface3::IGetNextFace Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstFace Method (IMidSurface3)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface3 Interface](#) : GetFirstFace Method (IMidSurface3)

Gets the first face in this midsurface feature and three other items.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetFirstFace( _  
    ByRef FromFace1Disp As System.Object, _  
    ByRef FromFace2Disp As System.Object, _  
    ByRef Thickness As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface3  
Dim FromFace1Disp As System.Object  
Dim FromFace2Disp As System.Object  
Dim Thickness As System.Double  
Dim value As System.Object  
  
value = instance.GetFirstFace(FromFace1Disp, FromFace2Disp, Thickness)
```

C#

```
System.object GetFirstFace(  
    out System.object FromFace1Disp,  
    out System.object FromFace2Disp,  
    out System.double Thickness  
)
```

C++/CLI

```
System.Object^ GetFirstFace(  
& [Out] System.Object^ FromFace1Disp,  
& [Out] System.Object^ FromFace2Disp,  
& [Out] System.double Thickness  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FromFace1Disp
[Face](#) on the original part body used in generating the neutral face
FromFace2Disp
Parallel [face](#) to FromFace1Disp on the original part body used in generating the neutral face
Thickness
Distance between the two parallel faces, FromFace1Disp and FromFace2Disp

Return Value

First [face](#) in this midsurface feature

Visual Basic for Applications (VBA) Syntax

See [MidSurface3::GetFirstFace](#).

Remarks

- The first two return values are the two faces from the original part body that were used to generate this midsurface face.
- The next return value is the thickness (in meters) between the two parallel faces from the original part body.
- The last return value is the first face in this midsurface feature.

Use [IMidSurface3::GetNextFace](#) to get the next neutral face in this midsurface feature.

See Also

[IMidSurface3 Interface](#)
[IMidSurface3 Members](#)
[IMidSurface3::GetFaceCount Method](#)
[IMidSurface3::GetNextFace Method](#)
[IMidSurface3::GetFirstFace Method](#)
[IMidSurface3::GetNextFace Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstFaceArray Method (IMidSurface3)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface3 Interface](#) : GetFirstFaceArray Method (IMidSurface3)

Gets the first face and the thickness between the faces.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstFaceArray( _  
    ByRef Thickness As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface3  
Dim Thickness As System.Double  
Dim value As System.Object  
  
value = instance.GetFirstFaceArray(Thickness)
```

C#

```
System.object GetFirstFaceArray(  
    out System.double Thickness  
)
```

C++/CLI

```
System.Object^ GetFirstFaceArray(  
& [Out] System.double Thickness  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Thickness
Thickness between the faces

Return Value

First [face](#)

Visual Basic for Applications (VBA) Syntax

See [MidSurface3::GetFirstFaceArray](#).

Remarks

A separator is needed between the front faces and back faces. Thus, a NULL always exists between the front and back faces.

For example, if there are five faces in the model, then the mid-surface has five faces. To get the five faces:

- Call [IMidSurface3::GetFirstFaceArray](#) once.
- Call [IMidSurface3::GetNextFaceArray](#) four times.

At each call, the data is arranged as follows if there is one front face in the array:

[*Neutral face*], [*front face*], NULL, [*back face*]

If there are more than one front face in the array, then the data is arranged as follows:

[*Neutral face*], [*front face1*, *front face2*], NULL, [*back face1*, *back face2*]

To get the next face from the original paired faces, call [IMidSurface3::GetNextFaceArray](#).

See Also

[IMidSurface3 Interface](#)
[IMidSurface3 Members](#)
[IMidSurface3::GetFaceCount Method](#)
[IMidSurface3::IGetFirstFaceArray Method](#)
[IMidSurface3::IGetNextFaceArray Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstFacePair Method (IMidSurface3)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface3 Interface](#) : GetFirstFacePair Method (IMidSurface3)

Gets the first pair of parallel faces in this midsurface feature and the thickness (in meters) between the two faces.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstFacePair( _  
    ByRef Thickness As System.Double, _  
    ByRef PartnerFaceDisp As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface3  
Dim Thickness As System.Double  
Dim PartnerFaceDisp As System.Object  
Dim value As System.Object  
  
value = instance.GetFirstFacePair(Thickness, PartnerFaceDisp)
```

C#

```
System.object GetFirstFacePair(  
    out System.double Thickness,  
    out System.object PartnerFaceDisp  
)
```

C++/CLI

```
System.Object^ GetFirstFacePair(  
& [Out] System.double Thickness,  
& [Out] System.Object^ PartnerFaceDisp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Thickness

Distance between these two parallel faces

PartnerFaceDisp

[Face](#) on the original part body used in generating the neutral face

Return Value

[Face](#) on the original part body used in generating the neutral face

Visual Basic for Applications (VBA) Syntax

See [MidSurface3::GetFirstFacePair](#).

Remarks

The two faces returned by this method are the two parallel faces from the original part body that were used to generate the first neutral face in this midsurface feature.

This method is similar to [IMidSurface3::GetFirstFace](#), except this method does not return the neutral face.

Call [IMidSurface3::GetNextFacePair](#) to get the next pair of faces in this midsurface feature.

See Also

[IMidSurface3 Interface](#)
[IMidSurface3 Members](#)
[IMidSurface3::IGetFirstFacePair Method](#)
[IMidSurface3::GetFacePairCount Method](#)
[IMidSurface3::GetNextFacePair Method](#)
[IMidSurface3::IGetNextFacePair Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFirstNeutralSheet Method (IMidSurface3)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface3 Interface](#) : GetFirstNeutralSheet Method (IMidSurface3)

Gets the first reference surface in this midsurface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFirstNeutralSheet() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface3  
Dim value As System.Object  
  
value = instance.GetFirstNeutralSheet()
```

C#

```
System.object GetFirstNeutralSheet()
```

C++/CLI

```
System.Object^ GetFirstNeutralSheet();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First reference surface sheet [body](#) in this midsurface feature

Visual Basic for Applications (VBA) Syntax

See [MidSurface3::GetFirstNeutralSheet](#).

Remarks

Each reference surface in the midsurface feature is considered to be a sheet body. If the reference surfaces are sewn together during the creation of the midsurface feature ([IModelDoc2::InsertMidSurfaceExt](#)), then the midsurface feature contains only one reference surface sheet body.

The sheet body returned from this method has the normal topology that you would expect to find on a body (for example, faces, edges, and so on). See the [IBody2](#) object for methods that provide access to this topology.

Call [IMidSurface3::GetNextNeutralSheet](#) to get the next reference surface in this midsurface feature.

See Also

[IMidSurface3 Interface](#)
[IMidSurface3 Members](#)
[IMidSurface3::IGetNextNeutralSheet Method](#)
[IMidSurface3::GetNeutralSheetCount Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNeutralSheetCount Method (IMidSurface3)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface3 Interface](#) : GetNeutralSheetCount Method (IMidSurface3)

Gets the total number of reference surfaces found in this midsurface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNeutralSheetCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IMidSurface3  
Dim value As System.Integer  
  
value = instance.GetNeutralSheetCount()
```

C#

```
System.int GetNeutralSheetCount()
```

C++/CLI

```
System.int GetNeutralSheetCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of reference surface sheet bodies found in this midsurface feature

Visual Basic for Applications (VBA) Syntax

See [MidSurface3::GetNeutralSheetCount](#).

Remarks

Each reference surface in the midsurface feature is considered to be a sheet body. If the reference surfaces are sewn together during the creation of our midsurface feature, [IFeatureManager::InsertMidSurface](#), then the midsurface feature contains only one reference surface sheet body.

See Also

[IMidSurface3 Interface](#)
[IMidSurface3 Members](#)
[IMidSurface3::GetFirstNeutralSheet Method](#)
[IMidSurface3::GetNextNeutralSheet Method](#)
[IMidSurface3::IGetFirstNeutralSheet Method](#)
[IMidSurface3::IGetNextNeutralSheet Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNextFace Method (IMidSurface3)

[See Also](#)



Gets the next neutral face in this midsurface feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetNextFace( _  
    ByRef FromFace1Disp As System.Object, _  
    ByRef FromFace2Disp As System.Object, _  
    ByRef Thickness As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface3  
Dim FromFace1Disp As System.Object  
Dim FromFace2Disp As System.Object  
Dim Thickness As System.Double  
Dim value As System.Object  
  
value = instance.GetNextFace(FromFace1Disp, FromFace2Disp, Thickness)
```

C#

```
System.object GetNextFace(  
    out System.object FromFace1Disp,  
    out System.object FromFace2Disp,  
    out System.double Thickness  
)
```

C++/CLI

```
System.Object^ GetNextFace(  
& [Out] System.Object^ FromFace1Disp,  
& [Out] System.Object^ FromFace2Disp,  
& [Out] System.double Thickness  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[FromFace1Disp](#)
[Face](#) on the original part body used in generating the neutral face
[FromFace2Disp](#)
[Face](#) on the original part body used in generating the neutral face
[Thickness](#)
Distance between the two parallel faces, FromFace1Disp and FromFace2Disp

Return Value

[Face](#) in this midsurface feature

Visual Basic for Applications (VBA) Syntax

See [MidSurface3::GetNextFace](#).

Remarks

Call [IMidSurface3::GetFirstFace](#) before calling this method to get the first neutral face.

This method returns the next neutral face in this midsurface feature along with three other items.

- The first two return values are the two faces from the original part body that were used to generate this neutral midsurface face.
- The next return value is the thickness (in meters) between the two parallel faces from the original part body.
- The last return value is the neutral face in this midsurface feature.

See Also

[IMidSurface3 Interface](#)
[IMidSurface3 Members](#)
[IMidSurface3::GetFaceCount Method](#)
[IMidSurface3::IGetFirstFace Method](#)
[IMidSurface3::IGetNextFace Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNextFaceArray Method (IMidSurface3)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface3 Interface](#) : GetNextFaceArray Method (IMidSurface3)

Gets the next face from the original paired faces and the thickness between the faces.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNextFaceArray( _  
    ByRef Thickness As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface3  
Dim Thickness As System.Double  
Dim value As System.Object  
  
value = instance.GetNextFaceArray(Thickness)
```

C#

```
System.object GetNextFaceArray(  
    out System.double Thickness  
)
```

C++/CLI

```
System.Object^ GetNextFaceArray(  
    & [Out] System.double Thickness  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Thickness
Thickness between the faces

Return Value

Next [face](#)

Visual Basic for Applications (VBA) Syntax

See [MidSurface3::GetNextFaceArray](#).

Remarks

A separator is needed between the front faces and back faces. Thus, a NULL always exists between the front faces and the back faces.

For example, if there are five faces in the model, then the mid-surface has five faces. To get the five faces:

- Call [IMidSurface3::GetFirstFaceArray](#) once.
- Call [IMidSurface2::GetNextFaceArray](#) four times.

At each call, the data is arranged as follows if there is one front face in the array:

[*Neutral face*], [*front face*], NULL, [*back face*]

If there are more than one front face in the array, then the data is arranged as follows:

[*Neutral face*], [*front face1*, *front face2*], NULL, [*back face1*, *back face2*]

Call [IMidSurface3::GetFirstFaceArray](#) to get the first face from the original paired faces.

See Also

[IMidSurface3 Interface](#)
[IMidSurface3 Members](#)
[IMidSurface3::GetFaceCount Method](#)
[IMidSurface3::GetFirstFaceArray Method](#)
[IMidSurface3::IGetFirstFaceArray Method](#)
[IMidSurface3::IGetNextFaceArray Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetNextFacePair Method (IMidSurface3)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface3 Interface](#) : [GetNextFacePair Method \(IMidSurface3\)](#)

Gets the next pair of parallel faces in this midsurface feature and the thickness (in meters) between the two faces.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNextFacePair( _  
    ByRef Thickness As System.Double, _  
    ByRef PartnerFaceDisp As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface3  
Dim Thickness As System.Double  
Dim PartnerFaceDisp As System.Object  
Dim value As System.Object  
  
value = instance.GetNextFacePair(Thickness, PartnerFaceDisp)
```

C#

```
System.object GetNextFacePair(  
    out System.double Thickness,  
    out System.object PartnerFaceDisp  
)
```

C++/CLI

```
System.Object^ GetNextFacePair(  
& [Out] System.double Thickness,  
& [Out] System.Object^ PartnerFaceDisp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Thickness

Distance between these two parallel faces

PartnerFaceDisp

[Face](#) on the original part body used in generating the neutral face

Return Value

[Face](#) on the original part body used in generating the neutral face

Visual Basic for Applications (VBA) Syntax

See [MidSurface3::GetNextFacePair](#).

Remarks

The two faces returned are the two parallel faces from the original part body that were used to generate the neutral face in this midsurface feature.

Call [IMidSurface3::GetFirstFacePair](#) to get the first pair of faces used in this midsurface feature.

This method is similar to [IMidSurface3::GetNextFace](#), except this method does not return the neutral face.

See Also

[IMidSurface3 Interface](#)
[IMidSurface3 Members](#)
[IMidSurface3::GetFirstFacePair Method](#)
[IMidSurface3::GetFacePairCount Method](#)
[IMidSurface3::GetNextFacePair Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNextNeutralSheet Method (IMidSurface3)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface3 Interface](#) : GetNextNeutralSheet Method (IMidSurface3)

Gets the next reference surface in this midsurface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNextNeutralSheet() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IMidSurface3  
Dim value As System.Object  
  
value = instance.GetNextNeutralSheet()
```

C#

```
System.object GetNextNeutralSheet()
```

C++/CLI

```
System.Object^ GetNextNeutralSheet();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next reference surface sheet [body](#) in this midsurface feature

Visual Basic for Applications (VBA) Syntax

See [MidSurface3::GetNextNeutralSheet](#).

Remarks

Each reference surface in the midsurface feature is considered a sheet body. If the reference surfaces are sewn together during the creation of the midsurface feature ([IFeatureManager::InsertMidSurface](#)), then the midsurface feature contains only one reference surface sheet body. If this is the case, then this method returns NULL. Use [IMidSurface2::GetFirstNeutralSheet](#) to get the first and only reference surface sheet body.

The sheet body returned from this method has the normal topology that you would expect to find on a body (for example, faces, edges, and so on). See the [IBody2](#) object for methods that provide access to this topology.

See Also

[IMidSurface3 Interface](#)
[IMidSurface3 Members](#)
[IMidSurface3::GetNeutralSheetCount Method](#)
[IMidSurface3::IGetFirstNeutralSheet Method](#)
[IMidSurface3::IGetNextNeutralSheet Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IEdgeGetFace Method (IMidSurface3)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface3 Interface](#) : IEdgeGetFace Method (IMidSurface3)

Gets the body face on which the specified midsurface edge lies.

.NET Syntax

Visual Basic (Declaration)

```
Function IEdgeGetFace(  
    ByVal EdgeInDisp As Edge _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As IMidSurface3  
Dim EdgeInDisp As Edge  
Dim value As Face2
```

```
value = instance.IEdgeGetFace(EdgeInDisp)
```

C#

```
Face2 IEdgeGetFace(  
    Edge EdgeInDisp  
)
```

C++/CLI

```
Face2^ IEdgeGetFace(  
& Edge^ EdgeInDisp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EdgeInDisp
Midsurface [edge](#)

Return Value

[Face](#) on the original solid body

Visual Basic for Applications (VBA) Syntax

See [MidSurface3::IEdgeGetFace](#).

Remarks

This condition occurs when a reference surface extends to meet one of the faces on the original part body. If the edge specified does not lie on one of the original part body faces, then a NULL is returned.

This edge is not topologically related to the face returned.

See Also

[IMidSurface3 Interface](#)
[IMidSurface3 Members](#)
[IMidSurface3::EdgeGetFace Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFaces Method (IMidSurface3)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface3 Interface](#) : IGetFaces Method (IMidSurface3)

Gets the faces in this midsurface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFaces( _  
    ByVal NumFaces As System.Integer _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As IMidSurface3  
Dim NumFaces As System.Integer  
Dim value As Face2  
  
value = instance.IGetFaces(NumFaces)
```

C#

```
Face2 IGetFaces(  
    System.int NumFaces  
)
```

C++/CLI

```
Face2^ IGetFaces(  
& System.int NumFaces  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumFaces
Number of faces

Return Value

- in-process, unmanaged C++: Pointer to an array of [faces](#)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IMidSurface3::GetFaceCount](#) to get NumFaces.

See Also

[IMidSurface3 Interface](#)
[IMidSurface3 Members](#)
[IMidSurface3::GetFaces Method](#)
[IMidSurface3::GetFirstFace Method](#)
[IMidSurface3::GetNextFace Method](#)
[IMidSurface3::IGetFirstFace Method](#)
[IMidSurface3::IGetNextFace Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFirstFace Method (IMidSurface3)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface3 Interface](#) : IGetFirstFace Method (IMidSurface3)

Gets the next neutral face in this midsurface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFirstFace( _  
    ByRef FromFace1Disp As Face2, _  
    ByRef FromFace2Disp As Face2, _  
    ByRef Thickness As System.Double _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As IMidSurface3  
Dim FromFace1Disp As Face2  
Dim FromFace2Disp As Face2  
Dim Thickness As System.Double  
Dim value As Face2  
  
value = instance.IGetFirstFace(FromFace1Disp, FromFace2Disp, Thickness)
```

C#

```
Face2 IGetFirstFace(  
    out Face2 FromFace1Disp,  
    out Face2 FromFace2Disp,  
    out System.double Thickness  
)
```

C++/CLI

```
Face2^ IGetFirstFace(  
& [Out] Face2^ FromFace1Disp,  
& [Out] Face2^ FromFace2Disp,  
& [Out] System.double Thickness  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FromFace1Disp

[Face](#) on the original part body used in generating the neutral face

FromFace2Disp

Parallel [face](#) to FromFace1Disp on the original part body used in generating the neutral face

Thickness

Distance between the two parallel faces, FromFace1Disp and FromFace2Disp

Return Value

First [face](#) in this midsurface feature

Visual Basic for Applications (VBA) Syntax

See [MidSurface3::IGetFirstFace](#).

Remarks

- The first two return values are the two faces from the original part body that were used to generate this midsurface face.
- The next return value is the thickness (in meters) between the two parallel faces from the original part body.

- The last return value is the first face in this midsurface feature.
- Use [IMidSurface3::IGetNextFace](#) to get the next neutral face in this midsurface feature.

See Also

[IMidSurface3 Interface](#)
[IMidSurface3 Members](#)
[IMidSurface3::GetFaceCount Method](#)
[IMidSurface3::GetFirstFace Method](#)
[IMidSurface3::GetNextFace Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFirstFaceArray Method (IMidSurface3)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface3 Interface](#) : IGetFirstFaceArray Method (IMidSurface3)

Gets the first face and the thickness between the faces.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFirstFaceArray( _  
    ByRef FromFrontFaceListDisp As Face2, _  
    ByRef SizeOfFrontFaceList As System.Integer, _  
    ByRef FromFaceBackListDisp As Face2, _  
    ByRef SizeOfBackFaceList As System.Integer, _  
    ByRef Thickness As System.Double _  
    ) As Face2
```

Visual Basic (Usage)



```
Dim instance As IMidSurface3  
Dim FromFrontFaceListDisp As Face2  
Dim SizeOfFrontFaceList As System.Integer  
Dim FromFaceBackListDisp As Face2  
Dim SizeOfBackFaceList As System.Integer  
Dim Thickness As System.Double  
Dim value As Face2  
  
value = instance.IGetFirstFaceArray(FromFrontFaceListDisp, SizeOfFrontFaceList,  
    FromFaceBackListDisp, SizeOfBackFaceList, Thickness)
```

C#

```
Face2 IGetFirstFaceArray(  
    out Face2 FromFrontFaceListDisp,  
    out System.int SizeOfFrontFaceList,  
    out Face2 FromFaceBackListDisp,  
    out System.int SizeOfBackFaceList,  
    out System.double Thickness  
)
```

C++/CLI

```
Face2^ IGetFirstFaceArray(  
& [Out] Face2^ FromFrontFaceListDisp,  
& [Out] System.int SizeOfFrontFaceList,  
& [Out] Face2^ FromFaceBackListDisp,  
& [Out] System.int SizeOfBackFaceList,  
& [Out] System.double Thickness  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FromFrontFaceListDisp

- in-process, unmanaged C++: Pointer to an array of front [faces](#)

• VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

SizeOfFrontFaceList

Number of front faces

FromFaceBackListDisp

- in-process, unmanaged C++: Pointer to an array of back [faces](#)

• VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

SizeOfBackFaceList

Number of back faces

Thickness

Thickness between the faces

Return Value

First [face](#)

Remarks

A separator is needed between the front faces and back faces. Thus, a NULL always exists between the front faces and the back faces.

For example, if there are five faces in the model, then the mid-surface has five faces. To get the five faces:

- Call `IMidSurface3::IGetFirstFaceArray` once.
- Call [IMidSurface3::IGetNextFaceArray](#) four times.

At each call, the data is arranged as follows if there is one front face in the array:

[*Neutral face*], [*front face*], NULL, [*back face*]

If there are more than one front face in the array, then the data is arranged as follows:

[*Neutral face*], [*front face1*, *front face2*], NULL, [*back face1*, *back face2*]

To get the next face from the original paired faces, call `IMidSurface3::IGetNextFaceArray`.

See Also

[IMidSurface3 Interface](#)

[IMidSurface3 Members](#)

[IMidSurface3::GetFaceCount Method](#)

[IMidSurface3::GetFirstFaceArray Method](#)

[IMidSurface3::GetNextFaceArray Method](#)

[IMidSurface3::IGetNextFaceArray Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFirstFacePair Method (IMidSurface3)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface3 Interface](#) : IGetFirstFacePair Method (IMidSurface3)

Gets the first pair of parallel faces in this midsurface feature and the thickness (in meters) between the two faces.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFirstFacePair( _  
    ByRef Thickness As System.Double, _  
    ByRef PartnerFaceDisp As Face2 _  
) As Face2
```

Visual Basic (Usage)

```
Dim instance As IMidSurface3  
Dim Thickness As System.Double  
Dim PartnerFaceDisp As Face2  
Dim value As Face2
```

```
value = instance.IGetFirstFacePair(Thickness, PartnerFaceDisp)
```

C#

```
Face2 IGetFirstFacePair(  
    out System.double Thickness,  
    out Face2 PartnerFaceDisp  
)
```

C++/CLI

```
Face2^ IGetFirstFacePair(  
& [Out] System.double Thickness,  
& [Out] Face2^ PartnerFaceDisp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Thickness

Distance between these two parallel faces

PartnerFaceDisp

[Face](#) on the original part body used in generating the neutral face

Return Value

[Face](#) on the original part body used in generating the neutral face

Visual Basic for Applications (VBA) Syntax

See [MidSurface3::IGetFirstFacePair](#).

Remarks

The two faces returned by this method are the two parallel faces from the original part body that were used to generate the first neutral face in this midsurface feature.

This method is similar to [IMidSurface3::IGetFirstFace](#), except this method does not return the neutral face.

Call [IMidSurface3::IGetNextFacePair](#) to get the next pair of faces in this midsurface feature.

See Also

[IMidSurface3 Interface](#)
[IMidSurface3 Members](#)
[IMidSurface3::GetFacePairCount Method](#)
[IMidSurface3::GetFirstFacePair Method](#)
[IMidSurface3::GetNextFacePair Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFirstNeutralSheet Method (IMidSurface3)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface3 Interface](#) : IGetFirstNeutralSheet Method (IMidSurface3)

Gets the first reference surface in this midsurface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFirstNeutralSheet() As Body2
```

Visual Basic (Usage)



```
Dim instance As IMidSurface3  
Dim value As Body2
```

```
value = instance.IGetFirstNeutralSheet()
```

C#

```
Body2 IGetFirstNeutralSheet()
```

C++/CLI

```
Body2^ IGetFirstNeutralSheet();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

First reference surface sheet [body](#) in this midsurface feature

Visual Basic for Applications (VBA) Syntax

See [MidSurface3::IGetFirstNeutralSheet](#).

Remarks

Each reference surface in the midsurface feature is considered to be a sheet body. If the reference surfaces are sewn together during the creation of the midsurface feature ([IFeatureManager::InsertMidSurface](#)), then the midsurface feature contains only one reference surface sheet body.

The sheet body returned from this method has the normal topology that you would expect to find on a body (for example, faces, edges, and so on). See the [IBody2](#) object for methods that provide access to this topology.

Call [IMidSurface3::IGetNextNeutralSheet](#) to get the next reference surface in this midsurface feature.

See Also

[IMidSurface3 Interface](#)
[IMidSurface3 Members](#)
[IMidSurface3::GetFirstNeutralSheet Method](#)
[IMidSurface3::GetNeutralSheetCount Method](#)
[IMidSurface3::GetNextNeutralSheet Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNextFace Method (IMidSurface3)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface3 Interface](#) : IGetNextFace Method (IMidSurface3)

Gets the next neutral face in this midsurface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNextFace( _  
    ByRef FromFace1Disp As Face2, _  
    ByRef FromFace2Disp As Face2, _  
    ByRef Thickness As System.Double _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As IMidSurface3  
Dim FromFace1Disp As Face2  
Dim FromFace2Disp As Face2  
Dim Thickness As System.Double  
Dim value As Face2
```

```
value = instance.IGetNextFace(FromFace1Disp, FromFace2Disp, Thickness)
```

C#

```

Face2 IGetNextFace(
    out Face2 FromFace1Disp,
    out Face2 FromFace2Disp,
    out System.double Thickness
)

```

C++/CLI

```

Face2^ IGetNextFace(
    & [Out] Face2^ FromFace1Disp,
    & [Out] Face2^ FromFace2Disp,
    & [Out] System.double Thickness
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[FromFace1Disp](#)
[Face](#) on the original part body used in generating the neutral face
[FromFace2Disp](#)
[Face](#) on the original part body used in generating the neutral face
[Thickness](#)
 Distance between the two parallel faces, FromFace1Disp and FromFace2Disp

Return Value

[Face](#) in this midsurface feature

Visual Basic for Applications (VBA) Syntax

See [MidSurface3::IGetNextFace](#).

Remarks

Call [IMidSurface3::IGetFirstFace](#) before calling this method to get the first neutral face.

This method returns the next neutral face in this midsurface feature along with three other items.

- The first two return values are the two faces from the original part body that were used to generate this neutral midsurface face.
- The next return value is the thickness (in meters) between the two parallel faces from the original part body.
- The last return value is the neutral face in this midsurface feature.

See Also

[IMidSurface3 Interface](#)
[IMidSurface3 Members](#)
[IMidSurface3::GetFirstFace Method](#)
[IMidSurface3::GetNextFace Method](#)
[IMidSurface3::GetFaceCount Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNextFaceArray Method (IMidSurface3)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface3 Interface](#) : IGetNextFaceArray Method (IMidSurface3)

Gets the next face from the original paired faces and the thickness between the faces.

Visual Basic Syntax

Visual Basic (Declaration)

```

Function IGetNextFaceArray( _
    ByRef FromFrontFaceListDisp As Face2, _
    ByRef SizeOfFrontFaceList As System.Integer, _
    ByRef FromFaceBackListDisp As Face2, _

```

```

ByRef SizeOfBackFaceList As System.Integer, _
ByRef Thickness As System.Double _
) As Face2

```

Visual Basic (Usage)



```

Dim instance As IMidSurface3
Dim FromFrontFaceListDisp As Face2
Dim SizeOfFrontFaceList As System.Integer
Dim FromFaceBackListDisp As Face2
Dim SizeOfBackFaceList As System.Integer
Dim Thickness As System.Double
Dim value As Face2

value = instance.IGetNextFaceArray(FromFrontFaceListDisp, SizeOfFrontFaceList,
FromFaceBackListDisp, SizeOfBackFaceList, Thickness)

```

C#

```

Face2 IGetNextFaceArray(
    out Face2 FromFrontFaceListDisp,
    out System.int SizeOfFrontFaceList,
    out Face2 FromFaceBackListDisp,
    out System.int SizeOfBackFaceList,
    out System.double Thickness
)

```

C++/CLI

```

Face2^ IGetNextFaceArray(
    & [Out] Face2^ FromFrontFaceListDisp,
    & [Out] System.int SizeOfFrontFaceList,
    & [Out] Face2^ FromFaceBackListDisp,
    & [Out] System.int SizeOfBackFaceList,
    & [Out] System.double Thickness
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FromFrontFaceListDisp

- in-process, unmanaged C++: Pointer to an array of front [faces](#)

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

SizeOfFrontFaceList

Number of front faces

FromFaceBackListDisp

- in-process, unmanaged C++: Pointer to an array of back [faces](#)

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

SizeOfBackFaceList

Number of back faces

Thickness

Thickness between the faces

Return Value

Next [face](#)

Remarks

A separator is needed between the front faces and back faces. Thus, a NULL always exists between the front faces and the back faces.

For example, if there are five faces in the model, then the mid-surface has five faces. To get the five faces:

- Call [IMidSurface3::IGetFirstFaceArray](#) once.
- Call [IMidSurface3::IGetNextFaceArray](#) four times.

At each call, the data is arranged as follows if there is one front face in the array:

[*Neutral face*], [*front face*], NULL, [*back face*]

If there are more than one front face in the array, then the data is arranged as follows:

[*Neutral face*], [*front face1*, *front face2*], NULL, [*back face1*, *back face2*]

Call [IMidSurface3::IGetFirstFaceArray](#) to get the first face from the original paired faces.

See Also

[IMidSurface3 Interface](#)
[IMidSurface3 Members](#)
[IMidSurface3::GetFaceCount Method](#)
[IMidSurface3::GetFirstFaceArray Method](#)
[IMidSurface3::GetNextFaceArray Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNextFacePair Method (IMidSurface3)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface3 Interface](#) : IGetNextFacePair Method (IMidSurface3)

Gets the next pair of parallel faces in this midsurface feature and the thickness (in meters) between the two faces.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNextFacePair( _  
    ByRef Thickness As System.Double, _  
    ByRef PartnerFaceDisp As Face2 _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As IMidSurface3  
Dim Thickness As System.Double  
Dim PartnerFaceDisp As Face2  
Dim value As Face2  
  
value = instance.IGetNextFacePair(Thickness, PartnerFaceDisp)
```

C#

```
Face2 IGetNextFacePair(  
    out System.double Thickness,  
    out Face2 PartnerFaceDisp  
)
```

C++/CLI

```
Face2^ IGetNextFacePair(  
& [Out] System.double Thickness,  
& [Out] Face2^ PartnerFaceDisp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Thickness
Distance between these two parallel faces
PartnerFaceDisp
[Face](#) on the original part body used in generating the neutral face

Return Value

[Face](#) on the original part body used in generating the neutral face

Visual Basic for Applications (VBA) Syntax

See [MidSurface3::IGetNextFacePair](#).

Remarks

The two faces returned are the two parallel faces from the original part body that were used to generate the neutral face in this midsurface feature.

Call [IMidSurface3::IGetFirstFacePair](#) to get the first pair of faces used in this midsurface feature.

This method is similar to [IMidSurface3::IGetNextFace](#), except this method does not return the neutral face.

See Also

[IMidSurface3 Interface](#)
[IMidSurface3 Members](#)
[IMidSurface3::GetFacePairCount Method](#)
[IMidSurface3::GetFirstFacePair Method](#)
[IMidSurface3::GetNextFacePair Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNextNeutralSheet Method (IMidSurface3)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IMidSurface3 Interface](#) : IGetNextNeutralSheet Method (IMidSurface3)

Gets the next reference surface in this midsurface feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNextNeutralSheet() As Body2
```

Visual Basic (Usage)



```
Dim instance As IMidSurface3  
Dim value As Body2
```

```
value = instance.IGetNextNeutralSheet()
```

C#

```
Body2 IGetNextNeutralSheet()
```

C++/CLI

```
Body2^ IGetNextNeutralSheet();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next reference surface sheet [body](#) in this midsurface feature

Visual Basic for Applications (VBA) Syntax

See [MidSurface3::IGetNextNeutralSheet](#).

Remarks

Each reference surface in the midsurface feature is considered a sheet body. If the reference surfaces are sewn together during the creation of the midsurface feature ([IFeatureManager::InsertMidSurface](#)), then the midsurface feature contains only one reference surface sheet body. If this is the case, then this method returns NULL. Use [IMidSurface3::IGetFirstNeutralSheet](#) to get the first and only reference surface sheet body.

The sheet body returned from this method has the normal topology that you would expect to find on a body (for example, faces, edges, and so on). See the [IBody2](#) object for methods that provide access to this topology.

See Also

[IMidSurface3 Interface](#)
[IMidSurface3 Members](#)
[IMidSurface3::GetFirstNeutralSheet Method](#)
[IMidSurface3::GetNeutralSheetCount Method](#)
[IMidSurface3::GetNextNeutralSheet Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0